

# TTH300

## Head-mount temperature transmitter



Temperature transmitter for all communications protocols. Redundancy thanks to two inputs.

### Measurement made easy

TTH300

### Introduction

The TTH300 is available with the HART, PROFIBUS PA and FOUNDATION Fieldbus communications protocols.

The transmitter has global approvals for explosion protection up to zone 0.

The TTH300 implements various NAMUR recommendations, including NE 89 and NE 107.

Safety-relevant applications up to SIL 3 (redundant) are supported in accordance with IEC 61508.

### Additional Information

Additional documentation on TTH300 is available for download free of charge at [www.abb.com/temperature](http://www.abb.com/temperature). Alternatively simply scan this code:



## Table of contents

<b>1 Safety.....</b>	<b>4</b>	<b>6 Installation.....</b>	<b>18</b>
General information and instructions.....	4	Safety instructions.....	18
Warnings.....	4	Ambient conditions.....	18
Intended use.....	5	Ambient temperature.....	18
Improper use.....	5	Transport- / Storage temperature.....	18
Warranty provisions.....	5	Climate class in accordance with DIN EN 60654-1.....	18
Cyber security disclaimer.....	5	Vibration resistance in accordance with IEC 60068-2-6.....	18
Software downloads.....	5	Shock resistance in accordance with IEC 60068-2-27.....	18
Manufacturer's address.....	5	IP rating.....	18
Service address.....	5	Installation options.....	18
<b>2 Use in potentially explosive atmospheres in accordance with ATEX and IECEx.....</b>	<b>6</b>	Installation on the measuring inset.....	18
Ex marking.....	6	Installation in the cover of the connection head.....	19
Transmitter.....	6	Installation on the top-hat rail.....	19
LCD indicator.....	6	Installing / removing the optional LCD indicator.....	19
Temperature data.....	7	Disassembling the LCD indicator.....	19
Transmitter.....	7	Installing the LCD indicator.....	19
LCD indicator.....	7	Rotating the LCD indicator.....	19
Electrical data.....	7	<b>7 Electrical connections.....</b>	<b>20</b>
Transmitter.....	7	Safety instructions.....	20
LCD indicator.....	8	Protection of the transmitter from damage caused by highly energetic electric interferences.....	20
Installation instructions.....	9	Conductor material.....	21
ATEX / IECEx.....	9	Terminal assignment.....	22
IP protection rating of housing.....	9	Electrical data for inputs and outputs.....	24
Electrical connections.....	9	Input - resistance thermometer / resistances.....	24
Commissioning.....	12	Input - thermocouples / voltages.....	24
Operating instructions.....	12	Output – HART®.....	25
Protection against electrostatic discharges.....	12	Output – PROFIBUS PA®.....	25
<b>3 Use in potentially explosive atmospheres in accordance with cFMus, FM and CSA.....</b>	<b>13</b>	Output – FOUNDATION Fieldbus®.....	26
Transmitter Ex marking cFMus.....	13	Power supply.....	26
Transmitter Ex marking FM / CSA.....	13	Power supply – HART®.....	26
LCD indicator Ex marking.....	14	Power supply – PROFIBUS / FOUNDATION Fieldbus.....	27
Installation instructions.....	15	<b>8 Commissioning.....</b>	<b>28</b>
IP protection rating of housing.....	15	General.....	28
Electrical connections.....	15	Checks prior to commissioning.....	28
Commissioning.....	15	Communication.....	28
Operating instructions.....	15	HART® Communication.....	28
Protection against electrostatic discharges.....	15	PROFIBUS® Communication.....	29
<b>4 Product identification.....</b>	<b>16</b>	FOUNDATION Fieldbus® Communication.....	30
Name plate.....	16	Basic Setup.....	30
<b>5 Transport and storage.....</b>	<b>17</b>		
Inspection.....	17		
Transporting the device.....	17		
Storing the device.....	17		
Ambient conditions.....	17		
Returning devices.....	17		

<b>9</b>	<b>Operation</b> .....	<b>31</b>
	Safety instructions.....	31
	Hardware settings .....	31
	Devices with HART® from HW-Rev.: 02.00 (corresponds to Software from SW-Rev.: 03.00 and higher) .....	31
	Devices with PROFIBUS PA®, FOUNDATION Fieldbus®, and HART® to HW-Rev.: 01.07 .....	31
	Menu navigation.....	32
	Process display.....	32
	Error messages in the HART® LCD display .....	33
	Error messages in the PROFIBUS PA® and FOUNDATION Fieldbus® LCD display .....	34
	Factory settings .....	35
	Firmware settings .....	35
<b>10</b>	<b>Maintenance</b> .....	<b>36</b>
	Safety instructions.....	36
<b>11</b>	<b>Recycling and disposal</b> .....	<b>36</b>
<b>12</b>	<b>Specification</b> .....	<b>36</b>
<b>13</b>	<b>Additional documents</b> .....	<b>36</b>
<b>14</b>	<b>Appendix</b> .....	<b>37</b>
	Return form .....	37

# 1 Safety

## General information and instructions

These instructions are an important part of the product and must be retained for future reference.

Installation, commissioning, and maintenance of the product may only be performed by trained specialist personnel who have been authorized by the plant operator accordingly. The specialist personnel must have read and understood the manual and must comply with its instructions.

For additional information or if specific problems occur that are not discussed in these instructions, contact the manufacturer.

The content of these instructions is neither part of nor an amendment to any previous or existing agreement, promise or legal relationship.

Modifications and repairs to the product may only be performed if expressly permitted by these instructions.

Information and symbols on the product must be observed.

These may not be removed and must be fully legible at all times.

The operating company must strictly observe the applicable national regulations relating to the installation, function testing, repair and maintenance of electrical products.

## Warnings

The warnings in these instructions are structured as follows:

### **DANGER**

The signal word '**DANGER**' indicates an imminent danger. Failure to observe this information will result in death or severe injury.

### **WARNING**

The signal word '**WARNING**' indicates an imminent danger. Failure to observe this information may result in death or severe injury.

### **CAUTION**

The signal word '**CAUTION**' indicates an imminent danger. Failure to observe this information may result in minor or moderate injury.

### **NOTICE**

The signal word '**NOTICE**' indicates possible material damage.

### **Note**

'**Note**' indicates useful or important information about the product.

## Intended use

This device is intended for the following uses:

- To measure the temperature of fluid, pulpy or pasty substances and gases or resistance/voltage values.

The device has been designed for use exclusively within the technical limit values indicated on the name plate and in the data sheets.

- The maximum ambient temperature must not be exceeded.
- The IP rating of the housing must be observed during operation.
- For use in potentially explosive atmospheres, follow the associated guidelines.
- When using as a SIL-device in safety-relevant applications, the corresponding SIL-Safety Manual should be observed.

## Improper use

The following are considered to be instances of especially improper use of the device:

- Material application, for example by painting over the housing, name plate or welding/soldering on parts.
- Material removal, for example by spot drilling the housing.

## Warranty provisions

Using the device in a manner that does not fall within the scope of its intended use, disregarding this manual, using underqualified personnel, or making unauthorized alterations releases the manufacturer from liability for any resulting damage. This renders the manufacturer's warranty null and void.

## Cyber security disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is operator's sole responsibility to provide and continuously ensure a secure connection between the product and your network or any other network (as the case may be).

Operator shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information.

ABB and its affiliates are not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

## Software downloads

By visiting the web pages indicated below, you will find notifications about newly found software vulnerabilities and options to download the latest software. It is recommended that you visit this web pages regularly:

[www.abb.com/cybersecurity](http://www.abb.com/cybersecurity)

[ABB Library – TTH300 – Software downloads](#)



## Manufacturer's address

### ABB AG

#### Measurement & Analytics

Schillerstr. 72  
32425 Minden  
Germany

Tel: +49 571 830-0

Fax: +49 571 830-1806

## Service address

### Customer service center

Tel: +49 180 5 222 580

Email: [automation.service@de.abb.com](mailto:automation.service@de.abb.com)

## 2 Use in potentially explosive atmospheres in accordance with ATEX and IECEx

### Note

- Further information on the approval of devices for use in potentially explosive atmospheres can be found in the explosion protection test certificates (at [www.abb.com/temperature](http://www.abb.com/temperature)).
- Depending on the design, a specific marking in accordance with ATEX or IECEx applies.
- A list of standards, including the output data to which the device conforms, can be found in the examination certificate or manufacturer's declaration supplied with the device.

## Ex marking

### Transmitter

#### ATEX intrinsic safety

The device fulfills the requirements of Directive 2014/34/EU in case of corresponding purchase orders and is approved for use in Zone 0, 1 and 2.

#### Model TTH300-E1H

To HW-Rev.: 01.07:	
Type Examination Test Certificate	PTB 05 ATEX 2017 X
From HW-Rev.: 02.00.00:	
Type Examination Test Certificate	PTB 20 ATEX 2008 X

#### Model TTH300-E1P and TTH300-E1F

Type Examination Test Certificate		PTB 09 ATEX 2016 X
II 1 G	Ex ia IIC T6...T1 Ga	
II 2 (1) G	Ex [ia IIC Ga] ib IIC T6...T1 Gb	
II 2 G (1D)	Ex [ia IIIC Da] ib IIC T6...T1 Gb	

#### ATEX non-sparking and increased safety

The device fulfills the requirements of Directive 2014/34/EU in case of corresponding purchase orders and is approved for use in Zone 2.

#### Model TTH300-E2H

To HW-Rev.: 01.07:	
Manufacturer's Declaration	
II 3 G Ex nA IIC T6...T1 Gc	
From HW-Rev.: 02.00.00:	
Type Examination Test Certificate	PTB 20 ATEX 2008 X

II 3 G Ex ec IIC T6...T1 Gc

#### TTH300-E1P and TTH300-E1F

Manufacturer's Declaration	
II 3 G Ex nA IIC T6...T1 Gc	
II 3 G Ex ec IIC T6...T1 Gc	

#### IECEx intrinsic safety

Approved for use in Zone 0, 1, and 2.

#### Model TTH300-H1H

To HW-Rev.: 01.07:	
IECEx certificate of conformity	IECEx PTB 09.0014X
From HW-Rev.: 02.00.00:	
IECEx certificate of conformity	IECEx PTB 20.0035X

#### Model TTH300-H1P and TTH300-H1F

IECEx certificate of conformity		IECEx PTB 11.0108X
Ex ia IIC T6...T1 Ga		
Ex [ia IIC Ga] ib IIC T6...T1 Gb		
Ex [ia IIIC Da] ib IIC T6...T1 Gb		

### LCD indicator

#### ATEX intrinsic safety

The device fulfills the requirements of Directive 2014/34/EU in case of corresponding purchase orders and is approved for use in Zone 0, 1 and 2.

Type Examination Test Certificate	PTB 05 ATEX 2079 X
II 1G Ex ia IIC T6...T1 Ga	

#### IECEx intrinsic safety

Approved for use in Zone 0, 1, and 2.

IECEx certificate of conformity	IECEx PTB 12.0028X
Ex ia IIC T6...T1 Ga	

## Temperature data

### Transmitter

ATEX / IECEx intrinsic safety, ATEX non-sparking and increased safety

Temperature class	Permissible ambient temperature range
T6	-50 to 56 °C (-58 to 132.8 °F)
T4-T1	-50 to 85 °C (-58 to 185.0 °F)

### LCD indicator

ATEX / IECEx intrinsic safety, ATEX non-sparking and increased safety

Temperature class	Permissible ambient temperature range
T6	-50 to 56 °C (-58 to 132.8 °F)
T4-T1	-50 to 85 °C (-58 to 185 °F)

## Electrical data

### Transmitter

Intrinsic safety type of protection Ex ia IIC (Part 1)

#### Supply circuit <sup>1)</sup>

	TTH300-E1H	TTH300-E1P/-H1P	ENTITY
	TTH300-H1H	TTH300-E1F/-H1F	
	FISCO <sup>1)</sup>		
Max. voltage	$U_i = 30 \text{ V}$	$U_i \leq 17.5 \text{ V}$	$U_i \leq 24.0 \text{ V}$
Short-circuit current	$I_i = 130 \text{ mA}$	$I_i \leq 183 \text{ mA}^{2)}$	$I_i \leq 250 \text{ mA}$
Max. power	$P_i = 0.8 \text{ W}$	$P_i \leq 2.56 \text{ W}^{2)}$	$P_i \leq 1.2 \text{ W}$
Internal inductance	$L_i = 160 \mu\text{H}^{3)}$	$L_i \leq 10 \mu\text{H}$	$L_i \leq 10 \mu\text{H}$
Internal capacitance	$C_i = 0.57 \text{ nF}^{4)}$	$C_i \leq 5 \text{ nF}$	$C_i \leq 5 \text{ nF}$

1) FISCO in accordance with EN 60079-27

2) II B FISCO:  $I_i \leq 380 \text{ mA}$ ,  $P_i \leq 5.32 \text{ W}$

3) Only applies to HART variants.

From HW-Rev.: 02.00.00, previously 0.5 mH

4) Only applies to HART variants. From HW-Rev.: 1.07, previously 5 nF

Intrinsic safety type of protection Ex ia IIC (Part 2)

TTH300-E1H, TTH300-H1H

#### Measurement current circuit

	Resistance	Thermocouples,
	thermometers, resistors	voltages
Max. voltage	$U_o = 6.5 \text{ V}$	$U_o = 1.2 \text{ V}$
Short-circuit current	$I_o = 17.8 \text{ mA}^{1)}$	$I_o = 50 \text{ mA}$
Max. power	$P_o = 29 \text{ mW}^{2)}$	$P_o = 60 \text{ mW}$
Internal inductance	$L_i \approx 0 \text{ mH}$ (negligible)	$L_i \approx 0 \text{ mH}$ (negligible)
Internal capacitance	$C_i = 49 \text{ nF}$	$C_i = 49 \text{ nF}$
Maximum permissible external inductance	$L_o = 5 \text{ mH}$	$L_o = 5 \text{ mH}$
Maximum permissible external capacitance	$C_o = 1.65 \mu\text{F}^{3)}$	$C_o = 1.15 \mu\text{F}^{4)}$

1) From HW-Rev.: 02.00.00, previously 25 mA

2) From HW-Rev.: 02.00.00, previously 38 mW

3) From HW-Rev.: 02.00.00, previously 1.55  $\mu\text{F}$

4) From HW-Rev.: 02.00.00, previously 1.05  $\mu\text{F}$

## ... 2 Use in potentially explosive atmospheres in accordance with ATEX and IECEx

### ... Electrical data

Intrinsic safety type of protection Ex ia IIC (Part 2)  
TTH300-E1P, TTH300-H1P, TTH300-E1F, TTH300-H1F

#### Measurement current circuit

	Resistance Thermocouples, voltages thermometers, resistors	
Max. voltage	$U_o = 6.5 \text{ V}$	$U_o = 1.2 \text{ V}$
Short-circuit current	$I_o = 25 \text{ mA}$	$I_o = 50 \text{ mA}$
Max. power	$P_o = 38 \text{ mW}$	$P_o = 60 \text{ mW}$
Internal inductance	$L_i \approx 0 \text{ mH (negligible)}$	$L_i \approx 0 \text{ mH (negligible)}$
Internal capacitance	$C_i = 49 \text{ nF}$	$C_i = 49 \text{ nF}$
Maximum permissible external inductance	$L_o = 5 \text{ mH}$	$L_o = 5 \text{ mH}$
Maximum permissible external capacitance	$C_o = 1.55 \text{ }\mu\text{F}$	$C_o = 1.05 \text{ }\mu\text{F}$

#### Intrinsic safety type of protection Ex ia IIC (part 3)

##### LCD indicator interface

Max. voltage	$U_o = 6.2 \text{ V}$
Short-circuit current	$I_o = 65.2 \text{ mA}$
Max. power	$P_o = 101 \text{ mW}$
Internal inductance	$L_i \approx 0 \text{ mH (negligible)}$
Internal capacitance	$C_i \approx 0 \text{ nF (negligible)}$
Maximum permissible external inductance	$L_o = 5 \text{ mH}$
Maximum permissible external capacitance	$C_o = 1.4 \text{ }\mu\text{F}$

Type of protection non-sparking and increased safety  
TTH300-E2H from HW-Rev.: 02.00.00

#### Supply circuit

Max. voltage	$U_s = 30 \text{ V}$
Rated fuse current	$I_f = 32 \text{ mA}$

#### Measurement current circuit

Max. voltage	$U_b = 6.5 \text{ V}$
Max. output current	$I_b = 17.8 \text{ mA}$
Max. output power	$P_b = 29 \text{ mW}$
LCD indicator interface	Use not permitted

#### LCD indicator

Intrinsic safety type of protection Ex ia IIC

#### Supply circuit

Max. voltage	$U_i = 9 \text{ V}$
Short-circuit current	$I_i = 65.2 \text{ mA}$
Max. power	$P_i = 101 \text{ mW}$
Internal inductance	$L_i \approx 0 \text{ mH (negligible)}$
Internal capacitance	$C_i \approx 0 \text{ nF (negligible)}$

## Installation instructions

### ATEX / IECEx

The installation, commissioning, maintenance and repair of devices in potentially explosive atmospheres must only be carried out by appropriately trained personnel. Works may be carried out only by persons, whose training has included instructions on different types of protection and installation techniques, concerned rules and regulations as well as general principles of zoning. The person must possess the appropriate competences for the type of work to be conducted.

When operating with combustible dusts, comply with EN 60079-31.

The safety instructions for electrical apparatus in potentially explosive areas must be in accordance with Directive 2014/34/EU (ATEX) and IEC 60079-14 (Installation of electrical equipment in potentially explosive areas).

Comply with the applicable regulations for the protection of employees to ensure safe operation.

### IP protection rating of housing

The temperature transmitter and type A or type AS LCD indicator must be installed according to type of protection 'intrinsic safety' (Ex i) such that an IP rating of at least IP 20 is achieved in accordance with IEC 60529.

Perform installation according to type of protection 'non-sparking' (Ex nA) or type of protection 'increased safety' (Ex ec) such that an IP rating of at least IP 54 and a degree of contamination of 2 or better is achieved in accordance with IEC 60664-1.

## Electrical connections

### Grounding

If, for functional reasons, the intrinsically safe circuit needs to be grounded by means of a connection to the potential equalization, it may only be grounded at one point.

### Intrinsic safety installation check

If transmitters are operated in an intrinsically safe circuit, proof that the interconnection is intrinsically safe must be provided in accordance with IEC/EN 60079-14 as well as IEC/EN 60079-25. The supply isolators / DCS inputs must feature intrinsically safe input protection circuits in order to eliminate hazards (spark formation).

In order to provide proof of intrinsic safety, the electrical limit value must be used as the basis for the EC-type examination certificates for the equipment (devices); this includes the capacitance and inductance values of the cables.

Proof of intrinsic safety is said to have been provided if the following conditions are fulfilled when a comparison is carried out in relation to the limit values of the equipment:

Transmitter (intrinsically safe equipment)	Supply isolator / DCS input (related equipment)
	$U_i \geq U_o$
	$I_i \geq I_o$
	$P_i \geq P_o$
	$L_i + L_c \text{ (cable)} \leq L_o$
	$C_i + C_c \text{ (cable)} \leq C_o$




Figure 1: Intrinsic safety proof

## ... 2 Use in potentially explosive atmospheres in accordance with ATEX and IECEx

### ... Installation instructions

**Installation in a potentially explosive atmosphere**  
 Transmitters can be installed in all kinds of industrial sectors. Potentially explosive systems are divided into zones, meaning that a wide range of different instruments are also required. For this, pay attention to the country-specific guidelines and certificates!

**Note**  
 Ex relevant specifications must be taken from the EC-type examination certificates and other relevant certificates that apply in each case.

With transmitters for PROFIBUS PA and FOUNDATION Fieldbus H1 applications, FISCO interconnection methods can be used.

**ATEX – Zone 0**  
**Marking: II 1 G Ex ia IIC T6...T1 Ga**




Figure 2: Hookup in ATEX – Zone 0

When using the transmitter in Zone 0, it must be installed in a suitable housing with IP -rating IP 20.

The input for the supply isolator must be designed with ‘Ex ia’ type of protection.

When using the transmitter in Zone 0, make sure that impermissible electrostatic charging of the transmitter is avoided (observe the warnings on the device).

As the user, it is your responsibility to ensure that the sensor instrumentation meets the requirements of applicable explosion protection standards.

**Note**  
 When operating the transmitter in Zone 0 (EPL ‘Ga’), the compatibility of the device materials with the surrounding atmosphere must be ensured.

Encapsulation material used for the transmitter:  
 Polyurethane (PUR)

**ATEX – Zone 1 (0)**  
**Marking: II 2 (1) G Ex [ia IIC Ga] ib IIC T6...T1 Gb**





Figure 3: Hookup in ATEX – Zone 1 (0)

When using the transmitter in Zone 1, it must be installed in a suitable housing with IP -rating IP 20.

The input of the supply isolator must be designed with ‘Ex ib’ type of protection.

As the user, it is your responsibility to ensure that the sensor instrumentation meets the requirements of applicable explosion protection standards. The sensor can be installed in Zone 1 or Zone 0.

When using the transmitter in Zone 1, you must ensure that impermissible electrostatic charging of the temperature transmitter is prevented (observe the warnings on the device).


**ATEX – Zone 1 (20)****Marking: II 2 G (1D) Ex [ia IIIC Da] ib IIC T6...T1 Gb****Figure 4: Hookup in ATEX – Zone 1 (20)**

When using the transmitter in Zone 1, it must be installed in a suitable housing with IP -rating IP 20.

The input for the supply isolator must be designed with 'Ex ib' type of protection.

As the user, it is your responsibility to ensure that the sensor instrumentation meets the requirements of applicable explosion protection standards. The sensor can be installed in Zone 20 or Zone 21.

When using the transmitter in Zone 1, make sure that impermissible electrostatic charging of the temperature transmitter is avoided (observe the warnings on the device).

**ATEX – Zone 2****Marking:****II 3 G Ex nA IIC T6...T1 Gc****II 3 G Ex ec IIC T6...T1 Gc****Figure 5: Hookup in ATEX – Zone 2**

When using the transmitter in Zone 2, observe the following:

- The temperature transmitter must be installed in a suitable housing that reaches at least IP rating IP 54 in accordance with IEC 60529 and a degree of contamination of 2 or better in accordance with IEC 60664-1.
- In addition to the housing, suitable cable glands must be used.
- The other requirements specified for potentially explosive atmospheres must be met.
- External measures must be made for the power supply circuit in order to prevent the rated voltage from being up-scaled by more than 40 % in the event of transient disturbances.
- The electrical connections must only be opened or closed when there is no hazardous atmosphere.
- When using the transmitter in Zone 2, make sure that impermissible electrostatic charging of the temperature transmitter is prevented (observe the warnings on the device).
- The connection leads must be permanently installed and secured against tensile load.

## ... 2 Use in potentially explosive atmospheres in accordance with ATEX and IECEx

### ... Installation instructions

#### Note

In addition, the following points for TTH300 HART (TTH300-E2H) from HW-Rev.: 02.00.00 must be observed:

- The power supply circuit of the transmitter must be limited by an upstream fuse with a fuse current rating of 32 mA and a fuse rated voltage of  $\geq 30$  V. The fuse can be located in the associated supply isolator or must be separately installed upstream. The breaking capacity of the fuse must be the same or greater than the maximum assumed short-circuit current at the installation site (usually 1,500 A).
- The display / service interface must not be used in type of protection 'Ex nA' and 'Ex ec'.

### Commissioning

The commissioning and parameterization of the device may also be carried out in potentially explosive atmospheres using a handheld terminal that has been approved accordingly under consideration of an intrinsic safety installation check. Alternatively, an Ex modem can be connected to the circuit outside the potentially explosive atmosphere.

### Operating instructions

#### Protection against electrostatic discharges

The plastic parts inside the device can store electrostatic charges.

Make sure that no electrostatic charges can accumulate when handling the device.

### 3 Use in potentially explosive atmospheres in accordance with cFMus, FM and CSA

#### Note

- Further information on the approval of devices for use in potentially explosive atmospheres can be found in the explosion protection test certificates (at [www.abb.com/temperature](http://www.abb.com/temperature)).
- Depending on the design, a specific marking in accordance with FM, CSA or cFMus applies.

#### Transmitter Ex marking cFMus

##### cFMus Intrinsically Safe

###### Model TTH300-L1H for USA or TTH300-R1H for Canada

From HW-Rev.: 02.00

Control Drawing TTH300-L1H

IS Class I, Div. 1,2 Group ABCD T6, T4

Zone 0 AEx/Ex ia IIC T6...T1 Ga

Zone 1 AEx/Ex [ia Ga] ib IIC T6...T1 Gb

Zone 1 AEx/Ex ib IIC T6...T1 Gb / [AEx/Ex ia Da] IIIC

##### cFMus Non-Incendive

###### Model TTH300-L2H for USA or TTH300-R2H for Canada

From HW-Rev.: 02.00

Control Drawing TTH300-L2H

NI Class I, Div. 2 Group ABCD T6, T4

Zone 2 AEx/Ex nA IIC T6... T1 Gc

Zone 2 AEx/Ex ec IIC T6...T1 Gc

#### Transmitter Ex marking FM / CSA

##### FM Intrinsically Safe

###### Model TTH300-L1H

Up to HW-Rev.: 01.07:

Control Drawing SAP\_214829

###### Model TTH300-L1P

Control Drawing TTH300-L1P (IS)

###### Model TTH300-L1F

Control Drawing TTH300-L1F (IS)

Class I, Div. 1 + 2, Groups A, B, C, D

Class I, Zone 0, AEx ia IIC T6

##### FM Non-Incendive

###### Model TTH300-L2H

Up to HW-Rev.: 01.07:

Control Drawing 214831 (Non-Incendive)

###### Model TTH300-L2P

Control Drawing TTH300-L2P (NI\_PS)

TTH300-L2P (NI\_AA)

###### Model TTH300-L2F

Control Drawing TTH300-L2F (NI\_PS)

TTH300-L2F (NI\_AA)

Class I, Div. 2, Groups A, B, C, D

## ... 3 Use in potentially explosive atmospheres in accordance with cFMus, FM and CSA

### ... Transmitter Ex marking FM / CSA

#### CSA Intrinsically Safe

##### Model TTH300-R1H

Up to HW-Rev.: 01.07:

Control Drawing 214826

##### Model TTH300-R1P

Control Drawing TTH300-R1P (IS)

##### Model TTH300-R1F

Control Drawing TTH300-R1F (IS)

Class I, Div. 1 + 2, Groups A, B, C, D

Class I, Zone 0, Ex ia IIC T6

#### CSA Non-Incendive

##### Model TTH300-R2H

Up to HW-Rev.: 01.07: SAP\_214824 (Non-Incendive)

Control Drawing SAP\_214896 (Non-Incendive)

##### Model TTH300-R2P

Control Drawing TTH300-R2P (NI\_PS)

TTH300-R2P (NI\_AA)

##### Model TTH300-R2F

Control Drawing TTH300-R2F (NI\_PS)

TTH300-R2F (NI\_AA)

Class I, Div. 2, Groups A, B, C, D

### LCD indicator Ex marking

#### FM Intrinsically Safe

Control Drawing SAP\_214 748

I.S. Class I Div 1 and Div 2, Group: A, B, C, D or

I.S. Class I Zone 0 AEx ia IIC T\*

$U_i / V_{max} = 9 \text{ V}$ ,  $I_i / I_{max} < 65.2 \text{ mA}$ ,  $P_i = 101 \text{ mW}$ ,  $C_i = 0.4 \mu\text{F}$ ,  $L_i = 0$

#### FM Non-Incendive

Control Drawing SAP\_214 751

N.I. Class I Div 2, Group: A, B, C, D or Ex nL IIC T\*\*, Class I Zone 2

$U_i / V_{max} = 9 \text{ V}$ ,  $I_i / I_{max} < 65.2 \text{ mA}$ ,  $P_i = 101 \text{ mW}$ ,  $C_i = 0.4 \mu\text{F}$ ,  $L_i = 0$

#### CSA Intrinsically Safe

Control Drawing SAP\_214 749

I.S. Class I Div 1 and Div 2; Group: A, B, C, D or

I.S. Zone 0 Ex ia IIC T\*

$U_i / V_{max} = 9 \text{ V}$ ,  $I_i / I_{max} < 65.2 \text{ mA}$ ,  $P_i = 101 \text{ mW}$ ,  $C_i < 0.4 \mu\text{F}$ ,  $L_i = 0$

#### CSA Non-Incendive

Control Drawing SAP\_214 750

N.I. Class I Div 2, Group: A, B, C, D or Ex nL IIC T\*\*, Class I Zone 2

$U_i / V_{max} = 9 \text{ V}$ ,  $I_i / I_{max} < 65.2 \text{ mA}$ ,  $P_i = 101 \text{ mW}$ ,  $C_i < 0.4 \mu\text{F}$ ,  $L_i = 0$

\* Temp. Ident: T6 T<sub>amb</sub> 56 °C, T4 T<sub>amb</sub> 85 °C

\*\* Temp. Ident: T6 T<sub>amb</sub> 60 °C, T4 T<sub>amb</sub> 85 °C

## Installation instructions

The installation, commissioning, maintenance and repair of devices in areas with explosion hazard must only be carried out by appropriately trained personnel.

The operator must strictly observe the applicable national regulations with regard to installation, function tests, repairs, and maintenance of electrical devices. (e. g. NEC, CEC).

**Warnings and instructions should be followed as per notes on the associated control drawing for installation in the associated hazardous area.**

The control drawings are available for download under the following link. Just scan or click on the QR code:

[ABB Library – TTH300 – control drawings](#)



### IP protection rating of housing

The temperature transmitter and LCD indicator Type A and Type AS must be installed such that an IP rating of at least IP 20 is achieved in accordance with IEC 60529.

### Electrical connections

#### Grounding

If, for functional reasons, the intrinsically safe circuit needs to be grounded by means of a connection to the potential equalization, it may only be grounded at one point.

#### Note

When operating the transmitter in Zone 0, the compatibility of the device materials with the surrounding atmosphere must be guaranteed.

Encapsulation material used for the transmitter:

Polyurethane (PUR)

### Installation in a potentially explosive atmosphere

Transmitters can be installed in all kinds of industrial sectors. Potentially explosive systems are divided into zones, meaning that a wide range of different instruments are also required. For this, pay attention to the country-specific guidelines and certificates!

## Commissioning

The commissioning and parameterization of the device may also be carried out in potentially explosive atmospheres using a handheld terminal that has been approved accordingly under consideration of an intrinsic safety installation check.

Alternatively, an Ex modem can be connected to the circuit outside the potentially explosive atmosphere.

## Operating instructions

### Protection against electrostatic discharges

The plastic parts inside the device can store electrostatic charges.

Make sure that no electrostatic charges can accumulate when handling the device.

## 4 Product identification

### Name plate


**Note**



Products that are marked with the adjacent symbol may **not** be disposed of as unsorted municipal waste (domestic waste). They should be disposed of through separate collection of electric and electronic devices.

**Note**

The ambient temperature range (14) provided on the name plate refers only to the transmitter itself and not to the sensor element used in the measuring inset. For devices with PROFIBUS PA or FOUNDATION Fieldbus, the device-ID is also specified.



- ① Manufacturer, manufacturer address, manufacturing year - week
- ② Safety integrity level, SIL logo (optional with HART transmitter)
- ③ CE mark (EU conformity), if not on additional plate
- ④ Type designation / model
- ⑤ Transmitter communications protocol (HART, FF, PA)
- ⑥ 2D barcode for serial number in accordance with order
- ⑦ Serial number of the device electronics (7 or 8 digits)
- ⑧ Software revision
- ⑨ Hardware version
- ⑩ 'Follow product documentation' symbol
- ⑪⑫⑬ **HART transmitter:**
- ⑪ Set measuring range of the transmitter
- ⑫ Measuring point tag (TAG) in accordance with order (optional)
- ⑬ Set sensor type and circuit type
- ⑭⑮ **Transmitter FOUNDATION Fieldbus or PROFIBUS PA:**
- ⑫ Measuring point tag (TAG) in accordance with order (optional)
- ⑬ DEVICE\_ID or Ident\_Number
- ⑭ Ambient temperature range, on additional plate for Ex versions
- ⑮ Transmitter specification (supply voltage range, output current range, communications protocol)
- ⑯ Coding of the type of protection of the device (in accordance with ordering information)
- ⑰ Serial number of the device (serial number in accordance with order)

Figure 6: HART name plate (example)




Figure 7: PROFIBUS PA name plate (example)





Figure 8: FOUNDATION Fieldbus name plate (example)

Devices with an explosion-proof design are marked with the following additional data plate.



- ① Type designation in accordance with approval
- ② Approval number
- ③ Protection class of the explosion-proof design (explosion protection marking)
- ④ Temperature class of the explosion-proof design
- ⑤ 'Follow product documentation' symbol
- ⑥ CE mark (EU conformity) and notified body for quality assurance
- ⑦ Ex marking

Figure 9: Additional data plate for explosion-protected devices (example)

**Note**

The name plates displayed are examples. The device identification plates affixed to the device can differ from this representation.

## 5 Transport and storage

### Inspection

Check the devices immediately after unpacking for possible damage that may have occurred from improper transport. Details of any damage that has occurred in transit must be recorded on the transport documents. All claims for damages must be submitted to the shipper without delay and before installation.

### Transporting the device

Observe the following instructions:

- Do not expose the device to humidity during transport. Pack the device accordingly.
- Pack the device so that it is protected against vibrations during transport, for example, by using air-cushioned packing.

### Storing the device

Bear the following points in mind when storing devices:

- Store the device in its original packaging in a dry and dust-free location.
- Observe the permitted ambient conditions for transport and storage.
- Avoid storing the device in direct sunlight.
- In principle, the devices may be stored for an unlimited period. However, the warranty conditions stipulated in the order confirmation of the supplier apply.

### Ambient conditions

The ambient conditions for the transport and storage of the device correspond to the ambient conditions for operation of the device.

Adhere to the device data sheet!

### Returning devices

Use the original packaging or a secure transport container of an appropriate type if you need to return the device for repair or recalibration purposes.

Fill out the return form (see **Return form** on page 37) and include this with the device.

In accordance with the EU Directive governing hazardous materials, the owner of hazardous waste is responsible for its disposal or must observe the following regulations for shipping purposes:

All devices delivered to ABB must be free from any hazardous materials (acids, alkalis, solvents, etc.).

### Address for return shipment:

Please contact Customer Center Service acc. to page 5 for nearest service location.

## 6 Installation

### Safety instructions

#### **⚠ DANGER**

**Improper installation and commissioning of the device carries a risk of explosion.**

For use in potentially explosive atmospheres, observe the information in **Use in potentially explosive atmospheres in accordance with ATEX and IECEx** on page 6 and **Use in potentially explosive atmospheres in accordance with cFMus, FM and CSA** on page 13!

### Ambient conditions

#### Ambient temperature

- Standard: -40 to 85 °C (-40 to 185 °F)
- Optional: -50 to 85 °C (-58 to 185 °F)
- Limited temperature range for explosion-proof design: see relevant certificate

#### Transport- / Storage temperature

-50 to 85 °C (-58 to 185 °F)

#### Climate class in accordance with DIN EN 60654-1

Cx -40 to 85 °C (-40 to 185 °F) at 5 to 95 % relative air humidity

#### Temperature and humidity limits

In accordance with IEC 60068-2-30

#### Vibration resistance in accordance with IEC 60068-2-6

10 to 2000 Hz at 5 g, during operation and transport

#### Shock resistance in accordance with IEC 60068-2-27

gn = 30, during operation and transport

#### IP rating

- Power supply circuit: IP 20
- Measurement current circuit: IP 00 or IP-rating of installation housing

### Installation options

There are three options for installing the transmitter:

- Installation in the cover of the connection head (without springs)
- Direct installation on the measuring inset (with springs)
- Installation on a top-hat rail

#### Installation on the measuring inset




Figure 10: Mounting examples

#### Note

Before mounting the transmitter on the measuring inset, remove the ceramic block on the measuring inset and the captive screws in the transmitter.

To install the transmitter on the measuring inset, cambered toothed discs and the corresponding mounting screws are required; these must be ordered as separate accessories:

Measuring inset installation set (2 fixing screws, 2 springs, 2 toothed discs) order number: 263750

1. Remove the ceramic block from the measuring inset ③.
2. Remove the screws from the transmitter ②. Remove the sleeves from the screw holes and then remove the screws.
3. Insert new fixing screws ① from above in the fixing holes of the transmitter.
4. Place the cambered toothed discs ④ with curve facing upward on the downward protruding screw thread.
5. Connect the power supply cable to the transmitter according to connection diagram.
6. Place the transmitter in the housing on the measuring inset and secure it.

#### Note

The toothed discs between measuring inset and transmitter are straightened when the screws are tightened. This enables them to grip the mounting screws.

### Installation in the cover of the connection head




Figure 11: Mounting examples

1. Release the screw plug ③ for the cover of the connection head.
2. Open the cover ①.
3. Secure the transmitter ② at the proper position on the cover, using the captive screws found in the transmitter.

### Installation on the top-hat rail




Figure 12: Mounting examples

When mounted on a top-hat rail, the transmitter can be placed at a distance from the sensor in a housing that is suitable for the ambient conditions.

## Installing / removing the optional LCD indicator

The transmitter can be optionally equipped with an LCD indicator.

### NOTICE

#### Damage to the LCD indicator caused by incorrect installation / disassembly

The flat ribbon cable of the LCD indicator can become damaged due to incorrect installation / disassembly.

- Make sure the flat ribbon cable does not get twisted or torn when installing / disassembling or rotating the LCD indicator.

### Disassembling the LCD indicator

The indicator must be removed to enable connection of the sensor line or supply line:

- Carefully remove the LCD indicator from the transmitter inset. The LCD indicator is held firmly in place, meaning that you may have to use the tip of a screwdriver to pry it loose. Take care to avoid any mechanical damage.

### Installing the LCD indicator

No tools are required to install the LCD indicator.

1. Carefully insert the guide pins for the LCD indicator in the guide holes of the transmitter inset. Make sure the black connection socket fits into the terminal on the transmitter inset.
2. Then press the LCD indicator in as far as it will go. Make sure that the guide pins and connection socket are fully inserted.

### Rotating the LCD indicator

The position of the LCD indicator can be adjusted to suit the mounting position of the transmitter, to ensure that the display is as clearly legible as possible.

There are twelve positions at increments of 30°.

1. Carefully turn the LCD indicator to the left to release it from its holder.
2. Carefully turn the LCD indicator until the required position is reached.
3. Insert the LCD indicator into its holder again and turn it to the right into the required position until it snaps into place.

## 7 Electrical connections

### Safety instructions

#### **⚠ DANGER**

**Improper installation and commissioning of the device carries a risk of explosion.**

For use in potentially explosive atmospheres, observe the information in **Use in potentially explosive atmospheres in accordance with ATEX and IECEx** on page 6 and **Use in potentially explosive atmospheres in accordance with cFMus, FM and CSA** on page 13!

Observe the following instructions:

- The electrical connection may only be established by authorized specialist personnel and in accordance with the connection diagrams.
- The relevant regulations must be observed during electric installation.
- The electrical connection information in the instruction must be observed; otherwise, the electric IP rating may be adversely affected.
- Safe isolation of electric circuits which are dangerous if touched is ensured only if the connected devices satisfy the requirements of DIN EN 61140 (VDE 0140 Part 1) (basic requirements for safe isolation).
- To ensure safe isolation, install connection leads separate from electric circuits which are dangerous if touched, or implement additional insulation measures.
- Connections must only be established in a dead-voltage state!
- The transmitter has no switch-off elements. Therefore, overcurrent protective devices, lightning protection, or voltage disconnection options must be provided with the installation.
- The power supply and signal are routed in the same conductor and should be implemented as a SELV or PELV circuit in accordance with the relevant standard (standard version). For the explosion-proof design, the guidelines in accordance with the Ex standard must be adhered to.
- You need to check that the available power supply corresponds to the information on the name plate.

#### Note

The signal cable wires must be provided with wire end sleeves. The slotted screws of the connection terminals are tightened with a size 1 screwdriver (3.5 or 4 mm).

### Protection of the transmitter from damage caused by highly energetic electric interferences

The transmitter has no switch-off elements. Therefore, overcurrent protective devices, lightning protection, or voltage disconnection options must be provided at the plant. For the shielding and grounding of the device and the connection cable, observe **Terminal assignment** on page 22.

#### **NOTICE**

##### **Temperature transmitter damage!**

Overvoltage, overcurrent and high-frequency interference signals on the supply connection as well as sensor connection side of the device can damage the temperature transmitter.



- (A) Do not weld
- (B) No high-frequency interference signals / switching operations of large consumers
- (C) No overvoltage due to lightning

Figure 13: Warning signs

Overcurrent and overvoltage can occur through for example welding operations, switching operations of large electric consumers, or lightning in the vicinity of the transmitter, sensor, as well as connector cables.

Temperature transmitters are sensitive devices on the sensor side as well. Long connector cables to the sensor can encourage damaging interference. This can already happen if temperature sensors are connected to the transmitter during installation, but are not yet integrated into the system (no connection to the supply isolator / DCS)!

### Suitable protective measures

The following items should be observed to protect the transmitter from sensor-side damage:

- In the vicinity of the transmitter, sensor and sensor connector cable in case of a connected sensor, high-energy overvoltage, overcurrent and high-frequency interference signals due to welding operations, lightning, circuit breakers or large consumers of electricity among others should be absolutely avoided.
- The connection cable of the sensor on the transmitter should be disconnected when performing welding work in the vicinity of the installed transmitter, sensor, as well as supply lines from the sensor to the transmitter.
- This correspondingly also applies to the supply side, if there is a connection there.

## Conductor material

### **NOTICE**

#### **Danger of wire break!**

The use of stiff cable material can lead to wire breaks in the cables.

- Only use cable material with stranded wires.

#### **Supply voltage**

Power supply cable:

Flexible standard cable material

Maximum wire cross section:

1.5 mm<sup>2</sup> (AWG 16)

#### **Sensor connection**


Depending on the type of sensor, a variety of cable materials can be used for connections.

The integrated internal reference junction makes it possible to directly connect thermal compensating cables.

## ... 7 Electrical connections

### Terminal assignment

Resistance thermometers (RTD) / resistors (potentiometer)



(A) Potentiometer, four-wire circuit

(B) Potentiometer, three-wire circuit

(C) Potentiometer, two-wire circuit

(D) 2 × RTD, three-wire circuit\*

(E) 2 × RTD, two-wire circuit\*

(F) RTD, four-wire circuit

(G) RTD, three-wire circuit

(H) RTD, two-wire circuit

(I) Sensor 1

(J) Sensor 2\*

(K) Interface for LCD indicators and service


(1) - (6) Sensor connection (of measuring inset)

(7) - (8) 4 to 20 mA HART®, PROFIBUS PA®, FOUNDATION Fieldbus®

\* Sensor backup / sensor redundancy, sensor drift monitoring, mean measurement, or differential measurement

Figure 14: Terminal assignment for resistance thermometers (RTD) / resistors (potentiometers)

**Thermocouples / voltages and resistance thermometers (RTD) / thermocouple combinations**



- (A) 2 × voltage measurement\*
- (B) 1 × voltage measurement
- (C) 2 × thermocouple\*
- (D) 1 × thermocouple
- (E) 1 × RTD, four-wire circuit and 1 × thermocouple\*
- (F) 1 × RTD, three-wire circuit and 1 × thermocouple\*
- (G) 1 × RTD, two-wire circuit and 1 × thermocouple\*
- (H) Sensor 1
- (I) Sensor 2<sup>1)</sup>
- (J) Interface for LCD indicators and service
- (1) – (6) Sensor connection (of measuring inset)
- (7) – (8) 4 to 20 mA HART®, PROFIBUS PA®, FOUNDATION Fieldbus®

\* Sensor backup / sensor redundancy, sensor drift monitoring, mean measurement, or differential measurement

**Figure 15: Terminal assignment for thermocouples / voltages and resistance thermometers (RTD) / thermocouple combinations**

## ... 7 Electrical connections

### Electrical data for inputs and outputs

#### Input - resistance thermometer / resistances

##### Resistance thermometer

- Pt100 in accordance with IEC 60751, JIS C1604, MIL-T-24388
- Ni in accordance with DIN 43760
- Cu in accordance with recommendation OIML R 84

##### Resistance measurement

- 0 to 500  $\Omega$
- 0 to 5000  $\Omega$

##### Sensor connection type

Two-, three-, four-wire circuit

##### Connection lead

- Maximum sensor line resistance per line 50  $\Omega$  in accordance with NE 89
- Three-wire circuit:  
Symmetrical sensor line resistances
- Two-wire circuit:  
Compensation up to 100  $\Omega$  total lead resistance

##### Measurement current

< 300  $\mu$ A

##### Sensor short circuit

< 5  $\Omega$  (for resistance thermometer)

##### Sensor wire break

- Measuring range: 0 to 500  $\Omega$  > 0.6 to 10 k $\Omega$
- Measuring range: 0 to 5  $\Omega$  > 5.3 to 10 k $\Omega$

Detection of sensor wire break in accordance with NE 89 in all lines

##### Sensor error signaling

- Resistance thermometer:  
Sensor short circuit and sensor wire break
- Linear resistance measurement:  
Sensor wire break

#### Input - thermocouples / voltages

##### Types

- B, E, J, K, N, R, S, T in accordance with IEC 60584
- U, L in accordance with DIN 43710
- C in accordance with IEC 60584 / ASTM E988
- D in accordance with ASTM E988

##### Voltages

- -125 to 125 mV
- -125 to 1100 mV

##### Connection lead

- Maximum sensor line resistance:  
per line 1.5 k $\Omega$ , total 3 k $\Omega$

Detection of sensor wire break in accordance with NE 89 in all lines

##### Input resistance

> 10 M $\Omega$

##### Internal reference junction Pt1000, IEC 60751 Cl. B

(no additional jumpers necessary)

##### Sensor error signaling

- Thermocouple:  
Sensor wire break
- Linear voltage measurement:  
Sensor wire break

##### Functionality input

##### Freestyle characteristic / 32-points-sampling point table

- Resistance measurement up to a maximum of 5 k $\Omega$
- Voltages up to maximum 1.1 V

##### Sensor error adjustment

- Through Callendar-Van Dusen coefficients
- Through value table, 32 support points
- Through single-point adjustment (offset adjustment)
- Through two-point adjustment

##### Input functionality

- 1 Sensor
- 2 Sensors:  
mean measurement,  
differential measurement,  
sensor redundancy,  
Sensor drift monitoring

**Output – HART®****Note**

The HART® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

**Transmission behavior**

- Temperature linear
- Resistance linear
- Voltage linear

**Output signal**

- Configurable 4 to 20 mA (standard)
- Configurable 20 to 4 mA  
(dynamic range: 3.8 to 20.5 mA in accordance with NE 43)

**Simulation mode**

3.5 to 23.6 mA

**Induced current consumption**

< 3.5 mA

**Maximum output current**

23.6 mA

**Configurable error current signal****Note**

Regardless of the alarm setting (underrange or overrange), a high alarm or low alarm is always generated for some internal device errors (e.g. hardware errors). Detailed information about this can be found in the SIL-Safety Manual.

**Notice – Before SW-Rev.: 03.00**

The default factory setting for the error current signal is high alarm 22 mA.

- Overrange / high alarm 22 mA (20.0 to 23.6 mA)
- Underrange / low alarm 3.6 mA (3.5 to 4.0 mA)

**Notice – From SW-Rev.: 03.00**

The default factory setting for the error current signal is low alarm 3.5 mA, in accordance with NAMUR recommendations NE 93, NE 107 and NE 131.

- Overrange / high alarm 22 mA (20.0 to 23.6 mA)
- Underrange / low alarm 3.5 mA (3.5 to 4.0 mA)

**Output – PROFIBUS PA®****Note**

The PROFIBUS PA® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

**Output signal**

- PROFIBUS – MBP (IEC 61158-2)
- Baud rate 31.25 kBit/s
- PA-Profile 3.01
- FISCO compliant (IEC 60079-27)
- ID-Number: 0x3470 [0x9700]

**Error current signal**

- FDE (Fault Disconnection Electronic)

**Block structure**

- Physical Block
- Transducer Block 1 – Temperature
- Transducer Block 2 – HMI (LCD indicator)
- Transducer Block 3 – enhanced diagnosis
- Analog Input 1 – Primary Value (Calculated Value\*)
- Analog Input 2 – SECONDARY VALUE\_1 (Sensor 1)
- Analog Input 3 – SECONDARY VALUE\_2 (Sensor 2)
- Analog Input 4 – SECONDARY VALUE\_3 (reference junction temperature)
- Analog Output – optional HMI display (Transducer Block 2)
- Discrete Input 1 – extended diagnosis 1 (Transducer Block 3)
- Discrete Input 2 – extended diagnosis 2 (Transducer Block 3)

\* Sensor 1, Sensor 2 or difference or mean

For detailed information see the PROFIBUS PA® interface description (COM/TTX300/PB).

## ... 7 Electrical connections

### ... Electrical data for inputs and outputs

#### Output – FOUNDATION Fieldbus®

**Note**

The FOUNDATION Fieldbus® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

**Output signal**

- FOUNDATION Fieldbus H1 (IEC 611582-2)
- Baud rate 31.25 kBit/s, ITK 5.x
- FISCO compliant (IEC 60079-27)
- Device ID:000320001F...

**Error current signal**

- FDE (Fault Disconnection Electronic)

**Block structure\***

- Resource Block
- Transducer Block 1 – Temperature
- Transducer Block 2 – HMI (LCD indicator)
- Transducer Block 3 – enhanced diagnosis
- Analog Input 1 – PRIMARY\_VALUE\_1 (Sensor 1)
- Analog Input 2 – PRIMARY\_VALUE\_2 (Sensor 2)
- Analog Input 3 – PRIMARY\_VALUE\_3 (Calculated Value\*\*)
- Analog Input 4 – SECONDARY\_VALUE (reference junction temperature)
- Analog Output – optional HMI display (Transducer Block 2)
- Discrete Input 1 – extended diagnosis 1 (Transducer Block 3)
- Discrete Input 2 – extended diagnosis 2 (Transducer Block 3)
- PID – PID controller

LAS (Link Active Scheduler) link master functionality

\* For the block description, block index, execution times, and block class, refer to the interface description

\*\* Sensor 1, Sensor 2 or difference or mean

For detailed information, see the COM/TTX300/FF FOUNDATION Fieldbus® interface description.

**Power supply**

Two-wire technology, polarity safe; power supply lines = signal lines

**Note**

Following calculations apply for standard applications. This should be taken into consideration when working with a higher maximum current.

**Power supply – HART®**

**Supply voltage**

Non-Ex application:  
 $U_s = 11 \text{ to } 42 \text{ V DC}$

Ex applications:  
 $U_s = 11 \text{ to } 30 \text{ V DC}$

**Maximum permissible residual ripple for supply voltage**


During communication this is in accordance with the HART FSK ‘Physical Layer’ specification.

**Undervoltage detection on the transmitter**

If the terminal voltage on the transmitter down-scales a value of 10 V, this may lead to an output current of  $I_a \leq 3.6 \text{ mA}$ .

**Maximum load**

$$R_B = (\text{supply voltage} - 11 \text{ V}) / 0.022 \text{ A}$$



- (A) TTH300
- (B) TTH300 in Ex-applications
- (C) HART communication resistance

Figure 16: Maximum load depending on supply voltage

**Maximum power consumption**

$$P = U_s \times 0.022 \text{ A}$$

E.G.  $U_s = 24 \text{ V} \rightarrow P_{\text{max}} = 0.528 \text{ W}$

### Voltage drop on the signal line

When connecting the devices, note the voltage drop on the signal line. The minimum supply voltage on the transmitter must not be undershot.




Figure 17: HART load resistance

U<sub>1min</sub>: Minimum supply voltage on the transmitter

U<sub>2min</sub>: Minimum supply voltage of the supply isolator / DCS input

R: Line resistance between transmitter and supply isolator

R<sub>250</sub>: Resistance (250 Ω) for HART functionality

### Standard application with 4 to 20 mA functionality

When connecting these components, observe the following condition:

$$U_{1min} \leq U_{2min} - 22 \text{ mA} \times R$$

### Standard application with HART functionality

Adding resistance R<sub>250</sub> increases the minimum supply voltage U<sub>2min</sub>:  $U_{1min} \leq U_{2min} - 22 \text{ mA} \times (R + R_{250})$

For HART functionality, use supply isolators or DCS input cards with a HART mark. If this is not possible, a resistance of  $\geq 250 \Omega$  (< 1100 Ω) must be added to the interconnection.

The signal line can be operated with / without grounding. When establishing a ground connection (minus side), make sure that only one side of the terminal is connected to the equipotential bonding.

For further information on the revision of the standard HART protocol and on switching options, see **HART® Communication** on page 28 and **Hardware settings** on page 31..

### Power supply – PROFIBUS / FOUNDATION Fieldbus

#### Supply voltage

Non-Ex application:

$$U_S = 9 \text{ to } 32 \text{ V DC}$$

Ex-applications with:

$$U_S = 9 \text{ to } 17 \text{ V DC (FISCO)}$$

$$U_S = 9 \text{ to } 24 \text{ V DC (Fieldbus Entity model I.S.)}$$

Current consumption:

$$\leq 12 \text{ mA}$$

### Standard application with PROFIBUS PA and FOUNDATION Fieldbus H1 functionality

During hookup, the following condition should be complied with:

$$U_{1min} \leq U_{2min} - 12 \text{ mA} \times R$$

## 8 Commissioning

### General

In case of corresponding order the transmitter is ready for operation after mounting and installation of the connections. The parameters are set at the factory.

The connected lines must be checked for firm seating. Only firmly seated lines ensure full functionality.

### Checks prior to commissioning

The following points must be checked before commissioning the device:

- Correct wiring in accordance with **Electrical connections** on page 20.
- The ambient conditions must correspond to the information given on the name plate and in the data sheet.

## Communication

### HART® Communication

#### Note

The HART® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

Communication with the transmitter takes place using the HART protocol. The communication signal is modulated onto both wires of the signal line in accordance with the HART FSK 'Physical Layer' specification.

The HART modem is connected at the signal line of the current output via which power is also supplied via the power supply unit.

The device is listed with the FieldComm Group.




Figure 18: Example of HART® interface connection

Manufacturer ID	0x1A
Device-ID*	HART 5: 0x004B (0x000B), HART 7: 0x1A4B (0x1A0B)
Profile	From SW-Rev.: 03.00 (corresponds to HW-Rev.: 02.00 and higher): HART 5.9 and HART 7.6, can be switched via <ul style="list-style-type: none"> <li>• LCD indicator with configuration function</li> <li>• Tools</li> <li>• HART commands</li> </ul> Default, if nothing else ordered: HART 7.6.  To SW-Rev.: 01.03: HART 5.1 and HART 7, switchable via DIP switch. Default, if nothing else ordered: HART 5.1.  SW-Rev.: 01.01: HART 5.1, previously HART 5.
Configuration	On device using LCD indicator DTM, EDD, FDI (FIM)
Transmission signal	BELL Standard 202

\* From SW-Rev.: 03.01.00, previously see brackets

### Operating modes

- Point-to-point communication mode – standard (general address 0)
- HART 5: Multidrop mode (addressing 1 to 15)
- HART 7: Addressing 0 to 63, independent of current loop mode
- Burst Mode

### Configuration options / tools

#### Driver-independent:

- HMI LCD indicator with configuration function

#### Driver-dependent:

- Device management / Asset management tools
- FDT technology – via TTX300-DTM driver (Asset Vision Basic / DAT200)
- EDD – via TTX300 EDD driver (Handheld terminal, Field Information Manager / FIM)
- FDI technology – via TTX300 FDI Device Package (Field Information Manager / FIM)

### Diagnosis notice

- Overrange- / underrange in accordance with NE 43
- HART® diagnosis

#### Extended from SW-Rev.: 03.00:

- Device status signaling according to NE 107
- Freely configurable diagnostic categorization with diagnostic history in accordance with NE 107

### Tracking of events and configuration changes, from SW-Rev.: 03.00

The HART® device stores information on critical events and configuration changes.

The information can be output via tools:

- Event monitor for the logging of critical events
- Configuration monitor for configuration changes

For detailed information, see HART® COM/TTX300/HART interface description.

### PROFIBUS® Communication

#### Note

The PROFIBUS PA® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.

The interface conforms to Profile 3.01

(standard PROFIBUS®, EN 50170, DIN 1924 [PRO91]).




Figure 19: Example of PROFIBUS PA® interface connection

Manufacturer ID	0x1A
ID number	0x3470 [0x9700]
Profile	PA 3.01 (see PROFIBUS PA® interface description (COM/TTX300/PB))
Configuration	On device using LCD indicator DTM EDD GSD
Transmission signal	IEC 61158-2

### Voltage / current consumption

- Average current consumption: 12 mA.  
In the event of an error, the FDE function (= Fault Disconnection Electronic) integrated in the device makes sure that the current consumption cannot exceed a maximum of 20 mA.

## ... 8 Commissioning

### ... Communication

#### FOUNDATION Fieldbus® Communication

##### Note

The FOUNDATION Fieldbus® protocol is an unsecured protocol, as such the intended application should be assessed to ensure that these protocols are suitable before implementation.




Figure 20: Example of FOUNDATION Fieldbus® interface connection

Device ID	000320001F...
ITK	5.x (see FOUNDATION Fieldbus® interface description (COM/TTX300/FF))
Configuration	On device using LCD indicator EDD
Transmission signal	IEC 61158-2

#### Voltage / current consumption

- Average current consumption: 12 mA.  
In the event of an error, the FDE function (= Fault Disconnection Electronic) integrated in the device makes sure that the current consumption cannot exceed a maximum of 20 mA.

### Basic Setup

##### Note

The communication and configuration of the transmitter via HART®, PROFIBUS PA®, and FOUNDATION Fieldbus H1® are described in the separate documentation “Interface Description” for the relevant protocol (COM/TTX300/...).

The following configuration types are available for the transmitter:

- With DTM: Configuration can be performed within an FDT frame application that is approved for use with the DTM.
- With EDD: Configuration can be performed within an EDD frame application that is approved for use with the EDD.
- With FDI-Package (FIM): Configuration is possible within an FDI frame applications (Field Information Manager / FIM) for which the FDI packages are released.
- With LCD indicator Type A with operating buttons  
Commissioning via the LCD indicator does not require any tools to be connected to the device and is therefore the simplest way of configuring the TTH300.  
The general operation and menus of the LCD indicator are described in **Menu navigation** on page 32.

##### Note

Unlike configuration using the DTM, EDD or FDI-Package (FIM) the functionality of the transmitter can only be changed to a limited extent with the LCD indicator.

## 9 Operation

### Safety instructions

If there is a chance that safe operation is no longer possible, take the device out of operation and secure it against unintended startup.

### Hardware settings

#### Devices with HART® from HW-Rev.: 02.00 (corresponds to Software from SW-Rev.: 03.00 and higher)

HART devices from HW-Rev.: 02.00 do not have DIP switches. The desired HART profile (HART 7 or HART 5) the write protection are set via the operating buttons of the LCD display (optional), tools or HART commands.

#### Note

Factory setting, unless explicitly ordered otherwise:

- HART 7
- Write protection OFF

#### Devices with PROFIBUS PA®, FOUNDATION Fieldbus®, and HART® to HW-Rev.: 01.07




Figure 21: DIP switch on the transmitter  
(not for HART devices from HW rev. 02.00)

The transmitter has two DIP switches that can be accessed via a hinged cover.

- Switch 1 activates the hardware write protection.
- Switch 2 supports the FOUNDATION Fieldbus requirement for a hardware enable for simulation in accordance with ITK.

For transmitters that support HART 7, switch 2 allows the desired HART version to be set (HART 5 or HART 7).


DIP switch	Function
①	<b>Local write protection</b> Off: Local write protection deactivated On: Local write protection activated
②	<b>Enabling the simulation (only with FOUNDATION Fieldbus)</b> Off: Simulation blocked On: Simulation enabled  <b>Selecting the HART version (only with HART protocol)</b> Off: HART 5 On: HART 7

#### Note (not for HART devices from HW-Rev.: 02.00)

- Factory settings: Both switches 'OFF'. Local write protection deactivated and HART 5, unless explicitly ordered HART 7 (HART version) or simulation locked (FOUNDATION Fieldbus).
- With PROFIBUS PA devices, Switch 2 must always be in the 'OFF' position.

## ... 9 Operation

### Menu navigation



- ① Operating buttons for menu navigation
- ② Indication of menu designation
- ③ Indication of menu number
- ④ Marking to indicate relative position within the menu
- ⑤ Indication of the current function assigned to the operating buttons and

Figure 22: LCD display (example)

You can use the or operating buttons to browse through the menu or select a number or character within a parameter value.

Different functions can be assigned to the and operating buttons. The function ⑤ that is currently assigned to them is shown on the LCD display.

#### Control button functions

	Meaning
Exit	Exit menu
Back	Go back one submenu
Cancel	Cancel a parameter entry
Next	Select the next position for entering numerical and alphanumeric values

	Meaning
Select	Select submenu / parameter
Edit	Edit parameter
OK	Save parameter entered

#### Note

For detailed information on the parameterization of the device, consult the associated operating instructions.

### Process display



- ① Measuring point tagging (Device TAG)
- ② Current process values
- ③ 'Button function' symbol
- ④ 'Parameterization protected' symbol

Figure 23: Process display (example)

The process display appears on the LCD display when the device is powered on. It shows information about the device and current process values.

The way in which the current process values are shown can be adjusted on the configuration level.

The symbols at the bottom of the process display are used to indicate the functions of the operating buttons and , in addition to other information.

From SW-Rev.: 03.00, two process variables can also be optionally displayed: one is displayed above the other.

Symbol	Description
	Call up information level.
	Call up configuration level.
	The device is protected against changes in the parametrization.


## Error messages in the HART® LCD display

In the event of an error, different information appears depending on the revision:

- To SW-Rev.: 01.03: A symbol or letter (device status) and a number (DIAG.NO.)
- From SW-Rev.: 03.00: The relevant device status symbol and the associated diagnosis group.



To SW-Rev.: 01.03



From SW-Rev.: 03.00

The diagnostic messages are divided into the following groups in accordance with the NAMUR classification scheme:

Symbol letter*	Status symbols according to NAMUR NE 107**	Description	
I	not applicable	OK or Information	Device is functioning or information is available
C		Check Function	Device is undergoing maintenance (for example simulation)
S		Off Specification	Device or measuring point is being operated outside of the specifications
M		Maintenance Required	Request service to prevent the measuring point from failing
F		Failure	Error; measuring point has failed

\* To SW-Rev.: 01.03

\*\* From SW-Rev.: 03.00

The error can then be read in plain text via the “Diagnosis” information level (from SW-Rev.: 03.00).

Additionally, the diagnostic messages are divided into the following areas:

Range	Description
Electronics	Diagnosis for device hardware.
Sensor	Diagnosis for sensor elements and connection lines.
Configuration	Diagnosis of the communication interface and parameterization / configuration.
Operating conditions	Diagnosis for ambient and process conditions.
Process (from SW-Rev.: 03.00)	Notes and warnings when leaving the sensor or process temperature range.

### Note

For a detailed description of the errors and notices on troubleshooting, see "**Diagnosis / error messages**" in the **operating instruction**.

## ... 9 Operation

### Error messages in the PROFIBUS PA® and FOUNDATION Fieldbus® LCD display

In the event of an error, a message consisting of a symbol and text appears at the bottom of the process screen (e. g. electronics). The text displayed provides information about the area in which the error has occurred.



The error messages are divided into four groups in accordance with the NAMUR classification scheme. The group assignment can only be changed using a DTM or EDD:

Symbol	Description
	Error / failure
	Check function
	Outside of the specification
	Maintenance required

The error can then be read in plain-text format on the 'Diagnosis' information level.

The error messages are also divided into the following areas:

Range	Description
Electronics	Diagnosis for device hardware.
Sensor	Diagnosis for sensor elements and connection lines.
Installation / Configuration	Diagnosis for communication interface and parameterization / configuration
Operating conditions	Diagnosis for ambient and process conditions.

#### Note

For a detailed description of the errors and notices on troubleshooting, see "**Diagnosis / error messages**" in the **operating instruction**.

## Factory settings

### Firmware settings

The transmitter is configured ex works.

#### HART® devices from SW-Rev.: 03.00

These devices can be reset to the factory setting as well as to the setting according to the customer order.

- With the menu item “Factory reset” in the service menu, the settings are reset to the factory settings in accordance with the following table (corresponds to default configuration BS).
- The menu item “Reset to Order” in the service menu is used to reset the settings to the configuration ordered by the customer (default configuration BS, customer-specific configuration without special user characteristic BF or customer-specific configuration with special user characteristic BG).

The currently set HART protocol remains unchanged during “Factory reset” and “Reset to Order”.

#### Devices with PROFIBUS PA®, FOUNDATION Fieldbus®, and HART® (all SW revisions)

The following table with the corresponding parameter values applies:

Menu	Designation	Parameter	Factory setting	
Device Setup	Write protection	–	No	
	Input Sensor 1	Sensor Type	Pt100 (IEC60751)	
		R-Connection	Three-wire	
		Measured Range Begin <sup>1)</sup>	0	
		Measured Range End <sup>1)</sup>	100	
		Engineering Unit	Degrees °C	
		Damping	Off	
Process Alarm	Fault signaling <sup>1)</sup>		To SW-Rev.: 01.03: Overrange / high alarm 22 mA <sup>1)</sup> From SW-Rev.: 03.00: Underrange / low alarm 3.5 mA <sup>1)</sup>	
		Input Sensor 2	Sensor Type	Off
		Input / output assignment	Measurement type	Sensor 1
		TAG	–	–
	HART Descriptor <sup>1)</sup>	–	To SW-Rev.: 01.03: TIXXX- <sup>1)</sup>	
Display	Display Value	–	Process Variable	
	Bargraph <sup>1)</sup>	–	Yes, output % <sup>1)</sup>	
	Language	–	English	
	Contrast	–	50 %	
Communication	HART Burstmode <sup>1)</sup>	Status <sup>1)</sup>	Off <sup>1)</sup>	
	Bus Address <sup>2) 3)</sup>	–	126 <sup>2)</sup> / 30 <sup>3)</sup>	
	Simulation mode <sup>3)</sup>	–	Off <sup>3)</sup>	
	HART Protocol	–	HART 5 / 7 <sup>4)</sup>	

1) Only applies to HART transmitters

2) Only applies to PROFIBUS PA transmitters

3) Only applies to FOUNDATION Fieldbus transmitters

4) The currently set HART protocol remains unchanged during all types of reset (all SW revisions).

## 10 Maintenance

### Safety instructions

#### CAUTION

##### Risk of burns due to hot measuring media

The device surface temperature may exceed 70 °C (158 °F), depending on the measuring medium temperature!

- Before starting work on the device, make sure that it has cooled sufficiently.

If transmitters are used as intended under normal operating conditions, no maintenance is required.

#### Note

For detailed information on the maintenance of the device, consult the associated operating instructions (OI)!

## 11 Recycling and disposal

#### Note



Products that are marked with the adjacent symbol may **not** be disposed of as unsorted municipal waste (domestic waste).

They should be disposed of through separate collection of electric and electronic devices.

This product and its packaging are manufactured from materials that can be recycled by specialist recycling companies.

Bear the following points in mind when disposing of them:

- As of 8/15/2018, this product will be under the open scope of the WEEE Directive 2012/19/EU and relevant national laws (for example, ElektroG - Electrical Equipment Act - in Germany).
- The product must be supplied to a specialist recycling company. Do not use municipal waste collection points. These may be used for privately used products only in accordance with WEEE Directive 2012/19/EU.
- If there is no possibility to dispose of the old equipment properly, our Service can take care of its pick-up and disposal for a fee.

## 12 Specification

#### Note

The device data sheet is available in the ABB download area at [www.abb.com/temperature](http://www.abb.com/temperature).

## 13 Additional documents

#### Note

Declarations of conformity of the device are available in the download area of ABB at [www.abb.com/temperature](http://www.abb.com/temperature). In addition, these are also included with the device in case of ATEX-certified devices.

"Diagnosis / error messages" in the operating instruction

## 14 Appendix

### Return form

#### Statement on the contamination of devices and components

Repair and/or maintenance work will only be performed on devices and components if a statement form has been completed and submitted.

Otherwise, the device/component returned may be rejected. This statement form may only be completed and signed by authorized specialist personnel employed by the operator.

#### Customer details:

Company: \_\_\_\_\_

Address: \_\_\_\_\_

Contact person: \_\_\_\_\_

Telephone: \_\_\_\_\_

Fax: \_\_\_\_\_

Email: \_\_\_\_\_

#### Device details:

Type: \_\_\_\_\_

Serial no.: \_\_\_\_\_

Reason for the return/description of the defect: \_\_\_\_\_

\_\_\_\_\_

#### Was this device used in conjunction with substances which pose a threat or risk to health?

Yes

No

If yes, which type of contamination (please place an X next to the applicable items):

biological

corrosive / irritating

combustible (highly / extremely combustible)

toxic

explosive

other toxic substances

radioactive

Which substances have come into contact with the device?

1. \_\_\_\_\_

2. \_\_\_\_\_

3. \_\_\_\_\_

We hereby state that the devices/components shipped have been cleaned and are free from any dangerous or poisonous substances.

\_\_\_\_\_  
Town/city, date

\_\_\_\_\_  
Signature and company stamp

## Trademarks

HART is a registered trademark of FieldComm Group, Austin, Texas, USA

PROFIBUS and PROFIBUS PA are registered trademarks of PROFIBUS & PROFINET International (PI)

FOUNDATION Fieldbus is a registered trademark of FieldComm Group, Austin, Texas, USA.

## Notes

---

## **ABB Measurement & Analytics**

For your local ABB contact, visit:  
**[www.abb.com/contacts](http://www.abb.com/contacts)**

For more product information, visit:  
**[www.abb.com/temperature](http://www.abb.com/temperature)**

---

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail.  
ABB does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB.