



Valid for software versions B.12 and higher

Valid for HART software versions X.30 and higher

Model FXE4000-DE41

FXE4000-DE43

FXE4000-DE21

FXE4000-DE23



Electromagnetic Flowmeter FXE4000 (COPA-XE/MAG-XE)

Operating Instructions

D184B132U02

07.2006

Manufacturer:

ABB Automation Products GmbH

Dransfelder Straße 2
D-37079 Göttingen
Germany
Tel.: +49 551 905-534
Fax: +49 551 905-555
CCC-support.deapr@de.abb.com

© Copyright 2006 by ABB Automation Products GmbH
Subject to change without notice

This document is protected by copyright. It assists the user with the safe and efficient operation of the device. The contents may not be copied or reproduced in whole or in excerpts without prior approval of the copyright holder.

1	Safety	7
1.1	General Safety Information	7
1.2	Intended use	7
1.3	Improper use	8
1.4	Technical limit values	8
1.5	Allowed Fluids	9
1.6	Warranty provision	9
1.7	Labels and symbols	9
1.7.1	Symbols and warnings	9
1.7.2	Name Plate / Factory Tag	10
1.8	Operator liability	13
1.9	Personnel qualification	13
1.10	Returning devices	13
1.11	Transport safety information	13
1.12	Electrical installation safety information	14
1.13	Operating safety information	14
1.14	Maintenance and inspection safety information	14
2	Design and function	15
2.1	Measuring principle	15
2.2	Design	16
2.3	Device designs	16
2.3.1	Compact Design (COPA-XE)	16
2.3.2	Remote Design (MAG-XE)	17
3	Transport	18
3.1	Inspection	18
3.2	General information on transport	18
3.3	Transport of flanged units smaller than DN 450	18
3.4	Transport of flanged units larger than DN 400	19
4	Installation	20
4.1	Installation Requirements	20
4.1.1	Electrode axis	20
4.1.2	In- and outlet pipe sections	20
4.1.3	Vertical connections	20
4.1.4	Horizontal connections	20
4.1.5	Free inlet or outlet	20
4.1.6	Strongly contaminated fluids	20
4.1.7	Installation in the vicinity of pumps	21
4.1.8	Installation in larger size pipelines	21
4.2	Approved EMF for custody transfer	22

4.2.1	Approved flowmeter sizes for “cold water and waste water”	22
4.2.2	Approved flowmeter sizes for “liquids other than water and chemical fluids”	22
4.2.3	Installation requirements for volume flowrate totalizers	22
4.3	Installation	23
4.3.1	Supports for meter sizes larger than DN 400.....	23
4.3.2	General information on installation	23
4.3.3	Information on 3A conformity	24
4.3.4	Mounting the measuring tube.....	26
4.3.5	Torque information	27
4.4	Display / housing rotation	28
4.4.1	Display rotation	28
4.4.2	Housing rotation	29
4.5	Ground.....	29
4.5.1	General information on ground connections	29
4.5.2	Metal pipe with fixed flanges	29
4.5.3	Metal pipe with loose flanges	30
4.5.4	Non-metallic pipes or pipes with insulating liner	30
4.5.5	Flowmeter primary in stainless steel design, model DE 21 and DE 23	31
4.5.6	Ground for units with hard or soft rubber liners.....	31
4.5.7	Ground for devices with protective plates	31
4.5.8	Ground with conductive PTFE grounding plate	31
4.6	Electrical connection	32
4.6.1	Operating the terminals.....	32
4.6.2	Preparing the signal and excitation current cable	33
4.6.3	Signal and excitation cable connection for model FXE4000 (MAG-XE)	35
4.6.4	Connection for protection class IP68	36
4.6.5	Interconnection Diagrams	39
5	Start-up.....	46
5.1	Preliminary checks prior to start-up.....	46
5.2	Commissioning the unit.....	48
5.2.1	Switching on auxiliary power	48
5.2.2	Device configuration.....	48
5.3	Commissioning PROFIBUS PA units.....	50
5.3.1	Information on voltage/current consumption.....	53
5.3.2	System integration	53
5.4	Commissioning FOUNDATION FIELDBUS units	55
6	Parameterization.....	57
6.1	Display options	57
6.2	Data entry	58
6.3	Entering data in “short form”.....	60

6.4	Parameter overview in “short form”	61
6.5	Software history	71
6.5.1	For transmitters without communication or ACSII communication or PROFIBUS DP	71
6.5.2	For transmitters with HART protocol, PROFIBUS PA, FOUNDATION fieldbus communication.....	71
7	Error messages	72
8	Maintenance / Repair.....	74
8.1	Flowmeter primary.....	74
8.2	Cleaning	75
8.3	Gaskets	75
8.4	Replacing the transmitter	75
9	Spare parts list.....	76
9.1	Fuses for transmitter electronics	76
9.2	Cable set COPA-XE	76
9.3	Spare parts COPA-XE.....	77
9.4	Spare parts transmitter E4	78
9.4.1	Field-mount housing.....	78
9.4.2	Panel mount housing	79
9.4.3	Rail mount housing	79
9.5	Spare parts flowmeter primary	80
10	Technical data.....	81
10.1	Measuring Accuracy.....	81
10.1.1	Reference Conditions per EN 29104	81
10.1.2	Maximum Measurement Error.....	81
10.2	Model DE41F, DE41W, DE43F, DE43W	81
10.2.1	General specifications.....	81
10.2.2	Material load for flanged design model DE41F / DE43F	83
10.2.3	Material load for wafer design models DE41W/DE43W	84
10.3	Model DE 21, DE21F, DE23, DE23F	84
10.3.1	General specifications.....	84
10.3.2	Material load for devices with variable process connections DN3 ... 100 (1/10 ... 4") Model DE21_/DE23_	85
10.3.3	Material load for flanged design Model DE21F / DE23F	85
10.3.4	Material load for wafer design models DE21W / DE 23W	86
11	Transmitter	86
11.1	Specifications:	86
11.2	Housing Variants	87
11.3	Converter scale drawing FXE 4000-E4 (MAG-XE).....	88
11.3.1	Converter housing and suggested installation.....	88
11.3.2	Converter as panel mount housing	89
11.3.3	Rail mount housing	89

Contents

12 Appendix	90
12.1 Permits and certifications	90
12.2 Overview of setting parameters and technical design	91
12.3 Additional documents	93
13 Index	94

1 Safety

1.1 General Safety Information

The “Safety” chapter provides an overview of the safety aspects to be observed for the operation of the device.

The device is built based on state-of-the-art technology and is operationally safe. It was tested and left the factory in a proper state. The requirements in the manual as well as the documentation and certificates must be observed and followed in order to maintain this state for the period of operation.

The general safety requirements must be complied with completely during operation of the device. In addition to the general information, the individual chapters of the manual contain descriptions about processes or procedural instructions with specific safety information.

Only the observance of all safety information enables the optimal protection of personnel as well as the environment from hazards and the safe and trouble-free operation of the device.

1.2 Intended use

This device is intended for the following uses:

- To transmit fluid, pulpy or pasty substances with electrical conductivity.
- To measure the flowrate of the operating volume or mass flow units (at constant pressure / temperature), if a mass engineering unit is selected.

The following items are included in the intended use:

- Read and follow the instructions in this manual.
- Observe the technical ratings (refer to the section “Technical limit values”).
- Use only allowed liquids for measurement (refer to the section “Allowed fluids”)

1.3 Improper use

The following uses of the device are prohibited:

- Operation as a flexible adapter in piping, e.g., to compensate for pipe offsets, pipe vibrations, pipe expansions, etc.
- Use as a climbing aid, e.g., for assembly purposes.
- Use as a support for external loads, e.g., as a support for pipes, etc.
- Material gain, e.g., by painting over the name plate or adding parts by welding / soldering.
- Material loss, e.g., by drilling the housing.

Repairs, alterations and enhancements or the installation of replacement parts is only permissible as far as described in the manual. Further actions must be verified with ABB Automation Products GmbH. Excluded from this are repairs performed by ABB-authorized specialist shops.

1.4 Technical limit values

The device is designed for use exclusively within the stated values on the name plate and within the technical limit values specified in the data sheets.

The following technical limit values must be observed:

- The permissible pressure (PS) in the permissible fluid temperature (TS) may not exceed the pressure-temperature ratings.
- The maximum operating temperature may not be exceeded.
- The permitted ambient temperature may not be exceeded.
- The housing protection class must be observed.
- The flowmeter primary may not be operated in the vicinity of powerful electromagnetic fields, e.g., motors, pumps, transformers, etc. A minimum spacing of approx. 100 cm should be maintained. For installation on or to steel parts (e.g., steel brackets), a minimum spacing of approx. 100 mm should be maintained (based on IEC801-2 and IECTC77B).

1.5 Allowed Fluids

When measuring fluids, the following points must be observed:

- Fluids may only be used if, based on state-of-the-art technology or the operating experience of the user, it is assured that chemical and physical properties of the components coming into contact with the fluids (signal electrodes, ground electrodes, liners and, possibly, process connections, protective plates or protective flanges) are not affected during the operating life.
- Fluids with unknown properties or abrasive agents may only be used if the operator can perform regular and suitable tests to ensure the safe condition of the device.
- Observe the information on the name plate.

1.6 Warranty provision

A use contrary to the device’s stipulated use, disregarding of this manual, the use of under-qualified personnel as well as unauthorized alterations excludes the manufacturer of liability from any resulting damages. The manufacturer’s warranty expires.

1.7 Labels and symbols

1.7.1 Symbols and warnings



Danger – <Serious damage to health / risk to life>

One of these symbols in conjunction with the “Danger” warning indicates an imminent danger. If it is not avoided, death or serious injury will result.



Warning – <Bodily injury>

The symbol in conjunction with the “Warning” message indicates a possibly dangerous situation. If it is not avoided, death or serious injury could result.



Caution – <Slight injuries>

The symbol in conjunction with the “Caution” message indicates a possibly dangerous situation. If it is not avoided, slight or minor injury can result. May also be used for property damage warnings.



Attention – <Property damage>!

The symbol indicates a possibly damaging situation. If it is not avoided, the product or something in its area can be damaged.



Important!

The symbol indicates operator tips or especially useful information. This is not a message for a dangerous or damaging situation.

1.7.2 Name Plate / Factory Tag

The factory tag or name plate can be found at the following locations on the unit housing:




Fig. 1

1 Name Plate

2 Factory Tag

1.7.2.1 Identifying the device design (Variant of the electronic)

1. Identifying the model:

The model number of the device (see no. 3 in the description of the name plate) can be found on the name plate. The connection diagram for the respective model is contained in the section “Terminal connection diagrams”. Technical data, material load curves, etc., are organized by model in the section “Technical data”.

2. Identifying the transmitter design:

The transmitter design (Variant) can be identified from the plate located on the metal frame of the transmitter plug-in module (see arrow in figure showing the name plate) or based on the name plate on the transmitter housing (see the following table).

3. Identifying the software version:

Information regarding the software version is provided on the plate located on the metal frame of the transmitter plug-in module.

Variant	Description
Variant 01	Current output + pulse output active + switching input + switching output
Variant 02	Current output + pulse output active + switching input + switching output + HART protocol
Variant 03	Current output + pulse output passive + switching input + switching output
Variant 04	Current output + pulse output passive + switching input + switching output + HART protocol
Variant 05	Current output + pulse output passive + switching output + RS485
Variant 06	Pulse output passive + switching output + PROFIBUS DP
Variant 14	PROFIBUS PA 3.0
Variant 15	FOUNDATION Fieldbus
Variant 16	PROFIBUS PA 3.0 (with M12 plug)



Note

The design of variants 01 and 02 includes identical hardware. The same applies for variants 02 and 04. The pulse output is set to active or passive using jumpers.

1.7.2.2 Name Plate

The name plate is located on the transmitter housing.




Fig. 2

- | | |
|---|-----------------------------------|
| 1 CE mark (EC conformity) | 6 Protection class of housing |
| 2 Different designs of the transmitter (see the table in the section "Identifying the device design") | 7 Power supply |
| 3 Model no. of device: | 8 Max. perm. temperature of fluid |
| 4 Order no. | 9 Power Consumption |
| 5 Measuring tube lining | 10 Cs, Cz, calibration factors |

1.7.2.3 Factory Tag

The factory tag is located on the flowmeter primary housing. If the pressure equipment is subject to the PED (see section 3 para. 3 PED 97/23/EC), two labels are required:

Pressure equipment subject to PED




Fig. 3

The factory tag contains the following information:

- 1 CE mark (with number of labeled location) to confirm the device meets the requirements of pressure equipment directive 97/23/EC.
- 2 Serial number for identification of the pressure equipment by the manufacturer.
- 3 Nominal size and nominal pressure rating of pressure equipment.
- 4 Flange material, liner material and electrode material (wetted parts).
- 5 Year of manufacture and specification of fluid group as per the pressure equipment directive (PED). Fluid group 1 = hazardous liquids, gaseous.
- 6 Manufacturer of the pressure equipment.

Pressure equipment outside the applicable range of the PED



Fig. 4

The factory tag contains most of the specifications included on the plate described above with the following differences:

- There is no CE mark because the pressure equipment, as per section 3 para. 3 of the PED, is outside the applicable range of the pressure equipment directive 97/23/EC.
- The reason for the exception is specified in section 3 para. 3 of the PED. The pressure equipment is categorized as SEP (= sound engineering practice).

i

Note

If the factory tag is not present, the device is not in compliance with directive 97/23/EC. The exception applies for water, power and connected equipment accessories in accordance with guideline 1/16 of sec. 1 para. 3.2 of the pressure equipment directive.

1.8 Operator liability

- Before the use of corrosive and abrasive materials to be measured, the operator must clarify the resistance of all parts that come into contact with the materials to be measured. ABB will gladly support you with the selection, however, cannot accept any liability.
- The operators must strictly observe the applicable national regulations in their countries with regards to installation, function tests, repairs, and maintenance of electrical devices.

1.9 Personnel qualification

The installation, commissioning and maintenance of the device may only be carried out through trained specialist personell authorized by the plant operator. The specialist personnel must have read and understood the manual and comply with its instructions.

1.10 Returning devices

Use the original packaging or a suitably secure packaging for returning the device for repair or for recalibration. Include the properly filled out return form (see attachment) with the device.

According to EC guidelines for hazardous materials, the owner of hazardous waste is responsible for its disposal or must observe the following regulations for its shipping:

All delivered devices to ABB Automation Products GmbH must be free from any hazardous materials (acids, alkali, solvents, etc.).

Rinse out and neutralize hazardous materials from all hollow spaces such as between meter tube and housing. For flowmeters primary larger than DN 350, the service screw (for draining condensate fluid) at the lower point of the housing must be opened to dispose of hazardous substances and to neutralize the coil and electrode chamber. These activities must be confirmed in writing using the return form.

1.11 Transport safety information

Observe the following information:

- Depending on the device, the center of gravity may not be in the center of the equipment.
- The protective pates or dust caps mounted at the process connections of devices equipped with PTFE/PFA may only be removed before installation.

To prevent possible leakage, make sure that the liner on the flange is not cut or damaged.

Observe the following instructions:

- The flow direction must correspond to the direction indicated on the device, if labeled.
- Comply with the maximum torque for all flange bolts.
- Install the devices without mechanical tension (torsion, bending).
- Install flange and wafer units with coplanar counter flanges.
- Only install devices for the intended operating conditions and with suitable seals.
- Secure the flange bolts and nuts against pipeline vibrations.

1.12 Electrical installation safety information

The electrical connection may only be performed by authorized specialists according to the electrical plans.

Comply with electrical connection information in the manual. Otherwise, the electrical protection can be affected.

Ground the measurement system according to requirements.

1.13 Operating safety information

During operation with hot fluids, contact with the surface may result in burns.

Aggressive fluids may result in corrosion and abrasion of the liner or electrodes. As a result, pressurized fluids may escape prematurely.

Due to wear on the flange seal or process connection gaskets (e.g., aseptic threaded pipe connections, Tri-Clamp, etc.), a pressurized medium may escape.

When using internal flat gaskets, these can become embrittled through CIP/SIP processes.

1.14 Maintenance and inspection safety information

**Warning – Risk to persons!**

When the housing cover is open, EMC and protection against contact are suspended. There are electric circuits within the housing which pose a contact risk. The auxiliary power must be switched off before opening the housing cover.

**Warning – Risk to persons!**

The inspection screw (for draining condensate fluid) for devices \geq DN 450 can be under pressure. The medium which spurts out can cause severe injuries. Depressurize pipes before opening the inspection screw.

Corrective maintenance work may only be performed by trained personnel.

- Depressurize the device and adjoining lines or containers before removing the device.
- Check whether hazardous materials are used as materials to be measured before opening the device. Residual amounts of hazardous material may still be present in the device and could escape when the device is opened.
- As far as provided in the scope of the operational responsibility, check the following items through a regular inspection:
 - the pressure-carrying walls / lining of the pressure device
 - the measurement-related function
 - the leak tightness
 - the wear (corrosion)

2 Design and function

2.1 Measuring principle

Measurements performed by the electromagnetic flowmeter are based on Faraday's law of induction. A voltage is generated in a conductor when it moves through a magnetic field.

This principle is applied to a conductive fluid in the measuring tube through which a magnetic field is generated perpendicular to the flow direction (see schematic).

The voltage induced in the fluid is measured by two electrodes located diametrically opposite each other. This signal voltage U_E is proportional to the magnetic induction B , the electrode spacing D and the average flow velocity v .

Considering that the magnetic induction B and the electrode spacing D are constant values, a proportionality exists between the signal voltage U_E and the average flow velocity v . From the equation for calculating the volume flowrate, it follows that the signal voltage is linearly proportional to the volume flowrate: $U_E \sim q_v$.

The induced voltage is converted by the transmitter to standardized, analog and digital signals.




Fig. 5: Electromagnetic flowmeter schematic

1	Magnet coil	
2	Measuring tube in electrode plane	
3	Signal electrode	
U_E	Signal voltage	$U_E \sim B \cdot D \cdot v$
B	Magnetic induction	
D	Electrode spacing	$q_v = \frac{D^2 \pi}{4} \cdot v$
v	Average flow velocity	$U_E \sim q_v$
q_v	Volume flow	

2.2 Design

An electromagnetic flowmeter system consists of a flowmeter primary and a transmitter. The flowmeter primary is installed in the specified pipeline while the transmitter (MAG-XE) is mounted locally or at a central location. In the Compact Design (COPA-XE), the flowmeter primary and transmitter comprise a single unit.

2.3 Device designs

2.3.1 Compact Design (COPA-XE)

The μ P transmitter and the flowmeter primary comprise a single mechanical entity.




Fig. 6

The Compact Design comes with aluminum or stainless steel housing.

- Aluminum housing: Models FXE4000-DE43F and FXE4000-DE43W
- Stainless steel housing: Models FXE4000-DE23 / -DE23F / -DE23W

2.3.2 Remote Design (MAG-XE)

The μ P transmitter is mounted at a separate location from the flowmeter primary. Up to 50 m cable length are permitted for conductivities above $5 \mu\text{S}/\text{cm}$. The electrical connection between the transmitter and the flowmeter primary is provided by a signal cable.




Fig. 7

The transmitter is available in several designs:

- Rail / Panel mount (A)
- Field mount housing (B)

The flowmeter primary comes with aluminum or stainless steel housing.

- Aluminum housing: Models FXE4000-DE41F and FXE4000-DE41W
- Stainless steel housing: Models FXE4000-DE21 / -DE21F / -DE21W

3 Transport

3.1 Inspection

Check the devices for possible damage that may have occurred from improper transport. Damages in transit must be recorded on the transport documents. All claims for damages must be claimed without delay against the shipper and before the installation.

3.2 General information on transport

Observe the following when transporting the device to the measurement site:

- The center of gravity may not be in the center of the device.
- The protective plates or dust caps mounted at the process connections of devices equipped with PTFE/PFA may only be removed before installation. To prevent possible leakage, make sure that the liner is not cut or damaged.
- Flanged units may not be lifted by the transmitter housing or terminal box.

3.3 Transport of flanged units smaller than DN 450



Warning – Danger of injuries due to slipping meter.

The center of gravity for the complete device may be higher than the lifting straps. Make sure the device has not rotated or slipped unintentionally during transport. Support the meter laterally.

For transport of flanged units smaller than DN 450 use a lifting strap. Wrap the straps around both process connections when lifting the device. Avoid chains since these may damage the housing.




Fig. 8: Transport of flanged units smaller than DN 450

3.4 Transport of flanged units larger than DN 400



Caution - Potential damage to parts!

Use of a forklift to transport the device can bent the housing and damage the internal magnet coils.

Flanged units may not be lifted at the middle of the housing when transporting via forklift.

Flanged units may not be lifted by the terminal box or at the middle of the housing. Use only the eye bolts on the device to lift and install it in the pipeline.




Fig. 9: Transport of flanged units larger than DN 400

4 Installation

4.1 Installation Requirements

The device measures the flowrate in both directions. The factory default is forward flow, as shown in Fig. 10.




Fig. 10

The following items must be observed:

4.1.1 Electrode axis

Electrode axis (1) should be horizontal if at all possible or no more than 45° from horizontal.




Fig. 11

4.1.2 In- and outlet pipe sections

Straight inlet section	Straight outlet section
$\geq 3 \times \text{DN}$	$\geq 2 \times \text{DN}$

DN = Flowmeter primary size

- Do not install fittings, manifolds, valves etc. directly in front of the meter tube (1).
- Butterfly valves must be installed so that the valve plate does not extend into the flowmeter primary.
- Valves or other turn-off components should be installed in the outlet pipe section (2).
- For compliance with the measuring accuracy, observe the inlet and outlet pipe sections.




Fig. 12

4.1.3 Vertical connections

- Vertical installation for measurement of abrasive fluids, flow preferably from below to above.




Fig. 13

4.1.4 Horizontal connections

- Meter tube must always be completely full.
- Provide for a slight incline of the connection for degassing.




Fig. 14

4.1.5 Free inlet or outlet

- Do not install the flowmeter at the highest point or in the draining-off side of the pipeline, flowmeter runs empty, air bubbles can form (1).
- Provide for a siphon fluid intake for free inlets or outlets so that the pipeline is always full (2).




Fig. 15

4.1.6 Strongly contaminated fluids

- For strongly contaminated fluids, a bypass connection according to the figure is recommended so that operation of the system can continue to run without interruption during the mechanical cleaning.




Fig. 16

4.1.7 Installation in the vicinity of pumps

- For flowmeter primaries which are to be installed in the vicinity of pumps or other vibration generating equipment, the utilization of mechanical snubbers is advantageous.




Fig. 17

4.1.8 Installation in larger size pipelines

Determine the arising pressure loss for use of flanged reducers (1):

1. Calculate the diameter ratio d/D .
2. Determine the flow velocity from the flow range nomograph (Fig. 19).
3. Read the pressure drop on the Y-axis in Fig. 19.




Fig. 18

- d = Inside diameter of the flowmeter
- v = Flow velocity [m/s]
- Δp = Pressure drop [mbar]
- D = Inside diameter of the pipeline

Nomograph for pressure drop determinations

For adaptor with $\alpha/2 = 8^\circ$




Fig. 19

4.2 Approved EMF for custody transfer

Approvals

The design of the measurement instrument "Electromagnetic volume flowrate totalizer with electrical counter" has been approved by the National Institute for Science and Technology (Physikalisch-Technischen Bundesanstalt) in Braunschweig, Germany. The following approvals have been granted for the volume flowrate totalizer which consists of a flowmeter primary and a converter:

6.221	Electromagnetic volume flowrate totalizer with a Class "A and B" electrical counter for cold water and waste water
87.12	
5.721	Electromagnetic volume flowrate totalizer with electrical counter for liquids other than water
87.05	

Appendix (EO6) or Appendix 5 (EO5) of the certification regulations of 1988 apply to the electromagnetic volume flowrate totalizer with electrical counter.

Certification

The electromagnetic volume flowrate totalizer is certified on the test stands in Göttingen, Germany which have been approved for certification calibrations. After the calibration has been completed, the parameters which impact the certification regulations, can only be changed in the presence of a certification agent.

4.2.1 Approved flowmeter sizes for "cold water and waste water"

DN	Min. Allow. Flow Range End Value (approx. 2 m/s)	Max. Allow. Flow Range End Value (approx. 10 m/s)
25	2,4 m ³ /h	12 m ³ /h
32	5 m ³ /h	25 m ³ /h
40	9 m ³ /h	45 m ³ /h
40	14 m ³ /h	70 m ³ /h
65	24 m ³ /h	120 m ³ /h
80	36 m ³ /h	180 m ³ /h
100	56 m ³ /h	280 m ³ /h
125	84 m ³ /h	420 m ³ /h
150	128 m ³ /h	640 m ³ /h
000	220 m ³ /h	1100 m ³ /h
250	360 m ³ /h	1800 m ³ /h
300	500 m ³ /h	2500 m ³ /h
350	700 m ³ /h	3500 m ³ /h
400	900 m ³ /h	4500 m ³ /h
500	1420 m ³ /h	7100 m ³ /h
600	2000 m ³ /h	10000 m ³ /h
700	2800 m ³ /h	14000 m ³ /h
800	3600 m ³ /h	18000 m ³ /h
900	4600 m ³ /h	23000 m ³ /h
1000	5600 m ³ /h	28000 m ³ /h

4.2.2 Approved flowmeter sizes for "liquids other than water and chemical fluids"

Flowmeter Size and Maximum Allowable Flowrates				
DN	Q _{max} Liter/min			
25	Selectively	60 ... 200	In steps of	10
32	Selectively	100 ... 400	In steps of	20
40	Selectively	150 ... 750	In steps of	50
50	Selectively	250 ... 1000	In steps of	50
65	Selectively	400 ... 2000	In steps of	100
80	Selectively	700 ... 3000	In steps of	100
100	Selectively	900 ... 4500	In steps of	100
150	Selectively	2000 ... 10000	In steps of	500

Minimum Flowrates and Fluids		
DN	Minimum Flowrate Liter	Fluid
25	20	Beer
32	20	Beer
40	20	Beer, Milk
50	200	Beer, Wort
65	500	Milk, Wort, Beer
80	500	Milk, Wort, Beer
100	2000	Brine, Wort
150	2000	Brine

Min. flow range: approx. 2.5 m/s. Max. flow range approx. 10 m/s. The actual flow ranges must be in accord with the values listed in the tables. Subsequent range changes require a new calibration on an agency certified test stand.

4.2.3 Installation requirements for volume flowrate totalizers

The following installation requirements are to be observed in each case:

For flow metering in one flow direction:

Cold/Waste Water	
In front of flowmeter primary	After flowmeter primary
5 x DN	2 x DN
Other Fluids (other than water)	
10 x DN	5 x DN

For flow metering in both flow directions:

Cold/Waste Water	
In front of flowmeter primary	After flowmeter primary
5 x DN	5 x DN
Other Fluids (other than water)	
10 x DN	10 x DN




Fig. 20

4.3 Installation

4.3.1 Supports for meter sizes larger than DN 400



Warning - Potential damage to parts!

Improper support for the device may result in deformed housing and damage to internal magnet coils.

Place the supports at the edge of the housing (see arrows in the figure).

Devices with meter sizes larger than DN 400 must be mounted with support on a sufficiently strong foundation.




Fig. 21: Support for meter sizes larger than DN 400

4.3.2 General information on installation

The following points must be observed during installation:

- The flow direction must correspond to the indicated direction, if labeled.
- All flange bolts must be tightened to the maximum torque value.
- Install the devices without mechanical tension (torsion, bending).
- Install flange and wafer units with coplanar counter flanges and use only appropriate gaskets.
- Use only gaskets made from a compatible material for the fluid and fluid temperatures.
- Gaskets must not extend into the flow area since possible turbulence could influence the device accuracy.
- The pipeline may not cause any unallowable forces or torques on the device.
- Do not remove the plugs in the cable connectors until you are ready to install the electrical cable.
- Make sure the gaskets for the housing cover are seated properly. Tighten the cover properly.
- A separate transmitter (MAG-XE) must be installed at a largely vibration-free location.
- Do not expose the transmitter to direct sunlight. Provide appropriate sun protection.

4.3.3 Information on 3A conformity

The device may not be installed vertically with the terminal box or transmitter housing pointing downward.




Fig. 22



Note

The transmitter housing (COPA) cannot be rotated in 3A design.

The "mounting bracket" option no longer applies.




Fig. 23

1 Bracket

Please ensure that the leakage hole of the process connection is located at the deepest point of the installed device.



Fig. 24

1 Leakage hole

4.3.4 Mounting the measuring tube

The device can be installed at any location in a pipeline under consideration of the installation conditions.



Warning - Potential damage to device!

Use of graphite with the flange or process connection gaskets is prohibited. In some instances, an electrically conductive coating may form on the inside of the measuring tube. Vacuum shocks in the pipelines should be avoided to prevent damage to the liners (PTFE). Vacuum shocks can destroy the device.

1. Remove protective plates, if present, to the right and left of the measuring tube. To prevent possible leakage, make sure that the liner on the flange is not cut or damaged.
2. Position the measuring tube coplanar and centered between the pipes.
3. Install gaskets between the surfaces.



Note

For best results, make sure the flowmeter primary gaskets fit concentrically with the measuring tube.

4. Use the appropriate bolts for the flanges as per the section "Torque information".
5. Slightly grease the threaded nuts.
6. Tighten the nuts in a crosswise manner as shown in the figure. Observe the torque values specified under "Torques".

First tighten the nuts to 50% of maximum torque, then to 80% and finally on the third time tighten to the maximum. Do not exceed the max. torque.




Fig. 25

4.3.5 Torque information

4.3.5.1 Flanged units

Nominal size DN		Nominal pressure	Screws	Max. tightening torque
mm	Inch	PN		Nm
3-10	3/8"	40	4 x M12	8
15	1/2"	40	4 x M12	10
20	3/4"	40	4 x M12	16
25	1"	40	4 x M12	21
32	1 1/4"	40	4 x M16	34
40	1 1/2"	40	4 x M16	43
50	2"	40	4 x M16	56
65	2 1/2"	40	8 x M16	39
80	3"	40	8 x M16	49
100	4"	16	8 x M16	47
125	5"	16	8 x M16	62
150	6"	16	8 x M20	83
200	8"	16	12 x M20	81
250	10"	16	12 x M24	120
300	12"	16	12 x M24	160
350	14"	16	16 x M24	195
400	16"	16	16 x M27	250
500	20"	10	20 x M24	200
600	24"	10	20 x M27	260
700	28"	10	24 x M27	300
800	32"	10	24 x M30	390
900	36"	10	28 x M30	385
1000	40"	10	28 x M33	480

4.3.5.2 Wafer units

Nominal size DN		Nominal pressure	Screws	Max. tightening torque
mm	Inch	PN		Nm
3-8	3/8"	40	4 x M12	2,3
10	3/8"	40	4 x M12	7
15	1/2"	40	4 x M12	7
20	3/4"	40	4 x M12	11
25	1"	40	4 x M12	15
32	1 1/4"	40	4 x M16	26
40	1 1/2"	40	4 x M16	33
50	2	40	4 x M16	46
65	2 1/2"	16	8 x M16	30
80	3	16	8 x M16	40
100	4	16	8 x M20	67

4.3.5.3 Variable process connections for models DE21 and DE23

Nominal size DN		Max. tightening torque
mm	Inch	
3-10	3/8"	6,5
15	1/2"	9
20	3/4"	20
25	1	32
32	1 1/4"	56
40	1 1/2"	80
50	2	30
65	2 1/2"	42
80	3	100
100	4	125

4.4 Display / housing rotation

Depending on the installation position, the housing or display can be rotated to enable horizontal readings.




Fig. 26

4.4.1 Display rotation



Caution - Potential damage to parts!

When the housing is open, EMC protection is impaired and protection against contact is suspended. Before opening the housing, switch off power to all connecting cables.

1. Switch off auxiliary power.
2. Screw off housing cover (1).
3. Remove Phillips screws (3).
4. Pull of the display, rotate 90° to the left or right and reinstall.
5. Tighten screws for display and then attach housing cover.
6. If the flow direction indicators in the display do not match the actual flow direction, the parameter "Flow indication" should be changed from "normal" to "inverse".



Note

Check that the gaskets are properly seated when sealing the housing cover. Otherwise, the protection class IP 67 is not maintained.

4.4.2 Housing rotation

1. The transmitter housing can be rotated to the left by 90° after loosening both screws (2).
2. Tighten the screws again.

4.5 Ground

4.5.1 General information on ground connections

Observe the following items when grounding the device:

- Use the supplied green/yellow cable as a ground wire.
- Connect the ground screw for the flowmeter primary (on flange and transmitter housing) to the ground.
- The terminal box or COPA housing must also be grounded.
- For plastic pipes or pipes with insulating lining, the ground is provided by the grounding plate or grounding electrodes.
- When stray currents are present in the pipeline, install a grounding plate at the front and back of the flowmeter primary.
- For measurement-related reasons, the potentials in the ground and in the pipeline should be identical.
- An additional ground via the terminals is not required.

i

Note

If the flowmeter primary is installed in plastic pipeline, or in pipelines with an insulating lining, transient current may flow through the grounding electrode in special cases. In the long term, this may destroy the flowmeter primary, since the ground electrode will in turn degrade electrochemically. In these special cases, the connection to the ground must be performed using grounding plates.

4.5.2 Metal pipe with fixed flanges

1. Insert M6x12 threads (2) in the flanges for the pipeline.
2. Secure the ground straps (1) with screw, spring washer and shim as shown in the figure.
3. Use a copper wire (min. 2.5 mm²) to establish the ground connection between the flowmeter primary and an appropriate grounding point.




Fig. 27

4.5.3 Metal pipe with loose flanges

1. Solder the threaded nuts (2) M6 to the pipeline.
2. Secure the ground straps (1) with nuts, spring washer and shim as shown in the figure, and connect to the flowmeter primary with ground connection (3).
3. Use a copper wire (min. 2.5 mm²) to connect between the ground connection (3) and an appropriate grounding point.




Abb. 28

4.5.4 Non-metallic pipes or pipes with insulating liner

For plastic pipes or pipes with insulating lining, the ground is provided by the grounding plate as shown in the figure below or via grounding electrodes that must be installed in the device (option). If grounding electrodes are used, the grounding plate is not necessary.

1. Install the flowmeter primary with grounding plate (1) in the pipeline.
2. Connect the terminal plug for the grounding plate (3) and ground connection on the flowmeter primary (2) with the grounding strap.
3. Use a copper wire (min. 2.5 mm²) to connect between the ground connection (2) and an appropriate grounding point.




Fig. 29

4.5.5 Flowmeter primary in stainless steel design, model DE 21 and DE 23

Ground the stainless steel model as shown in the figure. The measuring agent is grounded via the adapter (1) and an additional ground is not required.




Fig. 30

4.5.6 Ground for units with hard or soft rubber liners

For devices with meter sizes DN125 and larger, the liner contains a conductive element. This element grounds the fluid.

4.5.7 Ground for devices with protective plates

The protective plates are used to protect the edges of the liner in the measuring tube, e.g., for abrasive fluids. In addition, they function as a grounding plate.

- For plastic or pipes with insulating lining, electrically connect the protective plate in the same manner as a grounding plate.

4.5.8 Ground with conductive PTFE grounding plate

For devices with a meter size between DN 10 ... 150, grounding plates made of conductive PTFE are available. These are installed similar to conventional grounding plates.

4.6 Electrical connection

4.6.1 Operating the terminals




Fig. 31

- 1 Terminals for flowmeter primary
- 2 Terminals for transmitter (remote version)
- 3 Terminals for transmitter (compact version)

4.6.2 Preparing the signal and excitation current cable

Cut to length and terminate the cable as shown.



Note

Use wire end sleeves.





Fig. 32



- 1 Measurement potential, yellow
- 2 white
- 3 Electrode signal line, red

- 4 Electrode signal line, blue
- 5 SE clamp (shield)



Note

The shields may not touch (signal short circuit).

Observe the following items when routing cables:

- The signal and excitation current cable carries a voltage signal of only a few millivolts and therefore must be routed the shortest distance possible. The maximum permissible signal cable length is 50 m.
- Avoid routing the cable in the vicinity of electrical equipment or switching elements that can create stray fields, switching pulses and induction. If this is not possible, run the signal/excitation current cable through a metal pipe and connect this to the ground.
- All leads must be shielded and connected to station ground.
- Do not run the signal cable over junction boxes or terminal blocks. A shielded excitation cable (white) is run parallel to the signal lines (red and blue). As a result, only one cable is required between the flowmeter primary and the transmitter.
- To shield against magnetic interspersion, the cable contains outer shielding that is attached to the SE clamp.
- Make sure during installation that the cable is provided with a water trap (1). For vertical installation, align the cable glands pointing downward.




Fig. 33

4.6.3 Signal and excitation cable connection for model FXE4000 (MAG-XE)

The flowmeter primary is connected to the transmitter via the signal/excitation current cable (part no. D173D025U01). The coils of the flowmeter primary are supplied with a field voltage by the transmitter over terminals M1/M2. Connect the signal/excitation current cable to the flowmeter primary as shown in the figure.

- 1 red
- 2 blue
- 3 yellow
- 4 SE clamp
- 5 Signal cable
- 6 Ground connection
- 7 white




Fig. 34

Terminal designation	Connection
1 + 2	Wires for the measuring signal.
3	Internal lead (yellow), measurement potential.
M1 + M2	Connections for magnetic field excitation.
SE	Outer cable shield.

4.6.4 Connection for protection class IP68

For flowmeters primary with protection class IP 68, the maximum flooding height is 5 m. The supplied cable (part no. D173D025U01) fulfills all submersion requirements




Fig. 35

- 1 Max. flooding height 5 m

4.6.4.1 Connection

1. Use the signal cable (part no. D173D025U01) to connect the flowmeter primary and the transmitter.
2. Connect the signal cable in the terminal box of the flowmeter primary.
3. Route the cable from the terminal box to over the maximum flooding height of 5 m.
4. Tighten the cable gland.
5. Carefully seal the terminal box. Make sure the gaskets for the cover are seated properly.



Caution - Potential damage to parts!

The jacket of the signal cable must not be damaged. Otherwise, the protection class IP 68 for the flowmeter primary cannot be ensured.



Note

As an option, the flowmeter primary can be ordered with signal cable already connected to the terminal box.

4.6.4.2 Potting the connection box

If the terminal box is to be potted on-site, a special potting compound can be ordered separately (order no. D141B038U01). Potting is only possible if the flowmeter primary is installed horizontally.

Observe the following instructions during work activity:

**Warning - General hazards!**

The sealing compound is toxic. Observe all relevant safety measures.

Risk notes: R20, R36/37/38, R42/43

Harmful by inhalation. Avoid direct skin contact. Irritating to eyes.

Safety advice: P4, S23-A, S24/25, S26, S37, S38

Wear suitable protective gloves and ensure sufficient ventilation.

Follow the instructions that are provided by the manufacturer prior to starting any preparations.

Preparation

- Complete the installation before beginning sealing activities in order avoid moisture penetration. Before starting, check all the connections for correct fitting and stability.
- Do not overfill the terminal box. Keep the potting compound away from the O-ring and the seal/groove (see below).
- Prevent the potting compound from penetrating a conduit if an NPT ½" thread is used.

Procedure

1. Remove the outer wrapper by cutting with scissors where indicated.
2. Remove the rubber end caps from the centre clip. Remove the clip.
3. Knead both components thoroughly until a uniform blend is reached.
4. Cut open the bag at a corner.
5. Carefully fill the terminal box with potting compound until the connecting cable is covered.
6. Wait before closing the cover in order to allow the compound to dry, and to release any possible gas.
7. Ensure that the packaging material and the drying bag are disposed of in an environmentally sound manner.




Fig. 36

- | | |
|-----------------|--------------------|
| 1 Packaging bag | 4 Sealing compound |
| 2 Drying bag | 5 Filling height |
| 3 Clamp | |

4.6.5 Interconnection Diagrams

4.6.5.1 FXE4000 (COPA-XE), analog communication (incl. HART)




Fig. 37

1 a) Scaled pulse output, passive:

Pulse width adjustable from 0.1 to 2000 ms, terminals V8, V9, function E9, C9
 Optocoupler specifications: $f_{max} \leq 5 \text{ kHz}$, $0 \text{ V} \leq U_{CEL} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{CEH} \leq 30 \text{ V}$,
 $0 \text{ mA} \leq I_{CEH} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{CEL} \leq 220 \text{ mA}$

b) Scaled pulse output, active:

Pulse width adjustable from 0.1 to 2000 ms, terminals V8, V9, function 9, 10
 $20 \text{ mA} < I \leq 150 \text{ mA}$, $f_{max} \leq 4 \text{ Hz}$, pulse width $\leq 50 \text{ ms}$, pulse $T_{16V} \leq 25 \text{ ms}$; on/off ratio: 1:4
 ($T_{on} : T_{off}$), $f_{max} \leq 5 \text{ kHz}$, $2 \text{ mA} \leq I \leq 20 \text{ mA}$; $16 \text{ V} \leq U \leq 30 \text{ V}$

2 Contact output:

Function selectable via software to system monitor, empty pipe, max.-min.-alarm or V/R contact output*, terminals G2, P7

Optocoupler specifications: $f_{max} \leq 5 \text{ kHz}$,
 $0 \text{ V} \leq U_{CEL} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{CEH} \leq 30 \text{ V}$;
 $0 \text{ mA} \leq I_{CEH} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{CEL} \leq 220 \text{ mA}$

3 Contact input:

Function selectable via software as external zero return, external totalizer reset, external totalizer stop, terminals G2, X1

Optocoupler specifications: $16 \text{ V} \leq U \leq 30 \text{ V}$, $R_i = 2 \text{ k}\Omega$

4 Current Output:

Adjustable, terminals +/-, Current $\leq 600 \Omega$ for 0/4 ... 20 mA,
 Current $\leq 1200 \Omega$ for 0/2 ... 10 mA, Current $\leq 2400 \Omega$ for 0 ... 5 mA,
 Option: HART-Protocol

5 Supply Power:

See name plate

6 Functional ground

*) The default factory setting is the "forward direction" signal.

4.6.5.2 FXE4000 (COPA-XE), digital communication

Valid for PROFIBUS DP, PROFIBUS PA, FOUNDATION Fieldbus, ASCII




Fig. 38

1 PROFIBUS PA:

Terminals PA+, PA-: Connection for PROFIBUS PA according to IEC 61158-2 (Profile 3.0), $U = 9 - 32 \text{ V}$, $I = 13 \text{ mA}$ (normal operation); 17 mA (fault condition / FDE)

2 ASCII-Protocol (RS485):

Terminals Ux, V8: Scaled pulse output, passive (Optocoupler), pulse width adjustable between 0.1 ms to 2000 ms ,

Optocoupler specifications: $f_{\text{max}} 5 \text{ kHz}$, $0 \text{ V} \leq U_{\text{CEL}} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{\text{CEH}} \leq 30 \text{ V}$,
 $0 \text{ mA} \leq I_{\text{CEH}} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{\text{CEL}} \leq 220 \text{ mA}$

Terminals Ux, P7: Contact output, function selectable via software e.g. to system monitor, empty pipe, max. – min. –alarm or V/R contact output

Optocoupler specifications: $f_{\text{max}} 5 \text{ kHz}$, $0 \text{ V} \leq U_{\text{CEL}} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{\text{CEH}} \leq 30 \text{ V}$,
 $0 \text{ mA} \leq I_{\text{CEH}} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{\text{CEL}} \leq 220 \text{ mA}$

Terminals A, B: Serial data link RS485 for communication using ASCII-Protocol

Terminals +, -: Current output, terminals: +/-, current $\leq 600 \text{ } \Omega$ for $0/4$ to 20 mA

3 PROFIBUS DP:

Like design 2 but terminals +VD, A, B, GND connection for PROFIBUS DP according to EN 50170

4 FOUNDATION Fieldbus:

Terminals FF+, FF-: Connection for FOUNDATION Fieldbus (H1) according to IEC 61158-2, $U = 9 \dots 32 \text{ V}$, $I = 13 \text{ mA}$ (normal operation); 17 mA (fault condition / FDE)

5 Supply Power:

See name plate

6 Functional ground

4.6.5.3 FXE4000 MAG-XE, analog communication (incl. HART)




Fig. 39

1 a) Scaled pulse output, passive:

Pulse width adjustable from 0.1 to 2000 ms, terminals V8, V9, function E9, C9
 Optocoupler specifications: $f_{max} \leq 5 \text{ kHz}$, $0 \text{ V} \leq U_{CEL} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{CEH} \leq 30 \text{ V}$,
 $0 \text{ mA} \leq I_{CEH} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{CEL} \leq 220 \text{ mA}$

b) Scaled pulse output, active:

Pulse width adjustable from 0.1 to 2000 ms, terminals V8, V9, function 9, 10
 $20 \text{ mA} < I \leq 150 \text{ mA}$, $f_{max} \leq 4 \text{ Hz}$, pulse width $\leq 50 \text{ ms}$, pulse $T_{16V} \leq 25 \text{ ms}$; on/off ratio: 1:4
 ($T_{on} : T_{off}$), $f_{max} \leq 5 \text{ kHz}$, $2 \text{ mA} \leq I \leq 20 \text{ mA}$; $16 \text{ V} \leq U \leq 30 \text{ V}$

2 Contact output:

Function selectable via software to system monitor, empty pipe, max.-min.-alarm or V/R contact output*, terminals G2, P7
 Optocoupler specifications: $f_{max} \leq 5 \text{ kHz}$, $0 \text{ V} \leq U_{CEL} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{CEH} \leq 30 \text{ V}$,
 $0 \text{ mA} \leq I_{CEH} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{CEL} \leq 220 \text{ mA}$

3 Contact input:

Function selectable via software as external zero return, external totalizer reset, external totalizer stop, terminals G2, X1
 Optocoupler specifications: $16 \text{ V} \leq U \leq 30 \text{ V}$, $R_i = 2 \text{ k}\Omega$

4 Current output:

Adjustable, terminals +/-, Current $\leq 600 \Omega$ for 0/4 ... 20 mA,
 Current $\leq 1200 \Omega$ for 0/2 ... 10 mA, Current $\leq 2400 \Omega$ for 0 ... 5 mA,
 Option: HART-Protocol

5 Supply Power:

See name plate

6 Functional ground

7 White	9 Red	11 Steel shielding
8 Blue	10 Yellow	
A Converter	B Flowmeter primary	

*) The default factory setting is the "forward direction" signal.

4.6.5.4 FXE4000 (MAG-XE), digital communication

Valid for PROFIBUS DP, PROFIBUS PA, FOUNDATION Fieldbus, ASCII




Fig. 40

1 PROFIBUS PA:

Terminals PA+, PA-: Connection for PROFIBUS PA according to IEC 61158-2 (Profile 3.0), $U = 9 - 32 \text{ V}$, $I = 13 \text{ mA}$ (normal operation); 17 mA (fault condition / FDE)

2 ASCII-Protocol (RS485):

Terminals Ux, V8: Scaled pulse output, passive (Optocoupler), Pulse width adjustable between 0.1 ms to 2000 ms ,

Optocoupler specifications: $f_{\text{max}} 5 \text{ kHz}$, $0 \text{ V} \leq U_{\text{CEL}} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{\text{CEH}} \leq 30 \text{ V}$, $0 \text{ mA} \leq I_{\text{CEH}} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{\text{CEL}} \leq 220 \text{ mA}$

Terminals Ux, P7: Contact output, function selectable via software e.g. to system monitor, empty pipe, max. – min. –alarm or V/R contact output

Optocoupler specifications: $f_{\text{max}} 5 \text{ kHz}$, $0 \text{ V} \leq U_{\text{CEL}} \leq 2 \text{ V}$, $16 \text{ V} \leq U_{\text{CEH}} \leq 30 \text{ V}$, $0 \text{ mA} \leq I_{\text{CEH}} \leq 0.2 \text{ mA}$, $2 \text{ mA} \leq I_{\text{CEL}} \leq 220 \text{ mA}$

Terminals A, B: Serial data link RS485 for communication using ASCII-Protocol

Terminals +, -: Current output, terminals: +/-, current $\leq 600 \text{ } \Omega$ for $0/4$ to 20 mA

3 PROFIBUS DP:

Like design 2 but terminals +VD, A, B, GND connection for PROFIBUS DP according to EN 50170

4 FOUNDATION Fieldbus:

Terminals FF+, FF-: Connection for FOUNDATION Fieldbus (H1) according to IEC 61158-2, $U = 9 \dots 32 \text{ V}$, $I = 13 \text{ mA}$ (normal operation); 17 mA (fault condition / FDE)

5 Supply Power:

See name plate

6 Functional ground

7 White	9 Red	11 Steel shielding
8 Blue	10 Yellow	
A Converter	B Flowmeter primary	

4.6.5.5 Interconnection examples for the peripherals with analog communication (incl. HART)

Current Output

I = internal, E = external

0/4 - 20 mA Load ≤ 600 Ω

0/2 - 10 mA Load ≤ 1200 Ω

0 - 5 mA Load ≤ 2400 Ω




Fig. 41

Pulse Output (Optocoupler)

Pulse Output active



Fig. 42

Contact Input for External Zero Return (Function assigned in software)

External Totalizer Reset




Fig. 43

Contact Output for System Monitor, Max.-Min.-Alarm, Empty Pipe or Forward/Reverse Direction Signal (Function assigned in software)

Pulse Output passive Optocoupler, Separate Forward and Reverse Pulses on Contact Output




Fig. 44

4.6.5.6 Interconnection examples for the peripherals with digital communication

Current Output (only for ASCII-Communication)

0/4 - 20 mA load: max. 600 Ω

I = internal
E = external




Fig. 45

Pulse Output and Contact Output

(only available for PROFIBUS DP or ASCII-Protocol)

Connection example for separate pulses for forward and reverse direction using the contact output




Fig. 46

Contact Output Ux / P7 (for System Monitor, Max.-Min.-Alarm, Empty Pipe or Forward/Reverse Direction Signal ,Function assigned in software)

Pulse Output Ux/V8 (Optocoupler)

1 Forward

2 Reverse

I = internal

E = external

Data Link RS485 (ASCII Protocol)

Two wire data link, half-duplex, max. cable length: 1200 m, max. 32 instruments in parallel on bus cable, twisted pair cable.

I = internal
E = external




Fig. 47

PROFIBUS DP

The resistors R1, R2, R3 are bus termination resistors. They are to be installed when the instrument is connected at an end of the bus cable.

R1 = 390 Ω; R2 = 220 Ω; R3 = 390 Ω

- 1 PROFIBUS DP Cable (e.g. CDN110: 636469890140), max. Length 20 cm
- 2 Plug for T-Box (e.g. Manuf. Weidmüller 1784790000)




Fig. 48

PROFIBUS PA / FOUNDATION Fieldbus

The resistor R and the capacitor C form the bus termination. They are to be installed when the instrument is connected to the end of the bus cable.

R = 100 Ω; C = 1 μF

- 1 PROFIBUS PA
- 2 FOUNDATION Fieldbus

I = internal

E = external




Fig. 49

Connection example using M12 Plug (only for PROFIBUS PA)




Fig. 50

As an option, the bus cable can be connected using a M12 plug instead of PG connectors (see Ordering Information for the instrument). The instrument is then shipped completely wired. Suitable sockets (Type EPG300) together with additional accessories may be found in the List Sheet 10/63.6.44 DE.

5 Start-up

5.1 Preliminary checks prior to start-up

The following points must be checked before commissioning:

- The auxiliary power must be switched off.
- The auxiliary power must match the specifications started on the name plate.



Note

The connections for the auxiliary power can be found under the cover (1) in the connection area.




Fig. 51

1 Cover

- The pin assignment must correspond to the connection diagram.
- The unit must be grounded properly.
- The temperature limits must be observed.
- The EEPROM (1) must be plugged on the display board in the transmitter. The EEPROM is labeled with an order number and an end number. The end number can be found on the name plate of the corresponding flowmeter primary. These numbers must be identical.



Fig. 52

1 EEPROM

- The flowmeter primary must be installed at a largely vibration-free location.
- The flowmeter primary and the converter must be assigned properly for the model FXE4000 (MAG-XE). The flowmeters primary have an end number of X1, X2, etc., on the name plate. The transmitters have the end numbers Y1, Y2, etc. End numbers X1 and Y1 are considered a unit.
- Pulse output setting.

The pulse output can be operated as active output (24 VDC pulse) or as passive output (optocoupler). Settings for the pulse output are shown in the following figure.




Fig. 53 Setting the pulse output using jumpers

- A Pulse passive
- B Pulse active

1 Display board

Start-up

5.2 Commissioning the unit

5.2.1 Switching on auxiliary power

After switching on the auxiliary power, the flowmeter data in the external EEPROM is compared with the data saved internally. If the data is not identical, the transmitter uploads data from the external EEPROM automatically. Once completed, the message "Primary data are loaded" is displayed. The measuring equipment is now ready for operation.

The display shows the current flowrate.

5.2.2 Device configuration

The parameter setting can be done prior shipment in accordance to customer specifications upon request. If no customer information is available, the device is delivered with factory settings.

On-site configuration requires only a few parameter settings. For information on settings, refer to the chapter "Parameterization". A short overview of the menu structure can be found in the section "Parameter overview".

The following parameters should be checked or set before start-up:

1. **Flow range** (menu items "Range" and "Unit").

The device is set to the largest flow range, unless other customer information is available. The ideal flow range is approximately 2-3 m/s. First set the engineering unit of the flow range (e.g., m³/h or l/s) under menu item "Unit", and then set the flow range end value under "Range". The smallest and largest possible flow range end values are shown in the following table.



Note

The flow range end value is fixed for custody transfer devices.

Nominal size	Flow range end value	
	minimum (0.5 m/s)	maximum (10 m/s)
3	0.2 l/min	4 l/min
4	0,4 l/min	8 l/min
6	1,0 l/min	20 l/min
8	1,5 l/min	30 l/min
10	2,25 l/min	45 l/min
15	5 l/min	100 l/min
20	7,5 l/min	150 l/min
25	10 l/min	200 l/min
32	20 l/min	400 l/min
40	30 l/min	600 l/min
50	3 m ³ /h	60 m ³ /h
65	6 m ³ /h	120 m ³ /h
80	9 m ³ /h	180 m ³ /h
100	12 m ³ /h	240 m ³ /h

Nominal size	Flow range end value	
	minimum (0.5 m/s)	maximum (10 m/s)
125	21 m ³ /h	420 m ³ /h
150	30 m ³ /h	600 m ³ /h
200	54 m ³ /h	1080 m ³ /h
250	90 m ³ /h	1800 m ³ /h
300	120 m ³ /h	2400 m ³ /h
350	165 m ³ /h	3300 m ³ /h
400	225 m ³ /h	4500 m ³ /h
450	300 m ³ /h	6000 m ³ /h
500	330 m ³ /h	6600 m ³ /h
600	480 m ³ /h	6900 m ³ /h
700	660 m ³ /h	13200 m ³ /h
800	900 m ³ /h	18000 m ³ /h
900	1200 m ³ /h	24000 m ³ /h
1000	1350 m ³ /h	27000 m ³ /h

2. Current output (menu item “Current output”)

Select the desired current range (0 ... 20 mA or 4 ... 20 mA)

3. For devices with a fieldbus, the bus address must be set (menu item “Data Link”).

4. Pulse output (menu items “Pulse factor” and “Unit”).

To set the number of pulses per volume flow unit, a unit for the totalizer (e.g., m³ or l) must be selected under “Unit”. Afterward the number of pulses has to be entered in the menu item “Pulse factor”.

5 Pulse width (menu item “Pulse width”)

The pulse width at terminals V8 and V9 can be set between 0.1 ms and 2,000 ms.

6 System zero adjustment (menu item “System zero adjustment”)

The fluid in the flowmeter primary must be at absolute zero. The flowmeter primary must be full. Select the menu “System zero adjustment”. Next press ENTER. Use the STEP key to call up “automatic” and select ENTER to start the adjustment. During the automatic adjustment, the flowmeter primary counts from 255 to 0 in the second display line. The system zero point adjustment is completed when the counter reaches zero. The adjustment lasts approx. 20 seconds.

7 Detector empty pipe

(menu item “Detector e. pipe”), for devices with meter size DN10 and larger

The measuring tube for the flowmeter primary must be full. Select the menu “Detector e. pipe”. Next press ENTER. Use the STEP key to call up “Adjust detector e. pipe” and select ENTER to start the adjustment. A number is displayed. Use the STEP or DATA key to change to the value 2000 ± 25 Hz. To accept this value, press ENTER.

Now empty the pipeline. The adjustment value displayed must rise above the value set in the “Threshold” menu. This ensures the empty pipe detector is adjusted.



Note

When configuration is complete, all data must be saved. To do so, call up the menu item “Save data to ext. EEPROM” and select ENTER.

5.3 Commissioning PROFIBUS PA units

For units with PROFIBUS PA, the bus address must be checked or configured prior to start-up. If no bus address information was supplied by the customer, the unit was shipped with its BUS address set to “126”.

The address must be reset during start-up to a number within the valid range (0 ... 125).



Note

The address selected may only appear once in the segment.

The address can be set either locally on the unit (via the DIP switches on the digital board), using system tools, or via a PROFIBUS DP master class 2 such as SMART VISION.

The factory setting for DIP switch 8 is OFF, i.e., the address is set using the fieldbus. The front cover can be unscrewed to change the settings. It is also possible to set the address via menu by using the keys on the display board.

The PROFIBUS PA interface conforms with Profile 3.0 (fieldbus standard PROFIBUS, EN 50170, DIN 19245 [PRO91]). The converter transmission signal is designed according to IEC 61158-2.



Note

The manufacturer-specific PROFIBUS PA ID no. is: 0691 hex.
The unit can also be operated with the PROFIBUS standard ID nos. 9700 or 9740.

Example of local address setting (DIP switch 8 = On)




Fig. 54 Position of DIP switches using example of FXE4000 (COPA-XE)

Switches 1, 5, 7 = ON means: $1+16+64=81 \rightarrow$ Bus address 81

Switch	1	2	3	4	5	6	7	8
Status	Unit address							Address mode
Off	0	0	0	0	0	0	0	Bus
On	1	2	4	8	16	32	64	Local

Switch assignments

Switch	Assignment
1 ... 7	PROFIBUS address
8	Defines the addressing mode: Off = Set address via bus (factory setting) On = Set address via DIP switches nos. 1-7

Unit behavior with auxiliary power switched on

After switching on the auxiliary power, DIP switch 8 is polled:

Status	
ON	The address defined by DIP switches 1-7 applies. The address can no longer be changed once the unit is in operation, since DIP switch 8 is polled only once when auxiliary power is turned on.
OFF (Default)	The transmitter uses the address stored in the FRAM of the gateway. At shipment the address is set to "126" or to the address specified by the customer. Once the unit is in operation, the address can be changed via the bus or directly on the unit using the keys on the display board. The unit must be connected to the bus.

Unit behavior after replacing transmitter electronics

When the auxiliary power is switched on again, the data from the external EEPROM is uploaded. The external EEPROM can be found on the display board. The unit must be connected to the bus.

The unit address is not stored in the external EEPROM. As a result, the transmitter starts with the default address 126. When transmitter electronics are replaced, the address must be reset once. Only then is the address stored in the FRAM of the gateway. The transmitter subsequently uses the correct address when auxiliary power is switched on.

As a final step, the ID number selector must be checked.



Note

The factory default for the selector is ID no. 0x0691. The following ID numbers can also be selected: 0x0691, 0x9700 or 0x9740.

5.3.1 Information on voltage/current consumption

The behavior when switching on the unit corresponds to Draft DIN IEC / 65C / 155 / CDV of June 1996.

The average current draw of the unit is 13 mA. The voltage on the bus line must lie in the range of 9 ... 32 V DC.

**Note**

The upper limit of the voltage is electronically limited. In the event of an error, the integrated FDE function (Fault Disconnection Electronic) integrated in the device ensures that the current consumption can rise to a maximum of 17 mA.

5.3.2 System integration

Use of PROFIBUS-PA Profile B, B3.0 ensures interoperability and interchangeability of units. Interoperability means that devices from different manufacturers can be physically connected to a bus and are communication-ready. In addition, third-party devices can be interchanged without having to reconfigure the process control system.

To support interchangeability, ABB provides three different GSD files that can be integrated in the system.

Users decide at system integration whether to install the full range of functions or only part.

**Note**

Units are interchanged using the parameter ID number selector, which can only be modified on an acyclical basis.

The following table describes the available GSD files:

Number and type of function blocks	ID number	GSD file name
1 x AI	0x9700	PA139700.gsd
1 x AI; 1 x TOT	0x9740	PA139740.gsd
1 x AI; 2 x TOT; and all manufacturer-specific parameters	0x0691	ABB_0691.gsd

The manufacturer-specific GSD file ABB_0691 can be found on the CD supplied in the delivery volume.

The standard GSD files PA1397xx.gsd are available for download from the Profibus International homepage: <http://www.profibus.com>

**Note**

GSD files ABB_0691 and the interface description for PROFIBUS PA can be found on the CD supplied in the delivery volume. This can be re-ordered at any time from ABB at no cost (part no. D699D002U01).

5.4 Commissioning FOUNDATION FIELDBUS units

For units with a FOUNDATION fieldbus, the settings of the DIP switch must be checked prior to commissioning.

When integrating the unit in a process control system, a DD file (device description) and a CFF file (common file format) are required. The DD file contains the device description. The CFF file is required for the segment engineering. The engineering can be undertaken online or offline.

The DIP switches on the unit must be set correctly as follows:

DIP switch 1 must be OFF.


DIP switch 2 must also be OFF. Otherwise, the hardware write protection would not allow to alter parameters using a process control system.

The FOUNDATION fieldbus interface for the unit is compliant with the standards FF-890/891 and FF-902/90. The transmission signal of the converter is designed in accordance with IEC 61158-2.

The device is registered with the FOUNDATION fieldbus. The registration number is: IT 008000

Registration for the FOUNDATION fieldbus is recorded under manufacturer ID 0x000320 and unit ID 0x0016.

DIP switch locations



G00152

Abb. 55

DIP switch assignments

DIP switch 1:

Simulation release of the AI function blocks

DIP switch 2:

Hardware write protection for write access via the bus (all blocks locked)

DIP-Switch	1	2
Status	Simulation Mode	Write Protect
Off	Disabled	Disabled
On	Enabled	Enabled

Bus address settings

With FF, the bus address is automatically assigned via LAS (Link Active Scheduler). The address is recognized using a unique number (DEVICE_ID). This number is a combination of the manufacturer ID, device ID and device serial number.

The behavior when switching on the unit corresponds to Draft DIN IEC / 65C / 155 / CDV of June 1996.

The average DIP current draw of the unit is 13 mA. The voltage on the bus line must lie in the range of 9 ... 32 V DC.

i**Note**

The upper limit of the voltage is electronically limited. In the event of an error, the integrated FDE function (Fault Disconnection Electronic) integrated in the device ensures that the current consumption can rise to a maximum of 17 mA.

6 Parameterization

6.1 Display options

After switching on the auxiliary power, the current process information for the measuring point is displayed.

In the first line of the display, the current flow direction (→F for forward, ←R for reverse) is displayed along with the flowrate as a percentage or a physical unit. The second line of the display shows the totalizer value (7-digit) for the current flow direction, followed by the relevant unit.

Independent of the pulse factor, the totalizer value is always the current flowrate with relevant unit. This indicator is displayed in the following text as process information.

The totalizer value for the other flow direction can be displayed by pressing the STEP or DATA keys.

Examples:

```
→F 98.14 l/h
→F 12.30000 m3
```

- 1. Line Instantaneous flow forward
- 2. Line Totalizer value, forward

```
→F 98.14 l/h
←R 516.0000 m3
```

- 1. Line Instantaneous flow forward
- 2. Line Totalizer value, reverse (multiplex mode)

```
→F 98.14 l/h
→F 10230 m3
```

- 1. Line Instantaneous flow forward
- 2. Line Totalizer overflowed. →V and m³ flash

Totalizer overflow always occurs at a value of 9,999,999 units. If the totalizer value for a flow direction is larger than 9,999,999 units, the direction indicators (→F or ←R) and the totalizer unit (e.g., m³) flash in the second line of the display. The totalizer software can register up to 250 overflows. The overflow notification can be cleared for both directions by pressing ENTER.

Error condition

When an error occurs, a message appears in the first line of the display.

```
Flowrate > 130%
→F 10230 m3
```

This message is displayed alternatively in plain text and with the relevant error number. The plain text error message provides the error with the highest priority only. However, all existing errors are shown in the number display.

For a list of all possible error messages, refer to the section “Error messages”.

In addition to the error message, the alarm output is activated via optocoupler and the current output is set to the alarm value (menu “I_{out} for alarm”) (not applicable for error 6).

6.2 Data entry

Use the keys (3) to enter data when housing is open. If closed, use the magnet stick (6) and the magnet sensors. The stick is held over the appropriate NS symbol.




Fig. 56

- | | |
|----------------------------|----------------------|
| 1 Plug-in EEPROM | 4 Magnet sensor STEP |
| 2 Magnet sensor DATA/ENTER | 5 Magnet sensor C/CE |
| 3 Operator keys | 6 Magnet |

When entering data, the transmitter remains online, i.e., current and pulse outputs show the current operating mode. The functions of the individual keys are explained in the following:

- | | | |
|--|--------|--|
| | C/CE | Toggle between operating mode and menu. |
| | STEP ↓ | The STEP key is one of two arrow keys. Use STEP to scroll forward through the menu. All the desired parameters can be called up. |
| | DATA ↑ | The DATA key is one of two arrow keys. Use DATA to scroll backward through the menu. All the desired parameters can be called up. |
| | ENTER | The ENTER function requires that both arrow keys, STEP and DATA, be pressed simultaneously. ENTER has the following functions: <ul style="list-style-type: none"> • Turn on/off Program protection. • Access the parameter to be changed and set the new, selected or default parameter. |

The ENTER function is only active for 10 seconds. If no entries are made during this period, the old value is displayed on the transmitter.

ENTER function for magnet stick operation

The ENTER function is initiated when the DATA/ENTER sensor is activated for more than 3 seconds. The display flashes to indicate that the function is active.

There are two different methods of entering data:


- Numeric entry
- Entry from specified table

**Note**

When entering data, the values are checked for plausibility and, if necessary, rejected with an appropriate message.

Parameterization

6.3 Entering data in "short form"



6.4 Parameter overview in “short form”

Submenu/parameter	Input type	Comment
<div style="border: 1px solid black; padding: 2px; margin-bottom: 10px;">*Prog. Protection* On</div> <div style="margin-left: 40px;">ENTER</div>	<p style="text-align: center;">Table/numerical format</p> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">*Prog. Protection* Off</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Prog. Prot. Code 0</div> <div style="border: 1px solid black; padding: 2px;">*Prog. Protection* Off</div>	<p>Data can be entered only when Program protection is switched off. on/off</p> <p>If a number other than “0” (factory setting) is selected for the Program protection code, Program protection can only be switched off if this number (1-255) has been entered. When Program protection is switched off, parameters can be altered.</p>
<div style="border: 1px solid black; padding: 2px; margin-bottom: 10px;">Prog. Prot. Code On</div> <div style="margin-left: 40px;">ENTER</div>	<p style="text-align: center;">numerical</p> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Old PP Code? 0</div> <div style="border: 1px solid black; padding: 2px;">New PP Code? 0</div>	<p>After the program protection is switched off, you can change the PP code.</p> <p>Enter old PP code 0 = factory setting.</p> <p>Enter the new PP code (1-255) and press ENTER to accept. The new PP code is now active.</p>
<div style="border: 1px solid black; padding: 2px;">Language English</div>	<p style="text-align: center;">table format</p>	<p>German, English, French, Finnish, Spanish, Italian, Dutch, Danish, Swedish. For HART protocol PROFIBUS PA, FOUNDATION Fieldbus, German, English only.</p>
<div style="border: 1px solid black; padding: 2px; margin-bottom: 10px;">Submenu Primary</div> <div style="margin-left: 40px;">ENTER</div>	<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Meter size DN 250 10In</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Span Cs 6.25 Hz 56.123 %</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Zero Cz 6.25 Hz 0.1203 %</div> <div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;">Short model no. DE4...</div> <div style="border: 1px solid black; padding: 2px;">Order no. 000195368/X001</div>	<p>This submenu includes other parameters in addition to the nominal meter size. These cannot be changed. This information is also found on the name plate of the flowmeter. These numbers must be identical. For present meter size, refer to the name plate of the flowmeter primary.</p> <p>Span value Cs for the selected excitation frequency. Refer to the name plate on the flowmeter primary.</p> <p>For the flowmeter zero value Cz for the selected excitation frequency. Refer to the name plate on the flowmeter primary.</p> <p>Flowmeter primary short model number.</p> <p>Order. no. for flowmeter primary. This number must be identical to the name plate of the flowmeter and with the label on the external EEPROM, which is located on the display board.</p>

Submenu/parameter	Input type	Comment
<div style="border: 1px solid black; padding: 2px; margin-bottom: 5px;"> Cal-fact 10m/s 1800.00 m³/h </div> <div style="border: 1px solid black; padding: 2px;"> Range 400.00 m³/h </div>	numerical	Cal-fact is the maximum flow at velocity of 10 m/s. Cal-fact 10 m/s set automatically via the selected meter size. Measurement range for forward and reverse flow. Min. measurement range can be set between 0-0.5 m/s (0-0.05 Cal-fact). Max. measurement range can be set between 0-10 m/s (0-1 Cal-fact). Set the end value for the measurement range (0.5 - 10 m/s). The unit is selected in the Unit submenu.
<div style="border: 1px solid black; padding: 2px;"> Pulse factor 1.0000 /m³ </div>		
<div style="border: 1px solid black; padding: 2px;"> Pulse width 30.000 </div>	numerical	For external pulse output, pulse width can be set from 0.1 - 2000 ms. For PROFIBUS and FOUNDATION fieldbus, this menu item is not displayed.
<div style="border: 1px solid black; padding: 2px;"> Low flow cut-off 1.000 % </div>	numerical	0-10% range of the flow range set under "Qmax". Applicable for display and all outputs. If the flowrate is below the low flow cut-off setting, the flow is not measured. The current output is set to zero. The switching hysteresis for the low flow cutoff is 1%.
<div style="border: 1px solid black; padding: 2px;"> Damping 10.0000 sec </div>	numerical	Damping can be set in the range from 0.5 - 99.9999 s. The value refers to the response time for a step flowrate change from 0 to 99%. It affects the instantaneous value in the display and at the current output.
<div style="border: 1px solid black; padding: 2px;"> Filter On </div>	numerical	on/off (factory setting = OFF). When the output signal is noisy, switch on the filter and set a damping time > 2.4 s.
<div style="border: 1px solid black; padding: 2px;"> Density 2.54300 g/cm³ </div>	numerical	If the totalizer and display are to use mass units of g, kg, t, pounds or uton, a fixed density value must be entered for use in the conversion calculations. To convert the flowrate to mass flow units, a density value from 0.01 to 5.0 g/cm ³ can be entered.
<div style="border: 1px solid black; padding: 2px;"> System zero adj 3.5Hz </div>		Zero point adjustment.
<div style="border: 1px solid black; padding: 2px;"> System zero adj. manual </div>		Manual entry.
<div style="border: 1px solid black; padding: 2px;"> System zero adj. automatic </div>		Valve must be closed. Pipeline must be full. Fluid must be at zero. Press ENTER to perform the automatic adjustment.

Submenu/parameter	Input type	Comment						
<p>Submenu Unit</p> <p>ENTER</p> <p>Range Unit i/s</p> <p>Totalizer Unit m³</p> <p>Unit factor 3785.41 liter</p> <p>Unit name kgal /s /min /h</p> <p>Prog. Unit Without density</p>	<p>Table/numerical format</p>	<p> Exiting the submenu.</p> <p>lbs/s, lbs/min, lbs/h, uton/min, uton/h, uton/day, l/s, l/min, l/h, hl/s, hl/min, hl/h, m³/s, m³/min, m³/h, igps, igpm, igph, mgd, gpm, gph, bbl/s, bbl/min, bbl/h, bbl/day, bbl/min, bbl/h, kg/s, kg/min, kg/h, t/s, t/min, t/h, g/s, g/min, g/h, kgal/s, gkal/min, kgal/h</p> <p>ml, l, hl, m³, ical, gal, mgal, bbl, bls, kg, t, g, Ml, lb, uton, kgal</p> <p>If a desired unit is not listed in the table, you can define a flowrate unit based on liters. The value of 3785.41 shown here applies for the unit kgal (factory setting).</p> <p>Four character name for the user programmable unit.</p> <p>Prog. Unit for mass (with density) or volume flowrate (without density).</p>						
<p>Submenu Alarm</p> <p>ENTER</p> <p>Error log 0 ... 3 ...</p> <p>Max. alarm 130%</p> <p>Min. alarm 10%</p>	<p>Table/numerical format</p>	<p> Exiting the submenu.</p> <p>All detected errors (error 0-9, A, B, C) are saved. Press ENTER to clear the error log. First press ENTER and then STEP to display the clear text for each error. The limit for the desired MAX alarm can be set in 1% increments from 0 to 130% of the flow range set under "Range". The limit value applies for forward and reverse flow.</p> <p>If the alarm is set to MAX alarm, the contact across the terminals is actuated when the flowrate exceeds the alarm setting value. An alarm condition is indicated in the display by a flashing arrow pointing up.</p> <div data-bbox="991 1361 1262 1435" style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="padding: 2px 5px;">-> F</td> <td style="text-align: center; padding: 2px 5px;"></td> <td style="padding: 2px 5px;">115.67%</td> </tr> <tr> <td style="padding: 2px 5px;">-> F</td> <td style="text-align: center; padding: 2px 5px;"></td> <td style="padding: 2px 5px;">6789.12l</td> </tr> </table> </div> <p>Alarm limit, 0-130% of the flow range set under "Range". Configurable in 1% increments, 1% switching hysteresis (see MAX alarm).</p>	-> F		115.67%	-> F		6789.12l
-> F		115.67%						
-> F		6789.12l						
<p>Submenu Prog. Input/output</p> <p>ENTER</p> <p>Terminal P7/G2 general alarm</p> <p>Terminal X1/G2 Ext. Zero Return</p>	<p>table format</p>	<p>For PROFIBUS and FOUNDATION fieldbus, this menu is not displayed</p> <p>Contact output</p> <p>Terminal P7/G2 selectable: General alarm¹⁾, empty pipe¹⁾, F/R signal, no function, MAX alarm¹⁾, MIN alarm¹⁾, MAX/MIN alarm¹⁾</p> <p>¹⁾Contact output can be configured as "normally opened or closed".</p> <p>Contact input</p> <p>Terminal X1/G2 selectable: External zero return, totalizer reset, external totalizer stop, no function. For HART protocol, the external totalizer stop is not available. For PRSOFIBUS, the contact input is not available.</p>						

Submenu/parameter	Input type	Comment		
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Submenu Current output </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">ENTER</div> <div style="border: 1px solid black; padding: 5px;"> <table border="0" style="width: 100%;"> <tr> <td style="text-align: center;">Current output</td> </tr> <tr> <td style="text-align: center;">0 - 20 mA</td> </tr> </table> </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> lout at alarm 130% </div>	Current output	0 - 20 mA	<p style="text-align: center;">table format</p>	<p>This menu does not appear for the PROFIBUS PA or FOUNDATION fieldbus. For devices without the HART protocol option, the menu structure of the menu "Current output" is as follows:</p> <p>Selections 0-20 mA/4-20 mA, 0-10 mA/2-10 mA, 0-5 mA/9-10 mA, 10-20 mA/4-12 mA, 12-20 mA</p> <p>During an error condition, the contact output in the converter can be actuated. An error message is displayed and the current output is set to a fixed value. The selections are 3.8 mA or 0 or 130% of the selected current output range. For Error 3, flowrate > 130%, the current output is 130% of the selected current output.</p> <p>If "HART communication" was selected in the submenu (only available if option was ordered), then the menu structure in the Current output menu is as follows:</p> <p>Warning: For HART protocol, the current output is fixed at 4-20 mA. The value of the current output during an error condition can be defined in the menu below (for devices with HART protocol).</p> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> lout for alarm Low </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Low Alarm 4.000 mA </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> High Alarm 24.8 mA </div>
Current output				
0 - 20 mA				
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Submenu Data link </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">ENTER</div> <div style="border: 1px solid black; padding: 5px;"> <table border="0" style="width: 100%;"> <tr> <td style="text-align: center;">Communication</td> </tr> <tr> <td style="text-align: center;">ASCII</td> </tr> </table> </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Instr. address 0 </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Baud rate 4800 Baud </div>	Communication	ASCII	<p style="text-align: center;">Table/numerical format</p>	<p>The "Data link" submenu is displayed only if this option was ordered and is registered in the transmitter. Details on ASCII, HART, PROFIBUS PA or FOUNDATION fieldbus communication can be found in the relevant supplement to the operating instructions.</p> <p>1. Communication ASCII For this configuration, the menu structure is displayed as shown in the interface submenu on the left: Select from ASCII or ASCII2w. ASCII2w means ASCII communication over a 2-wire lead. Communication is half-duplex. Default setting: ASCII</p> <p>If several devices are connected to a bus (RS485 with ASCII protocol), each device must have a different address. In the device address menu, you can set an address from 0-99. Default value: 0</p> <p>You can set transmission speed between 110 to 28800 Baud for ASCII communication.</p>
Communication				
ASCII				

Submenu/parameter	Input type	Comment
	<div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Communication HART</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Instr. address 000</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Communication Profibus PA</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Slave address 126 -BUS-</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">ID no. Selector 0x9700</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Gateway 11/2002 D200S022U01 A.13</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Communication PROFIBUS DP</div> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px;">Slave address 008</div> <div style="border: 1px solid black; padding: 5px;">Function Param. PROFIB.DP</div>	<p>2. HART communication (only available, if unit was ordered with option). For this communications protocol, the menu structure is displayed as shown in the "Data link" submenu on the left: This information is for display only. There are no further selections.</p> <p>For HART protocol, a device address can be entered. The HART protocol has provisions for creating a bus with up to 15 devices (1-15). Warning: If an address greater than 0 is set for HART protocol, the device operates in Multidrop mode, i.e., the current output is fixed at 4 mA and there is only digital communication over the current output leads.</p> <p>3. PROFIBUS PA 3.0 communication (only available, if unit was ordered with option). For this communications protocol, the menu structure is displayed as shown in the "Data link" submenu on the left: Read only – no changes possible. Only for PROFIBUS PA communication (no function for FF) display of slave address. Factory setting: 126 Information for the DIP switches. DIP switches 1-7 define the PROFIBUS address, DIP switches 8 defines the address mode: DIP switch 8 = Off = Addressing via bus or keypad using the menus for device. The message "-BUS-" is displayed. DIP switch 8 = On = Addressing via DIP switches 1-7; the message "-switch-" is displayed. Factory setting for DIP switch 8: Off Only for PROFIBUS PA communication (no function for FF) Setting the ID no. for the selector. 0x9700; 0x9740: Selections: 0x0691, 6668 Factory setting: 0x0691. It is not possible to change modes during cyclical communication, but only in STOP state. The ID no. 0x6668 provides backward compatibility with the Profile 2.0. Display of gateway software version. Display only, no changes possible. The message "No Gateway" appears, if the device is not connected to the bus.</p> <p>4. PROFIBUS DP communication (only available, if unit was ordered with option). For this communications protocol, the menu structure is displayed as shown in the "Data link" submenu on the left: PROFIBUS DP selectable. The device address on the PROFIBUS DP can be set in this menu or via the bus. In the menu, set the bus address using 3 digits. Value range 0-126 Default value: 126 Display only, no selection possible. For more information, refer to the separate interface description for PROFIBUS DP devices.</p>

Parameterization

Submenu/parameter	Input type	Comment
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Submenu Function test </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 2px 5px; margin-right: 5px;">ENTER</div> <div style="border: 1px solid black; padding: 5px; margin-left: 10px;"> Function test Iout </div> </div> <div style="border: 1px solid black; padding: 5px; margin-left: 10px;"> Function test RAM (ASIC) </div>	Table/numerical format	<p>This menu is not displayed for PROFIBUS DP/PA and FOUNDATION fieldbus.</p> <p>For PROFIBUS DP/PA and FOUNDATION fieldbus</p> <p>Function test of current output, data input in mA. Function test of int. module, auto. test of RAM (ASIC), NVRAM, EPROM (program), EEPROM, ext. EEPROM. Additional functions: Terminal P7/G2, switch S201, display, terminal X1/G2, HART command, simulation and test mode.</p>
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Submenu Detector e. pipe </div> <div style="display: flex; align-items: center; margin-bottom: 10px;"> <div style="border: 1px solid black; border-radius: 50%; padding: 2px 5px; margin-right: 5px;">ENTER</div> <div style="border: 1px solid black; padding: 5px; margin-left: 10px;"> Detector e. pipe On </div> </div> <div style="border: 1px solid black; padding: 5px; margin-left: 10px;"> Iout at empty pipe 130 % </div> <div style="border: 1px solid black; padding: 5px; margin-left: 10px; margin-top: 10px;"> alarm empty pipe On </div> <div style="border: 1px solid black; padding: 5px; margin-left: 10px; margin-top: 10px;"> threshold 2300 Hz </div> <div style="border: 1px solid black; padding: 5px; margin-left: 10px; margin-top: 10px;"> Adjust Detector e. pipe </div>	Table/numerical format	<p>A full measuring tube is essential for an accurate measurement. If this condition cannot be fulfilled, the function "Detector empty pipe" can be used to switch off all output signals in case the pipe runs empty. To activate the function, press ENTER. Then press STEP to switch detector on or off. off = detector no function on = when the measuring tube is empty, a message is displayed. The following menu appears, if the "Detector empty pipe" function is on.</p> <p>Current output status for an empty pipe: If for an empty pipe, the detector and the alarm are on, then the current output is set as follows: Selectable for 0-20 mA 0 % = 0 mA or 3.6 mA or 130 % = 26 mA. Selectable for 4-20 mA 0 % = 0 mA or 3.6 mA or 130 % = 26 mA. Set Error 3 (flowrate >130 %) always as 130 % = 26 mA. For HART protocol, Iout is displayed if empty pipe "low" or "high".</p> <p>The "low" or "high" status is set in the "Current output" menu. The alarm output is activated and the message "Empty pipe" and "Error 0" is displayed. This menu does not appear for the PROFIBUS PA or FOUNDATION fieldbus.</p> <p>on = when measuring tube is empty, message via contact P7, G2 or Ux, P7 off = when measuring tube is empty, no message via contact. This menu does not appear for the PROFIBUS PA or FOUNDATION fieldbus.</p> <p>Switching threshold 2300 Hz for actuating the pipe empty alarm.</p> <p>The measuring tube must be full. After pressing ENTER, the following information is displayed (example)</p> <div style="border: 1px solid black; padding: 5px; margin: 10px auto; width: fit-content;"> Adjust 1750 196 </div> <p>Use the STEP or DATA key to change the value 1750 to 2000 ± 25 Hz. To accept this value, press ENTER. Now empty the pipeline/measuring tube. The adjustment value displayed must rise above the value set in the "Threshold" menu. The empty pipe detector is adjusted now.</p>

Submenu/parameter	Input type	Comment
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Submenu Totalizer </div> <div style="display: flex; align-items: center;"> <div style="border: 1px solid black; padding: 5px; margin-right: 10px;">ENTER</div> <div style="border: 1px solid black; padding: 5px;"> Totalizer -> F reset </div> </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Totalizer -> F 4697.00 m³ </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Overflow -> F 250 </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Totalizer <- R reset </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Totalizer <- R 625.000 m³ </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Totalizer <- R 004 </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Totalizer function Standard </div> <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> Power outage reset </div>	<p style="text-align: center;">Table/numerical format</p>	<div style="border: 1px solid black; border-radius: 10px; padding: 5px; margin-bottom: 10px; display: flex; align-items: center;"> C/CE Exiting the submenu. </div> <p>The totalizer values and overflow counters can be reset individually for the forward and reverse flow directions by pressing ENTER. First, the number of overflows (if present) are cleared; pressing ENTER again clears the totalizer values. If the totalizer overflows, the direction indicator and unit flash in the process display. The software for the internal totalizer can register up to 250 overflows. When an overflow occurs (totalizer value > 10,000,000 units), the totalizer is reset and the overflow counter is incremented by one. If more than 250 overflows occur, the message "Overflows > 250" is displayed.</p> <p>The forward totalizer is reset using the ENTER key. If the overflow > 0, only overflow is displayed. This function is not supported for a custody transfer device.</p> <p>The totalizer value for the directions "Forward" and "Reverse" flow direction can also be preset. This allows values from an old totalizer to be transferred to a new one when replacing a transmitter. Select the parameter with the arrow keys. The current totalizer status is displayed in the second line. After pressing ENTER only the old totalizer value can be entered numerically. Press ENTER to accept the value. Totalizer preset (value is adjustable) Line 2 of display = present value</p> <p>This function is not supported for certified devices. Overflow counter max. 250, 1 overflow = pulse totalizer >9,999,999 units (display value is reset and one overflow is counted).</p> <p>See Forward Totalizer</p> <p>See Forward Totalizer</p> <p>See Forward Totalizer</p> <p>Selections are: "Standard" or "Difference totalizer". Use the STEP and DATA keys to make a selection, and is completed with ENTER. For the "Standard totalizer function", the counting pulse for forward and reverse flow is registered on two separate totalizers. If the flow direction in the "Operating mode" menu is "Forward", only the forward totalizer counts. For the "Differential count", one shared internal totalizer is used for both flow directions. For the forward flow direction, the pulses are added. For the reverse flow direction, they are subtracted. The pulse output is not affected by this setting.</p> <p>A flashing asterisk in the first line of the display indicates a power outage. Press ENTER to clear this message. This function is only available on devices with the HART protocol option.</p>

Submenu/parameter	Input type	Comment
<div style="border: 1px solid black; padding: 5px; margin-bottom: 10px;"> Submenu Display </div> <div style="text-align: center;">table format</div> <div style="display: flex; align-items: center; justify-content: center; margin: 10px 0;"> <div style="border: 1px solid black; border-radius: 50%; padding: 5px; margin-right: 10px;">ENTER</div> <div style="border: 1px solid black; padding: 5px;"> 1st Line Q [%] </div> </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> 2nd Line Totalizer </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> 1st line multipl. Q [Bar graph] </div> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> 2nd line multipl. Off </div>		<div style="border: 1px solid black; border-radius: 10px; padding: 5px; margin-bottom: 10px; display: flex; align-items: center;"> C/CE Exiting the submenu </div> <p>Select the value displayed on line 1: Flowrate in %, physical unit, totalizer, totalizer forwards, totalizer reverse, TAG no. or bar graph.</p> <p>See line 1</p> <p>In addition to displaying the first line, you can select from the following in the multiplex mode: Flowrate in %, physical unit, totalizer, totalizer forwards, totalizer reverse, TAG no., bar graph or blank line</p> <p>The display switches automatically in a 10-second cycle.</p> <p>Additional display options for PROFIBUS PA or FOUNDATION fieldbus devices: Flowrate in %, physical unit, differential totalizer, totalizer forwards, totalizer reverse, TAG no. or bar graph. Further options include: Slave address, Protection and Status, Channel, Mode, Status.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> 1. Line Sl Prot Stat </div> <p>Example of "Slave address, Protection and Status" in line 1</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> AD: 46 BUS Stop 1353 m³ </div> <p>The information is displayed as follows.</p> <p>The first line shows the current BUS address for the device (here Ad: 46); then the Address Mode "Prot" (here: BUS, i.e., the address is set via the BUS and not via DIP switches on the device.</p> <p>If DIP switch 8 is "ON", then the BUS address is defined via DIP switches 1-7 and "switch" is displayed instead of "BUS". The status of the communication is also displayed (here: Stop) (Operate, Clear or Stop) Operate for active cyclical communication. Stop if no cyclical communication is active.</p> <p>The second line shows the totalizer value for the example above.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> 1. Line Chan Mode Stat </div> <p>Example of "Channel, Mode and Status" in line 1</p> <div style="border: 1px solid black; padding: 5px; margin: 5px 0;"> A1 Auto Go.Cas 1353 m³ </div> <p>The information is displayed as follows</p> <p>The first line shows the channel (here A1) A1 corresponds to the AI block A2 corresponds to the totalizer block Tot 1 A3 corresponds to the totalizer block Tot 2 In addition, the mode of the selected block is displayed (Auto, Manual or OOS - out of service) and the status (Go.Not =Good not cascade, Go.Cas=Good cascade, Bad, unc=uncertain) The three channels (A1, A2, A3) are displayed one after the other with their mode and status.</p>

Submenu/parameter	Input type	Comment								
		<table border="1" data-bbox="884 271 1099 342"> <tr> <td>1. Line</td> <td>A1</td> <td>Value</td> <td>Unit</td> </tr> </table> <p>Example of "A1, Value and Unit" in line 1</p> <table border="1" data-bbox="884 383 1099 454"> <tr> <td>A1</td> <td>149.501</td> <td>l</td> <td>1353 m³</td> </tr> </table> <p>The information is displayed as follows.</p> <p>First, the block for the value and unit is displayed. A1 corresponds to the AI block A2 corresponds to the totalizer block Tot 1 A3 corresponds to the totalizer block Tot 2. In addition, its value is displayed (here 149,501) with physical unit (here "l" – liter). The display shows the 3 blocks in sequence (A1, A2, A3) with value and unit.</p> <p>Note: If the BUS is not connected when switching on the device, the message "No Gateway" is displayed.</p>	1. Line	A1	Value	Unit	A1	149.501	l	1353 m³
1. Line	A1	Value	Unit							
A1	149.501	l	1353 m³							
<p>Submenu Operating mode</p> <p>ENTER</p> <p>Operating mode Standard</p> <p>Flow direction Forward / Reverse</p> <p>Flow indication normal</p> <p>Load Data from ext. EEPROM</p> <p>Store Data to ext. EEPROM</p> <p>Model number 05/02 Part number B.12</p>	<p>table format</p> <p>table format</p> <p>table format</p>	<p>C/CE</p> <p>Exiting the submenu</p> <p>Standard/Fast Standard: Continuous flowrate measurements Fast: Accelerated flowrate processing (short batch times > 3 s or pulsating flow) The transmitter must be capable of operating at a higher excitation frequency. In this operating mode, faster signal measurement improves reproducibility for short measurement periods and during pump operation.</p> <p>Specify measurement direction: "Forward/reverse" or "Forward" only. For "Forward" the device measures only forward direction.</p> <p>The flow direction can be inverted, i.e., forward flow can be defined as reverse flow direction. To do so, select "Inverse"</p> <p>When replacing the transmitter, data from the external EEPROM is uploaded automatically when auxiliary power is switched on. Data can also be loaded from the external EEPROM upon command.</p> <p>Important! After startup, the current settings must be stored in the external EEPROM. This also applies when changing settings. Indicates the software version in use. 05/02 = release date B.12 = version level</p>								

Submenu/parameter	Input type	Comment
<div style="border: 1px solid black; padding: 5px; width: fit-content; margin-bottom: 10px;">TAG number</div> <div style="border: 1px solid black; padding: 5px; width: fit-content; margin-top: 100px;">Service code</div>		<p>A max. 16-character, alphanumeric TAG number for the measuring point can be entered using upper and lowercase letters or numbers.</p> <p>For devices with the HART protocol option or PROFIBUS PA / FOUNDATION fieldbus, the following menu is displayed:</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px; width: fit-content;">Communication TAG</div> <p>An alphanumeric identifier can be entered here for the meter location (8 characters).</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px; width: fit-content;">Customer TAG</div> <p>An alphanumeric measuring point name (16 characters) is displayed here. Can only be set via BUS, e.g., using SMARTVISION.</p> <div style="border: 1px solid black; padding: 5px; margin-bottom: 5px; width: fit-content;">Message</div> <p>An alphanumeric measuring point name (32 characters) is displayed here. Can only be set via BUS, e.g., using SMARTVISION.</p> <p>For ABB Service only</p>

6.5 Software history

6.5.1 For transmitters without communication or ACSII communication or PROFIBUS DP

Software D699B179U01		
Software version	Type of changes	Documentation/ Enhancements
B.10	Original software Transmitter can be operated via ASCII protocol	-
B.11	Software optimization, optimization of start routine	-
B.12	Implemented slave address for PROFIBUS DP	Updated software menu for setting address
B.13	Software supports external zero point adjustment for open collector	Updated software menu for external zero point adjustment

6.5.2 For transmitters with HART protocol, PROFIBUS PA, FOUNDATION fieldbus communication

Software D699B180U01		
Software version	Type of changes	Documentation/ Enhancements
X.10	-	Upgraded HART software to DN600-1000
X.20	Function enhancement	Incorporated new HART commands
X.21	Function enhancement	Implemented menu for querying analog resets in the service area
X.22	-	Message when switching on changed from "Bailey Fischer&Porter" to "ABB Automation"
X.23	Enhanced functionality of PROFIBUS PA3.0	Software menu updated to include to "PROFIBUS and FF menu".
X.31	Software adaptation for PROFIBUS PA3.0	To enable operation of PROFIBUS PA3.0 as well as FOUNDATION fieldbus, software adaptations were performed
X.33	Function enhancement	Implementation of "ID no. selector" for purpose of backward compatibility between PA3.0 -> PA2.0
X.34	Function enhancement	Limited max. adjustable alarm current. Manufacturer specific HART commands added
X.35	Function enhancement	Enables readout of gateway software version

7 Error messages

The following list of error messages provides explanations of the error codes shown in the display. When entering information, the error codes 0 to 9, A, B, C do not appear.

Error code	System errors	Error removal
0	Pipeline not filled.	Open shut-off devices; fill pipeline; adjust Detector empty pipe cut-off
1	A/D converter	Reduce flowrate, throttle shut-off device.
2	Positive or negative reference too small	Check connection board and transmitter.
3	Flowrate greater than 130%	Reduce flowrate, change flow range.
4	External zero return activated	Zero return activated by pump or field contact.
5	RAM defective 1. Error 5 appears in the display: second error 5 appears in Error log only	Program must be reinitialized. Contact ABB Service department. Information: Corrupted data in RAM, computer automatically resets and uploads data from EEPROM.
7	Positive reference is too large	Check signal cables and magnetic field excitation.
8	Negative reference is too large	Check signal cables and magnetic field excitation.
6	Error > V	Reset forward totalizer or preset new values in totalizer.
	Error totalizer < R	Reset reverse totalizer or preset new values in totalizer.
	Error totalizer	Forward/reverse or difference totalizer is defective Reset forward/reverse totalizer
9	Excitation frequency is incorrect	Check line frequency for supply power 50/60 Hz or for AC/DC auxiliary power error in the digital signal board.
A	MAX alarm limit value	Reduce flowrate.
B	MIN alarm limit value	Increase flowrate.
C	Flowmeter primary data invalid	The data for the flowmeter primary in the external EEPROM is invalid. Compare data in the submenu "Flowmeter primary" with data listed on the name plate. If the values match, use "Store primary" to reset the error message. If the values are not identical, the flowmeter primary data must first be reentered and must then be completed with "Store primary". Contact ABB Service.
10	Entry > 1.00 Q _{max} DN > 10 m/s	Reduce flow range Q _{max} .
11	Entry > 0.05 Q _{max} DN > 0.5 m/s	Increase flow range Q _{max} .
16	Entry > 10% low flow cut-off	Decrease input value.
17	Entry < 0% low flow cut-off	Increase input value.
20	Entry ≥ 100 s Damping	Decrease input value.
21	Entry < 0.5 s damping	Increase entry value (as a function of the excitation frequency).
22	Entry > 99 device address	Decrease input value.
38	Entry > 1000 pulse/unit	Decrease input value.
39	Entry < 0.001 pulse/unit	Increase input value.

Error code	System errors	Error removal
40	Max. pulse frequency exceeded, scaled pulse output, pulse factor (5 kHz)	Reduce pulse factor.
41	Min. pulse frequency below limit < 0.00016 Hz	Increase pulse factor.
42	Entry > 2000 ms pulse width	Decrease input value.
43	Entry < 0.1 ms pulse width	Increase input value.
44	Entry > 5.0 g/cm ³ density	Decrease input value.
45	Entry < 0.01 g/cm ³ density	Increase input value.
46	Input too large	Reduce pulse width entry value.
54	Zero flowmeter primary > 50 Hz	Check the ground and ground signals. Adjustment can be made if the flowmeter primary is filled with fluid and the flowrate is zero.
56	Entry > 3000 threshold Detector empty pipe	Reduce entry value, check "Detector empty pipe" adjustment.
74/76	Entry > 130% MAX – or MIN alarm	Decrease input value.
91	Data in internal EEPROM invalid	Data in internal EEPROM invalid, for corrective measures, see Error code 5.
92	Data in ext. EEPROM incorrect	Data (e.g., Q _{max} , damping) in external EEPROM is invalid, access possible. Occurs when function "Store data in ext. EEPROM" was not called. Use the function "Store data to ext. EEPROM" to clear the error message.
93	Ext. EEPROM is incorrect or not installed	No access possible, component defective. If the component is not installed, the current ext. EEPROM that belongs to the flowmeter must be plugged in above the display.
94	Ver. ext. EEPROM incorrect	The database has not been updated to the present software version. Use the function "Load data from ext. EEPROM" to automatically update the external data. Use the function "Store data to ext. EEPROM" to clear the error message.
95	External flowmeter primary data incorrect	See error code C.
96	Ver. EEPROM incorrect	Database version in the EEPROM is different from the installed software. Clear the error by selecting "Update".
97	Flowmeter primary incorrect	The data for the flowmeter primary in the internal EEPROM is invalid. Clear the error by selecting "Load primary". (see error code C)
98	Ver. EEPROM is incorrect or not installed	No access possible, components defective. If the component is not installed, the current EEPROM that belongs to the flowmeter must be plugged in.
99	Input too large Entry is too small.	Reduce input value. Increase input value.

8 Maintenance / Repair

Repair and maintenance activities may only be performed by authorized customer service personnel.

When replacing or repairing individual components, original spare parts must be used.



Caution - Potential damage to parts!

The electronic components of the printed circuit board can be damaged by static electricity (observe ESD guidelines). Make sure that the static electricity in your body is discharged when touching electronic components.



Warning – Electrical voltage risk!

When the housing is open, EMC protection is impaired and protection against contact is suspended.

Before opening the housing, switch off power to all connecting cables.

8.1 Flowmeter primary

Essentially no maintenance is required for the flowmeter primary. The following items should be checked annually:

- Ambient conditions (air circulation, humidity)
- Seal integrity of the process connections
- Cable entry points and cover screws,
- Operational reliability of the auxiliary power feed, the lightning protection and the grounds

The flowmeter primary electrodes must be cleaned when the flowrate information on the transmitter changes when recording the identical flowrate volume. If the display shows a higher flowrate, the contamination is insulating. If the flowrate displayed is lower, the contamination results in a short-circuit.

For repairs to the lining, electrodes or magnet coil, the flowmeter must be returned to the local office of ABB.



Note

When sending the flowmeter to the local office of ABB, complete the return form in the appendix and include with device.

8.2 Cleaning

When cleaning the exterior of meters, make sure that the cleaning agent used does not corrode the housing surface and the seals.

8.3 Gaskets

Some device designs are shipped with special gaskets. These gaskets must be used and installed properly to prevent leakage.

For all other device designs, use commercially available gaskets made from a compatible material for the fluid and prevailing temperature (rubber, PDPE, It, EPDM, silicon, Viton, etc.).



Note

A flowmeter primary in wafer configurations is installed without gaskets directly in the pipeline.

8.4 Replacing the transmitter

The parameter settings are stored in an EEPROM (1). The EEPROM can be found on the display board.

If the converter electronic is replaced, the parameter settings can be transferred plugging the EEPROM on the Displayboard of the new converter. Flowmeter-specific data is updated automatically.




Fig. 57: Example COPA-XE

- | | |
|----------------------------|----------------------|
| 1 Pluggable in EEPROM | 4 Magnet sensor STEP |
| 2 Magnet sensor DATA/ENTER | 5 Magnet sensor C/CE |
| 3 Operator Keys | |



Warning – Electrical voltage risk!

When the housing is open, EMC protection is impaired and protection against contact is suspended.

- Power to all connecting cables must be switched off.

9 Spare parts list

**Note**

Spare parts can be ordered from your local ABB Service

9.1 Fuses for transmitter electronics




Fig. 58

No.	Description	Order number
1	Fuse for 24 V AC/DC (1 A) Fuse for 100 -230 V AC (0.5 A)	D151B025U07 D151B025U05
2	Fuse F103 (0.125 A)	D151F003U14

9.2 Cable set COPA-XE

- 1 Cable set for connecting transmitter plug-in module and terminal block (I/O), (see following table)
- 2 Cable for auxiliary power
- 3 Cable for electrode signal
- 4 Cable for coil excitation




Fig. 59

To identify the design of the transmitter, refer to the name plate located on the metal frame of the transmitter.

Model no.:	DE43F
Order no.:	25702/X001
U/f:	AC/DC 24 V 50/60 Hz
S _{max} :	< 10 VA
Variant:	04

Description	Order number for cable set (see item 1 in Fig. 59)
Variant 01-04 (Current output + pulse output active + switching input + switching output)	D677A294U01
Variant 05 (Current output + pulse output passive + switching output + RS485)	D677A294U04
Variant 06 (Pulse output passive + switching output + PROFIBUS DP)	D677A294U05
Variants 11, 13, 14, 16 (PROFIBUS PA 3.0)	D677A294U08
Variant 15 (FOUNDATION Fieldbus)	D677A294U09

9.3 Spare parts COPA-XE



Fig. 60

No.	Description	Order number
1	Cover with window (new)	D641A023U11
2	Cable gland M20x1.5	D150A008U15
3	Cover "small"	D379D167U02
4	O-ring 100x3.5	D101A026U01

9.4 Spare parts transmitter E4

9.4.1 Field-mount housing




Fig. 61

No.	Description	Order number
1	Field-mount housing M20x1.5 complete (empty), without transmitter plug-in module, without connection board	D641A033U01
2	Lens screw with Phillips head M4x10	D004G108AU01
3	Cover small	D641A029U01
4	Cable gland M20x1.5	D150A008U15
5	Spring washer	D085D020AU20
6	Connection board compl. incl. cable set for standard outputs incl. HART (variants 01-04).	D674A861U01
	Connection board compl. incl. cable set for RS485 (variant 05).	D674A861U02
	Connection board compl. incl. cable set for PROFIBUS DP (variant 06/09).	D674A861U03
	Connection board compl. incl. cable set for PROFIBUS PA or FOUNDATION fieldbus (variants 11, 13, 14, 16)	D674A861U04
	Set, consisting of parts 2, 3, 4, 5	D614L996U01

9.4.2 Panel mount housing



Abb. 62

No.	Description	Order number
1	Panel mount housing compl. incl. cable set, variants 1-5, 7	D674A663U01
2	Panel mount housing compl. incl. cable set, variants 6	D674A663U02

9.4.3 Rail mount housing



Abb. 63

No.	Description	Order number
1	Rail mount housing compl. incl. cable set, variants 1-5	D674A572U03
2	Rail mount housing compl. incl. cable set, variants 6	D674A572U02

9.5 Spare parts flowmeter primary




Fig. 64

No.	Description	Order number	
		for model DE21	for model DE41
1	Housing cover gasket	D333F016U01	D333F022U01
2	Screw M4 x 14 with Insert ring and Spacer	D396B013U01 D115B004U01 D375A018U01	D009G113AU20 D085A021BU20 D106A001U25
3	Housing cover	D612A127U01	D612A152U01
4	Terminal box, bottom section	D612A128U01	D612A153U09
5	Cable gland	D150A008U02	D150A004U14 (M20 x 1.5)
6	Sealing ring for seal plugs	D150Z007U06	-
7	Seal plugs	D150Z007U05	D150Z007U08 (M20 x 1.5)
8	Terminal board compl.	D684A690U02	D685A862U02

The parts are also available as a set

Description	Consisting of parts – numbers	Order number	
		for model DE21	for model DE41
Set 1 “Housing cover”	1, 2, 3	D614L999U01	D614L999U02
Set 2 “Gasket”	5, 6, 7	D614L998U01	D614L998U02
Set 3 “Terminal board”	8	D614L997U01	D614L997U02

10 Technical data

10.1 Measuring Accuracy

10.1.1 Reference Conditions per EN 29104

Fluid Temperatures	20 °C (68 °F) ± 2 K
Ambient Temperature	20 °C (68 °F) ± 2 K
Supply Power	Line voltage per name plate UN ± 1 % and Frequency f ± 1 %
Installation Conditions	- Upstream >10xDN straight section - Downstream >5xDN straight section
Warm Up Phase	30 min

10.1.2 Maximum Measurement Error

Pulse Output (Standard Calibration; 0.5% of rate):

- $Q > 0.07 Q_{maxDN} \pm 0.5 \%$ of rate
- $Q < 0.07 Q_{maxDN} \pm 0.00035 Q_{maxDN}$

Q_{maxDN} = maximum flowrate for the flowmeter size 10 m/s

Pulse Output (Optional Calibration; 0.25 % of rate):

- $Q > 0.14 Q_{maxDN} \pm 0.25 \%$ of rate
- $Q < 0.14 Q_{maxDN} \pm 0.00035 Q_{maxDN}$

Q_{maxDN} = maximum flowrate for the flowmeter size 10 m/s

Analog Output Effects

Same as pulse output plus $\pm 0.1 \%$ of rate.




Fig. 65

- Y Accuracy ± of rate in [%]
- X Flow velocity v in [m/s]

10.2 Model DE41F, DE41W, DE43F, DE43W

10.2.1 General specifications

Min. allow. Pressure as a function of Fluid Temperature

Liner	Meter Size	P _{Operation} at T _{Operation} *	mbar abs.
Hard rubber	15 ... 250 (1/2 ... 10")	0	< 90 °C (194 °F)
	300 ... 1000 (12 ... 40")	0	< 90 °C (194 °F)
Soft rubber	50 ... 250 (2 ... 10")	0	< 90 °C (194 °F)
	300 ... 1000 (12 ... 40")	0	< 90 °C (194 °F)
PTFE KTW approved	10 ... 600 (3/8 ... 24")	270	< 20 °C (68 °F)
		400	< 100 °C (212 °F)
PFA	3 ... 100 (1/10 ... 4")	500	< 130 °C (266 °F)
		0	< 130 °C (266 °F)

*) Higher temperatures are allowed for CIP/SIP cleaning for limited time periods, see Table „Maximum Allowable Cleaning Temperature“.

Max. Allowable Cleaning Temperature

CIP-Cleaning	Liner:	T _{max}	T _{max} minutes	T _{Amb.}
Steam cleaning	PTFE, PFA	150 °C (302 °F)	60	25 °C (77 °F)
Liquid cleaning	PTFE, PFA	140 °C (284 °F)	60	25 °C (77 °F)

If the ambient temperature is > 25°C, then the difference must be subtracted from the max. cleaning temperature. $T_{max} - \Delta \text{°C}$. $\Delta \text{°C} = T_{Amb.} - 25 \text{°C}$.

Technical data

Min. Allowable Ambient Temperature as a function of Fluid Temperature

For flowmeters with carbon steel flanges




Fig. 66

For flowmeters with stainless steel flanges




Fig. 67

- Y = Ambient temperature °C/°F
 X = Fluid temperature °C/°F
 — Temperature range for COPA-XE
 - - - - - Temperature range for MAG-XE

Remark:

- Max. allow. fluid temperature for hard/soft rubber liners ≤ 90 °C (194 °F)
- Max. allow. fluid temperature for PTFE/ PFA liners ≤ 130 °C (266 °F)

Materials, Flowmeter Primary

Part	Standard	Options
Liner	PTFE, PFA, hard rubber, soft rubber	—
Signal and ground electrodes for - Hard rubber, soft rubber	SS 1.4571 [316Ti]	Hast. B-3 (2.4600), Hast. C-4 (2.4610), Titanium, Tantalum, Platinum-Iridium, 1.4539 [904L]
- PTFE, PFA	Hast. C-4 (2.4610)	SS1.4571[316Ti] Hast. B-3 (2.4600) Titanium, Tantalum, Platinum-Iridium, 1.4539 [904L]
Ground plate	SS 1.4571 [316Ti]	Upon request
Protection plate	SS 1.4571 [316Ti]	Upon request

Process Connection Materials

Part	Standard	Options
Flange DN 3 ... 15 (1/10 ... 1/2") DN 20 ... 400 (3/4 ... 16")	SS 1.4571 [316Ti] (standard) Steel (galvanized)	SS1.4571-[316Ti]
DN 450 ... 1000 (18 ... 40")	Steel (painted)	SS1.4571-[316Ti]

Part	Standard	Options
Housing DN 3 ... 400(1/10 ... 16")	Two-piece cast aluminum housing, painted, paint coat 60 µm thick, RAL 9002	—
DN 450 ... 1000 (18 ... 40")	Welded steel construction, painted, paint coat 60 µm thick, RAL 9002	—
Connection box	Cast alum., painted, 60 µm thick, frame: dark gray, RAL7012, cover: light gray, RAL 9002	—
Meter tube	SS 1.4301 [304]	—
PG-Connector	Polyamide	—

Storage Temperature

- 20 °C (-4 °F) ... +70 °C (158 °F)

Protection Class per EN 60529

IP 67

IP 68 (only for MAG-XE flowmeter primary)

Pipeline Vibration Following EN 60068-2-6

The following applies for compact design FXE4000 (COPA-XE):

- In the range of 10 - 55 Hz max. 0.15 mm deflection
- In the range of 55 -150 Hz max. 2 g acceleration

The following applies for separate converter (MAG-XE):

Converter

- In the range of 10 - 55 Hz max. 0.15 mm deflection

Flowmeter primary

- In the range of 10 - 55 Hz max. 0.15 mm deflection
- In the range of 55 -150 Hz max. 2 g acceleration

Designs

The flanged flowmeters comply with the installation lengths defined in VDI/VDE 2641, ISO 13359 or DVGW (W420, Design WP, ISO 4064 short).

10.2.2 Material load for flanged design model DE41F / DE43F

Limits for the allowable fluid temperature (TS) and allowable pressure (PS) are a function of the liner and flange materials of the flowmeter (see instrument name plate).

Max. temperature ≤ 90 °C (194 °F) for hard/soft rubber liners

Max. temperature ≤ 130 °C (266 °F) for PTFE/PFA liners

DIN-Flange SS 1.4571 [316Ti] to DN 600 (24")




Fig. 68

ASME Flange SS1.4571[316Ti] to DN 300 (12") (CL150/300) to DN 1000 (40") (CL150)




Fig. 69

DIN-Flange Steel to DN 600 (24")




Fig. 70

ASME flange carbon steel to DN 300 (12") (CL150/300) to DN 1000 (40") (CL150)




Fig. 71

JIS 10K-B2210 flange

Meter Size	Material	PN	TS	PS [bar]
32 ... 100 (1¼ ... 4")	SS1.4571-[316Ti]	10	-25 ... +130 °C (-13 ... +266 °F)	10
32 ... 100 (1¼ ... 4")	Carbon Steel	10	-25 ... +130 °C (-13 ... +266 °F)	10

Max. temperature ≤ 90 °C (194 °F) for hard/soft rubber liners

DIN-Flange SS 1.4571 DN 700 (28") to DN 1000 (40")




Fig. 72

DIN-Flange carbon steel DN 700 (28") to DN 1000 (40")




Fig. 73

Technical data

10.2.3 Material load for wafer design models DE41W/DE43W

Meter Size	TS _{max}	TS _{min}	PS _{max} [bar]
3-100 (1/10 ... 4")	130 °C (266 °F)	-10 °C (14 °F)	16 (CL 150)

10.3 Model DE 21, DE21F, DE23, DE23F

10.3.1 General specifications

Minimum Allowable Absolute Pressure

Liner	Meter Size	mbar abs.	at	T _{operation} *
PFA	3 ... 100 (1/10 ... 4")	0		< 130 °C (266 °F)

*) Higher temperatures are allowed for CIP/SIP cleaning for limited time periods, see Table „Maximum Allowable Cleaning Temperature“.

Max. Allowable Cleaning Temperature

CIP-Cleaning	Liner:	T _{max}	minutes	T _{Amb.}
Steam cleaning	PFA	150 °C (302 °F)	60	25 °C (77 °F)
Liquid cleaning	PFA	140 °C (284 °F)	60	25 °C (77 °F)

If the ambient temperature is > 25, then the difference must be subtracted from the max. cleaning temperature.

$$T_{max} - \Delta \text{ °C} \cdot \Delta \text{ °C} = T_{Amb.} - 25 \text{ °C}$$

Maximum Allowable Temperature Shock

Liner	Temp Shock max. Temp. Diff. °C	°C/min
PFA	any	any

Min. Allowable Ambient Temperature as a function of Fluid Temperature




Fig. 74

- Y = Ambient temperature °C/°F
- X = Fluid temperature °C/°F
- Temperature range for COPA-XE
- Temperature range for MAG-XE

Materials, Flowmeter Primary

Liner	Electrode Material		Electrodes Design	
	Standard	Options	Standard	Options
PFA	Hast.-C4 (1.4539 for food ind. fittings & Tri-Clamp)	Hast.-B3 W.-Nr. 1.4539 W.-Nr. 1.4571 tantalum, titanium, platinum-iridium	Flat head	Pointed head (≥ DN 10)

Process Connection Materials

Process Connection	Standard
Flange	SS 1.4571 [316Ti]
Wafer design	None
Weld stubs	SS 1.4404 [316L]
Food ind. fitting	SS 1.4404 [316L]
Tri-Clamp	SS 1.4404 [316L]
External threads	SS 1.4404 [316L]

Connection Box	Standard	Option
COPA-XE	Cast alum., painted, frame paint coat: dark gray, RAL7012, cover: light gray, RAL 9002	Converter housing made completely of Str. Stl. SS 1.4301 [304]
MAG-XE	SS 1.4301 [304]	-
Meter tube	SS 1.4301 [304]	-
PG-Connector	Polyamide	-
Flowmeter primary housing	Deep drawn housing SS 1.4301 [304]	

Gasket Material

Process Connection	Gasket Material
Wafer design	None
Weld stubs, food ind. fittings, Tri-Clamp, external threads	EPDM (Ethylene-Propylene) with FDA approval, silicone with FDA approval
Housing gasket	Silicone

Storage Temperature

- 20 °C (-4 °F) ... +70 °C (158 °F)

Protection Class per EN 60529

IP 67

IP 68 (only for MAG-XE flowmeter primary)

Pipeline Vibration Following EN 60068-2-6

The following applies for compact design FXE4000 (COPA-XE):

- In the range of 10 - 55 Hz max. 0.15 mm deflection
- In the range of 55 - 150 Hz max. 2 g acceleration

The following applies for separate converter (MAG-XE):

Converter

- In the range of 10 - 55 Hz max. 0.15 mm deflection

Flowmeter primary

- In the range of 10 - 55 Hz max. 0.15 mm deflection
- In the range of 55 - 150 Hz max. 2 g acceleration

10.3.2 Material load for devices with variable process connections DN3 ... 100 (1/10 ... 4") Model DE21_/DE23_

Process Connection Liner PFA	Meter Size	PS _{max} [bar]	TS _{min}	TS _{max}
Wafer design	3 ... 50 (1/10 ... 2")	40	-25 °C (-13 °F)	130 °C (266 °F)
	65 ... 100 (2 1/2 ... 4")	16		
	3 ... 40 (1/10 ... 1 1/2")	40		
Weld stubs	50, 80 (2", 3")	16	-25 °C (-13 °F)	130 °C (266 °F)
	65, 100	10		

	(2 1/2", 4")			
Food ind. fittings per DN 11851	3 ... 40 (1/10 ... 1 1/2")	40	-25 °C (-13 °F)	130 °C (266 °F)
	50, 80 (2", 3")	16		
	65, 100 (2 1/2", 4")	10		
Tri-Clamp per DIN 32676	3 ... 50 (1/10 ... 2")	16	-25 °C (-13 °F)	121 °C (250 °F)
	65 ... 100 (2 1/2 ... 4")	10		
Tri-Clamp per ASME 32676	3 ... 100 (1/10 ... 4")	10	-25 °C (-13 °F)	130 °C (266 °F)
External threads ISO 228	3 ... 25 (1/10 ... 1")	10	-25 °C (-13 °F)	130 °C (266 °F)

10.3.3 Material load for flanged design Model DE21F / DE23F

DIN-Flange SS 1.4571 [316Ti] to DN 100 (4")




Fig. 75

ASME-Flange SS 1.4571 [316Ti] to DN 100 (4")




Fig. 76

JIS 10K-B2210 Flange

Meter Size	Material	PN	TS	PS [bar]
25 ... 100 (1 ... 4")	SS1.4571-[316Ti]	10	-25 ... +130 °C (-13 ... +266 °F)	10
25 ... 100 (1 ... 4")	Carbon Steel	10	-10 ... +130 °C (14 ... +266 °F)	10

10.3.4 Material load for wafer design models DE21W / DE 23W




Fig. 77

*) Higher temperatures are allowed for CIP/SIP cleaning for limited time periods, see table "Maximum Allowable Cleaning Temperature".

JIS 10K-B2210 Wafer Design

Meter Size	Material	PN	TS [°C]	PS [bar]
32-100 (1 ¼ ... 4")	W.-Nr. 1.4404	10	-25 ... +130 °C	10
	W.-Nr. 1.4435		-13 ... 266 °F	
	W.-Nr. 1.4301			

11 Transmitter

11.1 Specifications:

Flow range	Continuously adjustable between 0.5 and 10 m/s
Max. accuracy	≤ 0.5 % of rate ≤ 0.25 % of rate (option)
Reproducibility	≤ 0.15 % of rate
Minimum conductivity	5 µS/cm (20 µS/cm for demineralized water)
Response time	For a step change 0-99 % (corresponds to 5 τ) ≥ 1 s for 6 1/2 Hz exciter frequency
Supply power	High voltage AC: 100 - 230 V (- 15/+10 %) Low voltage AC: 16.8 -26.4 V Low voltage DC: 16.8 - 31.2 V, ripple: < 5 %
Supply frequency	47 - 63 Hz
Magnetic field supply	6¼ Hz, 7½ Hz 12½ Hz, 15 Hz, 25 Hz, 30 Hz (50/60 Hz supply power)
Power	≤ 14 VA for AC supply power (flowmeter primary incl. converter) For AC supply power ≤ 6 W for DC supply power DC (flowmeter primary incl. converter)
Ambient temperature	-20 °C to +60 °C
Electrical connections	Spring loaded screwless terminals
Forward/Reverse flow metering	Flow direction is indicated by direction arrows in the display and signaled over the optocoupler output (ext. contact output).

11.2 Housing Variants

COPA XE

Compact design with converter housing made of cast light metal, painted, paint coat 60 µm thick, rear section RAL 7012 dark gray, front section (cover) RAL 9002 light gray

Option

Converter housing made of stainless steel [304]

MAG-XE

- Field mount housing made of cast light metal, painted, paint coat 60 µm thick, rear section RAL 7012 dark gray, front section (cover) RAL 9002 light gray
- Panel installation housing
- Housing for rail mounting

Weight

COPA-XE: see Data Sheet

MAG-XE (converter):

- Field mount housing: 4.5 kg
- Rail mount housing: 1.2 kg
- Panel installation housing 1.2 kg

Signal Cable (only for MAG-XE)

Max. cable length between flowmeter primary and converter: 50 m.

Scope of delivery: 10 m.

If more than 10 m is required, the cable can be ordered under the order number D173D025U01.

11.3 Converter scale drawing FXE 4000-E4 (MAG-XE)

11.3.1 Converter housing and suggested installation




Fig. 78 (Dimensions in mm)

- 1 Field mount housing with window
- 2 Cable gland M20 x 1.5
- 3 Installation holes for pipe mounting set for a 2" – pipe installation; mounting set upon request (order no. 612B091U07)
- 4 Protection class IP 67

11.3.2 Converter as panel mount housing




Fig. 79 (Dimensions in mm)

- A Panel installation 96 x 96 (control panel section 92 x 92^{+0.8} mm)
 - B Front view
 - C Rear view
- Protection class IP 20

11.3.3 Rail mount housing




Fig. 80 (Dimensions in mm)

- 1 Supply power connection plug
- 2 Connection plug In- / Outputs
- 3 Station ground
- 4 Signal/ activation cable connection plug
- 5 Min. distance for pulling out plug

12 Appendix

12.1 Permits and certifications

	Symbol	Description
CE mark		<p>The CE mark indicates that the device complies with the following directives and their basic safety requirements:</p> <ul style="list-style-type: none"> • CE mark on the name plate of transmitter <ul style="list-style-type: none"> – Conforms with EMC directive 89/336/EEG – Conforms with low voltage directive 73/23/EEG • CE mark on the factory tag of flowmeter primary <ul style="list-style-type: none"> – Conforms with pressure equipment directive (PED) 97/23/EC <p>By placing the CE mark on its devices, ABB Automation Products GmbH declares its conformance with these directives.</p> <p>Pressure equipment does not receive a CE mark on the factory tag, if the following conditions exist:</p> <ul style="list-style-type: none"> • The max. permissible pressure (PS) is less than 0.5 bar. • Due to low pressure risks (nominal width \leq DN 25 / 1") no approval procedures are required. <p>This unit was designed and manufactured in accordance with "sound engineering practices".</p>

12.2 Overview of setting parameters and technical design

Measuring point:		TAG no.:
Flowmeter model:		Transmitter model:
Order no.:	Device no.:	Order no.:
Measured medium temp.:		Power supply:
Lining:	Electrodes:	Exciter frequency:
C _{zero} :	C _{Span} :	System zero point:

Parameter	Setting range
Prog. Protection code:	0-255 (0=factory setting)
Language:	e.g., German, English, French, etc.
Nominal size:	DN 3 - 1000
Range:	0.05 Q _{max} DN -1 Q _{max} DN
Pulse factor:	0.001 - 1000 pulse/phys. unit
Pulse width:	0.100 - 2000 ms
Low cut-off setting:	0 - 10% of flow range end value
Damping:	0.5 - 99.99 seconds
Filter:	ON / OFF
Density:	0.01 g/cm ³ - 5.0 g/cm ³
Range unit.:	e.g., l/s, l/min, l/h, hl/s, hl/min, hl/h, etc.
Unit totalizer:	z. B. e.g., l, hl, m ³ , igal, gal, etc.
Max. alarm:	%
Min. alarm:	%
Terminal P7/G2:	e.g., Max. alarm, Min. alarm, Max./Min. alarm, general alarm, etc.
Terminal X1/G2:	External cutoff, totalizer reset, no function.
Current output:	0/4-20 mA, 0/2-10 mA, 0-5 mA, 0-10-20 mA, 4-12-20 mA
I _{out} for alarm:	0 %, 130 %, 3.8 mA, Low, High
Detector e. pipe:	ON / OFF
Alarm e. pipe:	ON / OFF
I _{out} for e. pipe:	0 %, 130 %, 3.8 mA, Low, High
threshold:	2300 Hz
Adjust empty pipe:	Software potentiometer
Totalizer function:	Standard, difference totalizer
1. Display line:	Q (%), Q (unit), Q (mA), counter V/R, TAG number, blank line, bar graph
2. Display line:	Q (%), Q (unit), Q (mA), counter V/R, TAG number, blank line, bar graph
1. Multiplex line:	ON / OFF
2. Multiplex line:	ON / OFF
Operating mode:	Standard/Fast
Flow direction:	Forward / Reverse
Flow indication:	Normal, inverse
Data to ext. Save to EEPROM:	Yes / No

Pulse output:	<input type="checkbox"/> Optocoupler	<input type="checkbox"/> Active 24V
Switching input/output:	<input type="checkbox"/> Yes	<input type="checkbox"/> No
Communication:	<input type="checkbox"/> HART protocol <input type="checkbox"/> PROFIBUS DP	<input type="checkbox"/> PROFIBUS PA <input type="checkbox"/> FOUNDATION Fieldbus
Certified device:	<input type="checkbox"/> Yes	<input type="checkbox"/> No

Statement about the contamination of devices and components

The repair and/or maintenance of devices and components will only be performed when a completely filled out explanation is present.

Otherwise, the shipment can be rejected. This explanation may only be filled out and signed by authorized specialist personnel of the operator.

Customer details:

Company:

Address:

Contact person:

Telephone:

Fax:

E-Mail:

Device details:

Type:

Serial no.:

Reason for the return/description of the defect:

Was this device used for working with substances which pose a threat or health risk?

Yes No

If yes, which type of contamination (please place an X next to the applicable items)

biological	<input type="checkbox"/>	corrosive/irritating	<input type="checkbox"/>	combustible (highly/extremely combustible)	<input type="checkbox"/>
toxic	<input type="checkbox"/>	explosive	<input type="checkbox"/>	other toxic substances	<input type="checkbox"/>
radioactive	<input type="checkbox"/>				

Which substances have had contact with the device?

1.

2.

3.

We hereby certify that the devices/parts shipped were cleaned and are free from any dangerous or poisonous materials.

City, Date

Signature and company stamp

12.3 Additional documents**English-language documents**

- Commissioning Instructions (D184B133U02)
- Data Sheet (D841S075U02)
- Interface description for devices with HART communication (D184B108U02)
- Interface description for devices with PROFIBUS DP communication (D184B093U10)
- Interface description for devices with PROFIBUS PA communication (D184B093U26)
- Interface description for devices with PROFIBUS Fieldbus communication (D184B093U18)

13 Index

A	
Additional documents	93
Appendix	90
Approved measurement mediums.....	9
B	
Builder's plate	12
C	
Checks	46
Commissioning FOUNDATION FIELDBUS units	55
Commissioning PROFIBUS PA units	50
Commissioning the unit	48
Connection for protection class IP68	36
COPA-XE	16
D	
Data entry	58
Design	16
Design and function	15
Device designs.....	16
Display options.....	57
Display rotation	28
E	
Electrical connection.....	32
Electrical installation safety information.....	14
Error messages.....	72
Excitation cable.....	35
F	
Factory Tag.....	10
Flowmeter primary	74
Fuse COPA-XE.....	76
FXE4000 (COPA-XE), analog communication (incl. HART)	39
FXE4000 (COPA-XE), digital communication	40
FXE4000 (MAG-XE), digital communication	42
FXE4000 MAG-XE, analog communication (incl. HART)	41
G	
Gaskets.....	26, 75
General information on ground connections.....	29
General information on transport.....	18
General Safety Information.....	7
Ground	29
Ground for devices with protective plate	31
Ground for stainless steel model DE 21 and DE 23	31
Ground for units with hard or soft rubber liners	31
Ground with conductive PTFE grounding plate	31
H	
Housing rotation.....	28
I	
Improper use.....	8
In- and outlet pipe sections.....	20
Information on voltage/current consumption	53
Inspection.....	18
Installation.....	20, 23
Intended use	7
Interconnection Diagrams	39
Interconnection examples for the peripherals with analog communication (incl. HART).....	43
Interconnection examples for the peripherals with digital communication.....	44
L	
Labels and symbols	9
M	
MAG-XE	17
Maintenance / Repair.....	74
Maintenance safety information.....	14
Measuring principle.....	15
Mounting the measuring tube	26
N	
Name Plate	10, 11
Non-metallic pipes	30
O	
Operating safety information.....	14
Operating the terminals	32
Operator liability	13
P	
Parameter description.....	61
Parameterization.....	57
Permits and certifications.....	90

Personnel qualification.....	13	Start-up	46
Pipes with insulating liner	30	Supports.....	23
Potting the connection box	37	Symbols and warnings.....	9
Protective plates	26	System integration	53
R		T	
Replacing the transmitter.....	75	Technical data.....	81
Returning devices	13	Technical limit values.....	8
S		Torque information.....	27
Safety.....	7	Transmitter.....	86
Signal cable	35	Transport.....	18
Spare parts COPA-XE.....	76, 77	Transport of flanged units \geq DN 400.....	19
Spare parts flowmeter primary.....	80	Transport safety information	13
Spare parts list.....	76	W	
Spare parts transmitter E4.....	78	Warranty provision	9

ABB has Sales & Customer Support
expertise in over 100 countries worldwide.

www.abb.com/flow

The Company's policy is one of continuous product
improvement and the right is reserved to modify the
information contained herein without notice.

Printed in the Fed. Rep. of Germany (07.2006)

© ABB 2006



ABB Limited

Oldends Lane, Stonehouse
Gloucestershire, GL10 3TA
UK

Tel: +44 (0)1453 826661
Fax: +44 (0)1453 829671

ABB Inc.

125 E. County Line
Road
Warminster, PA 18974
USA

Tel: +1 215 674 6000
Fax: +1 215 674 7183

ABB Automation Products GmbH

Dransfelder Str. 2
37079 Goettingen
Germany

Tel: +49 551 905-534
Fax: +49 551 905-555
CCC-support.deapr@de.abb.com