

ABB Ability™ Smart Sensor, Generation 2

Installation with wedge mount



IMPORTANT! Read these instructions in their entirety before installing the ABB Ability™ Smart Sensor, Generation 2 with wedge mount.



ATTENTION

Install as per industry codes and regulations

The Smart Sensor should be installed by technically qualified personnel. Failure to install the sensor in compliance with applicable codes and regulations and according to the manufacturer’s recommendations may result in electrical shock, fire hazard, unsatisfactory performance or equipment failure, and may void the sensor warranty.

Applicable installation areas for Smart Sensor with steel wedge mount

Smart Sensor with wedge mount can be installed on safe areas but also on following hazardous areas:

- Mines (Group I): All zones
- Gas (Group II A, B, C): All zones
- Dust (Group III): All zones



WARNING

Only qualified individuals who are familiar with appropriate national codes, local codes and sound practices should install, repair or modify electric motor and/or related accessories. Installation should conform to appropriate codes and practices. Failure to follow these instructions could result in serious personal injury, death and/or property damage.

Electrical live circuit hazard. Do not touch electrically live parts or equipment. For a safe installation, disconnect, lockout and tagout the asset’s power supply before installing or servicing the sensor.



CAUTION

Asset surface temperature hazard. The external surface of an electric motor may reach temperatures which can cause discomfort, burns or injury to individuals who come into contact with the hot surface. For safety reasons the asset should be switched off and allowed to cool before attempting to install the sensor. Asset surface temperatures should only be measured with suitable instruments and not estimated by hand touch or direct skin contact. Failure to observe this precaution could result in bodily injury.

Do not replace batteries! Incorrect use of batteries voids the certifications of the Smart Sensor, such as hazardous area certifications, safety certifications, and IP rating. Dispose of used sensors according to instructions.

Quick start guide

Step	Instructions	Additional information
1	Install the ABB Ability™ Smart Sensor Platform App.	The Smart Sensor Platform App can be found in App Store (Apple) and Google Play Store (Android). Note: In some countries these stores may not be accessible. For more information see www.abb.com/smartsensor .
2	Register in the ABB Ability™ Smart Sensor Platform App.	- Follow the sign-up link in the app. - Alternatively, you can sign up on the web portal at https://smartsensor.abb.com . - Skip this step if you have already registered.
3	Log in to the ABB Ability™ Smart Sensor Platform App.	- Create or join an existing organization. - Follow the instructions on the screen.
4	Install the ABB Ability™ Smart Sensor.	- Make sure that you have the required components. - Install the sensor according to the installation steps in this manual.
5	Activate the sensor with the ABB Ability™ Smart Sensor Platform App.	- Navigate to the main menu in the app and tap Activate Sensor . - Follow the instructions displayed on the mobile screen.
6	Commission the asset in the ABB Ability™ Smart Sensor Platform App.	- Navigate to the Commission new asset menu in the app. - Select the equipment profile you want to monitor. - Follow the instructions on the screen.
7	Take first measurements and check the asset condition.	Select the asset and navigate to Load Measurements .

For more detailed instructions, visit www.abb.com/smartsensor.

Installation instruction

Obey the following instructions for the installation of ABB Ability™ Smart Sensors on motors.

Notes:

- For effective Bluetooth® communication, mount the sensor with a clear line of sight to any communication devices to be used (your smartphone or a Bluetooth® gateway).
- The mounting orientation must be such that the A-axis on the sensor housing is parallel to the rotating shaft. If this is not physically possible, the T-axis must be parallel to the rotating shaft.

Mounting position on motor

Mount the sensor between the drive-end and non-drive-end bearings, as near to the center as possible.

Note: The sensor mount cannot be removed after installation.

Supported motors

This mounting instruction applies for motors up to frame sizes equivalent to IEC 500.

For information on motor types monitored with the ABB Ability™ Smart Sensor, visit www.abb.com/smartsensor.

Instructions for hazardous area

1. The wedge mount should be grounded in hazardous area installations. The grounding can be provided either via the spike at the end of the mount or by attaching a grounding wire to the mount with the M3 screw.
2. Do the grounding according to local regulations. As a reference, the IEC 60079-14 defines the minimum diameter for grounding wire as 4 mm².

Materials needed for the installation

1	Wedge mount
2	M6 hexagon socket screw
3	Cover for screw hole
4	ABB Ability™ Smart Sensor, generation 2
5	Loctite™ EA 3463 or similar putty
6	50 mm long hex bit (5 mm for M6 screw) and torque wrench
7	Rubber gloves
-	Other miscellaneous items: Safety goggles, degreasing agent, rubber mallet, possibly threadlocker, and suitable tools and materials to do the grounding if sensor is installed in hazardous area.



WARNING

Direct skin exposure to solvents and/or threadlocker could cause discomfort or injury, including, but not limited to, burning or skin irritation. Use appropriate protective gloves and goggles when performing this task.

Installation steps

Step 1

Degrease the upper and lower surfaces of the selected fin at the recommended mounting position.



CAUTION

Review and obey all manufacturer's instructions and safety precautions when using degreasing agent.

Step 2

Apply Loctite™ EA 3463 or similar putty to the end of the wedge mount. The picture shows the minimum amount of glue required. If grounding of the mounting piece needs to be performed using the spike, do not cover the spike at the end of the mount with glue.




CAUTION

Review and obey all manufacturer's instructions and safety precautions when using glue.

Step 3

Push the wedge mount between the cooling fins of the motor.



Step 4

Use a hammer with a rubber or plastic head to insert the mounting wedge until the end of the wedge touches the frame of the motor.

Ground the mounting piece if sensor is installed in hazardous areas mentioned on page 1. Make sure that the spike of mounting piece protrudes the painting and provides sufficient path for grounding, maximum 1 MΩ according to IEC 60079-14.

As an alternate method for grounding, bring a grounding wire of minimum 4 mm² diameter on the M3 screw of the mounting piece.

Allow the putty to dry before performing step 5. For information on curing time, see the instructions and recommendations in the putty manufacturer's user manual.

Step 5

Press the putty firmly to the mount and make sure that the installation is robust.

Step 6

Fasten the ABB Ability™ Smart Sensor G2 to the wedge mount by using the M6 hexagon socket screw.

Tighten the screw with 10 Nm (7.4 ft-lb) of torque. Make sure to hold the sensor while tightening the screw to avoid exerting torque on the glue.


Make sure that the ABB Ability™ Smart Sensor, G2 is mounted parallel to the rotating shaft by aligning it with the motor fins. Assemble the screw hole cover to hide the screw hole.

Note: In harsh environments, use threadlocker.

Step 7

Activate the sensor and commission the asset. See section Quick start guide, steps 5–7.

Note: After commissioning, the sensor has a two-month trial period with full functionality. After the trial period, the usage can be continued by activating a subscription acquired from a local ABB sales unit.



For questions, feedback and support, contact:

Product information

www.abb.com/smartsensor

Support

support.smartsensor@abb.com

Subscriptions

<https://eu.marketplace.ability.abb/>

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB Ltd does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB Ltd.
Copyright © 2022 ABB
All rights reserved