



ABB i-bus[®] KNX Meter Interface Module ZS/S 1.1 Product Manual

Contents

Page

1	General	3
1.1	Using the product manual.....	4
1.1.1	Structure of the product manual	4
1.1.2	Notes	4
1.2	Product and functional overview.....	5
2	Device technology	7
2.1	Technical data	7
2.2	Connection schematic	9
2.3	Dimensional drawing	10
2.4	Assembly and installation	11
3	Commissioning	13
3.1	Application program.....	13
3.1.1	Conversion	13
3.1.1.1	Procedure	14
3.2	Parameters	15
3.2.1	Parameter window <i>General</i>	16
3.2.2	Parameter window <i>Meter Reading</i>	22
3.2.3	Parameter window <i>Power Values</i>	25
3.2.4	Parameter window <i>Instrument Values</i>	30
3.3	Communication objects	35
3.3.1	Communication objects <i>General</i>	35
3.3.2	Communication objects <i>Meter Reading</i>	38
3.3.3	Communication objects <i>Power Values</i>	41
3.3.4	Communication objects <i>Instrument Values</i>	43
3.3.5	Communication objects <i>Transformer Ratios</i>	45
3.3.6	Communication objects <i>Resettable Energy Register</i>	46
4	Planning and application	47
4.1	Energy meter overview	47
4.1.1	A-series	47
4.1.1.1	Function overview.....	48
4.1.2	DELTAplus	53
4.1.3	DELTAsingle.....	55
4.1.4	ODIN	55
4.1.5	ODINsingle	55
4.2	Behavior after bus voltage recovery, download and ETS reset	56
4.3	LED display	57
A	Appendix	59
A.1	Status byte code table	59
A.2	DELTAplus error codes	60
A.3	DELTAsingle error codes.....	61
A.4	Energy measurement	62
A.4.1	Measurement fundamentals	62
A.4.2	Measurements with current and/or voltage transformers.....	64
A.4.3	Energy calculation	66
A.5	Ordering Information.....	67

1 General

Energy measurement

The recording of energy variables and values as well as their processing is continually gaining in significance. This is not just due to the rising energy costs but also due to the frequently demanded evaluation and reading possibilities via a decentralized reading station. When combined with the features of the ABB i-bus[®], the operator or user in the field of intelligent building technology can implement comfortable and economical solutions for modern energy management. The demands placed on recording and evaluation as well as on billing and charging in commercial and functional buildings, and also in industrial systems and residential properties has increased significantly over recent years. ABB offers a wide range of meters and interfaces specially designed for these applications.

What is Automatic Meter Reading (AMR)?

Automatic Meter Reading (AMR) is the process of remote reading of data from meters. AMR allows the suppliers of electrical energy, as well as water, gas and district heating to improve the handling of their contracts and services. The ongoing costs involved in manual reading of the meter are eliminated and the consumption data become transparent.

What is energy management?

Energy management is the overall concept which ranges from planning of requirement to selection, installation and operation of energy generation systems. The objective is to provide complete coverage of the energy needs of the consumer and to use the most minimum amount of energy at the given comfort or production levels (industrial and commercial). Energy management can be applied in every building where energy is required: industrial buildings, office buildings, sports halls, dwellings, apartments, etc.

Reasons for energy management:

- Guaranteeing the provision of an interruption free supply of energy or power
- Retention of the voltage or current quality
- Economic efficiency, e.g. favorable power or heat prices, conservation of energy
- Environmental aspects, e.g. conservation of energy, energy recovery
- Independence of fossil based primary energy carriers

What is load management?

The primary objective of load management is an economical and resource efficient use of energy provided by electrical utility companies in industry, commercial applications and domestic households for environmental cost and/or safety reasons. Load management also incorporates measures for the avoidance of circuit overloads. Cost savings can be achieved by the avoidance of load peaks or reduction of consumption during tariff times when higher power prices are charged.

1.1 Using the product manual

This manual provides you with detailed technical information concerning the Meter Interface Module, its installation and commissioning.

This manual is subdivided into the following chapters:



Chapter 1	General
Chapter 2	Device technology
Chapter 3	Commissioning
Chapter 4	Planning and application
Chapter A	Appendix

1.1.1 Structure of the product manual

In chapter 3, the parameters for the Meter Interface Module in conjunction with the A-series, DELTAplus, DELTAsingle, ODIN and ODINsingle meter types are described. Following the parameter descriptions, you will find the descriptions of the available communication objects.

1.1.2 Notes

Notes and safety instructions are represented as follows in this manual:

Note
Tips for usage and operation
Examples
Application examples, installation examples, programming examples
Important
These safety instructions are used as soon as there is danger of a malfunction without risk of damage or injury.
Caution
These safety instructions are used as soon as there is danger of a malfunction without risk of damage or injury.
 Danger
These safety instructions are used if there is a danger for life and limb with inappropriate use.
 Danger
These safety instructions are used if there is a danger to life with inappropriate use.

1.2 Product and functional overview

The Meter Interface Module ZS/S 1.1 from ABB STOTZ-KONTAKT converts telegrams from ABB energy meters for the DIN rail mounting into KNX telegrams. The device features an infrared interface, which can be used to read the data from ABB energy meter types A-series, DELTAplus, DELTAsingle, ODIN and ODINsingle. These read values can be processed in a number of ways, e.g. in visualization systems, energy management systems or for billing purposes. Different values and variables can be processed by the Meter Interface Module in dependence on the meter type used.

The following functions are available with the application program *Meter data logging*:



2CMC 484 004 F0001

Functions of ZS/S 1.1 with A-series and DELTAplus meters*

- Exported active and reactive energy (total, tariffs 1/2/3/4)
- Active and reactive energy (total, tariffs 1/2/3/4)
- Instantaneous voltages and currents
- Instantaneous powers and power factors (active, reactive and apparent power)
- Instantaneous phase angle (voltage, current, power)
- Instantaneous frequency
- Quadrant
- Send and reset power failures (counter)
- Send and switch tariff
- Read voltage and current transformer ratio
- Status byte



2CDC 071 151 F0007

Functions of ZS/S 1.1 with DELTAsingle meter*

- Active energy
- Active Energy Tariffs 1/2/3/4
- Send and reset power failures (counter)
- Read tariff
- Status byte



2CDC 071 152 F0007

Functions of ZS/S 1.1 with ODIN meter*

- Active energy
- Transformer ratio (current)
- Status byte



2CDC 101 175 F0008

Functions of ZS/S 1.1 with ODIN single meter*

- Active energy
- Resettable energy register
- Send and reset power failures (counter)
- Status byte

* The scope of functions depends on the configuration of the corresponding meter type

2 Device technology



Meter Interface Module ZS/S

2CDC 071 153 F0007

The Meter Interface Module ZS/S enables remote reading of meter data and meter values from ABB energy meters from the A-series, DELTAplus, DELTAsingle, ODIN and ODINsingle.

The information that is read can be used, for example, for cost-center accounting, energy optimization, visualization or monitoring of installations. Furthermore, meter functions such as tariff switching, for example, can be controlled via KNX, depending on the meter type used.

The Meter Interface Module is a modular installation device (MDRC) in ProM design. It is designed for installation in a distribution board on 35 mm mounting rails. The connection to the ABB i-bus[®] KNX is established via the bus connection terminal.

2.1 Technical data

Power supply	Bus voltage	21 ...31 V DC via KNX
	Current consumption KNX	Maximum 12 mA
	Leakage loss	Maximum 250 mW
Operating and display elements	LED red and programming button	For assignment of the physical address and checking the bus connection
	Error LED (red)	On: No IR communication Flashing: Connected meter does not comply with parameterization
	2 LEDs input/output telegram (yellow)	Flashing: Telegram traffic IN/OUT
Connections	KNX	Via bus connection terminal 0.8 mm Ø, solid
Infrared interface	Compliant to IEC 61107	
Enclosure	IP 20	Complaint to EN 60 529
Protection class	II	Complaint to EN 61 140
Isolation category	Overtoltage category	III to EN 60 664-1
	Pollution degree	2 to EN 60 664-1
KNX safety extra low voltage	SELV 24 V DC	
Temperature ranges	Operation	-5 °C...+45 °C
	Storage	-25 °C...+55 °C
	Transport	-25 °C...+70 °C
Ambient conditions	Maximum air humidity	95 %, no condensation allowed
Design	Modular installation device (MDRC)	Modular installation device, ProM
	Dimensions	90 x 36 x 64.5 mm (H x W x D)
	Mounting width in space units	2 modules at 18 mm
	Mounting depth	68 mm

ABB i-bus[®] KNX

Device technology

Installation	On 35 mm mounting rail	Complaint to EN 60 715
Mounting position	On mounting rail adjacent to energy meter	Observe the installation instructions!
Weight	Approx. 0.1 kg	
Housing, color	Plastic, gray	
Approvals	KNX	
CE mark	In accordance with EMC and low-voltage guidelines	

Application program	Max. number of communication objects	Maximum number of group addresses	Maximum number of assignments
Meter data logging/...*	77	254	254


*... = Current version number of the application program. Please observe the software information on our homepage for this purpose.

Note

The programming requires Software Tool ETS2 V1.2a or higher. If ETS3 is used, a ".VD3" type file or higher must be imported. The application program is available in the ETS2/ETS3 at ABB/Energy management.

The device does not support the closing function of a project or the KNX device in the ETS. If you inhibit access to all devices of the project with *BCU code*, it has no effect on this device. Data can still be read and programmed.

2.2 Connection schematic




2CDC 072 014 F0007

ZS/S 1.1

- | | | | |
|---|-------------------------|---|-------------------------------|
| 1 | Label carrier | 5 | Input telegram LED (yellow) |
| 2 | Programming LED | 6 | Output telegram LED (yellow) |
| 3 | Bus connection terminal | 7 | Error LED (red) |
| 4 | Programming key | 8 | Infrared interface (sidewise) |

2.3 Dimensional drawing



ZS/S 1.1

2CDC 072 011 F0007

2.4 Assembly and installation


The Meter Interface Module ZS/S 1.1 is a modular installation device for quick installation in the distribution board on 35 mm mounting rails to EN 60 715.

The connection to the bus is implemented using the supplied bus connection terminal. The device is ready for operation after connection to the bus voltage.

Accessibility to the devices for the purpose of operation, testing, visual inspection, maintenance and repair must be provided compliant to VDE 0100-520.

The device is solely intended for installation in a closed distribution board. This is intended to minimize the occurrence of malfunctions caused by dirt, humidity and external light sources. The communication between the interface and the counters may be subjected to interference with direct incidence of light.

For operation, the Meter Interface Module must be snapped onto the mounting rail arranged flush to the energy meter, to ensure that communication via the infrared interface is assured. No air gap may exist between both devices. An air gap can interfere with the communication and makes the IR interface susceptible to malfunctions. If there is a malfunction of the IR communication, the LED *Error* will light red when bus voltage is available. In order to avoid the development of an air gap, ensure that the device is not subjected to vibrations after commissioning.



It is important to ensure that the Meter Interface Module and energy meter remain dust-free, dry and clean. In order to guarantee a secure interface function, we recommend checking the devices at regular intervals – taking account of the level of dirt in their environment – and to clean them.

The specifications and notes in the manuals for the corresponding meter must be observed for mounting, installation and commissioning of the DELTAplus, DELTAsingle, ODIN and ODINsingle energy meters.

Commissioning requirements

In order to commission the device, a PC with ETS (from ETS2 V1.2a or higher) as well as an interface to the ABB i-bus[®], e.g. via a KNX interface, is required.

The device is ready for operation after connection to the bus voltage. No additional auxiliary voltage is required.

Installation and commissioning may only be carried out by qualified electrical specialists. The appropriate standards, guidelines, regulations and specifications should be observed when planning and setting up electrical installations.

- Protect the device from damp, dirt and damage during transport, storage and operation.
- Only operate the device within the specified technical data limits!
- The device should only be operated in an enclosed housing (distribution board)!

Supplied state

The device is supplied with the physical address 15.15.255. The application program is pre-installed. It is therefore only necessary to load group addresses and parameters during commissioning.

However, the complete application program can be reloaded if required. After a change of application program, after an interrupted download or discharge of the device, a longer downtime may result.

Download behavior

Depending on the PC that is used, the progress bar for the download may take up to one and a half minutes before it appears due to the complexity of the device.

Assignment of the physical address

Assignment and programming of the physical address, group address and parameters are carried out in the ETS.

The device features a programming button for assignment of the physical device address. The red programming LED lights up after the button has been pushed. It switches off as soon as the ETS has assigned the physical address or the programming button is pressed again.

Cleaning

If devices become dirty, they can be cleaned using a dry cloth. Should a dry cloth not remove the dirt, the device can be cleaned using a slightly damp cloth and soap solution. Corrosive agents or solutions should never be used.

Maintenance

The device is maintenance-free. No repairs should be carried out by unauthorized personnel if damage occurs, e.g. during transport and/or storage. The warranty expires if the device is opened.

3 Commissioning

3.1 Application program

Programming is carried out with ETS from version ETS2 V1.2a onwards.

The Meter Interface Module ZS/S is delivered with a pre-installed application program. Hence, only group addresses and parameters must be loaded during commissioning. If necessary, the entire user program can be loaded. The device must be discharged beforehand.

Note

After the device is programmed, it may take up to ten seconds before the Meter Interface Module has synchronized with the energy meter. The interface is only ready for operation after this time. Because of the cyclic data exchange between the energy meter and the Meter Interface Module ZS/S 1.1, the average reaction time of the interface is approx. 6 seconds. This means that the requests or changes of meter readings or values are not sent immediately on the bus; they are sent after approx. 6 seconds.

In order to guarantee simple programming, the application program is structured dynamically, i.e. in the basic setting only very few important communication objects and parameters are visible. The full functionality of the application program becomes visible via the activation of the respective parameters.

3.1.1 Conversion

For ABB i-bus[®] KNX devices, it is possible to adopt the parameter settings and group addresses from earlier versions of the application program as of ETS3.

Furthermore, conversion can be used to transfer the existing parameterization of a device to a different device.


Note

When the term "channels" is used in the ETS, this always means inputs and/or outputs. In order to make the language of the ETS generally valid for as many ABB i-bus[®] devices as possible, the word "channels" was used here.

3.1.1.1

Procedure

- Insert the desired device into your project.
- Import the current application program into the ETS.
- Perform your parameterizations and program the device.
- Once you have programmed the device, you can transfer the settings to a second device.
- To do this, right-click on the product and select *Convert* from the *Plug-In* > context menu.



- Then make the desired settings in the dialog *Convert*.
- Finally, you must exchange the physical address and delete the old device.

3.2 Parameters

The parameterization of the Meter Interface Module is implemented using the Engineering Tool Software ETS from version ETS2 V1.2 or higher. The application program is available in the ETS2/ETS3 at ABB/Energy management.

The following chapter describes the parameters of the ZS/S 1.1 using the parameter windows. The parameter windows feature a dynamic structure so that further parameters may be enabled depending on the parameterization and the function of the outputs.

The default values of the parameters are underlined, e.g.:

Options: yes
 no

3.2.1 Parameter window *General*

Higher-level parameter settings for the connected meter can be made in the parameter window *General*.

Meter type

Options: A41, A42, A43, A44
 DELTAplus
 DELTAsingle
 ODIN
 ODINsingle

The energy meter connected to the interface is selected using this parameter. Depending on the selected meter type, communication objects, parameters or parameter pages are enabled for the respective meter type.

The following table shows the general parameters (without dependent parameters) and parameter options depending on the selected meter type.

Parameters	Parameter options				
	A-series	DELTAplus	DELTAsingle	ODIN	ODINsingle
Configuration	Active Energy Meter (direct connected) Active Energy Meter (transformer rated) Combination Meter (direct connected) Combination Meter (transformer rated)		Active Power Meter (direct connected)	Active Power Meter (direct connected) Active Power Meter (transformer rated)	Active Power Meter (direct connected)
Voltage network	4-Wire (L1, L2, L3, N) 3-Wire (L1, L2, L3) 2-Wire (L, N)		2-Wire (L, N)	4-Wire (L1, L2, L3, N)	2-Wire (L, N)
Tariffs	no Tariffs 4 Tariffs	no Tariffs 2 Tariffs 4 Tariffs	no Tariffs 2 Tariffs 4 Tariffs	no Tariffs	no Tariffs
Register for exported energy	no yes	-	-	-	-
Resettable energy register	-	-	-	-	no yes
Sending delay	no yes				
Send object "In Operation"	no yes				

Configuration

Options: Active Energy Meter (direct connected)
Active Energy Meter (transformer rated)
Combination Meter (direct connected)
Combination Meter (transformer rated)

Using this parameter, you can set or display whether the energy meter connected to the interface is an active energy meter or a combination meter. Active power meters only measure the active power or energy. Combination meters also measure the reactive and apparent power or energy.

Note
If a meter of the A4x type with the functionality <i>Platinum</i> is to be read, the option <i>Combination Meter</i> must be selected under the parameter <i>Configuration</i> .

- *Active Power Meter/Combination Meter* (direct connected): Currents up to 80 A are measured directly by the meter.
- *Active Power Meter/Combination Meter* (transformer rated): The communication objects *Transformer Ratio Current*, *Transformer Ratio Voltage* and *Total Transformer Ratio* are enabled.

The following parameters also appear:

Send power and instrument values as

Options: secondary values
primary values

This parameter is used to set how the power or instrument values are to be sent. This parameter appears only if a transformer rated active energy meter or combination meter of the type A41, A42, A43, A44 and DELTAplus is selected.

- *secondary values*: The set transformer ratio on the meter is not considered. The sent power values (active, reactive and apparent power) must be multiplied by the transformer ratio (CT x VT) in order to determine the actual value (primary value). The sent currents or voltages must be multiplied by the corresponding current transformer ratio (VT) in order to determine the actual value (primary value).

For more information see: [Energy measurement](#), page 62

- *primary values*: The set transformer ratio on the meter is considered. The actual or primary values, active, reactive and apparent power, current and voltage are sent.

Send Meter Reading values as

Options: secondary values (4 byte object type)
 primary values (8 byte object type)

This parameter is used to set how the energy values or meter readings are to be sent. This parameter appears only if a transformer rated active energy meter or combination meter of the type A41, A42, A43, A44, DELTAplus or ODIN is selected.

- *secondary values*: The set transformer ratio on the meter is not considered. The sent energy values (active or reactive power) must be multiplied by the transformer ratio (CT x VT) in order to determine the actual value (primary value).

For more information see: [Energy measurement](#), page 62

- *primary values*: The set transformer ratio on the meter is considered. The actual or primary energy values; Meter Reading, Active Energy; and Meter Reading, Reactive Energy are sent.

Note

Using this option, the energy consumption value is sent via an 8 byte communication object. It is necessary to ensure that the receiving device or software is capable of processing 8 byte values.

Voltage network

Options: 4-Wire (L1, L2, L3, N)
 3-Wire (L1, L2, L3)
 2-Wire (L, N)

Using this parameter, you set the type of voltage network that the energy meter connected to the interface is configured. Depending on the voltage network connected, the communication objects for 2-, 3- or 4-wire networks are displayed.

- 4-Wire (L1, L2, L3, N): 3-phase DELTAplus meters with neutral conductor (3 x 57-288 V or 100-500 V).
- 3-Wire (L1, L2, L3): 3-phase DELTAplus meters without neutral conductor (3 x 100-500 V).
- 2-Wire (L, N): 1-phase DELTAplus meter (1 x 57-288 V) and meters of the A 41 or A42 type.

Note

If a meter of the DELTAsingle or ODINsingle type is selected, the 2-wire voltage network (L, N) is preset and cannot be parameterized.

ABB i-bus[®] KNX Commissioning

Register for exported energy

Options: no
 yes

This parameter is displayed only if a meter of the A4x type is selected, and it enables the objects for the meter readings of the exported active or reactive energy*.

Note
Registers for exported energy are available only for meters of the A4x type with the functionality <i>Bronze, Silver, Gold and Platinum</i> .

- yes: The communication objects for exported active or reactive energy* appear.

 Meter Reading, Tot.Act.Energy**

 Meter Reading, Active Energy Tariff 1/ 2/ 3/ 4

 Meter Reading, Tot.React.Energy**

 Meter Reading, Reactive Energy Tariff 1/ 2/ 3/ 4

* The communication objects for the reactive energy exported are displayed only if a combination meter is selected.

** The communication objects *Meter Reading, Tot.Act. Energy* and *Meter Reading, Tot.React.Energy* only appear with the selection of a tariff meter.

Tariffs

Options: No Tariffs
 2 Tariffs*
 4 Tariffs

Using this parameter, you can select if the interface connected to the energy meter features tariff functions.

- *2/4 Tariffs*: The communication objects for sending of the tariff meter readings and for sending/switching the tariffs are displayed.

* Available only if a meter of the type DELTAplus or DELTAsingle is selected.

Note
Tariffs are available only for meters of the A4x type with the functionality <i>Silver, Gold and Platinum</i> . Tariff switching via KNX only functions with DELTAplus meters, which have no separate inputs for tariff switching. No tariffs can be parameterized if a meter of the type ODIN or ODINsingle is selected.

Resettable Energy Register

Options: no
yes

ODINsingle type (OD1365) energy meters feature a resettable energy register similar to a trip meter in a car. The resettable energy register can be used for revenue metering of an accounting period and then can be reset to 0 kWh via KNX. Furthermore, the number of resets is counted and sent.

- *yes*: The communication objects *Meter Reading*, *Resettable Energy Register*, *Reset Resettable Energy Register* and *Send Resets* assigned to the resettable energy register are displayed.

Note

The function or the parameter for the resettable energy register is displayed only if a meter of the type ODINsingle is selected.

Sending delay (Device number * Base delay time)

Options: no
yes

The sending delay is used to minimize the telegram traffic on the bus by ensuring that multiple meters in a KNX system send their readings at different times on the bus.

- *no*: The telegrams are sent without a delay, i.e. telegrams are sent immediately after a value is requested, e.g. with the communication object *Request Meter Reading* via the ABB i-bus.
- *yes*: The parameters *Device number* and *Base delay time* for setting the sending delay time are displayed. After every request of a value (meter reading, power value, instrument value), the information is sent via the bus after the set sending delay time has elapsed. The sending delay time is started after every ETS reset, after bus voltage recovery and after tariff switching.

What is the sending delay time?

The sending delay time results from the product of the set values:

Sending delay time = device number x base delay time.

In this way, groups of energy meters (up to 255 per group) can be established with the same base delay time. Every one of the up to 255 meters per group is assigned with a number with the parameter *Device number*. With a simultaneous meter reading request via the communication object *Request Meter Reading*, the meters of the device series send their readings via the bus.

If the options *Sending delay* and *Send cyclically* are activated simultaneously, delayed sending of the telegrams will only occur once directly after an ETS reset, after bus voltage recovery or tariff switching. This means that after each of these events the parameterized sending delay runs before the cyclic sending delay has commenced. With each subsequent send operation, only the cyclic rhythm is observed as the interfaces now send with a time offset.

ABB i-bus[®] KNX Commissioning

Device number

[1...255]

Options: 1...255

For assignment of the device number of the energy meter.

Base delay time in s

[1...65,535]

Options: 1...65,535

For setting the base delay time of the sending delay.

Send object "In Operation"

Options: no
send value "1" cyclically
send value "0" cyclically

The communication object *In Operation* indicates the correct function of the device on the bus. This cyclic telegram can be monitored by an external device.

Note
After bus voltage recovery, the communication object sends its value after the set sending delay has timed out.

- *send value "0/1" cyclically*: The communication object *In Operation* and the parameter *Cycle time in s* appear:

Cycle time in s

[1...65,535]

Options: 1...60...65,535

Here a time interval is set that the communication object *In Operation* uses to send a telegram cyclically.

3.2.2 Parameter window *Meter Reading*

In this parameter window, the sending behavior of the *meter readings* is defined.

The meter readings are always sent as 4 byte values with directly connected meters.

On transformer rated meters, meter readings or energy values can be sent as secondary values (4 byte) or primary values (8 byte).

Depending on the selected meter type and the set parameters, the following communication objects are available for the meter readings:

	A-series	DELTAplus	DELTAsingle	ODIN	ODINsingle
Active Energy	▪	▪	▪	▪	▪
Tot.Act.Energy*	▪	▪	▪	-	-
Active Energy Tariff 1/ 2/ 3/ 4/	▪	▪	▪	-	-
Reactive Energy	▪	▪	-	-	-
Tot.React.Energy*	▪	▪	-	-	-
Reactive Energy Tariff 1/ 2/ 3 /4	▪	▪	-	-	-
Active Energy Exported	▪	-	-	-	-
Total Active Energy Exported*	▪	-	-	-	-
Active Energy Exported Tariff 1/ 2/ 3/ 4	▪	-	-	-	-
Reactive Energy Exported	▪	-	-	-	-
Total Reactive Energy Exported*	▪	-	-	-	-
Reactive Energy Exported Tariff 1/ 2/ 3/ 4	▪	-	-	-	-
Resettable Energy Register	-	-	-	-	▪

* The communication objects *Total Active Energy (exported)* and *Total Reactive Energy (exported)* are displayed only if a tariff meter is selected.

Note

Communication objects for the reactive energy meter reading are displayed only if a combination meter is selected in [Parameter window General](#), page 16, parameter *Configuration*.

Communication objects for the meter reading of the (exported) active and reactive energy of tariffs 1-4 only appear when a meter with tariff function is selected (2 or 4 tariffs) in the [Parameter window General](#), page 16, parameter *Tariffs*.

Communication objects for the meter reading of the exported active and reactive energy are displayed only after selection of an active energy meter or combination meter of the type A41, A42, A43, A44 in the [Parameter window General](#), page 16, parameter *Register for exported energy*.

Reading of the momentary meter readings can be implemented via reading of the communication object values via *Value_Read*, e.g. with the assistance of the Engineering Tool Software ETS. The option of cyclically sending the meter readings or sending on request continues to apply. The meter readings are sent via a 4 byte communication object with a resolution of 1 Wh/varh. Thus meter readings up to a max. of 2,147,483,647 Wh/varh (2.147 GWh/Gvarh) can be sent. If values received from the connected meter are greater than the max. value, the max. value of 2,147,483,647 Wh/varh is always sent.

Send meter reading cyclically

Options: no
 yes

The meter readings are sent cyclically via the bus with this setting.

- **yes:** The parameter Cycle time in s is displayed. Using this parameter, the send interval at which the meter reading/the meter readings is/are to be sent is set. Multiple meters that send with the same cycle time can send at staggered times using the sending delay time (if it is parameterized) in order to avoid possible communication problems. Cyclical sending is interrupted as soon as communication to the energy meters cannot be established. The meter readings of the active and reactive energy are sent (only when a combination meter is selected). Only the tariff that is currently active and the sum of the tariffs are sent with tariff meters.

Cycle time in s
[1...172,800]

Options: 1...900...172,800

The parameter is displayed if the option *Send cyclically* has been selected. Here the time is set for cyclically sending the meter readings.

Note

If Sending delay and Send cyclically are activated simultaneously, timed offsetting of the meter reading telegrams will only occur once directly after an ETS reset, after bus voltage recovery or tariff switching, i.e. after each of these events the meter waits for the parameterized sending delay time before beginning with the cyclic sending process. With each subsequent send operation only the cyclic rhythm is observed as the meters now send with a time offset.

Send meter reading on request

Options: no
yes

With this setting, the meter readings are sent on request via a separate communication object.

- **yes:** The communication object *Request Meter Reading* is displayed. This communication object enables active reading of the momentary meter readings. After receiving a meter reading request telegram with the value 1, the meter reading is sent after a sending delay (if parameterized) via the bus.

The sending delay time prevents simultaneous sending of telegrams, if multiple meters react to the same meter reading request telegram.

3.2.3 Parameter window *Power Values*

In this parameter window, the sending behavior of the *power values* is defined.

Note

The parameter window *Power Values* appears only if a meter from the A-series or DELTAplus is selected.

General	Send power values cyclically	no
Meter Reading	Send power values on request	no
Power Values	Send power values on change	no
Instrument Values		

Depending on the selected version (active energy meter or combination meter) and parameterization, the following communication objects are available for the power values:

	A-series		DELTAplus	
	Active energy meter	Combination meter	Active energy meter	Combination meter
Active Power (Total)	▪	▪	▪	▪
Active Power L1, L2, L3	▪	▪	▪	▪
Total Reactive Power	-	▪	-	▪
Reactive Power L1, L2, L3	-	▪	-	▪
Apparent Power (Total)	-	▪	-	▪
Apparent power L1, L2, L3	-	▪	-	▪
Phase Angle Power (Total)	-	▪	-	▪
Phase Angle Power L1, L2, L3	-	▪	-	▪
Total Power Factor	▪	▪	▪	▪
Power Factor L1, L2, L3	-	▪	-	▪

Note

The parameters or communication objects for reactive and apparent power as well as phase angle are only displayed if, in the [Parameter window General](#), page 16, a combination meter (direct connected or transformer rated) has been selected under parameter *Configuration*.

If an energy meter is parameterized for 3- or 4-wire voltage networks, the following communication objects are displayed:

Total Active Power

Active Power L1, L2, L3

*Total Reactive and Apparent Power **

*Reactive and Apparent Power L1, L2, L3**

*Total Phase Angle Power**

*Phase Angle Current L1, L2, L3**

Total Power Factor

Power Factor L1, L2, L3

* These communication objects are only displayed with the selection of the combination meter in the [Parameter window General](#), page 16, parameter *Configuration*.

Reading of the actual power values can be implemented via reading of the communication object values via *Value_Read*, e.g. with the assistance of the Engineering Tool Software ETS. The option of *Send power values cyclically*; *Send power values on request* or *Send power values on change* continues to apply.

Send power values cyclically

Options: no
yes

- yes: The parameter *Cycle time in s* is displayed.

Cycle time in s [1...172,800]

Options: 1...900...172,800

Here the time is set for cyclically sending all power values via the bus. The send interval is defined with the parameter *Cycle time in s*. Multiple meters that send with the same cycle time can send at staggered times using the sending delay time (*if it is parameterized*) in order to avoid possible communication problems.

Note

If the sending delay and cyclic sending of the power values are activated, the sending delay time only runs once directly after an ETS reset, after bus voltage recovery or tariff switching. After the sending delay time has timed out, the cyclic send process commences. With each additional send operation, only the cycle time is observed as the interface now sends with a time offset. Cyclical sending is interrupted as soon as communication to the energy meters cannot be established.

Conversion of the cycle time in seconds

900 s = 15 minutes

3,600 s = 1 hour

86,400 s = 1 day

172,800 s = 2 days

Send power values on request

Options: no
yes

- yes: The communication object Request Power Values is displayed. This communication object enables active reading of the momentary power values. After receiving a telegram with a request with the value 1, all the momentary values (*active power, reactive power**, *apparent power**, *phase angle** and *power factor*) are sent after a sending delay time (if parameterized) via the bus. The sending delay time prevents simultaneous sending of telegrams, if several meters respond to the same request for power values.

* Only with the selection of the combination meter in the [Parameter window General](#), page 16, parameter Configuration.

Send power values on change

Options: no
 yes

- yes: The parameter values for entering the change values are displayed. If no change of the value occurs, the momentary power values are sent after the set cycle time (*if parameterized*) has timed out. After bus voltage recovery, programming and ETS reset, the power values whose change value is greater than or equal to ± 1 (0 = do not send) are sent after the sending delay time (*if parameterized*) has elapsed.

Send Active Power in W at +/- [0...65,535]

Options: 0...65,535 (0 = do not send)

The change value to be entered here applies for the communication objects *Active Power (Total; Active Power L1, L2, L3)**. If the preset change value is exceeded or undershot, the corresponding momentary active power value is sent on the bus.

The change value in meters with a transformer ratio always relates to the set parameter option (*send as primary values or as secondary values*) of the parameter *Send power and instrument values* in the [Parameter window General](#), page 16.

* These objects are only displayed with the selection of a 3-wire network or 4-wire network in the [Parameter window General](#), page 16, parameter *Voltage network*.

Send Reactive Power in var at +/- [0...65,535]

Options: 0...65,535 (0 = do not send)

This parameter is only displayed as soon as a combination meter has been selected in the [Parameter window General](#), page 16, parameter *Configuration*.

The change value to be entered here applies for the communication objects *Reactive Power (Total; Reactive Power L1, L2, L3)**. If the preset change value is exceeded or undershot, the corresponding momentary reactive power value is sent on the bus.

The change value in meters with a transformer ratio always relates to the set parameter option (*send as primary values or as secondary values*) of the parameter *Send power and instrument values* in the [Parameter window General](#), page 16.

* These objects are only displayed with the selection of a 3-wire network or 4-wire network in the [Parameter window General](#), page 16, parameter *Voltage Network*.

Send Apparent Power in VA at +/- [0...65,535]

Options: 0...65,535 (0 = do not send)

This parameter is only displayed as soon as a combination meter has been selected in the [Parameter window General](#), page 16, parameter *Configuration*.

The change value to be entered here applies for the communication objects *Apparent Power (Total; Apparent Power L1, L2, L3)**. If the preset change value is exceeded or undershot, the corresponding momentary apparent power value is sent on the bus.

The change value in meters with a transformer ratio always relates to the set parameter option (*send as primary values or as secondary values*) of the parameter *Send power and instrument values* in the [Parameter window General](#), page 16.

* These objects are only displayed with the selection of a 3-wire network or 4-wire network in the [Parameter window General](#), page 16, parameter *Voltage Network*.

Send Phase Angle Power in degrees at +/- [0...90]

Options: 0...65,535 (0 = do not send)

This parameter is only displayed as soon as a combination meter has been selected in the [Parameter window General](#), page 16, parameter *Configuration*.

The change value to be entered here applies for the communication objects *Phase Angle Power (Total; Phase Angle Power L1, L2, L3)**.

If the preset change value is exceeded or undershot, the corresponding momentary phase angle power value is sent on the bus.

* These objects are only displayed with the selection of a 3-wire network or 4-wire network in the [Parameter window General](#), page 16, parameter *Voltage network*.

Send Power Factor at +/- 0.01 * Value [0...100]

Options: 0 ...100

The change value to be entered here applies for the communication objects *Power Factor (Total; Power Factor L1, L2, L3)**. If the preset change value is exceeded or undershot, the corresponding momentary power factor value is sent on the bus.

* These objects are only displayed with the selection of a 3-wire network or 4-wire network in the [Parameter window General](#), page 16, parameter *Voltage network*.

3.2.4 Parameter window *Instrument Values*

In this parameter window, the sending behavior of the *instrument values* is defined.

Note

The parameter window *Instrument Values* appears only if a meter from the A-series or DELTAplus is selected.

General	Send instrument values cyclically	no
Meter Reading	Send instrument values on request	no
Power Values	Send instrument values on change	no
Instrument Values		

Depending on the selected configuration (*active energy meter* or *combination meter*) and parameterized voltage network, the following communication objects are available for the instrument values:

	A-series		DELTAplus	
	Active power meter	Combination meter	Active power meter	Combination meter
Current (L1, L2, L3)	▪	▪	▪	▪
Current N*	-	▪	-	-
Voltage (L1-N, L2-N, L3-N)	▪	▪	▪	▪
Voltage L1-L2, L2-L3, L1-L3**	▪	▪	▪	▪
Frequency***	▪	▪	▪	▪
Phase Angle Current (L1, L2, L3)****	-	▪	-	▪
Phase Angle Voltage (L1, L2, L3)****	-	▪	-	▪
Total Quadrant****	-	▪	-	▪
Quadrant L1, L2, L3****	-	▪	-	▪

* The communication object *Current N* is displayed only if a combination meter of the A4x type is selected.

** The communication objects *Voltage L1-L3* are displayed only if a meter of the A4x type for 3-wire or 4-wire networks is selected.

*** The communication object *Frequency* is inactive and does not send any values if a meter from the A-series with the functionality *Steel* is selected.

**** These communication objects are displayed only if a combination meter is selected.

Reading of the actual instrument values can be implemented via reading of the communication object values via *Value_Read*, e.g. with the assistance of the Engineering Tool Software ETS. The option of cyclically sending the instrument values, sending the instrument values on request or when a change occurs continues to apply.

Send instrument values cyclically

Options: no
 yes

- yes: The parameter *Cycle time in s* is displayed.

Cycle time in s [1...172,800]

Options: 1...900...172,800

Here the time is set for cyclically sending all instrument values via the bus. The send interval is defined with the parameter *Cycle time in s*. Multiple meters that send with the same cycle time can send at staggered times using the sending delay time (if it is parameterized) in order to avoid possible communication problems.

Note

If the sending delay and cyclic sending of the instrument values are activated, the sending delay time only runs once directly after an ETS reset, after bus voltage recovery or tariff switching. After the sending delay time has timed out, the cyclic send process commences. With each additional send operation, only the cycle time is observed as the interface now sends with a time offset.
Cyclical sending is interrupted as soon as communication to the energy meters cannot be established.

Conversion of the cycle time in seconds

900 s = 15 minutes

3,600 s = 1 hour

86,400 s = 1 day

172,800 s = 2 days

Send instrument values on request

Options: no
 yes

- yes: The communication object *Request Instrument Values* is displayed. This communication object enables active reading of the momentary instrument values. After receiving a telegram with a request with the value 1, all the momentary values (*current, voltage, frequency, phase angle current/voltage, quadrant*) are sent after a sending delay time (if parameterized) via the bus. The sending delay time prevents simultaneous sending of telegrams, if several meters respond to the same request for instrument values.

Send instrument values on change

Options: no
 yes

- yes: The parameter values for entering the change values are displayed. If no change of the value occurs, the momentary instrument values are sent after the set cycle time (if parameterized) has timed out. After bus voltage recovery, programming and ETS reset, the instrument values whose change value is greater than or equal to ± 1 (0 = do not send) are sent after the sending delay time (if parameterized) has elapsed.

Send Current in mA at +/- 100 mA Value [0...65,535]

Options: 0...65,535 (0 = do not send)

The change value to be entered here relates to the communication objects *Current (Current L1, L2, L3, N)*. If the preset change value is exceeded or undershot with one of these communication objects, the momentary current value is sent. If the value 0 is entered, the current value is not sent.

The change value is calculated on the basis of 100 mA and the value or factor to be entered, e.g.:

Change value = Basis x factor
 = 100 mA x 10
 = 1,000 mA
 = 1 A

The change value in meters with a transformer ratio always relates to the set parameter option (*send as primary values or as secondary values*) of the parameter *Send power and instrument values* in the [Parameter window General](#), page 16.

ABB i-bus[®] KNX Commissioning

Send Voltage in mV at +/- 10 mV Value [0...65,535]

Options: 0...65,535 (0 = do not send)

The change value to be entered here relates to the communication objects *Voltage* (*Voltage L1-N, L2-N, L3-N, L1-L2, L2-L3, L1-L3*). If the preset change value is exceeded or undershot with one of these communication objects, the momentary voltage values are sent on the bus. If the value 0 is entered, the voltage value is not sent.

The change value is calculated on the basis of 10 mV and the value or factor to be entered, e.g.:

Change value = Basis x factor
= 10 mV x 1,000
= 10,000 mV
= 10 V

The change value in meters with a transformer ratio always relates to the set parameter option (*send as primary values or as secondary values*) of the parameter *Send power and instrument values* in the [Parameter window General](#), page 16.

Note

When using transformers it is important to observe that practical values which are dependent on the transformer are used.

Send Frequency in Hz at +/- 0.1 Hz * Value [0...100]

Options: 0...100 (0 = do not send)

If the preset change value is exceeded or undershot, the corresponding actual frequency is sent on the bus. If the value 0 is entered, the voltage value is not sent, e.g.

Change value = Basis x factor
= 0.1 Hz x 10
= 1 Hz

Send Phase Angle Voltage in degrees at +/- [0...90]

Options: 0...90 (0 = do not send)

These parameters are only displayed with the selection of the combination meter in the [Parameter window General](#), page 16, parameter *Configuration*.

The change value to be entered here relates to the communication objects *Phase Angle Current (Phase Angle Current L1, L2, L3)* or *Phase Angle Voltage (Phase Angle Voltage L1, L2, L3)*. If the preset change value is exceeded or undershot with one of these communication objects, the momentary phase angle current or voltage values are sent on the bus.

Send Quadrant on change

Options: no
 yes

This parameter is only displayed with the selection of the combination meter in the [Parameter window General](#), page 16, parameter *Configuration*.

- **yes:** The communication objects *Quadrant (Total Quadrant; Quadrant L1, L2, L3)* are displayed. If the communication object value changes with the communication object *Quadrant (Total and/or Quadrant L1, L2, L3)*, the momentary quadrant is sent on the bus.

3.3 Communication objects

3.3.1 Communication objects *General*

No.	Function	Object name	Data type	Flags
0	Request Status Values	General	EIS 1, 1 bit DPT 1.017	C, W, T
<p>If a telegram with the value 1 is received on this communication object, all status objects are sent on the bus. Thus the momentary state of the Meter Interface Module and energy meters can be checked.</p> <p>The following communication objects are sent on request:</p> <ul style="list-style-type: none"> No. 2 Status Byte No. 3 Error Signal No. 4 Meter Type No. 5 False Meter Type No. 6 Send Power Fail Counter (does not apply to meters from the A-series with the functionality <i>Steel</i>) 				
1	In Operation	General	EIS 1, 1 bit DPT 1.001	C, R, T
<p>This communication object is activated by the parameter <i>Send object "In Operation"</i>. The Meter Interface Module cyclically sends a telegram with the value 1 or 0 on this communication object. This telegram can be used by other devices for function monitoring. If, for example, the telegram with the value 1 is sent to an actuator with the function Staircase lighting, the failure of the Meter Interface Module can be signaled by the absence of the telegram.</p>				
2	Status Byte	General	Non EIS, 8 bit	C, R, T
<p>With this communication object different types of status information of the meter can be sent on the bus. Each individual bit of the telegram corresponds to a defined state or error of the meter. If an error or state is detected, the corresponding bit is set to 1 and the status byte is sent after approx. six seconds. In addition, the communication object <i>Error Signal</i> is sent in order to indicate that an error has occurred. If the errors have been corrected and the status byte once again has the value 0, the communication object <i>Error Signal</i> also sends a telegram with the value 0. Thus the correction of the error can be indicated.</p> <p>In order to obtain the actual value of the status byte, the communication object value can be read via <i>Value_Read</i>, e.g. with the assistance of the Engineering Tool Software ETS.</p> <p>The communication object is also sent after bus voltage recovery, programming and ETS reset.</p> <p>The Status byte code table, page 59, enables quick decoding of the telegram code for the corresponding error type.</p> <p>Telegram code (1 byte): 76543210</p> <ul style="list-style-type: none"> 7: End value of Meter Reading, Active Energy reached (only with 4 byte value) 6: End value of Meter Reading, Reactive Energy reached (only with 4 byte value) 5: Internal or hardware error in meter 4: IR communication error with meter 3: Current I1, I2 and/or I3 outside of the specification limit* 2: Power is negative (total power or one of three phases) 1: No voltage or undervoltage / overvoltage on phase 1, 2 or 3 0: Installation fault: <ul style="list-style-type: none"> L and N interchanged Time + date not set* <p>* only with meter type DELTAsingle in operation</p> <p>Telegram value: 0 = not activated 1 = activated</p>				

No.	Function	Object name	Data type	Flags
3	Error Signal	General	EIS 1, 1 bit DPT 1.005	C, R, T
<p>On this communication object an error signal in the form of a common error signal is sent on the bus. An error signal can have many causes and can be decoded with the assistance of the status byte or by reading out the DELTAplus error codes, page 60. The communication object is sent as soon as a bit of the communication object <i>Status Byte</i> is set to 1. If the errors have been corrected and the status byte has the value 0, the communication object <i>Error Signal</i> also sends a telegram with the value 0. Thus the correction of the error can be indicated. The communication object is also sent after bus voltage recovery, programming and ETS reset.</p> <p>Telegram value: 0 = no error 1 = error</p>				
4	Meter Type	General	Non EIS, 8 bit	C, R, T
<p>Via this communication object it is possible to read the meter type connected to the Meter Interface Module:</p> <p>Telegram value: 0 = DELTAplus 1 = DELTAsingle 2 = ODIN 3 = ODINsingle 4 = A41, A42, A43, A44</p> <p> Other = reserved</p> <p> 254 = Unknown meter 255 = No meter connected</p> <p>In order to obtain the actual value/connected meter, the communication object value can be read via <i>Value_Read</i>, e.g. with the assistance of the Engineering Tool Software ETS. Furthermore, the communication object is also sent with a change, after bus voltage recovery, programming and ETS reset.</p>				
5	False Meter Type	General	EIS 1, 1 bit DPT 1.005	C, R, T
<p>The Meter Interface Module cyclically scans the connected meters. If the meter parameterized in the ETS does not correspond with the connected meter, this communication object is sent.</p> <p>Telegram value: 0 = Parameterization OK 1 = False Meter Type parameterized</p>				

ABB i-bus[®] KNX Commissioning

No.	Function	Object name	Data type	Flags
6	Send Power Fail Counter	General	EIS 14, 1 byte DPT 5.010	C, R, T
<p>The interface sends the momentary number of mains power failures on this communication object. A power failure is detected as soon as the voltage on all phases drops below 57.7 V -20 %. The number of power failures is sent with a change and on bus voltage recovery.</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>Note</p> <p>With counters from the A-series with the functionality <i>Steel</i>, no power failures can be sent. The object is inactive.</p> </div>				
7	Reset Power Fail Counter	General	EIS 1, 1 bit DPT 1.017	C, W, T
<p>If a telegram is received on this communication object, the meter count of power failures is deleted. This can take up to ten seconds. If the erasing process fails, communication object No. 6 is sent again. If the erasing procedure is successful, object No. 6 is also sent.</p> <p>Telegram value: 0 = no function 1 = Reset power fail counter</p> <div style="border: 1px solid black; padding: 5px; margin: 10px 0;"> <p>Note</p> <p>With counters from the A-series with the functionality <i>Steel</i>, no power failures can be deleted. The object is inactive.</p> </div>				
8	Source of Tariff Switching	General	EIS 1, 1 bit DPT 1.001	C, W
<p>This function is available only for energy meters of the types DELTAplus and A4x, which do not feature separate inputs for tariff switching and which have an internal clock for tariff switching.</p> <p>With this communication object, the source that is used to switch the tariff in the meter is selected. This communication object is displayed only as soon as a meter with tariffs has been selected in the Parameter window General, page 16, parameter <i>Tariffs</i>.</p> <p>Telegram value: 0 = Tariff switching via internal clock in the meter 1 = Tariff switching via KNX</p>				

3.3.2 Communication objects *Meter Reading*

No.	Function	Object name	Data type	Flags
10	Request Meter Reading	Meter reading	EIS 1, 1 bit DPT 1.017	C, W, T
<p>The momentary meter readings are requested via the telegram with the value 1 on this communication object. The request applies for the communication objects No. 11-30. The momentary meter readings – depending on the meters used – are sent on the bus after the sending delay time (if parameterized).</p> <p>Telegram value: 0 = no function 1 = Request Meter Reading</p>				
11 12 13 14 15	Tot.Act.Energy* Active Energy, Tariff 1 Active Energy, Tariff 2 Active Energy, Tariff 3 Active Energy, Tariff 4	Meter reading Meter reading Meter reading Meter reading Meter reading	EIS 11, 4 byte DPT 13.010 or Non EIS, 8 byte DPT 29.010	C, R, T
<p>On these communication objects the momentary meter readings for active energy are sent.</p> <p>If a meter with 2** or 4 tariffs is selected in the Parameter window General, page 16, communication objects No. 11-13 or 11-15 are displayed. If a tariff meter has been parameterized, communication object No. 11 sends the meter reading of the sum of all tariffs of the consumed active energy, whereas communication objects No. 12-15 send the consumed active energy of the respective tariffs.</p> <p>Only the tariff that is currently active and the sum of the tariffs are sent. The communication object is also sent after bus voltage recovery, programming and ETS reset.</p> <p>With the 4 byte communication object, meter readings up to a max. of 2,147,483,647 Wh (2.147 GWh) and a resolution of 1 Wh can be sent. If values received from the connected meter are greater than the max. value, the end value of 2,147,483,647 Wh and the status bit No. 7 (end value of Meter Reading, Active Energy reached) are always sent.</p> <p>If a transformer rated meter is used, the energy consumption values of the active energy are sent as the primary values. For this purpose an 8 byte communication object is displayed. It is necessary to ensure that the receiving device or software is capable of processing 8 byte values.</p> <p>* The communication object <i>Tot.Act.Energy</i> is only displayed if a tariff meter has been selected and indicates the sum of the meter readings of tariff 1 + 2 or tariff 1 + 2 + 3 + 4.</p> <p>** 2 tariffs available only for meters of the configuration DELTAplus.</p>				

ABB i-bus[®] KNX Commissioning

No.	Function	Object name	Data type	Flags
16	Tot.React.Energy*	Meter reading	EIS 11, 4 byte	C, R, T
17	Reactive Energy, Tariff 1	Meter reading	DPT 13.012 or	
18	Reactive Energy, Tariff 2	Meter reading	Non EIS, 8 byte	
19	Reactive Energy, Tariff 3	Meter reading	DPT 29.012	
20	Reactive Energy, Tariff 4	Meter reading		
<p>On these communication objects the momentary meter readings for reactive energy are sent. These communication objects are displayed only if a combination meter of the A4x type or DELTAplus has been selected in the Parameter window General, page 16.</p> <p>If a meter with 2** or 4 tariffs is selected in the Parameter window General, page 16, communication objects No. 6-18 or 16-20 are displayed. If a tariff meter has been parameterized, communication object No. 16 sends the meter reading of the sum of all tariffs of the consumed reactive energy, whereas communication objects No. 17-20 send reactive energy of the respective tariffs.</p> <p>Only the tariff that is currently active and the sum of the tariffs are sent. The communication object is also sent after bus voltage recovery, programming and ETS reset.</p> <p>With the 4 byte communication object meter readings up to a max. of 2,147,483,647 varh (2.147 Gvarh) and a resolution of 1 varh can be sent. If values received from the connected meter are greater than the max. value, the end value of 2,147,483,647 varh and the status bit No. 6 (end value of Meter Reading, Reactive Energy reached) is always sent.</p> <p>If a transformer rated meter is used, the energy consumption values of the reactive energy are sent as the primary values. For this purpose an 8 byte communication object is displayed. It is necessary to ensure that the receiving device or software is capable of processing 8 byte values.</p> <p>* The communication object <i>Tot.React.Energy</i> is only displayed if a tariff meter has been selected and indicates the sum of the meter readings of tariff 1 + 2 or tariff 1 + 2 + 3 + 4.</p> <p>** 2 tariffs available only for meters of the configuration DELTAplus.</p>				
21	Total Active Energy Exported*	Meter reading	EIS 11, 4 byte	C, R, T
22	Active Energy Exported, Tariff 1	Meter reading	DPT 13.010	
23	Active Energy Exported, Tariff 2	Meter reading	or	
24	Active Energy Exported, Tariff 3	Meter reading	Non EIS, 8 byte	
25	Active Energy Exported, Tariff 4	Meter reading	DPT 29.010	
<p>These communication objects are available only for meters of the A4x type and send the momentary meter readings of the active energy exported.</p> <p>Communication object No. 21 is enabled if, in the Parameter window General, page 16, under parameter <i>Register for exported energy</i>, the option <i>yes</i> was selected. If the option <i>4 Tariffs</i> is additionally selected under the parameter <i>Tariffs</i>, communication options 22-25 are enabled. If a tariff meter has been parameterized, communication object No. 21 sends the meter reading of the sum of all tariffs of the exported active energy, whereas communication objects No. 22-25 send the exported active energy of the respective tariffs.</p> <p>Only the tariff that is currently active and the sum of the tariffs are sent. The communication object is also sent after bus voltage recovery, programming and ETS reset.</p> <p>With the 4 byte communication object, meter readings up to a max. of 2,147,483,647 Wh (2.147 GWh) and a resolution of 1 Wh can be sent. If values received from the connected meter are greater than the max. value, the end value of 2,147,483,647 Wh and the status bit No. 7 (end value of Meter Reading, Active Energy reached) are always sent.</p> <p>If a transformer rated meter is used, the energy consumption values of the active energy are sent as the primary values. For this purpose an 8 byte communication object is displayed. It is necessary to ensure that the receiving device or software is capable of processing 8 byte values.</p> <p>* The communication object <i>Total Active Energy Exported</i> is only displayed if a tariff meter has been selected and indicates the sum of the meter readings of tariffs 1 + 2 + 3 + 4.</p>				

No.	Function	Object name	Data type	Flags
26	Total Reactive Energy Exported*	Meter reading	EIS 11, 4 byte	C, R, T
27	Reactive Energy Exported, Tariff 1	Meter reading	DPT 13.012	
28	Reactive Energy Exported, Tariff 2	Meter reading	or	
29	Reactive Energy Exported, Tariff 3	Meter reading	Non EIS, 8 byte	
30	Reactive Energy Exported, Tariff 4	Meter reading	DPT 29.012	
<p>These communication objects are available only if a combination meter of the A4x type is selected, and they send the momentary meter readings of the reactive energy exported.</p> <p>Communication object No. 27 is enabled if, in the Parameter window General, page 16, under parameter <i>Register for exported energy</i>, the option <i>yes</i> was selected. If the option <i>4 Tariffs</i> is additionally selected under the parameter <i>Tariffs</i>, communication options 27-30 are enabled. If a tariff meter has been parameterized, communication object No. 26 sends the meter reading of the sum of all tariffs of the exported reactive energy, whereas communication objects No. 27-30 send the exported reactive energy of the respective tariffs.</p> <p>Only the tariff that is currently active and the sum of the tariffs are sent. The communication object is also sent after bus voltage recovery, programming and ETS reset.</p> <p>With the 4 byte communication object, meter readings up to a max. of 2,147,483,647 Wh (2.147 GWh) and a resolution of 1 Wh can be sent. If values received from the connected meter are greater than the max. value, the end value of 2,147,483,647 Wh and the status bit No. 7 (end value of Meter Reading, Reactive Energy reached) is always sent.</p> <p>If a transformer rated meter is used, the energy consumption values of the reactive energy are sent as the primary values. For this purpose an 8 byte communication object is displayed. It is necessary to ensure that the receiving device or software is capable of processing 8 byte values.</p> <p>* The communication object <i>Total Reactive Energy Exported</i> is only displayed if a tariff meter has been selected and indicates the sum of the meter readings of tariffs 1 + 2 + 3 + 4.</p>				
31	Send Tariff	Tariff	Non EIS, 8 bit	C, R, T
<p>On these communication objects the tariff momentarily in use is sent, provided that a tariff meter with 2** or 4 tariffs has been selected in the Parameter window General, page 16. If the tariff is changed on the meter or via KNX, a new tariff is sent. The communication object is also sent after bus voltage recovery, programming and ETS reset.</p> <p>Telegram value: 0 = No tariff available 1 = Tariff 1 2 = Tariff 2 3 = Tariff 3 4 = Tariff 4 Other values = no function</p> <p>** 2 tariffs available only for meters of the configuration DELTAplus.</p>				
32	Tariff Switching	Tariff	Non EIS, 8 bit	C, W, T
<p>This communication object is only displayed as soon as a tariff meter has been selected in the Parameter window General, page 16.</p> <p>This communication object allows switching between 4 different tariffs. Switching to the required tariff is performed if a valid communication object value is received. If an invalid communication object value is received, the momentarily active tariff is sent. After the sending delay (if parameterized) the momentary data of the old tariff and the new tariff and sum of all tariffs up to the time of the tariff switch are sent on the bus. If the tariff could not be switched, the momentarily active tariff is sent again.</p> <p>Tariff switching via KNX only functions with DELTAplus or A4x type energy meters which have no separate tariff inputs for tariff switching.</p> <p>Telegram value: 0 = no function 1 = Switch to tariff 1 2 = Switch to tariff 2 3 = Switch to tariff 3 4 = Switch to tariff 4 Other values = no function</p>				

3.3.3 Communication objects *Power Values*

The communication objects for the power values are available only for the meter types A4x and DELTAplus [depending on the configuration (active energy meter or combination meter) and voltage network].

No.	Function	Object name	Data type	Flags
33	Request Power Values	Power values	EIS 1, 1 bit DPT 1.017	C, W, T
<p>The momentary power values are requested via the telegram with the value 1 on this communication object. The request applies for communication objects No. 34-53 (if they are functional). The momentarily applicable values are sent on the bus after the sending delay time (if parameterized).</p> <p>Telegram value: 0 = no function 1 = Request Power Values</p>				
34 35 36 37	Total Active Power Active Power L1 Active Power L2 Active Power L3	Power value	EIS 9, 4 byte DPT 14.056	C, R, T
<p>On these communication objects the momentary active power values of phases L1...L3 as well as the total active power are sent. The communication objects for the active powers L1...L3 are displayed dependent on the parameterized voltage network (2-, 3- or 4-wire voltage network). The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Power Values, page 25.</p>				
38 39 40 41	Total Reactive Power Reactive Power L1 Reactive Power L2 Reactive Power L3	Power value	EIS 9, 4 byte DPT 14.056	C, R, T
<p>On these communication objects the momentary reactive power values of phases L1...L3, as well as the total reactive power are sent. They are only displayed when a combination meter has been selected and/or are dependent on the parameterized voltage network (2-, 3- or 4-wire voltage network). The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Power Values, page 25.</p>				
42 43 44 45	Total Apparent Power Apparent Power L1 Apparent Power L2 Apparent Power L3	Power value	EIS 9, 4 byte DPT 14.056	C, R, T
<p>On these communication objects the momentary apparent power values of phases L1...L3, as well as the total apparent power are sent. They are only displayed when a combination meter has been selected and/or are dependent on the parameterized voltage network (2-, 3- or 4-wire voltage network). The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Power Values, page 25.</p>				

ABB i-bus[®] KNX Commissioning

No.	Function	Object name	Data type	Flags
46	Total Phase Angle Power	Power value	EIS 9, 4 byte DPT 14.055	C, R, T
47	Phase Angle Power L1			
48	Phase Angle Power L2			
49	Phase Angle Power L3			
<p>On these communication objects the phase angles of the power values L1...L3 as well as the total phase angle in degrees [°] are sent. They are only displayed when a combination meter has been selected and/or are dependent on the parameterized voltage network (2-, 3- or 4-wire voltage network). The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Power Values, page 25.</p>				
50	Total Power Factor	Power value	EIS 9, 4 byte DPT 14.057	C, R, T
51	Power Factor L1			
52	Power Factor L2			
53	Power Factor L3			
<p>On these communication objects the momentary power factors (cos phi) L1...L3, as well as the total power factor are sent. They are only displayed when a combination meter has been selected and/or are dependent on the parameterized voltage network (2-, 3- or 4-wire voltage network). The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Power Values, page 25.</p>				

3.3.4 Communication objects *Instrument Values*

The communication objects for the instrument values are available only for the meter types A4x and DELTAplus [depending on the configuration (active energy meter or combination meter) and voltage network].

No.	Function	Object name	Data type	Flags
54	Request Instrument Values	Instrument value	EIS 1, 1 bit DPT 1.017	C, W, T
<p>The momentary instrument values are requested via the telegram with the value 1 on this communication object (current, voltage, frequency, phase angle current and voltage, quadrant). The request applies for communication objects No. 55-74 (if they are functional).</p> <p>The momentarily applicable values are sent on the bus after the sending delay time (if parameterized).</p> <p>Telegram value: 0 = no function 1 = Request Instrument Values</p>				
55 56 57 58	Current (L1) Current L2 Current L3 Current N	Instrument value	EIS 9, 4 byte DPT 14.019	C, R, T
<p>On these communication objects the currents of phases L1...L3 are sent.</p> <p>The communication objects of currents L1...L3 are displayed with the selection of a 3- or 4-wire voltage network. Communication object No. 58 is available only for combination meters of the A4x type.</p> <p>The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Instrument Values, page 30.</p>				
59 60 61 62 63 64	Voltage (L1-N) Voltage L2-N Voltage L3-N Voltage L1-L2 Voltage L2-L3 Voltage L1-L3	Instrument value	EIS 9, 4 byte DPT 14.027	C, R, T
<p>On these communication objects the voltages of the individual phases relative to zero and to one another are sent. The communication objects for the voltages are displayed <i>dependent on the meter type A4x or DELTAplus used and the parameterized voltage network (2-, 3-, or 4-wire network)</i>.</p> <p>The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Instrument Values, page 30.</p>				
65	Frequency	Instrument value	EIS 9, 4 byte DPT 14.033	C, R, T
<p>On this communication object the momentary frequency of the voltage network is sent.</p> <p>The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Instrument Values, page 30.</p>				

ABB i-bus[®] KNX Commissioning

No.	Function	Object name	Data type	Flags
66 67 68	Phase Angle Current (L1) Phase Angle Current L2 Phase Angle Current L3	Instrument value	EIS 9, 4 byte DPT 14.055	C, R, T
<p>On these communication objects the phase angles of currents L1...L3 are sent. They are only displayed when a combination meter has been selected and/or are dependent on the parameterized voltage network (2-, 3- or 4-wire voltage network). The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Instrument Values, page 30.</p>				
69 70 71	Phase Angle Voltage (L1) Phase Angle Voltage L2 Phase Angle Voltage L3	Instrument value	EIS 9, 4 byte DPT 14.055	C, R, T
<p>On these communication objects the phase angles of voltages L1...L3 are sent. They are only displayed when a combination meter has been selected and/or are dependent on the parameterized voltage network (2-, 3- or 4-wire voltage network). The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Instrument Values, page 30.</p>				
72 73 74 75	Total Quadrant Quadrant L1 Quadrant L2 Quadrant L3	Instrument value	Non EIS, 8 byte	C, R, T
<p>The quadrant in which the meter measures is sent in these communication objects. These communication objects are only displayed when a combination meter has been selected and/or are dependent on the parameterized voltage network (2-, 3- or 4-wire voltage network). The send behavior (cyclically, on request, send on change) of these communication objects can be set in the Parameter window Instrument Values, page 30.</p> <p>Telegram value: 0 = No quadrant available 1 = Quadrant 1 2 = Quadrant 2 3 = Quadrant 3 4 = Quadrant 4 Other values = no function</p>				

3.3.5 Communication objects *Transformer Ratios*

No.	Function	Object name	Data type	Flags
76	Transformer Ratio Voltage	Transformer	EIS 10, 2 byte DPT 7.001	C, R, T
76	Transformer Ratio Voltage*	Transformer	EIS 11, 4 byte DPT 12.001	
77	Transformer Ratio Current	Transformer	EIS 10, 2 byte DPT 7.001	C, R, T
78	Total Transformer Ratio	Transformer	EIS 11, 4 byte DPT 12.001	C, R, T

On these communication objects the interface sends the set voltage or current transformer ratios on the meter. These communication objects are only displayed if a transformer rated energy meter has been selected beforehand in the [Parameter window General](#), page 16. The transformer ratios are sent after bus voltage recovery, after an ETS reset, after programming and with a change. The *Total Transformer Ratio* is calculated from the product of the *current* and *voltage transformer ratios*:

$$GT = CT * VT$$

GT = Total Transformer Ratio
 CT = Transformer Ratio Current
 VT = Transformer Ratio Voltage

* The communication object *Transformer Ratio Voltage* (4 byte) is available only for transformer rated meters of the A4x type.

3.3.6 Communication objects *Resettable Energy Register*

The communication objects for a resettable energy register are available only for the meter of the type ODINsingle (OD1365). The communication objects are displayed as soon as the parameter *Resettable Energy Register* has been confirmed with *yes*.

No.	Function	Object name	Data type	Flags		
12	Meter Reading	Resettable Energy Register	EIS 10, 2 byte DPT 7.001	C, R, T		
<table border="1"> <tr> <td>Note</td> </tr> <tr> <td>This communication object is only available with the meter configuration ODINsingle type OD1365.</td> </tr> </table> <p>This communication object displays the intermediate meter reading (similar to a trip meter in a car) of the active energy. The value of the communication object is also sent after bus voltage recovery, programming and an ETS reset. With the 4 byte communication object, meter readings up to a max. of 2,147,483,647 Wh (2.147 GWh) and a resolution of 1 Wh can be sent. If values received from the connected meter are greater than the max. value, the end value of 2,147,483,647 Wh and the status bit No. 7 (end value of Meter Reading, Active Energy reached) are always sent.</p>					Note	This communication object is only available with the meter configuration ODINsingle type OD1365.
Note						
This communication object is only available with the meter configuration ODINsingle type OD1365.						
79	Resettable Energy Register Reset	Resettable Energy Register	EIS 10, 2 byte DPT 7.001	C, R, T		
<table border="1"> <tr> <td>Note</td> </tr> <tr> <td>This communication object is only available with the meter configuration ODINsingle type OD1365.</td> </tr> </table> <p>If a telegram with the value 1 is received on this communication object, the resettable energy register value (communication object No. 12) is reset to 0 kWh. This can take up to ten seconds. If the reset operation fails, communication objects No. 11, 12 and 80 are sent again. If the erasing procedure is successful, object No. 12 is also sent.</p> <p>Telegram value: 0 = no function 1 = reset energy register value</p>					Note	This communication object is only available with the meter configuration ODINsingle type OD1365.
Note						
This communication object is only available with the meter configuration ODINsingle type OD1365.						
80	Send Resets	Resettable Energy Register	EIS 11, 4 byte DPT 12.001	C, R, T		
<table border="1"> <tr> <td>Note</td> </tr> <tr> <td>This communication object is only available with the meter configuration ODINsingle type OD1365.</td> </tr> </table> <p>The number of energy register resets can be sent with this communication object via the Meter Interface Module. The number of resets is sent if the resettable energy register is reset via the bus or on the meter itself using the Reset button and at bus voltage recovery.</p>					Note	This communication object is only available with the meter configuration ODINsingle type OD1365.
Note						
This communication object is only available with the meter configuration ODINsingle type OD1365.						

ABB i-bus[®] KNX Planning and application

4 Planning and application

4.1 Energy meter overview

A detailed overview of all available energy meters from ABB can be found in the energy meter [main catalog](#) (2CMC 480 001 C0201).

4.1.1 A-series

Type key

	Example	A	4	3	1	1	2	-	1	0	0
A-series (7 space units and 4 space units)		A									
Hardware/electronics - advanced			4								
Single phase direct connected				1							
Single phase transformer connected				2							
Three phase direct connected				3							
Three phase transformer connected				4							
Functionality - steel					1						
Functionality - bronze					2						
Functionality - silver					3						
Functionality - gold					4						
Functionality - platinum					5						
Accuracy class 1						1					
Accuracy class 2						2					
Accuracy class 0.5						5					
Integrated interface- none							0				
Integrated interface - infrared (IR)							1				
Integrated interface - RS-485							2				
Integrated interface - M-bus							3				
IEC approved + MID approved and verified									1		
Standard version										0	
Version for industrial applications (690 V)										1	
Version for railway applications (16.7 Hz)										2	
Standard version											0

ABB i-bus[®] KNX

Planning and application

4.1.1.1 Function overview

For simple selection of the right meter, various "metal colors" corresponding to the properties and functions are assigned to the energy meters from the A-series. They are described in the overview below.

Functions	A-Series				
	Platinum	Gold	Silver	Bronze	Steel
Type key for metal colors ¹	A4X 500 - XXX	A4X 400 - XXX	A4X 300 - XXX	A4X 200 - XXX	A4X 100 - XXX
Active energy measurement	•	•	•	•	•
Class B (cl. 1)	•	•	•	•	•
Pulse output	•	•	•	•	•
Alarm function	•	•	•	•	•
Bi-directional meters (supply/consumption)	•	•	•	•	•
Resettable energy register	•	•	•	•	•
Tariffs 1-4	•	•	•	•	•
Class C (cl. 0.5) for transformer rated meters	○	○	○	•	•
Value memory (day, week, month)	•	•	•	•	•
Min./max. values	•	•	•	•	•
Tariff control via integrated clock	•	•	•	•	•
Load profiles	•	•	•	•	•
Harmonics measurement	•	•	•	•	•
Reactive energy measurement	•	•	•	•	•
Inputs/output					
Pulse or alarm output	•	•	•	•	•
2 inputs/2 outputs	•	•	•	•	•
4 inputs/outputs (configurable)	•	•	•	•	•
Integrated interfaces					
M-bus	○	○	○	○	○
Modbus (RS-485)	○	○	○	○	○
Infrared (IR)	•	•	•	•	•

• = Standard

○ = Optional

¹ Type example = Platinum A41513 - 100

Note

Time dependent functions (value/event memories, min./max. values, load profiles, harmonics measurement), pulse inputs/outputs and resettable energy registers cannot be read or controlled via Meter Interface Module ZS/S 1.1.

ABB i-bus[®] KNX

Planning and application



Single phase meter
 80 A, 4 DIN with IR port
 Verified and approved according to MID
 IEC approval

Direct connected electricity meter

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import measurement					
Steel	57 ... 288 V AC	B (Cl. 1)	Pulse output	A41 111 - 100	2CMA170554R1000
Silver	57 ... 288 V AC	B (Cl. 1)	2 output, 2 input	A41 311 - 100	2CMA170502R1000

Direct connected electricity meter, RS-485

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import measurement					
Steel	57 ... 288 V AC	B (Cl. 1)	Pulse output	A41 112 - 100	2CMA170500R1000
Active import and export measurement					
Bronze	57 ... 288 V AC	B (Cl. 1)	Pulse output	A41 212 - 100	2CMA170501R1000
Silver	57 ... 288 V AC	B (Cl. 1)	2 output, 2 input	A41 312 - 100	2CMA170503R1000
Gold	57 ... 288 V AC	B (Cl. 1)	2 output, 2 input	A41 412 - 100	2CMA170505R1000

Direct connected electricity meter, M-bus

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import and export measurement					
Silver	57 ... 288 V AC	B (Cl. 1)	2 output, 2 input	A41 313 - 100	2CMA170504R1000
Gold	57 ... 288 V AC	B (Cl. 1)	2 output, 2 input	A41 413 - 100	2CMA170506R1000
Active and reactive import and export measurement					
Platinum	57 ... 288 V AC	B (Cl. 1) Reactive Cl. 2	Configurable	A41 513 - 100	2CMA170508R1000

ABB i-bus[®] KNX

Planning and application




Single phase meter

6 A, 4 DIN with IR port






Verified and approved according to MID

IEC approval

CTVT connected electricity meter

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import measurement					
 Steel	57 ... 288 V AC	B (Cl. 1)	Pulse output	A42 111 - 100	2CMA170555R1000

CTVT connected electricity meter, RS-485

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import measurement					
 Steel	57 ... 288 V AC	B (Cl. 1)	Pulse output	A42 112 - 100	2CMA170510R1000
Active import and export measurement					
 Bronze	57 ... 288 V AC	B (Cl. 1)	Pulse output	A42 212 - 100	2CMA170511R1000
 Silver	57 ... 288 V AC	B (Cl. 1)	2 output, 2 input	A42 312 - 100	2CMA170512R1000
 Gold	57 ... 288 V AC	B (Cl. 1)	2 output, 2 input	A42 412 - 100	2CMA170513R1000
Active and reactive import and export measurement, 16.7 Hz					
 Platinum	57 ... 288 V AC	C (Cl. 0.5) Reactive Cl. 2	Configurable	A42 552 - 120	2CMA170518R1000

CTVT connected electricity meter, M-bus



Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import and export measurement					
 Gold	57 ... 288 V AC	B (Cl. 1)	2 output, 2 input	A42 413 - 100	2CMA170514R1000
Active and reactive import and export measurement, 16.7 Hz					
 Platinum	57 ... 288 V AC	C (Cl. 0.5) Reactive Cl. 2	Configurable	A42 553 - 120	2CMA170519R1000

ABB i-bus[®] KNX Planning and application



Three phase meter

80 A, 7 DIN with IR port

Verified and approved according to MID

IEC approval

Direct connected electricity meter

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import measurement					
Steel	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	Pulse output	A43 111 - 100	2CMA170520R1000
Steel	3 x 57/100 ... 288/500 V AC	A (Cl. 2)	Pulse output	A43 121 - 100	2CMA170521R1000
Active import and export measurement					
Bronze	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	2 output, 2 input	A43 211 - 100	2CMA100012R1000
Silver	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	2 output, 2 input	A43 311 - 100	2CMA170524R1000

Direct connected electricity meter, RS-485

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import and export measurement					
Bronze	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	Pulse output	A43 212 - 100	2CMA170522R1000
Silver	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	2 output, 2 input	A43 312 - 100	2CMA170525R1000
Gold	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	2 output, 2 input	A43 412 - 100	2CMA170528R1000
Active and reactive import and export measurement					
Platinum	3 x 57/100 ... 288/500 V AC	B (Cl. 1) Reactive Cl. 2	Configurable	A43 512 - 100	2CMA170531R1000

Direct connected electricity meter, M-bus

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import and export measurement					
Bronze	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	Pulse output	A43 213 - 100	2CMA170523R1000
Silver	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	2 output, 2 input	A43 313 - 100	2CMA170526R1000
Gold	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	2 output, 2 input	A43 413 - 100	2CMA170529R1000
Active and reactive import and export measurement					
Platinum	3 x 57/100 ... 288/500 V AC	B (Cl. 1) Reactive Cl. 2	Configurable	A43 513 - 100	2CMA170532R1000

ABB i-bus[®] KNX

Planning and application



Three phase meter

6 A, 7 DIN with IR port

Verified and approved according to MID

IEC approval

CTVT connected electricity meter

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import measurement					
Steel	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	Pulse output	A44 111 - 100	2CMA170533R1000
Active import and export measurement					
Bronze	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	2 output, 2 input	A44 211 - 100	2CMA100013R1000
Silver	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	2 output, 2 input	A44 311 - 100	2CMA170536R1000

CTVT connected electricity meter, RS-485

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import and export measurement					
Bronze	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	Pulse output	A44 212 - 100	2CMA170534R1000
Silver	3 x 57/100 ... 288/500 V AC	C (Cl. 0.5)	2 output, 2 input	A44 352 - 100	2CMA170537R1000
Gold	3 x 57/100 ... 288/500 V AC	C (Cl. 0.5)	2 output, 2 input	A44 452 - 100	2CMA170540R1000
Active and reactive import and export measurement					
Platinum	3 x 57/100 ... 288/500 V AC	C (Cl. 0.5) Reactive Cl. 2	Configurable	A44 552 - 100	2CMA170545R1000
Active and reactive import and export measurement, 690 V AC					
Platinum	3 x 100/173 ... 400/690 V AC	C (Cl. 0.5) Reactive Cl. 2	2 output, 2 input	A44 552 - 110	2CMA170549R1000

CTVT connected electricity meter, M-bus

Functionality	Voltage V	Accuracy class	I/O	Type	Order code
Active import and export measurement					
Bronze	3 x 57/100 ... 288/500 V AC	B (Cl. 1)	Pulse output	A44 213 - 100	2CMA170535R1000
Silver	3 x 57/100 ... 288/500 V AC	C (Cl. 0.5)	2 output, 2 input	A44 353 - 100	2CMA170538R1000
Gold	3 x 57/100 ... 288/500 V AC	C (Cl. 0.5)	2 output, 2 input	A44 453 - 100	2CMA170541R1000
Active and reactive import and export measurement					
Platinum	3 x 57/100 ... 288/500 V AC	C (Cl. 0.5) Reactive Cl. 2	Configurable	A44 553 - 100	2CMA170546R1000
Active and reactive import and export measurement, 690 V AC					
Platinum	3 x 100/173 ... 400/690 V AC	C (Cl. 0.5) Reactive Cl. 2	2 output, 2 input	A44 553 - 110	2CMA170548R1000

ABB i-bus[®] KNX

Planning and application

4.1.2 DELTAplus

ABB offers a comprehensive range of energy meters of the DELTAplus type. In the same way, meters of the DZ+(EIB) type can be read. In the following an overview of the available device configurations suitable for connection to the Meter Interface Module is provided:

Type key

	1	2	3	4	5	6-8
Sequence of the type designation	1	2	3	4	5	6-8
Type designation example	D	D	B	1	3	056
Basis						
Standard	D					
Measurement method						
Active energy meter CTVT connected		A				
Active power meter with direct connection		B				
Active and reactive power with CTVT connection		C				
Active and reactive power with direct connection		D				
Communication						
Pulse output, IR interface			B			
Accuracy						
Class 1				1		
Class 2				2		
Voltage						
1 x 57 - 288 V (2-wire AC grid L, N)					1	
3 x 100-500 V (3-wire three-phase L1, L2, L3)					2	
3 x 57-288 / 100-500 V (4-wire three-phase L1, L2, L3, N)					3	
Optional functions						
No options						000
4 tariffs (control only via 230 V input)						002
4 tariffs switching via IR communication (ZS/S)						004
4 tariffs switching via IR communication (ZS/S) or by internal clock. Time-dependent functions*						006

* S0 meter pulses and time dependent functions cannot be processed via the Meter Interface Module.

The following energy meters of the DELTAplus type (MID¹ certification) can be read via the Meter Interface Module ZS/S:

Standard meters DELTAplus

Meters with transformer rating for 1 A and 5 A transformers

Type	Voltage [V]	Current [A]	Class	Order No.
Active power meters				
DAB11000	1 x 57...288	1 (6)	1	2CMA 180 819 R1000
DAB12000	3 x 100...500	1 (6)	1	2CMA 180 807 R1000
DAB13000	3 x 57/100 to 3 x 288/500	1 (6)	1	2CMA 180 806 R1000
Combination meters (active and reactive power)				
DCB12000	3 x 100...500	1 (6)	1	2CMA 180 809 R1000
DCB13000	3 x 57/100 to 3 x 288/500	1 (6)	1	2CMA 180 808 R1000
Tariff meters				
DAB13002 ²	3 x 57/100 to 3 x 288/500	1 (6)	1	2CMA 180 871 R1000
DAB13004 ³	3 x 57/100 to 3 x 288/500	1 (6)	1	2CMA 139 460 R1000
DAB13006 ⁴	3 x 57/100 to 3 x 288/500	1 (6)	1	2CMA 139 392 R1000

Direct measuring meters DELTAplus

Type	Voltage [V]	Current [A]	Class	Order No.
Active power meters				
DBB21000	1 x 57...288	5(80)	2	2CMA 180 804 R1000
DBB12000	3 x 100...500	5(80)	1	2CMA 180 803 R1000
DBB22000	3 x 100...500	5(80)	2	2CMA 180 802 R1000
DBB13000	3 x 57/100 to 3 x 288/500	5(80)	1	2CMA 180 801 R1000
DBB23000	3 x 57/100 to 3 x 288/500	5(80)	2	2CMA 180 800 R1000
Combination meter (active and reactive power)				
DDB23000	3 x 57/100 to 3 x 288/500	5(80)	2	2CMA 180 810 R1000
Tariff meters				
DBB23002 ²	3 x 57/100 to 3 x 288/500	5(80)	2	2CMA 180 813 R1000
DBB23004 ³	3 x 57/100 to 3 x 288/500	5(80)	2	2CMA 139 461 R1000
DBB23006 ⁴	3 x 57/100 to 3 x 288/500	5(80)	2	2CMA 139 394 R1000

¹ The S0 pulse outputs of certified meters are checked to ensure that they function during calibration. However, they are not calibrated. On combination meters only the active power section is calibrated. The validity period for the official calibration is eight years.

² Control of the tariffs only via 230 V input

³ Control of the tariffs via IR communication (ZS/S 1.1)

⁴ Control of the tariffs via IR communication (ZS/S 1.1) or by internal clock

ABB i-bus[®] KNX

Planning and application

4.1.3 DELTAsingle

The following energy meters of the DELTAsingle type (MID¹ certification) for 2-wire AC current (1 phase + N, 230 V ~) can be read via the Meter Interface Module ZS/S:

Type	Integrated clock	Tariffs ²	Pulse output	Order No.
FBB11200	-	1	yes	2CMA 180 892 R1000
FBB11205	yes	2	yes	2CMA 180 894 R1000
FBB11206	yes	4	yes	2CMA 180 896 R1000
FBU11200	-	1	-	2CMA 180 891 R1000
FBU11205	yes	2	-	2CMA 180 893 R1000
FBU11206	yes	4	-	2CMA 180 895 R1000

¹ The S0 pulse outputs of certified meters are checked to ensure that they function during calibration. However, they are not calibrated. On combination meters only the active power section is calibrated. The validity period for the official calibration is eight years.

² Tariffs can only be controlled via the meter and not via the Meter Interface Module.

4.1.4 ODIN

The following energy meters of the ODIN type can be read via the Meter Interface Module ZS/S:

Direct meters for four-wire three-phase (3 phases + N, 3 x 230/400 V~)

Type	Voltage [V]	Current [A]	Class	Order No.
OD4165	3 x 230/400	65	2	2CMA 131 024 R1000

Transformer rated meters for /5 A transformers for four-wire three-phase (3 phases + N, 3 x 230/400 V~)

Type	Voltage [V]	Current [A]	Class	Order No.
OD4110	3 x 230/400	5	2	2CMA 131 024 R1000

4.1.5 ODINsingle

The following energy meters of the ODINsingle type can be read via the Meter Interface Module ZS/S:

Direct meter (1-phase + N, 230 V ~)

Type	Voltage [V]	Current [A]	Class	Order No.
OD1065	230	65	1	2CMA 131 040 R1000

Direct meter , (1-phase + N, 230 V ~) with resettable energy register and pulse output

Type	Voltage [V]	Current [A]	Class	Order No.
OD1365	230	65	1	2CMA 131 041 R1000

4.2 Behavior after bus voltage recovery, download and ETS reset

	Bus voltage recovery* (BW)	Behavior after programming	ETS reset <i>Reset device</i>
Sending delay	Active, if parameterized	Active, if parameterized	Active, if parameterized
Meter reading ¹ Active / reactive energy (Tariffs 1 -4, total)	Momentary meter reading (or meter reading tariff X and meter reading total) is sent	Momentary meter reading (or meter reading tariff X and meter reading total) is sent	Momentary meter reading (or meter reading tariff X and meter reading total) is sent
Power values ² P _{active} , P _{reactive} , P _{apparent} , phase angle, power factor	Are sent as soon as the change value under parameter <i>Send power values on change</i> is $\geq \pm 1$	Are sent as soon as the change value under parameter <i>Send power values on change</i> is $\geq \pm 1$	Are sent as soon as the change value under parameter <i>Send power values on change</i> is ≥ 1
Instrument values ² Current, voltage, frequency, phase angle (I, U)	Are sent as soon as the change value under parameter <i>Send instrument values on change</i> ≥ 1	Are sent as soon as the change value under parameter <i>Send instrument values on change</i> ≥ 1	Are sent as soon as the change value under parameter <i>Send instrument values on change</i> ≥ 1
Current tariff ³	Is sent	Is sent	Is sent
Transformer ratio ⁴ Current, voltage, total	Is sent	Is sent	Is sent
Power failures ³	Are sent	Are sent	Are sent
Status byte	Is sent	Is sent	Is sent
Error message	Is sent	Is sent	Is sent
Meter type	Is sent	Is sent	Is sent

¹ The meter reading of the reactive energy or meter reading total/tariffs 1-4 to be sent is dependent on the parameterized energy meter (meter type, configuration, tariffs).

² Power and instrument values are sent depending on the parameterized configuration of the meter of type A4x or DELTAplus.

³ Tariffs and power failures are not sent by energy meters of the ODIN type.

⁴ Transformer ratios can only be sent with meters of the type A4x or DELTAplus and ODIN.

Note

* We recommend the use of an Uninterruptible Power Supply such as the SU/S 30.640.1, to avoid brief failures of the bus voltage.

4.3 LED display

The status of the device and the IR communication are indicated via the LED on the front of the device. After bus voltage recovery, programming and/or ETS reset all three LEDs light up for approx. 1 second. Possible states of the display LEDs are compiled in the following table:

LED	Status	Description
LED (red) Error	Flashes	Parameterized meter does not correspond with connected meter
	ON	IR communication disrupted
LED (yellow) Teleg. OUT	Flashes	Telegram traffic from the interface to the meter
LED (yellow) Teleg. IN	Flashes	Telegram traffic from the meter to the interface

A.2 DELTAplus error codes

Energy meters of the DELTAplus type can indicate installation and connection faults on the display of the meter in the form of 3-digit error codes. The following table describes the individual error codes and the possible causes:

Error code	Description/cause		
100	No voltage or voltage too low in phase 1		
101	No voltage or voltage too low in phase 2		
102	No voltage or voltage too low in phase 3		
123	Power in phase 1 is negative <table border="1" data-bbox="507 683 1345 857"> <thead> <tr> <th>Note</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> – reverse polarity of current connection – direction of current flow through the current transformer is incorrect – phase voltages incorrectly connected – current transformer connected to incorrect current input </td> </tr> </tbody> </table>	Note	<ul style="list-style-type: none"> – reverse polarity of current connection – direction of current flow through the current transformer is incorrect – phase voltages incorrectly connected – current transformer connected to incorrect current input
Note			
<ul style="list-style-type: none"> – reverse polarity of current connection – direction of current flow through the current transformer is incorrect – phase voltages incorrectly connected – current transformer connected to incorrect current input 			
124	Power in phase 2 is negative <table border="1" data-bbox="507 981 1345 1155"> <thead> <tr> <th>Note</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> – Reverse polarity of current connection – Direction of current flow through the current transformer is incorrect – Incorrectly connected phase voltages – Current transformer connected to incorrect current input </td> </tr> </tbody> </table>	Note	<ul style="list-style-type: none"> – Reverse polarity of current connection – Direction of current flow through the current transformer is incorrect – Incorrectly connected phase voltages – Current transformer connected to incorrect current input
Note			
<ul style="list-style-type: none"> – Reverse polarity of current connection – Direction of current flow through the current transformer is incorrect – Incorrectly connected phase voltages – Current transformer connected to incorrect current input 			
125	Power in phase 3 is negative <table border="1" data-bbox="507 1279 1345 1453"> <thead> <tr> <th>Note</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> – Reverse polarity of current connection – Direction of current flow through the current transformer is incorrect – Incorrectly connected phase voltages – Current transformer connected to incorrect current input </td> </tr> </tbody> </table>	Note	<ul style="list-style-type: none"> – Reverse polarity of current connection – Direction of current flow through the current transformer is incorrect – Incorrectly connected phase voltages – Current transformer connected to incorrect current input
Note			
<ul style="list-style-type: none"> – Reverse polarity of current connection – Direction of current flow through the current transformer is incorrect – Incorrectly connected phase voltages – Current transformer connected to incorrect current input 			
126	Total effective power is negative <table border="1" data-bbox="507 1576 1345 1751"> <thead> <tr> <th>Note</th> </tr> </thead> <tbody> <tr> <td> <ul style="list-style-type: none"> – reverse polarity of one or more current connections – direction of current flow through one or more current transformers is wrong – Incorrectly connected phase voltages – Current transformer connected to incorrect current input </td> </tr> </tbody> </table>	Note	<ul style="list-style-type: none"> – reverse polarity of one or more current connections – direction of current flow through one or more current transformers is wrong – Incorrectly connected phase voltages – Current transformer connected to incorrect current input
Note			
<ul style="list-style-type: none"> – reverse polarity of one or more current connections – direction of current flow through one or more current transformers is wrong – Incorrectly connected phase voltages – Current transformer connected to incorrect current input 			
128	Phase voltage connected to neutral conductor N on meter (terminal 11) <table border="1" data-bbox="507 1874 1345 1955"> <thead> <tr> <th>Note</th> </tr> </thead> <tbody> <tr> <td>Incorrect connection of phase voltage and neutral conductor</td> </tr> </tbody> </table>	Note	Incorrect connection of phase voltage and neutral conductor
Note			
Incorrect connection of phase voltage and neutral conductor			

A.3 DELTAsingle error codes

Energy meters of the DELTAsingle type can indicate installation and connection faults on the display of the meter in the form of 3-digit error codes. The following table describes the individual error codes and the possible causes:

Error code	Description/cause
100	Checksum error tariff 1, active energy
101	Checksum error tariff 2, active energy
102	Checksum error tariff 3, active energy
103	Checksum error tariff 4, active energy
104	Checksum error total active energy
105	Checksum error monthly values, active energy
106	Checksum error
107	Checksum error
200	Checksum error tariff 1, reactive energy
201	Checksum error tariff 2, reactive energy
202	Checksum error tariff 3, reactive energy
203	Checksum error tariff 4, reactive energy
204	Checksum error total, reactive energy
205	Checksum error monthly values, reactive energy
300	Voltage U1, U2 or U3 too high (above meter specification range)
301	Voltage U1, U2 or U3 too low (under meter specification range)
302	Current I1, I2 or I3 too high (above meter specification range)
303	Frequency out of meter specification
304	U1 missing
305	U2 missing
306	U3 missing
307	Phase connected to neutral conductor
400	Negative power phase 1
401	Negative power phase 2
402	Negative power phase 3
403	Total negative power
404	External data signal on input out of specification
500	Pulse overlay
501	Date not set
502	Time not set
503	Tariffs incorrectly set
600	Single phase meter
601	Two phase meter
602	Three phase meter
603	Active energy
604	Reactive energy
700	EEPROM failure
701	Extended EEPROM failure
702	Vref is not VDD/2
703	Temperature sensor error
704	Clock error (RTC)
800 - 807	Internal error (for ABB use only)

A.4 Energy measurement


A.4.1 Measurement fundamentals

Different measurement methods are employed on energy meters depending on the type selected. The following equations are vector equations.



Measurement process with one measuring element

This method only produces the correct result when the phase loading is symmetrical (balanced).




$$P = 3 \cdot I_{L3} \cdot U_{L3}$$

This method is not suitable for exact measurements in three-phase networks, as a 100 % symmetrical load is generally very seldom.



Measurement process with 2 measuring elements

This method is used in three-phase networks without a neutral conductor (three conductor network) with the same or any load.



$$P = U_{L1} \cdot I_{L1} + U_{L2} \cdot I_{L2} + U_{L3} \cdot I_{L3}$$

$$\Sigma I = I_{L1} + I_{L2} + I_{L3} = 0$$

$$P = U_{L1} \cdot I_{L1} - U_{L2} (I_{L1} + I_{L3}) + U_{L3} \cdot I_{L3}$$


$$P = I_{L1}(U_{L1} - U_{L2}) + I_{L3}(U_{L3} - U_{L2})$$

This measurement process (with 2 measuring elements) is not suitable for very accurate measurements in networks with inductive or capacitive loads with a low $\cos \varphi$. In these cases, a measurement process with three measuring elements should be selected.



Measurement process with 3 measuring elements

This method is used in three-phase networks with neutral conductor (four-conductor networks). However, it can be used in networks without neutral conductor, provided that an artificial star point is provided.




$$P = U_{L1} \cdot I_{L1} + U_{L2} \cdot I_{L2} + U_{L3} \cdot I_{L3}$$

This measurement method is very accurate even with asymmetrical loads and a low $\cos \varphi$.

Active and reactive power

Capacitive or inductive loads result in a phase angle shift between the phase current and the phase voltage.



$$\text{Active power} = U \cdot I \cdot \cos \varphi$$

$$\text{Reactive power} = U \cdot I \cdot \sin \varphi$$

$$\text{Apparent power} = U \cdot I$$


The maximum permissible phase shift is often subject to a contractual agreement with the electrical utility company.

In order to ensure that the defined values are not exceeded, power factor compensation equipment is installed and the compensation is monitored with reactive power meters or combination meters.

A.4.2 Measurements with current and/or voltage transformers

Current and/or voltage transformers must be used in order to measure currents and voltages out of range of the rated measurement range of the meter.

It is important that the secondary currents and voltages of the measurement transformers are within the permissible approved measurement range of the transformer rated meters. In order to ensure the required accuracy, the selected transformers should have a higher accuracy class than the meter which is used. Please note that the current transformers must be connected using the correct polarity (K1 → L1, k1 → I1).



Note

Secondary measurement cables from the transformer must be laid separately from the main current cables.
The terminal block shown above is not compulsory for installation purposes but simplifies any service measures required.

Power consumption of the secondary measurement cables

If a current transformer is connected in series with an energy meter, the power consumption of the secondary measurement cables must be considered during design of the current transformer in order to obtain the correct measurement values. The current transformer rating (S_{sec}) must be selected to take the power requirement of the connected meters and the secondary power loss of the measurement cables into account.


The following applies: $S_{sec} \geq S_{cable} + S_{meter}$ S = apparent power (VA)

The table of reference values below presents the cable power loss (S_{cable}) as a function of the cable length and cross-section.

Secondary current A	Cross-section mm ²	Cable power loss (VA)						
		Cable length (input/output cable)						
		1 m	2 m	5 m	10 m	20 m	50 m	100 m
1 A	1.0	0.04	0.07	0.18	0.36	0.71	1.78	3.57
1 A	2.5	0.01	0.03	0.07	0.14	0.29	0.72	1.43
1 A	4.0	–	–	–	0.09	0.18	0.45	0.89
5 A	2.5	0.36	0.71	1.78	3.57	7.10	17.8	–
5 A	4.0	0.22	0.45	1.12	2.24	4.50	11.2	22.4
5 A	6.0	0.15	0.30	0.74	1.49	3.00	7.40	14.9

Energy summation

If the energy of several loads is to be measured using a single energy meter, the individual cables of assigned current transformers must be connected in parallel. All the current transformers used must have identical transformer ratios, and the sum of the currents may not exceed 6 A. In the example shown (3-wire network) the meter measures the sum of the energy consumption of cable 1 and cable 2. The type of load (asymmetrical or symmetrical) is irrelevant in this case.



The same application is possible in a 4-wire network. Current transformers are then required in L1, L2 and L3. Please note that the current transformers must be connected using the correct polarity (K1 → L1, k1 → I1).

A.4.3 Energy calculation

On directly connected energy meters, the energy on the LCD display is the same as the consumed energy. If current and/or voltage transformers are used, the displayed consumption value must be multiplied by the transformer ratio (CT x VT) in order to obtain the actual energy consumption.

The LED beside the registering mechanism and the LCD display symbols [A] and [R] flash at a frequency (Z_k) of:

- Direct meters: 1,000 pulses/kWh (kvarh)
- Meters with transformer rating: 5,000 pulses/kWh (kvarh)

In order to derive the LED/LCD flashing frequency with the given power, the equations in the following example can be used:

Three-wire three-phase current system with current and voltage transformers

Current transformer type:	250/5 A
Voltage transformer type:	600/100 V
Secondary current (I):	3 A
Secondary voltage (U):	100 V
Power factor (cos φ):	0.9
Meter constants (LED, LCD) (Z_k):	5,000 pulses/kWh

Voltage transformer ratio (VT):

$$VT = \frac{\text{Primary voltage (U}_P\text{)}}{\text{Secondary voltage (U}_S\text{)}} = \frac{600 \text{ V}}{100 \text{ V}} = 6$$

Current transformer ratio (CT):

$$CT = \frac{\text{Primary current (I}_P\text{)}}{\text{Secondary current (I}_S\text{)}} = \frac{250 \text{ A}}{5 \text{ A}} = 50$$

Secondary power (P_s):

$$P_s = \frac{\sqrt{3} \cdot U \cdot I \cdot \cos \varphi}{1000} = \frac{\sqrt{3} \cdot 100 \text{ V} \cdot 3 \text{ A} \cdot 0,9}{1000} = 0,47 \text{ kW}$$

Primary power (P_p):

$$P_p = P_s \cdot CT \cdot VT = 0,47 \text{ kWh} \cdot 50 \cdot 6 = 141 \text{ kW}$$

LED/LCD flash frequency (B_f):

$$B_f = \frac{P_s \cdot Z_k}{3600} = \frac{0,47 \text{ kW} \cdot 5000 \text{ Imp/kWh}}{3600} = 0,65 \text{ Hz}$$

LED/LCD flash period (B_p):

$$B_p = \frac{1}{B_f} = \frac{1}{0,65 \text{ Hz}} = 1,53 \text{ s}$$

When correctly connected the LED and the LCD display symbol [A] should flash approx. every 1.5 s in the example shown.

A.5 Ordering Information

Short description	Description	Order No.	bbn 40 16779 EAN	Price group	Unit weight 1 pc. [kg]	Packaging [pc]
ZS/S 1.1	Meter Interface Module, MDRC	2CDG 110 083 R0011	66207 9	26	0.1	1

Notes

Contact

ABB STOTZ-KONTAKT GmbH

Eppelheimer Straße 82

69123 Heidelberg, Germany

Phone: +49 (0)6221 701 607 (Marketing)

Fax: +49 (0)6221 701 724

E-mail: knx.marketing@de.abb.com

Additional information and contact partners:

www.abb.com/knx

Note:

We reserve the right to make technical changes or modify the contents of this document without prior notice.

With regard to purchase orders, the agreed particulars shall prevail. ABB AG does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB AG.

Copyright© 2012 ABB

All rights reserved