

ABB GENERAL PURPOSE DRIVES

ACS560 standard control program

Firmware manual



List of related manuals

See section Related documents on page 14.

You can find manuals and other product documents in PDF format on the Internet. See section Document library on the Internet on the inside of the back cover. For manuals not available in the Document library, contact your local ABB representative.

The code below opens an online listing of the manuals applicable to the product:



ACS560 manuals

Table of contents



2. Start-up, control with I/O and ID run



Table of contents

1. Introduction to the manual

Contents of this chapter	11
Applicability	11
Safety instructions	11
Target audience	11
Purpose of the manual	12
Contents of this manual	12
Categorization by frame (size)	13
Related documents	14
Terms and abbreviations	16
Cyber security disclaimer	17



2. Start-up, control with I/O and ID run

Contents of this chapter	19
How to start up the drive	20
How to start up the drive using the basic control panel	20
How to control the drive through the I/O interface	26
Identification (ID) run	27
ID run procedure	28

3. Using the control panel

4. Program features

What this chapter contains	33
Local control vs. external control	33
Local control	34
External control	34
Operating modes of the drive	37
Speed control mode	39
Torque control mode	39
Frequency control mode	39
Special control modes	39
Drive configuration and programming	39
Configuring via parameters	40
Control interfaces	41
Programmable analog inputs	41
Programmable analog outputs	41
Programmable digital inputs and outputs	41
Programmable relay outputs	41
Fieldbus control	41
Programmable I/O extensions	42
Application control	43
Reference ramping	43

6 Table of contents

Constant speeds/frequencies	44
Critical speeds/frequencies	44
Speed controller autotune	45
User Load Curve	49
Process PID control	50
PID trim function	54
Timed functions	60
Mechanical brake control	60
Motor control	65
Motor types	65
Motor identification	65
Scalar motor control	65
Vector control	66
Speed control performance figures	67
Torque control performance figures	68
Power loss ride-through	68
U/f ratio	68
Flux braking	69
DC magnetization	70
Energy optimization	72
Switching frequency	72
Rush control	73
Jogging	73
Speed compensated stop	76
DC voltage control	77
Overvoltage control	77
Undervoltage control (power loss ride-through)	77
Voltage control and trip limits	79
Brake chopper	81
Safety and protections	81
Fixed/Standard protections	81
Emergency stop	82
Motor thermal protection	83
Motor overload protection	88
Programmable protection functions	89
Automatic fault resets	92
Diagnostics	93
Signal supervision	93
Energy saving calculators	93
Load analyzer	94
Diagnostics menu	94
Miscellaneous	95
Backup and restore	95
User parameter sets	95
Data storage parameters	96
User lock	96
Sine filter support	97
Short and Long menu	97
Basic panel home view options	97



5. Control macros

Contents of this chapter	99
Overview	99
ABB standard macro	100
Default control connections for the ABB standard macro	101
Terminal sizes	101
ABB standard macro (vector)	103
Default control connections for the ABB standard (Vector) macro	104
Terminal sizes	104
3-wire macro	106
Default control connections for the 3-wire macro	107
Motor potentiometer macro	109
Default control connections for the ABB potentiometer macro	112
Terminal sizes	112
PID macro	114
Default control connections for the ABB PID macro	115
Panel PID macro	117
Default control connections for the Panel PID macro	118
Terminal sizes	118
Torque control macro	120
Default control connections for the Torque control macro	121
Pump and Fan Control (PFC) macro	123
Default control connections for the PFC macro	130
Soft Pump and Fan Control (SPFC) macro	132
Default control connections for the SPFC macro	139
Pharma macro	141
Default control connections for the Pharma macro	142
Plastic extrusion macro	144
Default control connections for the ABB Plastic extrusion macro	145
Jigar macro	147
Jigar machine sequence	147
Default control connections for the ABB Jigar macro	149
Parameter default values for different application macros	152



6. Parameters

What this chapter contains	159
Terms and abbreviations	160
Summary of parameter groups	161
Parameter listing	163
01 Actual values	163
03 Input references	166
04 Warnings and faults	167
05 Diagnostics	168
06 Control and status words	171
07 System info	176
10 Standard DI, RO	177
11 Standard DIO, FI, FO	185
12 Standard AI	186
13 Standard AO	191
19 Operation mode	196
20 Start/stop/direction	198
21 Start/stop mode	207
22 Speed reference selection	215

8 Table of contents

23 Speed reference ramp	224
24 Speed reference conditioning	228
25 Speed control	228
26 Torque reference chain	233
28 Frequency reference chain	238
30 Limits	249
31 Fault functions	256
32 Supervision	264
34 Timed functions	271
35 Motor thermal protection	278
36 Load analyzer	289
37 User load curve	290
40 Process PID set 1	293
41 Process PID set 2	307
43 Brake chopper	310
44 Mechanical brake control	312
45 Energy efficiency	313
46 Monitoring/scaling settings	317
47 Data storage	320
49 Panel port communication	321
50 Fieldbus adapter (FBA)	324
51 FBA A settings	328
52 FBA A data in	329
53 FBA A data out	330
58 Embedded fieldbus	330
70 Override	338
71 External PID1	340
76 PFC configuration	343
77 PFC maintenance and monitoring	349
90 Feedback selection	350
95 HW configuration	350
96 System	352
97 Motor control	359
98 User motor parameters	362
99 Motor data	363

Differences in the default values between 50 Hz and 60 Hz supply frequency settings	369
Parameters supported by Modbus backwards compatibility with 550	370

7. Additional parameter data

What this chapter contains	373
Terms and abbreviations	373
Fieldbus addresses	374
Parameter groups 1...9	375
Parameter groups 10...99	378

8. Fault tracing

What this chapter contains	407
Safety	407
Indications	407



Warnings and faults	407
Pure events	408
Editable messages	408
Warning/fault history	408
Event log	408
Viewing warning/fault information	408
Warning messages	410
Fault messages	422

9. Fieldbus control through the embedded fieldbus interface (EFB)

What this chapter contains	435
System overview	435
Connecting the fieldbus to the drive	435
Setting up the embedded fieldbus interface	437
Setting the drive control parameters	439
Basics of the embedded fieldbus interface	441
Control word and Status word	442
References	442
Actual values	442
Data input/outputs	442
Register addressing	442
About the control profiles	444
Control Word	445
Control Word for the ABB Drives profile	445
Control Word for the DCU Profile	446
Status Word	449
Status Word for the ABB Drives profile	449
Status Word for the DCU Profile	450
State transition diagrams	452
State transition diagram for the ABB Drives profile	452
References	454
References for the ABB Drives profile and DCU Profile	454
Actual values	455
Actual values for the ABB Drives profile and DCU Profile	455
Modbus holding register addresses	456
Modbus holding register addresses for the ABB Drives profile and DCU Profile	456
Modbus function codes	457
Exception codes	458
Coils (0xxxx reference set)	459
Discrete inputs (1xxxx reference set)	461
Error code registers (holding registers 400090...400100)	463

10. Fieldbus control through a fieldbus adapter

What this chapter contains	465
System overview	466
Basics of the fieldbus control interface	468
Control word and Status word	469
References	470
Actual values	471



Contents of the fieldbus Control word	472
Contents of the fieldbus Status word	474
The state diagram	475
Automatic drive configuration for fieldbus control	476
Automatic drive configuration for fieldbus control	477
Setting up the drive for fieldbus control manually	481
Parameter setting example: FPBA (PROFIBUS)	482

11. Control chain diagrams

Contents of this chapter	485
Frequency reference selection	486
Frequency reference modification	487
Speed reference source selection I	488
Speed reference source selection II	489
Speed reference ramping and shaping	490
Speed feedback	491
Speed error calculation	492
Speed controller	493
Torque reference source selection and modification	494
Reference selection for torque controller	495
Torque limitation	496
Process PID setpoint and feedback source selection	497
Process PID controller	498
External PID setpoint and feedback source selection	499
External PID controller	500
Direction lock	501
Override	502
PID trim auto connection	503

12. Parameterization with drive composer

Contents of this chapter	505
Drive composer	505
How to connect the drive composer	506

13. Parameterization with automation builder drive manager

Contents of this chapter	509
Automation builder drive manager	509

Further information





Introduction to the manual

Contents of this chapter

The chapter describes applicability, target audience and purpose of this manual. It also describes the contents of this manual and refers to a list of related manuals for more information.

Applicability

The manual applies to the ACS560 standard control program (IGPKA version 2.08 or later).

To check the firmware version of the control program in use, see system information parameter [07.05 Firmware version](#) (see page [176](#)) on the control panel.

Safety instructions

Follow all safety instructions.

- Read the **complete safety instructions** in the *Hardware manual* of the drive before you install, commission, or use the drive.
- Read the **firmware function-specific warnings and notes** before changing parameter values. These warnings and notes are included in the parameter descriptions presented in chapter [Parameters](#) on page [159](#).

Target audience

The reader is expected to know the fundamentals of electricity, wiring, electrical components and electrical schematic symbols.

The manual is written for readers worldwide.

Purpose of the manual

This manual provides information needed for designing, commissioning, or operating the drive system.

Contents of this manual

The manual consists of the following chapters:

- *Introduction to the manual* (this chapter, page 11) describes applicability, target audience, purpose and contents of this manual. At the end, it lists terms and abbreviations.
 - *Start-up, control with I/O and ID run* (page 19) describes how to start up the drive as well as how to start, stop, change the direction of the motor rotation and adjust the motor speed through the I/O interface.
 - *Using the control panel* (page 31) contains instructions for removing and reinstalling the assistant control panel and briefly describes its display, keys and key shortcuts.
 - *Program features* (page 33) describes program features with lists of related user settings, actual signals, and fault and warning messages.
 - *Control macros* (page 99) contains a short description of each macro together with a connection diagram. Macros are pre-defined applications which will save the user time when configuring the drive.
 - *Parameters* (page 159) describes the parameters used to program the drive.
 - *Additional parameter data* (page 353) contains further information on the parameters.
 - *Fault tracing* (page 387) lists the warning and fault messages with possible causes and remedies.
 - *Fieldbus control through the embedded fieldbus interface (EFB)* (page 415) describes the communication to and from a fieldbus network using the embedded fieldbus interface of the drive.
 - *Fieldbus control through a fieldbus adapter* (page 445) describes the communication to and from a fieldbus network using an optional fieldbus adapter module
 - *Control chain diagrams* (page 461) describes the parameter structure within the drive.
 - *Parameterization with drive composer* (page 479) describes about managing the drive parameters with drive composer application.
 - *Parameterization with automation builder drive manager* (page 483) describes about managing the drive parameters with automation builder drive manager application.
 - *Further information* (inside of the back cover, page 487) describes how to make product and service inquiries, get information on product training, provide feedback on ABB Drives manuals and find documents on the Internet.
-

Categorization by frame (size)

The ACS560 is manufactured in several frames (frame sizes), which are denoted as RN, where N is an integer. Some information which only concern certain frames are marked with the symbol of the frame (RN).

The frame is marked on the type designation label attached to the drive, see chapter *Operation principle and hardware description*, section *Type designation label* in the *Hardware manual* of the drive.

Related documents

Drive manuals and guides	Code (English)	Code (Hindi)
<i>ACS560 standard control program firmware manual</i>	3AXD50000044997	3AXD50000045887
<i>ACS560 (0.75 to 160 kW, 1.0 to 215 hp) hardware manual</i>	3AXD50000044998	3AXD50000045888
<i>ACS560 drives quick installation and start-up guide</i>	3AXD50000042620	(Multi Lingual)
Optional manuals or guides		
<i>ACS-AP-x Assistant control panels user's manual</i>	3AUA0000085685	
<i>ACS-BP-S Basic control panel user's manual</i>	3AXD50000032527	
<i>CDPI-01/-02 communication adapter module user's manual</i>	3AXD50000009929	
<i>DPMP-01 mounting platform for ACS-AP control panel</i>	3AUA0000100140	
<i>DPMP-02/03 mounting platform for ACS-AP control panel</i>	3AUA0000136205	
<i>FCAN-01 CANopen adapter module user's manual</i>	3AFE68615500	
<i>FECA-01 EtherCAT adapter module user's manual</i>	3AUA0000068940	
<i>FENA-01/-11/-21 Ethernet adapter module user's manual</i>	3AUA0000093568	
<i>FPBA-01 PROFIBUS DP adapter module user's manual</i>	3AFE68573271	
<i>FSCA-01 RS-485 adapter module user's manual</i>	3AUA0000109533	
<i>FPNO-21 PROFINET IO fieldbus adapter module user's manual</i>	3AXD50000158614	
<i>FMBT-21 Modbus/TCP Adapter Module User's Manual</i>	3AXD50000158607	
<i>FEIP-21 EtherNet/IP fieldbus adapter module User's manual</i>	3AXD50000158621	
<i>CCA-01 communication adapter quick guide</i>	3AXD50000018457	
<i>AOCH, NOCH du/dt filters hardware manual</i>	3AFE58933368	
<i>Sine filter hardware manual</i>	3AXD50000016814	
<i>NBRA-6xx Braking Choppers Inst/Start-up Guide</i>	3AFY58920541	
<i>Flange mounting kit installation supplement</i>	3AXD50000019100	

Flange mounting kit quick installation guide for ACX580-01 frames R0 to R5 [3AXD50000036610](#)

Flange mounting kit quick installation guide for ACS880-01 and ACX580-01 frames R6 to R8 [3AXD50000019099](#)

Tool and maintenance manuals and guides

Drive composer PC tool user's manual [3AUA0000094606](#)

Converter module capacitor reforming instructions [38FE64059629](#)

NETA-21 remote monitoring tool user's manual [3AUA0000096939](#)

NETA-21 remote monitoring tool installation and start-up guide [3AUA0000096881](#)

Terms and abbreviations

Term/abbreviation	Explanation
ACS-BP-S	Basic control panel, basic operator keypad for communication with the drive.
ACS-AP-x	Assistant control panel, advanced operator keypad for communication with the drive. The ACS560 supports types ACS-AP-I, ACS-AP-S and ACS-AP-W.
AI	Analog input; interface for analog input signals
AO	Analog output; interface for analog output signals
BACnet™	BACnet™ is a registered trademark of American Society of Heating, Refrigerating and Air-Conditioning Engineers (ASHRAE).
Brake chopper	Conducts the surplus energy from the intermediate circuit of the drive to the brake resistor when necessary. The chopper operates when the DC link voltage exceeds a certain maximum limit. The voltage rise is typically caused by deceleration (braking) of a high inertia motor.
Brake resistor	Dissipates the drive surplus braking energy conducted by the brake chopper to heat. Essential part of the brake circuit. See chapter <i>Brake chopper</i> in the <i>Hardware manual</i> of the drive.
BIO-01	Optional I/O extension module underneath the fieldbus adapter module.
Control board	Circuit board in which the control program runs.
DC link	DC circuit between rectifier and inverter
DC link capacitors	Energy storage which stabilizes the intermediate circuit DC voltage
DI	Digital input; interface for digital input signals
DPMP-01	Mounting platform for ACS-AP control panel (flange mounting)
DPMP-02/03	Mounting platform for ACS-AP control panel (surface mounting)
Drive	Frequency converter for controlling AC motors
EFB	Embedded fieldbus
FBA	Fieldbus adapter
FCAN-01	Optional CANopen adapter module
FCNA-01	ControlNet adapter module
FECA-01	Optional EtherCAT adapter module
FENA-01/-11/-21	Optional Ethernet adapter module for EtherNet/IP, Modbus TCP and PROFINET IO protocols
FEPL-02	Ethernet POWERLINK adapter module
FLON-01	LONWORKS® adapter module
FPBA-01	Optional PROFIBUS DP adapter module
Frame (size)	Refers to drive physical size, for example R0 and R1. The type designation label attached to the drive shows the frame of the drive, see chapter <i>Operation principle and hardware description</i> , section <i>Type designation label</i> in the <i>Hardware manual</i> of the drive.
IGBT	Insulated gate bipolar transistor: used for high efficiency and fast switching

Term/abbreviation	Explanation
Intermediate circuit	See DC link .
Inverter	Converts direct current and voltage to alternating current and voltage.
I/O	Input/Output
LONWORKS®	LONWORKS® (local operating network) is a networking platform specifically created to address the needs of control applications.
LSW	Least significant word
Macro	Pre-defined default values of parameters in drive control program. Each macro is intended for a specific application. See chapter Control macros on page 99.
NETA-21	Remote monitoring tool
Network control	With fieldbus protocols based on the Common Industrial Protocol (CIP™), such as Ethernet/IP, denotes the control of the drive using the Net Ctrl and Net Ref objects of the ODVA AC/DC Drive Profile. For more information, see www.odva.org , and the following manual: <i>FENA-01/-11/-21 Ethernet adapter module user's manual</i> (3AUA0000093568 [English]).
Parameter	User-adjustable operation instruction to the drive, or signal measured or calculated by the drive
PID/Loop controller	Proportional–integral–derivative controller. Drive speed control is based on PID algorithm.
PLC	Programmable logic controller
PROFIBUS, PROFIBUS DP, PROFINET IO	Registered trademarks of PI - PROFIBUS & PROFINET International
R0, R1,...	Frame (size)
RO	Relay output; interface for a digital output signal. Implemented with a relay.
Rectifier	Converts alternating current and voltage to direct current and voltage.
STO	Safe torque off. See chapter <i>The Safe torque off function</i> in the <i>Hardware manual</i> of the drive.

Cyber security disclaimer

This product is designed to be connected to and to communicate information and data via a network interface. It is Customer's sole responsibility to provide and continuously ensure a secure connection between the product and Customer network or any other network (as the case may be). Customer shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc.) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB and its affiliates are not liable for

damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

2

Start-up, control with I/O and ID run

Contents of this chapter



The chapter describes how to:

- perform the start-up
- start, stop, change the direction of the motor rotation and adjust the speed of the motor through the I/O interface
- perform an Identification run (ID run) for the drive.








How to start up the drive

■ How to start up the drive using the basic control panel

Safety	
	<p>Do not start-up the drive unless you are a qualified electrician.</p> <p>Read and obey the instructions in chapter <i>Safety instructions</i> at the beginning of the <i>Hardware manual</i> of the drive. Ignoring the instructions can cause physical injury or death, or damage to the equipment</p>
<input type="checkbox"/>	<p>Check the installation. See chapter <i>Installation checklist</i> in the <i>Hardware manual</i> of the drive.</p>
<input type="checkbox"/>	<p> Make sure there that the active start command is not on (DI1 in factory settings, i.e. ABB standard macro). The drive will start up automatically at power-up if the external run command is on and the drive is in the remote control mode.</p> <p>Check that the starting of the motor does not cause any danger.</p> <p>De-couple the driven machine if</p> <ul style="list-style-type: none"> • there is a risk of damage in case of an incorrect direction of rotation, or • a Normal ID run is required during the drive start-up, when the load torque is higher than 20% or the machinery is not able to withstand the nominal torque transient during the ID run.
General Information	
<input type="checkbox"/>	<p>The settings and examples referred in this chapter are with respect to the basic control panel. For more information on basic control panel settings and menu details, see <i>Quick installation and start-up guide</i> (3AXD50000042620) or <i>ACS-BP-S basic control panel's user's manual</i> (3AXD50000032527 [English]).</p> <p>If you are performing the procedure with assistant control panel, see <i>ACS-AP-x assistant control panels user's manual</i> (3AUA0000085685 [English]).</p>




























Hints on using the basic control panel	
<p>Display</p> <p>The control panel display shows the following elements:</p> <ol style="list-style-type: none"> Control location and related icons: Indicates how the drive is controlled. <ul style="list-style-type: none"> Loc: The drive is in local control, that is, controlled from the control panel. Rem: The drive is in remote control, that is, controlled through I/O or fieldbus. Rotation direction: Shows the forward (clockwise) or reverse (counter-clockwise) rotation of motor. Main: Navigates to the Main menu. Option: Navigates to the Options menu. Reference value: Allows to define the reference value of speed, frequency or current and its unit using the Up/Down arrow buttons. Actual value: Shows the actual value of speed, frequency or current and its unit. 	
1 – First start assistant guided settings: Language, unit, and motor nominal values	
<input type="checkbox"/> Have the motor name plate data in hand. Power up the drive.	
<input type="checkbox"/> Navigate to Main menu ≡ → Complete parameter list  → parameter 96.01 and select the desired language. Press  (OK).	
<input type="checkbox"/> Navigate to Main menu ≡ → Complete parameter list  → parameter 96.16 and change the unit, if needed. Press  (OK).	



















Refer to the motor nameplate for the following nominal value settings of the motor. Enter the values exactly as shown on the motor nameplate.

Example of a nameplate of an induction (asynchronous) motor:













<input type="checkbox"/>	Navigate to Main menu  and select Motor data  .										
<input type="checkbox"/>	Set the motor nominal current: <ul style="list-style-type: none"> • Use  and  to move the cursor left and right. • Use  and  to change the value. Press  (OK) to accept the new setting, or press  (Back) to go back to the previous view without making changes.	<table border="1" style="width: 100%;"> <tr> <td style="width: 50%;">Scalar</td> <td style="width: 50%;">2.20kW</td> </tr> <tr> <td style="background-color: #cccccc;">3A</td> <td>400.0V</td> </tr> <tr> <td colspan="2" style="text-align: center;"> 96.06 3.0 A </td> </tr> </table>	Scalar	2.20kW	3A	400.0V	96.06 3.0 A				
Scalar	2.20kW										
3A	400.0V										
96.06 3.0 A											
<input type="checkbox"/>	Set the torque and motor Cos Φ , if needed. Motor nominal cos Φ and nominal torque are optional. <ul style="list-style-type: none"> • Use  and  to move the cursor left and right. • Use  and  to change the value. Press  (OK) to accept the new setting, or press  (Back) to go back to the previous view without making changes.	<table border="1" style="width: 100%;"> <tr> <td style="width: 50%; background-color: #cccccc;">0.000Nm</td> <td style="width: 50%;">U V W</td> </tr> <tr> <td>Cos Φ</td> <td>0.00</td> </tr> <tr> <td colspan="2" style="text-align: center;"> 0.000Nm U V W Cos Φ 0.00 </td> </tr> </table>	0.000Nm	U V W	Cos Φ	0.00	0.000Nm U V W Cos Φ 0.00				
0.000Nm	U V W										
Cos Φ	0.00										
0.000Nm U V W Cos Φ 0.00											
<input type="checkbox"/>	Set the desired motor control mode. If Vector motor control mode is selected, make sure that ID run is performed. See ID run procedure .	<table border="1" style="width: 100%;"> <tr> <td style="width: 50%; background-color: #cccccc;">Scalar</td> <td style="width: 50%;">2.20kW</td> </tr> <tr> <td style="background-color: #cccccc;">4.7A</td> <td>400.0V</td> </tr> </table>	Scalar	2.20kW	4.7A	400.0V					
Scalar	2.20kW										
4.7A	400.0V										
<input type="checkbox"/>	Navigate to Options menu  →  and set the direction.	<table border="1" style="width: 100%;"> <tr> <td style="width: 30%;">Loc </td> <td style="width: 40%; text-align: center;">13.04</td> <td style="width: 30%; text-align: right;">10.13.04Hz</td> </tr> <tr> <td></td> <td style="text-align: center;">Hz</td> <td></td> </tr> <tr> <td></td> <td></td> <td style="text-align: right;"></td> </tr> </table>	Loc 	13.04	10.13.04Hz		Hz				
Loc 	13.04	10.13.04Hz									
	Hz										
											






<input type="checkbox"/>	<p>Navigate to the Options menu  and set the frequency/speed reference. Use  and  to change the value.</p> <p>Press  (OK) to accept the new setting, or press  (Back) to go back to the previous view without making changes.</p>	
<input type="checkbox"/>	<p>Press Start .</p> <p>Make sure that the motor is running in the required direction. The direction symbol is displayed in the home page. The forward direction is indicated by  and the reverse direction is indicated by .</p>	
<input type="checkbox"/>	<p>Press Stop .</p>	
<input type="checkbox"/>	<p>If you want to make a backup of the settings made so far, navigate to Main menu  and select Backup . You can restore and back up the data between drive and panel.</p> <p>Select the option and press  (OK) to accept or press  (Back) to go back to the previous view without making changes.</p>	
<input type="checkbox"/>	<p>The first start setup is complete and the drive is ready for use. The home view displays the values of selected signals.</p>	











2 – Additional settings
Macro/start-stop reference, ramp, and limit settings

<input type="checkbox"/>	<p>You can make any additional changes to the macro, ramp, and limits, if required.</p>	
<input type="checkbox"/>	<p>Macro settings</p> <p>Navigate to the Main menu  and select I/O connection .</p> <p>Select the desired macro. Use  and  to move the cursor left and right.</p> <p>Press  (OK) to accept or press  (Back) to go back to the previous view without making changes.</p> <p>Notes:</p> <ul style="list-style-type: none"> Changing the macro resets all settings to the default values of the selected macro and updates the I/O signals used in the drive. You can see the currently used I/O signals in the  menu. All macros, except the ABB standard (vector) and Pharma macro, use scalar motor control by default. You can change the motor control mode in the Motor data . 	 

Start, stop, and reference values
 If you do not wish to use a macro, navigate to **Main menu**  → **Complete parameter list**  → **Parameter groups 20, 21, and 23** and manually define the settings for start, stop and reference.
Notes:




- Changing the start, stop, and reference settings, changes the I/O signals used in the drive. You can see the currently used I/O signals in the  menu.
- Make sure that the used I/O connection matches with the actual I/O wiring. See [Control macros](#) on page 99.



Ramp settings
 Navigate to **Main menu**  → **Complete parameter list**  → **Parameter group 23** and change the parameters according to your need. For example, acceleration time, deceleration time, emergency stop time etc.
 After making the changes, press  **OK** to accept or press  (**Back**) to the previous view without making changes.


Limit settings
 Navigate to **Main menu**  → **Complete parameter list**  → **Parameter group 30** and change the parameters according to your need. For example, minimum speed, maximum speed, maximum current, etc.
 After making the changes, press  **OK** to accept or press  (**Back**) to the previous view without making changes.









3 – I/O menu


After the additional changes, make sure that the used I/O connection matches with the actual I/O wiring. See [Control macros](#) on page 99.
 To see the currently used I/O signals, navigate to **Main menu**  → **I/O menu**  → **I/O status** .

Use  and  to check the values.



4 – Diagnostics menu

After the additional adjustments and I/O connection validation, navigate to **Main menu**  → **Diagnostics**  and make sure that the setup is functioning correctly.
 Diagnostics menu displays the active faults , fault history , active warnings , and I/O status .









5 – Backup



After the start-up, it is recommended that you make a backup of the configured parameters.
You can restore and back up the data between drive and panel.

To backup the settings, navigate to **Main menu**

☰ →  ← .








Select  ←  or  →  as desired. Press  **Ok** to accept or press  **Back** to go back to the previous view without making changes.



How to control the drive through the I/O interface

The table below describes how to operate the drive through the digital and analog inputs when:

- the motor start-up is performed, and
- the default parameter settings of the ABB standard macro are in use.

Preliminary settings	
<p>If you need to change the direction of rotation, navigate to Menu  → Motor control  and make sure that the minimum speed/frequency limit has a negative value and the maximum speed/frequency limit has a positive value.</p>	
<p>Make sure that the ABB standard macro control connections are correct. See ABB standard macro on page 100.</p> <p>Make sure that the drive is in remote control. Press key  to switch between remote and local control.</p> <p>In remote control, the panel display shows text Rem at the top left.</p>	
Starting and controlling the speed of the motor	
<p>Switch on the digital input DI1 on.</p> <p>Observe the rotating arrow next to Rem. The dotted arrow appears until the setpoint is reached.</p> <p>Regulate the drive output frequency (motor speed) by changing the voltage of analog input AI1.</p>	
Changing the direction of the motor rotation	
<p>To change the direction, perform as follows</p> <ul style="list-style-type: none"> • For reverse direction, switch on the digital input DI2. • For forward direction, switch off the digital input DI2. 	
Stopping the motor	
<p>To stop the motor, switch digital input DI1 to off.</p> <p>Observe that the arrow stops rotating.</p>	



Identification (ID) run

During Identification (ID) run the drive identifies the characteristics of the motor for optimum motor control.

When the drive is started for the first time in vector control mode and after any parameter is changed in the parameter group *99 Motor data*, the drive automatically performs the *Standstill* ID run.












In most applications there is no need to perform a separate ID run. ID run needs to be performed manually if:


- vector control mode is used (parameter *99.04 Motor control mode* is set to *Vector [0]*), and
- drive operates near zero speed references, or
- operation at torque range above the motor nominal torque, over a wide speed range is needed.

To perform the ID run manually, see *ID run procedure*.



ID run procedure

Pre-check	
<div style="display: flex; align-items: center;">  <p>WARNING! The motor will run at up to approximately 50...80% of the nominal speed during the ID run. The motor will rotate in the forward direction. Make sure that it is safe to run the motor before performing the ID run!</p> </div>	
<div style="display: flex; align-items: center; margin-bottom: 10px;">  <div> <ul style="list-style-type: none"> <input type="checkbox"/> De-couple the motor from the driven equipment <input type="checkbox"/> Check that the values of the motor data parameters are equivalent to those on the motor nameplate. <input type="checkbox"/> Check that the STO circuit is closed. <p>If parameter values (from group <i>10 Standard DI, RO</i> to group <i>99 Motor data</i>) are changed before the ID run, check that the new settings meet the following conditions:</p> <ul style="list-style-type: none"> <input type="checkbox"/> <i>30.11 Minimum speed</i> ≤ 0 rpm <input type="checkbox"/> <i>30.12 Maximum speed</i> = motor rated speed (Normal ID run procedure needs the motor to be run at 100% speed.) <input type="checkbox"/> <i>30.17 Maximum current</i> $> I_{HD}$ <input type="checkbox"/> <i>30.20 Maximum torque 1</i> $> 50\%$ <p>Check that signals</p> <ul style="list-style-type: none"> <input type="checkbox"/> run enable (parameter <i>20.12 Run enable 1 source</i>) is active <input type="checkbox"/> start enable (parameter <i>20.19 Enable start command</i>) is active <input type="checkbox"/> enable to rotate (parameter <i>20.22 Enable to rotate</i>) is active. <input type="checkbox"/> Make sure that the panel is in local control (text Local shown at the top left). Press key Loc/Rem to switch between local and remote control. </div> </div>	
ID run	
<ul style="list-style-type: none"> <input type="checkbox"/> Navigate to Main menu  → Complete parameter list  → parameter 99.13 and select the type of ID run you want to do. Press  (OK) 	
<p>Panel LED starts blinking green to indicate an active warning (<i>AFF6</i>).</p> <p>You can hide the warning view by pressing  (Back).</p> <p>Press the start key () to start the ID run.</p> <p>Note: In general, it is recommended not to press any control panel keys during the ID run. However, you can stop the ID run at any time by pressing the stop key (.</p>	 

<p>□ During the ID run the arrow rotates at the top. After the ID run is completed, the arrow stops rotating and the rpm turns to 0.00. If the ID run fails, fault <i>FF61 ID run</i> is shown. For more information, see chapter <i>Fault tracing</i> on page 387.</p> <p>Note: You must repeat the ID run procedure if you have changed the motor parameters (99 <i>Motor data</i>) after the ID run was completed.</p>	
--	---







Using the control panel

The ACS560 drive supports both basic and assistant control panels. For more information, refer:

- *ACX-AP-x assistant control panel's user's manual* (3AUA0000085685 [English])

and

- *ACS-BP-S basic control panel's user's manual* (3AXD50000032527 [English])
-




Program features

What this chapter contains

This chapter describes some of the more important functions within the control program, how to use them and how to program them to operate. It also explains the control locations and operating modes.

Local control vs. external control

The AC560 drive has two main control locations, external and local. The control location is selected with the **Loc/Rem** key on the control panel or in the PC tool. The local control allows you to control the drive through control panel or drive composer and the remote control allows you to control the drive through PLC/fieldbus adapter/I/O connections/embedded fieldbus controller.



Local control

The control commands are given from the control panel keypad or from a PC equipped with Drive composer when the drive is in local control. Speed control mode is available in vector motor control mode and frequency mode is available when scalar motor control mode is used (see parameter [19.16 Local control mode](#)).

Local control is mainly used during commissioning and maintenance. The control panel always overrides the external control signal sources when used in local control. Changing the control location to local can be prevented by parameter [19.17 Local control disable](#).

The user can select by a parameter ([49.05 Communication loss action](#)) how the drive reacts to a control panel or PC tool communication break. (The parameter has no effect in external control.)

External control

When the drive is in external (remote) control, control commands are given through


- the I/O terminals (digital and analog inputs), or optional I/O extension modules
- the fieldbus interface (via the embedded fieldbus interface or an optional fieldbus adapter module).

Two external control locations, EXT1 and EXT2, are available. The user can select the sources of the start and stop commands separately for each location by setting parameters 20.01...20.10. Selection between EXT1 and EXT2 is done via any binary source such as a digital input or fieldbus control word (parameter 19.11 *Ext1/Ext2 selection*). The source of reference is selectable for each operating mode separately.


Communication fail functionality

The communication fail functionality ensures continuous process without interruptions. If there is a communication loss, the drive automatically changes the control location from EXT1 to EXT2. This enables process to be controlled, for example, with the drive PID controller. When the original control location recovers, the drive automatically switches control back to the communication network (EXT1).

EXT1/EXT2 selection for speed control




EXT1/EXT2 selection for frequency control



Block diagram: Run enable source for EXT1

The figure below shows the parameters that select the interface for run enable for external control location *EXT1*.




Settings


Parameters [19.11 Ext1/Ext2 selection](#) (page 197); [20.01...20.10](#) (page 198).

Operating modes of the drive

The drive can operate in several operating modes with different types of reference. The mode is selectable for each control location (Local, EXT1 and EXT2) in parameter group [19 Operation mode](#). An overview of the different reference types and control chains is shown below.



The following is a more detailed representation of the reference types and control chains. The page numbers refer to detailed diagrams in chapter [Control chain diagrams](#).



■ Speed control mode

The motor follows a speed reference given to the drive. This mode can be used either with estimated speed used as feedback.

Speed control mode is available in both local and external control. It is supported in vector motor control only.

Speed control uses speed reference chain. You can select speed reference using parameters in group [22 Speed reference selection](#) on page [215](#).

■ Torque control mode

Motor torque follows a torque reference given to the drive. Torque control mode is available in both local and external control. It is supported in vector motor control only.

Torque control uses torque reference chain. Select torque reference with parameters in group [26 Torque reference chain](#) on page [233](#).

■ Frequency control mode

The motor follows a frequency reference given to the drive. Frequency control is available in both local and external control. It is supported in scalar motor control only.

Frequency control uses frequency reference chain. You can select frequency reference using parameters in group [28 Frequency reference chain](#) on page [238](#).

■ Special control modes


In addition to the above-mentioned control modes, the following special control modes are available:

- Process PID control. For more information, see section [Process PID control](#) (page [50](#)).
- Emergency stop modes OFF1 and OFF3: Drive stops along the defined deceleration ramp and drive modulation stops.
- Jogging mode: Drive starts and accelerates to the defined speed when the jogging signal is activated. For more information, see section [Jogging](#) (page [73](#)).
- Pre-magnetization: DC magnetization of the motor before start. For more information, see section [Pre-magnetization](#) (page [70](#)).
- DC hold: Locking the rotor at (near) zero speed in the middle of normal operation. For more information, see section [DC hold](#) (page [70](#)).
- Pre-heating (motor heating): Keeping the motor warm when the drive is stopped. For more information, see section [Pre-heating \(Motor heating\)](#) (page [71](#)).

Drive configuration and programming

The drive control program performs the main control functions, including speed, torque and frequency control, drive logic (start/stop), I/O, feedback, communication

and protection functions. Control program functions are configured and programmed with parameters.



■ Configuring via parameters

Parameters configure all of the standard drive operations and can be set via

- the control panel, as described in chapter [Using the control panel](#)
- the Drive composer PC tool, see chapter [Parameterization with drive composer](#)
- the automation builder drive manager, see [Parameterization with automation builder drive manager](#) or
- the fieldbus interface, as described in chapters [Fieldbus control through the embedded fieldbus interface \(EFB\)](#) and [Fieldbus control through a fieldbus adapter](#).

All parameter settings are stored automatically to the permanent memory of the drive. However, if an external +24 V DC power supply is used for the drive control unit, it is highly recommended to force a save by using parameter [96.07 Parameter save manually](#) before powering down the control unit after any parameter changes have been made.

If necessary, the default parameter values can be restored by parameter [96.06 Parameter restore](#).

Control interfaces

■ Programmable analog inputs

The control unit has two programmable analog inputs. Each of the inputs can be independently set as a voltage (0/2...10 V) or current (0/4...20 mA) input by a switch on the control unit, or with parameters. Each input can be filtered, inverted and scaled.

Settings

Parameter group [12 Standard AI](#) (page [186](#)).

■ Programmable analog outputs

The control unit has two current (0...20 mA) analog outputs. Analog output 1 can be set as a voltage (0/2...10 V) or current (0/4...20 mA) output by a switch on the control unit, or with a parameter. Analog output 2 always uses current. Each output can be filtered, inverted and scaled.

Settings

Parameter group [13 Standard AO](#) (page [191](#)).

■ Programmable digital inputs and outputs

The control unit has six digital inputs.

Digital input DI5 can be used as a frequency input or digital input.

Settings

Parameter groups [10 Standard DI, RO](#) (page [177](#)) and [11 Standard DIO, FI, FO](#) (page [185](#)).

■ Programmable relay outputs

The control unit has three relay outputs. The signal to be indicated by the outputs can be selected by parameters.

Settings

Parameter group [10 Standard DI, RO](#) (page [177](#)).

■ Fieldbus control

The drive can be connected to several different automation systems through its fieldbus interfaces. See chapters [Fieldbus control through the embedded fieldbus interface \(EFB\)](#) (page [435](#)) and [Fieldbus control through a fieldbus adapter](#) (page [445](#)).

■ Programmable I/O extensions

Inputs and outputs can be added by using I/O extension modules.

The table below shows the number of I/O on the control unit as well as optional I/O extension modules.



Location	Digital inputs (DI)	Digital outputs (DO)	Digital I/Os (DIO)	Analog inputs (AI)	Analog outputs (AO)	Relay outputs (RO)
Base unit	2	-	-	-	-	1
BIO-01	3	1	-	1	-	-

Settings

Parameter groups [50 Fieldbus adapter \(FBA\)](#) (page 324), [51 FBA A settings](#) (page 328), [52 FBA A data in](#) (page 329), and [53 FBA A data out](#) (page 330) and [58 Embedded fieldbus](#) (page 330).

Application control

■ Reference ramping

Acceleration and deceleration ramping times can be set individually for speed, torque and frequency reference (**Main menu**  → **Motor control** ).

With a speed or frequency reference, the ramps are defined as the time it takes for the drive to accelerate or decelerate between zero speed or frequency and the value defined by parameter [46.01 Speed scaling](#) or [46.02 Frequency scaling](#). The user can switch between two preset ramp sets using a binary source such as a digital input. For speed reference, the shape of the ramp also can be controlled.

With a torque reference, the ramps are defined as the time it takes for the reference to change between zero and nominal motor torque (parameter [01.30 Nominal torque scale](#)).

Variable slope

Variable slope controls the slope of the speed ramp during a reference change. With this feature a constantly variable ramp can be used.

Variable slope is only supported in remote external control.

Settings

Parameters [23.28 Variable slope](#) (page [226](#)) and [23.29 Variable slope rate](#) (page [226](#)).


Special acceleration/deceleration ramps

The acceleration/deceleration times for the jogging function can be defined separately; see section [Jogging](#) (page [73](#)).

The change rate of the motor potentiometer function (page [76](#)) is adjustable. The same rate applies in both directions.

A deceleration ramp can be defined for emergency stop (“Off3” mode).

Settings

- Menu ☰ → Motor control .
- Speed reference ramping: Parameters [23.11...23.15](#) and [46.01](#) (pages [224](#) and [317](#)).
- Torque reference ramping: Parameters [01.30](#), [26.18](#) and [26.19](#) (pages [164](#) and [236](#)).
- Frequency reference ramping: Parameters [28.71...28.75](#) and [46.02](#) (pages [246](#) and [318](#)).
- Jogging: Parameters [23.20](#) and [23.21](#) (page [225](#)).
- Motor potentiometer: Parameter [22.78/22.79](#) (page [223](#)).
- Emergency stop (“Off3” mode): Parameter [23.23 Emergency stop time](#) (page [226](#)).

■ Constant speeds/frequencies

Constant speeds and frequencies are predefined references that can be quickly activated, for example, through digital inputs. It is possible to define up to 7 speeds for speed control and 7 constant frequencies for frequency control.



WARNING: Speeds and frequencies override the normal reference irrespective of where the reference is coming from.

Settings

Parameter groups [22 Speed reference selection](#) (page [215](#)) and [28 Frequency reference chain](#) (page [238](#)).

■ Critical speeds/frequencies

Critical speeds (sometimes called “skip speeds”) can be predefined for applications where it is necessary to avoid certain motor speeds or speed ranges because of, for example, mechanical resonance problems.

The critical speeds function prevents the reference from dwelling within a critical band for extended times. When a changing reference ([22.87 Speed reference act 7](#)) enters a critical range, the output of the function ([22.01 Speed ref unlimited](#)) freezes until the reference exits the range. Any instant change in the output is smoothed out by the ramping function further in the reference chain.


When the drive is limiting the allowed output speeds/frequencies, it limits to the absolutely lowest critical speed (critical speed low or critical frequency low) when accelerating from standstill, unless the speed reference is over the upper critical speed/ frequency limit.

The function is also available for scalar motor control with a frequency reference. The input of the function is shown by [28.96 Frequency ref act 7](#).

Example

A fan has vibrations in the range of 540...690 rpm and 1380...1560 rpm. To make the drive avoid these speed ranges,

- set the critical speeds function by turning on bit 0 of parameter [22.51 Critical speed function](#), and
- set the critical speed ranges as in the figure below.



Settings

- Critical speeds: parameters [22.51](#)...[22.57](#) (page [221](#))
- Critical frequencies: parameters [28.51](#)...[28.57](#) (page [245](#)).


■ Speed controller autotune

The speed controller of the drive can be automatically adjusted using the autotune function. Autotuning is based on an estimation of the mechanical time constant (inertia) of the motor and machine.

The autotune routine will run the motor through a series of acceleration/deceleration cycles, the number of which can be adjusted by parameter [25.40](#). Higher values will produce more accurate results, especially if the difference between initial and maximum speeds is small.

The maximum torque reference used during autotuning will be the initial torque (ie. torque when the routine is activated) plus [25.38](#), unless limited by the maximum torque limit (parameter group [30 Limits](#)) or the nominal motor torque ([99 Motor data](#)). The calculated maximum speed during the routine is the initial speed (ie. speed when the routine is activated) + [25.39](#), unless limited by parameter [30.12](#) or [99.09](#).

The diagram below shows the behavior of speed and torque during the autotune routine. In this example, [25.40](#) is set to 2.



Notes:

- If the drive cannot produce the requested braking power during the routine, the results will be based on the acceleration stages only, and not as accurate as with full braking power.
- The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.

Before activating the autotune routine

The prerequisites for performing the autotune routine are:


- The motor identification run (ID run) has been successfully completed
- Speed and torque limits (parameter group [30 Limits](#)) have been set
- The drive has been started and is running in speed control mode.

After these conditions have been fulfilled, autotuning can be activated by parameter [25.33](#) (or the signal source selected by it).

Autotune modes

Autotuning can be performed in three different ways depending on the setting of parameter [25.34](#). The selections *Smooth*, *Normal* and *Tight* define how the drive torque reference should react to a speed reference step after tuning. The selection *Smooth* will produce a slow but robust response; *Tight* will produce a fast response

but possibly too high gain values for some applications. The figure below shows speed responses at a speed reference step (typically 1...20%).



- A: Undercompensated
- B: Normally tuned (autotuning)
- C: Normally tuned (manually). Better dynamic performance than with B
- D: Overcompensated speed controller


Autotune results

At the end of a successful autotune routine, its results are automatically transferred into parameters

- [25.02](#) (proportional gain of the speed controller)
- [25.03](#) (integration time of the speed controller)
- [25.37](#) (mechanical time constant of the motor and machine).

Nevertheless, it is still possible to manually adjust the controller gain, integration time and derivation time.

The figure below is a simplified block diagram of the speed controller. The controller output is the reference for the torque controller.



Warning indications

A warning message [AF90](#), will be generated if the autotune routine does not complete successfully. See chapter [Fault tracing](#) (page 387) for further information.

Settings and diagnostics

Parameters groups: [25 Speed control](#) (page 228), [30 Limits](#) (page 249) and [99 Motor data](#) (page 363).

Parameters: [25.02 Speed proportional gain](#) (page 228), [25.03 Speed integration time](#) (page 229), [25.33 Speed controller autotune...](#)[25.40 Autotune repeat times](#) (page 233), [30.12 Maximum speed](#) (page 251) and [99.09 Motor nominal speed](#) (page 365).

Events: [AF90 Speed controller autotuning](#) (page 400).

User Load Curve

The User Load Curve (ULC) provides a supervisory function that monitors an input signal as a function of speed and load. The ULC consists of an overload and an underload curve, or just one of them.


Note: This feature is available only in vector control mode.

Some of the salient features of the ULC are:

- Formed by five points - The underload and overload curve are formed by five points where the points represent monitored signal as a function of speed.
- Warning and/or fault for overload and underload - A warning and/or fault can be displayed, if the monitored signal stays continuously over the overload/underload limit for a defined time. You can define the time in parameter [37.41 ULC overload timer](#)/[37.42 ULC underload timer](#) and the action in parameter [37.03 ULC overload actions](#)/[37.04 ULC underload actions](#).
- Sector based warning / fault - The five points makes four sectors and a warning and/or fault can be displayed at each sector. This helps to find the speed range that causes the fault or warning and the investigation can be performed accordingly.

For example, overload can be used to monitor for saw blade hitting a knot or fan load profiles becoming too high. Underload can be used to monitor for load dropping and breaking of conveyer belts or fan belts.

The below graph shows the underload and overload points in a user load curve.



Example

If,

N1 = 300 rpm, defined by parameter [37.11 ULC speed table point 1](#)

N2 = 600rpm, defined by parameter [37.12 ULC speed table point 2](#)

OL1 = 10%, defined by parameter [37.31 ULC overload point 1](#)

OL2 = 20%, defined by parameter [37.32 ULC overload point 2](#)

Parameter [37.03](#) = *Warning*

Overload axis = torque%, defined by parameter [37.02 ULC supervision signal](#)

Drive speed = 450 rpm,

the drive generates *A8BE* (Aux code 0001) warning, if the actual torque exceeds 15% (calculated by leaner interpolation between point (N1, OL1) and (N2, OL2) for the predefined time), after the time period mentioned in parameter [37.41 ULC overload timer](#).

If the parameter [37.03](#) is set as *Disabled*, the drive does not generate any warning.

Settings

Parameter group [37 User load curve](#) (page [290](#)).


■ Process PID control

There are two built-in process PID controllers (PID set 1 and PID set 2) in the drive. The controller can be used to control process variables such as pressure or flow in the pipe or fluid level in the container.

In process PID control, a process reference (setpoint) is connected to the drive instead of a speed reference. An actual value (process feedback) is also brought back to the drive. The process PID control adjusts the drive speed in order to keep the measured process quantity (actual value) at the desired level (setpoint). This means that user does not need to set a frequency/speed/torque reference to the drive but the drive adjust its operation according to the process PID.

The simplified block diagram below illustrates the process PID control. For more detailed block diagrams, see pages [497](#) and [474](#).

The drive contains two complete set of process PID controller settings that can be used in place of the other as and when required. See parameter [40.57 PID set1/set2 selection](#).



Note: Process PID control is available only in external control location EXT2. See section [Local control vs. external control](#) (page 33).

Quick configuration of the process PID controller

1. Activate the process PID controller: **Menu - Primary settings - PID - PID controls**
2. Select a feedback source: **Menu - Primary settings - PID - Feedback**
3. Select a setpoint source: **Menu - Primary settings - PID - Setpoint**
4. Set the gain, integration time, derivation time: **Menu - Primary settings - PID - Tuning**
5. Set the PID output limits: **Menu - Primary settings - PID - PID output**
6. Select the PID controller output as the source of, for example, [22.11 Ext1 speed ref1](#): **Menu - Primary settings - Start, stop, reference - Reference from**


Sleep and boost functions for process PID control

The sleep function is suitable for PID control applications where the consumption varies, such as clean water pumping systems. When used, it stops the pump completely during low demand, instead of running the pump slowly below its efficient operating range. The following example visualizes the operation of the function.

Example: The drive controls a pressure boost pump. The water consumption falls at night. As a consequence, the process PID controller decreases the motor speed. However, due to natural losses in the pipes and the low efficiency of the centrifugal pump at low speeds, the motor would never stop rotating. The sleep function detects the slow rotation and stops the unnecessary pumping after the sleep delay has passed. The drive shifts into sleep mode, still monitoring the pressure. The pumping resumes when the pressure falls under the predefined minimum level and the wakeup delay has passed.

The user can extend the PID sleep time by the boost functionality. The boost functionality increases the process setpoint for a predetermined time before the drive enters the sleep mode.




Sleep and boost function - Timing diagram



Tracking


In tracking mode, the PID block output is set directly to the value of parameter 40.50 (or 41.50) *Set 1 tracking ref selection*. The internal I term of the PID controller is set so that no transient is allowed to pass on to the output, so when the tracking mode is left, normal process control operation can be resumed without a significant bump.

Settings

- Main menu  → Connection macro I/O_{pin} → PID or Main menu  → Complete parameter list  → parameter [96.04](#) → PID.
- Parameter groups [40 Process PID set 1](#) (page [293](#)) and [41 Process PID set 2](#) (page [307](#)).

PID trim function


The PID trim function is used to maintain the set tension either by trimming the drive main speed reference or torque reference (speed controller output).

 **WARNING!** Make sure that the drive acceleration and deceleration time is set to 0 when using PID trim function. This is required to perform quick tension control by speed correction.

PID trim is implemented as one of the Process PID functions (parameter group [40 Process PID set 1](#) and [41 Process PID set 2](#)). Both PID set1 and PID set 2 can be used for this functionality.


The trimmed output is calculated from parameter [40.01 Process PID output actual](#) or [40.03 Process PID setpoint actual](#). This is based on the selection in parameter [40.56 Set 1 trim source](#) (for process PID set 1) or [41.56 Set 2 trim source](#) (for process PID set 2). In most of the use cases, [40.56 Set 1 trim source](#) or [41.56 Set 2 trim source](#) is set as *PID output*.

PID trim functionality in Variable Frequency Drive (VFD) is used in applications where tension control of the material is very essential. For example, auxiliary drives in metal process industries, infeed and outfeed of rotogravure printing machines, surface winder etc.



You must link the trimmed output from PID to the speed chain manually if PID trimmed output is used for trimming speed. Set below parameters as follows:

Parameter	Value
22.11 Ext1 speed ref1	Process speed reference given by 22.11 Ext1 speed ref1 source
22.12 Ext1 speed ref2	Other, 40.05 Process PID trim output act
22.13 Ext1 speed function	Add (ref1 + ref2)

**Notes:**

- The above settings are for Ext1 control location. Accordingly, you can set for Ext2 control location.
- The examples provided in this chapter are based on PID set 1. You can set the desired values for PID trim function's parameters to get the expected result.

The following modes are available:

- *Direct*
- *Proportional*, and
- *Combined*

Direct

The direct method is suitable where you need tension control at fixed rpm/line speed.


In this mode, the PID trimmed output (*40.05 Process PID trim output act*) is relative to the maximum speed (parameter *30.12 Maximum speed*), torque (*30.20 Maximum torque 1*) or frequency (*30.14 Maximum frequency*). The selection between these can be made by parameter *40.52 Set 1 trim selection*.

The calculated trimmed output is same throughout the speed range with respect to the stable PID output.

The *40.05 Process PID trim output act* is calculated using below formula:

$$\text{Par40.05} = \left(\frac{\text{Par40.01}}{100} \right) \times (\text{Par30.12 or 30.20 or 30.14}) \times \text{Par40.55}$$

The below graph shows the PID trim output in direct mode throughout the speed range. A fixed trim speed reference is added throughout the speed range.



Note: In the above graph, it is assumed that the PID output is limited/stable at 100. This is for understanding purpose only. In real case scenario, PID output can vary based on the setpoint and actual.

Example

If,

Par. *40.52 Set 1 trim selection* = *Speed*

Par. *40.56 Set 1 trim source* = *PID output*

Par. *30.12 Maximum speed* = 1500 rpm

Par. *40.01 Process PID output actual* = 100 (limited to 100)

Par. *40.55 Set 1 trim adjust* = 0.5

Then,

$$\text{Par40.05} = \left(\frac{100}{100} \right) \times 1500 \times 0.5$$

$$\text{Par40.05} = 750$$

Proportional

The proportional method is suitable for applications where tension control is required throughout the speed range but not near to zero speed.

In this mode, the PID trimmed output (*40.05 Process PID trim output act*) is relative to the reference selected by parameter *40.53 Set 1 trimmed ref pointer* and with *40.01 Process PID output actual* or *40.03 Process PID setpoint actual*.

It is recommended that the speed reference selected in *40.53 Set 1 trimmed ref pointer* and the reference source selected in *22.11 Ext1 speed ref1* and *40.53 Set 1 trimmed ref pointer* are same. This is required to make the proportional mode active.


In most of the use cases, the process speed reference is connected in *40.53 Set 1 trimmed ref pointer*. For example, if EXT1 control mode is used and the reference

source is AI scaled, then [22.11 Ext1 speed ref1](#) and [40.53 Set 1 trimmed ref pointer](#) should be configured to AI1 scaled.

The [40.05 Process PID trim output act](#) is calculated using below formula:

$$\text{Par40.05} = \left(\frac{\text{Par40.01}}{100} \right) \times \text{Par40.53} \times \text{Par40.55}$$

The below graph shows the PID trim output in proportional mode throughout the speed range. Here, the trimmed output is directly proportional to the value of parameter [40.53 Set 1 trimmed ref pointer](#).



Note: In the above graph, it is assumed that the PID output is limited/stable at 100. This is for understanding purpose only. In real case scenario, PID output can vary based on the setpoint and actual.

Example

If,

Par. [40.52 Set 1 trim selection](#) = Speed

Par. [40.56 Set 1 trim source](#) = PID output

Par. [40.53 Set 1 trimmed ref pointer](#) = AI1 scaled

Par. [22.11 Ext1 speed ref1](#) = AI1 scaled

Par. [12.20 AI1 scaled at AI1 max](#) = 1500

Par. [12.12 AI1 scaled value](#) = 750 (AI1 actual scaled value)

Par. [40.01 Process PID output actual](#) = 100

Par. [40.55 Set 1 trim adjust](#) = 0.5

Then,

$$\text{Par40.05} = \left(\frac{100}{100} \right) \times 750 \times 0.5$$

$$\text{Par40.05} = 375$$

Combined

The combined is suitable for applications where you need to maintain tension from zero speed to maximum speed


Combined method is a combination of direct and proportional mode. Here, the trim for zero speed is defined by [40.54 Set 1 trim mix](#) and the trim for speed greater than zero speed is defined by [40.55 Set 1 trim adjust](#). The trim value is directly proportional to value of [40.53 Set 1 trimmed ref pointer](#).

The process speed reference is connected in [40.53 Set 1 trimmed ref pointer](#). For example, if EXT1 control mode is used and the reference source is AI scaled, then [22.11 Ext1 speed ref1](#) and [40.53 Set 1 trimmed ref pointer](#) should be configured to AI1 scaled.

The [40.05 Process PID trim output act](#) is calculated using below formula:

$$\text{Par40.05} = \{(\text{Par30.12} \times \text{Par40.54}) + [(1 - \text{Par40.54}) \times \text{Par40.53}]\} \times \text{Par40.55}$$

The below graph shows the trim increase in combined mode.



Note: In the above graph, it is assumed that the PID output is limited/stable at 100. This is for understanding purpose only. In real case scenario, PID output can vary based on the setpoint and actual.

Example

If,

Par. [40.52 Set 1 trim selection](#) = Speed

Par. [40.56 Set 1 trim source](#) = PID output

Par. [30.12 Maximum speed](#) = 1500 rpm

Par. [40.53 Set 1 trimmed ref pointer](#) = AI1 scaled

Par. [22.11 Ext1 speed ref1](#) = AI1 scaled

Par. [12.20 AI1 scaled at AI1 max](#) = 1500

Par. [12.12 AI1 scaled value](#) = 750 (AI1 actual scaled value)

Par. [40.01 Process PID output actual](#) = 100 (limited to 100)

Par. [40.54 Set 1 trim mix](#) = 0.1

Par. [40.55 Set 1 trim adjust](#) = 0.5

Then,

If [40.53 Set 1 trimmed ref pointer](#) is 0.

$$\text{Par40.05} = \{(1500 \times 0.1) + [(1 - 0.1) \times 0]\} \times 1$$

$$\text{Par40.05} = 150$$

If [40.53 Set 1 trimmed ref pointer](#) is 750.

$$\text{Par40.05} = \{(1500 \times 0.1) + [(1 - 0.1) \times 750]\} \times 1$$

$$\text{Par40.05} = 825$$

If [40.53 Set 1 trimmed ref pointer](#) is 1500.

$$\text{Par40.05} = \{(1500 \times 0.1) + [(1 - 0.1) \times 1500]\} \times 1$$

$$\text{Par40.05} = 1500$$

PID trim auto connection

PID trim auto connection ([40.65 Trim auto connection](#)) enables the connection of PID trim output actual ([40.05 Process PID trim output act](#)) to the respective speed, torque or frequency reference chains. You can use parameter [40.52 Set 1 trim selection](#) (for PID set 1) or [41.52 Set 2 trim selection](#) (for PID set 2) and select the respective trim (speed, torque or frequency).

The motor control mode ([99.04 Motor control mode](#)) also impacts the PID trim output actual ([40.05 Process PID trim output act](#)) added to the speed, torque or frequency reference chains. In scalar control mode, the speed trim and torque trim values are zero and in vector control mode, the frequency trim value is zero.

See the control chain diagram on page [479](#).

Note: If the parameter [40.65 Trim auto connection](#) is disabled and the drive stops through Ramp stop (Off1) or Emergency ramp stop (Off3) emergency stop mode ([21.04 Emergency stop mode](#)), the PID trim output actual ([40.05 Process PID trim output act](#)) is not added to the frequency reference chain during the drive deceleration condition

Speed trim connection

Speed trim is added to [23.02 Speed ref ramp output](#). The parameter [24.01 Used speed reference](#) displays the final speed reference after the addition of speed trim.

Torque trim connection

Torque trim is added to the parameter [26.75 Torque reference act 5](#). The parameter [26.76 Torque reference act 6](#) displays the final torque reference after the addition of torque trim.

Frequency trim connection

Frequency trim is added to the parameter [28.02 Frequency ref ramp output](#) and generates the final frequency after the trim addition. At present, no parameter displays the final frequency reference after the addition of frequency trim.

Settings

- Parameter group [40 Process PID set 1](#) and parameters [40.51...40.56](#) (page [303](#)).
- Parameter group [41 Process PID set 2](#) and parameters [41.51...41.56](#) (page [309](#)).

■ Timed functions

Timed function enables to configure the drive to perform automated functions at a desired time on any day of a week. The function includes 12 timers, exception day settings, and boost time settings that help to configure the desired operation needed in the system.

Settings

Parameter group [34 Timed functions](#) (page [271](#)).

■ Mechanical brake control

A mechanical brake is used for holding the motor and driven machinery at zero speed when the drive is stopped, or not powered. The brake control logic observes the settings of parameter group [44 Mechanical brake control](#) as well as several external signals, and moves between the states presented in the diagram on page [61](#). The tables below the state diagram detail the states and transitions. The timing diagram on page [63](#) shows an example of a close-open-close sequence.

Inputs of the brake control logic

The start command of the drive (bit 5 of [06.16 Drive status word 1](#)) is the main control source of the brake control logic.

Outputs of the brake control logic


The mechanical brake is to be controlled by bit 0 of parameter [44.01 Brake control status](#). This bit should be selected as the source of a relay output (or a digital input/output in output mode) which is then wired to the brake actuator through a relay. See the wiring example on page [63](#).

The brake control logic, in various states, will request the drive control logic to hold the motor or ramp down the speed. These requests are visible in parameter [44.01 Brake control status](#).

Settings

Parameter group [44 Mechanical brake control](#) (page 312).

Brake state diagram



State descriptions

State name	Description
BRAKE DISABLED	Brake control is disabled (parameter 44.06 Brake control enable = 0, and 44.01 Brake control status b4 = 0). The open signal is active (44.01 Brake control status b0 = 1).
BRAKE OPENING:	Brake has been requested to open. (44.01 Brake control status b2 = 1). Open signal has been activated (44.01 Brake control status b0 is set). The load is held in place by the speed control of the drive until 44.08 Brake open delay elapses.
BRAKE OPEN	The brake is open (44.01 Brake control status b0 = 1). Hold request is removed (44.01 Brake control status b2 = 0), and the drive is allowed to follow the reference.
BRAKE CLOSING:	
BRAKE CLOSING WAIT	Brake has been requested to close. The drive logic is requested to ramp down the speed to a stop (44.01 Brake control status b3 = 1). The open signal is kept active (44.01 Brake control status b0 = 1). The brake logic will remain in this state until the motor speed is below 44.14 Brake close level .


State name	Description
<i>BRAKE CLOSING DELAY</i>	Closing conditions have been met. The open signal is deactivated (<i>44.01 Brake control status</i> b0 → 0). The ramp-down request is maintained (<i>44.01 Brake control status</i> b3 = 1). The brake logic will remain in this state until <i>44.13 Brake close delay</i> has elapsed. At this point, the logic proceeds to <i>BRAKE CLOSED</i> state.
<i>BRAKE CLOSED</i>	The brake is closed (<i>44.01 Brake control status</i> b0 = 0). The drive is not necessarily modulating.

State change conditions (\textcircled{n})

- 1 Brake control disabled (parameter *44.06 Brake control enable* → 0).
- 2 *06.11 Main status word*, bit 2 = 0.
- 3 Brake has been requested to open.
- 4 *44.08 Brake open delay* has elapsed.
- 5 Brake has been requested to close.
- 6 Motor speed is below closing speed *44.14 Brake close level*.
- 7 *44.13 Brake close delay* has elapsed.
- 8 Brake has been requested to open.
- 9 Brake control enabled (parameter *44.06 Brake control enable* → 1).

Timing diagram


The simplified timing diagram below illustrates the operation of the brake control function. Refer to the state diagram above. Wiring example



The figure below shows a brake control wiring example. The brake control hardware and wiring is to be sourced and installed by the customer.

⚠ WARNING! Make sure that the machinery into which the drive with brake control function is integrated fulfills the personnel safety regulations. Note that the frequency converter (a Complete Drive Module or a Basic Drive Module, as defined in IEC/EN 61800-2), is not considered as a safety device mentioned in the European Machinery Directive and related harmonized standards. Thus, the personnel safety of the complete machinery must not be based on a specific frequency converter feature (such as the brake control function), but it has to be implemented as defined in the application specific regulations.

The brake is controlled by bit 0 of parameter *44.01 Brake control status*. In this example, parameter *10.24 RO1 source* is set to *Brake command* (i.e. bit 0 of *44.01 Brake control status*).



Motor control

■ Motor types

The drive supports asynchronous AC induction.

■ Motor identification

The performance of vector control is based on an accurate motor model determined during the motor start-up.

A motor Identification magnetization is automatically performed the first time the start command is given. During this first start-up, the motor is magnetized at zero speed for several seconds and the motor and motor cable resistance are measured to allow the motor model to be created. This identification method is suitable for most applications.

In demanding applications a separate Identification run (ID run) can be performed.

Settings

[99.13 ID run requested](#) (page 366).

■ Scalar motor control

Scalar motor control is the default motor control method. In scalar control mode, the drive is controlled with a frequency reference.

ABB recommends to activate the scalar motor control mode in the following situations:

- If the exact nominal motor values are not available or the drive needs to run different motors after commissioning.
- If a short commissioning time is needed.
- If ID run is not required.
- In multimotor systems:
 - if the load is not equally shared between the motors
 - if the motors are of different sizes
 - if the motors are going to be changed after motor identification (ID run)
- If the nominal current of the motor is less than 1/6th of the nominal output current of the drive

Note: During this time, do not activate the motor phase loss fault ([31.19 Motor phase loss](#)) as the drive cannot measure the motor current accurately.
- If the drive is used without a motor connected (for example, for test purposes)
- If the drive runs a medium-voltage motor through a step-up transformer.
- If the drive is equipped with a sine filter.


Note: Performance of the vector control is not achieved in scalar control.

See also section [Operating modes of the drive](#) (page 37).

IR compensation for scalar motor control

IR compensation (also known as voltage boost) is available only when the motor control mode is scalar. When IR compensation is activated, the drive gives an extra voltage boost to the motor at low speeds. IR compensation is useful in applications, such as positive displacement pumps, that require a high break-away torque.

Note: IR compensation is not possible or required in vector control. The compensation is applied automatically.



Settings

- Parameters [97.13 IR compensation](#) (page 361)
- Main menu \equiv → Motor data \equiv or Main menu \equiv → Complete parameter list \equiv → Parameter [99.04](#).
- Parameter group [28 Frequency reference chain](#) (page 238).

Vector control

Vector control is the motor control mode intended for applications where high control accuracy is needed. It offers better control over the whole speed range, in particular in applications where slow speed with high torque is needed. It requires an identification run at startup. Vector control cannot be used in all applications, e.g. sine filters.

Vector control is based on stator flux and motor torque values.

- Stator flux is calculated by integrating the motor voltage in vector space.
The estimate of stator flux can be improved by utilizing the identified motor model.
- Motor torque is calculated as a cross product of the stator flux and the rotor current.

Both values can be achieved by controlling the output semiconductors switching. The output frequency is changed only when the actual values of stator flux and motor torque are different from their reference values by more than the allowed hysteresis. The reference value for the torque controller comes from the speed controller or directly from an external torque reference source.

Notes:



- Actual motor shaft speed is not needed for motor control.
- Vector control also requires measurement of the DC voltage and two motor phase currents.

The difference of vector control from the traditional control are:

- Torque control operates at the same time level as the power switch control.
- There is no separate voltage and frequency controlled PWM modulator.
- The output stage switching is based on the electromagnetic state of the motor.
- The best motor control accuracy is achieved by activating a separate motor identification run (normal ID run).


See also section [Speed compensated stop](#) (page 76).

Settings

- Main menu ≡ → Motor data  or Main menu ≡ → Complete parameter list  → parameter 99.04.
- Parameter 99.13 *ID run requested* (page 366).


Speed control performance figures

The table below shows typical performance figures for speed control.



Torque control performance figures

The drive can perform precise torque control without any speed feedback from the motor shaft. The table below shows typical performance figures for torque control.



Power loss ride-through

See section [Undervoltage control \(power loss ride-through\)](#) on page 77.

U/f ratio

The U/f function is available only in scalar motor control mode, which uses frequency control.

The function has the following modes:

- Linear
- Squared.

Linear mode

In linear mode, the ratio of voltage to frequency is constant below the field weakening point. This is used in constant torque applications where it may be necessary to produce torque at or near the rated torque of the motor throughout the frequency range

Squared mode

In squared mode, the ratio of the voltage to frequency increases as the square of the frequency below the field weakening point. This is typically used in centrifugal pump

or fan applications. For these applications, the torque required follows the square relationship with frequency. Therefore, if the voltage is varied using the square relationship, the motor operates at improved efficiency and lower noise levels in these applications.


The *U/f* function cannot be used with energy optimization. If parameter [45.11 Energy optimizer](#) is set to *Enable*, parameter [97.20 U/F ratio](#) is ignored.

Settings

Parameter [97.20 U/F ratio](#) (page [361](#)).

Flux braking

The drive can provide greater deceleration by raising the level of magnetization in the motor. By increasing the motor flux, the energy generated by the motor during braking can be converted to motor thermal energy.



The drive monitors the motor status continuously, also during flux braking. Therefore, flux braking can be used both for stopping the motor and for changing the speed. The other benefits of flux braking are:

- The braking starts immediately after a stop command is given. The function does not need to wait for the flux reduction before it can start the braking.
- The cooling of the induction motor is efficient. The stator current of the motor increases during flux braking, not the rotor current. The stator cools much more efficiently than the rotor.
- Flux braking can be used with induction motors and permanent magnet synchronous motors.

Two braking power levels are available:

- Moderate braking provides faster deceleration compared to a situation where flux braking is disabled. The flux level of the motor is limited to prevent excessive heating of the motor.
- Full braking exploits almost all available current to convert the mechanical braking energy to motor thermal energy. Braking time is shorter compared to moderate braking. In cyclic use, motor heating may be significant.



WARNING: The motor needs to be rated to absorb the thermal energy generated by flux braking.

Settings

Parameter [97.05 Flux braking](#) (page [360](#)).

■ DC magnetization

The drive has different magnetization functions for different phases of motor start/rotation/stop: pre-magnetization, DC hold, post-magnetization and pre-heating (motor heating).

Pre-magnetization

Pre-magnetization refers to DC magnetization of the motor before start. Depending on the selected start mode ([21.01 Start mode](#) or [21.19 Scalar start mode](#)), pre-magnetization can be applied to guarantee the highest possible breakaway torque, up to 200% of the nominal torque of the motor. By adjusting the pre-magnetization time ([21.02 Magnetization time](#)), it is possible to synchronize the motor start and, for example, the release of a mechanical brake.


Settings

Parameters [21.01 Start mode](#), [21.19 Scalar start mode](#), [21.02 Magnetization time](#)

DC hold

The function makes it possible to lock the rotor at (near) zero speed in the middle of normal operation. DC hold is activated by parameter [21.08 DC current control](#). When both the reference and motor speed drop below a certain level (parameter [21.09 DC hold speed](#)), the drive will stop generating sinusoidal current and start to inject DC into the motor. The current is set by parameter [21.10 DC current reference](#). When the

reference exceeds parameter [21.09 DC hold speed](#), normal drive operation continues.



Settings

Parameters [21.08 DC current control](#) and [21.09 DC hold speed](#)

Post-magnetization

This function keeps the motor magnetized for a certain period (parameter [21.11 Post magnetization time](#)) after stopping. This is to prevent the machinery from moving under load, for example before a mechanical brake can be applied. Post-magnetization is activated by parameter [21.08 DC current control](#). The magnetization current is set by parameter [21.10 DC current reference](#).

Note: Post-magnetization is only available when ramp stop is selected (see parameter [21.03 Stop mode](#)).

Settings

Parameters [21.03 Stop mode](#) (page 208), [21.08 DC current control](#) and [21.11 Pre-heating input source](#).

Pre-heating (Motor heating)

The pre-heating function keeps the motor warm and prevents condensation inside the motor by feeding it with DC current when the drive has been stopped. The heating can only be on when the drive is in the stopped state, and starting the drive stops the heating.

When pre-heating is activated and the stop command is given, pre-heating starts immediately if the drive is running below zero speed (see bit 0 in parameter [06.19 Speed control status word](#)). If the drive is running above zero speed, pre-heating is delayed by 60 seconds to prevent excessive current.

The function can be defined to be always active when the drive is stopped or it can be activated by a digital input, fieldbus, timed function or supervision function. For example, with the help of signal supervision function, the heating can be activated by a thermal measurement signal from the motor.

The pre-heating current fed to the motor can be defined as 0...30% of the nominal motor current.

Notes:

- In applications where the motor keeps rotating for a long time after the modulation is stopped, it is recommended to use ramp stop with pre-heating to prevent a sudden pull at the rotor when the pre-heating is activated.
- The heating function requires that the STO circuit is closed or not triggered open.
- The heating function requires that the drive is not faulted.
- Pre-heating uses DC hold to produce current.

Settings



Parameters [21.14 Pre-heating input source](#) and [21.16 Pre-heating current](#) (page 211)

■ Energy optimization

The energy optimization function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 1...20% depending on load torque and speed.

Note: With permanent magnet and synchronous reluctance motors, energy optimization is always enabled.

Settings

- Menu  → Energy efficiency 
- Parameter [45.11 Energy optimizer](#) (page 315)

■ Switching frequency

The drive has two switching frequencies: reference switching frequency and minimum switching frequency. The drive tries to keep the highest allowed switching frequency (= reference switching frequency) if thermally possible, and then adjusts dynamically between the reference and minimum switching frequencies depending on the drive temperature. When the drive reaches the minimum switching frequency (= lowest allowed switching frequency), it starts to limit output current as the heating up continues.

For derating, see chapter *Technical data*, section *Switching frequency derating* in the *Hardware manual* of the drive.

Example 1: If you need to fix the switching frequency to a certain value as with some external filters, set both the reference and the minimum switching frequency to this value and the drive will retain this switching frequency.


Example 2: If the reference switching frequency is set to 12 kHz and the minimum switching frequency is set to the smallest available value, the drive maintains the highest possible switching frequency to reduce motor noise and only when the drive heats it will decrease the switching frequency. This is useful, for example, in applications where low noise is necessary but higher noise can be tolerated when the full output current is needed.

Settings

Parameter [97.01 Switching frequency reference](#) and [97.02 Minimum switching frequency](#) (page 350).

■ Rush control

In torque control, the motor could potentially rush if the load were suddenly lost. The control program has a rush control function that decreases the torque reference whenever the motor speed exceeds [30.11 Minimum speed](#) or [30.12 Maximum speed](#).



The function is based on a PI controller. The program sets the proportional gain to 10.0 and integration time to 2.0 s.

Settings

Parameters [26.81 Rush control gain](#) (page 237) and [26.82 Rush control integration time](#) (page 237)

■ Jogging


The jogging function enables the use of a momentary switch to briefly rotate the motor. The jogging function is typically used during servicing or commissioning to

control the machinery locally. The function is available in both scalar and vector control. In vector control mode, the jogging speed reference is provided by parameters [22.42 Jogging 1 ref](#) and [22.43 Jogging 2 ref](#). In scalar control mode, the jogging frequency reference is provided by [28.42 Jogging 1 frequency ref](#) and [28.43 Jogging 2 frequency ref](#).

Two jogging functions (1 and 2) are available, each with their own activation sources and references. The signal sources are selected by parameters [20.26 Jogging 1 start source](#) and [20.27 Jogging 2 start source](#). When jogging is activated, the drive starts and accelerates to the defined jogging speed or frequency along the defined jogging acceleration ramp ([23.20 Acc time jogging](#)). After the activation signal switches off, the drive decelerates to a stop along the defined jogging deceleration ramp ([23.21 Dec time jogging](#)).

The figure and table below provide an example of how the drive operates during jogging. In the example, the ramp stop mode is used (see parameter [21.03 Stop mode](#)).

Jog cmd = State of source set by [20.26 Jogging 1 start source](#) or [20.27 Jogging 2 start source](#)
 Jog = State of source set by [20.25 Jogging enable](#)
 Start cmd = State of drive start command.



Phase	Jog cmd	Jog	Start cmd	Description
1-2	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
2-3	1	1	0	Drive follows the jog reference.
3-4	0	1	0	Drive decelerates to zero speed along the deceleration ramp of the jogging function.
4-5	0	1	0	Drive is stopped.

Phase	Jog cmd	Jog	Start cmd	Description
5-6	1	1	0	Drive accelerates to the jogging speed along the acceleration ramp of the jogging function.
6-7	1	1	0	Drive follows the jog reference.
7-8	0	1	0	Drive decelerates to zero speed/frequency along the deceleration ramp of the jogging function.
8-9	0	1->0	0	Drive is stopped. As long as the jog signal is on, start commands are ignored. After jog switches off, a fresh start command is required.
9-10	x	0	1	Drive accelerates to the speed/frequency reference along the selected acceleration ramp (parameters 23.11...23.15).
10-11	x	0	1	Drive follows the speed/frequency reference.
11-12	x	0	0	Drive decelerates to zero speed/frequency along the selected deceleration ramp (parameters 23.11...23.15).
12-13	x	0	0	Drive is stopped.
13-14	x	0	1	Drive accelerates to the speed/frequency reference along the selected acceleration ramp (parameters 23.11...23.15).
14-15	x	0->1	1	Drive follows the speed/frequency reference. As long as the start command is on, the jog signal is ignored. If the jog signal is on when the start command switches off, jogging is enabled immediately.
15-16	0->1	1	0	Start command switches off. The drive starts to decelerate along the selected deceleration ramp (parameters 23.11...23.15). When the jog command switches on, the decelerating drive adopts the deceleration ramp of the jogging function.
16-17	1	1	0	Drive follows the jog reference.
17-18	0	1->0	0	Drive decelerates to zero speed/frequency along the deceleration ramp of the jogging function.

See also the block diagram on page [468](#).

Notes:

- Jogging is not available when the drive is in local control.
- Jogging cannot be enabled when the drive start command is on, or the drive started when jogging is disabled. Starting the drive after the jog switches off requires a fresh start command.



WARNING! If jogging is enabled and activated while the start command is on, jogging will activate as soon as the start command switches off.


- If both jogging functions are activated, the one that was activated first has priority.
- The inching functions activated through fieldbus (see [06.01 Main control word](#), bits 8...9) use the references and ramp times defined for jogging, but do not require the jog signal.

Settings

Parameters [20.25 Jogging enable](#) (page 206), [20.26 Jogging 1 start source](#) (page 206), [20.27 Jogging 2 start source](#) (page 207), [22.42 Jogging 1 ref](#) (page 220), [22.43 Jogging 2 ref](#) (page 220), [28.42 Jogging 1 frequency ref](#) (page 244) [28.43 Jogging 2 frequency ref](#) (page 244), [23.20 Acc time jogging](#) (page 225) and [23.21 Dec time jogging](#) (page 225).

Speed compensated stop

Speed compensation stop is available for example for applications where a conveyer needs to travel a certain distance after receiving the stop command. At maximum speed, the motor is stopped normally along the defined deceleration ramp, after the application of a user defined delay to adjust the distance traveled. Below maximum speed, stop is delayed still more by running the drive at current speed before the motor is ramped to a stop. As shown in the figure, the distance traveled after the stop command is the same in both cases, that is, area A + area B equals area C. Speed compensation does not take into account shape times (parameters [23.32 Shape time 1](#) and [23.33 Shape time 2](#)). Positive shape times lengthen the distance traveled.



Speed compensation can be restricted to forward or reverse rotating direction.

Speed compensation is supported in both vector and scalar motor control.

Settings

Parameters [21.30 Speed compensated stop mode](#) (page 214), [21.31 Speed comp stop delay](#) (page 214) and [21.32 Speed comp stop threshold](#) (page 214).

DC voltage control


■ Overvoltage control

Overvoltage control of the intermediate DC link is typically needed when the motor is in generating mode. The motor can generate when it decelerates or when the load overhauls the motor shaft, causing the shaft to turn faster than the applied speed or frequency. To prevent the DC voltage from exceeding the overvoltage control limit, the overvoltage controller automatically decreases the generating torque when the limit is reached. The overvoltage controller also increases any programmed deceleration times if the limit is reached; to achieve shorter deceleration times, a brake chopper and resistor may be required.

■ Undervoltage control (power loss ride-through)

If the incoming supply voltage is cut off, the drive will continue to operate by utilizing the kinetic energy of the rotating motor. The drive is fully operational as long as the motor rotates and generates energy to the drive. The drive can continue operation after the break if the main contactor (if present) remained closed.

Note: Units equipped with a main contactor must be equipped with a hold circuit (e.g. UPS) to keep the contactor control circuit closed during a short supply break.



Implementing the undervoltage control (power loss ride-through)

Implement the undervoltage control function as follows:

- Check that the undervoltage control function of the drive is enabled with parameter [30.31 Undervoltage control](#).
- Parameter [21.01 Start mode](#) must be set to *Automatic* (in vector mode) or parameter [21.19 Scalar start mode](#) to *Automatic* (in scalar mode) to make flying start (starting into a rotating motor) possible.

If the installation is equipped with a main contactor, prevent its tripping at the input power break. For example, use a time delay relay (hold) in the contactor control circuit.



WARNING! Make sure that the flying restart of the motor will not cause any danger. If you are in doubt, do not implement the undervoltage control function.

Automatic restart

It is possible to restart the drive automatically after a short (max. 5 seconds) power supply failure by using the Automatic restart function, provided that the drive is allowed to run for 5 seconds without the cooling fans operating.

When enabled, the function takes the following actions upon a supply failure to a successful restart:

- The undervoltage fault is suppressed (but a warning is generated).
- Modulation and cooling is stopped to conserve any remaining energy.
- DC circuit pre-charging is enabled.

If the DC voltage is restored before the expiration of the period defined by parameter [21.18 Auto restart time](#) and the start signal is still on, normal operation will continue. However, if the DC voltage remains too low at that point, the drive trips on a fault, [3220 DC link undervoltage](#).



WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.

■ Voltage control and trip limits

The control and trip limits of the intermediate DC voltage regulator are relative to the supply voltage as well as drive/inverter type. The DC voltage (U_{DC}) is approximately 1.41 times the line-to-line supply voltage, and is displayed by parameter [01.11 DC voltage](#).

The following table shows the values of selected DC voltage levels. The drive DC voltage limits are calculated based on the parameter [95.01 Supply voltage](#) and [95.02 Adaptive voltage limits](#).

Notes:

- parameter [95.03 Estimated AC supply voltage](#) is the estimated voltage during start-up of the drive and is not continuously updated during the time limit.
- The absolute voltages vary according to the drive/inverter type and AC supply voltage range.

DC Voltage level [V]	95.01 Supply voltage		
	AC supply voltage range [V] 380...415	AC supply voltage range [V] 440...480	Automatic/Not selected
Overvoltage fault limit	842	842	842
Overvoltage control limit	779	779	779
Internal brake chopper start limit	779	779	779

DC Voltage level [V]	95.01 Supply voltage		
	AC supply voltage range [V] 380...415	AC supply voltage range [V] 440...480	Automatic/Not selected
Internal brake chopper stop limit	759	759	759
Oversvoltage warning limit	745	745	745
Undervoltage warning limit	$0.85 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.85 \times 1.35 \times 380 = 436 ^2)$	$0.85 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.85 \times 1.35 \times 440 = 463 ^2)$	$0.85 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.85 \times 1.35 \times 440 = 463 ^2)$
Undervoltage control limit	$0.78 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.78 \times 1.35 \times 380 = 400^2)$	$0.78 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.78 \times 1.35 \times 440 = 463 ^2)$	$0.78 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.78 \times 1.35 \times 440 = 463^2)$
Charging relay closing limit	$0.78 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.78 \times 1.35 \times 380 = 400 ^2)$	$0.78 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.78 \times 1.35 \times 440 = 463 ^2)$	$0.78 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.78 \times 1.35 \times 440 = 463 ^2)$
Charging relay opening limit	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.73 \times 1.35 \times 380 = 374 ^2)$	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.73 \times 1.35 \times 440 = 433 ^2)$	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.73 \times 1.35 \times 440 = 433 ^2)$
Undervoltage fault limit	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.73 \times 1.35 \times 380 = 374 ^2)$	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.73 \times 1.35 \times 440 = 433 ^2)$	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.45 \times 1.35 \times 440 = 433 ^2)$
DC voltage at upper bound of supply voltage range (U_{DCmax})	560	648	648
DC voltage at lower bound of supply voltage range (U_{DCmin})	513	594	594
Charging activation/standby limit ³⁾	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.73 \times 1.35 \times 380 = 374 ^2)$	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.73 \times 1.35 \times 440 = 433 ^2)$	$0.73 \times 1.41 \times \text{par } 95.03 \text{ value } ^1)$ $0.73 \times 1.35 \times 440 = 433 ^2)$
¹⁾ Parameter <i>Adaptive voltage limits</i> is set to <i>Enable</i> ²⁾ Parameter <i>Adaptive voltage limits</i> is set to <i>Disable</i> ³⁾ When standby is activated, drive modulation is stopped, the fan is stopped and the pre-charge circuit is activated. If the voltage exceeds this level again, the drive has to complete charging before it will automatically continue operation.			

A warning *A3A2 DC link undervoltage* is generated during any of the below conditions occurs:

- When drive is not modulating and the DC link voltage *01.11 DC voltage* is below 85% of the undervoltage warning limit.
- The drive is modulating, the DC link voltage *01.11 DC voltage* is below 73% of the standby limit and the parameter *21.18 Auto restart time* > 0. The warning continues to appear if the DC link voltage is continuously less than the standby limit until auto restart time elapses.

Note: Control board must be externally powered with 24 VDC to enable warning in this condition. Else, the control switches off once the DC voltage goes below hardware limit.

A fault [3220 DC link undervoltage](#) is generated during any of the below conditions:

- The DC link voltage [01.11 DC voltage](#) value is less than the undervoltage trip limit and the parameter [21.18 Auto restart time](#) is not enabled.
- The DC link voltage [01.11 DC voltage](#) value is less than the undervoltage trip limit and the parameter [21.18 Auto restart time](#) is enabled. The undervoltage trip occurs only if the warning continues to appear until auto restart time elapses.

Notes:

- Control board must be externally powered with 24 VDC to enable warning in this condition. Else, the control switches off once the DC voltage goes below the hardware limit.
- DC voltage stabilization parameter is available in service level parameters list. For more information, contact your local ABB representative.

Settings

Parameters [01.11 DC voltage](#) (page [163](#)), [30.30 Overvoltage control](#) (page [254](#)), [30.31 Undervoltage control](#) (page [254](#)), [95.01 Supply voltage](#) (page [350](#)) and [95.02 Adaptive voltage limits](#) (page [351](#)).

■ Brake chopper

A brake chopper can be used to handle the energy generated by a decelerating motor. When the DC voltage rises high enough, the chopper connects the DC circuit to an external brake resistor. The chopper operation is based on hysteresis.

The internal brake choppers in the drive (in frames R0...R3) start conducting at internal brake chopper start limit 780 V and stop conducting at internal brake chopper stop limit 760 V (AC supply 380...480 V).

For information on external brake choppers, refer to the respective user manual.

Note: Overvoltage control needs to be disabled for the chopper to operate.

Settings

Parameter [01.11 DC voltage](#) (page [163](#)), [30.30 Overvoltage control](#) (page [254](#)) and parameter group [43 Brake chopper](#) (page [310](#)).

Safety and protections

■ Fixed/Standard protections

Overcurrent

If the output current exceeds the internal overcurrent limit, the IGBTs are shut down immediately to protect the drive.

DC overvoltage

See section [Overvoltage control](#) on page 77.

DC undervoltage

See section [Undervoltage control \(power loss ride-through\)](#) on page 77.

Drive temperature

If the temperature rises high enough, the drive first starts to limit the switching frequency and then the current to protect itself. If it is still keeps heating up, for example because of a fan failure, an overtemperature fault is generated.

Short circuit

In case of a short circuit, the IGBTs are shut down immediately to protect the drive.

■ Emergency stop

The emergency stop signal is connected to the input selected by parameter [21.05 Emergency stop source](#). An emergency stop can also be generated through fieldbus (parameter [06.01 Main control word](#), bits 0...2).

The mode of the emergency stop is selected by parameter [21.04 Emergency stop mode](#). The following modes are available:

- Off1: Stop along the standard deceleration ramp defined for the particular reference type in use
- Off2: Stop by coasting
- Off3: Stop by the emergency stop ramp defined by parameter [23.23 Emergency stop time](#).

Notes:

- The installer of the equipment is responsible for installing the emergency stop devices and all additional devices needed for the emergency stop function to fulfill the required emergency stop categories. For more information, contact your local ABB representative.
- After an emergency stop signal is detected, the emergency stop function cannot be canceled even though the signal is canceled.
- If the minimum (or maximum) torque limit is set to 0%, the emergency stop function may not be able to stop the drive.
- During an emergency stop, the speed and torque reference parameters such as reference ramp shapes ([23.32 Shape time 1](#) and [23.33 Shape time 2](#)) are not considered.

Settings

Parameters [21.04 Emergency stop mode](#) (page 209), [21.05 Emergency stop source](#) (page 209), and [23.23 Emergency stop time](#) (page 226).

■ Motor thermal protection

The control program features two separate motor temperature monitoring functions. The temperature data sources and warning/trip limits can be set up independently for each function.

The motor temperature can be monitored using

- the motor thermal protection model (estimated temperature derived internally inside the drive), or
- sensors installed in the windings. This will result in a more accurate motor model.

Motor thermal protection model

The drive calculates the temperature of the motor on the basis of the following assumptions:

1. When power is applied to the drive for the first time, the motor is assumed to be at ambient temperature (defined by parameter [35.50 Motor ambient temperature](#)). After this, when power is applied to the drive, the motor is assumed to be at the estimated temperature.
2. Motor temperature is calculated using the user-adjustable motor thermal time and motor load curve. The load curve should be adjusted in case the ambient temperature exceeds 30%.

Note: The motor thermal model can be used when only one motor is connected to the inverter.

Implementing a motor temperature sensor connection



WARNING! IEC 60664 and IEC 61800-5-1 require double or reinforced insulation between live parts and the surface of accessible parts of electrical equipment which are either non-conductive or conductive but not connected to the protective earth.

You have four implementation alternatives:

- If there is double or reinforced insulation between the sensor and the live parts of the motor, you can connect the sensor directly to the analog/digital input(s) of the drive.
 - If there is basic insulation between the sensor and the live parts of the motor, you can connect the sensor to the analog/digital input(s) of the drive if all other circuits connected to the digital and analog inputs (typically extra-low voltage circuits) are protected against contact and insulated with basic insulation from other low-voltage circuits. The insulation must be rated for the same voltage level as the
-


drive main circuit. Note that extra-low voltage circuits (such as 24 V DC) typically do not meet these requirements.

- Alternative (for R0...R2 frames only): You can connect the sensor with a basic insulation to the analog/digital input(s) of the drive if you do not connect any other external control circuits to drive digital and analog inputs.

Temperature monitoring using PTC sensors

1...3 PTC sensors can be connected in series to an analog input and an analog output.


The analog output feeds a constant excitation current of 1.6 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function calculates the resistance of the sensor and generates an indication if overtemperature is detected.



Leave the sensor end of the cable shield unconnected.

For wiring of the sensor, refer to the drive hardware manual

The figure below shows typical PTC sensor resistance value as a function of temperature.



In R0...R2 frames, when an analog output is not available or used for other purposes, it is possible to setup a voltage divider connection that uses the internal resistance of a digital input.

1...3 PTC sensors can be connected in series with 10 V reference and digital and analog inputs. The temperature measurement function reads the voltage over the internal resistance of the digital input from the analog input and calculates the PTC resistance.



Note: RIIO-01 or BIO-01 is required for the analog input. By default, RIIO-01 is provided with the ACS560 drives.

Example settings

The parameters are set as follows for monitoring the temperature with PTC sensors:

Parameter	Value
35.11 Temperature 1 source	PTC analog I/O (20). For R0...R2 frames, it can be PTC AI/DI Voltage Divider tree (23) also.
35.14 Temperature 1 AI source	AI1
12.15 AI1 actual value	V
13.12 AO1 source	Temp sensor 1 excitation (20). Note: This is not applicable for R0...R2, if PTC AI/DI Voltage Divider tree is used.
35.12 Temperature 1 fault limit	Desired value



WARNING! IEC 60664 requires double or reinforced insulation between live parts and the surface of accessible parts of electrical equipment which are either non-conductive or conductive but not connected to the protective. Obey the electrical planning guidelines for implementing the motor temperature sensor connection. If you ignore them, injury or death, or damage to the equipment can occur

For wiring of the sensor, refer to the drive hardware manual.

Make sure that the DI used is not configured to any other use in the drive control program.

Temperature monitoring using Pt100 sensors

1...3 Pt100 sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 9.1 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

It is possible to adjust the motor temperature supervision limits and select how the drive reacts when overtemperature is detected.

See section [Implementing a motor temperature sensor connection](#) on page 83.

For the wiring of the sensor, see chapter Electrical installation, section *AI1 and AI2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1) in the drive hardware manual*.

Temperature monitoring using Pt1000 sensors

1...3 Pt1000 sensors can be connected in series to an analog input and an analog output.

The analog output feeds a constant excitation current of 0.1 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

See section [Implementing a motor temperature sensor connection](#) on page 83.

For the wiring of the sensor, see chapter *Electrical installation, AI1 and AI2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1) in the Hardware manual* of the drive.

Temperature monitoring using Ni1000 sensors

One Ni1000 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 9.1 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

See section [Implementing a motor temperature sensor connection](#) on page 83.

For the wiring of the sensor, see chapter *Electrical installation, AI1 and AI2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1) in the Hardware manual* of the drive.

Temperature monitoring using KTY84 sensors

One KTY84 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 2.0 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

The figure and table on page 146 show typical KTY84 sensor resistance values as a function of the motor operating temperature.

See section [Implementing a motor temperature sensor connection](#) on page 83.


For the wiring of the sensor, see chapter *Electrical installation, AI1 and AI2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1)* in the *Hardware manual* of the drive.

Temperature monitoring using KTY83 sensors

One KTY83 sensor can be connected to an analog input and an analog output on the control unit.

The analog output feeds a constant excitation current of 1.0 mA through the sensor. The sensor resistance increases as the motor temperature rises, as does the voltage over the sensor. The temperature measurement function reads the voltage through the analog input and converts it into degrees Celsius.

The figure and table below show typical KTY83 sensor resistance values as a function of the motor operating temperature.



It is possible to adjust the motor temperature supervision limits and select how the drive reacts when overtemperature is detected.

See section [Implementing a motor temperature sensor connection](#) on page 83.

For the wiring of the sensor, see chapter *Electrical installation, AI1 and AI2 as Pt100, Pt1000, Ni1000, KTY83 and KTY84 sensor inputs (X1)* in the *Hardware manual* of the drive.

Connection of motor temperature sensor to the drive via a relay

PTC alternative A: This table shows the insulation requirement for a customer's external relay, and the insulation requirement for the sensor to fulfill decisive voltage class A (double insulation) of IEC 60800-5-1.

PTC relay		Temperature sensor insulation requirement
Type	Insulation	
External relay	Basic insulation 6 kV	Basic insulation

PTC alternative B: Decisive voltage class B of IEC 60800-5-1 (basic insulation) is provided with a 6 kV relay. Circuits connected to all motor protection relay inputs and outputs must be protected against direct contact.

Pt100 alternative A: This table shows the insulation requirement for a customer's external relay, and the insulation requirement for the sensor to fulfill decisive voltage class A (double insulation) of IEC 60800-5-1.

Pt100 relay		Temperature sensor insulation requirement between sensor and live parts of motor
Type	Insulation	
External relay	Basic insulation 6 kV	Basic insulation

Pt100 alternative B: Decisive voltage class B of IEC 60800-5-1 (basic insulation) can be achieved when there is basic insulation between the sensor and live parts of the motor. Circuits connected to all motor protection relay inputs and outputs must be protected against direct contact.

Settings and diagnostics

Menu - Primary settings - Motor - Thermal protection estimated,
Menu - Primary settings - Motor - Thermal protection measured

Settings

Parameter group [35 Motor thermal protection](#) (page 278).

■ Motor overload protection

This section describes motor overload protection without using motor thermal protection model, either with estimated or measured temperature. For protection with the motor thermal protection model, see section [Motor thermal protection](#) on page 83.

Motor overload protection is required and specified by multiple standards including the US National Electric Code (NEC), UL 508C and the common UL/IEC 61800-5-1 standard in conjunction with IEC 60947-4-1. The standards allow for motor overload protection without external temperature sensors.

The protection feature allows the user to specify the class of operation in the same manner as the overload relays are specified in standards IEC 60947-4-1 and NEMA ICS 2.

Motor overload protection requires that you specify a motor current tripping level. This is defined by a curve using parameters [35.51](#), [35.52](#) and [35.53](#). The tripping level is the motor current at which the overload protection will ultimately trip if the motor current remains at this level continuously.

The motor overload class (class of operation), parameter [35.57 Motor overload class](#), is given as the time required for the overload relay to trip when operating at 7.2 times

the tripping level in the case of IEC 60947-4-1 and 6 times the tripping level in the case of NEMA ICS 2. The standards also specify the time to trip for current levels between the tripping level and the 6 times tripping level. The drive satisfies the IEC standard and NEMA standard trip times.

Using class 20 satisfies the UL 508C requirements.

The motor overload algorithm monitors the squared ratio (motor current / tripping level)² and accumulates this over time. This is sometimes to as I²t protection. The accumulated value is shown with parameter [35.05](#).

You can define with parameter [35.56](#) that when [35.05](#) reaches 88%, a motor overload warning will be generated, and when it reaches 100%, the drive will trip on the motor overload fault. The rate at which this internal value is increased depends on the actual current, tripping level current and overload class selected.

Parameters [35.51](#), [35.52](#) and [35.53](#) serve a dual purpose. They determine the load curve for temperature estimate as well as specify the overload tripping level.

Settings and diagnostics

Parameters common to motor thermal protection and motor overload protection: [35.51 Motor load curve...35.53 Break point](#) (page [286](#)).

Parameters specific to motor overload protection: [35.05 Motor overload level](#) (page [278](#)), [35.56 Motor overload action...35.57 Motor overload class](#) (page [288](#)).

Events: [A783 Motor overload](#) (page [395](#)) and [7122 Motor overload](#) (page [409](#)).

■ Programmable protection functions

External events (parameters [31.01...31.10](#))

Five different event signals from the process can be connected to selectable inputs to generate trips and warnings for the driven equipment. When the signal is lost, an external event (fault, warning, or a mere log entry) is generated.

Motor phase loss detection (parameter 31.19)

The parameter selects how the drive reacts whenever a motor phase loss is detected.

The motor phase loss detection is enabled by default and displays fault [3381 Output phase loss](#) whenever the drive detects a phase loss. The motor phase loss detection needs to be enabled or disabled based on the motor control mode and the nominal current as follows:

- With the vector control, the motor phase loss detection is always on and there are no operational limits.
- With the scalar control, the motor phase loss detection activates when the motor frequency is above 10% of the motor nominal frequency. This limit cannot be changed.

With motors having nominal current below 1/6 of drive nominal current, the supervision must be disabled as the drive cannot measure the motor current accurately.

Safe torque off detection (parameter 31.22)

The drive monitors the status of the Safe torque off input, and this parameter selects which indications are given when the signals are lost. (The parameter does not affect the operation of the Safe torque off function itself). For more information on the Safe torque off function, see chapter *Planning the electrical installation*, section *Implementing the Safe torque off function* in the *Hardware manual* of the drive.

Swapped supply and motor cabling (parameter 31.23)

The drive can detect if the supply and motor cables have accidentally been swapped (for example, if the supply is connected to the motor connection of the drive). The parameter selects if a fault is generated or not.


Current limit function (parameters 30.09, 30.17, and 30.10)

The drive monitors the maximum current limit, its related parameters and helps the motor not to reach its stall current limit. The maximum current, monitoring time, and how the drive should react to these conditions can be set in the parameters [30.17](#), [30.09](#), and [30.10](#) respectively.

By default, when the drive reaches the maximum current limit and exceeds the monitor time, a warning message ([A8B6](#)) is displayed.

Stall function (parameters 31.24...31.28)

The drive monitors the stall current limit, its related parameters and helps to prevent stalling of the motor. You can adjust the supervision limits (current, frequency and time) and choose how the drive reacts to a stall condition.



Notes

- ¹⁾ By default, displays a warning message when the drive reaches maximum current limit (30.17) and exceeds the current limit monitor time (30.09). You can configure the actions as required.
- ²⁾ The stall condition occurs when the output frequency is below the level set by parameter 31.27 *Stall frequency limit* or the motor speed is below the level set by parameter 31.26 *Stall speed limit*.
- ³⁾ If enabled, displays a warning message when the drive reaches stall current limit (31.25) and exceeds the stall time (31.28). You can configure the actions as required. By default, no action is configured.

Overspeed protection (parameter 31.30)

The user can set overspeed limits by specifying a margin that is added to the currently-used maximum and minimum speed limits.

Local control loss detection (parameter 49.05)

The parameter selects how the drive reacts to a control panel or PC tool communication break.

AI supervision (parameters 12.03...12.04)

The parameters select how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input. This can be due to broken I/O wiring or sensor.

Fan control (95.200)

Fan control prevents overheating and dust accumulation in the drive. The user can set the fan to run continuously in maximum speed (Always on [1]) or can set to run the fan in auto mode (Auto [0]). In auto mode, the fan operates according to the temperature of the drive.

■ Automatic fault resets

The drive can automatically reset itself after over-current, over-voltage, undervoltage and external faults. The user can also specify a fault that is automatically reset.

By default, automatic resets are off and must be specifically activated by the user.



WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function resets the drive automatically and continues operation after a fault.

Settings

Parameters [31.12](#)...[31.16](#) (page [258](#)).

Diagnostics

■ Signal supervision

Six signals can be selected to be supervised by this function. Whenever a supervised signal exceeds or falls below predefined limits, a bit in [32.01 Supervision status](#) is activated, and a warning or fault generated.

For example, if user wants to monitor DC voltage and generate a warning/fault message if it exceeds certain limit, he/she can select DC Voltage [7] in the parameter [32.07 Supervision 1 signal](#), set low/high limit in the parameter [32.09/32.10](#) and set the action in the parameter [32.06 Supervision 1 action](#).

The supervised signal is low-pass filtered.

Settings

Parameter group [32 Supervision](#) (page [264](#)).

■ Energy saving calculators

This feature consists of the following functionalities:

- An energy optimizer that adjusts the motor flux in such a way that the total system efficiency is maximized
- A counter that monitors used and saved energy by the motor and displays them in kWh, INR (based on the currency selected in [45.17](#)) or volume of CO₂ emissions, and
- A load analyzer showing the load profile of the drive (see separate section on page [94](#)).

By default energy tariff 1 ([45.12](#)) is 5 INR and energy tariff 1 ([45.13](#)) is 6 INR. This helps to display the saved money ([45.05/45.06/45.07](#)) in INR.

In addition, there are counters that show energy consumption in kWh of the current and previous hour as well as the current and previous day.

Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of the reference motor power given in parameter [45.19 Comparison power](#).

Settings

- Main menu ☰ → Energy efficiency 🍃
- Parameter group [45 Energy efficiency](#) (page [313](#)).
- Parameters [01.50 Current hour kWh](#), [01.51 Previous hour kWh](#), [01.52 Current day kWh](#) and [01.53 Previous day kWh](#) on page [164](#).

■ Load analyzer

Peak value logger





The user can select a signal to be monitored by a peak value logger. The logger records the peak value of the signal along with the time the peak occurred, as well as motor current, DC voltage and motor speed at the time of the peak. The peak value is sampled at 2 ms intervals.

Settings

Parameter group [36 Load analyzer](#) (page [289](#)).

■ Diagnostics menu

The **Diagnostics** menu provides quick information about active faults, warnings, fault history and I/O connection status. It also helps you to find out why the drive is not starting, stopping or running at the desired.

- Active faults  0 : Use this view to see the currently active faults. For information on the fault codes, see list of [Fault messages](#) on page [402](#).
- Fault history  : Use this view to see the fault history. For information on the fault codes, see list of [Fault messages](#) on page [402](#).
- Active warnings  0 : Use this view to see currently active warnings. For information on the warning codes, see list of [Warning messages](#) on page [390](#).
- I/O status  : Use this view to see currently active I/O settings.

Settings

Menu  → Diagnostics 

Miscellaneous

■ Backup and restore

You can make backups of the settings manually to the control panel and can restore backup to the drive, or a new drive replacing a faulty one. You can also make backups and restore on the panel with the Drive composer PC tool.

Backup

Manual backup

Make a backup when necessary, for example, after you have started up the drive or when you want to copy the settings to another drive.

Parameter changes from fieldbus interfaces are ignored unless you have forced parameter saving with parameter [96.07 Parameter save manually](#).




Automatic backup

The control panel has a dedicated space for one automatic backup. An automatic backup is created two hours after the last parameter change. After completing the backup, the panel waits for 24 hours before checking if there are additional parameter changes. If there are, it creates a new backup overwriting the previous one when two hours have passed after the latest change.

You cannot adjust the delay time or disable the automatic backup function.




Parameter changes from fieldbus interfaces are ignored unless you have forced parameter saving with parameter [96.07 Parameter save manually](#).

Restore

The backups are shown on the panel. Automatic backups are marked with icon  and manual backups with . To restore a backup, select it and press . In the following display you can view backup contents and restore all parameters or select a subset to be restored.

Note: To restore a backup, the drive has to be in Local control.

Settings

- Main menu  → Backup data  ← 
- Parameter [96.07 Parameter save manually](#) (page [354](#)).

■ User parameter sets

The drive supports four user parameter sets that can be saved to the permanent memory and recalled using drive parameters. It is also possible to use digital inputs to switch between user parameter sets. To change a user parameter set, the drive has to be stopped.

A user parameter set contains all editable values in parameter groups 10...99 except

- forced I/O values such as parameters [10.03 DI force selection](#) and [10.04 DI forced data](#)
- I/O extension module settings (group 15)
- data storage parameters (group 47)
- fieldbus communication settings (groups 50...53 and 58)
- parameter [95.01 Supply voltage](#).

As the motor settings are included in the user parameter sets, make sure the settings correspond to the motor used in the application before recalling a user set. In an application where different motors are used with the drive, the motor ID run needs to be performed with each motor and the results saved to different user sets. The appropriate set can then be recalled when the motor is switched.

Settings

Parameters [96.10...96.13](#) (page [355](#)).

■ Data storage parameters

Twelve (eight 32-bit, four 16-bit) parameters are reserved for data storage. These parameters are unconnected by default and can be used for linking, testing and commissioning purposes. They can be written to and read from using other parameters' source or target selections.

Settings

Parameter group [47 Data storage](#) (page [320](#)).

■ User lock

For better cyber security, it is highly recommended that you set a master pass code to prevent changing of parameter values and/or the loading of firmware and other files.



WARNING! ABB will not be liable for damages or losses caused by the failure to activate the user lock using a new pass code. See [Cyber security disclaimer](#) (page [17](#)).

To activate the user lock for the first time, enter the default pass code, 10000000, into [96.02 Pass code](#). This will make parameters [96.100...96.102](#) visible. Then enter a new pass code into [96.100 Change user pass code](#), and confirm the code in [96.101 Confirm user pass code](#). In [96.102 User lock functionality](#), define the actions that you want to prevent (we recommend you select all the actions unless otherwise required by the application).

To close the user lock, enter an invalid pass code into [96.02 Pass code](#), activate [96.08 Control board boot](#), or cycle the power. With the lock closed, parameters [96.100...96.102](#) are hidden.

To reopen the lock, enter your pass code into [96.02 Pass code](#). This will again make parameters [96.102...96.102](#) visible.

Settings

Parameters [96.02](#) (page [353](#)) and [96.100...96.102](#) (page [358](#)).

■ Sine filter support

The control program has a setting that enables the use of ABB sine filters (available separately). With a sine filter connected to the output of the drive, bit 1 of [95.01 Special HW settings](#) must be switched on. The setting forces the drive to use the scalar motor control mode, and limits the switching and output frequencies to

- prevent the drive from operating at filter resonance frequencies, and
- protect the filter from overheating.

Contact your local ABB representative before connecting a sine filter from another manufacturer.

Settings

Parameter [95.01 Special HW settings](#) (page [350](#)).

■ Short and Long menu

The drive uses short menu and long menu structure in the parameter list. The short menu displays common parameter list and the long menu displays complete parameter list. The Long and short menus are adjusted by parameter [96.02](#) password. The default value is short menu [1].

Settings

Parameter [96.02 Pass code](#) (page [353](#)).

■ Basic panel home view options

The drive provides 3 basic panel home view screens. The basic panel home view settings allows the user to select the parameters that needs to be displayed in each screen. The basic panel home view 1, 2, and 3 is applied when external control location is EXT 1 ([19.11 Ext1/Ext2 selection](#) = EXT 1) and the basic panel home view 4, 5, and 6 is applied when the external control location is EXT 2 ([19.11 Ext1/Ext2 selection](#) = EXT 2).

Settings

Parameter [49.19 Basic panel home view 1...49.19 Basic panel home view 1](#) (page [322](#)).



Control macros

Contents of this chapter

This chapter describes the intended use, operation and default control connections of the application. Apart from this, it also includes the list of parameter default values for each macro.

The settings and the example referred in this chapter are with respect to the basic control panel. However, you can also perform these actions using the assistant control panel.




Overview

Control macros are set of default parameter values suitable for a certain control configuration. When starting the drive, the user typically selects the best-suited control macro as a starting point and then makes necessary changes to tailor the settings to meet the requirements.



Control macros has the following features:

- Results in a much lower number of user edits compared to the traditional way of programming a drive.
- Allows quick configuration of the drive and enables quick start of the motor.

There are two ways of selecting the control macro from the **Main menu**  →:

- **Connection macro**  → **Macro**
or
- **Parameters**  → **Complete parameter list**  → **parameter 96.04**

Notes:

- Scalar control is the default control mode for all macros, except for the macros ABB standard and Pharma.
 - ABB standard macro with vector motor control mode is available as a different macro. For the other applications, you can change the motor control mode manually from the **Main menu**  → **Motor data** .
 - If Vector motor control mode is selected, make sure that ID run is performed. See [ID run procedure](#).
-

The control macros are categorized as application macros and communication macros.

Application macros

Application macros set the default parameters needed for certain industrial applications.

The available application macros are:

- [ABB standard macro](#)
- [ABB standard macro \(vector\)](#)
- [3-wire macro](#)
- [Motor potentiometer macro](#)
- [PID macro](#)
- [Panel PID macro](#)
- [Torque control macro](#)
- [Pump and Fan Control \(PFC\) macro](#)
- [Soft Pump and Fan Control \(SPFC\) macro](#)
- [Pharma macro](#)
- [Plastic extrusion macro](#)
- [Jigar macro](#)

ABB standard macro

ABB standard macro 1◇ 2↻ is the default macro






The macro has the following features:

- 2-wire I/O configuration with three constant frequency references
- Applicable for normal control purpose
- One signal is used to start or stop the motor and another signal is used to select the direction
- Uses scalar control by default.

Note: For vector control you can use the ABB standard (vector) macro (page [103](#)).

Default control connections for the ABB standard macro

		X1 Reference voltage and analog inputs		
		1	SCR	Signal cable shield (screen)
		2	AI1	External frequency reference: 0...10 V ¹⁾⁴⁾¹⁰⁾ ; see 22.11
		3	AGND	Analog input circuit, common
		4	+10V	10 V DC reference voltage
		5	AI2	Not configured ²⁾
		6	AGND	Analog input circuit, common
		7	AO1	Output frequency, 0...20 mA¹¹⁾: see 13.12
		8	AO2	Motor current¹¹⁾: see 13.22
		9	AGND	Analog output circuit common
		8) X2, X3 Aux. voltage output and programmable digital inputs		
		10	+24V	Aux. voltage output +24 VDC, max. 250 mA ³⁾
		11	DGND	Aux. voltage output common
		12	DCOM	Digital input common for all
		13	DI1	Stop (0) / Start (1)¹⁰⁾: see 20.03
		14	DI2	Forward (0) / reverse (1)¹⁰⁾: see 20.03
		15	DI3	Constant frequency sel 110)¹⁰⁾:
		16	DI4	Constant frequency sel 2⁴⁾¹⁰⁾: see 28.23
		17	DI5	Ramp 1 (0) / Ramp 2 (1)⁵⁾⁹⁾: see 28.71
		18	DI6	Not configured
		9) X6, X7, X8 Relay outputs		
		19	RO1C	Ready Run¹¹⁾: see 10.24 250 V AC / 30 V DC 2 A
		20	RO1A	
		21	RO1B	
		22	RO2C	Running¹¹⁾: see 10.27 250 V AC / 30 V DC 2 A
		23	RO2A	
		24	RO2B	
		25	RO3C	Fault (-1)¹¹⁾: see 10.30 250 V AC / 30 V DC 2 A
		26	RO3A	
		27	RO3B	
		X5 Built-in fieldbus		
		29	B+	Internal Modbus RTU (EIA-485), see <i>Fieldbus control through the embedded fieldbus interface (EFB)</i>
		30	A-	
		31	DGND	
		(Frame R0...R2)		
		S100	TERM&BIAS	Termination resistor and bias resistor switch
		(Frame R3...R8)		
		S100	TERM	Termination resistor switch
		S200	BIAS	Bias resistor switch
		X4 Safety torque off		
		R0...R2	-	Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See <i>Safe torque off function</i> in the drive hardware manual.
		33	OUT1	
		34	OUT2	
		35	SGND	
		36	IN1	
		37	IN2	
		X10 24 V AC/DC (frames R6...R8 only)		
		40	24 V AC/DC- in	24V AC/DC input, for control unit power supply when external main power is disconnected.
		41	24 V AC/DC+ in	
		X11 Redundant auxiliary voltage output (frames R0...R2 only)		
		42	+24 V	Aux. voltage output +24 V DC, max. 250 mA ³⁾
		43	DGND	Aux. voltage output common
		44	DCOM	Digital input common for all



Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) Current [0(4)...20 mA, $R_{in} < 500$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.15 AI1 unit selection*.
- 2) Current [0(4)...20 mA, $R_{in} = 100$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.25 AI2 unit selection*.
- 3) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V) - User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).
- 4) The constant speed are set based on the combination of sources as follows:

Source defined by parameter 28.22	Source defined by parameter 28.23	Constant speed active
0	0	Set speed through AI1
1	0	<i>Constant frequency 1</i>
0	1	<i>Constant frequency 2</i>

- 5) The speed reference ramp is set based on the combination of sources as follows:

DI5 parameter 28.71	Ramp set	Parameters
		Scalar control (default)
0	<i>Acc/Dec time 1</i>	<i>28.72 Freq acceleration time 1</i>
		<i>28.73 Freq deceleration time 1</i>
1	<i>Acc/Dec time 2</i>	<i>28.74 Freq acceleration time 2</i>
		<i>28.75 Freq acceleration time 2</i>

- 6) Connected with jumpers at the factory.
- 7) Applicable for R0...R2 frames only.
- 8) Use shielded twisted-pair cables for digital signals.
- 9) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 10) Input signal
- 11) Output signal

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.







ABB standard macro (vector)

The ABB standard macro (vector) is similar to the ABB standard macro. The ABB standard uses scalar motor control mode where as the ABB standard macro (vector) uses vector control as motor control mode.

Similar to ABB standard macro, ABB standard (vector) has the following features:

- 2-wire I/O configuration with three constant frequency references
- Applicable for normal control purpose
- One signal is used to start or stop the motor and another signal is used to select the direction.

To enable the macro, navigate to:

- **Main menu**  → **Connection macro**  → **1**  **2**  **ABB standard (vector)**
or
- **Main menu**  → **Complete parameter list**  **parameter 96.04 Macro select** → [17] [ABB standard \(vector\)](#).

■ **Default control connections for the ABB standard (Vector) macro**

X1 Reference voltage and analog inputs				
1	SCR	Signal cable shield (screen)		
2	AI1	External speed reference: 0...10 V ^{1) 4) 8)} ; see 22.11		
3	AGND	Analog input circuit, common		
4	+10V	10 V DC reference voltage		
5	AI2	Not configured ²⁾		
6	AGND	Analog input circuit, common		
7	AO1	Output frequency, 0...20 mA ⁹⁾ ; see 13.12		
8	AO2	Motor current, 0...20 mA ⁹⁾ ; see 13.22		
9	AGND	Analog output circuit common		
X2, X3 Aux. voltage output and programmable digital inputs				
10	+24V	Aux. voltage output +24 VDC, max. 250 mA ³⁾		
11	DGND	Aux. voltage output common		
12	DCOM	Digital input common for all		
13	DI1	Stop (0) / Start (1): see 20.03		
14	DI2	Forward (0) / reverse (1): see 20.03		
15	DI3	Constant speed sel 1 ^{4) 8)} ; see 22.22		
16	DI4	Constant speed sel 2 ^{4) 8)} ; see 22.23		
17	DI5	Ramp 1 (0) / Ramp 2 (1) ^{8) 8)} ; see 23.11		
18	DI6	Not configured		
X6, X7, X8 Relay outputs				
19	RO1C	Ready Run ⁹⁾ ; see 10.24 250 V AC / 30 V DC 2 A		
20	RO1A			
21	RO1B			
22	RO2C	Running ⁹⁾ ; see 10.27 250 V AC / 30 V DC 2 A		
23	RO2A			
24	RO2B			
25	RO3C	Fault(-1) ⁹⁾ ; see 10.30 250 V AC / 30 V DC 2 A		
26	RO3A			
27	RO3B			
X5 Built-in fieldbus				
29	B+	Internal Modbus RTU (EIA-485), see <i>Fieldbus control through the embedded fieldbus interface (EFB)</i>		
30	A-			
31	DGND			
(Frame R0...R2)				
S100	TERM&BIAS	Termination resistor and bias resistor switch		
(Frame R3...R8)				
S100	TERM	Termination resistor switch		
S200	BIAS	Bias resistor switch		
X4 Safety torque off				
R0...R2		R3...R8		
33	-	OUT1	Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See <i>Safe torque off function</i> in the drive hardware manual.	
34	SGND	OUT2		
35	OUT1	SGND		
36	IN1	IN1		
37	IN2	IN2		
X10 24 V AC/DC (frames R6...R8 only)				
40	24 V AC/DC- in	24 V AC/DC input, for control unit power supply when external main power is disconnected.		
41	24 V AC/DC+ in			
X11 Redundant auxiliary voltage output				
42	+24 V	Aux. voltage output +24 V DC, max. 250 mA ³⁾		
43	DGND	Aux. voltage output common		
44	DCOM	Digital input common for all		

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) Current [0(4)...20 mA, $R_{in} < 500$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.15 AI1 unit selection*.
- 2) Current [0(4)...20 mA, $R_{in} = 100$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.25 AI2 unit selection*.
- 3) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).
- 4) The constant speed are set based on the combination of sources as follows:

Source defined by par.22.22	Source defined by par.22.23	Constant speed active
0	0	Set speed through AI1
1	0	<i>Constant speed 1</i>

- 5) The speed reference ramp is set based on the combination of sources as follows:

DI5	Ramp set	Parameters
		Vector control (default)
0	1	<i>23.12 Acceleration time 1</i>
		<i>23.13 Deceleration time 1</i>
1	2	<i>23.14 Acceleration time 2</i>
		<i>23.15 Deceleration time 2</i>





- 6) Connected with jumpers at the factory.
- 7) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 8) Input signal
- 9) Output signal
- 10) For R0...R2 frames only

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

3-wire macro

This macro is used when the drive is controlled using momentary push-buttons. It provides three constant speeds. To enable the macro, select it in the **Primary settings** menu or set parameter [96.04 Macro select](#) to *3-wire*.

To enable the macro, navigate to:

- **Main menu**  → **Connection macro**  →   **3-wire macro**
or

Main menu  → **Complete parameter list**  parameter [96.04 Macro select](#) → [17] *3-wire*.

Default control connections for the 3-wire macro

		X1 Reference voltage and analog inputs	
	1	SCR	Signal cable shield (screen)
	2	AI1	External speed reference: $0...10\text{ V}^{(1)(6)}$; see 22.11
	3	AGND	Analog input circuit, common
	4	+10V	10 V DC reference voltage
	5	AI2	Not configured ^{b)}
	6	AGND	Analog input circuit, common
	7	AO1	Output frequency, $0...20\text{ mA}^{(6)(9)}$; see 13.12
	8	AO2	Motor current, $0...20\text{ mA}^{(9)}$; see 13.22
	9	AGND	Analog output circuit common
		X2, X3 Aux. voltage output and programmable digital inputs	
	10	+24V	Aux. voltage output +24 VDC, max. $250\text{ mA}^{(3)}$
	11	DGND	Aux. voltage output common
	12	DCOM	Digital input common for all
	13	DI1	Stop (0): see 20.03
	14	DI2	Stop (1): see 20.03
	15	DI3	Forward(0)/Reverse (1) ⁽⁸⁾ ; see 20.03
	16	DI4	Constant speed sel 2 ⁽²⁾⁽⁸⁾ ; see 22.23
	17	DI5	Constant speed sel 2 ⁽²⁾⁽⁸⁾ ; see 22.23
	18	DI6	Not configured
		X6, X7, X8 Relay outputs	
	19	RO1C	Ready Run ⁽⁹⁾ ; see 10.24 250 V AC / 30 V DC 2 A
	20	RO1A	
	21	RO1B	
	22	RO2C	Running ⁽⁹⁾ ; see 10.27 250 V AC / 30 V DC 2 A
	23	RO2A	
	24	RO2B	
	25	RO3C	Fault(-1) ⁽⁹⁾ ; see 10.30 250 V AC / 30 V DC 2 A
	26	RO3A	
	27	RO3B	
		X5 Built-in fieldbus	
	29	B+	Internal Modbus RTU (EIA-485), see <i>Fieldbus control through the embedded fieldbus interface (EFB)</i>
	30	A-	
	31	DGND	
		(Frame R0...R2)	
	S100	TERM&BIAS	Termination resistor and bias resistor switch
		(Frame R3...R8)	
	S100	TERM	Termination resistor switch
	S200	BIAS	Bias resistor switch
		X4 Safety torque off	
	R0...R2	-	Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See <i>Safe torque off function</i> in the drive hardware manual.
	R3...R8	OUT1	
R3...R8	33	SGND	
	34	OUT2	
	35	OUT1	
	36	IN1	IN1
4)	37	IN2	
	37	IN2	IN2
4)		IN2	
		X10 24 V AC/DC (frames R6...R8 only)	
	40	24 V AC/DC- in	24V AC/DC input, for control unit power supply when external main power is disconnected.
5)	41	24 V AC/DC+ in	
		X11 Redundant auxiliary voltage output	
	42	+24 V	Aux. voltage output +24 V DC, max. $250\text{ mA}^{(7)}$
	43	DGND	Aux. voltage output common
	44	DCOM	Digital input common for all

Terminal sizes:

- (frames R0...R8: 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes:

- 1) AI1 is used as a speed reference if vector control is selected.
- 2) In scalar control (default): See **Menu - Primary settings - Start, stop, reference - Constant frequencies** or parameter group [28 Frequency reference chain](#).
In vector control: See **Menu - Primary settings - Start, stop, reference - Constant speeds** or parameter group [22 Speed reference selection](#).

DI4	DI5	Operation/Parameter	
		Scalar control (default)	Vector control
0	0	Set frequency through AI1	Set speed through AI1
1	0	28.26 Constant frequency 1	22.26 Constant speed 1
0	1	28.27 Constant frequency 2	22.27 Constant speed 2
1	1	28.28 Constant frequency 3	22.28 Constant speed 3

- 3) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 4) Connected with jumpers at the factory.
- 5) Only frames R6...R11 have terminals 40 and 41 for external 24 V AC/DC input.
- 6) Select voltage or current for inputs AI1 and AI2 and output AO1 with parameters [12.15](#), [12.25](#) and [13.15](#), respectively.
- 7) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA /24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3).
- 8) Input signal
- 9) Output signal

Input signals

- Analog speed/frequency reference (AI1)
- Start, pulse (DI1)
- Stop, pulse (DI2)
- Direction selection (DI3)
- Constant speed/frequency selection (DI4, DI5)

Output signals

- Analog output AO1: Output frequency
 - Analog output AO2: Motor current
 - Relay output 1: Ready run
 - Relay output 2: Running
 - Relay output 3: Fault (-1)
-

Motor potentiometer macro

The motor potentiometer macro can be used to adjust the speed of the motor with two-push buttons or with PLCs that change the speed of the motor using two digital signals.

The source for the digital signals, used to increase the values, can be selected by parameters [22.73 Motor potentiometer up source](#) and [22.74 Motor potentiometer down source](#).

When enabled by [22.71 Motor potentiometer function](#), the motor potentiometer assumes the value set by [22.72 Motor potentiometer initial value](#). Depending on the mode selected in [22.71](#), the motor potentiometer value is either retained or reset over a power cycle.


The time to increase the speed from the minimum ([22.76 Motor potentiometer min value](#)) to the maximum ([22.77 Motor potentiometer max value](#)) is defined in the parameter [22.78 Motor potentiometer ramp up](#).

The time to decrease the speed from the maximum ([22.77 Motor potentiometer max value](#)) value to the minimum ([22.76 Motor potentiometer min value](#)) value is defined in the parameter [22.79 Motor potentiometer ramp down](#).

If the up and down signals are simultaneously on, the motor potentiometer value does not change.


The output of the function is shown by [22.80 Motor potentiometer ref act](#), which can directly be set as the reference source in the main selector parameters, or used as an input by other source selector parameters, both in scalar and vector control.

The following example shows the behavior of the motor potentiometer value.




Parameters [22.73 Motor potentiometer up source](#) and [22.74 Motor potentiometer down source](#) control speed or frequency from zero to maximum speed or frequency.




The running direction can be changed with parameter [20.04 Ext1 in2 source](#). See the following example.



Parameters [22.73 Motor potentiometer up source](#) and [22.74 Motor potentiometer down source](#) control speed or frequency from zero to maximum speed or frequency. The running direction can be changed with parameter [20.04 Ext1 in2 source](#). See the following example.



To enable the macro, navigate to:

- **Main menu**  → **Connection macro**  →  **Motor potentiometer**
or
 - **Main menu**  → **Complete parameter list**  parameter [96.04 Macro select](#) → [13] [Motor potentiometer](#).
-

Default control connections for the ABB potentiometer macro

		X1 Reference voltage and analog inputs and outputs			
		1	SCR	Signal cable shield (screen)	
		2	AI1	Not configured	
1...10 kohm		3	AGND	Analog input circuit, common	
		4	+10V	10 V DC reference voltage	
		5	AI2	Not configured	
		6	AGND	Analog input circuit, common	
Max. 500 ohm		7	AO1	Output frequency: 0...20 mA⁶⁾; see 13.12	
		8	AO2	Motor current: 0...20 mA⁶⁾; see 13.22	
		9	AGND	Analog output circuit common	
		X2, X3 Aux. voltage output and programmable digital inputs			
		10	+24V	Aux. voltage output +24 VDC, max. 250 mA ²⁾	
		11	DGND	Aux. voltage output common	
		12	DCOM	Digital input common for all	
		13	D11	Stop (0) / Start (1)⁵⁾; see 20.03	
		14	D12	Forward (0) / reverse (1)⁵⁾; see 20.03	
		15	D13	Reference up¹⁾⁵⁾; see 22.73	
		16	D14	Reference down¹⁾⁵⁾; see 22.74	
		17	D15	Constant frequency⁵⁾; see 28.22	
		18	D16	Run enable (if 0, drive stops)⁵⁾; see 20.12	
		X6,X7, X8 Relay outputs			
		19	RO1C	Ready run⁶⁾; see 10.24. 250 V AC / 30 V DC 2 A	
		20	RO1A		
		21	RO1B	Running⁶⁾; see 10.27. 250 V AC / 30 V DC 2 A	
		22	RO2C		
		23	RO2A	Fault (-1)⁶⁾; see 10.30. 250 V AC / 30 V DC 2 A	
		24	RO2B		
		25	RO3C		
		26	RO3A		
		27	RO3B		
		X5 Built-in fieldbus			
		29	B+	Internal Modbus RTU (EIA-485). See <i>Fieldbus control through the embedded fieldbus interface (EFB)</i> .	
		30	A-		
		31	DGND		
		(Frame R0...R2)			
		S100	TERM&BIAS	Termination resistor and bias resistor switch	
		(Frame R3...R8)			
		S100	TERM	Termination resistor switch	
		S200	BIAS	Bias resistor switch	
		X4 Safety torque off			
		R0...R2	-	OUT1	
R3...R8		33		OUT1	
		34	SGND	OUT2	
		35	OUT1	SGND	
		36	IN1	IN1	
		37	IN2	IN2	
		X10 24 V AC/DC (frames R6..R8 only)			
		40	24 V AC/DC- in	24V AC/DC input, for control unit power supply when external main power is disconnected.	
		41	24 V AC/DC+ in		
		X11 Redundant auxiliary voltage output (frames R0...R2)			
		42	+24 V	Aux. voltage output +24 V DC, max. 250 mA ²⁾	
		43	DGND	Aux. voltage output common	
		44	DCOM	Digital input common for all	

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

1) If DI3 and DI4 are both active or inactive, the frequency/speed reference is unchanged.

The existing frequency/speed reference is stored during stop and power down.

2) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

3) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

4) Connected with jumpers at the factory.

5) Input signal

6) Output signal

7) For R0...R2 frames only

In addition, below input is automatically set as follows:

No.	Name (Input/Setting)	Value
23.11	<i>Ramp set selection</i>	0 = <i>Acc/Dec time 1</i>

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD50000044998)*.


PID macro

The PID macro is suitable for applications where the drive is always controlled by PID and the reference comes from analog input AI1.

To enable the macro, navigate to:

- **Main menu**  → **Connection macro**  → **PID**
or
 - **Main menu**  → **Complete parameter list**  parameter [96.04 Macro select](#) → [14] [PID](#).
- .

Default control connections for the ABB PID macro



Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) The signal source is powered externally. See the manufacturer's instructions. To use sensors supplied by the drive aux. voltage output, see chapter *Electrical installation*, section *Connection examples of two-wire and three-wire sensors* in the *Hardware manual* of the drive
- 2) If Constant frequency is activated it overrides the reference from the PID controller output.
- 3) The internal setpoint are set based on the combination of sources as follows:

Source defined by par. 40.19 DI2	Source defined by par. 40.20 DI3	Internal setpoint active
0	0	Setpoint source: AI1
1	0	Set 1 internal setpoint 1
0	1	Set 1 internal setpoint 2
1	1	Set 1 internal setpoint 3

- 4) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 5) Connected with jumpers at the factory.
- 6) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).
- 7) Input signal
- 8) Output signal
- 9) For R0...R2 frames only

In addition, below inputs are set automatically as follows:






Parameter No.	Name (Input/Setting)	Value
20.01	Ext1 commands	1= In1 Start
23.11	Ramp set selection	0 = Acc/Dec time 1

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual* (3AXD50000044998).

Panel PID macro

The panel PID macro is suitable for applications where the drive is always controlled by a PID controller and the setpoint is defined with the control panel.

To enable the macro, navigate to:

- **Main menu**  → **Connection macro**  → **Panel PID**  PID
or
 - **Main menu**  → **Complete parameter list**  parameter *96.04 Macro select* → [15] *Panel PID*.
-

Default control connections for the Panel PID macro

X1 Reference voltage and analog inputs and outputs			
1	SCR	Signal cable shield (screen)	
2	AI1	Not configured ⁶⁾	
3	AGND	Analog input circuit, common	
4	+10V	10 V DC reference voltage	
5	AI2	PID feedback, 4...20mA^{1) 7)} ; see 40.08	
6	AGND	Analog input circuit, common	
7	AO1	Output frequency, 0...20 mA⁸⁾ ; see 13.12	
8	AO2	Motor current, 0...20 mA⁸⁾ ; see 13.22	
9	AGND	Analog output circuit common	
X2, X3 Aux. voltage output and programmable digital inputs			
10	+24V	Aux. voltage output +24 VDC, max. 250 mA ⁵⁾	
11	DGND	Aux. voltage output common	
12	DCOM	Digital input common for all	
13	DI1	Stop (0) / Start (1) PID¹⁾ ; see 20.03	
14	DI2	Not configured	
15	DI3	Not configured	
16	DI4	Constant frequency 1^{2) 1)} ; see 28.26	
17	DI5	Run enable (if 0, drive stops)¹⁾ ; see 20.12	
18	DI6	Not configured	
X6,X7, X8 Relay outputs			
19	RO1C	Ready run ⁸⁾ ; see 10.24 250 V AC / 30 V DC 2 A	
20	RO1A		
21	RO1B	Running ⁸⁾ ; see 10.27 250 V AC / 30 V DC 2 A	
22	RO2C		
23	RO2A	Fault (-1) ⁸⁾ ; see 10.30 250 V AC / 30 V DC 2 A	
24	RO2B		
25	RO3C		
26	RO3A		
27	RO3B		
X5 Built-in fieldbus			
29	B+	Internal Modbus RTU (EIA-485). Internal Modbus RTU (EIA-485). See <i>Fieldbus control through the embedded fieldbus interface (EFB)</i> .	
30	A-		
31	DGND		
(Frame R0...R2)			
S100	TERM&BIAS	Termination resistor and bias resistor switch	
(Frame R3...R8)			
S100	TERM	Termination resistor switch	
S200	BIAS	Bias resistor switch	
X4 Safety torque off			
R0...R2	R3...R		
33	-	OUT1	Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See <i>Safe torque off function</i> in the drive hardware manual.
34	SGND	OUT2	
35	OUT1	SGND	
36	IN1	IN1	
37	IN2	IN2	
X10 24 V AC/DC (frames R6..R8 only)			
40	24 V AC/DC- in	24V AC/DC input, for control unit power supply when external main power is disconnected.	
41	24 V AC/DC+ in		
X11 Redundant auxiliary voltage output (frames R0...R2)			
42	+24 V	Aux. voltage output +24 V DC, max. 250 mA ⁵⁾	
43	DGND	Aux. voltage output common	
44	DCOM	Digital input common for all	

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) The signal source is powered externally. See the manufacturer's instructions. To use sensors supplied by the drive aux. voltage output, see chapter Electrical installation, section *Connection examples* of two-wire and three-wire sensors in the Hardware manual of the drive.
- 2) If Constant frequency is activated it overrides the reference from the PID controller output.
- 3) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 4) Connected with jumpers at the factory.
- 5) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).
- 6) PID setpoint is from control panel reference
- 7) Input signal
- 8) Output signal
- 9) For R0...R2 frames only

In addition, below inputs are set automatically as follows:

Parameter No.	Name (Input/Setting)	Value
20.01	<i>Ext1 commands</i>	1 = <i>In1 Start</i>
23.11	<i>Ramp set selection</i>	0 = <i>Acc/Dec time 1</i>

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD50000044998)*.

Torque control macro

This macro is used in applications in which torque control of the motor is required.

These are typically tension applications, where a particular tension needs to be maintained in the mechanical system.


Torque reference is given through analog input AI2, typically as a current signal in the range of 0...20 mA (corresponding to 0...100% of rated motor torque).

The start/stop signal is connected to digital input DI1. The direction is determined by DI2. Through digital input DI3, it is possible to select speed control (EXT1) instead of torque control (EXT2). As with the PID control macro, speed control can be used for commissioning the system and checking the motor direction.

It is also possible to change the control to local (control panel or PC tool) by pressing the Loc/Rem key. By default, the local reference is speed; if a torque reference is required, the value of parameter [19.16 Local control mode](#) should be changed to Torque.

A constant speed (by default, 300 rpm) can be activated through DI4. DI5 switches between acceleration/deceleration time sets 1 and 2. The acceleration and deceleration times are defined by parameters [23.12...23.15](#).

Default control connections for the Torque control macro



Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) Current [0(4)...20 mA, $R_{in} < 500$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.15 AI1 unit selection*.
- 2) Current [0(4)...20 mA, $R_{in} = 100$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.25 AI2 unit selection*.
- 3) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3).
- 4) Connected with jumpers at the factory.
- 5) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 6) Can be used to set up pressure alarm warning.
- 7) Can be used for cold start prevention with connection to 'temperature reached' output of temperature controller or PLC
- 8) Input signal
- 9) Output signal
- 10) For R0...R2 frames only

In addition, some inputs and settings are set automatically as follows:

No.	Name (Input/Setting)	Value
19.11	<i>Ext1/Ext2 selection</i>	5 = <i>DI3</i>
19.14	<i>Ext2 control mode</i>	3 = <i>Torque</i>
20.02	<i>Ext1 start trigger type</i>	1 = <i>Level</i>
20.06	<i>Ext2 commands</i>	2 = <i>In1 Start; In2 Dir</i>
20.07	<i>Ext2 start trigger type</i>	1 = <i>Level</i>
20.08	<i>Ext2 in1 source</i>	2 = <i>DI1</i>
20.09	<i>Ext2 in2 source</i>	2 = <i>DI2</i>
20.12	<i>Run enable 1 source</i>	7 = <i>DI6</i>
22.22	<i>Constant speed sel1</i>	5 = <i>DI4</i>
23.11	<i>Ramp set selection</i>	0 = <i>DI5</i>
26.11	<i>Torque ref1 source</i>	2 = <i>AI2 scaled</i>
31.11	<i>Fault reset selection</i>	0 = <i>Not used</i>

For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD5000044998)*

Pump and Fan Control (PFC) macro

The PFC macro is suitable for pump or fan systems consisting of one drive and multiple pumps/fans.

The PFC macro can be used to:

- Control the speed of one of the pumps/fans
- Connect or disconnect the auxiliary pumps in Direct On Line (DOL) connection as and when required.


For example, in a pump application with multiple pumps, the PFC logic controls the pumps as follows:

1. The drive varies the motor speed (VSD motor) to control the output of the first pump. This pump is the speed regulated pump.
2. When the demand (represented by the process PID reference) exceeds the capacity of the first pump (a user defined speed/frequency limit), the PFC logic automatically starts the auxiliary pump using the drive relay output.
3. The PFC logic reduces the speed of the first pump to balance the system output and to get the optimum energy efficiency.
4. The PID controller adjusts the speed/frequency of the first pump in such a way that the system output meets the process need.
5. If the demand further increases, the PFC logic adds further auxiliary pumps in similar manner.
6. When the demand drops, the drive reduces the speed of the first pump and when it reaches below the minimum limit (user defined speed/frequency limit), the PFC logic automatically stops the auxiliary pump. At the same time, the PFC logic increases the speed of the first pump to account for the missing output of the stopped auxiliary pump.

Note: The PFC is supported in external control location EXT2 only. However, you can use EXT1 for manual control of pump 1.

The below timing diagram explains how and when an auxiliary pump is connected with the PFC logic.

Example of a 3-pump constant pressure water supply application:




- Pump 1 - connected to VSD motor
- Pump 2 - connected to auxiliary motor 1
- Pump 3 - connected to auxiliary motor 2

Flow consumption versus pump status

Consumption	Pump 1	Pump 2	Pump 3
Low	VSD	Off	Off
↓	VSD	DOL	Off
High	VSD	DOL	DOL
↓	VSD	DOL	Off
Low	VSD	Off	Off
VSD	Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.		
DOL	Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.		
Off	Off-line. Pump stops.		

PFC enabled pump control timing diagram



In addition, the PFC logic also supports the following features:

Autochange

Autochange functionality or the automatic rotation can be used to automatically rotate the start order of the PFC system. This function has the following features:

- Keeps the run time of the pumps/fans equal over time to even their wear .
- Prevent any pump/fan from standing still for too long, which otherwise would clog up the unit.

In some cases it is desirable to rotate the start order only when all units are stopped, for example to minimize the impact on the process.


The Autochange function can be defined in the parameter group [76 PFC configuration](#).

Note: The Autochange function also triggered by the Timed function. See description on page [60](#).

There are 2 modes of auto change with PFC:

1. Autochange PFC with auxiliary motors
In this mode auto rotation happens with only 2nd and 3rd pump. Two pumps meet the flow consumption for long term running and the 3rd pump is reserved for shifting.
-

Example of PFC autochange with auxiliary pumps in a 3-pump constant pressure water supply application:



Pump 1 - connected to VSD motor

Pump 2 - connected to auxiliary motor 1

Pump 3 - connected to auxiliary motor 2


Flow consumption versus pump status			
Consumption	Pump 1	Pump 2	Pump 3
Low	VSD	Off	Off
Normal	VSD	DOL	Off
↓	VSD	Off	DOL
↓	VSD	DOL	Off
Normal	VSD	Off	DOL
VSD	Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.		
DOL	Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.		
Off	Off-line. Pump stops.		

2. Autochange PFC with all the motors

In this mode, all motors involves in the autochange. VSD motor moves to next

pump one by one, but the auxiliary motor is always is on-line in DOL mode. Two pumps meet the flow consumption for long term running and the 3rd pump is reserved for shifting. All the motors shifts for autochange routine and special auxiliary circuit is needed for the same. This system is similar to the SPFC.

Example of PFC autochange with all motors in a 3-pump constant pressure water supply application:



- Pump 1 - connected to Motor 1
- Pump 2 - connected to Motor 2
- Pump 3 - connected to Motor 23

Flow consumption versus pump status			
Consumption	Pump 1	Pump 2	Pump 3
Low	VSD	Off	Off
Normal	VSD	DOL	Off
↓	Off	VSD	DOL
↓	DOL	Off	VSD
Normal	VSD	DOL	Off
VSD	Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.		
DOL	Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.		
Off	Off-line. Pump stops.		

Interlock

The Interlock function can be used to notify the PFC logic on when a motor is not available. For example, when a motor is under maintenance or due to manual direct-on-line starting.

When the interlock signal of a motor is in Available status, the motor participates in the PFC starting sequence. If the signal is in Interlocked status, the motor is excluded from the PFC sequence.

The interlock function can be defined in the parameter group [76 PFC configuration](#).

Parameter Settings

To enable the PFC macro, navigate to:

- **Main menu**  → **Connection macro**  → **PFC**
or
- **Main menu**  → **Complete parameter list**  parameter [96.04 Macro select](#) → [\[16\] PFC](#).

The following default values are used for PFC macro:

No.	Value	No.	Value
10.24	7 = <i>Running</i>	20.08	7 = <i>DI6</i>
10.27	15 = <i>Fault (-1)</i>	20.09	0 = <i>Always off</i>
10.30	46 = <i>PFC2</i>	20.12	3 = <i>DI2</i>
12.17	0	20.19	1 = <i>Selected</i>
12.20	50.0	21.03	0 = <i>Coast</i>
13.12	2 = <i>Output frequency</i>	22.11	1 = <i>AI1 scaled</i>
13.18	50.0	22.18	16 = <i>PID</i>
19.11	1 = <i>DI3</i>	22.22	0 = <i>Always off</i>
19.17	0 = <i>No</i>	22.23	0 = <i>Always off</i>
20.01	1 = <i>In1 Start</i>	22.73	0 = <i>Not used</i>
20.03	2 = <i>DI1</i>	22.74	0 = <i>Not used</i>
20.04	0 = <i>Always off</i>	23.11	0 = <i>Acc/Dec time 1</i>
20.05	0 = <i>Always off</i>	28.11	1 = <i>AI1 scaled</i>
20.06	1 = <i>In1 Start</i>	28.15	16 = <i>PID</i>
28.22	0 = <i>Always off</i>	40.19	0 = <i>Not selected</i>
28.23	0 = <i>Always off</i>	40.20	0 = <i>Not selected</i>
28.71	0 = <i>Acc/Dec time 1</i>	40.32	2.50
30.11	-1500 rpm	40.33	3.0
31.01	1 = <i>Inactive (true)</i>	76.21	2 = <i>PFC</i>
31.02	0 = <i>Fault</i>	76.25	2
40.07	2 = <i>On when drive running</i>	76.27	2
40.16	11 = <i>AI1 percent</i>	99.04	0 = <i>Scalar</i>
40.17	0 = <i>Not selected</i>		

Default control connections for the PFC macro

		X1 Reference voltage and analog inputs and outputs			
		1	SCR	Signal cable shield (screen)	
1...10 kohm		2	AI1	PID setpoint, 0...10 V^{1) 5)} ; see 40.16	
		3	AGND	Analog input circuit, common	
		4	+10V	10 V DC reference voltage	
		5	AI2	PID feedback, 4...20mA^{1) 5)} ; see 40.08	
		6	AGND	Analog input circuit, common	
Max. 500 ohm		7	AO1	Output frequency: 0...20 mA⁶⁾ ; see 13.12	
		8	AO2	Motor current, 0...20 mA⁶⁾ ; see 13.22	
	2)	9	AGND	Analog output circuit common	
		X2, X3 Aux. voltage output and programmable digital inputs			
		10	+24V	Aux. voltage output +24 VDC, max. 250 mA ⁴⁾	
		11	DGND	Aux. voltage output common	
	3)	12	DCOM	Digital input common for all	
		13	D11	Stop (0) / Start (1) (EXT 1)⁵⁾ ; see 20.03	
		14	D12	Run enable (if 0, drive stops)⁵⁾ ; see 20.12 .	
		15	D13	EXT1 (0) / EXT 2 (1)⁵⁾ ; see 19.11	
		16	D14	Not configured	
		17	D15	Not configured	
		18	D16	Not configured	
		X6,X7, X8 Relay outputs			
		19	RO1C	Running⁶⁾ ; see 10.27 250 V AC / 30 V DC 2 A	
		20	RO1A		
		21	RO1B	Fault (-1)⁶⁾ ; see 10.30 250 V AC / 30 V DC 2 A	
		22	RO2C		
		23	RO2A	PFC2 (the 2nd motor = the first auxiliary motor)⁶⁾ ; see 10.30 250 V AC / 30 V DC	
		24	RO2B		
		25	RO3C		
		26	RO3A		
		27	RO3B		
		X5 Built-in fieldbus			
		29	B+	Internal Modbus RTU (EIA-485). See Fieldbus control through the embedded fieldbus interface (EFB) .	
		30	A-		
		31	DGND		
		(Frame R0...R2)			
		S100	TERM&BIAS	Termination resistor and bias resistor switch	
		(Frame R3...R8)			
		S100	TERM	Termination resistor switch	
		S200	BIAS	Bias resistor switch	
		X4 Safety torque off			
		R0...R2	R3...R	Safety torque off function. Factory connection. Both circuits must be closed for the drive to start. See <i>Safe torque off function</i> in the drive hardware manual.	
		33	-		OUT1
		34	SGND		OUT2
R3...R8		35	OUT1		SGND
	7)	36	IN1		IN1
3)		37	IN2		IN2
		X10 24 V AC/DC (frames R6...R8 only)			
		40	24 V AC/DC- in	24V AC/DC input, for control unit power supply when external main power is disconnected.	
		41	24 V AC/DC+ in		
		X11 Redundant auxiliary voltage output (frames R0...R2)			
		42	+24 V	Aux. voltage output +24 V DC, max. 250 mA ⁴⁾	
		43	DGND	Aux. voltage output common	
		44	DCOM	Digital input common for all	

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) The signal source is powered externally. See the manufacturer's instructions. To use sensors supplied by the drive aux. voltage output, see chapter *Electrical installation*, section *Connection examples of two-wire and three-wire sensors* in the Hardware manual of the drive.
- 2) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 3) Connected with jumpers at the factory.
- 4) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).
- 5) Input signal
- 6) Output signal
- 7) For R0...R2 frames only

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

Soft Pump and Fan Control (SPFC) macro

The Soft Pump and Fan Control (SPFC) logic is a variant of the PFC logic for pump and fan alternation applications where lower pressure peaks are desirable when a new auxiliary motor is to be started. The SPFC logic is an easy way to implement soft starting of direct on line (auxiliary) motors.

In SPFC all the pumps are auxiliary pump and get connected to Direct On Line (DOL) or drive as and when required. In PFC only primary pump is connected to the drive.


In SPFC logic the auxiliary pumps are connected as follows:

1. As the expected flow rate/demand increases, the speed of auxiliary pump 1 increases accordingly. When the auxiliary pump reaches the start speed ([76.30](#)) and exceeds the start delay ([76.55](#)), the drive connects the drive controlled motor (auxiliary pump 1) to the supply network in a flying start, that is, while the motor is still coasting.
2. The drive then connects to the auxiliary pump 2 and starts controlling the speed.
3. The auxiliary pump 1 is connected DOL through a contactor.
4. Further auxiliary motors, if connected, are started in a similar manner. The motor stopping routine is the same as for the normal PFC routine.
5. In some cases SPFC makes it possible to soften the start-up current while connecting auxiliary motors on-line. Lower pressure peaks on the pipelines and pumps may be achieved as a result.

Note: The SPFC is supported in external control location EXT2 only. EXT1 can be used for the manual control of pump 1.

The below timing diagram explains how and when an auxiliary pump is connected with the SPFC logic.

Example of a 3-pump constant pressure water supply application:



Pump 1 is connected to Motor 1

Pump 2 is connected to Motor 2

Pump 3 is connected to Motor 3

Flow consumption versus pump status


Consumption	Pump 1	Pump 2	Pump 3
Low	VSD	Off	Off
↓	DOL	VSD	Off
High	DOL	DOL	DOL
↓	DOL	Off	VSD
← Low	Off	Off	Off
↓	VSD	Off	DOL
High	DOL	VSD	DOL
↓	DOL	VSD	Off
Low	Off	VSD	Off
↓	VSD	DOL	Off
High	DOL	DOL	VSD

VSD
Variable Speed Drive (yellow colour connecting line in the figure).
Controlled by drive, tuning the output speed according to PID control.

DOL
Direct On Line (red colour connecting line in the figure). Pump is running
at fixed motor nominal speed.

Off
Off-line. Pump stops.

SPFC enabled pump control timing diagram.




Autochange

SPFC system supports autochange naturally as the drive starts all the pump. Autochange functionality in SPFC is similar to autochange function in PFC except that autochange with auxiliary motor is not applicable for SPFC. See section [Autochange](#) on 126.

In autochange, two pumps meet the flow consumption for long term running and the 3rd pump is reserved for shifting.

Example of a 3-pump constant pressure water supply application:



Pump 1 - connected to Motor 1





Pump 2 - connected to Motor 2

Pump 3 - connected to Motor 3

Flow consumption versus pump status			
Consumption	Pump 1	Pump 2	Pump 3
Low	VSD	Off	Off
▶ Normal	DOL	VSD	Off
↓	Off	DOL	VSD
Normal	VSD	DOL	Off
▶ Normal	DOL	VSD	Off
VSD	Variable Speed Drive (yellow colour connecting line in the figure). Controlled by drive, tuning the output speed according to PID control.		
DOL	Direct On Line (red colour connecting line in the figure). Pump is running at fixed motor nominal speed.		
Off	Off-line. Pump stops.		

Parameter Settings



To enable the SPFC macro, navigate to :

- **Main menu**  → **Connection macro**  → **SPFC**
or
- **Main menu**  → **Complete parameter list**  parameter **96.04 Macro select** → [18] **SPFC**.

The following default values are used for the SPFC macro:

No.	Value	No.	Value
10.24	7 = <i>Running</i>	22.73	0 = <i>Not used</i>
10.27	45 = <i>PFC1</i>	22.74	0 = <i>Not used</i>
10.30	46 = <i>PFC2</i>	23.11	6 = <i>DI5</i>
12.17	0	28.11	1 = <i>AI1 scaled</i>
12.20	50.0	28.15	16 = <i>PID</i>
13.12	2 = <i>Output frequency</i>	28.22	0 = <i>Always off</i>
13.18	50.0	28.23	0 = <i>Always off</i>
19.11	5 = <i>DI3</i>	28.71	0 = <i>Acc/Dec time 1</i>
19.17	0 = <i>No</i>	30.11	-1500 rpm
20.01	1 = <i>In1 Start</i>	31.01	1 = <i>Inactive (true)</i>
20.03	2 = <i>DI1</i>	31.02	0 = <i>Fault</i>
20.04	0 = <i>Always off</i>	40.07	2 = <i>On when drive running</i>
20.05	0 = <i>Always off</i>	40.16	11 = <i>AI1 percent</i>
20.06	1 = <i>In1 Start</i>	40.17	0 = <i>Not selected</i>
20.08	7 = <i>DI6</i>	40.19	0 = <i>Not selected</i>
20.09	0 = <i>Always off</i>	40.20	0 = <i>Not selected</i>
20.12	3 = <i>DI2</i>	40.32	2.50
20.19	1 = <i>Selected</i>	40.33	3.0
21.03	0 = <i>Coast</i>	76.21	2 = <i>SPFC</i>
22.11	16 = <i>PID</i>	76.25	2
22.18	16 = <i>PID</i>	76.27	2
22.22	0 = <i>Always off</i>	99.04	0 = <i>Scalar</i>
22.23	0 = <i>Always off</i>		

SPFC circuit diagram



Default control connections for the SPFC macro

X1 Reference voltage and analog inputs and outputs		
1	SCR	Signal cable shield (screen)
2	AI1	PID setpoint, 0...10 V ^{1) 5)} ; see 40.16
3	AGND	Analog input circuit, common
4	+10V	10 V DC reference voltage
5	AI2	PID feedback, 4...20 mA ^{1) 5)} ; see 40.08
6	AGND	Analog input circuit, common
7	AO1	Output frequency: 0...20 mA ⁶⁾ ; see 13.12
8	AO2	Motor current, 0...20 mA ⁶⁾ ; see 13.22
9	AGND	Analog output circuit common

1...10 kohm

Max. 500 ohm

2)

X2, X3 Aux. voltage output and programmable digital inputs		
10	+24V	Aux. voltage output +24 V DC, max. 250 mA ⁴⁾
11	DGND	Aux. voltage output common
12	DCOM	Digital input common for all
13	DI1	Stop (0) / Start (1) (EXT 1) ⁵⁾ ; see 20.03
14	DI2	Run enable ⁵⁾ ; see 20.12 (if 0, drive stops).
15	DI3	EXT1 (0) / EXT 2 (1) ⁵⁾ ; see 19.11
16	DI4	Not configured
17	DI5	Not configured
18	DI6	Stop (0) / Start (1) (EXT 2); see 20.04

3)

X6, X7, X8 Relay outputs		
19	RO1C	Running ⁶⁾ ; see 10.24 250 V AC / 30 V DC 2 A
20	RO1A	
21	RO1B	
22	RO2C	PFC1 (1st auxiliary pump) ⁶⁾ ; see 10.27 250 V AC / 30 V DC 2 A
23	RO2A	
24	RO2B	
25	RO3C	PFC2 (2nd auxiliary pump) ⁶⁾ ; see 10.30 250 V AC / 30 V DC 2 A
26	RO3A	
27	RO3B	

X5 Built-in fieldbus		
29	B+	Internal Modbus RTU (EIA-485). See <i>Fieldbus control through the embedded fieldbus interface (EFB)</i> .
30	A-	
31	DGND	

(Frame R0...R2)		
S100	TERM&BIAS	Termination resistor and bias resistor switch

(Frame R3...R8)		
S100	TERM	Termination resistor switch
S200	BIAS	Bias resistor switch

Safety torque off			
X4		R0...R2	R3...R
R3...R8	33	-	OUT1
	34	SGND	OUT2
	35	OUT1	SGND
	36	IN1	IN1
	37	IN2	IN2

3)

X10 24 V AC/DC (frames R6...R8 only)		
40	24 V AC/DC- in	24 V AC/DC input, for control unit power supply when external main power is disconnected.
41	24 V AC/DC+ in	

X11 Redundant auxiliary voltage output (frames R0...R2)		
42	+24 V	Aux. voltage output +24 V DC, max. 250 mA ⁴⁾
43	DGND	Aux. voltage output common
44	DCOM	Digital input common for all

Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

1) The signal source is powered externally. See the manufacturer's instructions. To use sensors supplied by the drive aux. voltage output, see chapter *Electrical installation*, section *Connection examples of two-wire and three-wire sensors* in the Hardware manual of the drive.

2) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.

3) Connected with jumpers at the factory.

4) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).

5) Input signal

6) Input signal

7) For R0...R2 frames only


For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

Pharma macro

The various machines used in the pharmaceutical industry, e.g. Agitators, mixers, centrifuges, etc. are driven by motors which are controlled by drives. You can use the Pharma macro to automatically configure the basic drive parameters required to control these machines. The following settings are configured automatically with this macro:

- Start, stop, and multiple constant speed selections
- Ramp time
- Motor control
- Relay output
- Analog output


The below figure explains how a drive is connected to a motor in a reactor.



To enable the Pharma macro, navigate to :

- **Main menu** \equiv \rightarrow **Connection macro** \rightarrow **Pharma**
- or
- **Main menu** \equiv \rightarrow **Complete parameter list** \rightarrow parameter **96.04 Macro select** \rightarrow [19] [Pharma Application](#).

Default control connections for the Pharma macro



Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) Current [0(4)...20 mA, $R_{in} < 500$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.15 AI1 unit selection*.
- 2) Current [0(4)...20 mA, $R_{in} = 100$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.25 AI2 unit selection*.
- 3) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2-RO3).
- 4) The constant speed is set based on the following combination of sources:

Source defined by No.22.22	Source defined by No.22.23	Source defined by par.22.24	Constant speed active	Value
0	0	0	Set speed through AI1	-
1	0	0	<i>Constant speed 1</i>	600
0	1	0	<i>Constant speed 2</i>	900
0	0	1	<i>Constant speed 4</i>	1480

- 5) Connected with jumpers at the factory.
- 6) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 7) Input signal
- 8) Output signal
- 9) For R0...R2 frames only

In addition, some inputs and settings are set automatically as follows:

No.	Name (Input/Setting)	Value
20.01	<i>Ext1 commands</i>	4 = <i>In1P Start; In2 Stop</i>
21.03	<i>Stop mode</i>	1 = <i>Ramp</i>
23.11	<i>Ramp set selection</i>	0 = <i>Acc/Dec time 1</i>
23.12	<i>Acceleration time 1</i>	300 s
23.13	<i>Deceleration time 1</i>	300 s
99.04	<i>Motor control mode</i>	1 = <i>Vector</i>


For information on cable connection and drive operation, see *Control Connections* in the *Hardware manual (3AXD50000044998)*.

Plastic extrusion macro

Plastic extrusion in a plastic industry is a process of converting plastic materials from solid to liquid states and reconstituting them as finished components.

The below diagram shows the different process involved in a plastic extrusion.

Basic plastic extrusion block diagram




The plastic granules (in solid state) are fed as input which then goes through various process in the extruder machine to get the desired plastic product as output. The extruder operates with five to six motors and drives, depending on the type of extruder machine.

The Plastic extrusion macro is suitable for the drives used in plastic extrusion industry.

To enable the macro, navigate to:

- **Main menu** \equiv \rightarrow **Connection macro** \rightarrow **Plastic extrusion** 
- or
- **Main menu** \equiv \rightarrow **Complete parameter list** \rightarrow parameter **96.04 Macro select** \rightarrow [20] [Plastic Extrusion](#).

Default control connections for the ABB Plastic extrusion macro



Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) Current [0(4)...20 mA, $R_{in} < 500 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input as selected with parameter *12.15 AI1 unit selection*.
- 2) Current [0(4)...20 mA, $R_{in} = 100 \text{ ohm}$] or voltage [0(2)...10 V, $R_{in} > 200 \text{ kohm}$] input as selected with parameter *12.25 AI2 unit selection*.
- 3) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3).
- 4) Connected with jumpers at the factory.
- 5) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 6) Can be used to set up pressure alarm warning.
- 7) Can be used for cold start prevention with connection to 'temperature reached' output of temperature controller or PLC
- 8) Input signal
- 9) Output signal
- 10) For R0...R2 frames only

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD50000044998)*.

Additional Notes

- Some inputs and settings are set automatically as follows:

No.	Name (Input/Setting)	Value
20.01	<i>Ext1 commands</i>	<i>In1 Start</i>
21.03	<i>Stop mode</i>	<i>Ramp</i>

- As per the default settings, when the AI1 reference is at any value, the drive can be started. If you want to enable the drive to start the motor only when the AI reference is below minimum value, set the parameter as follows:


No.	Name (Input/Setting)	Value
32.07	<i>Supervision 1 signal</i>	<i>AI1</i>
32.09	<i>Supervision 1 low</i>	1.00V
32.05	<i>Supervision 1 function</i>	<i>Low</i>
20.19	<i>Enable start command</i>	<i>Supervision 1</i>

When the extruder is jammed and the motor is stopped, you can use these settings to prevent the motor to start with existing AI reference. This helps to prevent damage of the screw in the extruder.

Jigar macro

The Jigar machine is a machine used in the textile industry. The ABB Jigar macro is suitable for the Jigar machine and automatically configures the drive parameters required for Jigar machine applications.

Jigar machine has two main rollers controlled by two separate drive. If one act as winder and the other act as unwinder and vice versa.



Jigar machine sequence

The Jigar machine has two operation sequences:

1. The fabric rolls on the first roller and passes it to the coloring section. In the coloring section, the fabric winds to the second roller.
2. Once the second roller fills, the process reverses and the second roller starts unwinding and the first roller winds the fabric.


	Machine sequence 1		Machine sequence 2	
	Drive 1 (Winder)	Drive 2 (Unwinder)	Drive 2 (Winder)	Drive 1 (Unwinder)
Unwinding	<i>Speed</i> / Forward direction		<i>Speed</i> / Forward direction	
Winding		<i>Torque</i> mode - Reverse direction		<i>Torque</i> mode - Reverse direction

To enable the macro, navigate to:

- **Main menu** \equiv \rightarrow **Connection macro** $|/0$ \rightarrow **Jigar**
or

Main menu \equiv \rightarrow **Complete parameter list** \rightarrow parameter **96.04 Macro select** \rightarrow [30] **Jigar**.

Default control connections for the ABB Jigar macro



Terminal sizes

- (frames R0...R8): 0.14...1.5 mm² (all terminals)
- Tightening torques: 0.5...0.6 N·m (0.4 lbf·ft)

Notes

- 1) Current [0(4)...20 mA, $R_{in} < 500$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.15 AI1 unit selection*.
- 2) Current [0(4)...20 mA, $R_{in} = 100$ ohm] or voltage [0(2)...10 V, $R_{in} > 200$ kohm] input as selected with parameter *12.25 AI2 unit selection*.
- 3) Total load capacity of the auxiliary voltage output +24V (X2:10) = 6.0 W (250 mA / 24 V). User can use this source for either of the I/O connections (DI1... DI2- RO1 or DI3...DI6 - RO2~RO3).
- 4) Connected with jumpers at the factory.
- 5) Ground the outer shield of the cable 360 degrees under the grounding clamp on the grounding shelf for the control cables.
- 6) Can be used to set up pressure alarm warning.
- 7) Can be used for cold start prevention with connection to 'temperature reached' output of temperature controller or PLC
- 8) Input signal
- 9) Output signal
- 10) For R0...R2 frames only
- 11) The start in forward direction is connected to digital input DI1 and the start/stop in reverse direction is connected to digital input DI2.
- 12) The start is connected to digital input DI1 and the torque reversal is connected to digital input DI2.
- 13) EXT1 is configured for speed control and EXT2 is configured for torque control in both drive 1 and drive 2.

For information on cable connection and drive operation, see *Control Connections* in the *hardware manual (3AXD5000044998)*.

Additional Notes

Some inputs and settings are set automatically as follows:

No.	Name (Input/Setting)	Value
12.20	<i>AI1 scaled at AI1 max</i>	1500.000
12.30	<i>AI2 scaled at AI2 max</i>	100.000
19.11	<i>Ext1/Ext2 selection</i>	<i>DI3</i>
19.14	<i>Ext2 control mode</i>	<i>Torque</i>
20.01	<i>Ext1 commands</i>	<i>In1 Start fwd; In2 Start rev</i>
20.06	<i>Ext2 commands</i>	<i>In1 Start</i>
20.08	<i>Ext2 in1 source</i>	<i>DI1</i>
22.22	<i>Constant speed sel1</i>	<i>Always off</i>
22.23	<i>Constant speed sel2</i>	<i>Always off</i>
23.11	<i>Ramp set selection</i>	<i>Acc/Dec time 1</i>
26.11	<i>Torque ref1 source</i>	<i>AI2 scaled</i>
26.20	<i>Torque reversal</i>	<i>DI2</i>
99.04	<i>Motor control mode</i>	<i>Vector</i>

Parameter default values for different application macros

The default values listed in the [Parameters](#) table on page 159 are applicable for ABB standard macro (factory macro). The default values may differ for other macros. The different default values for each application macros are listed in the below table.

Parameter	96.04 Macro select			
	ABB standard (1)	ABB standard (vector) (17)	Torque control (26)	3-wire (11)
10.24 RO1 source	2 = Ready run	2 = Ready run	2 = Ready run	2 = Ready run
10.27 RO2 source	7 = Running	7 = Running	7 = Running	7 = Running
10.30 RO3 source	15 = Fault (-1)	15 = Fault (-1)	15 = Fault (-1)	15 = Fault (-1)
12.20 AI1 scaled at AI1 max	50.000	1500.000	1500.000	50.000
12.30 AI2 scaled at AI2 min	50.000	1500.000	100.000	50.000
13.12 AO1 source	2 = Output frequency	1 = Motor speed used	1 = Motor speed used	2 = Output frequency
13.18 AO1 source max	50.0	1500.0	1500.0	50.0
19.11 Ext1/Ext2 selection	0 = EXT1	0 = EXT1	5 = DI3	0 = EXT1
19.14 Ext2 control mode	2 = Speed	2 = Speed	3 = Torque	2 = Speed
20.01 Ext1 commands	2 = In1 Start; In2 Dir	2 = In1 Start; In2 Dir	2 = In1 Start; In2 Dir	2 = In1P Start; In2 Stop; In3 Dir
20.03 Ext1 in1 source	2 = DI1	2 = DI1	2 = DI1	2 = DI1
20.04 Ext1 in2 source	3 = DI2	3 = DI2	3 = DI2	3 = DI2
20.05 Ext1 in3 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.06 Ext2 commands	0 = Not selected	0 = Not selected	1 = In1 Start	1 = In1 Start
20.08 Ext2 in1 source	0 = Always off	0 = Always off	2 = DI1	2 = DI1
20.09 Ext2 in2 source	0 = Always off	0 = Always off	3 = DI2	3 = DI2
20.12 Run enable 1 source	1 = Selected	1 = Selected	7 = DI6	4 = DI3
21.03 Stop mode	1 = Coast	1 = Coast	1 = Coast	1 = Coast
22.11 Ext1 speed ref1	1 = AI1 scaled	1 = AI1 scaled	1 = AI1 scaled	1 = AI1 scaled
22.18 Ext2 speed ref1	0 = Zero	0 = Zero	0 = Zero	0 = Zero
22.21 Constant speed function	0b0001	0b0001	0b0000	
22.22 Constant speed sel1	4 = DI3	4 = DI3	5 = DI4	5 = DI4
22.23 Constant speed sel2	5 = DI4	5 = DI4	5 = DI4	6 = DI5
22.24 Constant speed sel3	0 = Always off	0 = Always off	0 = Always off	0 = Always off

Parameter	96.04 Macro select			
	ABB standard (1)	ABB standard (vector) (17)	Torque control (26)	3-wire (11)
22.27 Constant speed 2	600	600	600	600
22.29 Constant speed 4	1200	1200	1200	1200
22.71 Motor potentiometer	0 = Disabled	0 = Disabled	0 = Disabled	0 = Disabled
22.73 Motor potentiometer up	0 = Not used	0 = Not used	0 = Not used	0 = Not used
22.74 Motor potentiometer	0 = Not used	0 = Not used	0 = Not used	0 = Not used
23.11 Ramp set selection	6 = DI5	6 = DI5	6 = DI5	0 = Acc/Dec time 1
23.12 Acceleration time 1	20.000s	20.000s	20.000s	20.000s
23.13 Deceleration time 1	20.000s	20.000s	20.000s	20.000s
28.11 Ext1 frequency ref1	1 = AI1 scaled	1 = AI1 scaled	1 = AI1 scaled	1 = AI1 scaled
28.15 Ext1 frequency ref2	0 = Zero	0 = Zero	0 = Zero	0 = Zero
28.22 Constant frequency sel1	4 = DI3	4 = DI3	4 = DI3	5 = DI4
28.23 Constant frequency sel2	5 = DI4	5 = DI4	5 = DI4	6 = DI5
28.71 Freq ramp set selection	6 = DI5	6 = DI5	6 = DI5	0 = Acc/Dec time 1
30.10 Current limit actions	0 = No action	0 = No action	0 = No action	0 = No action
30.11 Minimum speed	-1500.00	-1500.00	-1500.00	-1500.00
31.11 Fault reset selection	0 = Not used	0 = Not used	0 = Not used	0 = Not used
40.07 Process PID operation mode	0 = Off	0 = Off	0 = Off	0 = Off
40.16 Set 1 setpoint 1 source	11 = AI1 percent	11 = AI1 percent	1 = AI1 percent	1 = AI1 percent
40.17 Set 1 setpoint 2 source	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.19 Set 1 internal setpoint sel1	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.20 Set 1 internal setpoint sel2	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.32 Set 1 gain	1.00	1.00	1.00	1.00
40.33 Set 1 integration time	60.0	60.0	60.0	60.0
76.21 PFC configuration	0 = Off	0 = Off	0 = Off	0 = Off
76.25 Number of motors	1	1	1	1
76.27 Max number of motors allowed	1	1	1	1
99.04 Motor control mode	1 = Scalar	0 = Vector	0 = Vector	1 = Scalar

Parameter	96.04 Macro select			
	Motor potentiometer (13)	Pharma Application (19)	PID (14)	Panel PID (15)
10.24 RO1 source	11 = Ready run	2 = Ready run	2 = Ready run	2 = Ready run
10.27 RO2 source	7 = Running	7 = Running	7 = Running	7 = Running
10.30 RO3 source	15 = Fault (-1)	14 = Fault	15 = Fault (-1)	15 = Fault (-1)
12.20 AI1 scaled at AI1 max	50.000	1500.000	50.000	50.000
12.30 AI2 scaled at AI2 min	50.000	50.000	50.000	50.000
13.12 AO1 source	2 = Output frequency	1 = Motor speed used	2 = Output frequency	2 = Output frequency
13.18 AO1 source max	50.0	1500.0	50.0	50.0
19.11 Ext1/Ext2 selection	0 = EXT1	0 = EXT1	0 = EXT1	0 = EXT1
19.14 Ext2 control mode	2 = Speed	2 = Speed	2 = Speed	2 = Speed
19.17 Local control mode	0 = No	0 = No	0 = No	0 = No
20.01 Ext1 commands	2 = In1 Start; In2 Dir	4 = In1P Start; In2 Stop	1 = In1 Start	1 = In1 Start
20.03 Ext1 in1 source	2 = DI1	2 = DI1	2 = DI1	2 = DI1
20.04 Ext1 in2 source	3 = DI2	3 = DI2	0 = Always off	0 = Always off
20.05 Ext1 in3 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.06 Ext2 commands	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
20.08 Ext2 in1 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.09 Ext2 in2 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.12 Run enable 1 source	7 = DI6	1 = Selected	6 = DI5	6 = DI5
21.03 Stop mode	1 = Coast	1 = Coast	0 = Coast	0 = Coast
22.11 Ext1 speed ref1	15 = Motor potentiometer	1 = AI1 scaled	16 = PID	16 = PID
22.18 Ext2 speed ref1	0 = Zero	0 = Zero	0 = Zero	0 = Zero
22.21 Constant speed function	0b000	0b0001	0b0000	0b0000
22.22 Constant speed sel1	6 = DI5	4 = DI3	5 = DI4	5 = DI4
22.23 Constant speed sel2	0 = Always off	5 = DI4	0 = Always off	0 = Always off
22.24 Constant speed sel3	0 = Always off	5 = DI5	0 = Always off	0 = Always off
22.26 Constant speed 1	300	600	300	300
22.27 Constant speed 2	600	900	600	600

Parameter	96.04 Macro select			
	Motor potentiometer (13)	Pharma Application (19)	PID (14)	Panel PID (15)
22.29 Constant speed 4	1200	1480	1200	1200
22.71 Motor potentiometer function	1 = Enabled (init at stop /power-	0 = Disabled	0 = Disabled	0 = Disabled
22.73 Motor potentiometer up source	4 = DI3	0 = Not used	0 = Not used	0 = Not used
22.74 Motor potentiometer down source	5 = DI4	0 = Not used	0 = Not used	0 = Not used
23.11 Ramp set selection	0 = Acc/Dec time 1	0 = Acc/Dec time 1	0 = Acc/Dec time 1	0 = Acc/Dec time 1
23.12 Acceleration time 1	20.000s	300s	20.000s	20.000s
23.13 Deceleration time 1	20.000s	300s	20.000s	20.000s
28.11 Ext1 frequency ref1	15 = Motor potentiometer	1 = AI1 scaled	16 = PID	16 = PID
28.15 Ext1 frequency ref2	0 = Zero	0 = Zero	0 = Zero	0 = Zero
28.22 Constant frequency sel1	6 = DI5	4 = DI3	5 = DI4	5 = DI4
28.23 Constant frequency sel2	0 = Always off	5 = DI4	0 = Always off	0 = Always off
28.71 Freq ramp set selection	0 = Acc/Dec time 1	6 = DI5	0 = Acc/Dec time 1	0 = Acc/Dec time 1
30.10 Current limit actions	0 = No action	0 = No action	0 = No action	0 = No action
30.11 Minimum speed	-1500.00	-1500.00	-1500.00	-1500.00
31.11 Fault reset selection	0 = Not used	0 = Not used	0 = Not used	0 = Not used
40.07 Process PID operation mode	0 = Off	0 = Off	2 = On when drive running	2 = On when drive running
40.16 Set 1 setpoint 1 source	11 = AI1 percent	11 = AI1 percent	11 = AI1 percent	13 = Control panel (ref saved)
40.17 Set 1 setpoint 2 source	0 = Not selected	0 = Not selected	2 = Internal setpoint	0 = Not selected
40.19 Set 1 internal setpoint sel1	0 = Not selected	0 = Not selected	3 = DI2	0 = Not selected
40.20 Set 1 internal setpoint sel2	0 = Not selected	0 = Not selected	4 = DI3	0 = Not selected
40.32 Set 1 gain	1.00	1.00	1.00	1.00
40.33 Set 1 integration time	60.0	60.0	60.0	60.0
76.21 PFC configuration	0 = Off	0 = Off	0 = Off	0 = Off
76.25 Number of motors	1	1	1	1
76.27 Max number of motors allowed	1	1	1	1
99.04 Motor control mode	1 = Scalar	0 = Vector	1 = Scalar	1 = Scalar

Parameter	96.04 Macro select			
	PFC (16)	SPFC (18)	Plastic Extrusion (20)	Jigar (30)
10.24 RO1 source	7 = Running	7 = Running	11 = Zero speed	11 = Ready run
10.27 RO2 source	15 = Fault (-1)	43 = PFC1	7 = Running	7 = Running
10.30 RO3 source	46 = PFC2	46 = PFC2	14 = Fault	14 = Fault (-1)
12.20 AI1 scaled at AI1 max	50.000	50.000	1500.000	1500.000
12.30 AI2 scaled at AI2 max	50.000	50.000	50.000	100.000
13.12 AO1 source	2 = Output frequency	2 = Output frequency	1 = Motor speed used	1 = Output frequency
13.18 AO1 source max	50.0	50.0	1500.0	50.0
19.11 Ext1/Ext2 selection	1 = DI3	5 = DI3	0 = EXT1	0 = DI3
19.14 Ext2 control mode	2 = Speed	2 = Speed	2 = Speed	2 = Torque
19.17 Local control mode	0 = No	0 = No	1 = Yes	1 = No
20.01 Ext1 commands	1 = In1 Start	1 = In1 Start	1 = In1 Start	1 = In1 Start fwd; In2 Start rev
20.03 Ext1 in1 source	2 = DI1	2 = DI1	2 = DI1	2 = DI1
20.04 Ext1 in2 source	0 = Always off	0 = Always off	3 = DI2	3 = DI2
20.05 Ext1 in3 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.06 Ext2 commands	1 = In1 Start	1 = In1 Start	0 = Always off	0 = In1 Start
20.08 Ext2 in1 source	7 = DI6	7 = DI6	0 = Always off	0 = DI1
20.09 Ext2 in2 source	0 = Always off	0 = Always off	0 = Always off	0 = Always off
20.12 Run enable 1 source	3 = DI2	3 = DI2	1 = Selected	1 = Selected
21.03 Stop mode	0 = Coast	0 = Coast	1 = Ramp	1 = Coast
22.11 Ext1 speed ref1	1 = AI1 scaled	1 = AI1 scaled	1 = AI1 scaled	1 = AI1 scaled
22.18 Ext2 speed ref1	16 = PID	0 = Zero	0 = Zero	0 = Zero
22.21 Constant speed function	0b0001	0b0001	0b0001	0b0001
22.22 Constant speed sel1	0 = Always off	4 = DI3	4 = DI3	4 = Always off
22.23 Constant speed sel2	0 = Always off	5 = DI4	5 = DI4	5 = Always off
22.24 Constant speed sel3	0 = Always off	0 = Always off	0 = Always off	0 = Always off
22.26 Constant speed 1	300.00	300.00	300.00	300.00
22.27 Constant speed 2	600.00	600.00	600.00	600.00

Parameter	96.04 Macro select			Jigar (30)
	PFC (16)	SPFC (18)	Plastic Extrusion (20)	
22.29 Constant speed 4	1200.00	1200.00	1200.00	1200.00
22.71 Motor potentiometer function	0 = Disabled	0 = Disabled	0 = Disabled	0 = Disabled
22.73 Motor potentiometer up source	0 = Not used	0 = Not used	0 = Not used	0 = Not used
22.74 Motor potentiometer down source	0 = Not used	0 = Not used	0 = Not used	0 = Not used
23.11 Ramp set selection	0 = Acc/Dec time 1	6 = DI5	6 = DI5	6 = Acc/Dec time 1
23.12 Acceleration time 1	20.000s	20.000s	20.000s	20.000s
23.13 Deceleration time 1	20.000s	20.000s	20.000s	20.000s
26.11 Torque ref1 source	0 = Zero	0 = Zero	0 = Zero	2 = AI2 scaled
28.11 Ext1 frequency ref1	1 = AI1 scaled	1 = AI1 scaled	1 = AI1 scaled	1 = AI1 scaled
28.15 Ext1 frequency ref2	16 = PID	16 = PID	0 = Zero	0 = Zero
28.22 Constant frequency sel1	0 = Always off	0 = Always off	4 = DI3	4 = DI3
28.23 Constant frequency sel2	0 = Always off	0 = Always off	5 = DI4	5 = DI4
28.71 Freq ramp set selection	0 = Acc/Dec time 1	0 = Acc/Dec time 1	6 = DI5	6 = DI5
30.10 Current limit actions	0 = No action	0 = No action	1 = Warning	1 = No action
30.11 Minimum speed	-1500.00	-1500.00	0.00	0.00
31.11 Fault reset selection	0 = Not used	0 = Not used	0 = Not used	0 = Not used
40.07 Process PID operation mode	2 = On when drive running	2 = On when drive running	0 = Off	0 = Off
40.16 Set 1 setpoint 1 source	11 = AI1 percent	11 = AI1 percent	11 = AI1 percent	11 = AI1 percent
40.17 Set 1 setpoint 2 source	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.19 Set 1 internal setpoint sel1	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.20 Set 1 internal setpoint sel2	0 = Not selected	0 = Not selected	0 = Not selected	0 = Not selected
40.32 Set 1 gain	2.50	2.50	1.00	1.00
40.33 Set 1 integration time	3.0	3.0	60.0 s	60.0 s
76.21 PFC configuration	2 = PFC	2 = SPFC	0 = Off	0 = Off
76.25 Number of motors	2	2	1	1
76.27 Max number of motors allowed	2	2	1	1
99.04 Motor control mode	1 = Scalar	1 = Scalar	0 = Vector	0 = Vector



Parameters

What this chapter contains

The chapter describes the parameters, including actual signals of the control program.

The ACS560 parameter list uses long and short menu structure. ACS560 parameter list adopts long and short menu structure. The short menu displays common parameter list and the long menu displays complete parameter list. The long and short menus are adjusted by parameter 96.02 password. The default value is short menu [1].

Parameters	Input password	Long and short menu
96.02 password	1	Short menu
	2	Long menu

Terms and abbreviations

Term	Definition
Actual signal	Type of <i>parameter</i> that is the result of a measurement or calculation by the drive, or contains status information. Most actual signals are read-only, but some (especially counter-type actual signals) can be reset.
Def	(In the following table, shown on the same row as the parameter name) The default value of a <i>parameter</i> when used in the Factory macro. For information on other macro-specific parameter values, see chapter <i>Control macros</i> (page 99).
FbEq16	(In the following table, shown on the same row as the parameter range, or for each selection) 16-bit fieldbus equivalent: The scaling between the value shown on the panel and the integer used in communication when a 16-bit value is selected for transmission to an external system. A dash (-) indicates that the parameter is not accessible in 16-bit format. The corresponding 32-bit scalings are listed in chapter <i>Additional parameter data</i> (page 373).
Other	The value is taken from another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter.
Other [bit]	The value is taken from a specific bit in another parameter. Choosing "Other" displays a parameter list in which the user can specify the source parameter and bit.
Parameter	Either a user-adjustable operating instruction for the drive, or an <i>actual signal</i> .
p.u.	Per unit
[parameter number]	Value of the parameter

Summary of parameter groups

Group	Contents	Page
01 Actual values	Basic signals for monitoring the drive.	163
03 Input references	Values of references received from various sources.	166
04 Warnings and faults	Information on warnings and faults that occurred last.	167
05 Diagnostics	Various run-time-type counters and measurements related to drive maintenance.	168
06 Control and status words	Drive control and status words.	171
07 System info	Drive hardware and firmware information.	176
10 Standard DI, RO	Configuration of digital inputs and relay outputs.	177
11 Standard DIO, FI, FO	Configuration of the frequency input.	185
12 Standard AI	Configuration of standard analog inputs.	186
13 Standard AO	Configuration of standard analog outputs.	191
19 Operation mode	Selection of local and external control location sources and operating modes.	196
20 Start/stop/direction	Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection.	198
21 Start/stop mode	Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings.	207
22 Speed reference selection	Speed reference selection; motor potentiometer settings.	215
23 Speed reference ramp	Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive).	224
25 Speed control	Speed controller settings.	228
26 Torque reference chain	Settings for the torque reference chain.	233
28 Frequency reference chain	Settings for the frequency reference chain.	238
30 Limits	Drive operation limits.	249
31 Fault functions	Configuration of external events; selection of behavior of the drive upon fault situations.	256
32 Supervision	Configuration of signal supervision functions 1...6.	264
34 Timed functions	Configuration of the timed functions.	271
35 Motor thermal protection	Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration.	278
36 Load analyzer	Peak value and amplitude logger settings.	289
37 User load curve	Settings for user load curve.	290
40 Process PID set 1	Parameter values for process PID control.	293
41 Process PID set 2	A second set of parameter values for process PID control.	307
43 Brake chopper	Settings for the internal brake chopper.	310
44 Mechanical brake control	Configuration of mechanical brake control.	312
45 Energy efficiency	Settings for the energy saving calculators.	313
46 Monitoring/scaling settings	Speed supervision settings; actual signal filtering; general scaling settings.	317
47 Data storage	Data storage parameters that can be written to and read from using other parameters' source and target settings.	320

162 Parameters

Group	Contents	Page
49 Panel port communication	Communication settings for the control panel port on the drive.	321
50 Fieldbus adapter (FBA)	Fieldbus communication configuration.	324
51 FBA A settings	Fieldbus adapter A configuration.	328
52 FBA A data in	Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A.	329
53 FBA A data out	Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A.	330
58 Embedded fieldbus	Configuration of the embedded fieldbus (EFB) interface.	330
70 Override	Enabling/disabling of override function, override activation signal and override speed/frequency.	338
71 External PID1	Configuration of external PID.	340
76 PFC configuration	PFC (Pump and fan control) and Autochange configuration parameters. See also section Pump and Fan Control (PFC) macro on page 123.	343
77 PFC maintenance and monitoring	PFC (Pump and fan control) and Autochange configuration parameters. See also section Pump and Fan Control (PFC) macro on page 123.	349
95 HW configuration	Various hardware-related settings.	350
96 System	Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection.	352
97 Motor control	Switching frequency; slip gain; voltage reserve; flux braking; anti-cogging (signal injection); IR compensation.	359
98 User motor parameters	Motor values supplied by the user that are used in the motor model.	362
99 Motor data	Motor configuration settings.	363

Parameter listing

No.	Name/Value	Description	Def/FbEq16
01 Actual values		Basic signals for monitoring the drive. All parameters in this group are read-only unless otherwise noted. Note: Values of these actual signals are filtered with the filter time defined in group 46 Monitoring/scaling settings . The selection lists for parameters in other groups mean the raw value of the actual signal instead. For example, if a selection is "Output frequency" it does not point to the value of parameter 01.06 Output frequency but to the raw value.	
01.01	Motor speed used	Estimated motor speed. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed .	-
	-30000.00... 30000.00 rpm	Estimated motor speed.	See par. 46.01
01.02	Motor speed estimated	Estimated motor speed in rpm. A filter time constant for this signal can be defined by parameter 46.11 Filter time motor speed .	-
	-30000.00... 30000.00 rpm	Estimated motor speed.	See par. 46.01
01.03	Motor speed %	Motor speed in percent of the synchronous motor speed.	-
	-1000.00... 1000.00%	Motor speed.	10 = 1%
01.06	Output frequency	Estimated drive output frequency in Hz. A filter time constant for this signal can be defined by parameter 46.12 Filter time output frequency .	-
	-500.00...500.00 Hz	Estimated output frequency.	See par. 46.02
01.07	Motor current	Measured (absolute) motor current in A.	-
	0.00...30000.00 A	Motor current.	1 = 1 A
01.08	Motor current % of motor nom	Motor current (drive output current) in percent of the nominal motor current.	-
	0.0...1000.0%	Motor current.	1 = 1%
01.09	Motor current % of drive nom	Motor current (drive output current) in percent of the nominal drive current.	-
	0.0...1000.0%	Motor current.	1 = 1%
01.10	Motor torque	Motor torque in percent of the nominal motor torque. See also parameter 01.30 Nominal torque scale . A filter time constant for this signal can be defined by parameter 46.13 Filter time motor torque .	-
	-1600.0...1600.0%	Motor torque.	See par. 46.03
01.11	DC voltage	Measured DC link voltage.	-
	0.00...2000.00 V	DC link voltage.	10 = 1 V
01.13	Output voltage	Calculated motor voltage in V AC.	-
	0...2000 V	Motor voltage.	1 = 1 V

164 Parameters

No.	Name/Value	Description	Def/FbEq16
01.14	<i>Output power</i>	Drive output power. A filter time constant for this signal can be defined by parameter 46.14 Filter time power .	-
	-32768.00... 32767.00 kW	Output power.	See par. 46.04
01.15	<i>Output power % of motor nom</i>	Output power in percent of the nominal motor power.	-
	-300.00... 300.00%	Output power.	1 = 1%
01.16	<i>Output power % of drive nom</i>	Output power in percent of the nominal drive power.	-
	-300.00... 300.00%	Output power.	1 = 1%
01.17	<i>Motor shaft power</i>	Estimated mechanical power at motor shaft. The unit is selected by parameter 96.16 Unit selection .	-
	-32768.00... 32767.00 hp or kW	Motor shaft power.	See par. 46.04
01.18	<i>Inverter GWh counter</i>	Amount of energy that has passed through the drive (in either direction) in full gigawatt-hours. The minimum value is zero.	-
	0...65535 GWh	Energy in GWh.	1 = 1 GWh
01.19	<i>Inverter MWh counter</i>	Amount of energy that has passed through the drive (in either direction) in full megawatt-hours. Whenever the counter rolls over, 01.18 Inverter GWh counter is incremented. The minimum value is zero.	-
	0...1000 MWh	Energy in MWh.	1 = 1 MWh
01.20	<i>Inverter kWh counter</i>	Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. Whenever the counter rolls over, 01.19 Inverter MWh counter is incremented. The minimum value is zero.	-
	0...1000 kWh	Energy in kWh.	10 = 1 kWh
01.24	<i>Flux actual %</i>	Used flux reference in percent of nominal flux of motor.	-
	0...200%	Flux reference.	1 = 1%
01.30	<i>Nominal torque scale</i>	Torque that corresponds to 100% of nominal motor torque. The unit is selected by parameter 96.16 Unit selection . Note: This value is copied from parameter 99.12 Motor nominal torque if entered. Otherwise the value is calculated from other motor data.	-
	0.000...4000000 N·m or lb·ft	Nominal torque.	1 = 100 unit
01.31	<i>Ambient temperature</i>	Ambient temperature of the drive. Note: This parameter is applicable only for frames R6 or larger.	-
	°C or °F	Temperature	1 = 1 °
01.50	<i>Current hour kWh</i>	Current hour energy consumption. This is the energy of the last 60 minutes (not necessarily continuous) the drive has been running, not the energy of a calendar hour. The value is set to the value before the power cycle when the drive is again up and running.	-
	0.00... 1000000.00 kWh	Energy.	1 = 1 kWh

No.	Name/Value	Description	Def/FbEq16
01.51	<i>Previous hour kWh</i>	Previous hour energy consumption. The value <i>01.50 Current hour kWh</i> is stored here when its value has been cumulated for 60 minutes. The value is set to the value before the power cycle when the drive is again up and running.	-
	0.00... 1000000.00 kWh	Energy.	1 = 1 kWh
01.52	<i>Current day kWh</i>	Current day energy consumption. This is the energy of the last 24 hours (not necessarily continuous) the drive has been running, not the energy of a calendar day. The value is set to the value before the power cycle when the drive is again up and running.	-
	0.00... 1000000.00 kWh	Energy.	1 = 1 kWh
01.53	<i>Previous day kWh</i>	Previous day energy consumption. The value <i>01.52 Current day kWh</i> is stored here when its value has been cumulated for 24 hours. The value is set to the value before the power cycle when the drive is again up and running.	-
	0.00... 1000000.00 kWh	Energy.	1 = 1 kWh
01.54	<i>Cumulative inverter energy</i>	Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. The minimum value is zero.	-
	-200000000.0... 200000000.0 kWh	Energy in kWh.	10 = 1 kWh
01.55	<i>Inverter GWh counter (resettable)</i>	Amount of energy that has passed through the drive (in either direction) in full gigawatt-hours. The minimum value is zero. You can reset the value by setting it to zero. Resetting any of parameters <i>01.55...01.58</i> resets all of them.	-
	0...65535 GWh	Energy in GWh.	1 = 1 GWh
01.56	<i>Inverter MWh counter (resettable)</i>	Amount of energy that has passed through the drive (in either direction) in full megawatt-hours. Whenever the counter rolls over, <i>01.55 Inverter GWh counter (resettable)</i> is incremented. The minimum value is zero. You can reset the value by setting it to zero. Resetting any of parameters <i>01.55...01.58</i> resets all of them.	-
	0...1000 MWh	Energy in MWh.	1 = 1 MWh
01.57	<i>Inverter kWh counter (resettable)</i>	Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. Whenever the counter rolls over, <i>01.56 Inverter MWh counter (resettable)</i> is incremented. The minimum value is zero. You can reset the value by setting it to zero. Resetting any of parameters <i>01.55...01.58</i> resets all of them.	-
	0...1000 kWh	Energy in kWh.	10 = 1 kWh
01.58	<i>Inverter kWh counter (resettable)</i>	Amount of energy that has passed through the drive (in either direction) in full kilowatt-hours. The minimum value is zero. You can reset the value by setting it to zero. Resetting any of parameters <i>01.55...01.58</i> resets all of them.	-
	-200000000.0... 200000000.0 kWh	Energy in kWh.	10 = 1 kWh
01.61	<i>Abs motor speed used</i>	Absolute value of parameter <i>01.01 Motor speed used</i> .	-
	0.00... 30000.00 rpm	Estimated motor speed.	See par. 46.01

166 Parameters

No.	Name/Value	Description	Def/FbEq16
01.62	Abs motor speed %	Absolute value of parameter 01.03 Motor speed % .	-
	0.00... 1000.00%	Estimated motor speed.	10 = 1%
01.63	Abs output frequency	Absolute value of parameter 01.06 Output frequency .	-
	0.00...500.00 Hz	Estimated output frequency.	See par. 46.02
01.64	Abs motor torque	Absolute value of parameter 01.10 Motor torque .	-
	0.0...1600.0%	Motor torque.	See par. 46.03
01.65	Abs output power	Absolute value of parameter 01.14 Output power .	-
	0.00... 32767.00 kW	Output power.	1 = 1 kW
01.66	Abs output power % motor nom	Absolute value of parameter 01.15 Output power % of motor nom .	-
	0.00... 300.00%	Output power.	1 = 1%
01.67	Abs output power % drive nom	Absolute value of parameter 01.16 Output power % of drive nom .	-
	0.00... 300.00%	Output power.	1 = 1%
01.68	Abs motor shaft power	Absolute value of parameter 01.17 Motor shaft power .	-
	0.00... 32767.00 hp or kW	Motor shaft power.	1 = 1 kW or hp
03 Input references		Values of references received from various sources. All parameters in this group are read-only unless otherwise noted.	
03.01	Panel reference	Reference 1 given from the control panel or PC tool.	-
	-100000.00... 100000.00	Control panel or PC tool reference.	1 = 10
03.02	Panel reference remote	Reference 2 given from the control panel or PC tool.	-
	-100000.00... 100000.00	Control panel or PC tool reference.	1 = 10
03.05	FB A reference 1	Reference 1 received through fieldbus adapter A. See also chapter Fieldbus control through a fieldbus adapter (page 445).	-
	-100000.00... 100000.00	Reference 1 from fieldbus adapter A.	1 = 10
03.06	FB A reference 2	Reference 2 received through fieldbus adapter A.	-
	-100000.00... 100000.00	Reference 2 from fieldbus adapter A.	1 = 10
03.09	EFB reference 1	Scaled reference 1 received through the embedded fieldbus interface.	1 = 10
	-30000.00... 30000.00	Scaled reference 1 received through the embedded fieldbus interface.	1 = 10

No.	Name/Value	Description	Def/FbEq16
03.10	<i>EFB reference 2</i>	Scaled reference 2 received through the embedded fieldbus interface.	1 = 10
	-30000.00... 30000.00	Scaled reference 2 received through the embedded fieldbus interface.	1 = 10
04 Warnings and faults		Information on warnings and faults that occurred last. For explanations of individual warning and fault codes, see chapter <i>Fault tracing</i> . All parameters in this group are read-only unless otherwise noted.	
04.01	<i>Tripping fault</i>	Code of the 1st active fault (the fault that caused the current trip).	0x0000
	0x0000...0xffff	1st active fault.	1 = 1
04.02	<i>Active fault 2</i>	Code of the 2nd active fault.	0x0000
	0x0000...0xffff	2nd active fault.	1 = 1
04.03	<i>Active fault 3</i>	Code of the 3rd active fault.	0x0000
	0x0000...0xffff	3rd active fault.	1 = 1
04.06	<i>Active warning 1</i>	Code of the 1st active warning.	0x0000
	0x0000...0xffff	1st active warning.	1 = 1
04.07	<i>Active warning 2</i>	Code of the 2nd active warning.	0x0000
	0x0000...0xffff	2nd active warning.	1 = 1
04.08	<i>Active warning 3</i>	Code of the 3rd active warning.	0x0000
	0x0000...0xffff	3rd active warning.	1 = 1
04.11	<i>Latest fault</i>	Code of the 1st stored (non-active) fault.	0x0000
	0x0000...0xffff	1st stored fault.	1 = 1
04.12	<i>2nd latest fault</i>	Code of the 2nd stored (non-active) fault.	0x0000
	0x0000...0xffff	2nd stored fault.	1 = 1
04.13	<i>3rd latest fault</i>	Code of the 3rd stored (non-active) fault.	0x0000
	0x0000...0xffff	3rd stored fault.	1 = 1
04.16	<i>Latest warning</i>	Code of the 1st stored (non-active) warning.	0x0000
	0x0000...0xffff	1st stored warning.	1 = 1
04.17	<i>2nd latest warning</i>	Code of the 2nd stored (non-active) warning.	0x0000
	0x0000...0xffff	2nd stored warning.	1 = 1
04.18	<i>3rd latest warning</i>	Code of the 3rd stored (non-active) warning.	0x0000
	0x0000...0xffff	3rd stored warning.	1 = 1

No.	Name/Value	Description	Def/FbEq16															
04.40	<i>Event word 1</i>	Shows the user-defined event word. This word collects the status of the events (warnings, faults or pure events) selected by parameters 04.41...04.71 . This parameter is read-only.	-															
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>User bit 0</td> <td>1 = Event selected by parameter 04.41 is active</td> </tr> <tr> <td>1</td> <td>User bit 1</td> <td>1 = Event selected by parameter 04.43 is active</td> </tr> <tr> <td>...</td> <td>...</td> <td>...</td> </tr> <tr> <td>15</td> <td>User bit 15</td> <td>1 = Event selected by parameter 04.71 is active</td> </tr> </tbody> </table>				Bit	Name	Description	0	User bit 0	1 = Event selected by parameter 04.41 is active	1	User bit 1	1 = Event selected by parameter 04.43 is active	15	User bit 15	1 = Event selected by parameter 04.71 is active
Bit	Name	Description																
0	User bit 0	1 = Event selected by parameter 04.41 is active																
1	User bit 1	1 = Event selected by parameter 04.43 is active																
...																
15	User bit 15	1 = Event selected by parameter 04.71 is active																
	0000h...FFFFh	User-defined event word.	1 = 1															
04.41	<i>Event word 1 bit 0 code</i>	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 0 of 04.40 Event word 1 . The event codes are listed in chapter Fault tracing (page 387).	0x2310h															
	0000h...FFFFh	Code of event.	1 = 1															
04.43	<i>Event word 1 bit 1 code</i>	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 1 of 04.40 Event word 1 . The event codes are listed in chapter Fault tracing (page 387).	0x3210h															
	0000h...FFFFh	Code of event.	1 = 1															
04.45, 04.47, 04.49,															
04.71	<i>Event word 1 bit 15 code</i>	Selects the hexadecimal code of an event (warning, fault or pure event) whose status is shown as bit 15 of 04.40 Event word 1 . The event codes are listed in chapter Fault tracing (page 387).	0x2330h															
	0000h...FFFFh	Code of event.	1 = 1															
05 Diagnostics		Various run-time-type counters and measurements related to drive maintenance. All parameters in this group are read-only unless otherwise noted.																
05.01	<i>On-time counter</i>	On-time counter. The counter runs when the drive is powered.	0															
	0...65535 d	On-time counter.	1 = 1 d															
05.02	<i>Run-time counter</i>	Motor run-time counter. The counter runs when the inverter modulates.	0															
	0...65535 d	Motor run-time counter.	1 = 1 d															
05.03	<i>Hours run</i>	Corresponding parameter to 05.02 Run-time counter in hours, that is, 24 * 05.02 value + fractional part of a day.	-															
	0.0... 429496729.5 h	Hours.	1 = 1 h															
05.04	<i>Fan on-time counter</i>	Running time of the drive cooling fan. Can be reset from the control panel by keeping Reset down for over 3 seconds.	0															
	0...65535 d	Cooling fan run-time counter.	1 = 1 d															

No.	Name/Value	Description	Def/FbEq16																																				
05.10	<i>Control board temperature</i>	Measured temperature of the control board.	0																																				
	-100... 300 °C	Control board temperature in degrees Celsius or Fahrenheit.	1 = unit																																				
05.11	<i>Inverter temperature</i>	Estimated drive temperature in percent of fault limit. The fault limit varies according to the type of the drive. 0.0% = 0 °C (32 °F) 100.0% = Fault limit	0																																				
	-40.0... 160.0%	Drive temperature in percent.	1 = 1%																																				
05.20	<i>Diagnostic word 1</i>	Diagnostic word 1. For possible causes and remedies, see chapter <i>Fault tracing</i> .	0b0000																																				
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Any warning or fault</td> <td>Yes = Drive has generated a warning or tripped on a fault.</td> </tr> <tr> <td>1</td> <td>Any warning</td> <td>Yes = Drive has generated a warning.</td> </tr> <tr> <td>2</td> <td>Any fault</td> <td>Yes = Drive has tripped on a fault.</td> </tr> <tr> <td>3</td> <td>Reserved</td> <td></td> </tr> <tr> <td>4</td> <td>Overcurrent fit</td> <td>Yes = Drive has tripped on fault 2310 Overcurrent.</td> </tr> <tr> <td>5</td> <td>Reserved</td> <td></td> </tr> <tr> <td>6</td> <td>DC overvoltage</td> <td>Yes = Drive has tripped on fault 3210 DC link overvoltage.</td> </tr> <tr> <td>7</td> <td>DC undervoltage</td> <td>Yes = Drive has tripped on fault 3220 DC link undervoltage.</td> </tr> <tr> <td>8</td> <td>Reserved</td> <td></td> </tr> <tr> <td>9</td> <td>Device overtemp fit</td> <td>Yes = Drive has tripped on fault 4310 Excess temperature.</td> </tr> <tr> <td>10...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Value	0	Any warning or fault	Yes = Drive has generated a warning or tripped on a fault.	1	Any warning	Yes = Drive has generated a warning.	2	Any fault	Yes = Drive has tripped on a fault.	3	Reserved		4	Overcurrent fit	Yes = Drive has tripped on fault 2310 Overcurrent .	5	Reserved		6	DC overvoltage	Yes = Drive has tripped on fault 3210 DC link overvoltage .	7	DC undervoltage	Yes = Drive has tripped on fault 3220 DC link undervoltage .	8	Reserved		9	Device overtemp fit	Yes = Drive has tripped on fault 4310 Excess temperature .	10...15	Reserved	
Bit	Name	Value																																					
0	Any warning or fault	Yes = Drive has generated a warning or tripped on a fault.																																					
1	Any warning	Yes = Drive has generated a warning.																																					
2	Any fault	Yes = Drive has tripped on a fault.																																					
3	Reserved																																						
4	Overcurrent fit	Yes = Drive has tripped on fault 2310 Overcurrent .																																					
5	Reserved																																						
6	DC overvoltage	Yes = Drive has tripped on fault 3210 DC link overvoltage .																																					
7	DC undervoltage	Yes = Drive has tripped on fault 3220 DC link undervoltage .																																					
8	Reserved																																						
9	Device overtemp fit	Yes = Drive has tripped on fault 4310 Excess temperature .																																					
10...15	Reserved																																						
	0b0000...0b1111	Diagnostic word 1.	1 = 1																																				
05.21	<i>Diagnostic word 2</i>	Diagnostic word 2. For possible causes and remedies, see chapter <i>Fault tracing</i> .	0b0000																																				
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0...9</td> <td>Reserved</td> <td></td> </tr> <tr> <td>10</td> <td>Motor overtemperature fault</td> <td>Yes = Drive has tripped on fault 4981 External temperature 1 or 4982 External temperature 2.</td> </tr> <tr> <td>11...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Value	0...9	Reserved		10	Motor overtemperature fault	Yes = Drive has tripped on fault 4981 External temperature 1 or 4982 External temperature 2 .	11...15	Reserved																									
Bit	Name	Value																																					
0...9	Reserved																																						
10	Motor overtemperature fault	Yes = Drive has tripped on fault 4981 External temperature 1 or 4982 External temperature 2 .																																					
11...15	Reserved																																						
	0b0000...0b1111	Diagnostic word 2.	1 = 1																																				
05.22	<i>Diagnostic word 3</i>	Diagnostic word 3. For possible causes and remedies, see chapter <i>Fault tracing</i> .	0b0000																																				
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0...8</td> <td>Reserved.</td> <td></td> </tr> <tr> <td>9</td> <td>kWh pulse</td> <td>1 = kWh pulse is active.</td> </tr> <tr> <td>10</td> <td>Reserved.</td> <td></td> </tr> <tr> <td>11</td> <td>Fan command.</td> <td>1 = Drive fan is rotating above idle speed.</td> </tr> <tr> <td>12...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Value	0...8	Reserved.		9	kWh pulse	1 = kWh pulse is active.	10	Reserved.		11	Fan command.	1 = Drive fan is rotating above idle speed.	12...15	Reserved																			
Bit	Name	Value																																					
0...8	Reserved.																																						
9	kWh pulse	1 = kWh pulse is active.																																					
10	Reserved.																																						
11	Fan command.	1 = Drive fan is rotating above idle speed.																																					
12...15	Reserved																																						
	0b0000...0b1111	Diagnostic word 3.	1 = 1																																				
05.80	<i>Motor speed at fault</i>	Displays the motor speed (<i>01.01</i>) at which fault occurred.	-																																				
	-30000.00... 30000.00 rpm	Motor speed at fault.	See par. 46.01																																				

170 Parameters

No.	Name/Value	Description	Def/FbEq16																																		
05.81	<i>Output frequency at fault</i>	Displays the output frequency (01.06) at which fault occurred.	-																																		
	-500.00...500.00 Hz	Output frequency at fault.	See par. 46.02																																		
05.82	<i>DC voltage at fault</i>	Displays the DC link volt age (01.11) at which fault occurred.	-																																		
	0.00...2000.00 V	DC voltage at fault.	10 = 1 V																																		
05.83	<i>Motor current at fault</i>	Displays the motor current (01.07) at which fault occurred.	-																																		
05.84	<i>Motor torque at fault</i>	Displays the motor torque (01.10) at which fault occurred.	-																																		
	-1600.0...1600.0%	Motor torque at fault.	See par. 46.03																																		
05.85	<i>Main status word at fault</i>	Displays the main status word (06.11) at which fault occurred. For the bit list, see parameter 06.11 <i>Main status word</i> .	0x0000																																		
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> </tr> </thead> <tbody> <tr><td>0</td><td>Ready to switch ON</td></tr> <tr><td>1</td><td>Ready run</td></tr> <tr><td>2</td><td>Ready ref</td></tr> <tr><td>3</td><td>Tripped</td></tr> <tr><td>4</td><td>Not in use</td></tr> <tr><td>5</td><td>Not in use</td></tr> <tr><td>6</td><td>Not in use</td></tr> <tr><td>7</td><td>Warning</td></tr> <tr><td>8</td><td>Modulating</td></tr> <tr><td>9</td><td>Remote</td></tr> <tr><td>10</td><td>Net OK</td></tr> <tr><td>11</td><td>User bit 0</td></tr> <tr><td>12</td><td>User bit 1</td></tr> <tr><td>13</td><td>User bit 2</td></tr> <tr><td>14</td><td>Charging</td></tr> <tr><td>15</td><td>User bit 3</td></tr> </tbody> </table>	Bit	Name	0	Ready to switch ON	1	Ready run	2	Ready ref	3	Tripped	4	Not in use	5	Not in use	6	Not in use	7	Warning	8	Modulating	9	Remote	10	Net OK	11	User bit 0	12	User bit 1	13	User bit 2	14	Charging	15	User bit 3	
Bit	Name																																				
0	Ready to switch ON																																				
1	Ready run																																				
2	Ready ref																																				
3	Tripped																																				
4	Not in use																																				
5	Not in use																																				
6	Not in use																																				
7	Warning																																				
8	Modulating																																				
9	Remote																																				
10	Net OK																																				
11	User bit 0																																				
12	User bit 1																																				
13	User bit 2																																				
14	Charging																																				
15	User bit 3																																				
	0x0000...0xffff	Main status word at fault.	1 = 1																																		
05.86	<i>DI delayed status at fault</i>	Displays the DI delayed status (10.02) at which fault occurred. For the bit list, see parameter 10.02 <i>DI delayed status</i> .	0b0000																																		
	0b0000...0b1111	DI delayed status at fault.	1 = 1																																		
05.87	<i>Inverter temperature at fault</i>	Displays the inverter temperature (05.11) at which fault occurred.	-																																		
	-40...160°C	Inverter temperature at fault.	1 = 1°C																																		
05.88	<i>Reference used at fault</i>	Displays the reference used (28.01/23.01) at which fault occurred. The type of the reference depends on the selected operation mode (19.01).	-																																		

No.	Name/Value	Description	Def/FbEq16																																		
06 Control and status words		Drive control and status words.																																			
06.01	<i>Main control word</i>	<p>The main control word of the drive. This parameter shows the control signals as received from the selected sources (such as digital inputs, the fieldbus interfaces and the application program).</p> <p>For the bit descriptions see page 452. The related status word and state diagram are presented on pages 454 and 455 respectively.</p> <p>This parameter is read-only.</p> <table border="1" data-bbox="463 459 777 916"> <thead> <tr> <th>Bit</th> <th>Name</th> </tr> </thead> <tbody> <tr><td>0</td><td><i>Off1 control</i></td></tr> <tr><td>1</td><td><i>Off2 control</i></td></tr> <tr><td>2</td><td><i>Off3 control</i></td></tr> <tr><td>3</td><td><i>Run</i></td></tr> <tr><td>4</td><td><i>Ramp out zero</i></td></tr> <tr><td>5</td><td><i>Ramp hold</i></td></tr> <tr><td>6</td><td><i>Ramp in zero</i></td></tr> <tr><td>7</td><td><i>Reset</i></td></tr> <tr><td>8</td><td><i>Inching 1</i></td></tr> <tr><td>9</td><td><i>Inching 2</i></td></tr> <tr><td>10</td><td><i>Remote cmd</i></td></tr> <tr><td>11</td><td><i>Ext ctrl loc</i></td></tr> <tr><td>12</td><td><i>User bit 0</i></td></tr> <tr><td>13</td><td><i>User bit 1</i></td></tr> <tr><td>14</td><td><i>User bit 2</i></td></tr> <tr><td>15</td><td><i>User bit 3</i></td></tr> </tbody> </table>	Bit	Name	0	<i>Off1 control</i>	1	<i>Off2 control</i>	2	<i>Off3 control</i>	3	<i>Run</i>	4	<i>Ramp out zero</i>	5	<i>Ramp hold</i>	6	<i>Ramp in zero</i>	7	<i>Reset</i>	8	<i>Inching 1</i>	9	<i>Inching 2</i>	10	<i>Remote cmd</i>	11	<i>Ext ctrl loc</i>	12	<i>User bit 0</i>	13	<i>User bit 1</i>	14	<i>User bit 2</i>	15	<i>User bit 3</i>	0x0000
Bit	Name																																				
0	<i>Off1 control</i>																																				
1	<i>Off2 control</i>																																				
2	<i>Off3 control</i>																																				
3	<i>Run</i>																																				
4	<i>Ramp out zero</i>																																				
5	<i>Ramp hold</i>																																				
6	<i>Ramp in zero</i>																																				
7	<i>Reset</i>																																				
8	<i>Inching 1</i>																																				
9	<i>Inching 2</i>																																				
10	<i>Remote cmd</i>																																				
11	<i>Ext ctrl loc</i>																																				
12	<i>User bit 0</i>																																				
13	<i>User bit 1</i>																																				
14	<i>User bit 2</i>																																				
15	<i>User bit 3</i>																																				
0x0000...0xffff		Main control word.	1 = 1																																		

172 Parameters

No.	Name/Value	Description	Def/FbEq16																																		
06.11	<i>Main status word</i>	<p>Main status word of the drive.</p> <p>For the bit descriptions see page 454. The related control word and state diagram are presented on pages 452 and 455 respectively.</p> <p>This parameter is read-only.</p>	0x0000																																		
<table border="1"> <thead> <tr> <th data-bbox="412 320 486 341">Bit</th> <th data-bbox="491 320 725 341">Name</th> </tr> </thead> <tbody> <tr><td data-bbox="412 349 486 370">0</td><td data-bbox="491 349 725 370"><i>Ready to switch ON</i></td></tr> <tr><td data-bbox="412 378 486 399">1</td><td data-bbox="491 378 725 399"><i>Ready run</i></td></tr> <tr><td data-bbox="412 406 486 427">2</td><td data-bbox="491 406 725 427"><i>Ready ref</i></td></tr> <tr><td data-bbox="412 435 486 456">3</td><td data-bbox="491 435 725 456"><i>Tripped</i></td></tr> <tr><td data-bbox="412 464 486 485">4</td><td data-bbox="491 464 725 485"><i>Off 2 inactive</i></td></tr> <tr><td data-bbox="412 493 486 513">5</td><td data-bbox="491 493 725 513"><i>Off 3 inactive</i></td></tr> <tr><td data-bbox="412 521 486 542">6</td><td data-bbox="491 521 725 542"><i>Switch-on inhibited</i></td></tr> <tr><td data-bbox="412 550 486 571">7</td><td data-bbox="491 550 725 571"><i>Warning</i></td></tr> <tr><td data-bbox="412 579 486 600">8</td><td data-bbox="491 579 725 600"><i>At setpoint</i></td></tr> <tr><td data-bbox="412 608 486 628">9</td><td data-bbox="491 608 725 628"><i>Remote</i></td></tr> <tr><td data-bbox="412 636 486 657">10</td><td data-bbox="491 636 725 657"><i>Above limit</i></td></tr> <tr><td data-bbox="412 665 486 686">11</td><td data-bbox="491 665 725 686"><i>User bit 0</i></td></tr> <tr><td data-bbox="412 694 486 715">12</td><td data-bbox="491 694 725 715"><i>User bit 1</i></td></tr> <tr><td data-bbox="412 722 486 743">13</td><td data-bbox="491 722 725 743"><i>User bit 2</i></td></tr> <tr><td data-bbox="412 751 486 772">14</td><td data-bbox="491 751 725 772"><i>User bit 3</i></td></tr> <tr><td data-bbox="412 780 486 801">15</td><td data-bbox="491 780 725 801"><i>Reserved</i></td></tr> </tbody> </table>				Bit	Name	0	<i>Ready to switch ON</i>	1	<i>Ready run</i>	2	<i>Ready ref</i>	3	<i>Tripped</i>	4	<i>Off 2 inactive</i>	5	<i>Off 3 inactive</i>	6	<i>Switch-on inhibited</i>	7	<i>Warning</i>	8	<i>At setpoint</i>	9	<i>Remote</i>	10	<i>Above limit</i>	11	<i>User bit 0</i>	12	<i>User bit 1</i>	13	<i>User bit 2</i>	14	<i>User bit 3</i>	15	<i>Reserved</i>
Bit	Name																																				
0	<i>Ready to switch ON</i>																																				
1	<i>Ready run</i>																																				
2	<i>Ready ref</i>																																				
3	<i>Tripped</i>																																				
4	<i>Off 2 inactive</i>																																				
5	<i>Off 3 inactive</i>																																				
6	<i>Switch-on inhibited</i>																																				
7	<i>Warning</i>																																				
8	<i>At setpoint</i>																																				
9	<i>Remote</i>																																				
10	<i>Above limit</i>																																				
11	<i>User bit 0</i>																																				
12	<i>User bit 1</i>																																				
13	<i>User bit 2</i>																																				
14	<i>User bit 3</i>																																				
15	<i>Reserved</i>																																				
0x0000...0xffff		Main status word.	1 = 1																																		

No.	Name/Value	Description	Def/FbEq16
06.16	<i>Drive status word 1</i>	Drive status word 1. This parameter is read-only.	0b0000
Bit	Name	Description	
0	Enabled	1 = Both run enable (see par. 20.12) and start enable (20.19) signals are present.	
1	Inhibited	1 = Start inhibited. To start the drive, the inhibiting signal (see par. 06.18) must be removed and the start signal cycled.	
2	DC charged	1 = DC circuit has been charged.	
3	Ready to start	1 = Drive is ready to receive a start command.	
4	Following reference	1 = Drive is ready to follow given reference.	
5	Started	1 = Drive has been started.	
6	Modulating	1 = Drive is modulating (output stage is being controlled).	
7	Limiting	1 = Any operating limit (speed, torque, etc.) is active.	
8	Local control	1 = Drive is in local control.	
9	Network control	1 = Drive is in <i>network control</i> (see page 17).	
10	Ext1 active	1 = Control location EXT1 active.	
11	Ext2 active	1 = Control location EXT2 active.	
12	Reserved		
13	Start request	1 = Start requested. 0 = When Enable to rotate signal (see par. 20.22) is 0 (rotating of the motor is disabled).	
14	Running	1 = Drive is controlling speed or frequency, in PID sleep or pre-magnetization.	
15	Reserved		
0b0000...0b1111		Drive status word 1.	1 = 1
06.17	<i>Drive status word 2</i>	Drive status word 2. This parameter is read-only.	0b0000
Bit	Name	Description	
0	Identification run done	1 = Motor identification (ID) run has been performed.	
1	Magnetized	1 = The motor has been magnetized.	
2	Torque control	1 = Torque control mode active.	
3	Speed control	1 = Speed control mode active.	
4	Reserved		
5	Safe reference active	1 = A "safe" reference is applied by functions such as parameters 49.05 and 50.02.	
6	Last speed active	1 = A "last speed" reference is applied by functions such as parameters 49.05 and 50.02.	
7...8	Reserved		
9	Jogging active	1 = Jogging enable signal is on.	
10	Above limit	1 = Actual speed, frequency or torque equals or exceeds limit (defined by parameters 46.31...46.33). Valid in both directions of rotation.	
11...12	Reserved		
13	Start delay active	1 = Start..... delay (par. 21.22) active.	
14...15	Reserved		
0b0000...0b1111		Drive status word 2.	1 = 1

174 Parameters

No.	Name/Value	Description	Def/FbEq16																																																			
06.18	<i>Start inhibit status word</i>	Start inhibit status word. This word specifies the source of the inhibiting signal that is preventing the drive from starting. The conditions marked with an asterisk (*) only require that the start command is cycled. In all other instances, the inhibiting condition must be removed first. See also parameter 06.16 Drive status word 1 , bit 1. This parameter is read-only.	0b0000																																																			
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Not ready run</td> <td>1 = DC voltage is missing or drive has not been parametrized correctly. Check the parameters in groups 95 and 99.</td> </tr> <tr> <td>1</td> <td>Ctrl location changed</td> <td>* 1 = Control location has changed.</td> </tr> <tr> <td>2</td> <td>SSW inhibit</td> <td>1 = Control program is keeping itself in inhibited state.</td> </tr> <tr> <td>3</td> <td>Fault reset</td> <td>* 1 = A fault has been reset.</td> </tr> <tr> <td>4</td> <td>Lost start enable</td> <td>1 = Start enable signal missing.</td> </tr> <tr> <td>5</td> <td>Lost run enable</td> <td>1 = Run enable signal missing.</td> </tr> <tr> <td>6</td> <td>Reserved</td> <td></td> </tr> <tr> <td>7</td> <td>STO</td> <td>1 = Safe torque off function active.</td> </tr> <tr> <td>8</td> <td>Current calibration ended</td> <td>* 1 = Current calibration routine has finished.</td> </tr> <tr> <td>9</td> <td>ID run ended</td> <td>* 1 = Motor identification run has finished.</td> </tr> <tr> <td>10</td> <td>Reserved</td> <td></td> </tr> <tr> <td>11</td> <td>Em Off1</td> <td>1 = Emergency stop signal (mode off1).</td> </tr> <tr> <td>12</td> <td>Em Off2</td> <td>1 = Emergency stop signal (mode off2).</td> </tr> <tr> <td>13</td> <td>Em Off3</td> <td>1 = Emergency stop signal (mode off3).</td> </tr> <tr> <td>14</td> <td>Auto reset inhibit</td> <td>1 = The autoreset function is inhibiting operation.</td> </tr> <tr> <td>15</td> <td>Jogging active</td> <td>1 = The jogging enable signal is inhibiting operation.</td> </tr> </tbody> </table>				Bit	Name	Description	0	Not ready run	1 = DC voltage is missing or drive has not been parametrized correctly. Check the parameters in groups 95 and 99.	1	Ctrl location changed	* 1 = Control location has changed.	2	SSW inhibit	1 = Control program is keeping itself in inhibited state.	3	Fault reset	* 1 = A fault has been reset.	4	Lost start enable	1 = Start enable signal missing.	5	Lost run enable	1 = Run enable signal missing.	6	Reserved		7	STO	1 = Safe torque off function active.	8	Current calibration ended	* 1 = Current calibration routine has finished.	9	ID run ended	* 1 = Motor identification run has finished.	10	Reserved		11	Em Off1	1 = Emergency stop signal (mode off1).	12	Em Off2	1 = Emergency stop signal (mode off2).	13	Em Off3	1 = Emergency stop signal (mode off3).	14	Auto reset inhibit	1 = The autoreset function is inhibiting operation.	15	Jogging active	1 = The jogging enable signal is inhibiting operation.
Bit	Name	Description																																																				
0	Not ready run	1 = DC voltage is missing or drive has not been parametrized correctly. Check the parameters in groups 95 and 99.																																																				
1	Ctrl location changed	* 1 = Control location has changed.																																																				
2	SSW inhibit	1 = Control program is keeping itself in inhibited state.																																																				
3	Fault reset	* 1 = A fault has been reset.																																																				
4	Lost start enable	1 = Start enable signal missing.																																																				
5	Lost run enable	1 = Run enable signal missing.																																																				
6	Reserved																																																					
7	STO	1 = Safe torque off function active.																																																				
8	Current calibration ended	* 1 = Current calibration routine has finished.																																																				
9	ID run ended	* 1 = Motor identification run has finished.																																																				
10	Reserved																																																					
11	Em Off1	1 = Emergency stop signal (mode off1).																																																				
12	Em Off2	1 = Emergency stop signal (mode off2).																																																				
13	Em Off3	1 = Emergency stop signal (mode off3).																																																				
14	Auto reset inhibit	1 = The autoreset function is inhibiting operation.																																																				
15	Jogging active	1 = The jogging enable signal is inhibiting operation.																																																				
0b0000...0b1111		Start inhibit status word.	1 = 1																																																			
06.19	<i>Speed control status word</i>	Speed control status word. This parameter is read-only.	0b0000																																																			
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Zero speed</td> <td>1 = Drive has been running below zero speed limit (par. 21.06) for a time defined by parameter 21.07 Zero speed delay.</td> </tr> <tr> <td>1</td> <td>Forward</td> <td>1 = Drive is running in forward direction above zero speed limit (par. 21.06).</td> </tr> <tr> <td>2</td> <td>Reverse</td> <td>1 = Drive is running in reverse direction above zero speed limit (par. 21.06).</td> </tr> <tr> <td>3...6</td> <td>Reserved</td> <td></td> </tr> <tr> <td>7</td> <td>Any constant speed request</td> <td>1 = A constant speed or frequency has been selected; see par. 06.20.</td> </tr> <tr> <td>8...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Description	0	Zero speed	1 = Drive has been running below zero speed limit (par. 21.06) for a time defined by parameter 21.07 Zero speed delay .	1	Forward	1 = Drive is running in forward direction above zero speed limit (par. 21.06).	2	Reverse	1 = Drive is running in reverse direction above zero speed limit (par. 21.06).	3...6	Reserved		7	Any constant speed request	1 = A constant speed or frequency has been selected; see par. 06.20 .	8...15	Reserved																															
Bit	Name	Description																																																				
0	Zero speed	1 = Drive has been running below zero speed limit (par. 21.06) for a time defined by parameter 21.07 Zero speed delay .																																																				
1	Forward	1 = Drive is running in forward direction above zero speed limit (par. 21.06).																																																				
2	Reverse	1 = Drive is running in reverse direction above zero speed limit (par. 21.06).																																																				
3...6	Reserved																																																					
7	Any constant speed request	1 = A constant speed or frequency has been selected; see par. 06.20 .																																																				
8...15	Reserved																																																					
0b0000...0b1111		Speed control status word.	1 = 1																																																			

No.	Name/Value	Description	Def/FbEq16
06.20	Constant speed status word	Constant speed/frequency status word. Indicates which constant speed or frequency is active (if any). See also parameter 06.19 Speed control status word , bit 7, and section Constant speeds/frequencies (page 44). This parameter is read-only.	0b0000
	Bit	Name	Description
	0	Constant speed 1	1 = Constant speed or frequency 1 selected
	1	Constant speed 2	1 = Constant speed or frequency 2 selected
	2	Constant speed 3	1 = Constant speed or frequency 3 selected
	3	Constant speed 4	1 = Constant speed or frequency 4 selected
	4	Constant speed 5	1 = Constant speed or frequency 5 selected
	5	Constant speed 6	1 = Constant speed or frequency 6 selected
	6	Constant speed 7	1 = Constant speed or frequency 7 selected
	7...15	Reserved	
	0b0000...0b1111	Constant speed/frequency status word.	1 = 1
06.21	Drive status word 3	Drive status word 3. This parameter is read-only.	0b0000
	Bit	Name	Description
	0	DC hold active	1 = DC hold is active.
	1	Post-magnetizing active	1 = Post-magnetizing is active.
	2	Motor pre-heating active	1 = Motor pre-heating is active.
	3...15	Reserved	
	0b0000...0b1111	Drive status word 1.	1 = 1
06.29	MSW bit 10 selection	Selects a binary source whose status is transmitted as bit 10 (User bit 0) of 06.11 Main status word .	Above limit
	False	0	0
	True	1	1
	Above limit	Bit 10 of 06.17 Drive status word 2 (see page 173).	2
	Other [bit]	Source selection (see Terms and abbreviations on page 160).	-
06.30	MSW bit 11 selection	Selects a binary source whose status is transmitted as bit 11 (User bit 0) of 06.11 Main status word .	Ext ctrl loc
	False	0	0
	True	1	1
	Ext ctrl loc	Bit 11 of 06.01 Main control word (see page 172).	2
	Other [bit]	Source selection (see Terms and abbreviations on page 160).	-
06.31	MSW bit 12 selection	Selects a binary source whose status is transmitted as bit 12 (User bit 1) of 06.11 Main status word .	Ext run enable
	False	0	0
	True	1	1
	Ext run enable	Status of the external run enable signal (see parameter 20.12 Run enable 1 source)	2
	Other [bit]	Source selection (see Terms and abbreviations on page 160).	-

176 Parameters

No.	Name/Value	Description	Def/FbEq16																																				
06.32	<i>MSW bit 13 selection</i>	Selects a binary source whose status is transmitted as bit 13 (User bit 2) of <i>06.11 Main status word</i> .	<i>False</i>																																				
	False	0	0																																				
	True	1	1																																				
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160)	-																																				
06.33	<i>MSW bit 14 selection</i>	Selects a binary source whose status is transmitted as bit 14 (User bit 3) of <i>06.11 Main status word</i> .	<i>False</i>																																				
	False	0	0																																				
	True	1	1																																				
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160)	-																																				
07 System info		Drive hardware and firmware information. All parameters in this group are read-only.																																					
07.03	<i>Drive rating id</i>	Type of the drive. (Rating ID in brackets.)	Not selected																																				
07.04	<i>Firmware name</i>	Firmware identification.	-																																				
07.05	<i>Firmware version</i>	Version number of the firmware.	0.00.0.0																																				
	0.00.0.0...255.255. 255.255	-	1=1																																				
07.06	<i>Loading package name</i>	Name of the firmware loading package.	-																																				
07.07	<i>Loading package version</i>	Version number of the firmware loading package.	0.00.0.0																																				
	0.00.0.0...255.255. 255.255	-	1=1																																				
07.11	<i>Cpu usage</i>	Microprocessor load in percent.	0																																				
	0...100%	Microprocessor load.	1 = 1																																				
07.35	<i>Drive configuration</i>	Plug 'n' play configuration. Drive automatically detects and enables any installed fieldbus or C-series option.	0x0000																																				
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Bit</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Reserved</td> <td>8</td> <td>BIO-01</td> </tr> <tr> <td>1</td> <td>Base unit</td> <td>9</td> <td>RIIO-01</td> </tr> <tr> <td>2</td> <td>Reserved</td> <td>10</td> <td>FSCA-01</td> </tr> <tr> <td>3</td> <td>FENA-21</td> <td>11</td> <td>FEIP-21</td> </tr> <tr> <td>4</td> <td>FECA-01</td> <td>12</td> <td>FMBT-21</td> </tr> <tr> <td>5</td> <td>FPBA-01</td> <td>13</td> <td></td> </tr> <tr> <td>6</td> <td>FCAN-01</td> <td>14</td> <td>FPNO-21</td> </tr> <tr> <td>7</td> <td>Reserved</td> <td>15</td> <td>FEPL-02</td> </tr> </tbody> </table>	Bit	Name	Bit	Name	0	Reserved	8	BIO-01	1	Base unit	9	RIIO-01	2	Reserved	10	FSCA-01	3	FENA-21	11	FEIP-21	4	FECA-01	12	FMBT-21	5	FPBA-01	13		6	FCAN-01	14	FPNO-21	7	Reserved	15	FEPL-02	
Bit	Name	Bit	Name																																				
0	Reserved	8	BIO-01																																				
1	Base unit	9	RIIO-01																																				
2	Reserved	10	FSCA-01																																				
3	FENA-21	11	FEIP-21																																				
4	FECA-01	12	FMBT-21																																				
5	FPBA-01	13																																					
6	FCAN-01	14	FPNO-21																																				
7	Reserved	15	FEPL-02																																				
	0x0000...0xffff	Drive configuration.	1 = 1																																				

No.	Name/Value	Description	Def/FbEq16																								
07.36	<i>Drive configuration 2</i>	Plug 'n' play configuration. Drive automatically detects and enables any installed fieldbus or C-series option.	0x0000																								
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Bit</th> <th>Name</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>FLON-01</td> <td>4</td> <td>CMOD-02</td> </tr> <tr> <td>1</td> <td>FDNA-01</td> <td>5</td> <td>CPTC-02</td> </tr> <tr> <td>2</td> <td>FCNA-01</td> <td>6</td> <td>CHDI-01</td> </tr> <tr> <td>3</td> <td>CMOD-01</td> <td>7...15</td> <td>Reserved</td> </tr> </tbody> </table>	Bit	Name	Bit	Name	0	FLON-01	4	CMOD-02	1	FDNA-01	5	CPTC-02	2	FCNA-01	6	CHDI-01	3	CMOD-01	7...15	Reserved					
Bit	Name	Bit	Name																								
0	FLON-01	4	CMOD-02																								
1	FDNA-01	5	CPTC-02																								
2	FCNA-01	6	CHDI-01																								
3	CMOD-01	7...15	Reserved																								
	0x0000...0xffff	Drive configuration 2.	1 = 1																								
10 Standard DI, RO		Configuration of digital inputs and relay outputs.																									
10.01	<i>DI status</i>	Displays the electrical status of digital inputs DI1...DI6. The activation/deactivation delays of the inputs (if any are specified) are ignored. Bits 0...5 reflect the status of DI1...DI6. Example: 000000000010011b = DI5, DI2 and DI1 are on, DI3, DI4 and DI6 are off. This parameter is read-only.	0b0000																								
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>DI1</td> <td>1 = Digital input 1 is ON.</td> </tr> <tr> <td>1</td> <td>DI2</td> <td>1 = Digital input 2 is ON.</td> </tr> <tr> <td>2</td> <td>DI3</td> <td>1 = Digital input 3 is ON.</td> </tr> <tr> <td>3</td> <td>DI4</td> <td>1 = Digital input 4 is ON.</td> </tr> <tr> <td>4</td> <td>DI5</td> <td>1 = Digital input 5 is ON.</td> </tr> <tr> <td>5</td> <td>DI6</td> <td>1 = Digital input 6 is ON.</td> </tr> <tr> <td>6...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Description	0	DI1	1 = Digital input 1 is ON.	1	DI2	1 = Digital input 2 is ON.	2	DI3	1 = Digital input 3 is ON.	3	DI4	1 = Digital input 4 is ON.	4	DI5	1 = Digital input 5 is ON.	5	DI6	1 = Digital input 6 is ON.	6...15	Reserved		
Bit	Name	Description																									
0	DI1	1 = Digital input 1 is ON.																									
1	DI2	1 = Digital input 2 is ON.																									
2	DI3	1 = Digital input 3 is ON.																									
3	DI4	1 = Digital input 4 is ON.																									
4	DI5	1 = Digital input 5 is ON.																									
5	DI6	1 = Digital input 6 is ON.																									
6...15	Reserved																										
	0b0000...0b1111	Status for digital inputs.	1 = 1																								
10.02	<i>DI delayed status</i>	Displays the status of digital inputs DI1...DI6. Bits 0...5 reflect the delayed status of DI1...DI6. Example: 000000000010011b = DI5, DI2 and DI1 are on, DI3, DI4 and DI6 are off. This word is updated only after a 2 ms activation/deactivation delay. When the value of a digital input changes, it must remain the same in two consecutive samples, that is for 2 ms, for the new value to be accepted. This parameter is read-only.	0b0000																								
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>DI1</td> <td>1 = Digital input 1 is ON.</td> </tr> <tr> <td>1</td> <td>DI2</td> <td>1 = Digital input 2 is ON.</td> </tr> <tr> <td>2</td> <td>DI3</td> <td>1 = Digital input 3 is ON.</td> </tr> <tr> <td>3</td> <td>DI4</td> <td>1 = Digital input 4 is ON.</td> </tr> <tr> <td>4</td> <td>DI5</td> <td>1 = Digital input 5 is ON.</td> </tr> <tr> <td>5</td> <td>DI6</td> <td>1 = Digital input 6 is ON.</td> </tr> <tr> <td>6...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Description	0	DI1	1 = Digital input 1 is ON.	1	DI2	1 = Digital input 2 is ON.	2	DI3	1 = Digital input 3 is ON.	3	DI4	1 = Digital input 4 is ON.	4	DI5	1 = Digital input 5 is ON.	5	DI6	1 = Digital input 6 is ON.	6...15	Reserved		
Bit	Name	Description																									
0	DI1	1 = Digital input 1 is ON.																									
1	DI2	1 = Digital input 2 is ON.																									
2	DI3	1 = Digital input 3 is ON.																									
3	DI4	1 = Digital input 4 is ON.																									
4	DI5	1 = Digital input 5 is ON.																									
5	DI6	1 = Digital input 6 is ON.																									
6...15	Reserved																										
	0b0000...0b1111	Delayed status for digital inputs.	1 = 1																								

No.	Name/Value	Description	Def/FbEq16																
10.03	<i>DI force selection</i>	The electrical statuses of the digital inputs can be overridden for e.g. testing purposes. A bit in parameter <i>10.04 DI forced data</i> is provided for each digital input, and its value is applied whenever the corresponding bit in this parameter is 1. Note: Boot and power cycle reset the force selections (parameters <i>10.03</i> and <i>10.04</i>).	0b0000																
<table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Force DI1 to value of bit 0 of parameter <i>10.04 DI forced data</i>. (0 = Normal mode)</td> </tr> <tr> <td>1</td> <td>1 = Force DI2 to value of bit 1 of parameter <i>10.04 DI forced data</i>. (0 = Normal mode)</td> </tr> <tr> <td>2</td> <td>1 = Force DI3 to value of bit 2 of parameter <i>10.04 DI forced data</i>. (0 = Normal mode)</td> </tr> <tr> <td>3</td> <td>1 = Force DI4 to value of bit 3 of parameter <i>10.04 DI forced data</i>. (0 = Normal mode)</td> </tr> <tr> <td>4</td> <td>1 = Force DI5 to value of bit 4 of parameter <i>10.04 DI forced data</i>. (0 = Normal mode)</td> </tr> <tr> <td>5</td> <td>1 = Force DI6 to value of bit 5 of parameter <i>10.04 DI forced data</i>. (0 = Normal mode)</td> </tr> <tr> <td>6...15</td> <td>Reserved</td> </tr> </tbody> </table>				Bit	Value	0	1 = Force DI1 to value of bit 0 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)	1	1 = Force DI2 to value of bit 1 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)	2	1 = Force DI3 to value of bit 2 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)	3	1 = Force DI4 to value of bit 3 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)	4	1 = Force DI5 to value of bit 4 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)	5	1 = Force DI6 to value of bit 5 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)	6...15	Reserved
Bit	Value																		
0	1 = Force DI1 to value of bit 0 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)																		
1	1 = Force DI2 to value of bit 1 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)																		
2	1 = Force DI3 to value of bit 2 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)																		
3	1 = Force DI4 to value of bit 3 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)																		
4	1 = Force DI5 to value of bit 4 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)																		
5	1 = Force DI6 to value of bit 5 of parameter <i>10.04 DI forced data</i> . (0 = Normal mode)																		
6...15	Reserved																		
0b0000...0b1111		Override selection for digital inputs.	1 = 1																
10.04	<i>DI forced data</i>	Allows the data value of a forced digital input to be changed from 0 to 1. It is only possible to force an input that has been selected in parameter <i>10.03 DI force selection</i> . Bit 0 is the forced value for DI1; bit 5 is the forced value for the DI6.	0b0000																
<table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Force the value of this bit to D1, if so defined in parameter <i>10.03 DI force selection</i>.</td> </tr> <tr> <td>1</td> <td>Force the value of this bit to D3, if so defined in parameter <i>10.03 DI force selection</i>.</td> </tr> <tr> <td>2</td> <td>Force the value of this bit to D3, if so defined in parameter <i>10.03 DI force selection</i>.</td> </tr> <tr> <td>3</td> <td>Force the value of this bit to D4, if so defined in parameter <i>10.03 DI force selection</i>.</td> </tr> <tr> <td>4</td> <td>Force the value of this bit to D5, if so defined in parameter <i>10.03 DI force selection</i>.</td> </tr> <tr> <td>5</td> <td>Force the value of this bit to D6, if so defined in parameter <i>10.03 DI force selection</i>.</td> </tr> <tr> <td>6...15</td> <td>Reserved</td> </tr> </tbody> </table>				Bit	Value	0	Force the value of this bit to D1, if so defined in parameter <i>10.03 DI force selection</i> .	1	Force the value of this bit to D3, if so defined in parameter <i>10.03 DI force selection</i> .	2	Force the value of this bit to D3, if so defined in parameter <i>10.03 DI force selection</i> .	3	Force the value of this bit to D4, if so defined in parameter <i>10.03 DI force selection</i> .	4	Force the value of this bit to D5, if so defined in parameter <i>10.03 DI force selection</i> .	5	Force the value of this bit to D6, if so defined in parameter <i>10.03 DI force selection</i> .	6...15	Reserved
Bit	Value																		
0	Force the value of this bit to D1, if so defined in parameter <i>10.03 DI force selection</i> .																		
1	Force the value of this bit to D3, if so defined in parameter <i>10.03 DI force selection</i> .																		
2	Force the value of this bit to D3, if so defined in parameter <i>10.03 DI force selection</i> .																		
3	Force the value of this bit to D4, if so defined in parameter <i>10.03 DI force selection</i> .																		
4	Force the value of this bit to D5, if so defined in parameter <i>10.03 DI force selection</i> .																		
5	Force the value of this bit to D6, if so defined in parameter <i>10.03 DI force selection</i> .																		
6...15	Reserved																		
0b0000...0b1111		Forced values of digital inputs.	1 = 1																
10.05	<i>DI1 ON delay</i>	Defines the activation delay for digital input DI1.	0.0 s																
<p><i>t_{on}</i> = 10.05 DI1 ON delay <i>t_{off}</i> = 10.06 DI1 OFF delay *Electrical status of digital input. Indicated by <i>10.01 DI status</i>. **Indicated by <i>10.02 DI delayed status</i>.</p>																			
0.0 ... 3000.0 s		Activation delay for DI1.	10 = 1 s																
10.06	<i>DI1 OFF delay</i>	Defines the deactivation delay for digital input DI1. See parameter <i>10.05 DI1 ON delay</i> .	0.0 s																
0.0 ... 3000.0 s		Deactivation delay for DI1.	10 = 1 s																

No.	Name/Value	Description	Def/FbEq16
10.07	<i>DI2 ON delay</i>	Defines the activation delay for digital input DI2.	0.0 s
<p> $t_{On} = 10.07$ <i>DI2 ON delay</i> $t_{Off} = 10.08$ <i>DI2 OFF delay</i> *Electrical status of digital input. Indicated by 10.01 DI status. **Indicated by 10.02 DI delayed status. </p>			
	0.0 ... 3000.0 s	Activation delay for DI2.	10 = 1 s
10.08	<i>DI2 OFF delay</i>	Defines the deactivation delay for digital input DI2. See parameter 10.07 DI2 ON delay .	0.0 s
	0.0 ... 3000.0 s	Deactivation delay for DI2.	10 = 1 s
10.09	<i>DI3 ON delay</i>	Defines the activation delay for digital input DI3.	0.0 s
<p> $t_{On} = 10.09$ <i>DI3 ON delay</i> $t_{Off} = 10.10$ <i>DI3 OFF delay</i> *Electrical status of digital input. Indicated by 10.01 DI status. **Indicated by 10.02 DI delayed status. </p>			
	0.0 ... 3000.0 s	Activation delay for DI3.	10 = 1 s
10.10	<i>DI3 OFF delay</i>	Defines the deactivation delay for digital input DI3. See parameter 10.09 DI3 ON delay .	0.0 s
	0.0 ... 3000.0 s	Deactivation delay for DI3.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16
10.11	DI4 ON delay	Defines the activation delay for digital input DI4.	0.0 s
<p data-bbox="161 467 344 491">$t_{On} = 10.11$ DI4 ON delay</p> <p data-bbox="161 491 351 515">$t_{Off} = 10.12$ DI4 OFF delay</p> <p data-bbox="161 515 594 539">*Electrical status of digital input. Indicated by 10.01 DI status.</p> <p data-bbox="161 539 437 563">**Indicated by 10.02 DI delayed status.</p>			
0.0 ... 3000.0 s		Activation delay for DI4.	10 = 1 s
10.12	DI4 OFF delay	Defines the deactivation delay for digital input DI4. See parameter 10.11 DI4 ON delay .	0.0 s
0.0 ... 3000.0 s		Deactivation delay for DI4.	10 = 1 s
10.13	DI5 ON delay	Defines the activation delay for digital input DI5.	0.0 s
<p data-bbox="161 970 344 994">$t_{On} = 10.13$ DI5 ON delay</p> <p data-bbox="161 994 351 1018">$t_{Off} = 10.14$ DI5 OFF delay</p> <p data-bbox="161 1018 594 1042">*Electrical status of digital input. Indicated by 10.01 DI status.</p> <p data-bbox="161 1042 437 1066">**Indicated by 10.02 DI delayed status.</p>			
0.0 ... 3000.0 s		Activation delay for DI5.	10 = 1 s
10.14	DI5 OFF delay	Defines the deactivation delay for digital input DI5. See parameter 10.13 DI5 ON delay .	0.0 s
0.0 ... 3000.0 s		Deactivation delay for DI5.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16										
10.15	<i>DI6 ON delay</i>	Defines the activation delay for digital input DI6.	0.0 s										
<p> $t_{On} = 10.15$ <i>DI6 ON delay</i> $t_{Off} = 10.16$ <i>DI6 OFF delay</i> *Electrical status of digital input. Indicated by 10.01 DI status. **Indicated by 10.02 DI delayed status. </p>													
	0.0 ... 3000.0 s	Activation delay for DI6.	10 = 1 s										
10.16	<i>DI6 OFF delay</i>	Defines the deactivation delay for digital input DI6. See parameter 10.15 DI6 ON delay .	0.0 s										
	0.0 ... 3000.0 s	Deactivation delay for DI6.	10 = 1 s										
10.21	<i>RO status</i>	Status of relay outputs RO3...RO1.	0b0000										
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = RO1 is energized.</td> </tr> <tr> <td>1</td> <td>1 = RO2 is energized.</td> </tr> <tr> <td>2</td> <td>1 = RO3 is energized.</td> </tr> <tr> <td>3...15</td> <td>Reserved</td> </tr> </tbody> </table>	Bit	Value	0	1 = RO1 is energized.	1	1 = RO2 is energized.	2	1 = RO3 is energized.	3...15	Reserved	
Bit	Value												
0	1 = RO1 is energized.												
1	1 = RO2 is energized.												
2	1 = RO3 is energized.												
3...15	Reserved												
	0b0000...0b1111	Status of relay outputs.	1 = 1										
10.22	<i>RO force selection</i>	The signals connected to the relay outputs can be overridden for e.g. testing purposes. A bit in parameter 10.23 RO forced data is provided for each relay output, and its value is applied whenever the corresponding bit in this parameter is 1. Note: Boot and power cycle reset the force selections (parameters 10.22 and 10.23).	0b0000										
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Force RO1 to value of bit 0 of parameter 10.23 RO forced data. (0 = Normal mode)</td> </tr> <tr> <td>1</td> <td>1 = Force RO2 to value of bit 1 of parameter 10.23 RO forced data. (0 = Normal mode)</td> </tr> <tr> <td>2</td> <td>1 = Force RO3 to value of bit 2 of parameter 10.23 RO forced data. (0 = Normal mode)</td> </tr> <tr> <td>3...15</td> <td>Reserved</td> </tr> </tbody> </table>	Bit	Value	0	1 = Force RO1 to value of bit 0 of parameter 10.23 RO forced data . (0 = Normal mode)	1	1 = Force RO2 to value of bit 1 of parameter 10.23 RO forced data . (0 = Normal mode)	2	1 = Force RO3 to value of bit 2 of parameter 10.23 RO forced data . (0 = Normal mode)	3...15	Reserved	
Bit	Value												
0	1 = Force RO1 to value of bit 0 of parameter 10.23 RO forced data . (0 = Normal mode)												
1	1 = Force RO2 to value of bit 1 of parameter 10.23 RO forced data . (0 = Normal mode)												
2	1 = Force RO3 to value of bit 2 of parameter 10.23 RO forced data . (0 = Normal mode)												
3...15	Reserved												
	0b0000...0b1111	Override selection for relay outputs.	1 = 1										

182 Parameters

No.	Name/Value	Description	Def/FbEq16										
10.23	<i>RO forced data</i>	Contains the values of relay outputs that are used instead of the connected signals if selected in parameter 10.22 RO force selection . Bit 0 is the forced value for RO1.	0b0000										
<table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Force the value of this bit to RO1, if so defined in parameter 10.22 RO force selection.</td> </tr> <tr> <td>1</td> <td>Force the value of this bit to RO2, if so defined in parameter 10.22 RO force selection.</td> </tr> <tr> <td>2</td> <td>Force the value of this bit to RO3, if so defined in parameter 10.22 RO force selection.</td> </tr> <tr> <td>3...15</td> <td>Reserved</td> </tr> </tbody> </table>				Bit	Value	0	Force the value of this bit to RO1, if so defined in parameter 10.22 RO force selection .	1	Force the value of this bit to RO2, if so defined in parameter 10.22 RO force selection .	2	Force the value of this bit to RO3, if so defined in parameter 10.22 RO force selection .	3...15	Reserved
Bit	Value												
0	Force the value of this bit to RO1, if so defined in parameter 10.22 RO force selection .												
1	Force the value of this bit to RO2, if so defined in parameter 10.22 RO force selection .												
2	Force the value of this bit to RO3, if so defined in parameter 10.22 RO force selection .												
3...15	Reserved												
	0b0000...0b1111	Forced RO values.	1 = 1										
10.24	<i>RO1 source</i>	Selects a drive signal to be connected to relay output RO1.	<i>Ready run</i>										
	Not energized	Output is not energized.	0										
	Energized	Output is energized.	1										
	Ready run	Bit 1 of 06.11 Main status word (see page 172).	2										
	Enabled	Bit 0 of 06.16 Drive status word 1 (see page 173).	4										
	Started	Bit 5 of 06.16 Drive status word 1 (see page 173).	5										
	Magnetized	Bit 1 of 06.17 Drive status word 2 (see page 173).	6										
	Running	Bit 6 of 06.16 Drive status word 1 (see page 173).	7										
	Ready ref	Bit 2 of 06.11 Main status word (see page 172).	8										
	At setpoint	Bit 8 of 06.11 Main status word (see page 172).	9										
	Reverse	Bit 2 of 06.19 Speed control status word (see page 174).	10										
	Zero speed	Bit 0 of 06.19 Speed control status word (see page 174).	11										
	Above limit	Bit 10 of 06.17 Drive status word 2 (see page 173).	12										
	Warning	Bit 7 of 06.11 Main status word (see page 172).	13										
	Fault	Bit 3 of 06.11 Main status word (see page 172).	14										
	Fault (-1)	Inverted bit 3 of 06.11 Main status word (see page 172).	15										
	Fault/Warning	Bit 3 of 06.11 Main status word OR bit 7 of 06.11 Main status word (see page 172).	16										
	Overcurrent	Fault 2310 Overcurrent has occurred.	17										
	Overvoltage	Fault 3210 DC link overvoltage has occurred.	18										
	Drive temp	Fault 2381 IGBT overload or 4110 Control board temperature or 4210 IGBT overtemperature or 4290 Cooling or 42F1 IGBT temperature or 4310 Excess temperature or 4380 Excess temperature difference has occurred.	19										
	Undervoltage	Fault 3220 DC link undervoltage has occurred.	20										
	Motor temp	Fault 4981 External temperature 1 or 4982 External temperature 2 has occurred.	21										
	Brake command	Bit 0 of 44.01 Brake control status (see page 312).	22										
	Ext2 active	Bit 11 of 06.16 Drive status word 1 (see page 173).	23										
	Remote control	Bit 9 of 06.11 Main status word (see page 172).	24										
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271).	27										
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271).	28										
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271).	29										
	Reserved		30...32										


No.	Name/Value	Description	Def/FbEq16
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264).	33
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264).	34
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264).	35
	Start delay	Bit 13 of 06.17 Drive status word 2 (see page 173).	39
	RO/DIO control word bit0	Bit 0 of 10.99 RO/DIO control word (see page 184).	40
	RO/DIO control word bit1	Bit 1 of 10.99 RO/DIO control word (see page 184).	41
	RO/DIO control word bit2	Bit 2 of 10.99 RO/DIO control word (see page 184).	42
	PFC1	Bit 0 of 76.01 PFC status (see page 343).	45
	PFC2	Bit 1 of 76.01 PFC status (see page 343).	46
	PFC3	Bit 2 of 76.01 PFC status (see page 343).	47
	PFC4	Bit 3 of 76.01 PFC status (see page 343).	48
	Event word 1	Event word 1 = 1 if any bit of 04.40 Event word 1 (see page 168) is 1, that is, if any warning, fault or pure event that has been defined with parameters 04.43...04.71 is on.	53
	User load curve	Bit 3 (Outside load limit) of 37.01 ULC output status word (see page 290).	61
	RO/DIO control word	Maps to corresponding bit in parameter 10.99 RO/DIO control word . For example, Bit 0 of 10.99 RO/DIO control word controls RO1, Bit 1 of 10.99 RO/DIO control word controls RO2, and so on.	62
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
10.25	RO1 ON delay	Defines the activation delay for relay output RO1.	0.0 s
<p> $t_{On} = 10.25$ RO1 ON delay $t_{Off} = 10.26$ RO1 OFF delay </p>			
	0.0 ... 3000.0 s	Activation delay for RO1.	10 = 1 s
10.26	RO1 OFF delay	Defines the deactivation delay for relay output RO1. See parameter 10.25 RO1 ON delay .	0.0 s
	0.0 ... 3000.0 s	Deactivation delay for RO1.	10 = 1 s
10.27	RO2 source	Selects a drive signal to be connected to relay output RO2. For the available selections, see parameter 10.24 RO1 source .	<i>Running</i>


No.	Name/Value	Description	Def/FbEq16													
10.28	<i>RO2 ON delay</i>	Defines the activation delay for relay output RO2.	0.0 s													
<p>$t_{On} = 10.28 \text{ RO2 ON delay}$ $t_{Off} = 10.29 \text{ RO2 OFF delay}$</p>																
	0.0 ... 3000.0 s	Activation delay for RO2.	10 = 1 s													
10.29	<i>RO2 OFF delay</i>	Defines the deactivation delay for relay output RO2. See parameter 10.28 RO2 ON delay .	0.0 s													
	0.0 ... 3000.0 s	Deactivation delay for RO2.	10 = 1 s													
10.30	<i>RO3 source</i>	Selects a drive signal to be connected to relay output RO3. For the available selections, see parameter 10.24 RO1 source .	<i>Fault (-1)</i>													
10.31	<i>RO3 ON delay</i>	Defines the activation delay for relay output RO3.	0.0 s													
<p>$t_{On} = 10.31 \text{ RO3 ON delay}$ $t_{Off} = 10.32 \text{ RO3 OFF delay}$</p>																
	0.0 ... 3000.0 s	Activation delay for RO3.	10 = 1 s													
10.32	<i>RO3 OFF delay</i>	Defines the deactivation delay for relay output RO3. See parameter 10.31 RO3 ON delay .	0.0 s													
	0.0 ... 3000.0 s	Deactivation delay for RO3.	10 = 1 s													
10.99	<i>RO/DIO control word</i>	Storage parameter for controlling the relay outputs e.g. through the embedded fieldbus interface. To control the relay outputs (RO) of the drive, send a control word with the bit assignments shown below as Modbus I/O data. Set the target selection parameter of that particular data (58.101...58.114) to <i>RO/DIO control word</i> . In the source selection parameter of the desired output, select the appropriate bit of this word.	0b0000													
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>RO1</td> <td rowspan="3">Source bits for relay outputs RO1...RO3. See parameters 10.24, 10.27 and 10.30.</td> </tr> <tr> <td>1</td> <td>RO2</td> </tr> <tr> <td>2</td> <td>RO3</td> </tr> <tr> <td>3...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Description	0	RO1	Source bits for relay outputs RO1...RO3. See parameters 10.24 , 10.27 and 10.30 .	1	RO2	2	RO3	3...15	Reserved	
Bit	Name	Description														
0	RO1	Source bits for relay outputs RO1...RO3. See parameters 10.24 , 10.27 and 10.30 .														
1	RO2															
2	RO3															
3...15	Reserved															


No.	Name/Value	Description	Def/FbEq16
	0b0000...0b1111	RO/DIO control word.	1 = 1
10.101	<i>RO1 toggle counter</i>	Displays the number of times relay output RO1 has changed states.	0
	0...4294967000	State change count.	1 = 1
10.102	<i>RO2 toggle counter</i>	Displays the number of times relay output RO2 has changed states.	0
	0...4294967000	State change count.	1 = 1
10.103	<i>RO3 toggle counter</i>	Displays the number of times relay output RO3 has changed states.	0
	0...4294967000	State change count.	1 = 1


11 Standard DIO, FI, FO		Configuration of the frequency input.	
11.21	<i>DI5 configuration</i>	Selects how digital input 5 is used.	<i>Digital input</i>
	Digital input	DI5 is used as a digital input.	0
	Frequency input	DI5 is used as a frequency input.	1
11.38	<i>Freq in 1 actual value</i>	Displays the value of frequency input 1 (via DI6/DI5 when it is used as a frequency input) before scaling. See parameter 11.42 <i>Freq in 1 min</i> . This parameter is read-only.	0
	0 ... 16000 Hz	Unscaled value of frequency input 1.	1 = 1 Hz
11.39	<i>Freq in 1 scaled value</i>	Displays the value of frequency input 1 (via DI5 or DI6 when it is used as a frequency input) after scaling. See parameter 11.42 <i>Freq in 1 min</i> . This parameter is read-only.	0
	-32768.000... 32767.000	Scaled value of frequency input 1 (DI5 or DI6).	1 = 1
11.42	<i>Freq in 1 min</i>	Defines the minimum for the frequency actually arriving at frequency input 1 (DI5 or DI6 when it is used as a frequency input). The incoming frequency signal (11.38 <i>Freq in 1 actual value</i>) is scaled into an internal signal (11.39 <i>Freq in 1 scaled value</i>) by parameters 11.42...11.45 as follows:	0 Hz
	0 ... 16000 Hz	Minimum frequency of frequency input 1 (DI5 or DI6).	1 = 1 Hz


No.	Name/Value	Description	Def/FbEq16
11.43	<i>Freq in 1 max</i>	Defines the maximum for the frequency actually arriving at frequency input 1 (DI5 or DI6 when it is used as a frequency input). See parameter 11.42 Freq in 1 min .	16000 Hz
	0 ... 16000 Hz	Maximum frequency for frequency input 1 (DI5 or DI6).	1 = 1 Hz
11.44	<i>Freq in 1 at scaled min</i>	Defines the value that is required to correspond internally to the minimum input frequency defined by parameter 11.42 Freq in 1 min . See diagram at parameter 11.42 Freq in 1 min .	0.000
	-32768.000... 32767.000	Value corresponding to minimum of frequency input 1.	1 = 1
11.45	<i>Freq in 1 at scaled max</i>	Defines the value that is required to correspond internally to the maximum input frequency defined by parameter 11.43 Freq in 1 max . See diagram at parameter 11.42 Freq in 1 min .	50.000
	-32768.000... 32767.000	Value corresponding to maximum of frequency input 1.	1 = 1

12 Standard AI		Configuration of standard analog inputs.									
12.02	<i>AI force selection</i>	<p>The true readings of the analog inputs can be overridden for e.g. testing purposes. A forced value parameter is provided for each analog input, and its value is applied whenever the corresponding bit in this parameter is 1.</p> <p>Note: AI filter times (parameters 12.16 AI1 filter time and 12.26 AI2 filter time) have no effect on forced AI values (parameters 12.13 AI1 forced value and 12.23 AI2 forced value).</p> <p>Note: Boot and power cycle reset the force selections (parameters 12.02 and 12.03).</p>	0b0000								
<table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Force AI1 to value of parameter 12.13 AI1 forced value.</td> </tr> <tr> <td>1</td> <td>1 = Force AI2 to value of parameter 12.23 AI2 forced value.</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> </tr> </tbody> </table>		Bit	Value	0	1 = Force AI1 to value of parameter 12.13 AI1 forced value .	1	1 = Force AI2 to value of parameter 12.23 AI2 forced value .	2...15	Reserved		
Bit	Value										
0	1 = Force AI1 to value of parameter 12.13 AI1 forced value .										
1	1 = Force AI2 to value of parameter 12.23 AI2 forced value .										
2...15	Reserved										
	0b000...0b1111	Forced values selector for analog inputs AI1 and AI2.	1 = 1								
12.03	<i>AI supervision function</i>	<p>Selects how the drive reacts when an analog input signal moves out of the minimum and/or maximum limits specified for the input.</p> <p>The supervision applies a margin of 0.5 V or 1.0 mA to the limits. For example, if the maximum limit for the input is 7.000 V, the maximum limit supervision activates at 7.500 V. The inputs and the limits to be observed are selected by parameter 12.04 AI supervision selection.</p>	<i>No action</i>								
	No action	No action taken.	0								
	Fault	Drive trips on 80A0 AI supervision .	1								
	Warning	Drive generates an A8A0 AI supervision warning.	2								
	Last speed	<p>Drive generates a warning (A8A0 AI supervision) and freezes the speed (or frequency) to the level the drive was operating at. The speed/frequency is determined on the basis of actual speed using 850 ms low-pass filtering.</p> <p> WARNING! Make sure that it is safe to continue operation in case of a communication break.</p>	3								


No.	Name/Value	Description	Def/FbEq16																		
	Speed ref safe	Drive generates a warning (<i>A8A0 AI supervision</i>) and sets the speed to the speed defined by parameter <i>22.41 Speed ref safe</i> (or <i>28.41 Frequency ref safe</i> when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	4																		
12.04	<i>AI supervision selection</i>	Specifies the analog input limits to be supervised. See parameter <i>12.03 AI supervision function</i> .	0b0000																		
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>AI1 < MIN</td> <td>1 = Minimum limit supervision of AI1 active.</td> </tr> <tr> <td>1</td> <td>AI1 > MAX</td> <td>1 = Maximum limit supervision of AI1 active.</td> </tr> <tr> <td>2</td> <td>AI2 < MIN</td> <td>1 = Minimum limit supervision of AI2 active.</td> </tr> <tr> <td>3</td> <td>AI2 > MAX</td> <td>1 = Maximum limit supervision of AI2 active.</td> </tr> <tr> <td>4...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Description	0	AI1 < MIN	1 = Minimum limit supervision of AI1 active.	1	AI1 > MAX	1 = Maximum limit supervision of AI1 active.	2	AI2 < MIN	1 = Minimum limit supervision of AI2 active.	3	AI2 > MAX	1 = Maximum limit supervision of AI2 active.	4...15	Reserved		
Bit	Name	Description																			
0	AI1 < MIN	1 = Minimum limit supervision of AI1 active.																			
1	AI1 > MAX	1 = Maximum limit supervision of AI1 active.																			
2	AI2 < MIN	1 = Minimum limit supervision of AI2 active.																			
3	AI2 > MAX	1 = Maximum limit supervision of AI2 active.																			
4...15	Reserved																				
	0b000...0b1111	Activation of analog input supervision.	1 = 1																		
12.11	<i>AI1 actual value</i>	Displays the value of analog input AI1 in mA or V (depending on whether the input is set to current or voltage by a hardware setting). This parameter is read-only.	0																		
	0.000...11.000 V	Value of analog input AI1.	1000 = 1 unit																		
12.12	<i>AI1 scaled value</i>	Displays the value of analog input AI1 after scaling. See parameters <i>12.19 AI1 scaled at AI1 min</i> and <i>12.20 AI1 scaled at AI1 max</i> . This parameter is read-only.	0																		
	-32768.000... 32767.000	Scaled value of analog input AI1.	1 = 1																		
12.13	<i>AI1 forced value</i>	Forced value that can be used instead of the true reading of the input. See parameter <i>12.02 AI force selection</i> .	0																		
	0.000...11.000 V	Forced value of analog input AI1.	1000 = 1 unit																		
12.15	<i>AI1 unit selection</i>	Selects the unit for readings and settings related to analog input AI1. Note: In firmware ASCL2 and ASCL4), this setting must match the corresponding hardware setting on the drive control unit. See chapter <i>Electrical installation</i> , section <i>Switches</i> in the <i>Hardware manual</i> of the drive and the default control connections for the macro in use in chapter <i>Control macros</i> (page 99). Control board reboot (either by cycling the power or through parameter <i>96.08 Control board boot</i>) is required to validate any changes in the hardware settings.	V																		
	V	Volts.	2																		
	mA	Milliamperes.	10																		



No.	Name/Value	Description	Def/FbEq16
12.16	<i>AI1 filter time</i>	<p>Defines the filter time constant for analog input AI1.</p>  <p style="text-align: center;">$O = I \times (1 - e^{-t/T})$</p> <p>I = filter input (step) O = filter output t = time T = filter time constant</p> <p>Note: The signal is also filtered due to the signal interface hardware (approximately 0.25 ms time constant). This cannot be changed by any parameter.</p>	0.100 s
	0.000...30.000 s	Filter time constant.	1000 = 1
12.17	<i>AI1 min</i>	<p>Defines the minimum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting. See also parameter 12.19 AI1 scaled at AI1 min.</p>	0.000
	0.000...11.000 V	Minimum value of AI1.	1000 = 1
12.18	<i>AI1 max</i>	<p>Defines the maximum site value for analog input AI1. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting. See also parameter 12.19 AI1 scaled at AI1 min.</p>	10.000
	0.000...11.000 V	Maximum value of AI1.	1000 = 1

No.	Name/Value	Description	Def/FbEq16
12.19	<i>AI1 scaled at AI1 min</i>	Defines the real internal value that corresponds to the minimum analog input AI1 value defined by parameter 12.17 AI1 min . (Changing the polarity settings of 12.19 and 12.20 can effectively invert the analog input.) 	0.000
	-32768.000... 32767.000	Real value corresponding to minimum AI1 value.	1 = 1
12.20	<i>AI1 scaled at AI1 max</i>	Defines the real internal value that corresponds to the maximum analog input AI1 value defined by parameter 12.18 AI1 max . See the drawing at parameter 12.19 AI1 scaled at AI1 min .	50.000
	-32768.000... 32767.000	Real value corresponding to maximum AI1 value.	1 = 1
12.21	<i>AI2 actual value</i>	Displays the value of analog input AI2 in mA or V (depending on whether the input is set to current or voltage by a hardware setting). This parameter is read-only.	-
	0.000...22.000 mA	Value of analog input AI2.	1000 = 1 unit
12.22	<i>AI2 scaled value</i>	Displays the value of analog input AI2 after scaling. See parameters 12.29 AI2 scaled at AI2 min and 12.101 AI1 percent value . This parameter is read-only.	0.000
	-32768.000... 32767.000	Scaled value of analog input AI2.	1 = 1
12.23	<i>AI2 forced value</i>	Forced value that can be used instead of the true reading of the input. See parameter 12.02 AI force selection .	0.000
	0.000...22.000 mA	Forced value of analog input AI2.	1000 = 1 unit
12.25	<i>AI2 unit selection</i>	Selects the unit for readings and settings related to analog input AI2. Note: In firmware ASCL2 and ASCL4), this setting must match the corresponding hardware setting on the drive control unit. See chapter <i>Electrical installation</i> , section <i>Switches</i> in the <i>Hardware manual</i> of the drive and the default control connections for the macro in use in chapter Control macros (page 99). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	<i>mA</i>
	V	Volts.	2



No.	Name/Value	Description	Def/FbEq16
	mA	Milliamperes.	10
12.26	<i>AI2 filter time</i>	Defines the filter time constant for analog input AI2. See parameter 12.16 AI1 filter time .	0.100 s
	0.000...30.000 s	Filter time constant.	1000 = 1 s
12.27	<i>AI2 min</i>	Defines the minimum site value for analog input AI2. Set the value actually sent to the drive when the analog signal from plant is wound to its minimum setting.	4.000 mA
	0.000...22.000	Minimum value of AI2.	1000 = 1 unit
12.28	<i>AI2 max</i>	Defines the maximum site value for analog input AI2. Set the value actually sent to the drive when the analog signal from plant is wound to its maximum setting.	20.000 mA
	0.000...22.000 mA	Maximum value of AI2.	1000 = 1 unit
12.29	<i>AI2 scaled at AI2 min</i>	Defines the real value that corresponds to the minimum analog input AI2 value defined by parameter 12.27 AI2 min . (Changing the polarity settings of 12.29 and 12.101 can effectively invert the analog input.) 	0.000
	-32768.000... 32767.000	Real value corresponding to minimum AI2 value.	1 = 1
12.30	<i>AI2 scaled at AI2 max</i>	Defines the real value that corresponds to the minimum analog input AI2 value defined by parameter 12.28 AI2 max . See the drawing at parameter of 12.29 AI2 scaled at AI2 min .	50.000
	-32768.000... 32767.000	Real value corresponding to maximum AI2 value.	1 = 1
12.101	<i>AI1 percent value</i>	Value of analog input AI1 in percent of AI1 scaling (12.18 AI1 max - 12.17 AI1 min).	0
	0.00...100.00%	AI1 value	100 = 1%
12.102	<i>AI2 percent value</i>	Value of analog input AI2 in percent of AI2 scaling (12.28 AI2 max - 12.27 AI2 min).	0
	0.00...100.00%	AI2 value	100 = 1%

No.	Name/Value	Description	Def/FbEq16								
13 Standard AO		Configuration of standard analog outputs.									
13.02	<i>AO force selection</i>	The source signals of the analog outputs can be overridden for e.g. testing purposes. A forced value parameter is provided for each analog output, and its value is applied whenever the corresponding bit in this parameter is 1. Note: Boot and power cycle reset the force selections (parameters 13.02 and 13.11).	0b0000								
<table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Force AO1 to value of parameter 13.13 AO1 forced value. (0 = Normal mode)</td> </tr> <tr> <td>1</td> <td>1 = Force AO2 to value of parameter 13.23 AO2 forced value. (0 = Normal mode)</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> </tr> </tbody> </table>				Bit	Value	0	1 = Force AO1 to value of parameter 13.13 AO1 forced value . (0 = Normal mode)	1	1 = Force AO2 to value of parameter 13.23 AO2 forced value . (0 = Normal mode)	2...15	Reserved
Bit	Value										
0	1 = Force AO1 to value of parameter 13.13 AO1 forced value . (0 = Normal mode)										
1	1 = Force AO2 to value of parameter 13.23 AO2 forced value . (0 = Normal mode)										
2...15	Reserved										
	0b0000...0b1111	Forced values selector for analog outputs AO1 and AO2.	1 = 1								
13.11	<i>AO1 actual value</i>	Displays the value of AO1 in mA This parameter is read-only.	-								
	0.000...22.000 mA	Value of AO1.	1 = 1 mA								
13.12	<i>AO1 source</i>	Selects a signal to be connected to analog output AO1.	<i>Output frequency</i>								
	Zero	None.	0								
	Motor speed used	01.01 Motor speed used (page 163).	1								
	Output frequency	01.06 Output frequency (page 163).	3								
	Motor current	01.07 Motor current (page 163).	4								
	Motor current % of motor nominal	01.08 Motor current % of motor nom (page 163).	5								
	Motor torque	01.10 Motor torque (page 163).	6								
	DC voltage	01.11 DC voltage (page 163).	7								
	Output power	01.14 Output power (page 164).	8								
	Freq ref used	28.02 Frequency ref ramp output (page 238).	14								
	Process PID out	40.01 Process PID output actual (page 293).	16								
	Temp sensor 1 excitation	The output is used to feed an excitation current to the temperature sensor 1, see parameter 35.11 Temperature 1 source . See also section Motor thermal protection (page 83).	20								
	Temp sensor 2 excitation	The output is used to feed an excitation current to the temperature sensor 2, see parameter 35.21 Temperature 2 source . See also section Motor thermal protection (page 83).	21								
	Abs motor speed used	01.61 Abs motor speed used (page 166).	26								
	Abs motor speed %	01.62 Abs motor speed % (page 166).	27								
	Abs output frequency	01.63 Abs output frequency (page 166).	28								
	Abs motor torque	01.64 Abs motor torque (page 166).	30								
	Abs output power	01.65 Abs output power (page 166).	31								
	Abs motor shaft power	01.68 Abs motor shaft power (page 166).	32								
	AO1 data storage	13.91 AO1 data storage (page 196).	37								

No.	Name/Value	Description	Def/FbEq16
	AO2 data storage	13.92 AO2 data storage (page 196).	38
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
13.13	AO1 forced value	Forced value that can be used instead of the selected output signal. See parameter 13.02 AO force selection .	0.000 mA
	0.000...22.000 mA/ 0.000...11.000 V	Forced value for AO1.	1 = 1 unit
13.15	AO1 unit selection	Selects the unit for readings and settings related to analog input AO1. Note: In firmware ASCL2 and ASCL4, this setting must match the corresponding hardware setting on the drive control unit. See chapter <i>Electrical installation</i> , section <i>Switches</i> in the <i>Hardware manual</i> of the drive and the default control connections for the macro in use in chapter Control macros (page 99). Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.	<i>mA</i>
	V	Volts.	2
	mA	Milliamperes.	10
13.16	AO1 filter time	Defines the filtering time constant for analog output AO1.  $O = I \times (1 - e^{-t/T})$ <p>I = filter input (step) O = filter output t = time T = filter time constant</p>	0.100 s
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s

No.	Name/Value	Description	Def/FbEq16
13.17	AO1 source min	<p data-bbox="395 172 908 260">Defines the real minimum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the minimum required AO1 output value (defined by parameter 13.19 AO1 out at AO1 src min).</p> <div data-bbox="412 292 871 611">  <p data-bbox="412 292 871 611">The graph plots I_{AO1} (mA) on the vertical axis against the Signal (real) selected by 13.12 on the horizontal axis. The output current is constant at 13.19 mA for signals up to 13.17. Between 13.17 and 13.18, the output increases linearly from 13.19 mA to 13.20 mA. For signals greater than 13.18, the output remains constant at 13.20 mA.</p> </div> <p data-bbox="395 643 908 683">Programming 13.17 as the maximum value and 13.18 as the minimum value inverts the output.</p> <div data-bbox="412 715 871 1034">  <p data-bbox="412 715 871 1034">The graph plots I_{AO1} (mA) on the vertical axis against the Signal (real) selected by 13.12 on the horizontal axis. The output current is constant at 13.20 mA for signals up to 13.18. Between 13.18 and 13.17, the output decreases linearly from 13.20 mA to 13.19 mA. For signals greater than 13.17, the output remains constant at 13.19 mA.</p> </div>	0.0


No.	Name/Value	Description	Def/FbEq16
AO has automatic scaling. Every time the source for the AO is changed, the scaling range is changed accordingly. User given minimum and maximum values override the automatic values.			
	13.12 AO1 source , 13.22 AO2 source	13.17 AO1 source min , 13.27 AO2 source min	13.18 AO1 source max , 13.28 AO2 source max
0	Zero	N/A (Output is constant zero.)	
1	Motor speed used	0	46.01 Speed scaling
3	Output frequency	0	46.02 Frequency scaling
4	Motor current	0	Max. value of 30.17 Maximum current
5	Motor current % of motor nominal	0%	100%
6	Motor torque	0	46.03 Torque scaling
7	DC voltage	Min. value of 01.11 DC voltage	Max. value of 01.11 DC voltage
8	Output power	0	46.04 Power scaling
14	Freq ref used	0	46.02 Frequency scaling
16	Process PID out	Min. value of 40.01 Process PID output actual	Max. value of 40.01 Process PID output actual
20	Temp sensor 1 excitation	N/A (Analog output is not scaled; it is determined by the sensor's triggering voltage.)	
21	Temp sensor 2 excitation	N/A (Analog output is not scaled; it is determined by the sensor's triggering voltage.)	
26	Abs motor speed used	0	46.01 Speed scaling
27	Abs motor speed %	0	46.01 Speed scaling
28	Abs output frequency	0	46.02 Frequency scaling
30	Abs motor torque	0	46.03 Torque scaling
31	Abs output power	0	46.04 Power scaling
32	Abs motor shaft power	0	46.04 Power scaling
37	AO1 data storage	13.91 AO1 data storage (page 196).	-
38	AO2 data storage	13.92 AO2 data storage (page 196).	-
	Other	Min. value of the selected parameter	Max. value of the selected parameter
	-32768.0...32767.0	Real signal value corresponding to minimum AO1 output value.	1 = 1
13.18	AO1 source max	Defines the real maximum value of the signal (selected by parameter 13.12 AO1 source) that corresponds to the maximum required AO1 output value (defined by parameter 13.20 AO1 out at AO1 src max). See parameter 13.17 AO1 source min .	50.0
	-32768.0...32767.0	Real signal value corresponding to maximum AO1 output value.	1 = 1
13.19	AO1 out at AO1 src min	Defines the minimum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min .	0.000 mA
	0.000...22.000 mA / 0.000...11.000 V	Minimum AO1 output value.	1000 = 1 mA
13.20	AO1 out at AO1 src max	Defines the maximum output value for analog output AO1. See also drawing at parameter 13.17 AO1 source min .	20.000 mA
	0.000...22.000 mA / 0.000...11.000 V	Maximum AO1 output value.	1000 = 1 mA

No.	Name/Value	Description	Def/FbEq16
13.21	<i>AO2 actual value</i>	Displays the value of AO2 in mA. This parameter is read-only.	0.000
	0.000 ... 22.000 mA	Value of AO2.	1000 = 1 mA
13.22	<i>AO2 source</i>	Selects a signal to be connected to analog output AO2. Alternatively, sets the output to excitation mode to feed a constant current to a temperature sensor. For the selections, see parameter 13.12 AO1 source .	<i>Motor current</i>
13.23	<i>AO2 forced value</i>	Forced value that can be used instead of the selected output signal. See parameter 13.02 AO force selection .	0.000 mA
	0.000 ... 22.000 mA	Forced value for AO2.	1000 = 1 mA
13.26	<i>AO2 filter time</i>	Defines the filtering time constant for analog output AO2. See parameter 13.16 AO1 filter time .	0.100 s
	0.000 ... 30.000 s	Filter time constant.	1000 = 1 s
13.27	<i>AO2 source min</i>	Defines the real minimum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the minimum required AO2 output value (defined by parameter 13.29 AO2 out at AO2 src min). See parameter 13.17 AO1 source min about the AO automatic scaling.	0.0
		 <p>Programming 13.27 as the maximum value and 13.28 as the minimum value inverts the output.</p> 	
	-32768.0...32767.0	Real signal value corresponding to minimum AO2 output value.	1 = 1

No.	Name/Value	Description	Def/FbEq16
13.28	<i>AO2 source max</i>	Defines the real maximum value of the signal (selected by parameter 13.22 AO2 source) that corresponds to the maximum required AO2 output value (defined by parameter 13.30 AO2 out at AO2 src max). See parameter 13.27 AO2 source min . See parameter 13.17 AO1 source min about the AO automatic scaling.	3.2
	-32768.0...32767.0	Real signal value corresponding to maximum AO2 output value.	1 = 1
13.29	<i>AO2 out at AO2 src min</i>	Defines the minimum output value for analog output AO2. See also drawing at parameter 13.27 AO2 source min .	4.000 mA
	0.000 ... 22.000 mA	Minimum AO2 output value.	1000 = 1 mA
13.30	<i>AO2 out at AO2 src max</i>	Defines the maximum output value for analog output AO2. See also drawing at parameter 13.27 AO2 source min .	20.000 mA
	0.000 ... 22.000 mA	Maximum AO2 output value.	1000 = 1 mA
13.91	<i>AO1 data storage</i>	Storage parameter for controlling analog output AO1 e.g. through the embedded fieldbus interface. In parameter 13.12 AO1 source , select AO1 data storage . Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.101...58.114) to AO1 data storage .	0.00
	-327.68...327.67	Storage parameter for AO1.	100 = 1
13.92	<i>AO2 data storage</i>	Storage parameter for controlling analog output AO2 e.g. through the embedded fieldbus interface. In parameter 13.22 AO2 source , select AO2 data storage . Then set this parameter as the target of the incoming value data. With the embedded fieldbus interface, simply set the target selection parameter of that particular data (58.101...58.114) to AO2 data storage .	0.00
	-327.68...327.67	Storage parameter for AO2.	100 = 1

19 Operation mode		Selection of local and external control location sources and operating modes. See also section Operating modes of the drive (page 37).	
19.01	<i>Actual operation mode</i>	Displays the operating mode currently used. See parameters 19.11...19.14 . This parameter is read-only.	<i>Scalar (Hz)</i>
	Zero	None.	1
	Speed	Speed control (in vector motor control mode).	2
	Torque	Torque control (in vector motor control mode).	3
	Min	The torque selector is comparing the output of the speed controller (25.01 Torque reference speed control) and torque reference (26.74 Torque ref ramp out) and the smaller of the two is used (in vector motor control mode).	4
	Max	The torque selector is comparing the output of the speed controller (25.01 Torque reference speed control) and torque reference (26.74 Torque ref ramp out) and the greater of the two is used (in vector motor control mode).	5
	Add	The speed controller output is added to the torque reference (in vector motor control mode).	6
	Reserved		7...9

No.	Name/Value	Description	Def/FbEq16
	Scalar (Hz)	Frequency control in scalar motor control mode (in scalar motor control mode).	10
	Forced magn.	Motor is in magnetizing mode.	20
19.11	<i>Ext1/Ext2 selection</i>	Selects the source for external control location EXT1/EXT2 selection. 0 = EXT1 1 = EXT2	<i>EXT1</i>
	EXT1	EXT1 (permanently selected).	0
	EXT2	EXT2 (permanently selected).	1
	FBA A MCW bit 11	Control word bit 11 received through fieldbus interface A.	2
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	3
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	4
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	5
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	6
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	7
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	8
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	19
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	20
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	21
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264).	25
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264).	26
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264).	27
	EFB MCW bit 11	Control word bit 11 received through the embedded fieldbus interface.	32
	FBA A connection loss	Detected communication loss of fieldbus interface A changes control mode to EXT2.	33
	EFB connection loss	Detected communication loss of embedded fieldbus interface changes control mode to EXT2.	35
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
19.12	<i>Ext1 control mode</i>	Selects the operating mode for external control location EXT1 in vector motor control mode.	<i>Speed</i>
	Zero	None.	1
	Speed	Speed control. The torque reference used is <i>25.01 Torque reference speed control</i> (output of the speed reference chain).	2
	Torque	Torque control. The torque reference used is <i>26.74 Torque ref ramp out</i> (output of the torque reference chain).	3
	Minimum	Combination of selections Speed and Torque: the torque selector compares the speed controller output (<i>25.01 Torque reference speed control</i>) and the torque reference (<i>26.74 Torque ref ramp out</i>) and selects the smaller of the two. If speed error becomes negative, the drive follows the speed controller output until speed error becomes positive again. This prevents the drive from accelerating uncontrollably if the load is lost in torque control.	4

No.	Name/Value	Description	Def/FbEq16								
	Maximum	Combination of selections Speed and Torque: the torque selector compares the speed controller output (25.01 Torque reference speed control) and the torque reference (26.74 Torque ref ramp out) and selects the greater of the two. If speed error becomes positive, the drive follows the speed controller output until speed error becomes negative again. This prevents the drive from accelerating uncontrollably if the load is lost in torque control.	5								
19.14	Ext2 control mode	Selects the operating mode for external control location EXT2 in vector motor control mode. For the selections, see parameter 19.12 Ext1 control mode .	Speed								
19.16	Local control mode	Selects the operating mode for local control in vector motor control mode.	Speed								
	Speed	Speed control. The torque reference used is 25.01 Torque reference speed control (output of the speed reference chain).	0								
	Torque	Torque control. The torque reference used is 26.74 Torque ref ramp out (output of the torque reference chain).	1								
19.17	Local control disable	Enables/disables local control (startHand and stopOff buttons on the control panel, and the local controls on the PC tool).  WARNING! Before disabling local control, ensure that the control panel is not needed for stopping the drive.	No								
	No	Local control enabled.	0								
	Yes	Local control disabled.	1								
20 Start/stop/direction		Start/stop/direction and run/start/jog enable signal source selection; positive/negative reference enable signal source selection. For information on control locations, see section Local control vs. external control (page 33).									
20.01	Ext1 commands	Selects the source of start, stop and direction commands for external control location 1 (EXT1). See also parameters 20.02 .. 20.05 . See parameter 20.21 for the determination of the actual direction.	In1 Start; In2 Dir								
	Not selected	No start or stop command sources selected.	0								
	In1 Start	The source of the start and stop commands is selected by parameter 20.03 Ext1 in1 source . The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="344 1141 692 1248"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1 (20.02 = Edge)</td> <td>Start</td> </tr> <tr> <td>1 (20.02 = Level)</td> <td>Stop</td> </tr> <tr> <td>0</td> <td>Stop</td> </tr> </tbody> </table>	State of source 1 (20.03)	Command	0 -> 1 (20.02 = Edge)	Start	1 (20.02 = Level)	Stop	0	Stop	1
State of source 1 (20.03)	Command										
0 -> 1 (20.02 = Edge)	Start										
1 (20.02 = Level)	Stop										
0	Stop										


No.	Name/Value	Description	Def/FbEq16															
	In1 Start; In2 Dir	<p>The source selected by 20.03 Ext1 in1 source is the start signal; the source selected by 20.04 Ext1 in2 source determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="395 279 910 406"> <thead> <tr> <th data-bbox="395 279 591 323">State of source 1 (20.03)</th> <th data-bbox="596 279 792 323">State of source 2 (20.04)</th> <th data-bbox="798 279 910 323">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="395 331 591 355">0</td> <td data-bbox="596 331 792 355">Any</td> <td data-bbox="798 331 910 355">Stop</td> </tr> <tr> <td data-bbox="395 363 591 387">0 -> 1 (20.02 = Edge)</td> <td data-bbox="596 363 792 387">0</td> <td data-bbox="798 363 910 387">Start forward</td> </tr> <tr> <td data-bbox="395 395 591 419">1 (20.02 = Level)</td> <td data-bbox="596 395 792 419">1</td> <td data-bbox="798 395 910 419">Start reverse</td> </tr> </tbody> </table>	State of source 1 (20.03)	State of source 2 (20.04)	Command	0	Any	Stop	0 -> 1 (20.02 = Edge)	0	Start forward	1 (20.02 = Level)	1	Start reverse	2			
State of source 1 (20.03)	State of source 2 (20.04)	Command																
0	Any	Stop																
0 -> 1 (20.02 = Edge)	0	Start forward																
1 (20.02 = Level)	1	Start reverse																
	In1 Start fwd; In2 Start rev	<p>The source selected by 20.03 Ext1 in1 source is the forward start signal; the source selected by 20.04 Ext1 in2 source is the reverse start signal. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="395 534 910 742"> <thead> <tr> <th data-bbox="395 534 591 579">State of source 1 (20.03)</th> <th data-bbox="596 534 792 579">State of source 2 (20.04)</th> <th data-bbox="798 534 910 579">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="395 587 591 611">0</td> <td data-bbox="596 587 792 611">0</td> <td data-bbox="798 587 910 611">Stop</td> </tr> <tr> <td data-bbox="395 619 591 663">0 -> 1 (20.02 = Edge) 1 (20.02 = Level)</td> <td data-bbox="596 619 792 663">0</td> <td data-bbox="798 619 910 663">Start forward</td> </tr> <tr> <td data-bbox="395 671 591 716">0</td> <td data-bbox="596 671 792 716">0 -> 1 (20.02 = Edge) 1 (20.02 = Level)</td> <td data-bbox="798 671 910 716">Start reverse</td> </tr> <tr> <td data-bbox="395 724 591 748">1</td> <td data-bbox="596 724 792 748">1</td> <td data-bbox="798 724 910 748">Stop</td> </tr> </tbody> </table>	State of source 1 (20.03)	State of source 2 (20.04)	Command	0	0	Stop	0 -> 1 (20.02 = Edge) 1 (20.02 = Level)	0	Start forward	0	0 -> 1 (20.02 = Edge) 1 (20.02 = Level)	Start reverse	1	1	Stop	3
State of source 1 (20.03)	State of source 2 (20.04)	Command																
0	0	Stop																
0 -> 1 (20.02 = Edge) 1 (20.02 = Level)	0	Start forward																
0	0 -> 1 (20.02 = Edge) 1 (20.02 = Level)	Start reverse																
1	1	Stop																
	In1P Start; In2 Stop	<p>The sources of the start and stop commands are selected by parameters 20.03 Ext1 in1 source and 20.04 Ext1 in2 source. The state transitions of the source bits are interpreted as follows:</p> <table border="1" data-bbox="395 869 910 965"> <thead> <tr> <th data-bbox="395 869 591 914">State of source 1 (20.03)</th> <th data-bbox="596 869 792 914">State of source 2 (20.04)</th> <th data-bbox="798 869 910 914">Command</th> </tr> </thead> <tbody> <tr> <td data-bbox="395 922 591 946">0 -> 1</td> <td data-bbox="596 922 792 946">1</td> <td data-bbox="798 922 910 946">Start</td> </tr> <tr> <td data-bbox="395 954 591 978">Any</td> <td data-bbox="596 954 792 978">0</td> <td data-bbox="798 954 910 978">Stop</td> </tr> </tbody> </table> <p>Notes:</p> <ul data-bbox="395 1013 910 1098" style="list-style-type: none"> Parameter 20.02 Ext1 start trigger type has no effect with this setting. When source 2 is 0, the Start and Stop keys on the control panel are disabled. 	State of source 1 (20.03)	State of source 2 (20.04)	Command	0 -> 1	1	Start	Any	0	Stop	4						
State of source 1 (20.03)	State of source 2 (20.04)	Command																
0 -> 1	1	Start																
Any	0	Stop																

No.	Name/Value	Description	Def/FbEq16																
	In1P Start; In2 Stop; In3 Dir	<p>The sources of the start and stop commands are selected by parameters 20.03 Ext1 in1 source and 20.04 Ext1 in2 source. The source selected by 20.05 Ext1 in3 source determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>State of source 2 (20.04)</th> <th>State of source 3 (20.05)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0 -> 1</td> <td>1</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Any</td> <td>Stop</td> </tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> Parameter 20.02 Ext1 start trigger type has no effect with this setting. When source 2 is 0, the Start and Stop keys on the control panel are disabled. 	State of source 1 (20.03)	State of source 2 (20.04)	State of source 3 (20.05)	Command	0 -> 1	1	0	Start forward	0 -> 1	1	1	Start reverse	Any	0	Any	Stop	5
State of source 1 (20.03)	State of source 2 (20.04)	State of source 3 (20.05)	Command																
0 -> 1	1	0	Start forward																
0 -> 1	1	1	Start reverse																
Any	0	Any	Stop																
	In1P Start fwd; In2P Start rev; In3 Stop	<p>The sources of the start and stop commands are selected by parameters 20.03 Ext1 in1 source, 20.04 Ext1 in2 source and 20.05 Ext1 in3 source. The source selected by 20.05 Ext1 in3 source determines the stop. The state transitions of the source bits are interpreted as follows:</p> <table border="1"> <thead> <tr> <th>State of source 1 (20.03)</th> <th>State of source 2 (20.04)</th> <th>State of source 3 (20.05)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>Any</td> <td>1</td> <td>Start forward</td> </tr> <tr> <td>Any</td> <td>0 -> 1</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>Any</td> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table> <p>Note: Parameter 20.02 Ext1 start trigger type has no effect with this setting.</p>	State of source 1 (20.03)	State of source 2 (20.04)	State of source 3 (20.05)	Command	0 -> 1	Any	1	Start forward	Any	0 -> 1	1	Start reverse	Any	Any	0	Stop	6
State of source 1 (20.03)	State of source 2 (20.04)	State of source 3 (20.05)	Command																
0 -> 1	Any	1	Start forward																
Any	0 -> 1	1	Start reverse																
Any	Any	0	Stop																
	Control panel	The start and stop commands are taken from the control panel (or PC connected to the panel connector).	11																
	Fieldbus A	The start and stop commands are taken from fieldbus adapter A. Note: Set also 20.02 Ext1 start trigger type to <i>Level</i> .	12																
	Embedded fieldbus	The start and stop commands are taken from the embedded fieldbus interface. Note: Set also 20.02 Ext1 start trigger type to <i>Level</i> .	14																
20.02	Ext1 start trigger type	<p>Defines whether the start signal for external control location EXT1 is edge-triggered or level-triggered.</p> <p>Note: This parameter is not effective if a pulse-type start signal is selected. See the descriptions of the selections of parameter 20.01 Ext1 commands.</p>	<i>Level</i>																
	Edge	The start signal is edge-triggered.	0																
	Level	The start signal is level-triggered.	1																
20.03	Ext1 in1 source	Selects source 1 for parameter 20.01 Ext1 commands .	<i>DI1</i>																
	Always off	0 (always off).	0																
	Always on	1 (always on).	1																
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2																
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3																

No.	Name/Value	Description	Def/FbEq16												
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4												
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5												
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6												
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7												
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	18												
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	19												
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	20												
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264).	24												
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264).	25												
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264).	26												
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-												
<i>20.04</i>	<i>Ext1 in2 source</i>	Selects source 2 for parameter <i>20.01 Ext1 commands</i> . For the available selections, see parameter <i>20.03 Ext1 in1 source</i> .	<i>DI2</i>												
<i>20.05</i>	<i>Ext1 in3 source</i>	Selects source 3 for parameter <i>20.01 Ext1 commands</i> . For the available selections, see parameter <i>20.03 Ext1 in1 source</i> .	<i>Always off</i>												
<i>20.06</i>	<i>Ext2 commands</i>	Selects the source of start, stop and direction commands for external control location 2 (EXT2). See also parameters <i>20.07...20.10</i> . See parameter <i>20.21</i> for the determination of the actual direction.	<i>Not selected</i>												
	Not selected	No start or stop command sources selected.	0												
	In1 Start	The source of the start and stop commands is selected by parameter <i>20.08 Ext2 in1 source</i> . The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="396 895 743 1002"> <thead> <tr> <th>State of source 1 (<i>20.08</i>)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1 (<i>20.07 = Edge</i>)</td> <td>Start</td> </tr> <tr> <td>1 (<i>20.07 = Level</i>)</td> <td>Stop</td> </tr> <tr> <td>0</td> <td>Stop</td> </tr> </tbody> </table>	State of source 1 (<i>20.08</i>)	Command	0 -> 1 (<i>20.07 = Edge</i>)	Start	1 (<i>20.07 = Level</i>)	Stop	0	Stop	1				
State of source 1 (<i>20.08</i>)	Command														
0 -> 1 (<i>20.07 = Edge</i>)	Start														
1 (<i>20.07 = Level</i>)	Stop														
0	Stop														
	In1 Start; In2 Dir	The source selected by <i>20.08 Ext2 in1 source</i> is the start signal; the source selected by <i>20.09 Ext2 in2 source</i> determines the direction. The state transitions of the source bits are interpreted as follows: <table border="1" data-bbox="396 1129 904 1257"> <thead> <tr> <th>State of source 1 (<i>20.08</i>)</th> <th>State of source 2 (<i>20.09</i>)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Any</td> <td>Stop</td> </tr> <tr> <td>0 -> 1 (<i>20.07 = Edge</i>)</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>1 (<i>20.07 = Level</i>)</td> <td>1</td> <td>Start reverse</td> </tr> </tbody> </table>	State of source 1 (<i>20.08</i>)	State of source 2 (<i>20.09</i>)	Command	0	Any	Stop	0 -> 1 (<i>20.07 = Edge</i>)	0	Start forward	1 (<i>20.07 = Level</i>)	1	Start reverse	2
State of source 1 (<i>20.08</i>)	State of source 2 (<i>20.09</i>)	Command													
0	Any	Stop													
0 -> 1 (<i>20.07 = Edge</i>)	0	Start forward													
1 (<i>20.07 = Level</i>)	1	Start reverse													

202 Parameters

No.	Name/Value	Description	Def/FbEq16																
	In1 Start fwd; In2 Start rev	<p>The source selected by 20.08 Ext2 in1 source is the forward start signal; the source selected by 20.09 Ext2 in2 source is the reverse start signal. The state transitions of the source bits are interpreted as follows:</p> <table border="1"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Stop</td> </tr> <tr> <td>0 -> 1 (20.07 = Edge) 1 (20.07 = Level)</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0</td> <td>0 -> 1 (20.07 = Edge) 1 (20.07 = Level)</td> <td>Start reverse</td> </tr> <tr> <td>1</td> <td>1</td> <td>Stop</td> </tr> </tbody> </table>	State of source 1 (20.08)	State of source 2 (20.09)	Command	0	0	Stop	0 -> 1 (20.07 = Edge) 1 (20.07 = Level)	0	Start forward	0	0 -> 1 (20.07 = Edge) 1 (20.07 = Level)	Start reverse	1	1	Stop	3	
State of source 1 (20.08)	State of source 2 (20.09)	Command																	
0	0	Stop																	
0 -> 1 (20.07 = Edge) 1 (20.07 = Level)	0	Start forward																	
0	0 -> 1 (20.07 = Edge) 1 (20.07 = Level)	Start reverse																	
1	1	Stop																	
	In1P Start; In2 Stop	<p>The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The state transitions of the source bits are interpreted as follows:</p> <table border="1"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>Start</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> Parameter 20.07 Ext2 start trigger type has no effect with this setting. When source 2 is 0, the Start and Stop keys on the control panel are disabled. 	State of source 1 (20.08)	State of source 2 (20.09)	Command	0 -> 1	1	Start	Any	0	Stop	4							
State of source 1 (20.08)	State of source 2 (20.09)	Command																	
0 -> 1	1	Start																	
Any	0	Stop																	
	In1P Start; In2 Stop; In3 Dir	<p>The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source and 20.09 Ext2 in2 source. The source selected by 20.10 Ext2 in3 source determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>State of source 3 (20.10)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>1</td> <td>0</td> <td>Start forward</td> </tr> <tr> <td>0 -> 1</td> <td>1</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>Any</td> <td>0</td> <td>Any</td> <td>Stop</td> </tr> </tbody> </table> <p>Notes:</p> <ul style="list-style-type: none"> Parameter 20.07 Ext2 start trigger type has no effect with this setting. When source 2 is 0, the Start and Stop keys on the control panel are disabled. 	State of source 1 (20.08)	State of source 2 (20.09)	State of source 3 (20.10)	Command	0 -> 1	1	0	Start forward	0 -> 1	1	1	Start reverse	Any	0	Any	Stop	5
State of source 1 (20.08)	State of source 2 (20.09)	State of source 3 (20.10)	Command																
0 -> 1	1	0	Start forward																
0 -> 1	1	1	Start reverse																
Any	0	Any	Stop																

No.	Name/Value	Description	Def/FbEq16																
	In1P Start fwd; In2P Start rev; In3 Stop	<p>The sources of the start and stop commands are selected by parameters 20.08 Ext2 in1 source, 20.09 Ext2 in2 source and 20.10 Ext2 in3 source. The source selected by 20.10 Ext2 in3 source determines the direction. The state transitions of the source bits are interpreted as follows:</p> <table border="1"> <thead> <tr> <th>State of source 1 (20.08)</th> <th>State of source 2 (20.09)</th> <th>State of source 3 (20.10)</th> <th>Command</th> </tr> </thead> <tbody> <tr> <td>0 -> 1</td> <td>Any</td> <td>1</td> <td>Start forward</td> </tr> <tr> <td>Any</td> <td>0 -> 1</td> <td>1</td> <td>Start reverse</td> </tr> <tr> <td>Any</td> <td>Any</td> <td>0</td> <td>Stop</td> </tr> </tbody> </table> <p>Note: Parameter 20.07 Ext2 start trigger type has no effect with this setting.</p>	State of source 1 (20.08)	State of source 2 (20.09)	State of source 3 (20.10)	Command	0 -> 1	Any	1	Start forward	Any	0 -> 1	1	Start reverse	Any	Any	0	Stop	6
State of source 1 (20.08)	State of source 2 (20.09)	State of source 3 (20.10)	Command																
0 -> 1	Any	1	Start forward																
Any	0 -> 1	1	Start reverse																
Any	Any	0	Stop																
	Control panel	The start and stop commands are taken from the control panel (or PC connected to the panel connector).	11																
	Fieldbus A	The start and stop commands are taken from fieldbus adapter A. Note: Set also 20.07 Ext2 start trigger type to <i>Level</i> .	12																
	Embedded fieldbus	The start and stop commands are taken from the embedded fieldbus interface. Note: Set also 20.07 Ext2 start trigger type to <i>Level</i> .	14																
20.07	Ext2 start trigger type	Defines whether the start signal for external control location EXT2 is edge-triggered or level-triggered. Note: This parameter is not effective if a pulse-type start signal is selected. See the descriptions of the selections of parameter 20.06 Ext2 commands .	<i>Level</i>																
	Edge	The start signal is edge-triggered.	0																
	Level	The start signal is level-triggered.	1																
20.08	Ext2 in1 source	Selects source 1 for parameter 20.06 Ext2 commands . For the available selections, see parameter 20.03 Ext1 in1 source .	<i>Always off</i>																
20.09	Ext2 in2 source	Selects source 2 for parameter 20.06 Ext2 commands . For the available selections, see parameter 20.03 Ext1 in1 source .	<i>Always off</i>																
20.10	Ext2 in3 source	Selects source 3 for parameter 20.06 Ext2 commands . For the available selections, see parameter 20.03 Ext1 in1 source .	<i>Always off</i>																
20.11	Run enable stop mode	Selects the way the motor is stopped when the run enable signal switches off. The source of the run enable signal is selected by parameter 20.12 Run enable 1 source .	<i>Coast</i>																
	Coast	Stops by switching off the output semiconductors of the drive. The motor coasts to a stop.  WARNING! If a mechanical brake is used, ensure it is safe to stop the drive by coasting.	0																
	Ramp	Stops along the active deceleration ramp. See parameter group 23 Speed reference ramp on page 224 .	1																
	Torque limit	Stops according to torque limits (parameters 30.19 and 30.20).	2																



204 Parameters

No.	Name/Value	Description	Def/FbEq16
20.12	<i>Run enable 1 source</i>	Selects the source of the external run enable signal. If the run enable signal is switched off, the drive will not start. If already running, the drive will stop according to the setting of parameter 20.11 Run enable stop mode . 1 = Run enable signal on. See also parameter 20.19 Enable start command .	<i>Selected</i>
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2)	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5)	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271)	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271)	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271)	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264)	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264)	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264)	26
	FBAA MCW bit 3	Control word bit 3 received through fieldbus interface A	30
	EFB MCW bit 3	Control word bit 3 received through the embedded fieldbus interface	32
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160)	-
20.19	<i>Enable start command</i>	Selects the source for the start enable signal. 1 = Start enable. With the signal switched off, any drive start command is inhibited. (Switching the signal off while the drive is running will not stop the drive.) See also parameter 20.12 Run enable 1 source .	<i>Selected</i>
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2)	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5)	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271)	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271)	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271)	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264)	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264)	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264)	26

No.	Name/Value	Description	Def/FbEq16	
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160)	-	
20.21	<i>Direction</i>	Reference direction lock. Defines the direction of the drive rather than the sign of the reference, except in some cases. In the table the actual drive rotation is shown as a function of parameter 20.21 Direction and Direction command (from DI configured in 20.01 Ext1 commands or 20.06 Ext2 commands and its related parameters).	<i>Request</i>	
	Par. 20.21 Direction	DI = Forward	DI = Reverse	DI not defined
	<i>Forward</i>	Motor rotates in forward direction	Motor rotates in forward direction	Same as forward DI
	<i>Reverse</i>	Motor rotates in reverse direction	Motor rotates in reverse direction	Same as reverse DI
	<i>Request</i>			
	Reference from motor potentiometer reference /other	Motor rotates in forward direction	Motor rotates in reverse direction	Same as forward DI
	Reference from AI/FB/EFB/Control Panel Ref Saved & Copied/Safe Speed / Last Speed	Motor rotates in direction of reference	Motor rotates always in reverse direction (-1 * ABS [Reference])	Same as forward DI
	Reference from Constant Speed/ PID / Jog ref	Motor rotates in direction of reference [DI have no effect]	Motor rotates in direction of reference [DI have no effect]	DI have no effect
	Request	Refer the table above for rotation direction of motor.		0
	Forward	Motor rotates forward regardless of the sign of the external reference. (Negative reference values are replaced by zero. Positive reference values are used as is.)		1
	Reverse	Motor rotates reverse regardless of the sign of the external reference. (Negative reference values are replaced by zero. Positive reference values are multiplied by -1.)		2
20.22	<i>Enable to rotate</i>	Setting this parameter to 0 stops motor rotating but does not affect any other conditions for rotating. Setting the parameter back to 1 starts motor rotating again. This parameter can be used for example with a signal from some external equipment to prevent the motor rotating before the equipment is ready. When this parameter is 0 (rotating of the motor is disabled), bit 13 of parameter 06.16 Drive status word 1 is set to 0.	<i>Selected</i>	
	Not selected	0 (always off)		0
	Selected	1 (always on)		1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0)		2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1)		3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2)		4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3)		5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4)		6



No.	Name/Value	Description	Def/FbEq16
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5)	7
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271)	18
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271)	19
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	20
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264)	24
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264)	25
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264)	26
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160)	-
20.25	<i>Jogging enable</i>	<p>Selects the source for a jog enable signal. (The sources for jogging activation signals are selected by parameters <i>20.26 Jogging 1 start source</i> and <i>20.27 Jogging 2 start source</i>.)</p> <p>1 = Jogging is enabled. 0 = Jogging is disabled.</p> <p>Note: Jogging can be enabled only when no start command from an external control location is active. On the other hand, if jogging is already enabled, the drive cannot be started from an external control location (apart from inching commands through fieldbus). See section <i>Rush control</i> (page 73).</p>	<i>Not selected</i>
	Not selected	0	0
	Selected	1	1
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0)	2
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1)	3
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2)	4
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3)	5
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4)	6
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5)	7
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271)	18
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271)	19
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271)	20
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264)	24
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264)	25
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264)	26
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160)	-
20.26	<i>Jogging 1 start source</i>	<p>If enabled by parameter <i>20.25 Jogging enable</i>, selects the source for the activation of jogging function 1. (Jogging function 1 can also be activated through fieldbus regardless of parameter <i>20.25</i>.)</p> <p>1 = Jogging 1 active</p> <p>Notes:</p> <ul style="list-style-type: none"> If both jogging 1 and 2 are activated, the one that was activated first has priority. This parameter cannot be changed while the drive is running. 	<i>Not selected</i>
	Not selected	0	0
	Selected	1	1

No.	Name/Value	Description	Def/FbEq16
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0)	2
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1)	3
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2)	4
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3)	5
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4)	6
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5)	7
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271)	18
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271)	19
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271)	20
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264)	24
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264)	25
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264)	26
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160)	-
<i>20.27</i>	<i>Jogging 2 start source</i>	If enabled by parameter <i>20.25 Jogging enable</i> , selects the source for the activation of jogging function 2. (Jogging function 2 can also be activated through fieldbus regardless of parameter <i>20.25</i> .) 1 = Jogging 2 active. For the selections, see parameter <i>20.26 Jogging 1 start source</i> . Notes: <ul style="list-style-type: none"> • If both jogging 1 and 2 are activated, the one that was activated first has priority. • This parameter cannot be changed while the drive is running. 	<i>Not selected</i>
21 Start/stop mode		Start and stop modes; emergency stop mode and signal source selection; DC magnetization settings.	
<i>21.01</i>	<i>Start mode</i>	Selects the motor start function for the vector motor control mode, ie. when <i>99.04 Motor control mode</i> is set to <i>Vector</i> . Notes: <ul style="list-style-type: none"> • The start function for the scalar motor control mode is selected by parameter <i>21.19 Scalar start mode</i>. • Starting into a rotating motor is not possible when DC magnetizing is selected (<i>Fast</i> or <i>Const time</i>). • With permanent magnet motors, <i>Automatic</i> start mode must be used. • This parameter cannot be changed while the drive is running. See also section <i>DC magnetization</i> (page 70).	<i>Automatic</i>
	Fast	The drive pre-magnetizes the motor before start. The pre-magnetizing time is determined automatically, being typically 200 ms to 2 s depending on motor size. This mode should be selected if a high break-away torque is required.	0



No.	Name/Value	Description	Def/FbEq16										
	Const time	<p>The drive pre-magnetizes the motor before start. The pre-magnetizing time is defined by parameter 21.02 Magnetization time. This mode should be selected if constant pre-magnetizing time is required (e.g. if the motor start must be synchronized with the release of a mechanical brake). This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough.</p> <p> WARNING! The drive will start after the set magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.</p>	1										
	Automatic	<p>Automatic start guarantees optimal motor start in most cases. It includes the flying start function (starting into a rotating motor) and the automatic restart function. The drive motor control program identifies the flux as well as the mechanical state of the motor and starts the motor instantly under all conditions.</p> <p>Note: If parameter 99.04 Motor control mode is set to <i>Scalar</i>, no flying start or automatic restart is possible unless parameter 21.19 Scalar start mode is set to <i>Automatic</i>.</p>	2										
21.02	Magnetization time	<p>Defines the pre-magnetization time when</p> <ul style="list-style-type: none"> parameter 21.01 Start mode is set to <i>Const time</i> (in vector motor control mode), or parameter 21.19 Scalar start mode is set to <i>Const time</i> (in scalar motor control mode). <p>After the start command, the drive automatically premagnetizes the motor for the set time. To ensure full magnetizing, set this parameter to the same value as, or higher than, the rotor time constant. If not known, use the rule-of-thumb value given in the table below:</p> <table border="1" data-bbox="344 911 852 1086"> <thead> <tr> <th>Motor rated power</th> <th>Constant magnetizing time</th> </tr> </thead> <tbody> <tr> <td>< 1 kW</td> <td>≥ 50 to 100 ms</td> </tr> <tr> <td>1 to 10 kW</td> <td>≥ 100 to 200 ms</td> </tr> <tr> <td>10 to 200 kW</td> <td>≥ 200 to 1000 ms</td> </tr> <tr> <td>200 to 1000 kW</td> <td>≥ 1000 to 2000 ms</td> </tr> </tbody> </table> <p>Note: This parameter cannot be changed while the drive is running.</p>	Motor rated power	Constant magnetizing time	< 1 kW	≥ 50 to 100 ms	1 to 10 kW	≥ 100 to 200 ms	10 to 200 kW	≥ 200 to 1000 ms	200 to 1000 kW	≥ 1000 to 2000 ms	500
Motor rated power	Constant magnetizing time												
< 1 kW	≥ 50 to 100 ms												
1 to 10 kW	≥ 100 to 200 ms												
10 to 200 kW	≥ 200 to 1000 ms												
200 to 1000 kW	≥ 1000 to 2000 ms												
	0...10000 ms	Constant DC magnetizing time.	1 = 1										
21.03	Stop mode	<p>Selects the way the motor is stopped when a stop command is received.</p> <p>Additional braking is possible by selecting flux braking (see parameter 97.05 Flux braking).</p>	<i>Coast</i>										
	Coast	<p>Stops by switching off the output semiconductors of the drive. The motor coasts to a stop.</p> <p> WARNING! If a mechanical brake is used, ensure it is safe to stop the drive by coasting.</p>	0										
	Ramp	<p>Stops along the active deceleration ramp. See parameter group 23 Speed reference ramp on page 224 or 28 Frequency reference chain on page 238.</p>	1										


No.	Name/Value	Description	Def/FbEq16
	Torque limit	Stops according to torque limits (parameters 30.19 and 30.20). This mode is only possible in vector motor control mode.	2
21.04	Emergency stop mode	Selects the way the motor is stopped when an emergency stop command is received. The source of the emergency stop signal is selected by parameter 21.05 Emergency stop source .	Ramp stop (Off1)
	Ramp stop (Off1)	With the drive running: <ul style="list-style-type: none"> • 1 = Normal operation. • 0 = Normal stop along the standard deceleration ramp defined for the particular reference type (see section Rush control [page 73]). After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1. With the drive stopped: <ul style="list-style-type: none"> • 1 = Starting allowed. • 0 = Starting not allowed. 	0
	Coast stop (Off2)	With the drive running: <ul style="list-style-type: none"> • 1 = Normal operation. • 0 = Stop by coasting. The drive can be restarted by restoring the start interlock signal and switching the start signal from 0 to 1. With the drive stopped: <ul style="list-style-type: none"> • 1 = Starting allowed. • 0 = Starting not allowed. 	1
	Eme ramp stop (Off3)	With the drive running: <ul style="list-style-type: none"> • 1 = Normal operation • 0 = Stop by ramping along emergency stop ramp defined by parameter 23.23 Emergency stop time. After the drive has stopped, it can be restarted by removing the emergency stop signal and switching the start signal from 0 to 1. With the drive stopped: <ul style="list-style-type: none"> • 1 = Starting allowed • 0 = Starting not allowed 	2
21.05	Emergency stop source	Selects the source of the emergency stop signal. The stop mode is selected by parameter 21.04 Emergency stop mode . 0 = Emergency stop active 1 = Normal operation Note: This parameter cannot be changed while the drive is running.	Inactive (true)
	Active (false)	0.	0
	Inactive (true)	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	8
	Other [bit]	Source selection (see Terms and abbreviations on page 160).	-

210 Parameters

No.	Name/Value	Description	Def/FbEq16
21.06	<i>Zero speed limit</i>	Defines the zero speed limit. The motor is stopped along a speed ramp (when ramped stop is selected or emergency stop time is used) until the defined zero speed limit is reached. After the zero speed delay, the motor coasts to a stop.	30.00 rpm
	0.00...30000.00 rpm	Zero speed limit.	See par. 46.01
21.07	<i>Zero speed delay</i>	<p>Defines the delay for the zero speed delay function. The function is useful in applications where a smooth and quick restarting is essential. During the delay, the drive knows the rotor position accurately.</p> <p><u>Without zero speed delay:</u> The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter 21.06 Zero speed limit, inverter modulation is stopped and the motor coasts to a standstill.</p>  <p><u>With zero speed delay:</u> The drive receives a stop command and decelerates along a ramp. When actual motor speed falls below the value of parameter 21.06 Zero speed limit, the zero speed delay function activates. During the delay the function keeps the speed controller live: the inverter modulates, motor is magnetized and the drive is ready for a quick restart. Zero speed delay can be used e.g. with the jogging function.</p> 	0 ms
	0...30000 ms	Zero speed delay.	1 = 1

No.	Name/Value	Description	Def/FbEq16								
21.08	<i>DC current control</i>	<p>Activates/deactivates the DC hold and post-magnetization functions. See section <i>DC magnetization</i> (page 70).</p> <p>Note: DC magnetization causes the motor to heat up. In applications where long DC magnetization times are required, externally ventilated motors should be used. If the DC magnetization period is long, DC magnetization cannot prevent the motor shaft from rotating if a constant load is applied to the motor.</p>	0b0000								
<table border="1"> <thead> <tr> <th>Bit</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>1 = Enable DC hold. See section <i>DC hold</i> (page 70). Note: The DC hold function has no effect if the start signal is switched off.</td> </tr> <tr> <td>1</td> <td>1 = Enable post-magnetization. See section <i>Settings</i> (page 71). Note: Post-magnetization is only available when ramping is the selected stop mode (see parameter <i>21.03 Stop mode</i>).</td> </tr> <tr> <td>2...15</td> <td>Reserved</td> </tr> </tbody> </table>				Bit	Value	0	1 = Enable DC hold. See section <i>DC hold</i> (page 70). Note: The DC hold function has no effect if the start signal is switched off.	1	1 = Enable post-magnetization. See section <i>Settings</i> (page 71). Note: Post-magnetization is only available when ramping is the selected stop mode (see parameter <i>21.03 Stop mode</i>).	2...15	Reserved
Bit	Value										
0	1 = Enable DC hold. See section <i>DC hold</i> (page 70). Note: The DC hold function has no effect if the start signal is switched off.										
1	1 = Enable post-magnetization. See section <i>Settings</i> (page 71). Note: Post-magnetization is only available when ramping is the selected stop mode (see parameter <i>21.03 Stop mode</i>).										
2...15	Reserved										
	0b000...0b1111	DC magnetization selection.	1 = 1								
21.09	<i>DC hold speed</i>	Defines the DC hold speed in speed control mode. See parameter <i>21.08 DC current control</i> , and section <i>DC hold</i> (page 70).	5.00 rp								
	0.00...1000.00 rpm	DC hold speed.	See par. 46.01								
21.10	<i>DC current reference</i>	Defines the DC hold current in percent of the motor nominal current. See parameter <i>21.08 DC current control</i> , and section <i>DC magnetization</i> (page 70). After 100 s post-magnetization time, the maximum magnetization current is limited to the magnetization current corresponding to the actual flux reference.	30.0								
	0.0...100.0%	DC hold current.	1 = 1								
21.11	<i>Post magnetization time</i>	Defines the length of time for which post-magnetization is active after stopping the motor. The magnetization current is defined by parameter <i>21.10 DC current reference</i> . See parameter <i>21.08 DC current control</i> .	0								
	0...3000 s	Post-magnetization time.	1 = 1								
21.14	<i>Pre-heating input source</i>	<p>Selects the source for controlling pre-heating for the motor. The status of the pre-heating is shown as bit 2 of <i>06.21 Drive status word 3</i>.</p> <p>Notes:</p> <ul style="list-style-type: none"> The heating function requires that STO is not triggered. The heating function requires that the drive is not faulted. 	<i>Off</i>								
	Off	0. Pre-heating is always deactivated.	0								
	On	1. Pre-heating is always activated when the drive is stopped.	1								
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0)	2								
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1)	3								
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2)	4								
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3)	5								
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4)	6								
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5)	7								

No.	Name/Value	Description	Def/FbEq16
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264)	8
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264)	9
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264)	10
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271)	11
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271)	12
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271)	13
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160)	-
21.15	Pre-heating time delay	Time delay before pre-heating starts after the drive is stopped.	60 s
	10...3000 s	Pre-heating time delay.	1 = 1 s
21.16	Pre-heating current	Defines the DC current used to heat the motor. The value is in percent of the nominal motor current.	0.0
	0.0...30.0%	Pre-heating current.	1 = 1
21.18	Auto restart time	<p>The motor can be automatically started after a short supply power failure using the automatic restart function. See section Automatic restart (page 79).</p> <p>When this parameter is set to 0.0 seconds, automatic restarting is disabled. Otherwise, the parameter defines the maximum duration of the power failure after which restarting is attempted. Note that this time also includes the DC precharging delay.</p> <p> WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a supply break.</p>	10.0
	0.0 s	Automatic restarting disabled.	0
	0.1...10.0 s	Maximum power failure duration.	1 = 1
21.19	Scalar start mode	<p>Selects the motor start function for the scalar motor control mode, ie. when 99.04 Motor control mode is set to Scalar.</p> <p>Notes:</p> <ul style="list-style-type: none"> • The start function for the vector motor control mode is selected by parameter 21.01 Start mode. • With permanent magnet motors, Automatic start mode must be used. • This parameter cannot be changed while the drive is running. <p>See also section DC magnetization (page 70).</p>	<i>Normal</i>
	Normal	Immediate start from zero speed.	0
	Const time	<p>The drive pre-magnetizes the motor before start. The pre-magnetizing time is defined by parameter 21.02 Magnetization time. This mode should be selected if constant pre-magnetizing time is required (e.g. if the motor start must be synchronized with the release of a mechanical brake). This setting also guarantees the highest possible break-away torque when the pre-magnetizing time is set long enough.</p> <p>Note: This mode cannot be used to start into a rotating motor.</p> <p> WARNING! The drive will start after the set pre-magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.</p>	1



No.	Name/Value	Description	Def/FbEq16
	Automatic	The drive automatically selects the correct output frequency to start a rotating motor. This is useful for flying starts: if the motor is already rotating, the drive will start smoothly at the current frequency. Note: Cannot be used in multimotor systems.	2
	Torque boost	The drive pre-magnetizes the motor before the start. The pre-magnetizing time is defined by parameter 21.02 Magnetization time . Torque boost is applied at start. Torque boost is stopped when output frequency exceeds 20 Hz or when it is equal to the reference value. See parameter 21.26 Torque boost current . This mode should be selected if a high break-away torque is required. Note: This mode cannot be used to start into a rotating motor.  WARNING! The drive will start after the set pre-magnetizing time has passed even if motor magnetization is not completed. In applications where a full break-away torque is essential, ensure that the constant magnetizing time is long enough to allow generation of full magnetization and torque.	3
	Automatic+boost	Automatic start with torque boost. Automatic start is performed first and the motor is magnetized. If the speed is found to be zero, torque boost is applied.	4
	Flying start	The drive automatically selects the correct output frequency to start a rotating motor. If the motor is already rotating, drive will start smoothly at the current frequency. The mode will start the motor with vector control and switch to scalar control on the fly when the motor speed has been found. Compared to the Automatic start mode, Flying start detects the motor speed faster. Flying start requires more accurate information about motor model. Therefore standstill ID run is done automatically when the drive is started for the first time after selecting Flying start. Motor plate values should be accurate. Wrong plate values may decrease the starting performance. Note During flying start, the drive will at first run in vector control mode. This is why, when using flying start, the drive nominal current setting must be in the allowed range for vector control mode, see parameter 99.06 Motor nominal current .	5
	Flying start+boost	Flying start with torque boost. Flying start is performed first and the motor is magnetized. If the speed is found to be zero, torque boost is applied.	6
21.21	DC hold frequency	Defines the DC hold frequency, which is used instead of parameter 21.09 DC hold speed when the motor is in scalar frequency mode. See parameter 21.08 DC current control , and section DC hold (page 70).	5.00
	0.00...1000.00 Hz	DC hold frequency.	1 = 1
21.22	Start delay	Defines the start delay. After the conditions for start have been fulfilled, the drive waits until the delay has elapsed and then starts the motor. During the delay, warning AFE9 Start delay is shown. Start delay can be used with all start modes.	0.00
	0.00...60.00 s	Start delay	1 = 1

214 Parameters

No.	Name/Value	Description	Def/FbEq16
21.26	<i>Torque boost current</i>	Maximum current supplied during torque boost. Can be used for permanent magnet synchronous motors only.	100.0
	15.0...300.0%	Value in percent of the nominal motor current.	1 = 1
21.27	<i>Torque boost time</i>	Defines the minimum and maximum torque boost time. If torque boost time is less than 40% of frequency acceleration time (see parameters 28.72 and 28.74), then torque boost time is set at 40% of frequency acceleration time.	20.0 s
	0.0...60.0 s	Nominal motor time.	1 = 1%
21.30	<i>Speed compensated stop mode</i>	Selects the method used to stop the drive. See also section. Speed compensated stop (page 76). Speed compensated stop is active only if <ul style="list-style-type: none"> the operation mode is not torque, and <ul style="list-style-type: none"> parameter 21.03 Stop mode is <i>Ramp</i>, or parameter 20.11 Run enable stop mode is <i>Ramp</i> (in case Run enable is missing). 	<i>Off</i>
	Off	Stop according parameter 21.03 Stop mode , no speed compensated stop.	0
	Speed comp FWD	If the direction of rotation is forward, speed compensation is used for constant distance braking. Speed difference (between used speed and maximum speed) is compensated by running the drive with current speed before the motor is stopped along a ramp. If the direction of rotation is reverse, the drive is stopped along a ramp.	1
	Speed comp REV	If the direction of rotation is reverse, speed compensation is used for constant distance braking. Speed difference (between used speed and maximum speed) is compensated by running the drive with current speed before the motor is stopped along a ramp. If the direction of rotation is forward, the drive is stopped along a ramp.	2
	Speed comp bipolar	Regardless of the direction of rotation, speed compensation is used for constant distance braking. Speed difference (between used speed and maximum speed) is compensated by running the drive with current speed before the motor is stopped along a ramp.	3
21.31	<i>Speed comp stop delay</i>	This delay adds distance to the total distance traveled during a stop from maximum speed. It is used to adjust the distance to match requirements so that the distance traveled is not solely determined by the deceleration rate.	0.00
	0.00...1000.00 s	Speed delay.	1 = 1
21.32	<i>Speed comp stop threshold</i>	This parameter sets a speed threshold below which the Speed compensated stop feature is disabled. In this speed region, the speed compensated stop is not attempted and the drive stops as it would, using the ramp option.	10%
	0...100%	Speed threshold as a percent of the motor nominal speed.	1 = 1%
21.34	<i>Force auto restart</i>	Forces automatic restart. The parameter is applicable only if parameter 95.04 Supply voltage is set to External 24V .	<i>Disable</i>
	Disable	Force auto restart disabled. Parameter 21.18 Auto restart time is in effect if its value is more than 0.0 s.	0


No.	Name/Value	Description	Def/FbEq16
	Enable	Force auto restart enabled. Parameter 21.18 Auto restart time is ignored. The drive never trips on the undervoltage fault and the start signal is on forever. When the DC voltage is restored, the normal operation continues.	1
22 Speed reference selection			
Speed reference selection; motor potentiometer settings. See the control chain diagrams on pages 488...465 .			
22.01	Speed ref unlimited	Displays the output of the speed reference selection block. See the control chain diagram on page 465 . This parameter is read-only.	-
	-30000.00... 30000.00 rpm	Value of the selected speed reference.	See par. 46.01
22.11	Ext1 speed ref1	<p>Selects Ext1 speed reference source 1.</p> <p>Two signal sources can be defined by this parameter and 22.12 Ext1 speed ref2. A mathematical function (22.13 Ext1 speed function) applied to the two signals creates an Ext1 reference (A in the figure below).</p> <p>A digital source selected by 19.11 Ext1/Ext2 selection can be used to switch between Ext1 reference and the corresponding Ext2 reference defined by parameters 22.18 Ext2 speed ref1, 22.19 Ext2 speed ref2 and 22.20 Ext2 speed function (B in the figure below).</p>	A1 scaled
	Zero	None.	0

No.	Name/Value	Description	Def/FbEq16
	AI1 scaled	12.12 AI1 scaled value (see page 187).	1
	AI2 scaled	12.22 AI2 scaled value (see page 189).	2
	FB A ref1	03.05 FB A reference 1 (see page 166).	4
	FB A ref2	03.06 FB A reference 2 (see page 166).	5
	EFB ref1	03.09 EFB reference 1 (see page 166).	8
	EFB ref2	03.10 EFB reference 2 (see page 167).	9
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID	40.01 Process PID output actual (output of the process PID controller).	16
	Frequency input	11.38 Freq in 1 actual value (when DI5 or DI6 is used as a frequency input).	17
	Control panel (ref saved)	Panel reference (03.01 Panel reference , see page 166) saved by the control system for the location where the control returns is used as the reference. <div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p>Reference</p> </div> <div style="flex: 1;"> <ul style="list-style-type: none"> ● Ext1 reference × Ext2 reference — Active reference - - - Inactive reference </div> </div>	18
	Control panel (ref copied)	Panel reference (03.01 Panel reference , see page 166) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. <div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p>Reference</p> </div> <div style="flex: 1;"> <ul style="list-style-type: none"> ● Ext1 reference × Ext2 reference — Active reference - - - Inactive reference </div> </div>	19
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
22.12	Ext1 speed ref2	Selects Ext1 speed reference source 2. For the selections, and a diagram of reference source selection, see parameter 22.11 Ext1 speed ref1 .	<i>Zero</i>
22.13	Ext1 speed function	Selects a mathematical function between the reference sources selected by parameters 22.11 Ext1 speed ref1 and 22.12 Ext1 speed ref2 . See diagram at 22.11 Ext1 speed ref1 .	<i>Ref1</i>
	Ref1	Signal selected by 22.11 Ext1 speed ref1 is used as speed reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as speed reference 1.	1
	Sub (ref1 - ref2)	The subtraction (22.11 Ext1 speed ref1 - 22.12 Ext1 speed ref2) of the reference sources is used as speed reference 1.	2
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as speed reference 1.	3

No.	Name/Value	Description	Def/FbEq16
	Min (ref1, ref2)	The smaller of the reference sources is used as speed reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as speed reference 1.	5
22.18	<i>Ext2 speed ref1</i>	Selects Ext2 speed reference source 1. Two signal sources can be defined by this parameter and 22.19 Ext2 speed ref2 . A mathematical function (22.20 Ext2 speed function) applied to the two signals creates an Ext2 reference. See diagram at 28.11 Ext1 frequency ref1 .	Zero
	Zero	None.	0
	AI1 scaled	12.12 AI1 scaled value (see page 187).	1
	AI2 scaled	12.22 AI2 scaled value (see page 189).	2
	FB A ref1	03.05 FB A reference 1 (see page 166).	4
	FB A ref2	03.06 FB A reference 2 (see page 166).	5
	EFB ref1	03.09 EFB reference 1 (see page 166).	8
	EFB ref2	03.10 EFB reference 2 (see page 167).	9
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID	40.01 Process PID output actual (output of the process PID controller).	16
	Frequency input	11.38 Freq in 1 actual value (when DI5 or DI6 is used as a frequency input).	17
	Control panel (ref saved)	Panel reference (03.01 Panel reference , see page 166) saved by the control system for the location where the control returns is used as the reference. 	18
	Control panel (ref copied)	Panel reference (03.01 Panel reference , see page 166) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. 	19
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
22.19	<i>Ext2 speed ref2</i>	Selects Ext2 speed reference source 2. For the selections, and a diagram of reference source selection, see parameter 22.18 Ext2 speed ref1 .	Zero

218 Parameters

No.	Name/Value	Description	Def/FbEq16
22.20	<i>Ext2 speed function</i>	Selects a mathematical function between the reference sources selected by parameters 22.18 Ext2 speed ref1 and 22.19 Ext2 speed ref2 . See diagram at 22.18 Ext2 speed ref1 .	<i>Ref1</i>
	Ref1	Signal selected by <i>Ext2 speed ref1</i> is used as speed reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as speed reference 1.	1
	Sub (ref1 - ref2)	The subtraction ([22.11 Ext1 speed ref1] - [22.12 Ext1 speed ref2]) of the reference sources is used as speed reference 1.	2
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as speed reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as speed reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as speed reference 1.	5
22.21	<i>Constant speed function</i>	Determines how constant speeds are selected, and whether the rotation direction signal is considered or not when applying a constant speed.	0b0001

Bit	Name	Information
0	Constant speed mode	<p>1 = Packed: 7 constant speeds are selectable using the three sources defined by parameters 22.22, 22.23 and 22.24.</p> <p>0 = Separate: Constant speeds 1, 2 and 3 are separately activated by the sources defined by parameters 22.22, 22.23 and 22.24 respectively. In case of conflict, the constant speed with the smaller number takes priority.</p>
1	Direction enable	<p>1 = Start dir: To determine running direction for a constant speed, the sign of the constant speed setting (parameters 22.26...22.32) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant speeds if all values in 22.26...22.32 are positive.</p> <p> WARNING: If the direction signal is reverse and the active constant speed is negative, the drive will run in the forward direction.</p> <p>0 = Accord Par: The running direction for the constant speed is determined by the sign of the constant speed setting (parameters 22.26...22.32).</p>
2...15	Reserved	

0b0000...0b1111	Constant speed configuration word.	1 = 1
-----------------	------------------------------------	-------

No.	Name/Value	Description	Def/FbEq16																																				
22.22	Constant speed sel1	When bit 0 of parameter 22.21 Constant speed function is 0 (Separate), selects a source that activates constant speed 1. When bit 0 of parameter 22.21 Constant speed function is 1 (Packed), this parameter and parameters 22.23 Constant speed sel2 and 22.24 Constant speed sel3 select three sources whose states activate constant speeds as follows:	DI3																																				
<table border="1"> <thead> <tr> <th>Source defined by par. 22.22</th> <th>Source defined by par. 22.23</th> <th>Source defined by par. 22.24</th> <th>Constant speed active</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>None</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>Constant speed 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>Constant speed 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>Constant speed 3</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>Constant speed 4</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>Constant speed 5</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>Constant speed 6</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>Constant speed 7</td> </tr> </tbody> </table>				Source defined by par. 22.22	Source defined by par. 22.23	Source defined by par. 22.24	Constant speed active	0	0	0	None	1	0	0	Constant speed 1	0	1	0	Constant speed 2	1	1	0	Constant speed 3	0	0	1	Constant speed 4	1	0	1	Constant speed 5	0	1	1	Constant speed 6	1	1	1	Constant speed 7
Source defined by par. 22.22	Source defined by par. 22.23	Source defined by par. 22.24	Constant speed active																																				
0	0	0	None																																				
1	0	0	Constant speed 1																																				
0	1	0	Constant speed 2																																				
1	1	0	Constant speed 3																																				
0	0	1	Constant speed 4																																				
1	0	1	Constant speed 5																																				
0	1	1	Constant speed 6																																				
1	1	1	Constant speed 7																																				
	Always off	0 (always off).	0																																				
	Always on	1 (always on).	1																																				
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2																																				
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3																																				
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4																																				
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5																																				
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6																																				
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7																																				
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271).	18																																				
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271).	19																																				
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271).	20																																				
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264).	24																																				
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264).	25																																				
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264).	26																																				
	Other [bit]	Source selection (see Terms and abbreviations on page 160).	-																																				
22.23	Constant speed sel2	When bit 0 of parameter 22.21 Constant speed function is 0 (Separate), selects a source that activates constant speed 2. When bit 0 of parameter 22.21 Constant speed function is 1 (Packed), this parameter and parameters 22.22 Constant speed sel1 and 22.24 Constant speed sel3 select three sources that are used to activate constant speeds. See table at parameter 22.22 Constant speed sel1 . For the selections, see parameter 22.22 Constant speed sel1 .	DI4																																				
22.24	Constant speed sel3	When bit 0 of parameter 22.21 Constant speed function is 0 (Separate), selects a source that activates constant speed 3. When bit 0 of parameter 22.21 Constant speed function is 1 (Packed), this parameter and parameters 22.22 Constant speed sel1 and 22.23 Constant speed sel2 select three sources that are used to activate constant speeds. See table at parameter 22.22 Constant speed sel1 . For the selections, see parameter 22.22 Constant speed sel1 .	Always off																																				

220 Parameters

No.	Name/Value	Description	Def/FbEq16
22.26	<i>Constant speed 1</i>	Defines constant speed 1 (the speed the motor will turn when constant speed 1 is selected).	300.00
	-30000.00... 30000.00 rpm	Constant speed 1.	See par. 46.01
22.27	<i>Constant speed 2</i>	Defines constant speed 2.	600.00
	-30000.00... 30000.00 rpm	Constant speed 2.	See par. 46.01
22.28	<i>Constant speed 3</i>	Defines constant speed 3.	900.00
	-30000.00... 30000.00 rpm	Constant speed 3.	See par. 46.01
22.29	<i>Constant speed 4</i>	Defines constant speed 4.	1200.00
	-30000.00... 30000.00 rpm	Constant speed 4.	See par. 46.01
22.30	<i>Constant speed 5</i>	Defines constant speed 5.	1500.00
	-30000.00... 30000.00 rpm	Constant speed 5.	See par. 46.01
22.31	<i>Constant speed 6</i>	Defines constant speed 6.	2400.00
	-30000.00... 30000.00 rpm	Constant speed 6.	See par. 46.01
22.32	<i>Constant speed 7</i>	Defines constant speed 7.	3000.00
	-30000.00... 30000.00 rpm	Constant speed 7.	See par. 46.01
22.41	<i>Speed ref safe</i>	Defines a safe speed reference value that is used with supervision functions such as <ul style="list-style-type: none"> • 12.03 AI supervision function • 49.05 Communication loss action • 50.02 FBA A comm loss func. 	0.00
	-30000.00... 30000.00 rpm	Safe speed reference.	See par. 46.01
22.42	<i>Jogging 1 ref</i>	Defines the speed reference for jogging function 1. For more information on jogging, see page 73 .	0.00
	-30000.00... 30000.00 rpm	Speed reference for jogging function 1.	See par. 46.01
22.43	<i>Jogging 2 ref</i>	Defines the speed reference for jogging function 2. For more information on jogging, see page 73 .	0.00
	-30000.00... 30000.00 rpm	Speed reference for jogging function 2.	See par. 46.01

No.	Name/Value	Description	Def/FbEq16
22.51	<i>Critical speed function</i>	Enables/disables the critical speeds function. Also determines whether the specified ranges are effective in both rotating directions or not. See also section <i>Critical speeds/frequencies</i> (page 44).	0b0000
	Bit	Name	Information
	0	Enable	1 = Enable: Critical speeds enabled. 0 = Disable: Critical speeds disabled.
	1	Sign mode	1 = Signed: The signs of parameters 22.52...22.57 are taken into account. 0 = Absolute: Parameters 22.52...22.57 are handled as absolute values. Each range is effective in both directions of rotation.
	2...15	Reserved	
	0b000...0b1111	Critical speeds configuration word.	1 = 1
22.52	<i>Critical speed 1 low</i>	Defines the low limit for critical speed range 1. Note: This value must be less than or equal to the value of 22.53 <i>Critical speed 1 high</i> .	0.00
	-30000.00... 30000.00 rpm	Low limit for critical speed 1.	See par. 46.01
22.53	<i>Critical speed 1 high</i>	Defines the high limit for critical speed range 1. Note: This value must be greater than or equal to the value of 22.52 <i>Critical speed 1 low</i> .	0.00
	-30000.00... 30000.00 rpm	High limit for critical speed 1.	See par. 46.01
22.54	<i>Critical speed 2 low</i>	Defines the low limit for critical speed range 2. Note: This value must be less than or equal to the value of 22.55 <i>Critical speed 2 high</i> .	0.00
	-30000.00... 30000.00 rpm	Low limit for critical speed 2.	See par. 46.01
22.55	<i>Critical speed 2 high</i>	Defines the high limit for critical speed range 2. Note: This value must be greater than or equal to the value of 22.54 <i>Critical speed 2 low</i> .	0.00
	-30000.00... 30000.00 rpm	High limit for critical speed 2.	See par. 46.01
22.56	<i>Critical speed 3 low</i>	Defines the low limit for critical speed range 3. Note: This value must be less than or equal to the value of 22.57 <i>Critical speed 3 high</i> .	0.00
	-30000.00... 30000.00 rpm	Low limit for critical speed 3.	See par. 46.01
22.57	<i>Critical speed 3 high</i>	Defines the high limit for critical speed range 3. Note: This value must be greater than or equal to the value of 22.56 <i>Critical speed 3 low</i> .	0.00
	-30000.00... 30000.00 rpm	High limit for critical speed 3.	See par. 46.01
22.71	<i>Motor potentiometer function</i>	Activates and selects the mode of the motor potentiometer. See section <i>Speed compensated stop</i> (page 76).	<i>Disabled</i>
	Disabled	Motor potentiometer is disabled and its value set to 0.	0

222 Parameters


No.	Name/Value	Description	Def/FbEq16
	Enabled (init at stop /power-up)	When enabled, the motor potentiometer first adopts the value defined by parameter 22.72 Motor potentiometer initial value . The value can then be adjusted from the up and down sources defined by parameters 22.73 Motor potentiometer up source and 22.74 Motor potentiometer down source . A stop or a power cycle will reset the motor potentiometer to the initial value (22.72).	1
	Enabled (resume always)	As Enabled (init at stop /power-up) , but the motor potentiometer value is retained over a stop or power cycle.	2
	Enabled (init to actual)	Whenever another reference source is selected, the value of the motor potentiometer follows that reference. After the source of reference returns to the motor potentiometer, its value can again be changed by the up and down sources (defined by 22.73 and 22.74).	3
22.72	Motor potentiometer initial value	Defines an initial value (starting point) for the motor potentiometer. See the selections of parameter 22.71 Motor potentiometer function .	0.00
	-32768.00... 32767.00	Initial value for motor potentiometer.	1 = 1
22.73	Motor potentiometer up source	Selects the source of motor potentiometer up signal. 0 = No change 1 = Increase motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.) Note: Motor potentiometer function up/down source control speed or frequency from zero to maximum speed or frequency. The running direction can be changed with parameter 20.04 Ext1 in2 source . See the figure in section Motor potentiometer macro on page 109 .	<i>Not used</i>
	Not used	Not used	0
	Not used	Not used	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271).	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271).	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271).	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264).	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264).	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264).	26
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-



No.	Name/Value	Description	Def/FbEq16
22.74	<i>Motor potentiometer down source</i>	Selects the source of motor potentiometer down signal. 0 = No change 1 = Decrease motor potentiometer value. (If both the up and down sources are on, the potentiometer value will not change.) Note: Motor potentiometer function up/down source control speed or frequency from zero to maximum speed or frequency. The running direction can be changed with parameter 20.04 Ext1 in2 source . See the figure in section Motor potentiometer macro on page 109. For the selections, see parameter 22.73 Motor potentiometer up source .	<i>Not used</i>
22.76	<i>Motor potentiometer min value</i>	Defines the minimum value of the motor potentiometer. Note: If vector control mode is used, value of this parameter must be changed.	-50.00
	-32768.00... 32767.00	Motor potentiometer minimum.	1 = 1
22.77	<i>Motor potentiometer max value</i>	Defines the maximum value of the motor potentiometer. Note: If vector control mode is used, value of this parameter must be changed.	50.00
	-32768.00... 32767.00	Motor potentiometer maximum.	1 = 1
22.78	<i>Motor potentiometer ramp up</i>	Defines the time required for the motor potentiometer to change from minimum (22.76) to maximum (22.77).	40.0 s
	0.0...3600.0 s	Motor potentiometer change time.	10=1
22.79	<i>Motor potentiometer ramp down</i>	Defines the time required for the motor potentiometer to change from maximum (22.77) to minimum (22.76).	40.0 s
	0.0...3600.0 s	Motor potentiometer change time.	10=1
22.80	<i>Motor potentiometer ref act</i>	The output of the motor potentiometer function. (The motor potentiometer is configured using parameters 22.71...22.74 .) This parameter is read-only.	0.00
	-32768.00... 32767.00	Value of motor potentiometer.	1 = 1
22.86	<i>Speed reference act 6</i>	Displays the value of the speed reference (EXT1 or EXT2) that has been selected by 19.11 Ext1/Ext2 selection . See diagram at 22.11 Ext1 speed ref1 or the control chain diagram on page 488. This parameter is read-only.	-
	-30000.00... 30000.00 rpm	Speed reference after additive 2.	See par. 46.01

224 Parameters

No.	Name/Value	Description	Def/FbEq16
22.87	<i>Speed reference act 7</i>	Displays the value of speed reference before application of critical speeds. See the control chain diagram on page 465. The value is received from 22.86 Speed reference act 6 unless overridden by <ul style="list-style-type: none"> any constant speed a jogging reference network control reference control panel reference safe speed reference. This parameter is read-only.	-
	-30000.00... 30000.00 rpm	Speed reference before application of critical speeds.	See par. 46.01
23 Speed reference ramp		Speed reference ramp settings (programming of the acceleration and deceleration rates for the drive). See the control chain diagram on page 468.	
23.01	<i>Speed ref ramp input</i>	Displays the used speed reference (in rpm) before it enters the ramping and shaping functions. See the control chain diagram on page 468. This parameter is read-only.	0.00
	-30000.00... 30000.00 rpm	Speed reference before ramping and shaping.	See par. 46.01
23.02	<i>Speed ref ramp output</i>	Displays the ramped and shaped speed reference in rpm. See the control chain diagram on page 468. This parameter is read-only.	0.00
	-30000.00... 30000.00 rpm	Speed reference after ramping and shaping.	See par. 46.01
23.11	<i>Ramp set selection</i>	Selects the source that switches between the two sets of acceleration/deceleration ramp times defined by parameters 23.12...23.15 . 0 = Acceleration time 1 and deceleration time 1 are active 1 = Acceleration time 2 and deceleration time 2 are active	DI5
	Acc/Dec time 1	0	0
	Acc/Dec time 2	1	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5)	7
	FBAA	For Transparent16 and Transparent32 profiles only, DCU control word bit 10 received through the fieldbus adapter.	18
	EFB DCU CW bit 10	Only for the DCU profile. DCU control word bit 10 received through the embedded fieldbus interface.	20
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-

No.	Name/Value	Description	Def/FbEq16
23.12	<i>Acceleration time 1</i>	Defines acceleration time 1 as the time required for the speed to change from zero to the speed defined by parameter 46.01 Speed scaling (not to parameter 30.12 Maximum speed). If the speed reference increases faster than the set acceleration rate, the motor speed will follow the acceleration rate. If the speed reference increases slower than the set acceleration rate, the motor speed will follow the reference. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.	20.000
	0.000...1800.000 s	Acceleration time 1.	10 = 1
23.13	<i>Deceleration time 1</i>	Defines deceleration time 1 as the time required for the speed to change from the speed defined by parameter 46.01 Speed scaling (not from parameter 30.12 Maximum speed) to zero. If the speed reference decreases slower than the set deceleration rate, the motor speed will follow the reference. If the reference changes faster than the set deceleration rate, the motor speed will follow the deceleration rate. If the deceleration rate is set too short, the drive will automatically prolong the deceleration in order not to exceed drive torque limits (or not to exceed a safe DC link voltage). If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control is on (parameter 30.30 Overvoltage control). Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	20.000
	0.000...1800.000 s	Deceleration time 1.	10 = 1
23.14	<i>Acceleration time 2</i>	Defines acceleration time 2. See parameter 23.12 Acceleration time 1 .	60.000
	0.000...1800.000 s	Acceleration time 2.	10 = 1
23.15	<i>Deceleration time 2</i>	Defines deceleration time 2. See parameter 23.13 Deceleration time 1 .	60.000
	0.000...1800.000 s	Deceleration time 2.	10 = 1
23.20	<i>Acc time jogging</i>	Defines the acceleration time for the jogging function ie. the time required for the speed to change from zero to the speed value defined by parameter 46.01 Speed scaling . See section Jogging (page 73).	60.000
	0.000...1800.000 s	Acceleration time for jogging.	10 = 1
23.21	<i>Dec time jogging</i>	Defines the deceleration time for the jogging function ie. the time required for the speed to change from the speed value defined by parameter 46.01 Speed scaling to zero. See section Jogging (page 73).	60.000
	0.000...1800.000 s	Deceleration time for jogging.	10 = 1



No.	Name/Value	Description	Def/FbEq16
23.23	<i>Emergency stop time</i>	<p>Defines the time inside which the drive is stopped if an emergency stop Off3 is activated (ie. the time required for the speed to change from the speed value defined by parameter 46.01 Speed scaling or 46.02 Frequency scaling to zero). Emergency stop mode and activation source are selected by parameters 21.04 Emergency stop mode and 21.05 Emergency stop source respectively. Emergency stop can also be activated through fieldbus.</p> <p>Note:</p> <ul style="list-style-type: none"> Emergency stop Off1 uses the standard deceleration ramp as defined by parameters 23.11...23.1523.12...23.13. The same parameter value is also used in frequency control mode (ramp parameters 28.71...28.7528.72...28.73). 	3.000
	0.000...1800.000 s	Emergency stop Off3 deceleration time.	10 = 1
23.28	<i>Variable slope</i>	<p>Activates the variable slope function, which controls the slope of the speed ramp during a speed reference change. This allows for a constantly variable ramp rate to be generated, instead of just the standard two ramps normally available. If the update interval of the signal from an external control system and the variable slope rate (23.29 Variable slope rate) are equal, speed reference (23.02 Speed ref ramp output) is a straight line.</p>  <p>t = update interval of signal from an external control system A = speed reference change during t</p> <p>This function is only active in remote external control.</p>	<i>Off</i>
	Off	Variable slope disabled.	0
	On	Variable slope enabled (not available in local control).	1
23.29	<i>Variable slope rate</i>	<p>Defines the rate of the speed reference change when variable slope is enabled by parameter 23.28 Variable slope. For the best result, enter the reference update interval into this parameter.</p>	50
	2...30000 ms	Variable slope rate.	1 = 1


No.	Name/Value	Description	Def/FbEq16
23.32	<i>Shape time 1</i>	<p>Defines the shape of the acceleration and deceleration ramps used with the set 1.</p> <p>0.000 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps.</p> <p>0.001...1000.000 s: S-curve ramp. S-curve ramps are ideal for lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between.</p> <p>Acceleration:</p>  <p>Deceleration:</p> 	0.000
	0.000...1800.000 s	Ramp shape at start and end of acceleration and deceleration.	10 = 1
23.33	<i>Shape time 2</i>	Defines the shape of the acceleration and deceleration ramps used with the set 2. See parameter 23.32 Shape time 1 .	0.000
	0.000...1800.000 s	Ramp shape at start and end of acceleration and deceleration.	10 = 1

No.	Name/Value	Description	Def/FbEq16
24 Speed reference conditioning		Speed error calculation; speed error window control configuration; speed error step. See the control chain diagram on page 468.	
24.01	<i>Used speed reference</i>	Displays the ramped and corrected speed reference (before speed error calculation). See the control chain diagram on page 468. This parameter is read-only.	-
	-30000.00... 30000.00 rpm	Speed reference used for speed error calculation.	See par. 46.01
24.02	<i>Used speed feedback</i>	Displays the speed feedback used for speed error calculation. See the control chain diagram on page 468. This parameter is read-only.	-
	-30000.00... 30000.00 rpm	Speed feedback used for speed error calculation.	See par. 46.01
24.03	<i>Speed error filtered</i>	Displays the filtered speed error. See the control chain diagram on page 468. This parameter is read-only.	-
	-30000.0... 30000.0 rpm	Filtered speed error.	See par. 46.01
25 Speed control		Speed controller settings. See the control chain diagrams on pages 469 and 470.	
25.01	<i>Torque reference speed control</i>	Displays the speed controller output that is transferred to the torque controller. See the control chain diagram on page 469. This parameter is read-only.	0.0
	-1600.0...1600.0%	Limited speed controller output torque.	See par. 46.03
25.02	<i>Speed proportional gain</i>	Defines the proportional gain (K_p) of the speed controller. Too high a gain may cause speed oscillation. The figure below shows the speed controller output after an error step when the error remains constant.	5.00
		If gain is set to 1, a 10% change in error value (reference - actual value) causes the speed controller output to change by 10%, i.e. the output value is input × gain.	
	0.00...250.00	Proportional gain for speed controller.	100 = 1

No.	Name/Value	Description	Def/FbEq16
25.03	<i>Speed integration time</i>	<p>Defines the integration time of the speed controller. The integration time defines the rate at which the controller output changes when the error value is constant and the proportional gain of the speed controller is 1. The shorter the integration time, the faster the continuous error value is corrected. This time constant must be set to the same order of magnitude as the time constant (time to respond) of the actual mechanical system being controlled, otherwise instability will result.</p> <p>Setting the integration time to zero disables the I-part of the controller. This is useful to do when tuning the proportional gain; adjust the proportional gain first, then return the integration time.</p> <p>Anti-windup (the integrator just integrates up to 100%) stops the integrator if the controller output is limited.</p> <p>The figure below shows the speed controller output after an error step when the error remains constant.</p>	2.50
<p style="text-align: right;">Gain = $K_p = 1$ $T_i =$ Integration time > 0 $T_D =$ Derivation time $= 0$</p>			
0.00...1000.00 s	Integration time for speed controller.	10 = 1	


No.	Name/Value	Description	Def/FbEq16
25.04	<i>Speed derivation time</i>	<p>Defines the derivation time of the speed controller. Derivative action boosts the controller output if the error value changes. The longer the derivation time, the more the speed controller output is boosted during the change. If the derivation time is set to zero, the controller works as a PI controller, otherwise as a PID controller. The derivation makes the control more responsive for disturbances. For simple applications, derivative time is not normally required and should be left at zero.</p> <p>The speed error derivative must be filtered with a low pass filter to eliminate disturbances.</p> <p>The figure below shows the speed controller output after an error step when the error remains constant.</p>	0.000
<p>Gain = $K_p = 1$ T_I = Integration time > 0 T_D = Derivation time > 0 T_s = Sample time period = 250 μs Δe = Error value change between two samples</p>			
	0.000...10.000 s	Derivation time for speed controller.	1000 = 1
25.05	<i>Derivation filter time</i>	Defines the derivation filter time constant. See parameter 25.04 Speed derivation time .	8
	0...10000 ms	Derivation filter time constant.	1 = 1

No.	Name/Value	Description	Def/FbEq16
25.06	<i>Acc comp derivation time</i>	<p>Defines the derivation time for acceleration(/deceleration) compensation. In order to compensate for a high inertia load during acceleration, a derivative of the reference is added to the output of the speed controller. The principle of a derivative action is described under parameter 25.04 Speed derivation time.</p> <p>Note: As a general rule, set this parameter to the value between 50 and 100% of the sum of the mechanical time constants of the motor and the driven machine.</p> <p>The figure below shows the speed responses when a high inertia load is accelerated along a ramp.</p> <p>No acceleration compensation:</p>  <p>Acceleration compensation:</p> 	0.00
	0.00...1000.00 s	Acceleration compensation derivation time.	10 = 1
25.07	<i>Acc comp filter time</i>	Defines the acceleration (or deceleration) compensation filter time constant. See parameters 25.04 Speed derivation time and 25.06 Acc comp derivation time .	8.0
	0.0...1000.0 ms	Acceleration/deceleration compensation filter time.	1 = 1
25.30	<i>Flux adaptation enable</i>	Enables/disables the flux optimization function. Flux Optimization reduces the total energy consumption and noise when the drive operates below the nominal load. This must be enabled for drives that usually operate below nominal load.	<i>Enable</i>
	Enable	Enables the flux optimization. Changes the magnitude of the flux depending on the actual load.	1
	Disable	Disables the flux optimization.	0

No.	Name/Value	Description	Def/FbEq16
25.33	<i>Speed controller autotune</i>	<p>Activates (or selects a source that activates) the speed controller autotune function. See section <i>Speed controller autotune</i> (page 383).</p> <p>The autotune will automatically set parameters <i>25.02 Speed proportional gain</i>, <i>25.03 Speed integration time</i> and <i>25.37 Mechanical time constant</i>.</p> <p>The prerequisites for performing the autotune routine are:</p> <ul style="list-style-type: none"> the motor identification run (ID run) has been successfully completed the speed and torque limits (parameter group <i>30 Limits</i>) have been set speed feedback filtering (parameter group 90 Feedback selection), speed error filtering (<i>24 Speed reference conditioning</i>) and zero speed (<i>21 Start/stop mode</i>) have been set, and the drive has been started and is running in speed control mode. <p> WARNING: The motor and machinery will run against the torque and speed limits during the autotune routine. MAKE SURE IT IS SAFE TO ACTIVATE THE AUTOTUNE FUNCTION!</p> <p>The autotune routine can be aborted by stopping the drive. 0?1 = Activate speed controller autotune</p> <p>Note: The value does not revert to 0 automatically</p>	<i>Off</i>
	Off	0	0
	On	1	1
25.34	<i>Speed controller autotune mode</i>	<p>Defines a control preset for the speed controller autotune function. The setting affects the way the torque reference will respond to a speed reference step.</p>	<i>Normal</i>
	Smooth	Slow but robust response.	0
	Normal	Medium setting.	1
	Tight	Fast response. May produce too high a gain value for some applications.	2
25.37	<i>Mechanical time constant</i>	<p>Mechanical time constant of the drive and the machinery as determined by the speed controller autotune function. The value can be adjusted manually.</p>	0.00
	0.00...1000.00 s	Mechanical time constant.	100 = 1 s
25.38	<i>Autotune torque step</i>	<p>Defines an added torque value used by the autotune function. This value is scaled to motor nominal torque.</p> <p>Note that the torque used by the autotune function can also be limited by the torque limits (in parameter group <i>30 Limits</i>) and nominal motor torque.</p>	10.00
	0.00...100.00%	Autotune torque step.	100 = 1%
25.39	<i>Autotune speed step</i>	<p>Defines a speed value added to the initial speed for the autotune routine. The initial speed (speed used when autotune is activated) plus the value of this parameter is the calculated maximum speed used by the autotune routine. The maximum speed can also be limited by the speed limits (in parameter group <i>30 Limits</i>) and nominal motor speed.</p> <p>The value is scaled to motor nominal speed.</p> <p>Note: The motor will exceed the calculated maximum speed slightly at the end of each acceleration stage.</p>	10.00

No.	Name/Value	Description	Def/FbEq16
	0.00...100.00%	Autotune speed step.	100 = 1%
25.40	<i>Autotune repeat times</i>	Determines how many acceleration/deceleration cycles are performed during the autotune routine. Increasing the value will improve the accuracy of the autotune function, and allow the use of smaller torque or speed step values.	5
	1...10		1 = 1
25.53	<i>Torque prop reference</i>	Displays the output of the proportional (P) part of the speed controller. See the control chain diagram on page 469. This parameter is read-only.	0.0
	-30000.0... 30000.0%	P-part output of speed controller.	See par. 46.03
25.54	<i>Torque integral reference</i>	Displays the output of the integral (I) part of the speed controller. See the control chain diagram on page 469. This parameter is read-only.	0.0
	-30000.0... 30000.0%	I-part output of speed controller.	See par. 46.03
25.55	<i>Torque deriv reference</i>	Displays the output of the derivative (D) part of the speed controller. See the control chain diagram on page 469. This parameter is read-only.	0.0
	-30000.0... 30000.0%	D-part output of speed controller.	See par. 46.03
25.56	<i>Torque acc compensation</i>	Displays the output of the acceleration compensation function. See the control chain diagram on page 469. This parameter is read-only.	0.0
	-30000.0... 30000.0%	Output of acceleration compensation function.	See par. 46.03
26 Torque reference chain		Settings for the torque reference chain. See the control chain diagrams on pages 470 and 471.	
26.01	<i>Torque reference to TC</i>	Displays the final torque reference given to the torque controller in percent. This reference is then acted upon by various final limiters, like power, torque, load etc. See the control chain diagrams on pages 470 and 471. This parameter is read-only.	0.0
	-1600.0...1600.0%	Torque reference for torque control.	See par. 46.03
26.02	<i>Torque reference used</i>	Displays the final torque reference (in percent of motor nominal torque) given to the torque controller, and comes after frequency, voltage and torque limitation. See the control chain diagram on page 472. This parameter is read-only.	0.0
	-1600.0...1600.0%	Torque reference for torque control.	See par. 46.03
26.08	<i>Minimum torque ref</i>	Defines the minimum torque reference. Allows for local limiting of the torque reference before it is passed on to the torque ramp controller. For absolute torque limiting, refer to parameter 30.19 <i>Minimum torque 1</i> .	-300.0%
	-1000.0...0.0%	Minimum torque reference.	See par. 46.03

No.	Name/Value	Description	Def/FbEq16
26.09	<i>Maximum torque ref</i>	Defines the maximum torque reference. Allows for local limiting of the torque reference before it is passed on to the torque ramp controller. For absolute torque limiting, refer to parameter 30.20 Maximum torque 1 .	300.0%
	0.0...1000.0%	Maximum torque reference.	See par. 46.03
26.11	<i>Torque ref1 source</i>	Selects torque reference source 1. Two signal sources can be defined by this parameter and 26.12 Torque ref2 source . A digital source selected by 26.14 Torque ref1/2 selection can be used to switch between the two sources, or a mathematical function (26.13 Torque ref1 function) applied to the two signals to create the reference.	Zero



Zero	None.	0
AI1 scaled	12.12 AI1 scaled value (see page 187).	1
AI2 scaled	12.22 AI2 scaled value (see page 189).	2
Reserved		3
FB A ref1	03.05 FB A reference 1 (see page 166).	4
FB A ref2	03.06 FB A reference 2 (see page 166).	5
Reserved		6...7
EFB ref1	03.09 EFB reference 1 (see page 166).	8
EFB ref2	03.10 EFB reference 2 (see page 167).	9
Reserved		10...14
Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
PID	40.01 Process PID output actual (output of the process PID controller).	16
Frequency input	11.38 Freq in 1 actual value (when DI5 is used as a frequency input).	17

No.	Name/Value	Description	Def/FbEq16
	Control panel (ref saved)	<p>Panel reference (03.01 Panel reference, see page 166) saved by the control system for the location where the control returns is used as the reference.</p> <p>Reference</p>	18
	Control panel (ref copied)	<p>Panel reference (03.01 Panel reference, see page 166) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (e.g. frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference.</p> <p>Reference</p>	19
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
26.12	Torque ref2 source	Selects torque reference source 2. For the selections, and a diagram of reference source selection, see parameter 26.11 Torque ref1 source .	<i>Zero</i>
26.13	Torque ref1 function	Selects a mathematical function between the reference sources selected by parameters 26.11 Torque ref1 source and 26.12 Torque ref2 source . See diagram at 26.11 Torque ref1 source .	<i>Ref1</i>
	Ref1	Signal selected by 26.11 Torque ref1 source is used as torque reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as torque reference 1.	1
	Sub (ref1 - ref2)	The subtraction (26.11 Torque ref1 source - 26.12 Torque ref2 source) of the reference sources is used as torque reference 1.	2
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as torque reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as torque reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as torque reference 1.	5
26.14	Torque ref1/2 selection	Configures the selection between torque references 1 and 2. See diagram at 26.11 Torque ref1 source . 0 = Torque reference 1 1 = Torque reference 2	<i>Torque reference 1</i>
	Torque reference 1	0	0
	Torque reference 2	1	1


No.	Name/Value	Description	Def/FbEq16
	Follow Ext1/Ext2 selection	Torque reference 1 is used when external control location EXT1 is active. Torque reference 2 is used when external control location EXT2 is active. See also parameter 19.11 Ext1/Ext2 selection .	2
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0)	3
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1)	4
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2)	5
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3)	6
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4)	7
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5)	8
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160)	-
26.17	Torque ref filter time	Defines a low-pass filter time constant for the torque reference.	0.000 s
	0.000...30.000 s	Filter time constant for torque reference.	1000 = 1 s
26.18	Torque ramp up time	Defines the torque reference ramp-up time, ie. the time for the reference to increase from zero to nominal motor torque.	0.000 s
	0.000...60.000 s	Torque reference ramp-up time.	100 = 1 s
26.19	Torque ramp down time	Defines the torque reference ramp-down time, ie. the time for the reference to decrease from nominal motor torque to zero.	0.000 s
	0.000...60.000 s	Torque reference ramp-down time.	100 = 1 s
26.20	Torque reversal	Selects the source of torque reversal function.	<i>Always off</i>
	Always off	Torque reversal function is disabled.	0
	Always on	Torque reversal function is enabled.	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271).	8
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271).	9
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271).	10
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264).	11
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264).	12
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264).	13
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
26.21	Torque sel torque in	Selects the source for 26.74 Torque ref ramp out .	<i>Torque ref torq ctrl</i>
	Not selected	None.	0
	Torque ref torq ctrl	Torque reference from the torque chain.	1
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
26.22	Torque sel speed in	Selects the source for 25.01 Torque reference speed control .	<i>Torque ref speed ctrl</i>
	Not selected	None.	0

No.	Name/Value	Description	Def/FbEq16
	Torque ref speed ctrl	Torque reference from the speed chain.	1
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
26.70	<i>Torque reference act 1</i>	Displays the value of torque reference source 1 (selected by parameter 26.11 Torque ref1 source). See the control chain diagram on page 470. This parameter is read-only.	0.0
	-1600.0...1600.0%	Value of torque reference source 1.	See par. 46.03
26.71	<i>Torque reference act 2</i>	Displays the value of torque reference source 2 (selected by parameter 26.12 Torque ref2 source). See the control chain diagram on page 470. This parameter is read-only.	0.0
	-1600.0...1600.0%	Value of torque reference source 2.	See par. 46.03
26.72	<i>Torque reference act 3</i>	Displays the torque reference after the function applied by parameter 26.13 Torque ref1 function (if any), and after selection (26.14 Torque ref1/2 selection). See the control chain diagram on page 470. This parameter is read-only.	0.0
	-1600.0...1600.0%	Torque reference after selection.	See par. 46.03
26.73	<i>Torque reference act 4</i>	Displays the torque reference after application of reference additive 1. See the control chain diagram on page 470. This parameter is read-only.	0.0
	-1600.0...1600.0%	Torque reference after application of reference additive 1.	See par. 46.03
26.74	<i>Torque ref ramp out</i>	Displays the torque reference after limiting and ramping. See the control chain diagram on page 470. This parameter is read-only.	0.0
	-1600.0...1600.0%	Torque reference after limiting and ramping.	See par. 46.03
26.75	<i>Torque reference act 5</i>	Displays the torque reference after control mode selection. See the control chain diagram on page 471. This parameter is read-only.	0.0
	-1600.0...1600.0%	Torque reference after control mode selection.	See par. 46.03
26.76	<i>Torque reference act 6</i>	Displays the torque reference after the trim addition to the parameter 26.75 Torque reference act 5 .	0.0
	-1600.0...1600.0%	Torque reference after control mode selection.	See par. 46.03
26.81	<i>Rush control gain</i>	Rush controller gain term. See section Rush control (page 73).	5.0
	0.0...10000.0	Rush controller gain (0.0 = disabled).	1 = 1
26.82	<i>Rush control integration time</i>	Rush controller integration time term.	2.0s
	0.0...10.0 s	Rush controller integration time (0.0 = disabled).	1 = 1s



238 Parameters

No.	Name/Value	Description	Def/FbEq16
28	Frequency reference chain	Settings for the frequency reference chain. See the control chain diagrams on pages 486 and 487 .	
28.01	<i>Frequency ref ramp input</i>	Displays the used frequency reference before ramping. See the control chain diagram on page 486 . This parameter is read-only.	0.00
	-500.00...500.00 Hz	Frequency reference before ramping.	See par. 46.02
28.02	<i>Frequency ref ramp output</i>	Displays the final frequency reference (after selection, limitation and ramping). See the control chain diagram on page 486 . This parameter is read-only.	0.00
	-500.00...500.00 Hz	Final frequency reference.	See par. 46.02

No.	Name/Value	Description	Def/FbEq16
28.11	<i>Ext1 frequency ref1</i>	<p>Selects Ext1 frequency reference source 1.</p> <p>Two signal sources can be defined by this parameter and 28.12 Ext1 frequency ref2. A mathematical function (28.13 Ext1 frequency function) applied to the two signals creates an Ext1 reference (A in the figure below).</p> <p>A digital source selected by 19.11 Ext1/Ext2 selection can be used to switch between Ext1 reference and the corresponding Ext2 reference defined by parameters 28.15 Ext2 frequency ref1, 28.16 Ext2 frequency ref2 and 28.17 Ext2 frequency function (B in the figure below).</p>	<i>AI1 scaled</i>






Zero	None	0
AI1 scaled	12.12 AI1 scaled value (see page 187)	1
AI2 scaled	12.22 AI2 scaled value (see page 189)	2
FB A ref1	03.05 FB A reference 1 (see page 166)	4
FB A ref2	03.06 FB A reference 2 (see page 166)	5
EFB ref1	03.09 EFB reference 1 (see page 166)	8
EFB ref2	03.10 EFB reference 2 (see page 167)	9
Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer)	15
PID	40.01 Process PID output actual (output of the process PID controller)	16

No.	Name/Value	Description	Def/FbEq16
	Frequency input	11.38 Freq in 1 actual value (when DI5 or DI6 is used as a frequency input).	17
	Control panel (ref saved)	Panel reference (03.01 Panel reference , see page 166) saved by the control system for the location where the control returns is used as the reference. 	18
	Control panel (ref copied)	Panel reference (03.01 Panel reference , see page 166) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. 	19
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
28.12	Ext1 frequency ref2	Selects Ext1 frequency reference source 2. For the selections, and a diagram of reference source selection, see parameter 28.11 Ext1 frequency ref1 .	<i>Zero</i>
28.13	Ext1 frequency function	Selects a mathematical function between the reference sources selected by parameters 28.11 Ext1 frequency ref1 and 28.12 Ext1 frequency ref2 . See diagram at 28.11 Ext1 frequency ref1 .	<i>Ref1</i>
	Ref1	Signal selected by 28.11 Ext1 frequency ref1 is used as frequency reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as frequency reference 1.	1
	Sub (ref1 - ref2)	The subtraction (28.11 Ext1 frequency ref1 - 28.12 Ext1 frequency ref2) of the reference sources is used as frequency reference 1.	2
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as frequency reference 1.	3
	Min (ref1, ref2)	The smaller of the reference sources is used as frequency reference 1.	4
	Max (ref1, ref2)	The greater of the reference sources is used as frequency reference 1.	5
28.15	Ext2 frequency ref1	Selects Ext2 frequency reference source 1. Two signal sources can be defined by this parameter and 28.16 Ext2 frequency ref2 . A mathematical function (28.17 Ext2 frequency function) applied to the two signals creates an Ext2 reference. See diagram at 28.11 Ext1 frequency ref1 .	<i>Zero</i>
	Zero	None.	0
	All1 scaled	12.12 All1 scaled value (see page 187).	1

No.	Name/Value	Description	Def/FbEq16
	AI2 scaled	12.22 AI2 scaled value (see page 189).	2
	FB A ref1	03.05 FB A reference 1 (see page 166).	4
	FB A ref2	03.06 FB A reference 2 (see page 166).	5
	EFB ref1	03.09 EFB reference 1 (see page 166).	8
	EFB ref2	03.10 EFB reference 2 (see page 167).	9
	Reserved		10...14
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	15
	PID	40.01 Process PID output actual (output of the process PID controller).	16
	Frequency input	11.38 Freq in 1 actual value (when DI5 or DI6 is used as a frequency input).	17
	Control panel (ref saved)	Panel reference (03.01 Panel reference , see page 166) saved by the control system for the location where the control returns is used as the reference. 	18
	Control panel (ref copied)	Panel reference (03.01 Panel reference , see page 166) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference. 	19
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
28.16	Ext2 frequency ref2	Selects Ext2 frequency reference source 2. For the selections, and a diagram of reference source selection, see parameter 28.15 Ext2 frequency ref1 .	<i>Zero</i>
28.17	Ext2 frequency function	Selects a mathematical function between the reference sources selected by parameters 28.15 Ext2 frequency ref1 and 28.16 Ext2 frequency ref2 . See diagram at 28.15 Ext2 frequency ref1 .	<i>Ref1</i>
	Ref1	Signal selected by 28.15 Ext2 frequency ref1 is used as frequency reference 1 as such (no function applied).	0
	Add (ref1 + ref2)	The sum of the reference sources is used as frequency reference 1.	1
	Sub (ref1 - ref2)	The subtraction ($[\text{28.15 Ext2 frequency ref1}] - [\text{28.16 Ext2 frequency ref2}]$) of the reference sources is used as frequency reference 1.	2

242 Parameters

No.	Name/Value	Description	Def/FbEq16															
	Mul (ref1 × ref2)	The multiplication of the reference sources is used as frequency reference 1.	3															
	Min (ref1, ref2)	The smaller of the reference sources is used as frequency reference 1.	4															
	Max (ref1, ref2)	The greater of the reference sources is used as frequency reference 1.	5															
28.21	<i>Constant frequency function</i>	Determines how constant frequencies are selected, and whether the rotation direction signal is considered or not when applying a constant frequency.	0b0001															
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Const freq mode</td> <td> <p>1 = Packed: 7 constant frequencies are selectable using the three sources defined by parameters 28.22, 28.23 and 28.24.</p> <p>0 = Separate: Constant frequencies 1, 2 and 3 are separately activated by the sources defined by parameters 28.22, 28.23 and 28.24 respectively. In case of conflict, the constant frequency with the smaller number takes priority.</p> </td> </tr> <tr> <td>1</td> <td>Direction enable</td> <td> <p>1 = Start dir: To determine running direction for a constant speed, the sign of the constant speed setting (parameters 22.26...22.32) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant speeds if all values in 22.26...22.32 are positive.</p> <p> WARNING: If the direction signal is reverse and the active constant speed is negative, the drive will run in the forward direction.</p> <p>0 = Accord Par: The running direction for the constant speed is determined by the sign of the constant speed setting (parameters 22.26...22.32).</p> </td> </tr> <tr> <td>2</td> <td>Frequency step</td> <td>Frequency step: 1 = Freq step enable; 0 = Freq step disable</td> </tr> <tr> <td>3...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Information	0	Const freq mode	<p>1 = Packed: 7 constant frequencies are selectable using the three sources defined by parameters 28.22, 28.23 and 28.24.</p> <p>0 = Separate: Constant frequencies 1, 2 and 3 are separately activated by the sources defined by parameters 28.22, 28.23 and 28.24 respectively. In case of conflict, the constant frequency with the smaller number takes priority.</p>	1	Direction enable	<p>1 = Start dir: To determine running direction for a constant speed, the sign of the constant speed setting (parameters 22.26...22.32) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant speeds if all values in 22.26...22.32 are positive.</p> <p> WARNING: If the direction signal is reverse and the active constant speed is negative, the drive will run in the forward direction.</p> <p>0 = Accord Par: The running direction for the constant speed is determined by the sign of the constant speed setting (parameters 22.26...22.32).</p>	2	Frequency step	Frequency step: 1 = Freq step enable; 0 = Freq step disable	3...15	Reserved	
Bit	Name	Information																
0	Const freq mode	<p>1 = Packed: 7 constant frequencies are selectable using the three sources defined by parameters 28.22, 28.23 and 28.24.</p> <p>0 = Separate: Constant frequencies 1, 2 and 3 are separately activated by the sources defined by parameters 28.22, 28.23 and 28.24 respectively. In case of conflict, the constant frequency with the smaller number takes priority.</p>																
1	Direction enable	<p>1 = Start dir: To determine running direction for a constant speed, the sign of the constant speed setting (parameters 22.26...22.32) is multiplied by the direction signal (forward: +1, reverse: -1). This effectively allows the drive to have 14 (7 forward, 7 reverse) constant speeds if all values in 22.26...22.32 are positive.</p> <p> WARNING: If the direction signal is reverse and the active constant speed is negative, the drive will run in the forward direction.</p> <p>0 = Accord Par: The running direction for the constant speed is determined by the sign of the constant speed setting (parameters 22.26...22.32).</p>																
2	Frequency step	Frequency step: 1 = Freq step enable; 0 = Freq step disable																
3...15	Reserved																	
0b000...0b1111		Constant frequency configuration word.	1 = 1															

No.	Name/Value	Description	Def/FbEq16																																				
28.22	<i>Constant frequency sel1</i>	<p>When bit 0 of parameter <i>28.21 Constant frequency function</i> is 0 (Separate), selects a source that activates constant frequency 1.</p> <p>When bit 0 of parameter <i>28.21 Constant frequency function</i> is 1 (Packed), this parameter and parameters <i>28.23 Constant frequency sel2</i> and <i>28.24 Constant frequency sel3</i> select three sources whose states activate constant frequencies as follows:</p>	<i>DI3</i>																																				
<table border="1"> <thead> <tr> <th>Source defined by par. 28.22</th> <th>Source defined by par. 28.23</th> <th>Source defined by par. 28.24</th> <th>Constant frequency active</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>0</td> <td>None</td> </tr> <tr> <td>1</td> <td>0</td> <td>0</td> <td>Constant frequency 1</td> </tr> <tr> <td>0</td> <td>1</td> <td>0</td> <td>Constant frequency 2</td> </tr> <tr> <td>1</td> <td>1</td> <td>0</td> <td>Constant frequency 3</td> </tr> <tr> <td>0</td> <td>0</td> <td>1</td> <td>Constant frequency 4</td> </tr> <tr> <td>1</td> <td>0</td> <td>1</td> <td>Constant frequency 5</td> </tr> <tr> <td>0</td> <td>1</td> <td>1</td> <td>Constant frequency 6</td> </tr> <tr> <td>1</td> <td>1</td> <td>1</td> <td>Constant frequency 7</td> </tr> </tbody> </table>				Source defined by par. 28.22	Source defined by par. 28.23	Source defined by par. 28.24	Constant frequency active	0	0	0	None	1	0	0	Constant frequency 1	0	1	0	Constant frequency 2	1	1	0	Constant frequency 3	0	0	1	Constant frequency 4	1	0	1	Constant frequency 5	0	1	1	Constant frequency 6	1	1	1	Constant frequency 7
Source defined by par. 28.22	Source defined by par. 28.23	Source defined by par. 28.24	Constant frequency active																																				
0	0	0	None																																				
1	0	0	Constant frequency 1																																				
0	1	0	Constant frequency 2																																				
1	1	0	Constant frequency 3																																				
0	0	1	Constant frequency 4																																				
1	0	1	Constant frequency 5																																				
0	1	1	Constant frequency 6																																				
1	1	1	Constant frequency 7																																				
	Always off	0.	0																																				
	Always on	1.	1																																				
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2																																				
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3																																				
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4																																				
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5																																				
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6																																				
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7																																				
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	18																																				
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	19																																				
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	20																																				
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264).	24																																				
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264).	25																																				
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264).	26																																				
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-																																				
28.23	<i>Constant frequency sel2</i>	<p>When bit 0 of parameter <i>28.21 Constant frequency function</i> is 0 (Separate), selects a source that activates constant frequency 2.</p> <p>When bit 0 of parameter <i>28.21 Constant frequency function</i> is 1 (Packed), this parameter and parameters <i>28.22 Constant frequency sel1</i> and <i>28.24 Constant frequency sel3</i> select three sources that are used to activate constant frequencies. See table at parameter <i>28.22 Constant frequency sel1</i>. For the selections, see parameter <i>28.22 Constant frequency sel1</i>.</p>	<i>DI4</i>																																				



244 Parameters

No.	Name/Value	Description	Def/FbEq16
28.24	<i>Constant frequency sel3</i>	When bit 0 of parameter <i>28.21 Constant frequency function</i> is 0 (Separate), selects a source that activates constant frequency 3. When bit 0 of parameter <i>28.21 Constant frequency function</i> is 1 (Packed), this parameter and parameters <i>28.22 Constant frequency sel1</i> and <i>28.23 Constant frequency sel2</i> select three sources that are used to activate constant frequencies. See table at parameter <i>28.22 Constant frequency sel1</i> . For the selections, see parameter <i>28.22 Constant frequency sel1</i> .	<i>Always off</i>
28.26	<i>Constant frequency 1</i>	Defines constant frequency 1 (the frequency the motor will turn when constant frequency 1 is selected).	5.00 Hz
	-500.00...500.00 Hz	Constant frequency 1.	See par. 46.02
28.27	<i>Constant frequency 2</i>	Defines constant frequency 2.	10.00 Hz
	-500.00...500.00 Hz	Constant frequency 2.	See par. 46.02
28.28	<i>Constant frequency 3</i>	Defines constant frequency 3.	15.00 Hz
	-500.00...500.00 Hz	Constant frequency 3.	See par. 46.02
28.29	<i>Constant frequency 4</i>	Defines constant frequency 4.	20.00 Hz
	-500.00...500.00 Hz	Constant frequency 4.	See par. 46.02
28.30	<i>Constant frequency 5</i>	Defines constant frequency 5.	25.00 Hz
	-500.00...500.00 Hz	Constant frequency 5.	See par. 46.02
28.31	<i>Constant frequency 6</i>	Defines constant frequency 6.	40.00 Hz
	-500.00...500.00 Hz	Constant frequency 6.	See par. 46.02
28.32	<i>Constant frequency 7</i>	Defines constant frequency 7.	50.00 Hz
	-500.00...500.00 Hz	Constant frequency 7.	See par. 46.02
28.41	<i>Frequency ref safe</i>	Defines a safe frequency reference value that is used with supervision functions such as <ul style="list-style-type: none"> • 12.03 AI supervision function • 49.05 Communication loss action • 50.02 FBA A comm loss func. 	0.00 Hz
	-500.00...500.00 Hz	Safe frequency reference.	See par. 46.02
28.42	<i>Jogging 1 frequency ref</i>	Defines the frequency reference for jogging function 1 in scalar control mode.	0.00 Hz
	-500.00...500.00 Hz	Jogging 1 frequency reference.	See par. 46.02
28.43	<i>Jogging 2 frequency ref</i>	Defines the frequency reference for jogging function 2 in scalar control mode.	0.00 Hz

246 Parameters

No.	Name/Value	Description	Def/FbEq16
28.71	<i>Freq ramp set selection</i>	Selects a source that switches between the two sets of acceleration/deceleration times defined by parameters 28.72...28.75 . 0 = Acceleration time 1 and deceleration time 1 are in force 1 = Acceleration time 2 and deceleration time 2 are in force	<i>DI5</i>
	Acc/Dec time 1	0	0
	Acc/Dec time 2	1	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0)	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1)	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2)	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3)	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4)	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5)	7
	FBAA	Only for the Transparent16 or Transparent32 profile. Transparent16 or Transparent32 control word bit received through the fieldbus A interface.	18
	EFB DCU CW bit 10	Only for the DCU profile. DCU control word bit 10 received through the embedded fieldbus interface.	20
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
28.72	<i>Freq acceleration time 1</i>	Defines acceleration time 1 as the time required for the frequency to change from zero to the frequency defined by parameter 46.02 Frequency scaling . After this frequency has been reached, the acceleration continues with the same rate to the value defined by parameter 30.14 Maximum frequency . If the reference increases faster than the set acceleration rate, the motor will follow the acceleration rate. If the reference increases slower than the set acceleration rate, the motor frequency will follow the reference. If the acceleration time is set too short, the drive will automatically prolong the acceleration in order not to exceed the drive torque limits.	20.000 s
	0.000...1800.000 s	Acceleration time 1.	10 = 1 s
28.73	<i>Freq deceleration time 1</i>	Defines deceleration time 1 as the time required for the frequency to change from the frequency defined by parameter 46.02 Frequency scaling (not from parameter 30.14 Maximum frequency) to zero. If there is any doubt about the deceleration time being too short, ensure that DC overvoltage control (30.30 Overvoltage control) is on. Note: If a short deceleration time is needed for a high inertia application, the drive should be equipped with braking equipment such as a brake chopper and brake resistor.	20.000 s
	0.000...1800.000 s	Deceleration time 1.	10 = 1 s
28.74	<i>Freq acceleration time 2</i>	Defines acceleration time 2. See parameter 28.72 Freq acceleration time 1 .	60.000 s
	0.000...1800.000 s	Acceleration time 2.	10 = 1 s
28.75	<i>Freq deceleration time 2</i>	Defines deceleration time 2. See parameter 28.73 Freq deceleration time 1 .	60.000 s
	0.000...1800.000 s	Deceleration time 2.	10 = 1 s



No.	Name/Value	Description	Def/FbEq16
28.76	<i>Freq ramp in zero source</i>	Selects a source that forces the frequency reference to zero. 0 = Force frequency reference to zero 1 = Normal operation	<i>Inactive</i>
	Active	0	0
	Inactive	1	1
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0)	2
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1)	3
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2)	4
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3)	5
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4)	6
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5)	7
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160)	-







No.	Name/Value	Description	Def/FbEq16
28.82	Shape time 1	<p>Defines the shape of the acceleration and deceleration ramps used with the set 1.</p> <p>0.000 s: Linear ramp. Suitable for steady acceleration or deceleration and for slow ramps.</p> <p>0.001...1000.000 s: S-curve ramp. S-curve ramps are ideal for lifting applications. The S-curve consists of symmetrical curves at both ends of the ramp and a linear part in between.</p> <p>Acceleration:</p>  <p>Deceleration:</p> 	0.000 s
0.000...1800.000 s		Ramp shape at start and end of acceleration and deceleration.	10 = 1 s
28.83	Shape time 2	Defines the shape of the acceleration and deceleration ramps used with the set 2. See parameter 28.82 Shape time 1.	0.000 s
0.000...1800.000 s		Ramp shape at start and end of acceleration and deceleration.	10 = 1 s

No.	Name/Value	Description	Def/FbEq16
28.92	Frequency ref act 3	Displays the frequency reference after the function applied by parameter 28.13 Ext1 frequency function (if any), and after selection (19.11 Ext1/Ext2 selection). See the control chain diagram on page 486 . This parameter is read-only.	0.00
	-500.00...500.00 Hz	Frequency reference after selection.	See par. 46.02
28.96	Frequency ref act 7	Displays the frequency reference after application of constant frequencies, control panel reference, etc. See the control chain diagram on page 486 . This parameter is read-only.	0.00
	-500.00...500.00 Hz	Frequency reference 7.	See par. 46.02
28.97	Frequency ref unlimited	Displays the frequency reference after application of critical frequencies, but before ramping and limiting. See the control chain diagram on page 486 . This parameter is read-only.	0.00
	-500.00...500.00 Hz	Frequency reference before ramping and limiting.	See par. 46.02

30 Limits		Drive operation limits.	
30.01	Limit word 1	Displays limit word 1. This parameter is read-only.f	0b0000

Bit	Name	Description	
0	Torq lim	1 = Drive torque is limited by the motor control (undervoltage control, current control, load angle control or pull-out control), or by the torque limits defined by parameters.	
1...2	Reserved		
3	Torq ref max	1 = Torque reference ramp input is being limited by 26.09 Maximum torque ref , 30.20 Maximum torque 1 , 30.26 Power motoring limit , or 30.27 Power generating limit . See the diagram on page 472 .	
4	Torq ref min	1 = Torque reference ramp input is being limited by 26.08 Minimum torque ref , 30.19 Minimum torque 1 , 30.26 Power motoring limit , or 30.27 Power generating limit . See the diagram on page 472 .	
5	Tlim max speed	1 = Torque reference is being limited by the rush control because of maximum speed limit (30.12 Maximum speed)	
6	Tlim min speed	1 = Torque reference is being limited by the rush control because of minimum speed limit (30.11 Minimum speed)	
7	Max speed ref lim	1 = Speed reference is being limited by 30.12 Maximum speed	
8	Min speed ref lim	1 = Speed reference is being limited by 30.11 Minimum speed	
9	Max freq ref lim	1 = Frequency reference is being limited by 30.14 Maximum frequency	
10	Min freq ref lim	1 = Frequency reference is being limited by 30.13 Minimum frequency	
0b0000...0b1111		Limit word 1.	1 = 1

No.	Name/Value	Description	Def/FbEq16																																																
30.02	<i>Torque limit status</i>	Displays the torque controller limitation status word. This parameter is read-only.	0b0000																																																
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Undervoltage</td> <td>*1 = Intermediate DC circuit undervoltage</td> </tr> <tr> <td>1</td> <td>Overvoltage</td> <td>*1 = Intermediate DC circuit overvoltage</td> </tr> <tr> <td>2</td> <td>Minimum torque</td> <td>*1 = Torque is being limited by 30.19 Minimum torque 1, 30.26 Power motoring limit, or 30.27 Power generating limit</td> </tr> <tr> <td>3</td> <td>Maximum torque</td> <td>*1 = Torque is being limited by 30.20 Maximum torque 1, 30.26 Power motoring limit, or 30.27 Power generating limit</td> </tr> <tr> <td>4</td> <td>Internal current</td> <td>1 = An inverter current limit (identified by bits 8...11) is active</td> </tr> <tr> <td>5</td> <td>Load angle</td> <td>(With permanent magnet motors and reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque</td> </tr> <tr> <td>6</td> <td>Motor pullout</td> <td>(With asynchronous motors only) Motor pull-out limit is active, ie. the motor cannot produce any more torque</td> </tr> <tr> <td>7</td> <td>Reserved</td> <td></td> </tr> <tr> <td>8</td> <td>Thermal</td> <td>1 = Input current is being limited by the main circuit thermal limit</td> </tr> <tr> <td>9</td> <td>Max current</td> <td>*1 = Maximum output current (I_{MAX}) is being limited</td> </tr> <tr> <td>10</td> <td>User current</td> <td>*1 = Output current is being limited by 30.17 Maximum current</td> </tr> <tr> <td>11</td> <td>Thermal IGBT</td> <td>*1 = Output current is being limited by a calculated thermal current value</td> </tr> <tr> <td>12</td> <td>IGBT overtemperature</td> <td>*1 = Output current is being limited because of estimated IGBT temperature</td> </tr> <tr> <td>13</td> <td>IGBT overload</td> <td>*1 = Output current is being limited because of IGBT junction to case temperature</td> </tr> <tr> <td>14...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table> <p>*Only one out of bits 0...3, and one out of bits 9...11 can be on simultaneously. The bit typically indicates the limit that is exceeded first.</p>				Bit	Name	Description	0	Undervoltage	*1 = Intermediate DC circuit undervoltage	1	Overvoltage	*1 = Intermediate DC circuit overvoltage	2	Minimum torque	*1 = Torque is being limited by 30.19 Minimum torque 1 , 30.26 Power motoring limit , or 30.27 Power generating limit	3	Maximum torque	*1 = Torque is being limited by 30.20 Maximum torque 1 , 30.26 Power motoring limit , or 30.27 Power generating limit	4	Internal current	1 = An inverter current limit (identified by bits 8...11) is active	5	Load angle	(With permanent magnet motors and reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque	6	Motor pullout	(With asynchronous motors only) Motor pull-out limit is active, ie. the motor cannot produce any more torque	7	Reserved		8	Thermal	1 = Input current is being limited by the main circuit thermal limit	9	Max current	*1 = Maximum output current (I_{MAX}) is being limited	10	User current	*1 = Output current is being limited by 30.17 Maximum current	11	Thermal IGBT	*1 = Output current is being limited by a calculated thermal current value	12	IGBT overtemperature	*1 = Output current is being limited because of estimated IGBT temperature	13	IGBT overload	*1 = Output current is being limited because of IGBT junction to case temperature	14...15	Reserved	
Bit	Name	Description																																																	
0	Undervoltage	*1 = Intermediate DC circuit undervoltage																																																	
1	Overvoltage	*1 = Intermediate DC circuit overvoltage																																																	
2	Minimum torque	*1 = Torque is being limited by 30.19 Minimum torque 1 , 30.26 Power motoring limit , or 30.27 Power generating limit																																																	
3	Maximum torque	*1 = Torque is being limited by 30.20 Maximum torque 1 , 30.26 Power motoring limit , or 30.27 Power generating limit																																																	
4	Internal current	1 = An inverter current limit (identified by bits 8...11) is active																																																	
5	Load angle	(With permanent magnet motors and reluctance motors only) 1 = Load angle limit is active, ie. the motor cannot produce any more torque																																																	
6	Motor pullout	(With asynchronous motors only) Motor pull-out limit is active, ie. the motor cannot produce any more torque																																																	
7	Reserved																																																		
8	Thermal	1 = Input current is being limited by the main circuit thermal limit																																																	
9	Max current	*1 = Maximum output current (I_{MAX}) is being limited																																																	
10	User current	*1 = Output current is being limited by 30.17 Maximum current																																																	
11	Thermal IGBT	*1 = Output current is being limited by a calculated thermal current value																																																	
12	IGBT overtemperature	*1 = Output current is being limited because of estimated IGBT temperature																																																	
13	IGBT overload	*1 = Output current is being limited because of IGBT junction to case temperature																																																	
14...15	Reserved																																																		
	0b0000...0b1111	Torque limitation status word.	1 = 1																																																
30.09	<i>Current limit monitor time</i>	Defines the drive current limit monitor time after which action is taken as specified in the parameter 30.10 .	10.00																																																
	0...120s	Current limit monitor time.	100=1																																																
30.10	<i>Current limit actions</i>	Selects how the drive reacts when the drive reaches the current limit (30.17 Maximum current) and exceeds the monitor time set by parameter 30.09 Current limit monitor time .	<i>No action</i>																																																
	No action	None (current limit action disabled).	0																																																
	Warning	The drive generates an A8B6 Current limit warning.	1																																																
	Fault	The drive trips on fault 8009 Current limit .	2																																																
30.11	<i>Minimum speed</i>	Defines the minimum allowed speed.  WARNING! This value must not be higher than 30.12 Maximum speed .  WARNING! In speed control mode only. In frequency control mode, use frequency limits (30.13 and 30.14).	-1500.00 rpm																																																
	-30000.00... 30000.00 rpm	Minimum allowed speed.	See par. 46.01																																																


No.	Name/Value	Description	Def/FbEq16
30.12	<i>Maximum speed</i>	Defines the maximum allowed speed. Note: This parameter does not affect the speed acceleration and deceleration ramp times. See parameter 46.01 Speed scaling .  WARNING! This value must not be lower than 30.11 Minimum speed .  WARNING! In speed control mode only. In frequency control mode, use frequency limits (30.13 and 30.14).	1500.00 rpm
	-30000.00... 30000.00 rpm	Maximum speed.	See par. 46.01
30.13	<i>Minimum frequency</i>	Defines the minimum allowed frequency.  WARNING! This value must not be higher than 30.14 Maximum frequency .  WARNING! in frequency control mode only.	-50.00 Hz
	-500.00...500.00 Hz	Minimum frequency.	See par. 46.02
30.14	<i>Maximum frequency</i>	Defines the maximum allowed frequency. Note: This parameter does not affect the frequency acceleration and deceleration ramp times. See parameter 46.02 Frequency scaling .  WARNING! This value must not be lower than 30.13 Minimum frequency .  WARNING! in frequency control mode only.	50.00 Hz
	-500.00...500.00 Hz	Maximum frequency.	See par. 46.02
30.17	<i>Maximum current</i>	Defines the maximum allowed drive current. The system sets the default value to 90% of the rated current. If required, you can increase the parameter value by 10%. Note: The maximum current range and default value depends on the drive type.	2.92 A
	0.00...3.24 A	Maximum drive current.	1 = 1 A


No.	Name/Value	Description	Def/FbEq16
30.18	<i>Torq lim sel</i>	<p>Selects a source that switches between two different predefined minimum torque limit sets.</p> <p>0 = minimum torque limit defined by 30.19 and maximum torque limit defined by 30.20 are active</p> <p>1 = minimum torque limit selected by 30.21 and maximum torque limit defined by 30.22 are active</p> <p>The user can define two sets of torque limits, and switch between the sets using a binary source such as a digital input.</p> <p>The first set of limits is defined by parameters 30.19 and 30.20. The second set has selector parameters for both the minimum (30.21) and maximum (30.22) limits that allows the use of a selectable analog source (such as an analog input).</p> <p>Note: In addition to the user-defined limits, torque may be limited for other reasons (such as power limitation). See block diagram <i>Torque limitation</i> on page 472.</p>	<i>Torque limit set 1</i>
	Torque limit set 1	0 (minimum torque limit defined by 30.19 and maximum torque limit defined by 30.20 are active).	0
	Torque limit set 2	1 (minimum torque limit selected by 30.21 and maximum torque limit defined by 30.22 are active).	1
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7
	Reserved		8...10
	EFB	Only for the DCU profile. DCU control word bit 15 received through the embedded fieldbus interface.	11
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-

No.	Name/Value	Description	Def/FbEq16
30.19	<i>Minimum torque 1</i>	Defines a minimum torque limit for the drive (in percent of nominal motor torque).	-300.0%
	-1600.0...0.0%	Minimum torque limit 1.	See par. 46.03
30.20	<i>Maximum torque 1</i>	Defines a maximum torque limit for the drive (in percent of nominal motor torque).	300.0%
	0.0...1600.0%	Maximum torque 1.	See par. 46.03
30.21	<i>Min torque 2 source</i>	Defines the source of the minimum torque limit for the drive (in percent of nominal motor torque) when <ul style="list-style-type: none"> the source selected by parameter 30.18 Torq lim sel is 1, or 30.18 is set to <i>Torque limit set 2</i>. See diagram at 30.18 Torq lim sel . Note: Any positive values received from the selected source are inverted.	<i>Minimum torque 2</i>
	Zero	None.	0
	AI1 scaled	12.12 AI1 scaled value (see page 187).	1
	AI2 scaled	12.22 AI2 scaled value (see page 189).	2
	Reserved		3...14
	PID	40.01 Process PID output actual (output of the process PID controller).	15
	Minimum torque 2	30.23 Minimum torque 2 .	16
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
30.22	<i>Max torque 2 source</i>	Defines the source of the maximum torque limit for the drive (in percent of nominal motor torque) when <ul style="list-style-type: none"> the source selected by parameter 30.18 Torq lim sel is 1, or 30.18 is set to <i>Torque limit set 2</i>. See diagram at 30.18 Torq lim sel . Note: Any negative values received from the selected source are inverted.	<i>Maximum torque 2</i>
	Zero	None.	0
	AI1 scaled	12.12 AI1 scaled value (see page 187).	1
	AI2 scaled	12.22 AI2 scaled value (see page 189).	2
	Reserved		3...14
	PID	40.01 Process PID output actual (output of the process PID controller).	15
	Maximum torque 2	30.24 Maximum torque 2 .	16
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
30.23	<i>Minimum torque 2</i>	Defines the minimum torque limit for the drive (in percent of nominal motor torque) when <ul style="list-style-type: none"> the source selected by 30.18 Torq lim sel is 1, or 30.18 is set to <i>Torque limit set 2</i> and <ul style="list-style-type: none"> 30.21 Min torque 2 source is set to <i>Minimum torque 2</i>. See diagram at 30.18 Torq lim sel .	-300.0%
	-1600.0...0.0%	Minimum torque limit 2.	See par. 46.03


254 Parameters

No.	Name/Value	Description	Def/FbEq16
30.24	Maximum torque 2	Defines the maximum torque limit for the drive (in percent of nominal motor torque) when The limit is effective when <ul style="list-style-type: none"> the source selected by 30.18 Torq lim sel is 1, or 30.18 is set to Torque limit set 2 and <ul style="list-style-type: none"> 30.22 Max torque 2 source is set to Maximum torque 2. See diagram at 30.18 Torq lim sel .	300.0%
	0.0...1600.0%	Maximum torque limit 2.	See par. 46.03
30.26	Power motoring limit	Defines the maximum allowed power fed by the inverter to the motor in percent of nominal motor power.	300.00%
	0.00...600.00%	Maximum motoring power.	1 = 1%
30.27	Power generating limit	Defines the maximum allowed power fed by the motor to the inverter in percent of nominal motor power. Note: If your application, like a pump or a fan, requires that the motor must rotate in one direction only, use speed/frequency limit (30.11 Minimum speed/30.13 Minimum frequency), or direction limit (20.21 Direction) to achieve this. Do not set parameter 30.19 Minimum torque 1 or 30.27 Power generating limit to 0%, as the drive is then not able to stop correctly.	-300.00%
	-600.00...0.00%	Maximum generating power.	1 = 1%
30.30	Overvoltage control	Enables the overvoltage control of the intermediate DC link. Fast braking of a high inertia load causes the voltage to rise to the overvoltage control limit. To prevent the DC voltage from exceeding the limit, the overvoltage controller automatically decreases the braking torque. Note: If the drive is equipped with a brake chopper and resistor, or a regenerative supply unit, the controller must be disabled.	Enable
	Disable	Overvoltage control disabled.	0
	Enable	Overvoltage control enabled.	1
30.31	Undervoltage control	Enables the undervoltage control of the intermediate DC link. If the DC voltage drops due to input power cut off, the undervoltage controller will automatically decrease the motor torque in order to keep the voltage above the lower limit. By decreasing the motor torque, the inertia of the load will cause regeneration back to the drive, keeping the DC link charged and preventing an undervoltage trip until the motor coasts to a stop. This will act as a power-loss ride-through functionality in systems with high inertia, such as a centrifuge or a fan.	Enable
	Disable	Undervoltage control disabled.	0
	Enable	Undervoltage control enabled.	1
30.35	Thermal current limitation	Enables/disables temperature-based output current limitation. The limitation should only be disabled if required by the application.	Enable
	Disable	Thermal current limitation disabled.	0
	Enable	Thermal current limitation enabled.	1

No.	Name/Value	Description	Def/FbEq16
30.36	<i>Speed limit selection</i>	<p>Selects a source that switches between two different predefined adjustable speed limit sets.</p> <p>0 = minimum speed limit defined by 30.11 and maximum speed limit defined by 30.12 are active</p> <p>1 = minimum speed limit selected by 30.37 and maximum speed limit defined by 30.38 are active.</p> <p>The user can define two sets of speed limits, and switch between the sets using a binary source such as a digital input.</p> <p>The user can define two sets of speed limits, and switch between the sets using a binary source such as a digital input.</p> <p>The first set of limits is defined by parameters 30.11 <i>Minimum speed</i> and 30.12 <i>Maximum speed</i>. The second set has selector parameters for both the minimum (30.37) and maximum (30.38) limits that allows the use of a selectable analog source (such as an analog input).</p> 	<i>Not selected</i>
Not selected		Adjustable speed limits are disabled. (Minimum speed limit defined by 30.11 <i>Minimum speed</i> and maximum speed limit defined by 30.12 <i>Maximum speed</i> are active).	0
Selected		Adjustable speed limits are enabled. (Minimum speed limit defined by 30.37 <i>Min speed source</i> source and maximum speed limit defined by 30.38 <i>Max speed source</i> are active).	1
Ext1 active		Adjustable speed limits are enabled if EXT1 is active.	2
Ext2 active		Adjustable speed limits are enabled if EXT2 is active.	3
Torque control		Adjustable speed limits are enabled if Torque control mode (vector motor control) is active.	4
DI1		Digital input DI1 (10.02 <i>DI delayed status</i> , bit 0).	5
DI2		Digital input DI2 (10.02 <i>DI delayed status</i> , bit 1).	6
DI3		Digital input DI3 (10.02 <i>DI delayed status</i> , bit 2).	7
DI4		Digital input DI4 (10.02 <i>DI delayed status</i> , bit 3).	8
DI5		Digital input DI5 (10.02 <i>DI delayed status</i> , bit 4).	9

No.	Name/Value	Description	Def/FbEq16
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	10
	<i>Other</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
30.37	<i>Min speed source</i>	Defines the source of a minimum speed limit for the drive when the source is selected by <i>30.36 Speed limit selection</i> .  WARNING! In vector motor control mode only. In scalar motor control mode, use frequency limits <i>30.13</i> and <i>30.14</i> .	<i>Minimum speed</i>
	Zero	None.	0
	AI1 scaled	<i>12.12 AI1 scaled value</i> .	1
	AI2 scaled	<i>12.22 AI2 scaled value</i> .	2
	Minimum speed	<i>30.11 Minimum speed</i> .	11
	<i>Other</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
30.38	<i>Max speed source</i>		<i>Minimum speed</i>
	Zero	None.	0
	AI1 scaled	<i>12.12 AI1 scaled value</i> .	1
	AI2 scaled	<i>12.22 AI2 scaled value</i> .	2
	Maximum speed	<i>30.12 Maximum speed</i> .	12
	<i>Other</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
31 Fault functions		Configuration of external events; selection of behavior of the drive upon fault situations.	
31.01	<i>External event 1 source</i>	Defines the source of external event 1. See also parameter <i>31.02 External event 1 type</i> . 0 = Trigger event 1 = Normal operation	<i>Inactive (true)</i>
	Active (false)	0.	0
	Inactive (true)	1.	1
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	3
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	4
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	5
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	6
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	7
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	8
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
31.02	<i>External event 1 type</i>	Selects the type of external event 1.	<i>Fault</i>
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
31.03	<i>External event 2 source</i>	Defines the source of external event 2. See also parameter <i>31.04 External event 2 type</i> . For the selections, see parameter <i>31.01 External event 1 source</i> .	<i>Inactive (true)</i>
31.04	<i>External event 2 type</i>	Selects the type of external event 2.	<i>Fault</i>
	Fault	The external event generates a fault.	0

No.	Name/Value	Description	Def/FbEq16
	Warning	The external event generates a warning.	1
31.05	<i>External event 3 source</i>	Defines the source of external event 3. See also parameter <i>31.06 External event 3 type</i> . For the selections, see parameter <i>31.01 External event 1 source</i> .	<i>Inactive (true)</i>
31.06	<i>External event 3 type</i>	Selects the type of external event 3.	<i>Fault</i>
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
31.07	<i>External event 4 source</i>	Defines the source of external event 4. See also parameter <i>31.08 External event 4 type</i> . For the selections, see parameter <i>31.01 External event 1 source</i> .	<i>Inactive (true)</i>
31.08	<i>External event 4 type</i>	Selects the type of external event 4.	<i>Fault</i>
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
31.09	<i>External event 5 source</i>	Defines the source of external event 5. See also parameter <i>31.10 External event 5 type</i> . For the selections, see parameter <i>31.01 External event 1 source</i> .	<i>Inactive (true)</i>
31.10	<i>External event 5 type</i>	Selects the type of external event 5.	<i>Fault</i>
	Fault	The external event generates a fault.	0
	Warning	The external event generates a warning.	1
31.11	<i>Fault reset selection</i>	Selects the source of an external fault reset signal. The signal resets the drive after a fault trip if the cause of the fault no longer exists. 0 -> 1 = Reset Note: A fault reset from the fieldbus interface is always observed regardless of this parameter.	<i>Not used</i>
	Not used	Not used.	0
	Not used	Not used.	1
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	18
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	19
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	20
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264).	24
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264).	25
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264).	26
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-


No.	Name/Value	Description	Def/FbEq16																								
31.12	Autoreset selection	<p>Selects faults that are automatically reset. The parameter is a 16-bit word with each bit corresponding to a fault type. Whenever a bit is set to 1, the corresponding fault is automatically reset.</p> <p> WARNING! Before you activate the function, make sure that no dangerous situations can occur. The function restarts the drive automatically and continues operation after a fault.</p> <p>The bits of this binary number correspond to the following faults:</p>	0x0000																								
<table border="1"> <thead> <tr> <th>Bit</th> <th>Fault</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Overcurrent</td> </tr> <tr> <td>1</td> <td>Overvoltage</td> </tr> <tr> <td>2</td> <td>Undervoltage</td> </tr> <tr> <td>3</td> <td>AI supervision fault</td> </tr> <tr> <td>4...9</td> <td>Reserved</td> </tr> <tr> <td>10</td> <td>Selectable fault (see parameter 31.13 Selectable fault)</td> </tr> <tr> <td>11</td> <td>External fault 1 (from source selected by parameter 31.01 External event 1 source)</td> </tr> <tr> <td>12</td> <td>External fault 2 (from source selected by parameter 31.03 External event 2 source)</td> </tr> <tr> <td>13</td> <td>External fault 3 (from source selected by parameter 31.05 External event 3 source)</td> </tr> <tr> <td>14</td> <td>External fault 4 (from source selected by parameter 31.07 External event 4 source)</td> </tr> <tr> <td>15</td> <td>External fault 5 (from source selected by parameter 31.09 External event 5 source)</td> </tr> </tbody> </table>				Bit	Fault	0	Overcurrent	1	Overvoltage	2	Undervoltage	3	AI supervision fault	4...9	Reserved	10	Selectable fault (see parameter 31.13 Selectable fault)	11	External fault 1 (from source selected by parameter 31.01 External event 1 source)	12	External fault 2 (from source selected by parameter 31.03 External event 2 source)	13	External fault 3 (from source selected by parameter 31.05 External event 3 source)	14	External fault 4 (from source selected by parameter 31.07 External event 4 source)	15	External fault 5 (from source selected by parameter 31.09 External event 5 source)
Bit	Fault																										
0	Overcurrent																										
1	Overvoltage																										
2	Undervoltage																										
3	AI supervision fault																										
4...9	Reserved																										
10	Selectable fault (see parameter 31.13 Selectable fault)																										
11	External fault 1 (from source selected by parameter 31.01 External event 1 source)																										
12	External fault 2 (from source selected by parameter 31.03 External event 2 source)																										
13	External fault 3 (from source selected by parameter 31.05 External event 3 source)																										
14	External fault 4 (from source selected by parameter 31.07 External event 4 source)																										
15	External fault 5 (from source selected by parameter 31.09 External event 5 source)																										
	0x0000...0xffff	Automatic reset configuration word.	1 = 1																								
31.13	Selectable fault	<p>Defines the fault that can be automatically reset using parameter 31.12 Autoreset selection, bit 10.</p> <p>Faults are listed in chapter Fault tracing (page 402).</p>	0x0000																								
	0x0000...0xffff	Fault code.	10 = 1																								
31.14	Number of trials	<p>Defines a time window for automatic fault resets. The maximum number of attempts made during any period of this length is defined by 31.15 Total trials time.</p> <p>Note: If the fault condition remains and cannot be reset, each reset attempt will generate an event and start a new time window. In practice, if the specified number of resets (31.14) at specified intervals (31.16) take longer than the value of 31.15, the drive will continue to attempt resetting the fault until the cause is eventually removed.</p> <p>Defines the number of automatic fault resets the drive performs within the time defined by parameter 31.15 Total trials time.</p>	0																								
	0...5	Number of automatic resets.	10 = 1																								
31.15	Total trials time	<p>Defines the time the automatic reset function will attempt to reset the drive. During this time, it will perform the number of automatic resets defined by 31.14 Number of trials.</p>	30.0 s																								
	1.0...600.0 s	Time for automatic resets.	10 = 1 s																								
31.16	Delay time	<p>Defines the time that the drive will wait after a fault before attempting an automatic reset. See parameter 31.12 Autoreset selection.</p>	0.0 s																								
	0.0...120.0 s	Autoreset delay.	10 = 1 s																								



No.	Name/Value	Description	Def/FbEq16																								
31.19	<i>Motor phase loss</i>	Selects how the drive reacts when a motor phase loss is detected.	<i>Fault</i>																								
	No action	No action taken.	0																								
	Fault	The drive trips on fault <i>3381 Output phase loss</i> .	1																								
31.22	<i>STO indication run/stop</i>	<p>Selects which indications are given when one or both Safe torque off (STO) signals are switched off or lost. The indications also depend on whether the drive is running or stopped when this occurs.</p> <p>The tables at each selection below show the indications generated with that particular setting.</p> <p>Notes:</p> <ul style="list-style-type: none"> This parameter does not affect the operation of the STO function itself. The STO function will operate regardless of the setting of this parameter: a running drive will stop upon removal of one or both STO signals, and will not start until both STO signals are restored and all faults reset. The loss of only one STO signal always generates a fault as it is interpreted as a malfunction. <p>For more information on the STO, see chapter <i>The Safe torque off function</i> in the <i>Hardware manual</i> of the drive.</p>	<i>Fault/Fault</i>																								
	Fault/Fault	<table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th>IN1</th> <th>IN2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Fault <i>5091 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i></td> </tr> <tr> <td>1</td> <td>1</td> <td>(Normal operation)</td> </tr> </tbody> </table>	Inputs		Indication (running or stopped)	IN1	IN2	0	0	Fault <i>5091 Safe torque off</i>	0	1	Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i>	1	0	Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i>	1	1	(Normal operation)	0							
Inputs		Indication (running or stopped)																									
IN1	IN2																										
0	0	Fault <i>5091 Safe torque off</i>																									
0	1	Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i>																									
1	0	Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i>																									
1	1	(Normal operation)																									
	Fault/Warning	<table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th colspan="2">Indication</th> </tr> <tr> <th>IN1</th> <th>IN2</th> <th>Running</th> <th>Stopped</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Fault <i>5091 Safe torque off</i></td> <td>Warning <i>A5A0 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i></td> <td>Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i></td> <td>Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i></td> </tr> <tr> <td>1</td> <td>1</td> <td colspan="2">(Normal operation)</td> </tr> </tbody> </table>	Inputs		Indication		IN1	IN2	Running	Stopped	0	0	Fault <i>5091 Safe torque off</i>	Warning <i>A5A0 Safe torque off</i>	0	1	Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i>	Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i>	1	0	Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i>	Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i>	1	1	(Normal operation)		1
Inputs		Indication																									
IN1	IN2	Running	Stopped																								
0	0	Fault <i>5091 Safe torque off</i>	Warning <i>A5A0 Safe torque off</i>																								
0	1	Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i>	Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i>																								
1	0	Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i>	Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i>																								
1	1	(Normal operation)																									

No.	Name/Value	Description	Def/FbEq16																								
	Fault/Event	<table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th colspan="2">Indication</th> </tr> <tr> <th>IN1</th> <th>IN2</th> <th>Running</th> <th>Stopped</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Fault <i>5091 Safe torque off</i></td> <td>Event <i>B5A0 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i></td> <td>Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i></td> <td>Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i></td> </tr> <tr> <td>1</td> <td>1</td> <td colspan="2">(Normal operation)</td> </tr> </tbody> </table>	Inputs		Indication		IN1	IN2	Running	Stopped	0	0	Fault <i>5091 Safe torque off</i>	Event <i>B5A0 Safe torque off</i>	0	1	Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i>	Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i>	1	0	Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i>	Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i>	1	1	(Normal operation)		2
Inputs		Indication																									
IN1	IN2	Running	Stopped																								
0	0	Fault <i>5091 Safe torque off</i>	Event <i>B5A0 Safe torque off</i>																								
0	1	Faults <i>5091 Safe torque off</i> and <i>FA81 Safe torque off 1</i>	Event <i>B5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i>																								
1	0	Faults <i>5091 Safe torque off</i> and <i>FA82 Safe torque off 2</i>	Event <i>B5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i>																								
1	1	(Normal operation)																									
	Warning/Warning	<table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th>IN1</th> <th>IN2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Warning <i>A5A0 Safe torque off</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i></td> </tr> <tr> <td>1</td> <td>1</td> <td>(Normal operation)</td> </tr> </tbody> </table>	Inputs		Indication (running or stopped)	IN1	IN2	0	0	Warning <i>A5A0 Safe torque off</i>	0	1	Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i>	1	0	Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i>	1	1	(Normal operation)	3							
Inputs		Indication (running or stopped)																									
IN1	IN2																										
0	0	Warning <i>A5A0 Safe torque off</i>																									
0	1	Warning <i>A5A0 Safe torque off</i> and fault <i>FA81 Safe torque off 1</i>																									
1	0	Warning <i>A5A0 Safe torque off</i> and fault <i>FA82 Safe torque off 2</i>																									
1	1	(Normal operation)																									
	Event/Event	<table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th>IN1</th> <th>IN2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Event <i>B5A0 STO event</i></td> </tr> <tr> <td>0</td> <td>1</td> <td>Event <i>B5A0 STO event</i> and fault <i>FA81 Safe torque off 1</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Event <i>B5A0 STO event</i> and fault <i>FA82 Safe torque off 2</i></td> </tr> <tr> <td>1</td> <td>1</td> <td>(Normal operation)</td> </tr> </tbody> </table>	Inputs		Indication (running or stopped)	IN1	IN2	0	0	Event <i>B5A0 STO event</i>	0	1	Event <i>B5A0 STO event</i> and fault <i>FA81 Safe torque off 1</i>	1	0	Event <i>B5A0 STO event</i> and fault <i>FA82 Safe torque off 2</i>	1	1	(Normal operation)	4							
Inputs		Indication (running or stopped)																									
IN1	IN2																										
0	0	Event <i>B5A0 STO event</i>																									
0	1	Event <i>B5A0 STO event</i> and fault <i>FA81 Safe torque off 1</i>																									
1	0	Event <i>B5A0 STO event</i> and fault <i>FA82 Safe torque off 2</i>																									
1	1	(Normal operation)																									
	No indication/No indication	<table border="1"> <thead> <tr> <th colspan="2">Inputs</th> <th rowspan="2">Indication (running or stopped)</th> </tr> <tr> <th>IN1</th> <th>IN2</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>None</td> </tr> <tr> <td>0</td> <td>1</td> <td>Fault <i>FA81 Safe torque off 1</i></td> </tr> <tr> <td>1</td> <td>0</td> <td>Fault <i>FA82 Safe torque off 2</i></td> </tr> <tr> <td>1</td> <td>1</td> <td>(Normal operation)</td> </tr> </tbody> </table>	Inputs		Indication (running or stopped)	IN1	IN2	0	0	None	0	1	Fault <i>FA81 Safe torque off 1</i>	1	0	Fault <i>FA82 Safe torque off 2</i>	1	1	(Normal operation)	5							
Inputs		Indication (running or stopped)																									
IN1	IN2																										
0	0	None																									
0	1	Fault <i>FA81 Safe torque off 1</i>																									
1	0	Fault <i>FA82 Safe torque off 2</i>																									
1	1	(Normal operation)																									
31.23	<i>Wiring or earth fault</i>	Selects how the drive reacts to incorrect input power and motor cable connection (ie. input power cable is connected to drive motor connection).	<i>Fault</i>																								
	No action	No action taken.	0																								
	Fault	The drive trips on fault <i>3181 Wiring or earth fault</i> .	1																								

No.	Name/Value	Description	Def/FbEq16
31.24	<i>Stall function</i>	Selects how the drive reacts to a stall condition. A stall condition is defined as follows: <ul style="list-style-type: none"> • The drive exceeds the stall current limit (31.25 Stall current limit), and • the output frequency is below the level set by parameter 31.27 Stall frequency limit or the motor speed is below the level set by parameter 31.26 Stall speed limit, and • the conditions above have been true longer than the time set by parameter 31.28 Stall time. 	<i>No action</i>
	No action	None (stall supervision disabled).	0
	Warning	The drive generates an <i>A780 Motor stall (Programmable warning: 31.24 Stall function)</i> warning.	1
	Fault	The drive trips on fault <i>7121 Motor stall</i> .	2
31.25	<i>Stall current limit</i>	Stall current limit in percent of the nominal current of the motor. See parameter 31.24 Stall function .	200.0%
	0.0...1600.0%	Stall current limit.	-
31.26	<i>Stall speed limit</i>	Stall speed limit in rpm. See parameter 31.24 Stall function .	150.00 rpm
	0.00...10000.00 rpm	Stall speed limit.	See par. 46.01
31.27	<i>Stall frequency limit</i>	Stall frequency limit. See parameter 31.24 Stall function . Note: Setting the limit below 10 Hz is not recommended.	15.00 Hz
	0.00...1000.00 Hz	Stall frequency limit.	See par. 46.02
31.28	<i>Stall time</i>	Stall time. See parameter 31.24 Stall function .	20 s
	0...3600 s	Stall time.	-

262 Parameters

No.	Name/Value	Description	Def/FbEq16
31.30	<i>Overspeed trip margin</i>	<p>Defines, together with 30.11 Minimum speed and 30.12 Maximum speed, the maximum allowed speed of the motor (overspeed protection). If the speed (24.02 Used speed feedback) feedback exceeds the speed limit defined by parameter 30.11 or 30.12 by more than the value of this parameter, the drive trips on the 7310 Overspeed fault.</p> <p>⚠ WARNING! This function only supervises the speed in vector motor control mode. The function is not effective in scalar motor control mode.</p> <p>Example: If the maximum speed is 1420 rpm and speed trip margin is 300 rpm, the drive trips at 1720 rpm.</p> <p><i>Speed feedback (24.02)</i></p> 	500.00 rpm
	0.00...10000.00 rpm	Overspeed trip margin.	See par. 46.01

No.	Name/Value	Description	Def/FbEq16
31.31	<i>Frequency trip margin</i>	<p>Defines, together with 30.13 Minimum frequency and 30.14 Maximum frequency, the maximum allowed frequency of the motor. If the speed (28.01 Frequency ref ramp input) exceeds the frequency limit defined by parameter 30.13 or 30.14 by more than the value of this parameter, the drive trips on the 73F0 Overfrequency fault.</p> <p> WARNING! This function only supervises the speed in scalar motor control mode. The function is not effective in vector motor control mode.</p> <p>Example: If the maximum speed is 40 Hz and speed trip margin is 10 Hz, the drive trips at 50 Hz.</p> <p><i>Frequency (25.02)</i></p> 	15.00 Hz
	0.00...10000.00 Hz	Overfrequency trip margin.	See par. 46.02
31.35	<i>Main fan fault function</i>	<p>Selects how the drive reacts when a main cooling fan speed problem is detected.</p> <p>An event is triggered according to the value of this parameter (fault, warning or no action)</p> <ul style="list-style-type: none"> • if the rotation speed signal from the fan is lower than the measured fan maximum speed (determined during the fan ID run) • if the measured fan maximum speed is lower than the predefined minimum value 	<i>Warning</i>
	Fault	Drive trips on fault 5080 Fan .	0
	Warning	Drive generates warning A581 Fan .	1
	No action	No action taken.	2

No.	Name/Value	Description	Def/FbEq16
31.36	<i>Aux fan fault function</i>	<p>Selects how the drive reacts when an auxiliary fan problem is detected.</p> <p>Certain drive types (especially those protected to IP55) have an auxiliary fan built into the front cover as standard. If it is necessary to operate the drive without the front cover (for example, during commissioning), you can set the parameter to value No action within two minutes from power-up to temporarily suppress the fault or warning. Return the value to Fault or Warning afterwards.</p> <p>This parameter is applicable only for frames R3 or larger. On frame sizes R3...R5, the auxiliary fan is attached to connector X10 and on frame sizes R6 and larger to connector X16.</p>	<i>Warning</i>
	Fault	The drive trips on fault <i>5081 Auxiliary fan broken</i> . The fault is suppressed for two minutes after power-up.	0
	Warning	The drive generates a warning <i>A582 Auxiliary fan missing</i> . The warning is suppressed for two minutes after power-up.	1
	No action	No action taken	2

32 Supervision

Configuration of signal supervision functions 1...6. Six values can be chosen to be monitored; a warning or fault is generated whenever predefined limits are exceeded. See also section *Signal supervision* (page 93).

32.01	<i>Supervision status</i>	<p>Signal supervision status word. Indicates whether the values monitored by the signal supervision functions are within or outside their respective limits.</p> <p>Note: This word is independent of the drive actions defined by parameters <i>32.06</i>, <i>32.16</i>, <i>32.26</i>, <i>32.36</i>, <i>32.46</i> and <i>32.56</i>.</p>	0b000
-------	---------------------------	---	-------

Bit	Name	Description
0	Supervision 1 active	1 = Signal selected by <i>32.07</i> is outside its limits.
1	Supervision 2 active	1 = Signal selected by <i>32.17</i> is outside its limits.
2	Supervision 3 active	1 = Signal selected by <i>32.27</i> is outside its limits.
3	Supervision 4 active	1 = Signal selected by <i>32.37</i> is outside its limits.
4	Supervision 5 active	1 = Signal selected by <i>32.47</i> is outside its limits.
5	Supervision 6 active	1 = Signal selected by <i>32.27</i> is outside its limits.
6...15	Reserved	

0b0000...0b1111	Signal supervision status word.	1 = 1
-----------------	---------------------------------	-------

32.05	<i>Supervision 1 function</i>	Selects the mode of signal supervision function 1. Determines how the monitored signal (see parameter <i>32.07</i>) is compared to its low and high limits (<i>32.09</i> and <i>32.10</i> respectively). The action to be taken when the condition is fulfilled is selected by <i>32.06</i> .	<i>Disabled</i>
	Disabled	Signal supervision 1 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3

No.	Name/Value	Description	Def/FbEq16
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal rises above the value defined by the high limit + 0.5 hysteresis. The action is deactivated when the signal falls below the value defined by the low limit - 0.5 hysteresis.	7
32.06	<i>Supervision 1 action</i>	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 1 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status .	<i>No action</i>
	No action	No warning or fault generated.	0
	Warning	Warning A8B0 Signal supervision 1 is generated.	1
	Fault	Drive trips on fault 80B0 Signal supervision 1 .	2
	Fault if running	If running, the drive trips on fault 80B0 Signal supervision 1 .	3
32.07	<i>Supervision 1 signal</i>	Selects the signal to be monitored by signal supervision function 1.	<i>Frequency</i>
	Zero	None.	0
	Speed	01.01 Motor speed used (page 163).	1
	Frequency	01.06 Output frequency (page 163).	3
	Current	01.07 Motor current (page 163).	4
	Torque	01.10 Motor torque (page 163).	6
	DC voltage	01.11 DC voltage (page 163).	7
	Output power	01.14 Output power (page 164).	8
	AI1	12.11 AI1 actual value (page 187).	9
	AI2	12.21 AI2 actual value (page 189).	10
	Inverter temperature	05.11 Inverter temperature (page 169).	23
	Process PID output	40.01 Process PID output actual (page 293).	24
	Process PID feedback	40.02 Process PID feedback actual (page 293).	25
	Process PID setpoint	40.03 Process PID setpoint actual (page 293).	26
	Process PID deviation	40.04 Process PID deviation actual (page 293).	27
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
32.08	<i>Supervision 1 filter time</i>	Defines a filter time constant for the signal monitored by signal supervision 1.	0.000 s
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s
32.09	<i>Supervision 1 low</i>	Defines the lower limit for signal supervision 1.	0.00
	-21474836.00... 21474836.00	Low limit.	-

No.	Name/Value	Description	Def/FbEq16
32.10	<i>Supervision 1 high</i>	Defines the high limit for signal supervision 1.	0.00
	-21474836.00... 21474836.00	High limit.	-
32.11	<i>Supervision 1 hysteresis</i>	Defines the hysteresis for the signal monitored by signal supervision 1.	0.00
	0.00...100000.00	Hysteresis.	-
32.15	<i>Supervision 2 function</i>	Selects the mode of signal supervision function 2. Determines how the monitored signal (see parameter 32.17) is compared to its low and high limits (32.19 and 32.20 respectively). The action to be taken when the condition is fulfilled is selected by 32.16.	<i>Disabled</i>
	Disabled	Signal supervision 2 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal rises above the value defined by the high limit + 0.5 hysteresis. The action is deactivated when the signal falls below the value defined by the low limit - 0.5 hysteresis.	7
32.16	<i>Supervision 2 action</i>	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 2 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 <i>Supervision status</i> .	<i>No action</i>
	No action	No warning or fault generated.	0
	Warning	Warning <i>A8B1 Signal supervision 2</i> is generated.	1
	Fault	Drive trips on fault <i>80B1 Signal supervision 2</i> .	2
	Fault if running	If running, the drive trips on fault <i>80B0 Signal supervision 1</i> .	3
32.17	<i>Supervision 2 signal</i>	Selects the signal to be monitored by signal supervision function 2. For the available selections, see parameter 32.07 <i>Supervision 1 signal</i> .	<i>Current</i>
32.18	<i>Supervision 2 filter time</i>	Defines a filter time constant for the signal monitored by signal supervision 2.	0.000 s
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s
32.19	<i>Supervision 2 low</i>	Defines the low limit for signal supervision 2.	0.00
	-21474836.00... 21474836.00	Low limit.	-
32.20	<i>Supervision 2 high</i>	Defines the high limit for signal supervision 2.	0.00
	-21474836.00... 21474836.00	High limit.	-

No.	Name/Value	Description	Def/FbEq16
32.21	<i>Supervision 2 hysteresis</i>	Defines the hysteresis for the signal monitored by signal supervision 2.	0.00
	0.00...100000.00	Hysteresis.	-
32.25	<i>Supervision 3 function</i>	Selects the mode of signal supervision function 3. Determines how the monitored signal (see parameter 32.27) is compared to its low and high limits (32.29 and 32.30 respectively). The action to be taken when the condition is fulfilled is selected by 32.26.	<i>Disabled</i>
	Disabled	Signal supervision 3 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal falls below its (hysteresis) low limit or rises above its (hysteresis) high limit.	7
32.26	<i>Supervision 3 action</i>	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 3 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 <i>Supervision status</i> .	<i>No action</i>
	No action	No warning or fault generated.	0
	Warning	Warning <i>A8B2 Signal supervision 3</i> is generated.	1
	Fault	Drive trips on fault <i>80B2 Signal supervision 3</i> .	2
	Fault if running	If running, the drive trips on fault <i>80B0 Signal supervision 1</i> .	3
32.27	<i>Supervision 3 signal</i>	Selects the signal to be monitored by signal supervision function 3. For the available selections, see parameter 32.07 <i>Supervision 1 signal</i> .	<i>Torque</i>
32.28	<i>Supervision 3 filter time</i>	Defines a filter time constant for the signal monitored by signal supervision 3.	0.000 s
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s
32.29	<i>Supervision 3 low</i>	Defines the low limit for signal supervision 3.	0.00
	-21474836.00... 21474836.00	Low limit.	-
32.30	<i>Supervision 3 high</i>	Defines the high limit for signal supervision 3.	0.00
	-21474836.00... 21474836.00	High limit.	-
32.31	<i>Supervision 3 hysteresis</i>	Defines the hysteresis for the signal monitored by signal supervision 3.	0.00
	0.00...100000.00	Hysteresis.	-

No.	Name/Value	Description	Def/FbEq16
32.35	Supervision 4 function	Selects the mode of signal supervision function 4. Determines how the monitored signal (see parameter 32.37) is compared to its low and high limits (32.39 and 32.30 respectively). The action to be taken when the condition is fulfilled is selected by 32.36 .	<i>Disabled</i>
	Disabled	Signal supervision 4 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal falls below its (hysteresis) low limit or rises above its (hysteresis) high limit.	7
32.36	Supervision 4 action	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 4 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status .	<i>No action</i>
	No action	No warning or fault generated.	0
	Warning	Warning A8B3 Signal supervision 4 is generated.	1
	Fault	Drive trips on fault 80B3 Signal supervision 4 .	2
	Fault if running	Drive trips on fault 80B0 Signal supervision 1 if the motor is running.	3
32.37	Supervision 4 signal	Selects the signal to be monitored by signal supervision function 4. For the available selections, see parameter 32.07 Supervision 1 signal .	<i>Zero</i>
32.38	Supervision 4 filter time	Defines a filter time constant for the signal monitored by signal supervision 4.	0.000 s
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s
32.39	Supervision 4 low	Defines the low limit for signal supervision 4.	0.00
	-21474836.00... 21474836.00	Low limit.	-
32.40	Supervision 4 high	Defines the high limit for signal supervision 4.	0.00
	-21474836.00... 21474836.00	High limit.	-
32.41	Supervision 4 hysteresis	Defines the hysteresis for the signal monitored by signal supervision 4.	0.00
	0.00...100000.00	Hysteresis.	-

No.	Name/Value	Description	Def/FbEq16
32.45	<i>Supervision 5 function</i>	Selects the mode of signal supervision function 5. Determines how the monitored signal (see parameter 32.47) is compared to its low and high limits (32.49 and 32.40 respectively). The action to be taken when the condition is fulfilled is selected by 32.46.	<i>Disabled</i>
	Disabled	Signal supervision 5 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal falls below its (hysteresis) low limit or rises above its (hysteresis) high limit.	7
32.46	<i>Supervision 5 action</i>	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 5 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 <i>Supervision status</i> .	<i>No action</i>
	No action	No warning or fault generated.	0
	Warning	Warning <i>A8B4 Signal supervision 5</i> is generated.	1
	Fault	Drive trips on fault <i>80B4 Signal supervision 5</i> .	2
	Fault if running	Drive trips on fault <i>80B0 Signal supervision 1</i> if the motor is running.	3
32.47	<i>Supervision 5 signal</i>	Selects the signal to be monitored by signal supervision function 5. For the available selections, see parameter 32.07 <i>Supervision 1 signal</i> .	<i>Zero</i>
32.48	<i>Supervision 5 filter time</i>	Defines a filter time constant for the signal monitored by signal supervision 5.	0.000 s
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s
32.49	<i>Supervision 5 low</i>	Defines the low limit for signal supervision 5.	0.00
	-21474836.00... 21474836.00	Low limit.	-
32.50	<i>Supervision 5 high</i>	Defines the high limit for signal supervision 5.	0.00
	-21474836.00... 21474836.00	High limit.	-
32.51	<i>Supervision 5 hysteresis</i>	Defines the hysteresis for the signal monitored by signal supervision 5.	0.00
	0.00...100000.00	Hysteresis.	-

270 Parameters

No.	Name/Value	Description	Def/FbEq16
32.55	Supervision 6 function	Selects the mode of signal supervision function 6. Determines how the monitored signal (see parameter 32.57) is compared to its low and high limits (32.59 and 32.50 respectively). The action to be taken when the condition is fulfilled is selected by 32.56 .	<i>Disabled</i>
	Disabled	Signal supervision 6 not in use.	0
	Low	Action is taken whenever the signal falls below its low limit.	1
	High	Action is taken whenever the signal rises above its high limit.	2
	Abs low	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit.	3
	Abs high	Action is taken whenever the absolute value of the signal rises above its (absolute) high limit.	4
	Both	Action is taken whenever the signal falls below its low limit or rises above its high limit.	5
	Abs both	Action is taken whenever the absolute value of the signal falls below its (absolute) low limit or rises above its (absolute) high limit.	6
	Hysteresis	Action is taken whenever the signal falls below its (hysteresis) low limit or rises above its (hysteresis) high limit.	7
32.56	Supervision 6 action	Selects whether the drive generates a fault, warning or neither when the value monitored by signal supervision 6 exceeds its limits. Note: This parameter does not affect the status indicated by 32.01 Supervision status .	<i>No action</i>
	No action	No warning or fault generated.	0
	Warning	Warning A8B5 Signal supervision 6 is generated.	1
	Fault	Drive trips on fault 80B5 Signal supervision 6 .	2
	Fault if running	Drive trips on fault 80B0 Signal supervision 1 if the motor is running.	3
32.57	Supervision 6 signal	Selects the signal to be monitored by signal supervision function 6. For the available selections, see parameter 32.07 Supervision 1 signal .	<i>Zero</i>
32.58	Supervision 6 filter time	Defines a filter time constant for the signal monitored by signal supervision 6.	0.000 s
	0.000 ... 30.000 s	Signal filter time.	1000 = 1 s
32.59	Supervision 6 low	Defines the low limit for signal supervision 6.	0.00
	-21474836.00... 21474836.00	Low limit.	-
32.60	Supervision 6 high	Defines the high limit for signal supervision 6.	0.00
	-21474836.00... 21474836.00	High limit.	-
32.61	Supervision 6 hysteresis	Defines the hysteresis for the signal monitored by signal supervision 6.	0.00
	0.00...100000.00	Hysteresis.	-

No.	Name/Value	Description	Def/FbEq16
34 Timed functions		Configuration of the timed functions. See also section <i>Motor control</i> (page 65).	
34.01	<i>Timed functions status</i>	Status of the combined timers. The status of a combined timer is the logical OR of all timers connected to it. This parameter is read-only.	0b0000
Bit	Name	Description	
0	Timed function 1	1 = Active.	
1	Timed function 2	1 = Active.	
2	Timed function 3	1 = Active.	
3...15	Reserved		
0b0000...0b1111		Status of combined timers 1...3.	1 = 1
34.02	<i>Timer status</i>	Status of timers 1...12. This parameter is read-only.	0b0000
Bit	Name	Description	
0	Timer 1	1 = Active.	
1	Timer 2	1 = Active.	
2	Timer 3	1 = Active.	
3	Timer 4	1 = Active.	
4	Timer 5	1 = Active.	
5	Timer 6	1 = Active.	
6	Timer 7	1 = Active.	
7	Timer 8	1 = Active.	
8	Timer 9	1 = Active.	
9	Timer 10	1 = Active.	
10	Timer 11	1 = Active.	
11	Timer 12	1 = Active.	
12...15	Reserved		
0b0000...0b1111		Timer status.	1 = 1

272 Parameters

No.	Name/Value	Description	Def/FbEq16																											
34.04	<i>Season/exception day status</i>	Status of seasons 1...3, exception weekday and exception holiday. Only one season can be active at a time. A day can be a workday and a holiday at the same time. This parameter is read-only.	0b0000																											
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Season 1</td> <td>1 = Active.</td> </tr> <tr> <td>1</td> <td>Season 2</td> <td>1 = Active.</td> </tr> <tr> <td>2</td> <td>Season 3</td> <td>1 = Active.</td> </tr> <tr> <td>3</td> <td>Season 4</td> <td>1 = Active.</td> </tr> <tr> <td>4...9</td> <td>Reserved</td> <td></td> </tr> <tr> <td>10</td> <td>Exception workday</td> <td>1 = Active.</td> </tr> <tr> <td>11</td> <td>Exception holiday</td> <td>1 = Active.</td> </tr> <tr> <td>12...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Description	0	Season 1	1 = Active.	1	Season 2	1 = Active.	2	Season 3	1 = Active.	3	Season 4	1 = Active.	4...9	Reserved		10	Exception workday	1 = Active.	11	Exception holiday	1 = Active.	12...15	Reserved	
Bit	Name	Description																												
0	Season 1	1 = Active.																												
1	Season 2	1 = Active.																												
2	Season 3	1 = Active.																												
3	Season 4	1 = Active.																												
4...9	Reserved																													
10	Exception workday	1 = Active.																												
11	Exception holiday	1 = Active.																												
12...15	Reserved																													
	0b0000...0b11110b1111	Status of the seasons and exception weekday and holiday.	1 = 1																											
34.10	<i>Timed functions enable</i>	Selects the source for the timed functions enable signal. 0 = Disabled. 1 = Enabled.	<i>Disabled</i>																											
	Disabled	0.	0																											
	Enabled	1.	1																											
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2																											
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3																											
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4																											
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5																											
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6																											
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7																											
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-																											

No.	Name/Value	Description	Def/FbEq16																																																
34.11	<i>Timer 1 configuration</i>	Defines when timer 1 is active.	0b0111																																																
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Monday</td> <td>1 = Monday is an active start day.</td> </tr> <tr> <td>1</td> <td>Tuesday</td> <td>1 = Tuesday is an active start day.</td> </tr> <tr> <td>2</td> <td>Wednesday</td> <td>1 = Wednesday is an active start day.</td> </tr> <tr> <td>3</td> <td>Thursday</td> <td>1 = Thursday is an active start day.</td> </tr> <tr> <td>4</td> <td>Friday</td> <td>1 = Friday is an active start day.</td> </tr> <tr> <td>5</td> <td>Saturday</td> <td>1 = Saturday is an active start day.</td> </tr> <tr> <td>6</td> <td>Sunday</td> <td>1 = Sunday is an active start day.</td> </tr> <tr> <td>7</td> <td>Season 1</td> <td>1 = Timer is active in season 1.</td> </tr> <tr> <td>8</td> <td>Season 2</td> <td>1 = Timer is active in season 2.</td> </tr> <tr> <td>9</td> <td>Season 3</td> <td>1 = Timer is active in season 3.</td> </tr> <tr> <td>10</td> <td>Season 4</td> <td>1 = Timer is active in season 4.</td> </tr> <tr> <td>11</td> <td>Exceptions</td> <td>0 = Exceptions days are disabled. 1 = Exception days are enabled. Bits 12 and 13 are taken into account.</td> </tr> <tr> <td>12</td> <td>Holidays</td> <td>0 = Timer is inactive on exception days configured as "Holiday". 1 = Timer is active on exception days configured as "Holiday".</td> </tr> <tr> <td>13</td> <td>Workdays</td> <td>0 = Timer is inactive on exception days configured as "Workday". 1 = Timer is active on exception days configured as "Workday".</td> </tr> <tr> <td>14...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Description	0	Monday	1 = Monday is an active start day.	1	Tuesday	1 = Tuesday is an active start day.	2	Wednesday	1 = Wednesday is an active start day.	3	Thursday	1 = Thursday is an active start day.	4	Friday	1 = Friday is an active start day.	5	Saturday	1 = Saturday is an active start day.	6	Sunday	1 = Sunday is an active start day.	7	Season 1	1 = Timer is active in season 1.	8	Season 2	1 = Timer is active in season 2.	9	Season 3	1 = Timer is active in season 3.	10	Season 4	1 = Timer is active in season 4.	11	Exceptions	0 = Exceptions days are disabled. 1 = Exception days are enabled. Bits 12 and 13 are taken into account.	12	Holidays	0 = Timer is inactive on exception days configured as "Holiday". 1 = Timer is active on exception days configured as "Holiday".	13	Workdays	0 = Timer is inactive on exception days configured as "Workday". 1 = Timer is active on exception days configured as "Workday".	14...15	Reserved		
Bit	Name	Description																																																	
0	Monday	1 = Monday is an active start day.																																																	
1	Tuesday	1 = Tuesday is an active start day.																																																	
2	Wednesday	1 = Wednesday is an active start day.																																																	
3	Thursday	1 = Thursday is an active start day.																																																	
4	Friday	1 = Friday is an active start day.																																																	
5	Saturday	1 = Saturday is an active start day.																																																	
6	Sunday	1 = Sunday is an active start day.																																																	
7	Season 1	1 = Timer is active in season 1.																																																	
8	Season 2	1 = Timer is active in season 2.																																																	
9	Season 3	1 = Timer is active in season 3.																																																	
10	Season 4	1 = Timer is active in season 4.																																																	
11	Exceptions	0 = Exceptions days are disabled. 1 = Exception days are enabled. Bits 12 and 13 are taken into account.																																																	
12	Holidays	0 = Timer is inactive on exception days configured as "Holiday". 1 = Timer is active on exception days configured as "Holiday".																																																	
13	Workdays	0 = Timer is inactive on exception days configured as "Workday". 1 = Timer is active on exception days configured as "Workday".																																																	
14...15	Reserved																																																		
	0b0000...0b1111	Configuration of timer 1.	1 = 1																																																
34.12	<i>Timer 1 start time</i>	Defines the daily start time of timer 1. The time can be changed in second steps. The timer can be started at a other time than the start time. E.g. if the timer's duration is more than one day and the active session starts during the time, the timer is started at 00:00 and stopped when there is no duration left.	00:00:00																																																
	00:00:00...23:59:59	Daily start time of the timer.	1 = 1																																																
34.13	<i>Timer 1 duration</i>	Defines the duration of timer 1. The duration can be changed in minute steps. The duration can extend over the change of the day but if an exception day becomes active, the period is interrupted at midnight. In the same way the period started on an exception day stays active only until the end of the day, even if the duration is longer. The timer will continue after a break if there is duration left.	00 00:00																																																
	00 00:00...07 00:00	Timer duration.	1 = 1																																																
34.14	<i>Timer 2 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111																																																
34.15	<i>Timer 2 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00																																																
34.16	<i>Timer 2 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00																																																
34.17	<i>Timer 3 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111																																																

274 Parameters

No.	Name/Value	Description	Def/FbEq16
34.18	<i>Timer 3 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.19	<i>Timer 3 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.20	<i>Timer 4 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.21	<i>Timer 4 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.22	<i>Timer 4 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.23	<i>Timer 5 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.24	<i>Timer 5 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.25	<i>Timer 5 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.26	<i>Timer 6 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.27	<i>Timer 6 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.28	<i>Timer 6 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.29	<i>Timer 7 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.30	<i>Timer 7 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.31	<i>Timer 7 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.32	<i>Timer 8 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.33	<i>Timer 8 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.34	<i>Timer 8 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.35	<i>Timer 9 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.36	<i>Timer 9 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.37	<i>Timer 9 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.38	<i>Timer 10 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.39	<i>Timer 10 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.40	<i>Timer 10 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.41	<i>Timer 11 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.42	<i>Timer 11 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.43	<i>Timer 11 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00
34.44	<i>Timer 12 configuration</i>	See 34.11 <i>Timer 1 configuration</i> .	0b0111
34.45	<i>Timer 12 start time</i>	See 34.12 <i>Timer 1 start time</i> .	00:00:00
34.46	<i>Timer 12 duration</i>	See 34.13 <i>Timer 1 duration</i> .	00 00:00

No.	Name/Value	Description	Def/FbEq16																																																			
34.60	<i>Season 1 start date</i>	Defines the start date of season 1 in format dd.mm, where dd is the number of the day and mm is the number of the month. The season changes at midnight. One season can be active at a time. Timers are started on exception days even if they are not inside the active season. The season start dates (1...4) must be given in increasing order to use all seasons. The default value is interpreted that the season is not configured. If the season start dates are not in increasing order and the value is something else than the default value, a season configuration warning is given.	1.1																																																			
-		Season start date.																																																				
34.61	<i>Season 2 start date</i>	Defines the start date of season 2. See 34.60 <i>Season 1 start date</i> .	1.1																																																			
34.62	<i>Season 3 start date</i>	Defines the start date of season 3. See 34.60 <i>Season 1 start date</i> .	1.1																																																			
34.63	<i>Season 4 start date</i>	Defines the start date of season 4. See 34.60 <i>Season 1 start date</i> .	1.1																																																			
34.70	<i>Number of active exceptions</i>	Defines how many of the exceptions are active by specifying the last active one. All preceding exceptions are active. Exceptions 1...3 are periods (duration can be defined) and exceptions 4...16 are days (duration is always 24 hours). Example: If the value is 4, exceptions 1...4 are active, and exceptions 5...16 are not active.	3																																																			
0...16		Number of active exception periods or days.	-																																																			
34.71	<i>Exception types</i>	Defines the types of exceptions 1...16 as workday or holiday. Exceptions 1...3 are periods (duration can be defined) and exceptions 4...16 are days (duration is always 24 hours).	0b0000																																																			
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>Exception 1</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>1</td><td>Exception 2</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>2</td><td>Exception 3</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>3</td><td>Exception 4</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>4</td><td>Exception 5</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>5</td><td>Exception 6</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>6</td><td>Exception 7</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>7</td><td>Exception 8</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>8</td><td>Exception 9</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>9</td><td>Exception 10</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>10</td><td>Exception 11</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>11</td><td>Exception 12</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>12</td><td>Exception 13</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>13</td><td>Exception 14</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>14</td><td>Exception 15</td><td>0 = Workday. 1 = Holiday</td></tr> <tr><td>15</td><td>Exception 16</td><td>0 = Workday. 1 = Holiday</td></tr> </tbody> </table>	Bit	Name	Description	0	Exception 1	0 = Workday. 1 = Holiday	1	Exception 2	0 = Workday. 1 = Holiday	2	Exception 3	0 = Workday. 1 = Holiday	3	Exception 4	0 = Workday. 1 = Holiday	4	Exception 5	0 = Workday. 1 = Holiday	5	Exception 6	0 = Workday. 1 = Holiday	6	Exception 7	0 = Workday. 1 = Holiday	7	Exception 8	0 = Workday. 1 = Holiday	8	Exception 9	0 = Workday. 1 = Holiday	9	Exception 10	0 = Workday. 1 = Holiday	10	Exception 11	0 = Workday. 1 = Holiday	11	Exception 12	0 = Workday. 1 = Holiday	12	Exception 13	0 = Workday. 1 = Holiday	13	Exception 14	0 = Workday. 1 = Holiday	14	Exception 15	0 = Workday. 1 = Holiday	15	Exception 16	0 = Workday. 1 = Holiday	
Bit	Name	Description																																																				
0	Exception 1	0 = Workday. 1 = Holiday																																																				
1	Exception 2	0 = Workday. 1 = Holiday																																																				
2	Exception 3	0 = Workday. 1 = Holiday																																																				
3	Exception 4	0 = Workday. 1 = Holiday																																																				
4	Exception 5	0 = Workday. 1 = Holiday																																																				
5	Exception 6	0 = Workday. 1 = Holiday																																																				
6	Exception 7	0 = Workday. 1 = Holiday																																																				
7	Exception 8	0 = Workday. 1 = Holiday																																																				
8	Exception 9	0 = Workday. 1 = Holiday																																																				
9	Exception 10	0 = Workday. 1 = Holiday																																																				
10	Exception 11	0 = Workday. 1 = Holiday																																																				
11	Exception 12	0 = Workday. 1 = Holiday																																																				
12	Exception 13	0 = Workday. 1 = Holiday																																																				
13	Exception 14	0 = Workday. 1 = Holiday																																																				
14	Exception 15	0 = Workday. 1 = Holiday																																																				
15	Exception 16	0 = Workday. 1 = Holiday																																																				
0b0000...0b1111		Types of exception period or days.	1 = 1																																																			

276 Parameters

No.	Name/Value	Description	Def/FbEq16
34.72	Exception 1 start	Defines the start date of the exception period in format dd.mm, where dd is the number of the day and mm is the number of the month. The timer started on an exception day is always stopped at 23:59:59 even if it has duration left. The same date can be configured to be holiday and workday. The date is active if any of exception days are active.	1.1
-		Start date of exception period 1.	
34.73	Exception 1 length	Defines the length of the exception period in days. Exception period is handled the same as a number of consecutive exception days.	0 d
	0...60 d	Length of exception period 1.	1 = 1
34.74	Exception 2 start	See 34.72 Exception 1 start .	1.1
34.75	Exception 2 length	See 34.73 Exception 1 length .	0 d
34.76	Exception 3 start	See 34.72 Exception 1 start .	1.1
34.77	Exception 3 length	See 34.73 Exception 1 length .	0 d
34.78	Exception day 4	Defines the date of exception day 4.	1.1
-		Start date of exception day 4. The timer started on an exception day is always stopped at 23:59:59 even if it has duration left.	
34.79	Exception day 5	See 34.79 Exception day 4 .	1.1
34.80	Exception day 6	See 34.79 Exception day 4 .	1.1
34.81	Exception day 7	See 34.79 Exception day 4	1.1
34.82	Exception day 8	See 34.79 Exception day 4 .	1.1
34.83	Exception day 9	See 34.79 Exception day 4 .	1.1
34.84	Exception day 10	See 34.79 Exception day 4 .	1.1
34.85	Exception day 11	See 34.79 Exception day 4 .	1.1
34.86	Exception day 12	See 34.79 Exception day 4 .	1.1
34.87	Exception day 13	See 34.79 Exception day 4 .	1.1
34.88	Exception day 14	See 34.79 Exception day 4 .	1.1
34.89	Exception day 15	See 34.79 Exception day 4 .	1.1
34.90	Exception day 16	See 34.79 Exception day 4 .	1.1

No.	Name/Value	Description	Def/FbEq16																																										
34.100	<i>Timed function 1</i>	Defines which timers are connected to combined timer 1. 0 = Not connected. 1 = Connected. See 34.01 Timed functions status .	0b0000																																										
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>Timer 1</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>1</td><td>Timer 2</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>2</td><td>Timer 3</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>3</td><td>Timer 4</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>4</td><td>Timer 5</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>5</td><td>Timer 6</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>6</td><td>Timer 7</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>7</td><td>Timer 8</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>8</td><td>Timer 9</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>9</td><td>Timer 10</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>10</td><td>Timer 11</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>11</td><td>Timer 12</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>12...15</td><td>Reserved</td><td></td></tr> </tbody> </table>				Bit	Name	Description	0	Timer 1	0 = Inactive. 1 = Active.	1	Timer 2	0 = Inactive. 1 = Active.	2	Timer 3	0 = Inactive. 1 = Active.	3	Timer 4	0 = Inactive. 1 = Active.	4	Timer 5	0 = Inactive. 1 = Active.	5	Timer 6	0 = Inactive. 1 = Active.	6	Timer 7	0 = Inactive. 1 = Active.	7	Timer 8	0 = Inactive. 1 = Active.	8	Timer 9	0 = Inactive. 1 = Active.	9	Timer 10	0 = Inactive. 1 = Active.	10	Timer 11	0 = Inactive. 1 = Active.	11	Timer 12	0 = Inactive. 1 = Active.	12...15	Reserved	
Bit	Name	Description																																											
0	Timer 1	0 = Inactive. 1 = Active.																																											
1	Timer 2	0 = Inactive. 1 = Active.																																											
2	Timer 3	0 = Inactive. 1 = Active.																																											
3	Timer 4	0 = Inactive. 1 = Active.																																											
4	Timer 5	0 = Inactive. 1 = Active.																																											
5	Timer 6	0 = Inactive. 1 = Active.																																											
6	Timer 7	0 = Inactive. 1 = Active.																																											
7	Timer 8	0 = Inactive. 1 = Active.																																											
8	Timer 9	0 = Inactive. 1 = Active.																																											
9	Timer 10	0 = Inactive. 1 = Active.																																											
10	Timer 11	0 = Inactive. 1 = Active.																																											
11	Timer 12	0 = Inactive. 1 = Active.																																											
12...15	Reserved																																												
	0b0000...0b1111	Timers connected to combined timer 1.	1 = 1																																										
34.101	<i>Timed function 2</i>	Defines which timers are connected to combined timer 2. See 34.01 Timed functions status .	0b0000																																										
34.102	<i>Timed function 3</i>	Defines which timers are connected to combined timer 3. See 34.01 Timed functions status .	0b0000																																										
34.110	<i>Boost time function</i>	Defines which combined timers (that is, timers that are connected to the combined timers) are activated with the extra time function.	0b0000																																										
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr><td>0</td><td>Timed function 1</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>1</td><td>Timed function 2</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>2</td><td>Timed function 3</td><td>0 = Inactive. 1 = Active.</td></tr> <tr><td>3...15</td><td>Reserved</td><td></td></tr> </tbody> </table>				Bit	Name	Description	0	Timed function 1	0 = Inactive. 1 = Active.	1	Timed function 2	0 = Inactive. 1 = Active.	2	Timed function 3	0 = Inactive. 1 = Active.	3...15	Reserved																												
Bit	Name	Description																																											
0	Timed function 1	0 = Inactive. 1 = Active.																																											
1	Timed function 2	0 = Inactive. 1 = Active.																																											
2	Timed function 3	0 = Inactive. 1 = Active.																																											
3...15	Reserved																																												
	0b0000...0b1111	Combined timers including the extra timer.	1 = 1																																										
34.111	<i>Boost time activation source</i>	Selects the source of extra time activation signal. 0 = Disabled. 1 = Enabled.	<i>Off</i>																																										
	Off	0.	0																																										
	On	1.	1																																										
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2																																										
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3																																										
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4																																										
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5																																										
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6																																										
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7																																										

278 Parameters

No.	Name/Value	Description	Def/FbEq16
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
34.112	<i>Boost time duration</i>	Defines the time inside which the extra time is deactivated after extra time activation signal is switched off. Example: If parameter 34.111 Boost time activation source is set to D11 and 34.112 Boost time duration is set to 00 01:30, the extra time is active for 1 hour and 30 minutes after digital input DI is deactivated.	00 00:00
	00 00:00...07 00:00	Extra time duration.	1 = 1
35 Motor thermal protection		Motor thermal protection settings such as temperature measurement configuration, load curve definition and motor fan control configuration. See also section Motor thermal protection (page 83).	
35.01	<i>Motor estimated temperature</i>	Displays the motor temperature as estimated by the internal motor thermal protection model (see parameters 35.50...35.55). The unit is selected by parameter 96.16 Unit selection . This parameter is read-only.	0
	-60...1000 °C or -76...1832 °F	Estimated motor temperature.	1 = 1°C
35.02	<i>Measured temperature 1</i>	Displays the temperature received through the source defined by parameter 35.11 Temperature 1 source . The unit is selected by parameter 96.16 Unit selection . This parameter is read-only.	0
	-60...5000 °C or -76...9032 °F, 0...5000 ohm or [35.12] ohm	Measured temperature 1. Note: With a PTC sensor, the unit is ohms. If the measured temperature source selection (35.11) is PTC analog I/O or PTC AI/DI Voltage divider tree, the motor thermal protection function converts the analog input signal (35.14) to PTC resistance value (ohms), and shows it in this parameter. This is the case even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm by the time being (96.16).	1 = 1 unit
35.03	<i>Measured temperature 2</i>	Displays the temperature received through the source defined by parameter 35.21 Temperature 2 source . The unit is selected by parameter 96.16 Unit selection . This parameter is read-only.	0
	-60...5000 °C or -76...9032 °F, 0...5000 ohm or [35.22] ohm	Measured temperature 2. Note: With a PTC sensor, the unit is ohms. If the measured temperature source selection (35.21) is PTC analog I/O or PTC AI/DI Voltage divider tree, the motor thermal protection function converts the analog input signal (35.24) to PTC resistance value (ohms), and shows it in this parameter. This is the case even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm by the time being (96.16).	1 = 1 unit
35.05	<i>Motor overload level</i>	Motor overload level as a percentage of the fault limit.	0.0
	0.0...300.0 %	Motor overload level	1 = 1unit

No.	Name/Value	Description	Def/FbEq16
35.11	<i>Temperature 1 source</i>	Selects the source from which measured temperature 1 is read. Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.	<i>Estimated temperature</i>
	Disabled	None. Temperature monitoring function 1 is disabled.	0
	Estimated temperature	Estimated motor temperature (see parameter <i>35.01 Motor estimated temperature</i>). The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in <i>35.50 Motor ambient temperature</i> .	1
	KTY84 analog I/O	KTY84 sensor connected to the analog input selected by parameter <i>35.14 Temperature 1 AI source</i> and an analog output. The following settings are required: <ul style="list-style-type: none"> • Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. • Set the appropriate analog input unit selection parameter in group <i>12 Standard AI</i> to V (volt). • In parameter group <i>13 Standard AO</i>, set the source selection parameter of the analog output to <i>Temp sensor 1 excitation</i>. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.	2
	1 × Pt100 analog I/O	Pt100 sensor connected to a standard analog input selected by parameter <i>35.14 Temperature 1 AI source</i> and an analog output. The following settings are required: <ul style="list-style-type: none"> • Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. • Set the appropriate analog input unit selection parameter in group <i>12 Standard AI</i> to V (volt). • In parameter group <i>13 Standard AO</i>, set the source selection parameter of the analog output to <i>Temp sensor 1 excitation</i>. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.	5
	2 × Pt100 analog I/O	As selection <i>1 × Pt100 analog I/O</i> , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6
	3 × Pt100 analog I/O	As selection <i>1 × Pt100 analog I/O</i> , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7
	Direct temperature	The temperature is taken from the source selected by parameter <i>35.14 Temperature 1 AI source</i> . The value of the source is assumed to be in the unit of temperature specified by parameter <i>96.16 Unit selection</i> .	11


No.	Name/Value	Description	Def/FbEq16
	KTY83 analog I/O	<p>KTY83 sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source and an analog output.</p> <p>The following settings are required:</p> <ul style="list-style-type: none"> Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. <p>The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.</p>	12
	1 × Pt1000 analog I/O	<p>Pt1000 sensor connected to a standard analog input selected by parameter 35.14 Temperature 1 AI source and an analog output.</p> <p>The following settings are required:</p> <ul style="list-style-type: none"> Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. <p>The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.</p>	13
	2 × Pt1000 analog I/O	<p>As selection 1 × Pt1000 analog I/O, but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.</p>	14
	3 × Pt1000 analog I/O	<p>As selection 1 × Pt1000 analog I/O, but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.</p>	15
	Ni1000	<p>Ni1000 sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source and an analog output.</p> <p>The following settings are required:</p> <ul style="list-style-type: none"> Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. <p>The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.</p>	16

No.	Name/Value	Description	Def/FbEq16
	PTC analog I/O	PTC sensor connected to analog input selected by parameter 35.14 Temperature 1 AI source and an analog output. The required settings are the same as with selection <i>KTY84</i> analog I/O. Note: With this selection, the control program converts the analog signal to PTC resistance value in ohms and shows it in parameter 35.02 . The parameter name and unit still refer to temperature.	20
	PTC AI/DI Voltage Divider tree	PTC sensor connected to the analog input selected by parameter 35.14 Temperature 1 AI source . A special voltage divider connection must be in use instead of the normal PTC connection. The voltage divider connection uses the terminals +10 V, digital input and analog input. See the drive hardware manual for the actual connection. This selection makes it possible to connect the PTC when no analog output is available. The required settings are same as with selection <i>KTY84 analog I/O</i> . Notes: <ul style="list-style-type: none"> • This is applicable only for frames R0...R2. • Make sure that the digital input that you connect to this voltage divider circuit is not used for any other purpose in the control program. • With this selection, the parameter 35.02 shows PTC resistance in ohms, not motor temperature even the parameter name and unit still refer to temperature. 	23
35.12	Temperature 1 fault limit	Defines the fault limit for temperature supervision function 1. When measured temperature 1 exceeds the limit, the drive trips on fault 4981 External temperature 1 . The unit is selected by parameter 96.16 Unit selection .	130 °C or 266 °F or 4500 ohm
	-60...5000 °C or -76...9032 °F or 0...5000 ohm	Fault limit for temperature monitoring function 1. Note: If the measured temperature source selection (35.11) is PTC analog I/O or PTC AI/DI Voltage divider tree, the motor thermal protection function converts the analog input signal (35.14) to PTC resistance value (ohms). Also this limit is then a resistance value even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm by the time being (96.16).	1 = 1 unit
35.13	Temperature 1 warning limit	Defines the warning limit for temperature supervision function 1. When measured temperature 1 exceeds the limit, warning A491 External temperature 1 is generated. The unit is selected by parameter 96.16 Unit selection .	110°C or 230°F or 4000 ohm
	-60...5000 °C or -76...9032 °F or 0...5000 ohm	Warning limit for temperature monitoring function 1. Note: If the measured temperature source selection (35.11) is PTC analog I/O or PTC AI/DI Voltage divider tree, the motor thermal protection function converts the analog input signal (35.14) to PTC resistance value (ohms). Also this limit is then a resistance value even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm by the time being (96.16).	1 = 1 unit
35.14	Temperature 1 AI source	Specifies the analog input when the setting of 35.11 Temperature 1 source requires measurement through an analog input.	<i>Not selected</i>
	Not selected	None.	0

No.	Name/Value	Description	Def/FbEq16
	AI1 actual value	Analog input AI1 on the control unit.	1
	AI2 actual value	Analog input AI2 on the control unit.	2
	<i>Other</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
35.21	<i>Temperature 2 source</i>	Selects the source from which measured temperature 2 is read. Usually this source is from a sensor connected to the motor controlled by the drive, but it could be used to measure and monitor a temperature from other parts of the process as long as a suitable sensor is used as per the selection list.	<i>Estimated temperature</i>
	Disabled	None. Temperature monitoring function 2 is disabled.	0
	Estimated temperature	Estimated motor temperature (see parameter <i>35.01 Motor estimated temperature</i>). The temperature is estimated from an internal drive calculation. It is important to set up the ambient temperature of the motor in <i>35.50 Motor ambient temperature</i> .	1
	KTY84 analog I/O	KTY84 sensor connected to the analog input selected by parameter <i>35.24 Temperature 2 AI source</i> and an analog output. The following settings are required: <ul style="list-style-type: none"> Set the appropriate analog input unit selection parameter in group <i>12 Standard AI</i> to V (volt). In parameter group <i>12 Standard AI</i>, set the source selection parameter of the analog output to <i>Temp sensor 2 excitation</i>. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.	2
	1 × Pt100 analog I/O	Pt100 sensor connected to a standard analog input selected by parameter <i>35.24 Temperature 2 AI source</i> and an analog output. The following settings are required: <ul style="list-style-type: none"> Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. Set the appropriate analog input unit selection parameter in group <i>12 Standard AI</i> to V (volt). In parameter group <i>13 Standard AO</i>, set the source selection parameter of the analog output to <i>Temp sensor 2 excitation</i>. The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.	5
	2 × Pt100 analog I/O	As selection <i>1 × Pt100 analog I/O</i> , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	6
	3 × Pt100 analog I/O	As selection <i>1 × Pt100 analog I/O</i> , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	7

No.	Name/Value	Description	Def/FbEq16
	Direct temperature	The temperature is taken from the source selected by parameter 35.24 Temperature 2 AI source . The value of the source is assumed to be in the unit of temperature specified by parameter 96.16 Unit selection .	11
	KTY83 analog I/O	<p>KTY83 sensor connected to the analog input selected by parameter 35.24 Temperature 2 AI source and an analog output.</p> <p>The following settings are required:</p> <ul style="list-style-type: none"> • Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. • Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). • In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. <p>The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.</p>	12
	1 × Pt1000 analog I/O	<p>Pt1000 sensor connected to a standard analog input selected by parameter 35.24 Temperature 2 AI source and an analog output.</p> <p>The following settings are required:</p> <ul style="list-style-type: none"> • Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. • Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). • In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. <p>The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.</p>	13
	2 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O , but with two sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	14
	3 × Pt1000 analog I/O	As selection 1 × Pt1000 analog I/O , but with three sensors connected in series. Using multiple sensors improves measurement accuracy significantly.	15

No.	Name/Value	Description	Def/FbEq16
	Ni1000	<p>Ni1000 sensor connected to the analog input selected by parameter 35.24 Temperature 2 AI source and an analog output.</p> <p>The following settings are required:</p> <ul style="list-style-type: none"> • Set the hardware jumper or switch related to the analog input to U (voltage). Any change must be validated by a control unit reboot. • Set the appropriate analog input unit selection parameter in group 12 Standard AI to V (volt). • In parameter group 13 Standard AO, set the source selection parameter of the analog output to Temp sensor 1 excitation. <p>The analog output feeds a constant current through the sensor. As the resistance of the sensor increases along with its temperature, the voltage over the sensor increases. The voltage is read by the analog input and converted into degrees.</p>	16
	PTC analog I/O	<p>PTC sensor connected to analog input selected by parameter 35.24 Temperature 2 AI source and an analog output.</p> <p>The required settings are the same as with selection KTY84 analog I/O.</p> <p>Note: With this selection, the control program converts the analog signal to PTC resistance value in ohms and shows it in parameter 35.02 The parameter name and unit still refer to temperature.</p>	20
	PTC AI/DI Voltage Divider tree	<p>PTC sensor connected to the analog input selected by parameter 35.24 Temperature 2 AI source. A special voltage divider connection must be in use instead of the normal PTC connection. The voltage divider connection uses the terminals +10 V, digital input and analog input. See the drive hardware manual for the actual connection.</p> <p>This selection makes it possible to connect the PTC when no analog output is available.</p> <p>The required settings are same as with selection KTY84 analog I/O.</p> <p>Notes:</p> <ul style="list-style-type: none"> • Make sure that the digital input that you connect to this voltage divider circuit is not used for any other purpose in the control program. • With this selection, the parameter 35.03 shows PTC resistance in ohms, not motor temperature even the parameter name and unit still refer to temperature. 	23
35.22	Temperature 2 fault limit	<p>Defines the fault limit for temperature supervision function 2. When measured temperature 1 exceeds the limit, the drive trips on fault 4982 External temperature 2.</p> <p>The unit is selected by parameter 96.16 Unit selection.</p>	130 °C or 266 °F or 4500 ohm
	-60...5000 °C or -76...9032 °F or 0...5000 ohm	<p>Fault limit for temperature monitoring function 2.</p> <p>Note: If the measured temperature source selection (35.21) is PTC analog I/O or PTC AI/DI Voltage divider tree, the motor thermal protection function converts the analog input signal (35.24) to PTC resistance value (ohms). Also this limit is then a resistance value even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm by the time being (96.16).</p>	1 = 1 unit

No.	Name/Value	Description	Def/FbEq16
35.23	<i>Temperature 2 warning limit</i>	Defines the warning limit for temperature supervision function 2. When measured temperature 1 exceeds the limit, warning <i>A492 External temperature 2</i> is generated. The unit is selected by parameter <i>96.16 Unit selection</i> .	110 °C or 230 °F or 0...4000 ohm
	-60...5000 °C or -76...9032 °F or 0...5000 ohm	Warning limit for temperature monitoring function 2. Note: If the measured temperature source selection (<i>35.21</i>) is PTC analog I/O or PTC AI/DI Voltage divider tree, the motor thermal protection function converts the analog input signal (<i>35.24</i>) to PTC resistance value (ohms). Also this limit is then a resistance value even the parameter name and unit refer to motor temperature (°C or °F). You cannot change the unit to ohm by the time being (<i>96.16</i>).	1 = 1 unit
35.24	<i>Temperature 2 AI source</i>	Specifies the analog input when the setting of <i>35.11 Temperature 1 source</i> requires measurement through an analog input.	<i>Not selected</i>
	Not selected	None.	0
	AI1 actual value	Analog input AI1 on the control unit.	1
	AI2 actual value	Analog input AI2 on the control unit.	2
	<i>Other</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
35.50	<i>Motor ambient temperature</i>	Defines the ambient temperature of the motor for the motor thermal protection model. The unit is selected by parameter <i>96.16 Unit selection</i> . The motor thermal protection model estimates the motor temperature on the basis of parameters <i>35.50...35.55</i> . The motor temperature increases if it operates in the region above the load curve, and decreases if it operates in the region below the load curve.  WARNING! The model cannot protect the motor if the motor does not cool properly because of dust, dirt, etc.	20 °C
	-60...100 °C or -76 ... 212 °F	Ambient temperature.	1 = 1°

No.	Name/Value	Description	Def/FbEq16
35.51	<i>Motor load curve</i>	<p>Defines the motor load curve together with parameters 35.52 Zero speed load and 35.53 Break point. The load curve is used by the motor thermal protection model to estimate the motor temperature.</p> <p>When the parameter is set to 100%, the maximum load is taken as the value of parameter 99.06 Motor nominal current (higher loads heat up the motor). The load curve level should be adjusted if the ambient temperature differs from the nominal value set in 35.50 Motor ambient temperature.</p>	100%
<p>I/I_N (%)</p> <p>I = Motor current I_N = Nominal motor current</p> <p>150</p> <p>100</p> <p>50</p> <p>35.52</p> <p>35.51</p> <p>35.53</p> <p>Drive output frequency</p>			
50...150%	Maximum load for the motor load curve.	1 = 1%	
35.52	<i>Zero speed load</i>	<p>Defines the motor load curve together with parameters 35.51 Motor load curve and 35.53 Break point. Defines the maximum motor load at zero speed of the load curve. A higher value can be used if the motor has an external motor fan to boost the cooling. See the motor manufacturer's recommendations.</p> <p>See parameter 35.51 Motor load curve.</p>	70%
25...150%	Zero speed load for the motor load curve.	1 = 1%	
35.53	<i>Break point</i>	<p>Defines the motor load curve together with parameters 35.51 Motor load curve and 35.52 Zero speed load. Defines the break point frequency of the load curve ie. the point at which the motor load curve begins to decrease from the value of parameter 35.51 Motor load curve towards the value of parameter 35.52 Zero speed load.</p> <p>See parameter 35.51 Motor load curve.</p>	45.00 Hz
1.00...500.00 Hz	Break point for the motor load curve.	See par. 46.02	

No.	Name/Value	Description	Def/FbEq16
35.54	<i>Motor nominal temperature rise</i>	Defines the temperature rise of the motor above ambient when the motor is loaded with nominal current. See the motor manufacturer's recommendations. The unit is selected by parameter 96.16 Unit selection .	80 °C
0...300 °C or 32...572 °F	Temperature rise.	1 = 1°	

No.	Name/Value	Description	Def/FbEq16
35.55	<i>Motor thermal time const</i>	<p>Defines the thermal time constant for use with the motor thermal protection model, defined as the time to reach 63% of the nominal motor temperature. See the motor manufacturer's recommendations.</p> <p>For thermal protection according to UL requirements for NEMA class motors, use the rule of thumb: Motor thermal time equals 35 times t6, where t6 (in seconds) is specified by the motor manufacturer as the time that the motor can safely operate at six times its rated current..</p>	256 s
<p>The figure consists of two vertically aligned graphs. The top graph plots 'Motor current' on the y-axis against 'Time' on the x-axis. It shows a rectangular pulse that reaches a level of 100% and then returns to zero. The bottom graph plots 'Temperature rise' on the y-axis against 'Time' on the x-axis. It shows a curve that starts at the origin, rises to a point where the temperature rise is 63% at a specific time interval (labeled 'Motor thermal time' with a bracket), continues to rise to 100% at the end of the current pulse, and then decays back to zero after the pulse ends. Dashed lines connect the start and end of the current pulse to the corresponding points on the temperature rise curve.</p>			
	100...10000 s	Motor thermal time constant.	1 = 1 s
35.56	<i>Motor overload action</i>	Selects how the drive reacts when the motor reaches overload condition.	<i>Warning and fault</i>
	No action	None.	0
	Warning only	The drive generates an <i>A783 Motor overload</i> warning when the motor is overloaded to the warning level, that is, parameter <i>35.05 Motor overload level</i> reaches value 88.0%.	1
	Warning and fault	The drive generates an <i>A783 Motor overload</i> warning when the motor is overloaded to the warning level, that is, parameter <i>35.05 Motor overload level</i> reaches value 88.0%. Drive trips on fault <i>7122 Motor overload</i> when the motor is overloaded to the fault level, that is, parameter <i>35.05 Motor overload level</i> reaches value 100.0%.	2
35.57	<i>Motor overload class</i>	<p>Selects the motor overload class to be used. The class of protection is specified by the user as the time for tripping at 7.2 times (IEC 60947-4-1) or 6 times (NEMA ICS) the tripping level current.</p> <p>See section <i>Motor overload protection</i> on page 88.</p>	<i>Class 20</i>
	Class 5	Class 5 relay trip class	0
	Class 10	Class 10 relay trip class	1
	Class 20	Class 20 relay trip class	2

No.	Name/Value	Description	Def/FbEq16
	Class 30	Class 30 relay trip class	3
	Class 40	Class 40 relay trip class	4
36 Load analyzer			
		Peak value and amplitude logger settings. See also section Load analyzer (page 94).	
36.01	PVL signal source	Selects the signal to be monitored by the peak value logger. The signal is filtered using the filtering time specified by parameter 36.02 PVL filter time . The peak value is stored, along with other pre-selected signals at the time, into parameters 36.10...36.15 . The peak value logger can be reset using parameter 36.09 Reset loggers . The logger is also reset whenever the signal source is changed. The date and time of the last reset are stored into parameters 36.16 and 36.17 respectively.	<i>Motor current</i>
	Not selected	None (peak value logger disabled).	0
	Motor speed used	01.01 Motor speed used (page 163).	1
	Output frequency	01.06 Output frequency (page 163).	3
	Motor current	01.07 Motor current (page 163).	4
	Motor torque	01.10 Motor torque (page 163).	6
	DC voltage	01.11 DC voltage (page 163).	7
	Output power	01.14 Output power (page 164).	8
	Speed ref ramp in	23.01 Speed ref ramp input (page 224).	10
	Speed ref ramp out	23.02 Speed ref ramp output (page 224).	11
	Torque ref used	26.02 Torque reference used (page 233).	13
	Freq ref used	28.02 Frequency ref ramp output (page 238).	14
	Process PID out	40.01 Process PID output actual (page 293).	16
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
36.02	PVL filter time	Peak value logger filtering time. See parameter 36.01 PVL signal source .	2.00 s
	0.00...120.00 s	Peak value logger filtering time.	100 = 1 s
36.09	Reset loggers	Resets the peak value logger and/or amplitude logger 2. (Amplitude logger 1 cannot be reset.)	<i>Done</i>
	Done	Reset completed or not requested (normal operation).	0
	PVL	Reset the peak value logger.	2
36.10	PVL peak value	Peak value recorded by the peak value logger.	0.00
	-32768.00... 32767.00	Peak value.	1 = 1
36.11	PVL peak date	The date on which the peak value was recorded.	1/1/1980
	1/1/1980...6/5/2159	Peak occurrence date.	-
36.12	PVL peak time	The time at which the peak value was recorded.	00:00:00
	00:00:00...23:59:59	Peak occurrence time.	-
36.13	PVL current at peak	Motor current at the moment the peak value was recorded.	0.00 A
	-32768.00... 32767.00 A	Motor current at peak.	1 = 1 A

No.	Name/Value	Description	Def/FbEq16
36.14	<i>PVL DC voltage at peak</i>	Voltage in the intermediate DC circuit of the drive at the moment the peak value was recorded.	0.00 V
	0.00...2000.00 V	DC voltage at peak.	10 = 1 V
36.15	<i>PVL speed at peak</i>	Motor speed at the moment the peak value was recorded.	0.00 rpm
	-30000.00... 30000.00 rpm	Motor speed at peak.	See par. 46.01
36.16	<i>PVL reset date</i>	The date on which the peak value logger was last reset.	1/1/1980
	1/1/1980...6/5/2159	Last reset date of the peak value logger.	-
36.17	<i>PVL reset time</i>	The time at which the peak value logger was last reset.	00:00:00
	00:00:00...23:59:59	Last reset time of the peak value logger.	-

37 User load curve		Settings for user load curve. See also section <i>User Load Curve</i> (page 49).	
37.01	<i>ULC output status word</i>	Displays the status of the monitored signal.	0b0000

Bit	Name	Description
0	Under load limit	1 = Signal lower than the underload curve.
1	Within load range	1 = Signal between the underload and overload curve.
2	Overload limit	1 = Signal higher than the overload curve.
3	Outside load limit	1 = Signal lower than the underload curve or higher than the overload curve.
3...15	Reserved	

	0b0000...0b1111	Status of the monitored signal.	1 = 1
37.02	<i>ULC supervision signal</i>	Selects the signal to be supervised.	<i>Motor torque %</i>
	Not selected	No signal selected. ULC disabled.	0
	Motor speed %	01.03 Motor speed % (page 163).	1
	Motor current %	01.08 Motor current % of motor nom (page 163).	2
	Motor torque %	01.10 Motor torque (page 163).	3
	Output power % of motor nominal	01.15 Output power % of motor nom (page 164).	4
	Output power % of drive nominal	01.16 Output power % of drive nom (page 164).	5
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
37.03	<i>ULC overload actions</i>	Selects an action taken if the signal stays over the overload curve in a sector for a defined time.	<i>Disabled</i>
	Disabled	No warnings or fault generated.	0
	Warning	The drive generates an ABBE ULC overload warning if the signal has been continuously over the overload curve for a time defined by parameter 37.41 ULC overload timer .	1
	Fault	The drive generates a 8002 ULC overload fault if the signal has been continuously over the overload curve for a time defined by parameter 37.41 ULC overload timer .	2

No.	Name/Value	Description	Def/FbEq16
	Warning/Fault	The drive generates an <i>A8BE ULC overload warning</i> if the signal has been continuously over the overload curve for a time defined by parameter <i>37.41 ULC overload timer</i> . The drive generates a <i>8002 ULC underload fault</i> if the signal has been continuously over the overload curve for a time defined by parameter <i>37.41 ULC overload timer</i> .	3
<i>37.04</i>	<i>ULC underload actions</i>	Selects an action taken if the signal stays under the underload curve for a defined time.	<i>Disabled</i>
	Disabled	No warnings or fault generated.	0
	Warning	The drive generates an <i>A8BF ULC underload warning</i> if the signal has been continuously under the underload curve for a time defined by parameter <i>37.42 ULC underload timer</i> .	1
	Fault	The drive generates a <i>8001 ULC underload fault</i> if the signal has been continuously under the underload curve for a time defined by parameter <i>37.42 ULC underload timer</i> .	2
	Warning/Fault	The drive generates an <i>A8BF ULC underload warning</i> if the signal has been continuously under the underload curve for a time defined by parameter <i>37.42 ULC underload timer</i> . The drive generates an <i>A8BF ULC underload warning</i> if the signal has been continuously under the underload curve for a time defined by parameter <i>37.42 ULC underload timer</i> .	3
<i>37.11</i>	<i>ULC speed table point 1</i>	Defines the first of the five speed points on the X-axis of the user load curve. The values of the parameters must satisfy: $-30000.0 \text{ rpm} \leq 37.11 \text{ ULC speed table point 1} < 37.12 \text{ ULC speed table point 2} < 37.13 \text{ ULC speed table point 3} < 37.14 \text{ ULC speed table point 4} < 37.15 \text{ ULC speed table point 5} \leq 30000.0 \text{ rpm}$. Speed points are used if parameter <i>99.04 Motor control mode</i> is set to <i>Vector</i> or if <i>99.04 Motor control mode</i> is set to <i>Scalar</i> and the reference unit is rpm.	150.0 rpm
	-30000.0...30000.0 rpm	Speed.	1 = 1 rpm
<i>37.12</i>	<i>ULC speed table point 2</i>	Defines the second speed point. See parameter <i>37.11 ULC speed table point 1</i> .	750.0 rpm
	-30000.0...30000.0 rpm	Speed.	1 = 1 rpm
<i>37.13</i>	<i>ULC speed table point 3</i>	Defines the third speed point. See parameter <i>37.11 ULC speed table point 1</i> .	1290.0 rpm
	-30000.0...30000.0 rpm	Speed.	1 = 1 rpm
<i>37.14</i>	<i>ULC speed table point 4</i>	Defines the fourth speed point. See parameter <i>37.11 ULC speed table point 1</i> .	1500.0 rpm
	-30000.0...30000.0 rpm	Speed.	1 = 1 rpm
<i>37.15</i>	<i>ULC speed table point 5</i>	Defines the fifth speed point. See parameter <i>37.11 ULC speed table point 1</i> .	1800.0 rpm
	-30000.0...30000.0 rpm	Speed.	1 = 1 rpm



292 Parameters

No.	Name/Value	Description	Def/FbEq16
37.21	<i>ULC underload point 1</i>	Defines the first of the five points on the Y-axis that together with the corresponding point on the X-axis (<i>37.11 ULC speed table point 1...37.15 ULC speed table point 5</i>) define the underload (lower) curve. The following conditions must be fulfilled: <ul style="list-style-type: none"> • <i>37.21 ULC underload point 1</i> ≤ <i>37.31 ULC overload point 1</i> • <i>37.22 ULC underload point 2</i> ≤ <i>37.32 ULC overload point 2</i> • <i>37.23 ULC underload point 3</i> ≤ <i>37.33 ULC overload point 3</i> • <i>37.24 ULC underload point 4</i> ≤ <i>37.34 ULC overload point 4</i> • <i>37.25 ULC underload point 5</i> ≤ <i>37.35 ULC overload point 5</i> 	10.0%
	-1600.0...1600.0%	Underload point.	1 = 1%
37.22	<i>ULC underload point 2</i>	Defines the second underload point. See parameter <i>37.21 ULC underload point 1</i> .	15.0%
	-1600.0...1600.0%	Underload point.	1 = 1%
37.23	<i>ULC underload point 3</i>	Defines the third underload point. See parameter <i>37.21 ULC underload point 1</i>	25.0%
	-1600.0...1600.0%	Underload point.	1 = 1%
37.24	<i>ULC underload point 4</i>	Defines the fourth underload point. See parameter <i>37.21 ULC underload point 1</i>	30.0%
	-1600.0...1600.0%	Underload point.	1 = 1%
37.25	<i>ULC underload point 5</i>	Defines the fifth underload point. See parameter <i>37.21 ULC underload point 1</i>	30.0%
	-1600.0...1600.0%	Underload point.	1 = 1%
37.31	<i>ULC overload point 1</i>	Defines the first of the five points on the Y-axis that together with the corresponding point on the X-axis (<i>37.11 ULC speed table point 1...37.15 ULC speed table point 5</i>) define the overload (higher) curve. At each of the five points the value of the underload curve point must be equal to or smaller than the value of the overload curve point. See parameter <i>37.21 ULC underload point 1</i> .	300.0%
	-1600.0...1600.0%	Overload point.	1 = 1%
37.32	<i>ULC overload point 2</i>	Defines the second overload point. See parameter <i>37.31 ULC overload point 1</i> .	300.0%
	-1600.0...1600.0%	Overload point.	1 = 1%
37.33	<i>ULC overload point 3</i>	Defines the third overload point. See parameter <i>37.31 ULC overload point 1</i> .	300.0%
	-1600.0...1600.0%	Overload point.	1 = 1%
37.34	<i>ULC overload point 4</i>	Defines the fourth overload point. See parameter <i>37.31 ULC overload point 1</i> .	300.0%
	-1600.0...1600.0%	Overload point.	1 = 1%
37.35	<i>ULC overload point 5</i>	Defines the fifth overload point. See parameter <i>37.31 ULC overload point 1</i> .	300.0%
	-1600.0...1600.0%	Overload point.	1 = 1%
37.41	<i>ULC overload timer</i>	Defines the time period for which time the monitored signal must remain continuously over the overload curve.	20.0 s
	0.0...10000.0 s	Time.	1 = 1 s

No.	Name/Value	Description	Def/FbEq16
37.42	<i>ULC underload timer</i>	Defines the time period for which time the monitored signal must remain continuously below the underload curve.	20.0 s
	0.0...10000.0 s	Time.	1 = 1 s
40 Process PID set 1			
		Parameter values for process PID control. The drive output can be controlled by the process PID. When the process PID control is enabled, the drive controls the process feedback to the reference value. Two different parameter sets can be defined for the process PID. One parameter set is in use at a time. The first set is made up of parameters 40.07...40.50 , the second set is defined by the parameters in group 41 Process PID set 2 . The binary source that defines which set is used is selected by parameter 40.57 PID set1/set2 selection . See also the control chain diagrams on pages 497 and 474 .	
40.01	<i>Process PID output actual</i>	Displays the output of the process PID controller. See the control chain diagram on page 474 . This parameter is read-only.	-
	-200000.00... 200000.00	Process PID controller output.	1 = 1
40.02	<i>Process PID feedback actual</i>	Displays the value of process feedback after source selection, mathematical function (parameter 40.10 Set 1 feedback function), and filtering. See the control chain diagram on page 497 . This parameter is read-only.	-
	-200000.00... 200000.00	Process feedback.	1 = 1
40.03	<i>Process PID setpoint actual</i>	Displays the value of process PID setpoint after source selection, mathematical function (40.18 Set 1 setpoint function), limitation and ramping. See the control chain diagram on page 497 . This parameter is read-only.	-
	-200000.00... 200000.00	Setpoint for process PID controller.	1 = 1
40.04	<i>Process PID deviation actual</i>	Displays the process PID deviation. By default, this value equals setpoint - feedback, but deviation can be inverted by parameter 40.31 Set 1 deviation inversion . See the control chain diagram on page 474 . This parameter is read-only.	-
	-200000.00... 200000.00	PID deviation.	1 = 1
40.05	<i>Process PID trim output act</i>	Displays the trimmed reference output. This parameter is read-only.	-
	-32768...32767	Trimmed reference.	1 = 1 unit


No.	Name/Value	Description	Def/FbEq16																																													
40.06	<i>Process PID status word</i>	Displays status information on process PID control. This parameter is read-only.	0b0000																																													
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PID active</td> <td>1 = Process PID control active.</td> </tr> <tr> <td>1</td> <td>Setpoint frozen</td> <td>1 = Process PID setpoint frozen.</td> </tr> <tr> <td>2</td> <td>Output frozen</td> <td>1 = Process PID controller output frozen.</td> </tr> <tr> <td>3</td> <td>PID sleep mode</td> <td>1 = Sleep mode active.</td> </tr> <tr> <td>4</td> <td>Sleep boost</td> <td>1 = Sleep boost active.</td> </tr> <tr> <td>5</td> <td>Trim mode</td> <td>1 = Trim mode active</td> </tr> <tr> <td>6</td> <td>Tracking mode</td> <td>1 = Tracking function active.</td> </tr> <tr> <td>7</td> <td>Output limit high</td> <td>1 = PID output is being limited by par. 40.37.</td> </tr> <tr> <td>8</td> <td>Output limit low</td> <td>1 = PID output is being limited by par. 40.36.</td> </tr> <tr> <td>9</td> <td>Deadband active</td> <td>1 = Deadband active (see parameter 40.39)</td> </tr> <tr> <td>10</td> <td>PID set</td> <td>0 = Parameter set 1 in use. 1 = Parameter set 2 in use.</td> </tr> <tr> <td>11</td> <td>Reserved</td> <td></td> </tr> <tr> <td>12</td> <td>Internal setpoint active</td> <td>1 = Internal setpoint active (see par. 40.16...40.23)</td> </tr> <tr> <td>13...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Value	0	PID active	1 = Process PID control active.	1	Setpoint frozen	1 = Process PID setpoint frozen.	2	Output frozen	1 = Process PID controller output frozen.	3	PID sleep mode	1 = Sleep mode active.	4	Sleep boost	1 = Sleep boost active.	5	Trim mode	1 = Trim mode active	6	Tracking mode	1 = Tracking function active.	7	Output limit high	1 = PID output is being limited by par. 40.37.	8	Output limit low	1 = PID output is being limited by par. 40.36.	9	Deadband active	1 = Deadband active (see parameter 40.39)	10	PID set	0 = Parameter set 1 in use. 1 = Parameter set 2 in use.	11	Reserved		12	Internal setpoint active	1 = Internal setpoint active (see par. 40.16...40.23)	13...15	Reserved	
Bit	Name	Value																																														
0	PID active	1 = Process PID control active.																																														
1	Setpoint frozen	1 = Process PID setpoint frozen.																																														
2	Output frozen	1 = Process PID controller output frozen.																																														
3	PID sleep mode	1 = Sleep mode active.																																														
4	Sleep boost	1 = Sleep boost active.																																														
5	Trim mode	1 = Trim mode active																																														
6	Tracking mode	1 = Tracking function active.																																														
7	Output limit high	1 = PID output is being limited by par. 40.37.																																														
8	Output limit low	1 = PID output is being limited by par. 40.36.																																														
9	Deadband active	1 = Deadband active (see parameter 40.39)																																														
10	PID set	0 = Parameter set 1 in use. 1 = Parameter set 2 in use.																																														
11	Reserved																																															
12	Internal setpoint active	1 = Internal setpoint active (see par. 40.16...40.23)																																														
13...15	Reserved																																															
	0b0000...0b1111	Process PID control status word.	1 = 1																																													
40.07	<i>Process PID operation mode</i>	Activates/deactivates process PID control. Note: Process PID control is only available in external control; see section <i>Local control vs. external control</i> (page 33).	Off																																													
	Off	Process PID control inactive.	0																																													
	On	Process PID control active.	1																																													
	On when drive running	Process PID control is active when the drive is running.	2																																													
40.08	<i>Set 1 feedback 1 source</i>	Selects the primary source of process feedback. See the control chain diagram on page 497.	A12 percent																																													
	Not selected	None.	0																																													
	AI1 scaled	12.12 AI1 scaled value (see page 187).	1																																													
	AI2 scaled	12.22 AI2 scaled value (see page 189).	2																																													
	Freq in scaled	11.39 Freq in 1 scaled value (see page 185).	3																																													
	AI1 percent	12.101 AI1 percent value (see page 190)	8																																													
	AI2 percent	12.102 AI2 percent value (see page 190)	9																																													
	Feedback data storage	40.91 Feedback data storage (see page 307),	10																																													
	Other	Source selection (see <i>Terms and abbreviations</i> on page 160).	-																																													
40.09	<i>Set 1 feedback 2 source</i>	Selects the second source of process feedback. The second source is used only if the setpoint function requires two inputs. For the selections, see parameter 40.08 Set 1 feedback 1 source.	Not selected																																													
40.10	<i>Set 1 feedback function</i>	Defines how process feedback is calculated from the two feedback sources selected by parameters 40.08 Set 1 feedback 1 source and 40.09 Set 1 feedback 2 source.	In1																																													
	In1	Source 1.	0																																													


No.	Name/Value	Description	Def/FbEq16
	ln1+ln2	Sum of sources 1 and 2.	1
	ln1-ln2	Source 2 subtracted from source 1.	2
	ln1*ln2	Source 1 multiplied by source 2.	3
	ln1/ln2	Source 1 divided by source 2.	4
	MIN(ln1,ln2)	Smaller of the two sources.	5
	MAX(ln1,ln2)	Greater of the two sources.	6
	AVE(ln1,ln2)	Average of the two sources.	7
	sqrt(ln1)	Square root of source 1.	8
	sqrt(ln1-ln2)	Square root of (source 1 - source 2).	9
	sqrt(ln1+ln2)	Square root of (source 1 + source 2).	10
	sqrt(ln1)+sqrt(ln2)	Square root of source 1 + square root of source 2.	11
40.11	Set 1 feedback filter time	Defines the filter time constant for process feedback.	0.000 s
	0.000...30.000 s	Feedback filter time.	1 = 1 s
40.14	Set 1 setpoint scaling	Defines, together with parameter 40.15 Set 1 output scaling, a general scaling factor for the external PID control chain. The scaling can be utilized when, for example, the process setpoint is input in Hz, and the output of the PID controller is used as an rpm value in speed control. In this case, this parameter might be set to 50, and parameter 40.15 to the nominal motor speed at 50 Hz. In effect, the output of the PID controller [40.15] when deviation (setpoint - feedback) = [40.14] and [40.32] = 1. Note: The scaling is based on the ratio between 40.14 and 40.15 . For example, the values 50 and 1500 would produce the same scaling as 1 and 3.	0.00
	-200000.00... 200000.00	Process setpoint base.	1=1
40.15	Set 1 output scaling	See parameter 40.14 Set 1 setpoint scaling	0.00
	-200000.00... 200000.00	Process PID controller output base.	1=1
40.16	Set 1 setpoint 1 source	Selects the primary source of process PID setpoint. See the control chain diagram on page 497 .	<i>AI1 percent</i>
	Not selected	None.	0
	Internal setpoint	Internal setpoint. See parameter 40.19 Set 1 internal setpoint sel1.	2
	AI1 scaled	12.12 AI1 scaled value (see page 187).	3
	AI2 scaled	12.22 AI2 scaled value (see page 189).	4
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the motor potentiometer).	8
	Freq in scaled	11.39 Freq in 1 scaled value (see page 185).	10
	AI1 percent	12.101 AI1 percent value (see page 190)	11
	AI2 percent	12.102 AI2 percent value (see page 190)	12

No.	Name/Value	Description	Def/FbEq16
	Control panel (ref saved)	<p>Panel reference (03.01 Panel reference, see page 166) saved by the control system for the location where the control returns is used as the reference.</p> <p><i>Reference</i></p>  <p>● Ext1 reference x Ext2 reference — Active reference ... Inactive reference</p>	13
	Control panel (ref copied)	<p>Panel reference (03.01 Panel reference, see page 166) for the previous control location is used as the reference when the control location changes if the references for the two locations are of the same type (eg frequency/speed/torque/PID); otherwise, the actual signal is used as the new reference.</p> <p><i>Reference</i></p>  <p>● Ext1 reference x Ext2 reference — Active reference ... Inactive reference</p>	14
FB A ref1		03.05 FB A reference 1 (see page 166).	15
FB A ref2		03.06 FB A reference 2 (see page 166).	16
EFB ref1		03.09 EFB reference 1 (see page 166).	19
EFB ref2		03.10 EFB reference 2 (see page 167).	20
Setpoint data storage		40.92 Setpoint data storage (see page 307)	24
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
40.17	Set 1 setpoint 2 source	<p>Selects the second source of process setpoint. The second source is used only if the setpoint function requires two inputs.</p> <p>For the selections, see parameter 40.16 Set 1 setpoint 1 source.</p>	<i>Not selected</i>
40.18	Set 1 setpoint function	<p>Selects a function between the setpoint sources selected by parameters 40.16 Set 1 setpoint 1 source and 40.17 Set 1 setpoint 2 source.</p>	<i>In1</i>
	In1	Source 1.	0
	In1+In2	Sum of sources 1 and 2.	1
	In1-In2	Source 2 subtracted from source 1.	2
	In1*In2	Source 1 multiplied by source 2.	3
	In1/In2	Source 1 divided by source 2.	4
	MIN(In1,In2)	Smaller of the two sources.	5
	MAX(In1,In2)	Greater of the two sources.	6
	AVE(In1,In2)	Average of the two sources.	7
	sqrt(In1)	Square root of source 1.	8
	sqrt(In1-In2)	Square root of (source 1 - source 2).	9
	sqrt(In1+In2)	Square root of (source 1 + source 2).	10

No.	Name/Value	Description	Def/FbEq16															
	sqrt(ln1)+sqrt(ln2)	Square root of source 1 + square root of source 2.	11															
40.19	<i>Set 1 internal setpoint sel1</i>	<p>Selects together with 40.20 Set 1 internal setpoint sel2 the internal setpoint out of the presets defined by parameters 40.21...40.23.</p> <p>Note: Parameters 40.16 Set 1 setpoint 1 source and 40.17 Set 1 setpoint 2 source must be set to <i>Internal setpoint</i>.</p> <table border="1"> <thead> <tr> <th>Source defined by par. 40.19</th> <th>Source defined by par. 40.20</th> <th>Setpoint preset active</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Setpoint source</td> </tr> <tr> <td>1</td> <td>0</td> <td>1 (par. 40.21)</td> </tr> <tr> <td>0</td> <td>1</td> <td>2 (par. 40.22)</td> </tr> <tr> <td>1</td> <td>1</td> <td>3 (par. 40.23)</td> </tr> </tbody> </table>	Source defined by par. 40.19	Source defined by par. 40.20	Setpoint preset active	0	0	Setpoint source	1	0	1 (par. 40.21)	0	1	2 (par. 40.22)	1	1	3 (par. 40.23)	<i>Not selected</i>
Source defined by par. 40.19	Source defined by par. 40.20	Setpoint preset active																
0	0	Setpoint source																
1	0	1 (par. 40.21)																
0	1	2 (par. 40.22)																
1	1	3 (par. 40.23)																
	Not selected	0.	0															
	Selected	1.	1															
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2															
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3															
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4															
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5															
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6															
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7															
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271).	18															
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271).	19															
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271).	20															
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264).	21															
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264).	22															
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264).	23															
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-															
40.20	<i>Set 1 internal setpoint sel2</i>	Selects together with 40.19 Set 1 internal setpoint sel1 the internal setpoint used out of the three internal setpoints defined by parameters 40.21...40.23 . See table at 40.19 Set 1 internal setpoint sel1 .	<i>Not selected</i>															
	Not selected	0.	0															
	Selected	1.	1															
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2															
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3															
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4															
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5															
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6															
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7															
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271).	18															
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271).	19															
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271).	20															
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264).	21															

No.	Name/Value	Description	Def/FbEq16
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264).	22
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264).	23
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
40.21	<i>Set 1 internal setpoint 1</i>	Internal process setpoint 1. See parameter 40.19 Set 1 internal setpoint sel1 .	0.00
	-200000.00... 200000.00	Internal process setpoint 1.	1 = 1
40.22	<i>Set 1 internal setpoint 2</i>	Internal process setpoint 2. See parameter 40.19 Set 1 internal setpoint sel1 .	0.00
	-200000.00... 200000.00	Internal process setpoint 2.	1 = 1
40.23	<i>Set 1 internal setpoint 3</i>	Internal process setpoint 3. See parameter 40.19 Set 1 internal setpoint sel1 .	0.00
	-200000.00... 200000.00	Internal process setpoint 3.	1 = 1
40.24	<i>Set 1 internal setpoint 0</i>	Internal process setpoint 0. See parameter 40.19 Set 1 internal setpoint sel1 .	0.00
	-200000.00... 200000.00	Internal process setpoint 0.	1 = 1
40.26	<i>Set 1 setpoint min</i>	Defines a minimum limit for the process PID controller setpoint.	0.00
	-200000.00... 200000.00	Minimum limit for process PID controller setpoint.	1 = 1
40.27	<i>Set 1 setpoint max</i>	Defines a maximum limit for the process PID controller setpoint.	200000.00
	-200000.00... 200000.00	Maximum limit for process PID controller setpoint.	1 = 1
40.28	<i>Set 1 setpoint increase time</i>	Defines the minimum time it takes for the setpoint to increase from 0% to 100%.	0.0 s
	0.0...1800.0 s	Setpoint increase time.	1 = 1
40.29	<i>Set 1 setpoint decrease time</i>	Defines the minimum time it takes for the setpoint to decrease from 100% to 0%.	0.0 s
	0.0...1800.0 s	Setpoint decrease time.	1 = 1
40.30	<i>Set 1 setpoint freeze enable</i>	Freezes, or defines a source that can be used to freeze, the setpoint of the process PID controller. This feature is useful when the reference is based on a process feedback connected to an analog input, and the sensor must be serviced without stopping the process. 1 = Process PID controller setpoint frozen See also parameter 40.38 Set 1 output freeze .	<i>Not selected</i>
	Not selected	Process PID controller setpoint not frozen.	0
	Selected	Process PID controller setpoint frozen.	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6

No.	Name/Value	Description	Def/FbEq16
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	18
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	19
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	20
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264).	21
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264).	22
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264).	23
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
40.31	<i>Set 1 deviation inversion</i>	Inverts the input of the process PID controller. 0 = Deviation not inverted (Deviation = Setpoint - Feedback) 1 = Deviation inverted (Deviation = Feedback - Setpoint) See also section <i>Sleep and boost functions for process PID control</i> (page 52).	<i>Not inverted (Ref - Fbk)</i>
	Not inverted (Ref - Fbk)	0.	0
	Inverted (Fbk - Ref)	1.	1
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
40.32	<i>Set 1 gain</i>	Defines the gain for the process PID controller. See parameter <i>40.33 Set 1 integration time</i> .	1.00
	0.01...100.00	Gain for PID controller.	100 = 1
40.33	<i>Set 1 integration time</i>	Defines the integration time for the process PID controller. This time needs to be set to the same order of magnitude as the reaction time of the process being controlled, otherwise instability will result.  <p>I = controller input (error) O = controller output G = gain Ti = integration time</p> <p>Note: Setting this value to 0 disables the "I" part, turning the PID controller into a PD controller.</p>	60.0 s
	0.0...9999.0 s	Integration time.	1 = 1 s

No.	Name/Value	Description	Def/FbEq16
40.34	<i>Set 1 derivation time</i>	Defines the derivation time of the process PID controller. The derivative component at the controller output is calculated on basis of two consecutive error values (E_{K-1} and E_K) according to the following formula: $PID\ DERIV\ TIME \times (E_K - E_{K-1})/T_S$, in which $T_S = 2\ ms$ sample time $E = Error = Process\ reference - process\ feedback$.	0.000 s
	0.000...10.000 s	Derivation time.	1000 = 1 s
40.35	<i>Set 1 derivation filter time</i>	Defines the time constant of the 1-pole filter used to smooth the derivative component of the process PID controller.  $O = I \times (1 - e^{-t/T})$ I = filter input (step) O = filter output t = time T = filter time constant	0.0 s
	0.0...10.0 s	Filter time constant.	10 = 1 s
40.36	<i>Set 1 output min</i>	Defines the minimum limit for the process PID controller output. Using the minimum and maximum limits, it is possible to restrict the operation range.	0.0
	-200000.00 ...200000.00	Minimum limit for process PID controller output.	1 = 1
40.37	<i>Set 1 output max</i>	Defines the maximum limit for the process PID controller output. See parameter 40.36 Set 1 output min .	100.0
	-200000.00 ...200000.00	Maximum limit for process PID controller output.	1 = 1
40.38	<i>Set 1 output freeze</i>	Freezes (or defines a source that can be used to freeze) the output of the process PID controller, keeping the output at the value it was before freeze was enabled. This feature can be used when, for example, a sensor providing process feedback must to be serviced without stopping the process. 1 = Process PID controller output frozen See also parameter 40.30 Set 1 setpoint freeze enable .	<i>Not selected</i>
	Not selected	Process PID controller output not frozen.	0
	Selected	Process PID controller output frozen.	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5

No.	Name/Value	Description	Def/FbEq16
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	18
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	19
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	20
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264).	21
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264).	22
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264).	23
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
40.39	<i>Set 1 deadband range</i>	Defines a deadband around the setpoint. Whenever process feedback enters the deadband, a delay timer starts. If the feedback remains within the deadband longer than the delay (<i>40.40 Set 1 deadband delay</i>), the PID controller output is frozen. Normal operation resumes after the feedback value leaves the deadband.	0.0
<p>The diagram shows three horizontal lines: Setpoint (top), Feedback (middle), and PID controller output (bottom). The feedback signal oscillates around the setpoint. A vertical double-headed arrow indicates the '40.39 Set 1 deadband range' between the setpoint and feedback lines. Vertical dashed lines mark the points where the feedback signal enters and leaves the deadband. Horizontal double-headed arrows indicate the '40.40 Set 1 deadband delay' periods where the feedback signal is within the deadband, during which the PID controller output is frozen (indicated by a horizontal line with a double-headed arrow labeled 'PID controller output frozen').</p>			
	0.....200000.0	Deadband range.	1 = 1
40.40	<i>Set 1 deadband delay</i>	Delay for the deadband. See parameter <i>40.39 Set 1 deadband range</i> .	0.0
	0.0 ... 3600.0 s	Delay for deadband area.	1 = 1 s
40.43	<i>Set 1 sleep level</i>	Defines the start limit for the sleep function. If the value is 0.0, set 1 sleep mode is disabled. The sleep function compares PID output (parameter <i>40.01 Process PID output actual</i>) to the value of this parameter. If PID output remains below this value longer than the sleep delay defined by <i>40.44 Set 1 sleep delay</i> , the drive enters the sleep mode and stops the motor.	0.0
	0.0...200000.0	Sleep start level.	1 = 1
40.44	<i>Set 1 sleep delay</i>	Defines a delay before the sleep function actually becomes enabled, to prevent nuisance sleeping. The delay timer starts when the sleep mode is enabled by parameter <i>40.43 Set 1 sleep level</i> , and resets when the sleep mode is disabled.	60.0
	0.0...3600.0 s	Sleep start delay.	1 = 1

No.	Name/Value	Description	Def/FbEq16
40.45	Set 1 sleep boost time	Defines a boost time for the sleep boost step. See parameter 40.46 Set 1 sleep boost step .	0.0
	0.0...3600.0 s	Sleep boost time.	1 = 1
40.46	Set 1 sleep boost step	When the drive is entering sleep mode, the process setpoint is increased by this value for the time defined by parameter 40.45 Set 1 sleep boost time . If active, sleep boost is aborted when the drive wakes up.	0.0
	0.0...200000.0	Sleep boost step.	1 = 1
40.47	Set 1 wake-up deviation	Defines the wake-up level as deviation between process setpoint and feedback. When the deviation exceeds the value of this parameter, and remains there for the duration of the wake-up delay (40.48 Set 1 wake-up delay), the drive wakes up. See also parameter 40.31 Set 1 deviation inversion .	0.00
	-200000.00... 200000.00	Wake-up level (as deviation between process setpoint and feedback).	1 = 1
40.48	Set 1 wake-up delay	Defines a wake-up delay for the sleep function to prevent nuisance wake-ups. See parameter 40.47 Set 1 wake-up deviation . The delay timer starts when the deviation exceeds the wake-up level (40.47 Set 1 wake-up deviation), and resets if the deviation falls below the wake-up level.	0.50
	0.00...60.00 s	Wake-up delay.	1 = 1
40.49	Set 1 tracking mode	Activates (or selects a source that activates) tracking mode. In tracking mode, the value selected by parameter 40.50 Set 1 tracking ref selection is substituted for the PID controller output. See also section Tracking (page 53). 1 = Tracking mode enabled	<i>Not selected</i>
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271).	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271).	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271).	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264).	21
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264).	22
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264).	23
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
40.50	Set 1 tracking ref selection	Selects the value source for tracking mode. See parameter 40.49 Set 1 tracking mode .	<i>Not selected</i>
	Not selected	None.	0
	AI1 scaled	12.12 AI1 scaled value (see page 187).	1

No.	Name/Value	Description	Def/FbEq16
	AI2 scaled	12.22 AI2 scaled value (see page 189).	2
	FB A ref1	03.05 FB A reference 1 (see page 166).	3
	FB A ref2	03.06 FB A reference 2 (see page 166).	4
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
40.51	Set 1 trim mode	Activates the trim function and selects between direct and proportional trimming (or a combination of both). With trimming, it is possible to apply a corrective factor to the drive reference (setpoint). The output after trimming is available as parameter 40.05 Process PID trim output act .	<i>Off</i>
	Off	The trim function is inactive.	0
	Direct	The trim function is active. The trimming factor is relative to the maximum speed, torque or frequency; the selection between these is made by parameter 40.52 Set 1 trim selection .	1
	Proportional	The trim function is active. The trimming factor is relative to the reference selected by parameter 40.53 Set 1 trimmed ref pointer .	2
	Combined	The trim function is active. The trimming factor is a combination of both <i>Direct</i> and <i>Proportional</i> modes; the proportions of each are defined by parameter 40.54 Set 1 trim mix .	3
40.52	Set 1 trim selection	Selects whether trimming is used for correcting the speed, torque or frequency reference.	<i>Speed</i>
	Torque	Torque reference trimming.	1
	Speed	Speed reference trimming.	2
	Frequency	Frequency reference trimming.	3
40.53	Set 1 trimmed ref pointer	Selects the signal source for the trim reference.	<i>Not selected</i>
	Not selected	None.	0
	AI1 scaled	12.12 AI1 scaled value (see page 187).	1
	AI2 scaled	12.22 AI2 scaled value (see page 189).	2
	FBA ref1	03.05 FB A reference 1 (see page 166).	3
	FBA ref2	03.06 FB A reference 2 (see page 166).	4
	<i>Other</i>	Source selection (see Terms and abbreviations).	-
40.54	Set 1 trim mix	When parameter 40.51 Set 1 trim mode is set to <i>Combined</i> , defines the effect of direct and proportional trim sources in the final trimming factor. 0.000 = 100% proportional 0.500 = 50% proportional, 50% direct 1.000 = 100% direct	0.000
	0.000...1.000	Trim mix.	1 = 1
40.55	Set 1 trim adjust	Defines a multiplier for the trimming factor. This value is multiplied by the result of parameter 40.51 Set 1 trim mode . Consequently, the result of the multiplication is used to multiply the result of parameter 40.56 Set 1 trim source .	1.000
	-100.000...100.000	Multiplier for trimming factor.	1 = 1
40.56	Set 1 trim source	Selects the reference to be trimmed.	<i>PID output</i>
	PID ref	PID setpoint.	1

No.	Name/Value	Description	Def/FbEq16
	PID output	PID controller output.	2
40.57	<i>PID set1/set2 selection</i>	Selects the source that determines whether process PID parameter set 1 (parameters 40.07...40.50) or set 2 (group 41 Process PID set 2) is used.	<i>PID set 1</i>
	PID set 1	0. Process PID parameter set 1 in use.	0
	PID set 2	1. Process PID parameter set 2 in use.	1
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	18
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	19
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	20
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264).	21
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264).	22
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264).	23
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
40.58	<i>Set 1 increase prevention</i>	Prevention of PID integration term increase for PID set 1.	<i>No</i>
	No	Increase prevention not in use.	0
	Limiting	The PID integration term is not increased if the maximum value for the PID output is reached. This parameter is valid for the PID set 1.	1
	Ext PID min lim	The process PID integration term is not increased when the output of the external PID has reached its minimum limit. In this setup, the external PID is used as a source for the process PID. This parameter is valid for the PID set 1.	2
	Ext PID max lim	The process PID integration term is not increased when the output of the external PID has reached its maximum limit. In this setup, the external PID is used as a source for the process PID. This parameter is valid for the PID set 1.	3
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
40.59	<i>Set 1 decrease prevention</i>	Prevention of PID integration term decrease for PID set 1.	<i>No</i>
	No	Decrease prevention not in use.	0
	Limiting	The PID integration term is not decreased if the minimum value for the PID output is reached. This parameter is valid for the PID set 1.	1
	Ext PID min lim	The process PID integration term is not decreased when the output of the external PID has reached its minimum limit. In this setup, the external PID is used as a source for the process PID. This parameter is valid for the PID set 1.	2

No.	Name/Value	Description	Def/FbEq16
	Ext PID max lim	The process PID integration term is not decreased when the output of the external PID has reached its maximum limit. In this setup, the external PID is used as a source for the process PID. This parameter is valid for the PID set 1.	3
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
40.60	<i>Set 1 PID activation source</i>	Selects the source of process PID set 1 activation.	<i>On</i>
	Off	Set 1 PID activation source is Off.	0
	On	Set 1 PID activation source is On.	1
	Follow Ext1/Ext2 selection	Selection follows the value of parameter 19.11 Ext1/Ext2 selection . By changing to Ext2 control location, Process PID set 1 is activated.	2
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	3
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	4
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	5
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	6
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	7
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	8
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
40.61	<i>Setpoint scaling actual</i>	Actual setpoint scaling. See parameter 40.14 Set 1 setpoint scaling .	0.00
	-200000.00... 200000.00 PID customer units	Scaling.	1 = 1 PID customer unit
40.62	<i>PID internal setpoint actual</i>	Displays the value of the internal setpoint. See the control chain diagram on page 474. This parameter is read-only.	-
	-200000.00... 200000.00 %	Process PID internal setpoint.	1 = 1
40.65	<i>Trim auto connection</i>	Enable the PID trim auto connection and connects the 40.05 Process PID trim output act to either speed, torque or frequency chains based on the trim selection parameter 40.52 Set 1 trim selection or 41.52 Set 2 trim selection .	<i>Disable</i>
	Disable	Trim auto connection disabled.	0
	Enable	Trim auto connection enabled.	1
40.79	<i>Set 1 units</i>	Selects the unit for process PID setpoint, feedback and deviation.	<i>°C</i>
	User text	User text	0
	%	%	1
	bar	bar	2
	kPa	kPa	3
	Pa	Pa	4
	psi	psi	5
	CFM	CFM	6
	inH ₂ O	inH ₂ O	7

306 Parameters

No.	Name/Value	Description	Def/FbEq16
	°C	°C	8
	°F	°F	9
	mbar	mbar	10
	m ³ /h	m ³ /h	11
	dm ³ /h	dm ³ /h	12
	l/s	l/s	13
	l/min	l/min	14
	l/h	l/h	15
	m ³ /s	m ³ /s	16
	m ³ /m	m ³ /m	17
	km ³ /h	km ³ /h	18
	gal/s	gal/s	19
	ft ³ /s	ft ³ /s	20
	ft ³ /m	ft ³ /m	21
	ft ³ /h	ft ³ /h	22
	ppm	ppm	23
	inHg	inHg	24
	kCFM	kCFM	25
	inWC	inWC	26
	GPM	GPM	27
	gal/m	gal/m	28
	in wg	in wg	29
	MPa	MPa	30
	ftWC	ftWC	31
40.80	Set 1 PID output min source	Selects the source for set 1 PID output minimum.	Set1 output min
	None	None.	0
	Set1 output min	40.36 Set 1 output min.	1
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
40.81	Set 1 PID output max source	Selects the source for set 1 PID output maximum.	Set1 output max
	None	None.	0
	Set1 output max	40.37 Set 1 output max.	1
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
40.89	Set 1 setpoint multiplier	Defines the multiplier with which the result of the function specified by parameter 40.18 Set 1 setpoint function is multiplied.	1.00
	-200000.00... 200000.00	Multiplier.	-
40.90	Set 1 feedback multiplier	Defines the multiplier used in formulas of parameter 40.10 Set 1 feedback function .	1.00
	-200000.00... 200000.00	Multiplier.	1 = 1

No.	Name/Value	Description	Def/FbEq16
40.91	<i>Feedback data storage</i>	Storage parameter for receiving a process feedback value e.g. through the embedded fieldbus interface. The value can be sent to the drive as Modbus I/O data. Set the target selection parameter of that particular data (58.101...58.114) to <i>Feedback data storage</i> . In 40.08 Set 1 feedback 1 source (or 40.09 Set 1 feedback 2 source), select <i>Feedback data storage</i> .	0.00
	-327.68...327.67	Storage parameter for process feedback.	100 = 1
40.92	<i>Setpoint data storage</i>	Storage parameter for receiving a process setpoint value e.g. through the embedded fieldbus interface. The value can be sent to the drive as Modbus I/O data. Set the target selection parameter of that particular data (58.101...58.114) to <i>Setpoint data storage</i> . In 40.16 Set 1 setpoint 1 source (or 40.17 Set 1 setpoint 2 source), select <i>Setpoint data storage</i> .	0.00
	-327.68...327.67	Storage parameter for process setpoint.	100 = 1
40.96	<i>Process PID output%</i>	Percentage scaled signal of parameter 40.01 Process PID feedback actual. Correct later.	0.00
	-100.00...100.00%	Percentage.	1=1
40.97	<i>Process PID feedback%</i>	Percentage scaled signal of parameter 40.02 Process PID feedback actual.	0.00
	-100.00...100.00%	Percentage.	1=1
40.98	<i>Process PID setpoint%</i>	Percentage scaled signal of parameter 40.03 Process PID setpoint actual.	0.00
	-100.00...100.00%	Percentage.	1=1
40.99	<i>Process PID deviation%</i>	Percentage scaled signal of parameter 40.04 Process PID deviation actual.	0.00
	-100.00...100.00%	Percentage.	1=1
41 Process PID set 2		A second set of parameter values for process PID control. The selection between this set and first set (parameter group 40 Process PID set 1) is made by parameter 40.57 PID set1/set2 selection. See also parameters 40.01...40.06, and the control chain diagrams on pages 497 and 474.	
41.08	<i>Set 2 feedback 1 source</i>	See parameter 40.08 Set 1 feedback 1 source.	<i>AI2 percent</i>
41.09	<i>Set 2 feedback 2 source</i>	See parameter 40.09 Set 1 feedback 2 source.	<i>Not selected</i>
41.10	<i>Set 2 feedback function</i>	See parameter 40.10 Set 1 feedback function.	<i>In1</i>
41.11	<i>Set 2 feedback filter time</i>	See parameter 40.11 Set 1 feedback filter time.	0.000 s
41.14	<i>Set 2 setpoint scaling</i>	See parameter 40.14 Set 2 setpoint scaling.	0.00
41.15	<i>Set 2 output scaling</i>	See parameter 40.15 Set 2 output scaling.	0.00
41.16	<i>Set 2 setpoint 1 source</i>	See parameter 40.16 Set 1 setpoint 1 source.	<i>AI1 percent</i>
41.17	<i>Set 2 setpoint 2 source</i>	See parameter 40.17 Set 1 setpoint 2 source.	<i>Not selected</i>

308 Parameters

No.	Name/Value	Description	Def/FbEq16
41.18	Set 2 setpoint function	See parameter 40.18 Set 1 setpoint function .	In1
41.19	Set 2 internal setpoint sel1	See parameter 40.19 Set 1 internal setpoint sel1 .	Not selected
41.20	Set 2 internal setpoint sel2	See parameter 40.20 Set 1 internal setpoint sel2 .	Not selected
41.21	Set 2 internal setpoint 1	See parameter 40.21 Set 1 internal setpoint 1 .	0.00
41.22	Set 2 internal setpoint 2	See parameter 40.22 Set 1 internal setpoint 2 .	0.00
41.23	Set 2 internal setpoint 3	See parameter 40.23 Set 1 internal setpoint 3 .	0.00
41.24	Set 2 internal setpoint 0	See parameter 40.24 Set 1 internal setpoint 0 .	0.00
41.26	Set 2 setpoint min	See parameter 40.26 Set 1 setpoint min .	0.00
41.27	Set 2 setpoint max	See parameter 40.27 Set 1 setpoint max .	200000.00
41.28	Set 2 setpoint increase time	See parameter 40.28 Set 1 setpoint increase time .	0.0 s
41.29	Set 2 setpoint decrease time	See parameter 40.29 Set 1 setpoint decrease time .	0.0 s
41.30	Set 2 setpoint freeze enable	See parameter 40.30 Set 1 setpoint freeze enable .	Not selected
41.31	Set 2 deviation inversion	See parameter 40.31 Set 1 deviation inversion .	Not inverted (Ref - Fbk)
41.32	Set 2 gain	See parameter 40.32 Set 1 gain .	1.00
41.33	Set 2 integration time	See parameter 40.33 Set 1 integration time .	60.0 s
41.34	Set 2 derivation time	See parameter 40.34 Set 1 derivation time .	0.000 s
41.35	Set 2 derivation filter time	See parameter 40.35 Set 1 derivation filter time .	0.0 s
41.36	Set 2 output min	See parameter 40.36 Set 1 output min .	0.0
41.37	Set 2 output max	See parameter 40.37 Set 1 output max .	100.0
41.38	Set 2 output freeze	See parameter 40.38 Set 1 output freeze .	Not selected
41.39	Set 2 deadband range	See parameter 40.39 Set 1 deadband range .	0.0
41.40	Set 2 deadband delay	See parameter 40.40 Set 1 deadband delay .	0.0
41.43	Set 2 sleep level	See parameter 40.43 Set 1 sleep level .	0.0
41.44	Set 2 sleep delay	See parameter 40.44 Set 1 sleep delay .	60.0 s
41.45	Set 2 sleep boost time	See parameter 40.45 Set 1 sleep boost time .	0.0 s
41.46	Set 2 sleep boost step	See parameter 40.46 Set 1 sleep boost step .	0.0
41.47	Set 2 wake-up deviation	See parameter 40.47 Set 1 wake-up deviation .	0.00

No.	Name/Value	Description	Def/FbEq16
41.48	<i>Set 2 wake-up delay</i>	See parameter 40.48 Set 1 wake-up delay .	0.50 s
41.49	<i>Set 2 tracking mode</i>	See parameter 40.49 Set 1 tracking mode .	<i>Not selected</i>
41.50	<i>Set 2 tracking ref selection</i>	See parameter 40.50 Set 1 tracking ref selection .	<i>Not selected</i>
41.51	<i>Set 2 trim mode</i>	See parameter 40.51 Set 1 trim mode .	<i>Off</i>
41.52	<i>Set 2 trim selection</i>	See parameter 40.52 Set 1 trim selection .	<i>Speed</i>
41.53	<i>Set 2 trimmed ref pointer</i>	See parameter 40.53 Set 1 trimmed ref pointer .	<i>Not selected</i>
41.54	<i>Set 2 trim mix</i>	See parameter 40.54 Set 1 trim mix .	0.000
41.55	<i>Set 2 trim adjust</i>	See parameter 40.55 Set 1 trim adjust .	1.000
41.56	<i>Set 2 trim source</i>	See parameter 40.56 Set 1 trim source .	<i>PID output</i>
41.58	<i>Set 2 increase prevention</i>	See parameter 40.58 Set 1 increase prevention .	<i>No</i>
41.59	<i>Set 2 decrease prevention</i>	See parameter 40.59 Set 1 decrease prevention .	<i>No</i>
41.60	<i>Set 2 PID activation source</i>	See parameter 40.60 Set 1 PID activation source .	<i>On</i>
41.79	<i>Set 2 units</i>	See parameter 40.79 Set 1 units .	°C
41.80	<i>Set 1 PID output min source</i>	Selects the source for set 2 PID output minimum.	<i>Set2 output min</i>
	None	None.	0
	Set2 output min	41.36 Set 2 output min .	1
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
41.81	<i>Set 1 PID output max source</i>	Selects the source for set 2 PID output maximum.	<i>Set2 output max</i>
	None	None.	0
	Set2 output max	41.37 Set 2 output max .	1
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
41.89	<i>Set 2 setpoint multiplier</i>	See parameter 40.89 Set 1 feedback multiplier	1.00
41.90	<i>Set 2 feedback multiplier</i>	Defines the multiplier used in formulas of parameter 41.10 Set 2 feedback function .	1.00
	-100000.00... 100000.00	Multiplier.	1 = 1

No.	Name/Value	Description	Def/FbEq16
43 Brake chopper		Settings for the internal brake chopper. This parameter group is applicable only for frames R0...R3	
43.01	<i>Braking resistor temperature</i>	Displays the estimated temperature of the brake resistor, or how close the brake resistor is to being too hot. The value is given in percent where 100% is the eventual temperature the resistor would reach when loaded long enough with its rated maximum load capacity (<i>43.09 Brake resistor Pmax cont</i>). The temperature calculation is based on the values of parameters <i>43.08</i> , <i>43.09</i> and <i>43.10</i> , and on the assumption that the resistor is installed as instructed by the manufacturer (ie it cools down as expected). This parameter is read-only.	0.0
	0.0...120.0%	Estimated brake resistor temperature.	1 = 1%
43.06	<i>Brake chopper enable</i>	Enables brake chopper control and selects the brake resistor overload protection method (calculation or measurement). Note: Before enabling brake chopper control, ensure that <ul style="list-style-type: none"> a brake resistor is connected overvoltage control is switched off (parameter <i>30.30 Overvoltage control</i>) the supply voltage range (parameter <i>95.01 Supply voltage</i>) has been selected correctly. 	<i>Disabled</i>
	Disabled	Brake chopper control disabled.	0
	Enabled with thermal model	Brake chopper control enabled with brake resistor protection based on the thermal model. If you select this, you must also specify the values needed by the model, ie. parameters <i>43.08... 43.12</i> . See the resistor data sheet.	1
	Enabled without thermal model	Brake chopper control enabled without resistor overload protection based on the thermal model. This setting can be used, for example, if the resistor is equipped with a thermal switch that is wired to open the main contactor of the drive if the resistor overheats. For more information, see chapter <i>Resistor braking</i> in the <i>Hardware manual</i> .	2
	Overvoltage peak protection	Brake chopper control enabled in an overvoltage condition. This setting is intended for situations where <ul style="list-style-type: none"> the braking chopper is not needed for runtime operation, ie. to dissipate the inertial energy of the motor, the motor is able to store a considerable amount magnetic energy in its windings, and the motor might, deliberately or inadvertently, be stopped by coasting. In such a situation, the motor would potentially discharge enough magnetic energy towards the drive to cause damage. To protect the drive, the brake chopper can be used with a small resistor dimensioned merely to handle the magnetic energy (not the inertial energy) of the motor. With this setting, the brake chopper is activated only whenever the DC voltage exceeds the overvoltage limit. During normal use, the brake chopper is not operating.	3

No.	Name/Value	Description	Def/FbEq16
43.07	<i>Brake chopper runtime enable</i>	Selects the source for quick brake chopper on/off control. 0 = Brake chopper IGBT pulses are cut off 1 = Normal brake chopper IGBT modulation allowed. This parameter can be used to enable chopper operation only when the supply is missing from a drive with a regenerative supply unit.	On
	Off	0.	0
	On	1.	1
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
43.08	<i>Brake resistor thermal tc</i>	Defines the thermal time constant for the brake resistor thermal model.	0 s
	0...10000 s	Brake resistor thermal time constant, ie the rated time to achieve 63% temperature.	1 = 1 s
43.09	<i>Brake resistor Pmax cont</i>	Defines the maximum continuous load of the brake resistor that will eventually raise the resistor temperature to the maximum allowed value (= continuous heat dissipation capacity of the resistor in kW) but not above it. The value is used in the resistor overload protection based on the thermal model. See parameter <i>43.06 Brake chopper enable</i> and the data sheet of the brake resistor used.	0.00 kW
	0.00... 10000.00 kW	Maximum continuous load of the brake resistor.	1 = 1 kW
43.10	<i>Brake resistance</i>	Defines the resistance value of the brake resistor. The value is used for the brake resistor protection based on the thermal model. See parameter <i>43.06 Brake chopper enable</i> .	0.0 ohm
	0.0...1000.0 ohm	Brake resistor resistance value.	1 = 1 ohm
43.11	<i>Brake resistor fault limit</i>	Selects the fault limit for the brake resistor protection based on the thermal model. See parameter <i>43.06 Brake chopper enable</i> . When the limit is exceeded, the drive trips on fault <i>7183 BR excess temperature</i> . The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter <i>43.09 Brake resistor Pmax cont</i> .	105%
	0...150%	Brake resistor temperature fault limit.	1 = 1%
43.12	<i>Brake resistor warning limit</i>	Selects the warning limit for the brake resistor protection based on the thermal model. See parameter <i>43.06 Brake chopper enable</i> . When the limit is exceeded, the drive generates a <i>A793 BR excess temperature</i> warning. The value is given in percent of the temperature the resistor reaches when loaded with the power defined by parameter <i>43.09 Brake resistor Pmax cont</i> .	95%
	0...150%	Brake resistor temperature warning limit.	1 = 1%

312 Parameters

No.	Name/Value	Description	Def/FbEq16
44 Mechanical brake control		Configuration of mechanical brake control. See also section Mechanical brake control (page 60).	
44.01	Brake control status	Displays the mechanical brake control status word. This parameter is read-only.	0b0000
Bit	Name	Information	
0	Open command	Close/open command to brake actuator (0 = close, 1 = open). Connect this bit to desired output.	
1	Opening torque request	1 = Opening torque requested from drive logic.	
2	Hold stopped request	1 = Hold requested from drive logic	
3	Ramp to stopped	1 = Ramping down to zero speed requested from drive logic	
4	Enabled	1 = Brake control is enabled	
5	Closed	1 = Brake control logic in BRAKE CLOSED state	
6	Opening	1 = Brake control logic in BRAKE OPENING state	
7	Open	1 = Brake control logic in BRAKE OPEN state	
8	Closing	1 = Brake control logic in BRAKE CLOSING state	
9...15	Reserved		
	0b0000...0b1111	Mechanical brake control status word.	1 = 1
44.06	Brake control enable	Activates/deactivates (or selects a source that activates/deactivates) the mechanical brake control logic. 0 = Brake control inactive 1 = Brake control active	Not selected
	Not selected	0.	0
	Selected	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7
	Timed function 1	Bit 0 of 34.01 Timed functions status (see page 271).	18
	Timed function 2	Bit 1 of 34.01 Timed functions status (see page 271).	19
	Timed function 3	Bit 2 of 34.01 Timed functions status (see page 271).	20
	Supervision 1	Bit 0 of 32.01 Supervision status (see page 264).	24
	Supervision 2	Bit 1 of 32.01 Supervision status (see page 264).	25
	Supervision 3	Bit 2 of 32.01 Supervision status (see page 264).	26
	Other [bit]	Source selection (see Terms and abbreviations on page 160).	-

No.	Name/Value	Description	Def/FbEq16
44.08	<i>Brake open delay</i>	Defines the brake open delay, ie. the delay between the internal open brake command and the release of motor speed control. The delay timer starts when the drive has magnetized the motor. Simultaneously with the timer start, the brake control logic energizes the brake control output and the brake starts to open. Set this parameter to the value of mechanical opening delay specified by the brake manufacturer.	0.00 s
	0.00...5.00 s	Brake open delay.	100 = 1 s
44.13	<i>Brake close delay</i>	Specifies a delay between a close command (that is, when the brake control output is de-energized) and when the drive stops modulating. This is to keep the motor live and under control until the brake actually closes. Set this parameter equal to the value specified by the brake manufacturer as the mechanical wake-up time of the brake.	0.00 s
	0.00...60.00 s	Brake close delay.	100 = 1 s
44.14	<i>Brake close level</i>	Defines the brake close speed as an absolute value. After motor speed has decelerated to this level, a close command is given.	100.00 rpm
	0.00...1000.00 rpm	Brake close speed.	See par. 46.01

45 Energy efficiency		Settings for the energy saving calculators. See also section <i>Energy saving calculators</i> (page 93).	
45.01	<i>Saved GW hours</i>	Energy saved in GWh compared to direct-on-line motor connection. This parameter is incremented when 45.02 <i>Saved MW hours</i> rolls over. This parameter is read-only (see parameter 45.21 <i>Energy calculations reset</i>).	0
	0...65535 GWh	Energy savings in GWh.	1 = 1 GWh
45.02	<i>Saved MW hours</i>	Energy saved in MWh compared to direct-on-line motor connection. This parameter is incremented when 45.03 <i>Saved kW hours</i> rolls over. When this parameter rolls over, parameter 45.01 <i>Saved GW hours</i> is incremented. This parameter is read-only (see parameter 45.21 <i>Energy calculations reset</i>).	0
	0...999 MWh	Energy savings in MWh.	1 = 1 MWh
45.03	<i>Saved kW hours</i>	Energy saved in kWh compared to direct-on-line motor connection. If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat, but the calculation still records savings made by controlling the speed. If the chopper is disabled, then regenerated energy from the motor is also recorded here. When this parameter rolls over, parameter 45.02 <i>Saved MW hours</i> is incremented. This parameter is read-only (see parameter 45.21 <i>Energy calculations reset</i>).	0.0
	0.0...999.9 kWh	Energy savings in kWh.	10 = 1 kWh

314 Parameters

No.	Name/Value	Description	Def/FbEq16
45.04	<i>Saved energy</i>	Energy saved in kWh compared to direct-on-line motor connection. If the internal brake chopper of the drive is enabled, all energy fed by the motor to the drive is assumed to be converted into heat. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.0
	0.0...214748364.0 kWh	Energy savings in kWh.	1 = 1 kWh
45.05	<i>Saved money x1000</i>	Monetary savings in thousands compared to direct-on-line motor connection. This parameter is incremented when 45.06 Saved money rolls over. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0 INR
	0...4294967295 thousands	Monetary savings in thousands of units.	1 = 1 unit
45.06	<i>Saved money</i>	Monetary savings compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection). When this parameter rolls over, parameter 45.05 Saved money x1000 is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.00 INR
	0.00...999.99 units	Monetary savings.	1 = 1 unit
45.07	<i>Saved amount</i>	Monetary savings compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in kWh by the currently active energy tariff (45.14 Tariff selection). This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.00 INR
	0.00...21474830.08 units	Monetary savings.	1 = 1 unit
45.08	<i>CO2 reduction in kilotons</i>	Reduction in CO ₂ emissions in metric kilotons compared to direct-on-line motor connection. This value is incremented when parameter 45.09 CO2 reduction in tons rolls over. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0
	0...65535 metric kilotons	Reduction in CO ₂ emissions in metric kilotons.	1 = 1 metric kiloton
45.09	<i>CO2 reduction in tons</i>	Reduction in CO ₂ emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter 45.18 CO2 conversion factor (by default, 0.5 metric tons/MWh). When this parameter rolls over, parameter 45.08 CO2 reduction in kilotons is incremented. This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.0
	0.0...999.9 metric tons	Reduction in CO ₂ emissions in metric tons.	1 = 1 metric ton



No.	Name/Value	Description	Def/FbEq16
45.10	<i>Total saved CO2</i>	Reduction in CO ₂ emissions in metric tons compared to direct-on-line motor connection. This value is calculated by multiplying the saved energy in MWh by the value of parameter 45.18 CO2 conversion factor (by default, 0.5 metric tons/MWh). This parameter is read-only (see parameter 45.21 Energy calculations reset).	0.0
	0.0...214748300.8 metric tons	Reduction in CO ₂ emissions in metric tons.	1 = 1 metric ton
45.11	<i>Energy optimizer</i>	Enables/disables the energy optimization function. The function optimizes the motor flux so that total energy consumption and motor noise level are reduced when the drive operates below the nominal load. The total efficiency (motor and drive) can be improved by 1...20% depending on load torque and speed. Note: With a permanent magnet motor or a synchronous reluctance motor, energy optimization is always enabled regardless of this parameter.	<i>Disable</i>
	Disable	Energy optimization disabled.	0
	Enable	Energy optimization enabled.	1
45.12	<i>Energy tariff 1</i>	Defines energy tariff 1 (price of energy per kWh). Depending on the setting of parameter 45.14 Tariff selection , either this value or 45.13 Energy tariff 2 is used for reference when monetary savings are calculated. Note: Tariffs are read only at the instant of selection, and are not applied retroactively.	5.000 INR
	0.000... 4294966.296 units	Energy tariff 1.	-
45.13	<i>Energy tariff 2</i>	Defines energy tariff 2 (price of energy per kWh). See parameter 45.12 Energy tariff 1 .	6.000 INR
	0.000... 4294966.296 units	Energy tariff 2.	-
45.14	<i>Tariff selection</i>	Selects (or defines a source that selects) which pre-defined energy tariff is used. 0 = 45.12 Energy tariff 1 1 = 45.13 Energy tariff 2	<i>Energy tariff 1</i>
	Energy tariff 1	0.	0
	Energy tariff 2	1.	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-
45.17	<i>Tariff currency unit</i>	Selects the currency unit based on which the values of parameters 45.05 , 45.06 , 45.07 , 45.12 , 45.13 are displayed.	<i>INR</i>
	INR	Displays the values of parameters 45.05 , 45.06 , 45.07 , 45.12 , 45.13 in Indian rupee.	100

316 Parameters

No.	Name/Value	Description	Def/FbEq16
	EUR	Displays the values of parameters 45.05 , 45.06 , 45.07 , 45.12 , 45.13 in euro.	101
	USD	Displays the values of parameters 45.05 , 45.06 , 45.07 , 45.12 , 45.13 in US dollars.	102
45.18	CO2 conversion factor	Defines a factor for conversion of saved energy into CO ₂ emissions (kg/kWh or tn/MWh).	0.500 tn/MWh (metric ton)
	0.000...65.535 tn/MWh	Factor for conversion of saved energy into CO ₂ emissions.	1 = 1 tn/MWh
45.19	Comparison power	Actual power that the motor absorbs when connected direct-on-line and operating the application. The value is used for reference when energy savings are calculated. Note: The accuracy of the energy savings calculation is directly dependent on the accuracy of this value. If nothing is entered here, then the nominal motor power is used by the calculation, but that may inflate the energy savings reported as many motors do not absorb nameplate power.	0.00 kW
	0.00...10000000.00 kW	Motor power.	1 = 1 kW
45.21	Energy calculations reset	Resets the savings counter parameters 45.01 ... 45.10 .	<i>Done</i>
	Done	Reset not requested (normal operation), or reset complete.	0
	Reset	Reset the savings counter parameters. The value reverts automatically to <i>Done</i> .	1
45.24	Hourly peak power value	Value of the peak power during the last hour, that is, the most recent 60 minutes after the drive has been powered up. The parameter is updated once every 10 minutes unless the hourly peak is found in the most recent 10 minutes. In that case, the values is shown immediately.	0.00 kW
	-3000.00 ... 3000.00 kW	Peak power value.	10 = 1 kW
45.25	Hourly peak power time	Time of the peak power value during the last hour.	00:00:00
		Time.	N/A
45.26	Hourly total energy (resettable)	Total energy consumption during the last hour, that is, the most recent 60 minutes. You can reset the value by setting it to zero.	0.00 kWh
	-3000.00 ... 3000.00 kWh	Total energy.	10 = 1 kWh
45.27	Daily peak power value (resettable)	Value of the peak power since midnight of the present day. You can reset the value by setting it to zero.	0.00 kW
	-3000.00 ... 3000.00 kW	Peak power value.	10 = 1 kW
45.28	Daily peak power time	Time of the peak power since midnight of the present day.	00:00:00
		Time.	N/A
45.29	Daily total energy (resettable)	Total energy consumption since midnight of the present day. You can reset the value by setting it to zero.	0.00 kWh
	-30000.00 ... 30000.00 kWh	Total energy.	1 = 1 kWh

No.	Name/Value	Description	Def/FbEq16
45.30	<i>Last day total energy</i>	Total energy consumption during the previous day, that is, between midnight of the previous day and midnight of the present day	0.00 kWh
	-30000.00 ... 30000.00 kWh	Total energy.	1 = 1 kWh
45.31	<i>Monthly peak power value (resettable)</i>	Value of the peak power during the present month, that is, since midnight of the first day of the present month. You can reset the value by setting it to zero.	0.00 kW
	-3000.00 ... 3000.00 kW	Peak power value.	10 = 1 kW
45.32	<i>Monthly peak power date</i>	Date of the peak power during the present month.	1/1/1980
	1/1/1980...6/5/2159	Date.	N/A
45.33	<i>Monthly peak power time</i>	Time of the peak power during the present month.	00:00:00
		Time.	N/A
45.34	<i>Monthly total energy (resettable)</i>	Total energy consumption from the beginning of the present month. You can reset the value by setting it to zero.	0.00 kWh
	-1000000.00 ... 1000000.00 kWh	Total energy.	0.01 = 1 kWh
45.35	<i>Last month total energy</i>	Total energy consumption during the previous month, that is, between midnight of the first day or the previous month and midnight of the first day of the present month.	0.00 kWh
	-1000000.00 ... 1000000.00 kWh		0.01 = 1 kWh
45.36	<i>Lifetime peak power value</i>	Value of the peak power over the drive lifetime.	0.00 kW
	-3000.00 ... 3000.00 kW	Peak power value.	10 = 1 kW
45.37	<i>Lifetime peak power date</i>	Date of the peak power over the drive lifetime.	1/1/1980
		Date.	N/A
45.38	<i>Lifetime peak power time</i>	Time of the peak power over the drive lifetime.	00:00:00
		Time.	N/A
46 Monitoring/scaling settings		Speed supervision settings; actual signal filtering; general scaling settings.	
46.01	<i>Speed scaling</i>	Defines the maximum speed value used to define the acceleration ramp rate and the initial speed value used to define the deceleration ramp rate (see parameter group 23 Speed reference ramp). The speed acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.12 Maximum speed). Also defines the 16-bit scaling of speed-related parameters. The value of this parameter corresponds to 20000 in e.g. fieldbus communication.	1500.00 rpm
	0.10...30000.00 rpm	Acceleration/deceleration terminal/initial speed.	1 = 1 rpm


No.	Name/Value	Description	Def/FbEq16
46.02	<i>Frequency scaling</i>	Defines the maximum frequency value used to define the acceleration ramp rate and the initial frequency value used to define deceleration ramp rate (see parameter group 28 Frequency reference chain). The frequency acceleration and deceleration ramp times are therefore related to this value (not to parameter 30.14 Maximum frequency). Also defines the 16-bit scaling of frequency-related parameters. The value of this parameter corresponds to 20000 in e.g. fieldbus communication.	50.00 Hz
	0.10...1000.00 Hz	Acceleration/deceleration terminal/initial frequency.	10 = 1 Hz
46.03	<i>Torque scaling</i>	Defines the 16-bit scaling of torque parameters. The value of this parameter (in percent of nominal motor torque) corresponds to 10000 in e.g. fieldbus communication.	100.0%
	0.1...1000.0%	Torque corresponding to 10000 on fieldbus.	10 = 1%
46.04	<i>Power scaling</i>	Defines the output power value that corresponds to 10000 in e.g. fieldbus communication. The unit is selected by parameter 96.16 Unit selection .	1000.00 kW
	0.10 ...30000.00 kW or hp	Power corresponding to 10000 on fieldbus.	1 = 1 unit
46.05	<i>Current scaling</i>	Defines the 16-bit scaling of current parameters. The value of this parameter corresponds to 10000 in fieldbus communication.	10000 A
	0...30000 A		
46.06	<i>Speed ref zero scaling</i>	Defines a speed corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBA A). For example, with a setting of 500, the fieldbus reference range of 0...20000 would correspond to a speed of 500... [46.01] rpm. Note: This parameter is effective only with the ABB Drives communication profile.	0.00 rpm
	0.00 ... 30000.00 rpm	Speed corresponding to minimum fieldbus reference.	1 = 1 rpm
46.07	<i>Frequency ref zero scaling</i>	Defines a frequency corresponding to a zero reference received from fieldbus (either the embedded fieldbus interface, or interface FBA A or FBA B). For example, with a setting of 30, the fieldbus reference range of 0...20000 would correspond to a speed of 30... [46.02] Hz. Note: This parameter is effective only with the ABB Drives communication profile.	0.00 Hz
	0.00 ... 1000.00 Hz	Speed corresponding to minimum fieldbus reference.	10 = 1 Hz
46.11	<i>Filter time motor speed</i>	Defines a filter time for signals 01.01 Motor speed used and 01.02 Motor speed estimated .	500 ms
	2...20000 ms	Motor speed signal filter time.	1 = 1 ms
46.12	<i>Filter time output frequency</i>	Defines a filter time for signal 01.06 Output frequency .	500 ms
	2...20000 ms	Output frequency signal filter time.	1 = 1 ms
46.13	<i>Filter time motor torque</i>	Defines a filter time for signal 01.10 Motor torque .	100 ms
	2...20000 ms	Motor torque signal filter time.	1 = 1 ms
46.14	<i>Filter time power</i>	Defines a filter time for signal 01.14 Output power .	100 ms
	2...20000 ms	Output power signal filter time.	1 = 1 ms


No.	Name/Value	Description	Def/FbEq16
46.21	<i>At speed hysteresis</i>	Defines the “at setpoint” limits for speed control of the drive. When the difference between speed reference (<i>22.87 Speed reference act 7</i>) and the speed feedback (<i>24.02 Used speed feedback</i>) is smaller than <i>46.21 At speed hysteresis</i> , the drive is considered to be “at setpoint”. This is indicated by bit 8 of <i>06.11 Main status word</i> . 	50.00 rpm
	0.00...30000.00 rpm	Limit for “at setpoint” indication in speed control.	See par. <i>46.01</i>
46.22	<i>At frequency hysteresis</i>	Defines the “at setpoint” limits for frequency control of the drive. When the absolute difference between reference (<i>28.96 Frequency ref ramp input</i>) and actual frequency (<i>01.06 Output frequency</i>) is smaller than <i>46.22 At frequency hysteresis</i> , the drive is considered to be “at setpoint”. This is indicated by bit 8 of <i>06.11 Main status word</i> . 	2.00 Hz
	0.00...1000.00 Hz	Limit for “at setpoint” indication in frequency control.	See par. <i>46.02</i>
46.31	<i>Above speed limit</i>	Defines the trigger level for “above limit” indication in speed control. When actual speed exceeds the limit, bit 10 of <i>06.17 Drive status word 2</i> is set.	1500.00 rpm
	0.00...30000.00 rpm	“Above limit” indication trigger level for speed control.	See par. <i>46.01</i>
46.32	<i>Above frequency limit</i>	Defines the trigger level for “above limit” indication in frequency control. When actual frequency exceeds the limit, bit 10 of <i>06.17 Drive status word 2</i> is set.	50.00 Hz
	0.00...1000.00 Hz	“Above limit” indication trigger level for frequency control.	See par. <i>46.02</i>

320 Parameters




No.	Name/Value	Description	Def/FbEq16
46.33	<i>Above torque limit</i>	Defines the trigger level for "above limit" indication in torque control. When actual torque exceeds the limit, bit 10 of 06.17 Drive status word 2 is set.	300.0%
	0.0...1600.0%	"Above limit" indication trigger level for torque control.	See par. 46.03
46.41	<i>kWh pulse scaling</i>	Defines the trigger level for the "kWh pulse" on for 50 ms. The output of the pulse is bit 9 of 05.22 Diagnostic word 3 .	1.000 kWh
	0.001... 1000.000 kWh	"kWh pulse" on trigger level.	1 = 1 kWh
46.43	<i>Power decimals</i>	Defines the number of decimal places of power-related parameters.	2
	0...3	Number of decimal places of power parameters.	1 = 1
46.44	<i>Current decimals</i>	Defines the number of decimal places of current-related parameters.	1
	0...3	Number of decimal places of current parameters.	1 = 1
47 Data storage		Data storage parameters that can be written to and read from using other parameters' source and target settings. Note that there are different storage parameters for different data types. See also section Data storage parameters (page 96).	
47.01	<i>Data storage 1 real32</i>	Data storage parameter 1.	0.000
	-2147483.000... 2147483.000	32-bit data.	-
47.02	<i>Data storage 2 real32</i>	Data storage parameter 2.	0.000
	-2147483.000... 2147483.000	32-bit data.	-
47.03	<i>Data storage 3 real32</i>	Data storage parameter 3.	0.000
	-2147483.000... 2147483.000	32-bit data.	-
47.04	<i>Data storage 4 real32</i>	Data storage parameter 4.	0.000
	-2147483.000... 2147483.000	32-bit data.	-
47.11	<i>Data storage 1 int32</i>	Data storage parameter 9.	0
	-2147483648... 2147483647	32-bit data.	-
47.12	<i>Data storage 2 int32</i>	Data storage parameter 10.	0
	-2147483648... 2147483647	32-bit data.	-
47.13	<i>Data storage 3 int32</i>	Data storage parameter 11.	0
	-2147483648... 2147483647	32-bit data.	-

No.	Name/Value	Description	Def/FbEq16
47.14	Data storage 4 int32	Data storage parameter 12.	0
	-2147483648... 2147483647	32-bit data.	-
47.21	Data storage 1 int16	Data storage parameter 17.	0
	-32768...32767	16-bit data.	1 = 1
47.22	Data storage 2 int16	Data storage parameter 18.	0
	-32768...32767	16-bit data.	1 = 1
47.23	Data storage 3 int16	Data storage parameter 19.	0
	-32768...32767	16-bit data.	1 = 1
47.24	Data storage 4 int16	Data storage parameter 20.	0
	-32768...32767	16-bit data.	1 = 1

49 Panel port communication		Communication settings for the control panel port on the drive.	
49.01	Node ID number	Defines the node ID of the drive. All devices connected to the network must have a unique node ID. Note: For networked drives, it is advisable to reserve ID 1 for spare/replacement drives.	1
	1...32	Node ID.	1 = 1
49.03	Baud rate	Defines the transfer rate of the link.	115.2 kbps
	38.4 kbps	38.4 kbit/s.	1
	57.6 kbps	57.6 kbit/s.	2
	86.4 kbps	86.4 kbit/s.	3
	115.2 kbps	115.2 kbit/s.	4
	230.4 kbps	230.4 kbit/s.	5
49.04	Communication loss time	Sets a timeout for control panel (or PC tool) communication. If a communication break lasts longer than the timeout, the action specified by parameter 49.05 Communication loss action is taken.	10.0 s
	0.3...3000.0 s	Panel/PC tool communication timeout.	10 = 1 s
49.05	Communication loss action	Selects how the drive reacts to a control panel (or PC tool) communication break.	Fault
	No action	No action taken.	0
	Fault	Drive trips on 7081 Control panel loss .	1
	Last speed	Drive generates an A7EE Panel loss warning and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2

No.	Name/Value	Description	Def/FbEq16
	Speed ref safe	Drive generates an <i>A7EE Panel loss</i> warning and sets the speed to the speed defined by parameter <i>22.41 Speed ref safe</i> (or <i>28.41 Frequency ref safe</i> when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
49.06	<i>Refresh settings</i>	Applies the settings of parameters <i>49.01...49.05</i> . Note: Refreshing may cause a communication break, so reconnecting the drive may be required.	<i>Done</i>
	Done	Refresh done or not requested.	0
	Configure	Refresh parameters <i>49.01...49.05</i> . The value reverts automatically to <i>Done</i> .	1
49.19	<i>Basic panel home view 1</i>	Selects the parameters that is shown in <i>Home view 1</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT1. Home view 1 is toggled automatically between Home view 4 (parameter <i>49.01</i>) according to the active external control location EXT1 or EXT2, respectively	<i>Auto</i>
	Auto	<i>01.06 Output frequency</i> (page 163) in scalar control mode, otherwise <i>01.01 Motor speed used</i> used (page 163).	0
	Motor speed used	<i>01.01 Motor speed used</i>	1
	Output frequency	<i>01.06 Output frequency</i>	3
	Motor current	<i>01.07 Motor current</i>	4
	Motor current% of motor nominal	<i>01.08 Motor current % of motor nom</i>	5
	Motor torque	<i>01.10 Motor torque</i>	6
	DC voltage	<i>01.11 DC voltage</i>	7
	Output power	<i>01.14 Output power</i>	8
	Speed ref ramp in	<i>23.01 Speed ref ramp input</i>	10
	Speed ref ramp out	<i>23.02 Speed ref ramp output</i>	11
	Freq ref used	<i>28.02 Frequency ref ramp output</i>	14
	Process PID out	<i>40.01 Process PID output actual</i>	16
	Temp sensor 1 excitation	The output is used to feed an excitation current to the temperature sensor 1, see parameter <i>35.11 Temperature 1 source</i> . See also section <i>Motor thermal protection</i> (page 83).	20
	Temp sensor 2 excitation	The output is used to feed an excitation current to the temperature sensor 2, see parameter <i>35.21 Temperature 2 source</i> . See also section <i>Motor thermal protection</i> (page 83).	21
	Abs motor speed used	<i>01.61 Abs motor speed used</i>	26
	Abs motor speed%	<i>01.62 Abs motor speed %</i>	27
	Abs output frequency	<i>01.63 Abs output frequency</i>	28
	Abs motor torque	<i>01.64 Abs motor torque</i>	30
	Abs output power	<i>01.65 Abs output power</i>	31
	Abs motor shaft power	<i>01.68 Abs motor shaft power</i>	32
	AO1 data storage	<i>13.91 AO1 data storage</i> .	37

No.	Name/Value	Description	Def/FbEq16
	AO2 data storage	13.92 AO2 data storage.	38
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
49.20	Basic panel home view 2	Selects the parameters that is shown in <i>Home view 2</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT1. Home view 2 is toggled automatically between Home view 5 (parameter 49.21) according to the active external control location EXT1 or EXT2, respectively See parameter 49.19 for the other selections than Auto.	<i>Auto</i>
	Auto	01.07 Motor current (page 163) .	0
49.21	Basic panel home view 3	Selects the parameters that is shown in <i>Home view 3</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT1. Home view 3 is toggled automatically between Home view 6 (parameter 49.221) according to the active external control location EXT1 or EXT2, respectively See parameter 49.19 for the other selections than Auto.	<i>Auto</i>
	Auto	01.10 Motor torque (page 163)	0
49.21	Basic panel home view 3	Selects the parameters that is shown in <i>Home view 4</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT2. Home view 1 is toggled automatically between Home view 4 (parameter 49.19) according to the active external control location EXT1 or EXT2, respectively. See parameter 49.19 for the other selections than Auto.	<i>Auto</i>
	Auto	Selects the same parameter as selected by parameter 49.19 Basic panel home view 1 for external control location EXT 1.	0
49.21	Basic panel home view 3	Selects the parameters that is shown in <i>Home view 5</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT2. Home view 2 is toggled automatically between Home view 5 (parameter 49.20) according to the active external control location EXT1 or EXT2, respectively. See parameter 49.19 for the other selections than Auto.	<i>Auto</i>
	Auto	Selects the same parameter as selected by parameter 49.20 Basic panel home view 2 for external control location EXT 1.	0
49.221	Basic panel home view 6	Selects the parameters that is shown in <i>Home view 6</i> of the Basic panel (ACS-BP-S) when the active external control location is EXT2. Home view 3 is toggled automatically between Home view 6 (parameter 49.21) according to the active external control location EXT1 or EXT2, respectively. See parameter 49.19 for the other selections than Auto.	<i>Auto</i>
	Auto	Selects the same parameter as selected by parameter 49.21 Basic panel home view 3 for external control location EXT 1.	0

No.	Name/Value	Description	Def/FbEq16
50	Fieldbus adapter (FBA)	Fieldbus communication configuration. See also chapter <i>Fieldbus control through a fieldbus adapter</i> (page 445).	
50.01	FBA A enable	Enables/disables communication between the drive and fieldbus adapter A, and specifies the slot the adapter is installed into.	Disable
	Disable	Communication between drive and fieldbus adapter A disabled.	0
	Enable	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 1.	1
50.02	FBA A comm loss func	Selects how the drive reacts upon a fieldbus communication break. The time delay is defined by parameter 50.03 FBA A comm loss t out.	No action
	No action	No action taken.	0
	Fault	Communication break detection active. Upon a communication break, the drive trips on a 7510 FBA A communication fault and coasts to a stop.	1
	Last speed	Communication break detection active. Upon a communication break, the drive generates a warning (A7C1 FBA A communication) and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Communication break detection active. Upon a communication break, the drive generates a warning (A7C1 FBA A communication) and sets the speed to the value defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used).  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive trips on 7510 FBA A communication. This occurs even though no control is expected from the fieldbus.	4
	Warning	Drive generates an A7C1 FBA A communication warning. This occurs even though no control is expected from the fieldbus.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
50.03	FBA A comm loss t out	Defines the time delay before the action defined by parameter 50.02 FBA A comm loss func is taken. Time count starts when the communication link fails to update the message.	0.3 s
	0.3...6553.5 s	Time delay.	1 = 1 s

No.	Name/Value	Description	Def/FbEq16								
50.04	<i>FBA A ref1 type</i>	Selects the type and scaling of reference 1 received from fieldbus adapter A. The scaling of the reference is defined by parameters 46.01...46.04, depending on which reference type is selected by this parameter.	<i>Speed or frequency</i>								
	Speed or frequency	Type and scaling is chosen automatically according to the currently active operation mode as follows: <table border="1" data-bbox="404 320 897 451"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Reference 1 type</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td><i>Speed</i></td> </tr> <tr> <td>Torque control</td> <td><i>Speed</i></td> </tr> <tr> <td>Frequency control</td> <td><i>Frequency</i></td> </tr> </tbody> </table>	Operation mode (see par. 19.01)	Reference 1 type	Speed control	<i>Speed</i>	Torque control	<i>Speed</i>	Frequency control	<i>Frequency</i>	0
Operation mode (see par. 19.01)	Reference 1 type										
Speed control	<i>Speed</i>										
Torque control	<i>Speed</i>										
Frequency control	<i>Frequency</i>										
	Transparent	No scaling is applied.	1								
	General	Generic reference without a specific unit.	2								
	Torque	The scaling is defined by parameter 46.03 <i>Torque scaling</i> .	3								
	Speed	The scaling is defined by parameter 46.01 <i>Speed scaling</i> .	4								
	Frequency	The scaling is defined by parameter 46.02 <i>Frequency scaling</i> .	5								
50.05	<i>FBA A ref2 type</i>	Selects the type and scaling of reference 2 received from fieldbus adapter A. The scaling of the reference is defined by parameters 46.01...46.04, depending on which reference type is selected by this parameter.	<i>Speed or frequency</i>								
	Speed or frequency	Type and scaling is chosen automatically according to the currently active operation mode as follows: <table border="1" data-bbox="404 780 897 911"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Reference 2 type</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td><i>Torque</i></td> </tr> <tr> <td>Torque control</td> <td><i>Torque</i></td> </tr> <tr> <td>Frequency control</td> <td><i>Torque</i></td> </tr> </tbody> </table>	Operation mode (see par. 19.01)	Reference 2 type	Speed control	<i>Torque</i>	Torque control	<i>Torque</i>	Frequency control	<i>Torque</i>	0
Operation mode (see par. 19.01)	Reference 2 type										
Speed control	<i>Torque</i>										
Torque control	<i>Torque</i>										
Frequency control	<i>Torque</i>										
	Transparent	No scaling is applied.	1								
	General	Generic reference without a specific unit.	2								
	Torque	The scaling is defined by parameter 46.03 <i>Torque scaling</i> .	3								
	Speed	The scaling is defined by parameter 46.01 <i>Speed scaling</i> .	4								
	Frequency	The scaling is defined by parameter 46.02 <i>Frequency scaling</i> .	5								
50.06	<i>FBA A SW sel</i>	Selects the source of the Status word to be sent to the fieldbus network through fieldbus adapter A.	<i>Auto</i>								
	Auto	Source of the Status word is chosen automatically.	0								
	Transparent mode	The source selected by parameter 50.09 <i>FBA A SW transparent source</i> is transmitted as the Status word to the fieldbus network through fieldbus adapter A.	1								

No.	Name/Value	Description	Def/FbEq16								
50.07	<i>FBA A actual 1 type</i>	Selects the type and scaling of actual value 1 transmitted to the fieldbus network through fieldbus adapter A. The scaling of the value is defined by parameters <i>46.01...46.04</i> , depending on which actual value type is selected by this parameter.	<i>Speed or frequency</i>								
	Speed or frequency	Type and scaling is chosen automatically according to the currently active operation mode as follows: <table border="1" data-bbox="350 352 844 483"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Actual value 1 type</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td><i>Speed</i></td> </tr> <tr> <td>Torque control</td> <td></td> </tr> <tr> <td>Frequency control</td> <td><i>Frequency</i></td> </tr> </tbody> </table>	Operation mode (see par. 19.01)	Actual value 1 type	Speed control	<i>Speed</i>	Torque control		Frequency control	<i>Frequency</i>	0
Operation mode (see par. 19.01)	Actual value 1 type										
Speed control	<i>Speed</i>										
Torque control											
Frequency control	<i>Frequency</i>										
	Transparent	No scaling is applied.	1								
	General	Generic reference without a specific unit.	2								
	Torque	The scaling is defined by parameter <i>46.03 Torque scaling</i> .	3								
	Speed	The scaling is defined by parameter <i>46.01 Speed scaling</i> .	4								
	Frequency	The scaling is defined by parameter <i>46.02 Frequency scaling</i> .	5								
50.08	<i>FBA A actual 2 type</i>	Selects the type and scaling of actual value 2 transmitted to the fieldbus network through fieldbus adapter A. The scaling of the value is defined by parameters <i>46.01...46.04</i> , depending on which actual value type is selected by this parameter.	<i>Speed or frequency</i>								
	Speed or frequency	Type and scaling is chosen automatically according to the currently active operation mode as follows: <table border="1" data-bbox="350 842 844 973"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Actual value 2 type</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td><i>Speed</i></td> </tr> <tr> <td>Torque control</td> <td></td> </tr> <tr> <td>Frequency control</td> <td><i>Frequency</i></td> </tr> </tbody> </table>	Operation mode (see par. 19.01)	Actual value 2 type	Speed control	<i>Speed</i>	Torque control		Frequency control	<i>Frequency</i>	0
Operation mode (see par. 19.01)	Actual value 2 type										
Speed control	<i>Speed</i>										
Torque control											
Frequency control	<i>Frequency</i>										
	Transparent	No scaling is applied.	1								
	General	Generic reference without a specific unit.	2								
	Torque	<i>01.01 Motor speed used</i> is sent as actual value 2. The scaling is defined by parameter <i>46.03 Torque scaling</i> .	3								
	Speed	The scaling is defined by parameter <i>46.01 Speed scaling</i> .	4								
	Frequency	The scaling is defined by parameter <i>46.02 Frequency scaling</i> .	5								
50.09	<i>FBA A SW transparent source</i>	Selects the source of the fieldbus status word when parameter <i>50.06 FBA A SW sel</i> is set to <i>Transparent mode</i> .	<i>Not selected</i>								
	Not selected	No source selected.	-								
	<i>Other</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-								
50.10	<i>FBA A act1 transparent source</i>	When parameter <i>50.07 FBA A actual 1 type</i> is set to <i>Transparent</i> , this parameter selects the source of actual value 1 transmitted to the fieldbus network through fieldbus adapter A.	<i>Not selected</i>								
	Not selected	No source selected.	-								
	<i>Other</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-								

No.	Name/Value	Description	Def/FbEq16
50.11	<i>FBA A act2 transparent source</i>	When parameter 50.08 FBA A actual 2 type is set to <i>Transparent</i> , this parameter selects the source of actual value 2 transmitted to the fieldbus network through fieldbus adapter A.	<i>Not selected</i>
	Not selected	No source selected.	-
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
50.12	<i>FBA A debug mode</i>	This parameter enables debug mode. Displays raw (unmodified) data received from and sent to fieldbus adapter A in parameters 50.13...50.18 .	<i>Disable</i>
	Disable	Debug mode disabled.	0
	Fast	Debug mode enabled. Cyclical data update is as fast as possible which increases CPU load on the drive.	1
50.13	<i>FBA A control word</i>	Displays the raw (unmodified) control word sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode . This parameter is read-only.	0.0.0.0
	0.0.0.0...FF.FF.FF.FF	Control word sent by master to fieldbus adapter A.	-
50.14	<i>FBA A reference 1</i>	Displays raw (unmodified) reference REF1 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode . This parameter is read-only.	0
	-2147483648... 2147483647	Raw REF1 sent by master to fieldbus adapter A.	0
50.15	<i>FBA A reference 2</i>	Displays raw (unmodified) reference REF2 sent by the master (PLC) to fieldbus adapter A if debugging is enabled by parameter 50.12 FBA A debug mode . This parameter is read-only.	0
	-2147483648... 2147483647	Raw REF2 sent by master to fieldbus adapter A.	-
50.16	<i>FBA A status word</i>	Displays the raw (unmodified) status word sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode . This parameter is read-only.	0.0.0.0
	0.0.0.0...FF.FF.FF.FF	Status word sent by fieldbus adapter A to master.	-
50.17	<i>FBA A actual value 1</i>	Displays raw (unmodified) actual value ACT1 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode . This parameter is read-only.	0
	-2147483648... 2147483647	Raw ACT1 sent by fieldbus adapter A to master.	-
50.18	<i>FBA A actual value 2</i>	Displays raw (unmodified) actual value ACT2 sent by fieldbus adapter A to the master (PLC) if debugging is enabled by parameter 50.12 FBA A debug mode . This parameter is read-only.	0
	-2147483648... 2147483647	Raw ACT2 sent by fieldbus adapter A to master.	-




No.	Name/Value	Description	Def/FbEq16
51 FBA A settings			
51.01	<i>FBA A type</i>	Displays the type of the connected fieldbus adapter module. 0 = Module is not found or is not properly connected, or is disabled by parameter <i>50.01 FBA A enable</i> ; 0 = None; 1 = PROFIBUS-DP; 32 = CANopen; 128 = Ethernet; 132 = PROFInet IO; 135 = EtherCAT; 485 = RS-485 comm. This parameter is read-only.	0
51.02	<i>FBA A Par2</i>	Parameters <i>51.02...51.26</i> are adapter module-specific. For more information, see the documentation of the fieldbus adapter module. Note that not all of these parameters are necessarily in use.	0
	0...65535	Fieldbus adapter configuration parameter.	1 = 1
...
51.26	<i>FBA A Par26</i>	See parameter <i>51.02 FBA A Par2</i> .	0
	0...65535	Fieldbus adapter configuration parameter.	1 = 1
51.27	<i>FBA A par refresh</i>	Validates any changed fieldbus adapter module configuration settings. After refreshing, the value reverts automatically to <i>Done</i> . Note: This parameter cannot be changed while the drive is running.	<i>Done</i>
	Done	Refreshing done.	0
	Configure	Refreshing.	1
51.28	<i>FBA A par table ver</i>	Displays the parameter table revision of the fieldbus adapter module mapping file (stored in the memory of the drive). In format axyz, where ax = major table revision number; yz = minor table revision number. This parameter is read-only.	0x0000
	0x0000...0xffff	Parameter table revision of adapter module.	-
51.29	<i>FBA A drive type code</i>	Displays the drive type code in the fieldbus adapter module mapping file (stored in the memory of the drive). This parameter is read-only.	-
	0...65535	Drive type code stored in the mapping file.	1 = 1
51.30	<i>FBA A mapping file ver</i>	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive in decimal format. This parameter is read-only.	-
	0...65535	Mapping file revision.	1 = 1
51.31	<i>D2FBA A comm status</i>	Displays the status of the fieldbus adapter module communication.	<i>Not configured</i>
	Not configured	Adapter is not configured.	0
	Initializing	Adapter is initializing.	1
	Time out	A timeout has occurred in the communication between the adapter and the drive.	2
	Configuration error	Adapter configuration error: mapping file not found in the file system of the drive, or mapping file upload has failed more than three times.	3
	Off-line	Fieldbus communication is off-line.	4

No.	Name/Value	Description	Def/FbEq16
	On-line	Fieldbus communication is on-line, or fieldbus adapter has been configured not to detect a communication break. For more information, see the documentation of the fieldbus adapter.	5
	Reset	Adapter is performing a hardware reset.	6
51.32	<i>FBA A comm SW ver</i>	Displays the common program revision of the adapter module in format xyz, where a = major revision number, xy = minor revision number, z = correction number or letter. Example: 190A = revision 1.90A.	0x0000
	0x0000...0xffff	Common program revision of adapter module.	-
51.33	<i>FBA A appl SW ver</i>	Displays the application program revision of the adapter module in format xyz, where a = major revision number, xy = minor revision number, z = correction number or letter. Example: 190A = revision 1.90A.	0x0000
	0x0000...0xffff	Application program version of adapter module.	-
52 FBA A data in			
		Selection of data to be transferred from drive to fieldbus controller through fieldbus adapter A. Note: 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
52.01	<i>FBA A data in1</i>	Parameters 52.01...52.12 select data to be transferred from the drive to the fieldbus controller through fieldbus adapter A.	<i>None</i>
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	Status Word (16 bits)	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	SW2 16bit	Status Word 2 (16 bits)	24

No.	Name/Value	Description	Def/FbEq16
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
...
52.12	FBA A data in12	See parameter 52.01 FBA A data in1 .	<i>None</i>
53 FBA A data out			
		Selection of data to be transferred from fieldbus controller to drive through fieldbus adapter A. Note: 32-bit values require two consecutive parameters. Whenever a 32-bit value is selected in a data parameter, the next parameter is automatically reserved.	
53.01	FBA A data out1	Parameters 53.01 ... 53.12 select data to be transferred from the fieldbus controller to the drive through fieldbus adapter A.	<i>None</i>
	None	None.	0
	CW 16bit	Control Word (16 bits)	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	CW2 16bit	Control Word 2 (16 bits)	21
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
...
53.12	FBA A data out12	See parameter 53.01 FBA A data out1 .	<i>None</i>
58 Embedded fieldbus			
		Configuration of the embedded fieldbus (EFB) interface. See also chapter Fieldbus control through the embedded fieldbus interface (EFB) (page 435).	
58.01	Protocol enable	Enables/disables the embedded fieldbus interface and selects the protocol to use.	<i>None</i>
	None	None (communication disabled).	0
	Modbus RTU	Embedded fieldbus interface is enabled and uses the Modbus RTU protocol.	1
58.02	Protocol ID	Displays the protocol ID and revision. This parameter is read-only.	-
		Protocol ID and revision.	1 = 1
58.03	Node address	Defines the node address of the drive on the fieldbus link. Values 1...247 are allowable. Two devices with the same address are not allowed on-line. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) .	1
	0...255	Node address (values 1...247 are allowed).	1 = 1
58.04	Baud rate	Selects the transfer rate of the fieldbus link. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) .	<i>19.2 kbps</i>
	Autodetect	Baud rate detected automatically	0
	4.8 kbps	4.8 kbit/s.	1
	9.6 kbps	9.6 kbit/s.	2

No.	Name/Value	Description	Def/FbEq16
	19.2 kbps	19.2 kbit/s.	3
	38.4 kbps	38.4 kbit/s.	4
	57.6 kbps	57.6 kbit/s.	5
	76.8 kbps	76.8 kbit/s.	6
	115.2 kbps	115.2 kbit/s.	7
58.05	Parity	Selects the type of parity bit and number of stop bits. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) .	8 EVEN 1
	8 NONE 1	Eight data bits, no parity bit, one stop bit.	0
	8 NONE 2	Eight data bits, no parity bit, two stop bits.	1
	8 EVEN 1	Eight data bits, even parity bit, one stop bit.	2
	8 ODD 1	Eight data bits, odd parity bit, one stop bit.	3
58.06	Communication control	Takes changed EFB settings in use, or activates silent mode.	Enabled
	Enabled	Normal operation.	0
	Refresh settings	Refreshes settings (parameters 58.01...58.05, 58.14...58.17, 58.25, 58.28...58.34) and takes changed EFB configuration settings in use. Reverts automatically to Enabled .	1
	Silent mode	Activates silent mode (no messages are transmitted). Silent mode can be terminated by activating the Refresh settings selection of this parameter.	2

No.	Name/Value	Description	Def/FbEq16
58.07	<i>Communication diagnostics</i>	Displays the status of the EFB communication. This parameter is read-only. Note that the name is only visible when the error is present (bit value is 1).	-
	Bit	Name	Description
	0	Init failed	1 = EFB initialization failed
	1	Addr config err	1 = Node address not allowed by protocol
	2	Silent mode	1 = Drive not allowed to transmit
			0 = Drive allowed to transmit
	3	Reserved	
	4	Wiring error	1 = Errors detected (A/B wires possibly swapped)
	5	Parity error	1 = Error detected: check parameters 58.04 and 58.05
	6	Baud rate error	1 = Error detected: check parameters 58.05 and 58.04
	7	No bus activity	1 = 0 bytes received during last 5 seconds
	8	No packets	1 = 0 packets (addressed to any device) detected during last 5 seconds
	9	Noise or addressing error	1 = Errors detected (interference, or another device with the same address on line)
	10	Comm loss	1 = 0 packets addressed to the drive received within timeout (58.16)
	11	CW/Ref loss	1 = No control word or references received within timeout (58.16)
	12	Not active	1 = Not active. EFB is not the active channel. Only used in redundant communication control.
	13	Protocol 1	1 = Used for protocol-dependent statuses. See protocol documentation.
	14	Protocol 2	See Bit 13 .
	15	Internal error	1 = internal error. Problem with the communication to the drive software.
	0000h...FFFFh	EFB communication status.	1 = 1
58.08	<i>Received packets</i>	Displays a count of valid packets addressed to the drive. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset down for over 3 seconds.	-
	0...4294967295	Number of received packets addressed to the drive.	1 = 1
58.09	<i>Transmitted packets</i>	Displays a count of valid packets transmitted by the drive. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset down for over 3 seconds.	-
	0...4294967295	Number of transmitted packets.	1 = 1
58.10	<i>All packets</i>	Displays a count of valid packets addressed to any device on the bus. During normal operation, this number increases constantly. Can be reset from the control panel by keeping Reset down for over 3 seconds.	-
	0...4294967295	Number of all received packets.	1 = 1
58.11	<i>UART errors</i>	Displays a count of character errors received by the drive. An increasing count indicates a configuration problem on the bus. Can be reset from the control panel by keeping Reset down for over 3 seconds.	-
	0...4294967295	Number of UART errors.	1 = 1

No.	Name/Value	Description	Def/FbEq16
58.12	<i>CRC errors</i>	Displays a count of packets with a CRC error received by the drive. An increasing count indicates interference on the bus. Can be reset from the control panel by keeping Reset down for over 3 seconds.	-
	0...4294967295	Number of CRC errors.	1 = 1
58.14	<i>Communication loss action</i>	Selects how the drive reacts to an EFB communication break. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) . See also parameters 58.15 Communication loss mode and 58.16 Communication loss time .	<i>Fault</i>
	No action	No action taken (monitoring disabled).	0
	Fault	The drive monitors communication loss when start/stop is expected from the EFB on the currently active control location. Drive trips on 6681 EFB comm loss if control in the currently active control location is expected from the EFB or reference is coming from the EFB, and the communication is lost.	1
	Last speed	Drive generates an A7CE EFB comm loss warning and freezes the speed to the level the drive was operating at. The speed is determined on the basis of actual speed using 850 ms low-pass filtering. This occurs if control or reference is expected from the EFB.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	2
	Speed ref safe	Drive generates an A7CE EFB comm loss warning and sets the speed to the speed defined by parameter 22.41 Speed ref safe (or 28.41 Frequency ref safe when frequency reference is being used). This occurs if control or reference is expected from the EFB.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	3
	Fault always	Drive continuously monitors for communication loss. Drive trips on 6681 EFB comm loss . This happens even though the drive is in a control location where the EFB start/stop or reference is not used.	4
	Warning	Drive generates an A7CE EFB comm loss warning. This occurs even though no control is expected from the EFB.  WARNING! Make sure that it is safe to continue operation in case of a communication break.	5
58.15	<i>Communication loss mode</i>	Defines which message types reset the timeout counter for detecting an EFB communication loss. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) . See also parameters 58.14 Communication loss action and 58.16 Communication loss time .	<i>Cw / Ref1 / Ref2</i>
	Any message	Any message addressed to the drive resets the timeout.	1
	Cw / Ref1 / Ref2	A write of the control word or a reference resets the timeout.	2

No.	Name/Value	Description	Def/FbEq16								
58.16	<i>Communication loss time</i>	Sets a timeout for EFB communication. If a communication break lasts longer than the timeout, the action specified by parameter 58.14 Communication loss action is taken. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) . See also parameter 58.15 Communication loss mode .	3.0 s								
	0.0...6000.0 s	EFB communication timeout.	1 = 1								
58.17	<i>Transmit delay</i>	Defines a minimum response delay in addition to any fixed delay imposed by the protocol. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) .	3.0 ms								
	0...65535 ms	Minimum response delay.	1 = 1								
58.18	<i>EFB control word</i>	Displays the raw (unmodified) status word sent by the drive to the Modbus controller. For debugging purposes. This parameter is read-only.	-								
	0000h...FFFFh	Control word sent by Modbus controller to the drive.	1 = 1								
58.19	<i>EFB status word</i>	Displays the raw (unmodified) status word for debugging purposes. This parameter is read-only.	-								
	0000h...FFFFh	Status word sent by the drive to the Modbus controller.	1 = 1								
58.25	<i>Control profile</i>	Defines the communication profile used by the protocol. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) .	<i>ABB Drives</i>								
	ABB Drives	ABB Drives control profile (with a 16-bit control word)	0								
	DCU Profile	DCU control profile (with a 16 or 32-bit control word)	5								
58.26	<i>EFB ref1 type</i>	Selects the type and scaling of reference 1 received through the embedded fieldbus interface. The scaled reference is displayed by 03.09 EFB reference 1 .	<i>Speed or frequency</i>								
	Speed or frequency	Type and scaling is chosen automatically according to the currently active operation mode as follows. <table border="1" data-bbox="349 1034 844 1166"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Reference 1 type</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td><i>Speed</i></td> </tr> <tr> <td>Torque control</td> <td><i>Speed</i></td> </tr> <tr> <td>Frequency control</td> <td><i>Frequency</i></td> </tr> </tbody> </table>	Operation mode (see par. 19.01)	Reference 1 type	Speed control	<i>Speed</i>	Torque control	<i>Speed</i>	Frequency control	<i>Frequency</i>	0
Operation mode (see par. 19.01)	Reference 1 type										
Speed control	<i>Speed</i>										
Torque control	<i>Speed</i>										
Frequency control	<i>Frequency</i>										
	Transparent	No scaling is applied.	1								
	General	Generic reference without a specific unit. Scaling: 1 = 100.	2								
	Torque	Torque reference. The scaling is defined by parameter 46.03 Torque scaling .	3								
	Speed	Speed reference. The scaling is defined by parameter 46.01 Speed scaling .	4								
	Frequency	Frequency reference. The scaling is defined by parameter 46.02 Frequency scaling .	5								

No.	Name/Value	Description	Def/FbEq16								
58.27	<i>EFB ref2 type</i>	Selects the type and scaling of reference 2 received through the embedded fieldbus interface. For the parameter selection, see 58.26 EFB ref1 type . The scaled reference is displayed by 03.10 EFB reference 2 .	<i>Torque</i>								
58.28	<i>EFB act1 type</i>	Selects the type of actual value 1.	<i>Speed or frequency</i>								
	Speed or frequency	Type and scaling is chosen automatically according to the currently active operation mode as follows. <table border="1" data-bbox="400 379 897 512"> <thead> <tr> <th>Operation mode (see par. 19.01)</th> <th>Actual 1 type</th> </tr> </thead> <tbody> <tr> <td>Speed control</td> <td><i>Speed</i></td> </tr> <tr> <td>Torque control</td> <td><i>Speed</i></td> </tr> <tr> <td>Frequency control</td> <td><i>Frequency</i></td> </tr> </tbody> </table>	Operation mode (see par. 19.01)	Actual 1 type	Speed control	<i>Speed</i>	Torque control	<i>Speed</i>	Frequency control	<i>Frequency</i>	0
Operation mode (see par. 19.01)	Actual 1 type										
Speed control	<i>Speed</i>										
Torque control	<i>Speed</i>										
Frequency control	<i>Frequency</i>										
	Transparent	No scaling is applied.	1								
	General	Generic reference without a specific unit. Scaling: 1 = 100.	2								
	Torque	Scaling is defined by parameter 46.03 Torque scaling .	3								
	Reserved		3								
	Speed	Scaling is defined by parameter 46.01 Speed scaling .	4								
	Frequency	Scaling is defined by parameter 46.02 Frequency scaling .	5								
58.29	<i>EFB act2 type</i>	Selects the type of actual value 2. For the selections, see parameter 58.28 EFB act1 type .	<i>Transparent</i>								
58.31	<i>EFB act1 transparent source</i>	Selects the source of actual value 1 when parameter 58.28 EFB act1 type is set to <i>Transparent</i> .	<i>Not selected</i>								
	Not selected	None.	0								
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-								
58.32	<i>EFB act2 transparent source</i>	Selects the source of actual value 2 when parameter 58.29 EFB act2 type is set to <i>Transparent</i> .	<i>Other</i> (par. 01.07 Motor current)								
	Not selected	None.	0								
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-								
58.33	<i>Addressing mode</i>	Defines the mapping between parameters and holding registers in the 400101...465535 Modbus register range. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) .	<i>Mode 0</i>								
	Mode 0	<u>16-bit values (groups 1...99, indexes 1...99):</u> Register address = 400000 + 100 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 2200 + 80 = 402280. <u>32-bit values (groups 1...99, indexes 1...99):</u> Register address = 420000 + 200 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 420000 + 4400 + 160 = 424560.	0								
	Mode 1	<u>16-bit values (groups 1...255, indexes 1...255):</u> Register address = 400000 + 256 × parameter group + parameter index. For example, parameter 22.80 would be mapped to register 400000 + 5632 + 80 = 405712.	1								

No.	Name/Value	Description	Def/FbEq16
	Mode 2	<u>32-bit values (groups 1...127, indexes 1...255):</u> Register address = 400000 + 512 × parameter group + 2 × parameter index. For example, parameter 22.80 would be mapped to register 400000 + 11264 + 160 = 411424.	2
58.34	<i>Word order</i>	Selects in which order 16-bit registers of 32-bit parameters are transferred. For each register, the first byte contains the high order byte and the second byte contains the low order byte. Changes to this parameter take effect after the control unit is rebooted or the new settings validated by parameter 58.06 Communication control (Refresh settings) .	<i>LO-HI</i>
	HI-LO	The first register contains the high order word, the second contains the low order word.	0
	LO-HI	The first register contains the low order word, the second contains the high order word.	1
58.101	<i>Data I/O 1</i>	Defines the address in the drive which the Modbus master accesses when it reads from or writes to the register address corresponding to Modbus register 1 (400001). The master defines the type of the data (input or output). The value is transmitted in a Modbus frame consisting of two 16-bit words. If the value is 16-bit, it is transmitted in the LSW (least significant word). If the value is 32-bit, the subsequent parameter is also reserved for it and must be set to <i>None</i> .	<i>CW 16bit</i>
	None	No mapping, register is always zero.	0
	CW 16bit	<i>ABB Drives</i> profile: 16-bit ABB drives control word; <i>DCU Profile</i> : lower 16 bits of the DCU control word	1
	Ref1 16bit	Reference REF1 (16 bits)	2
	Ref2 16bit	Reference REF2 (16 bits)	3
	SW 16bit	<i>ABB Drives</i> profile: 16-bit ABB drives status word; <i>DCU Profile</i> : lower 16 bits of the DCU status word	4
	Act1 16bit	Actual value ACT1 (16 bits)	5
	Act2 16bit	Actual value ACT2 (16 bits)	6
	Reserved		7...10
	CW 32bit	Control Word (32 bits)	11
	Ref1 32bit	Reference REF1 (32 bits)	12
	Ref2 32bit	Reference REF2 (32 bits)	13
	SW 32bit	Status Word (32 bits)	14
	Act1 32bit	Actual value ACT1 (32 bits)	15
	Act2 32bit	Actual value ACT2 (32 bits)	16
	Reserved		17...20
	CW2 16bit	<i>ABB Drives</i> profile: not used; <i>DCU Profile</i> : upper 16 bits of the DCU control word	21
	SW2 16bit	<i>ABB Drives</i> profile: not used / always zero; <i>DCU Profile</i> : upper 16 bits of the DCU status word	24
	Reserved		25...30
	RO/DIO control word	Parameter 10.99 RO/DIO control word .	31
	AO1 data storage	Parameter 13.91 AO1 data storage .	32

No.	Name/Value	Description	Def/FbEq16
	AO2 data storage	Parameter 13.92 AO2 data storage .	33
	Reserved		34...39
	Feedback data storage	Parameter 40.91 Feedback data storage .	40
	Setpoint data storage	Parameter 40.92 Setpoint data storage .	41
	<i>Other</i>	Source selection (see Terms and abbreviations on page 160).	-
58.102	Data I/O 2	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400002. For the selections, see parameter 58.101 Data I/O 1 .	Ref1 16bit
58.103	Data I/O 3	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400003. For the selections, see parameter 58.101 Data I/O 1 .	Ref2 16bit
58.104	Data I/O 4	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400004. For the selections, see parameter 58.101 Data I/O 1 .	SW 16bit
58.105	Data I/O 5	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400005. For the selections, see parameter 58.101 Data I/O 1 .	Act1 16bit
58.106	Data I/O 6	Defines the address in the drive which the Modbus master accesses when it reads from or writes to register address 400006. For the selections, see parameter 58.101 Data I/O 1 .	Act2 16bit
58.107	Data I/O 7	Parameter selector for Modbus register address 400007. For the selections, see parameter 58.101 Data I/O 1 .	None
...
58.114	Data I/O 14	Parameter selector for Modbus register address 400014. For the selections, see parameter 58.101 Data I/O 1 .	None

No.	Name/Value	Description	Def/FbEq16																											
70	Override	Enabling/disabling of override function, override activation signal and override speed/frequency.																												
70.01	Override status	Shows the override status. This parameter is read-only.	0b0000																											
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Description</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Override enabled</td> <td>0 = Override is disabled; 1 = Override is enabled.</td> </tr> <tr> <td>1</td> <td>Override active</td> <td>0 = Override is inactive; 1 = Drive is active.</td> </tr> <tr> <td>2</td> <td>Override direction is forward</td> <td>0 = Override direction is not forward; 1 = Override direction is forward.</td> </tr> <tr> <td>3</td> <td>Override direction is reverse</td> <td>0 = Override direction is not reverse; 1 = Override direction is reverse.</td> </tr> <tr> <td>4</td> <td>Override stop mode is active</td> <td>0 = Override stop mode is not active; 1 = Override stop mode is active.</td> </tr> <tr> <td>5...11</td> <td>Reserved</td> <td></td> </tr> <tr> <td>12</td> <td>Test mode active</td> <td>0 = Test mode is inactive; 1 = Test mode is active</td> </tr> <tr> <td>13...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Description	0	Override enabled	0 = Override is disabled; 1 = Override is enabled.	1	Override active	0 = Override is inactive; 1 = Drive is active.	2	Override direction is forward	0 = Override direction is not forward; 1 = Override direction is forward.	3	Override direction is reverse	0 = Override direction is not reverse; 1 = Override direction is reverse.	4	Override stop mode is active	0 = Override stop mode is not active; 1 = Override stop mode is active.	5...11	Reserved		12	Test mode active	0 = Test mode is inactive; 1 = Test mode is active	13...15	Reserved		
Bit	Name	Description																												
0	Override enabled	0 = Override is disabled; 1 = Override is enabled.																												
1	Override active	0 = Override is inactive; 1 = Drive is active.																												
2	Override direction is forward	0 = Override direction is not forward; 1 = Override direction is forward.																												
3	Override direction is reverse	0 = Override direction is not reverse; 1 = Override direction is reverse.																												
4	Override stop mode is active	0 = Override stop mode is not active; 1 = Override stop mode is active.																												
5...11	Reserved																													
12	Test mode active	0 = Test mode is inactive; 1 = Test mode is active																												
13...15	Reserved																													
	0b0000...0b1111		1=1																											
70.02	Override enable	Enables the override function.	<i>Off</i>																											
	Off	Override disabled.	0																											
	On	Override enabled.	1																											
70.03	Override activation source	Selects the source of the override activation. Value 0 of the source deactivates the override. Value 1 of the source activates the override.	<i>Not used</i>																											
	Not used	0.	0																											
	Used	1.	1																											
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2																											
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3																											
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4																											
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5																											
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6																											
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7																											
	-DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	8																											
	-DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	9																											
	-DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	10																											
	-DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	11																											
	-DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	12																											
	-DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	13																											
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-																											
70.04	Override reference source	Selects the source for the speed used in the override mode.	<i>Override speed/freq</i>																											
	Constant speed/freq	Constant speed used as the reference	0																											
	A11	<i>12.12 A11 scaled value</i> (page 187).	1																											
	A12	<i>12.22 A12 scaled value</i> (page 189).	2																											

No.	Name/Value	Description	Def/FbEq16
	Override speed/freq	Parameter 70.06 Override frequency / 70.07 Override speed is used as the reference.	3
	Motor potentiometer	22.80 Motor potentiometer ref act (output of the Motor potentiometer)	4
	Stop	The output of the drive is shut off and the motor no longer runs. Override is displayed on the panel but the motor does not run. Drive follows the specified stop type.	5
	Process PID set 1	Output of the process PID Set 1 (40.96) is used as the reference.	6
70.05	Override direction	Selects the source of the motor direction used in the override mode.	Forward
	Forward	Direction is forward.	0
	Reverse	Direction is reverse.	1
	DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	2
	DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	3
	DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	4
	DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	5
	DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	6
	DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	7
	-DI1	Digital input DI1 (10.02 DI delayed status , bit 0).	8
	-DI2	Digital input DI2 (10.02 DI delayed status , bit 1).	9
	-DI3	Digital input DI3 (10.02 DI delayed status , bit 2).	10
	-DI4	Digital input DI4 (10.02 DI delayed status , bit 3).	11
	-DI5	Digital input DI5 (10.02 DI delayed status , bit 4).	12
	-DI6	Digital input DI6 (10.02 DI delayed status , bit 5).	13
	Other [bit]	Source selection (see Terms and abbreviations on page 160).	-
70.06	Override frequency	Defines the frequency used as reference in the override mode if 70.04 Override reference source is set to Override speed/freq and the drive is in frequency mode..	0.0 Hz
	-500.0...500.0 Hz	Override frequency.	1 = 1 Hz
70.07	Override speed	Defines the speed used as reference in the override mode if 70.04 Override reference source is set to Override speed/freq and the drive is in speed mode.	0.0 rpm
	-30000.0... 30000.0 rpm	Override speed.	1 = 1 rpm
70.20	Override fault handling	Faults are grouped into high priority faults and low priority faults. The following faults are high priority, and they are displayed and they will stop the drive: 2310 Overcurrent , 2340 Short circuit , 3210 DC link overvoltage , 4981 External temperature 1 , 4982 External temperature 2 , 5090 STO hardware failure , 5091 Safe torque off , FA81 Safe torque off 1 , FA81 Safe torque off 2 . Other faults are low priority faults. Active low priority faults are reset when the drive enters override mode. Low priority faults are ignored when the drive is in override mode.	Fault on high priority
	Fault on high priority	Fault on high priority faults. The fault must be reset from the control panel or from a digital input.	0

340 Parameters

No.	Name/Value	Description	Def/FbEq16																																	
	Autoreset	Fault on high priority faults (except STO related faults) with automatic fault reset and run. See the list of high priority faults above. See parameter 70.21 Override auto reset trials .	1																																	
70.21	Override auto reset trials	Defines the number of automatic fault resets the drive performs during override operation. When the parameter is set to 0, reset trials are made continuously during the override operation. A value of 1...5 defines a specific number of automatic reset trials.	5																																	
	0...60	Number of automatic reset trials.	1 = 1																																	
70.22	Override auto reset time	Defines the time the drive will wait after a fault before attempting an automatic fault reset.	5.0 s																																	
	0.1...120.0 s	Auto reset delay time.	10 = 1 s																																	
71 External PID1		Configuration of external PID. See the control chain diagrams on pages 499 and 476 .																																		
71.01	External PID act value	See parameter 40.01 Process PID output actual .	-																																	
71.02	Feedback act value	See parameter 40.02 Process PID feedback actual .	-																																	
71.03	Setpoint act value	See parameter 40.03 Process PID setpoint actual .	-																																	
71.04	Deviation act value	See parameter 40.04 Process PID deviation actual .	-																																	
71.06	PID status word	Displays status information on process external PID control. This parameter is read-only.	-																																	
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PID active</td> <td>1 = Process PID control active.</td> </tr> <tr> <td>1</td> <td>Reserved</td> <td></td> </tr> <tr> <td>2</td> <td>Output frozen</td> <td>1 = Process PID controller output frozen. Bit is set if parameter 71.38 Output freeze enable is TRUE, or the deadband function is active (bit 9 is set).</td> </tr> <tr> <td>3...6</td> <td>Reserved</td> <td></td> </tr> <tr> <td>7</td> <td>Output limit high</td> <td>1 = PID output is being limited by par. 71.37.</td> </tr> <tr> <td>8</td> <td>Output limit low</td> <td>1 = PID output is being limited by par. 71.36.</td> </tr> <tr> <td>9</td> <td>Deadband active</td> <td>1 = Deadband is active (see par. 71.39)</td> </tr> <tr> <td>10...11</td> <td>Reserved</td> <td></td> </tr> <tr> <td>12</td> <td>Internal setpoint active</td> <td>1 = Internal setpoint active (see par. 71.16...71.23)</td> </tr> <tr> <td>13...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>				Bit	Name	Value	0	PID active	1 = Process PID control active.	1	Reserved		2	Output frozen	1 = Process PID controller output frozen. Bit is set if parameter 71.38 Output freeze enable is TRUE, or the deadband function is active (bit 9 is set).	3...6	Reserved		7	Output limit high	1 = PID output is being limited by par. 71.37 .	8	Output limit low	1 = PID output is being limited by par. 71.36 .	9	Deadband active	1 = Deadband is active (see par. 71.39)	10...11	Reserved		12	Internal setpoint active	1 = Internal setpoint active (see par. 71.16 ... 71.23)	13...15	Reserved	
Bit	Name	Value																																		
0	PID active	1 = Process PID control active.																																		
1	Reserved																																			
2	Output frozen	1 = Process PID controller output frozen. Bit is set if parameter 71.38 Output freeze enable is TRUE, or the deadband function is active (bit 9 is set).																																		
3...6	Reserved																																			
7	Output limit high	1 = PID output is being limited by par. 71.37 .																																		
8	Output limit low	1 = PID output is being limited by par. 71.36 .																																		
9	Deadband active	1 = Deadband is active (see par. 71.39)																																		
10...11	Reserved																																			
12	Internal setpoint active	1 = Internal setpoint active (see par. 71.16 ... 71.23)																																		
13...15	Reserved																																			
	0000h...FFFFh	Process PID control status word.	1 = 1																																	
71.07	PID operation mode	See parameter 40.07 Process PID operation mode .	Off																																	
71.08	Feedback 1 source	See parameter 40.08 Set 1 feedback 1 source .	A12 percent																																	
71.11	Feedback filter time	See parameter 40.11 Set 1 feedback filter time .	0.000 s																																	

No.	Name/Value	Description	Def/FbEq16
71.14	Setpoint scaling	Defines, together with parameter 71.15 Output scaling , a general scaling factor for the external PID control chain. The scaling can be utilized when, for example, the process setpoint is input in Hz, and the output of the PID controller is used as an rpm value in speed control. In this case, this parameter might be set to 50, and parameter 71.15 to the nominal motor speed at 50 Hz. In effect, the output of the PID controller [71.15] when deviation (setpoint - feedback) = [71.14] and [71.32] = 1. Note: The scaling is based on the ratio between 71.14 and 71.15 . For example, the values 50 and 1500 would produce the same scaling as 1 and 3.	1500.00
	-200000.00... 200000.00	Process setpoint base.	1 = 1
71.15	Output scaling	See parameter 71.14 Setpoint scaling .	1500.00
	-200000.00... 200000.00	Process PID controller output base.	1 = 1
71.16	Setpoint 1 source	See parameter 40.16 Set 1 setpoint 1 source .	AI1 percent
71.19	Internal setpoint sel1	See parameter 40.19 Set 1 internal setpoint sel1 .	Not selected
71.20	Internal setpoint sel2	See parameter 40.20 Set 1 internal setpoint sel2 .	Not selected
71.21	Internal setpoint 1	See parameter 40.21 Set 1 internal setpoint 1 .	0.00 PID customer units
71.22	Internal setpoint 2	See parameter 40.22 Set 1 internal setpoint 2 .	0.00 PID customer units
71.23	Internal setpoint 3	See parameter 40.23 Set 1 internal setpoint 3 .	0.00 PID customer units
71.26	Setpoint min	See parameter 40.26 Set 1 setpoint min .	0.00
71.27	Setpoint max	See parameter 40.27 Set 1 setpoint max .	200000.00
71.31	Deviation inversion	See parameter 40.31 Set 1 deviation inversion .	Not inverted (Ref - Fbk)
71.32	Gain	See parameter 40.32 Set 1 gain .	1.00
71.33	Integration time	See parameter 40.33 Set 1 integration time .	60.0 s
71.34	Derivation time	See parameter 40.34 Set 1 derivation time .	0.000 s
71.35	Derivation filter time	See parameter 40.35 Set 1 derivation filter time .	0.0 s
71.36	Output min	See parameter 40.36 Set 1 output min .	-200000.00
71.37	Output max	See parameter 40.37 Set 1 output max .	200000.00
71.38	Output freeze enable	See parameter 40.38 Set 1 output freeze .	Not selected

342 Parameters

No.	Name/Value	Description	Def/FbEq16
71.39	<i>Deadband range</i>	The control program compares the absolute value of parameter <i>71.04 Deviation act value</i> to the deadband range defined by this parameter. If the absolute value is within the deadband range for the time period defined by parameter <i>71.40 Deadband delay</i> , PID's deadband mode is activated and <i>71.06 PID status word</i> bit 9 <i>Deadband active</i> is set. Then PID's output is frozen and <i>71.06 PID status word</i> bit 2 <i>Output frozen</i> is set. If the absolute value is equal or greater than the deadband range, PID's deadband mode is deactivated.	0.0
	0.0...200000.0	Range	1 = 1
71.40	<i>Deadband delay</i>	Defines the deadband delay for the deadband function. See parameter <i>71.39 Deadband range</i> .	0.0 s
	0.0...3600.0 s	Delay	1 = 1 s
71.58	<i>Increase prevention</i>	See parameter <i>40.58 Set 1 increase prevention</i> .	No
71.59	<i>Decrease prevention</i>	See parameter <i>40.59 Set 1 decrease prevention</i> .	No
71.62	<i>Internal setpoint actual</i>	See parameter <i>40.62 PID internal setpoint actual</i> .	-
71.79	<i>External PID units</i>	Selects the unit for process PID setpoint, feedback and deviation.	%
	User text	User text	0
	%	%	1
	bar	bar	2
	kPa	kPa	3
	Pa	Pa	4
	psi	psi	5
	CFM	CFM	6
	inH ₂ O	inH ₂ O	7
	°C	°C	8
	°F	°F	9
	mbar	mbar	10
	m ³ /h	m ³ /h	11
	dm ³ /h	dm ³ /h	12
	l/s	l/s	13
	l/min	l/min	14
	l/h	l/h	15
	m ³ /s	m ³ /s	16
	m ³ /m	m ³ /m	17
	km ³ /h	km ³ /h	18
	gal/s	gal/s	19
	ft ³ /s	ft ³ /s	20
	ft ³ /m	ft ³ /m	21
	ft ³ /h	ft ³ /h	22
	ppm	ppm	23

No.	Name/Value	Description	Def/FbEq16
	inHg	inHg	24
	kCFM	kCFM	25
	inWC	inWC	26
	GPM	GPM	27
	gal/m	gal/m	28
	in wg	in wg	29
	MPa	MPa	30
	ftWC	ftWC	31


76 PFC configuration		PFC (Pump and fan control) and Autochange configuration parameters. See also section <i>Pump and Fan Control (PFC) macro</i> on page 123.																			
76.01	<i>PFC status</i>	Displays the running/stopped status of the PFC motors. PFC1, PFC2, PFC3 and PFC4 always correspond to the 1st...4th motor of the PFC system. If 76.74 Autochange auxiliary PFC auxiliary PFC is set to <i>Aux motors only</i> , PFC1 represents the motor connected to the drive and PFC2 the first auxiliary motor (the 2nd motor of the system). If 76.74 is set to <i>All motors</i> , PFC1 is the first motor, PFC2 the 2nd. The drive can be connected to any of these motors depending on the Autochange functionality.	0b0000																		
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>PFC 1 running</td> <td>0 = Stop, 1 = Start</td> </tr> <tr> <td>1</td> <td>PFC 2 running</td> <td>0 = Stop, 1 = Start</td> </tr> <tr> <td>2</td> <td>PFC 3 running</td> <td>0 = Stop, 1 = Start</td> </tr> <tr> <td>3</td> <td>PFC 4 running</td> <td>0 = Stop, 1 = Start</td> </tr> <tr> <td>4...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Value	0	PFC 1 running	0 = Stop, 1 = Start	1	PFC 2 running	0 = Stop, 1 = Start	2	PFC 3 running	0 = Stop, 1 = Start	3	PFC 4 running	0 = Stop, 1 = Start	4...15	Reserved		
Bit	Name	Value																			
0	PFC 1 running	0 = Stop, 1 = Start																			
1	PFC 2 running	0 = Stop, 1 = Start																			
2	PFC 3 running	0 = Stop, 1 = Start																			
3	PFC 4 running	0 = Stop, 1 = Start																			
4...15	Reserved																				
	0b0000...0b1111	Status of the PFC relay outputs.	1 = 1																		
76.02	<i>PFC system status</i>	Displays the status of the PFC system in text form. Provides a quick PFC system overview, e.g. if the parameter is added to the Home view on the control panel.	<i>PFC disabled</i>																		
	PFC disabled	-	0																		
	PFC enabled (not started)	-	1																		
	SPFC enabled (not started)	-	2																		
	MPFC enabled	-	3																		
	Invalid configuration	-	4																		
	PFC inactive (local control)	-	5																		
	PFC inactive (invalid operation mode)	-	6																		
	Drive motor interlocked	-	7																		
	All motors interlocked	-	8																		

344 Parameters

No.	Name/Value	Description	Def/FbEq16																					
	inactive (ext1 active)	-	9																					
	Running with VSD	-	100																					
	Running with VSD + 1 Aux	-	101																					
	Running with VSD + 2 Aux	-	102																					
	Running with VSD + 3 Aux	-	103																					
	Starting Aux1	-	200																					
	Starting Aux2	-	201																					
	Starting Aux3	-	202																					
	Stopping Aux1	-	300																					
	Stopping Aux2	-	301																					
	Stopping Aux3	-	302																					
	Autochange active	-	400																					
	No auxiliary motors available to be started	-	500																					
	Regulator bypass active	-	600																					
	MPFC connection ok	-	700																					
	PID sleep	-	800																					
	PID sleep boost	-	801																					
76.11	Pump/fan status 1	Shows the status of pump or fan 1.	0b0000																					
	<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Ready</td> <td>0 = False, 1 = True</td> </tr> <tr> <td>2</td> <td>Running</td> <td>0 = False, 1 = True</td> </tr> <tr> <td>5</td> <td>In PFC control</td> <td>0 = False, 1 = True</td> </tr> <tr> <td>1, 3, 4, 6...10</td> <td>Reserved</td> <td></td> </tr> <tr> <td>11</td> <td>Interlocked</td> <td>0 = False, 1 = True</td> </tr> <tr> <td>12...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Value	0	Ready	0 = False, 1 = True	2	Running	0 = False, 1 = True	5	In PFC control	0 = False, 1 = True	1, 3, 4, 6...10	Reserved		11	Interlocked	0 = False, 1 = True	12...15	Reserved			
Bit	Name	Value																						
0	Ready	0 = False, 1 = True																						
2	Running	0 = False, 1 = True																						
5	In PFC control	0 = False, 1 = True																						
1, 3, 4, 6...10	Reserved																							
11	Interlocked	0 = False, 1 = True																						
12...15	Reserved																							
	0b0000...0b1111	Status of pump or fan 1.	1 = 1																					
76.12	Pump/fan status 2	See parameter 76.11 Pump/fan status 1 .	-																					
76.13	Pump/fan status 3	See parameter 76.11 Pump/fan status 1 .	-																					
76.14	Pump/fan status 4	See parameter 76.11 Pump/fan status 1 .	-																					
76.21	PFC configuration	Selects the multi-pump/fan control (PFC) mode.	Off																					
	Off	PFC disabled.	0																					

No.	Name/Value	Description	Def/FbEq16
	PFC	PFC enabled. One pump at a time is controlled by the drive. The remaining pumps are direct-on-line pumps that are started and stopped by the drive logic The frequency (group 28 Frequency reference chain) / speed (group 22 Speed reference selection) reference must be defined as PID for the PFC functionality to work properly. SPFC enabled. For more information, see Pump and Fan Control (PFC) macro on page. 123	2
	SPFC	SPFC enabled. For more information, see Soft Pump and Fan Control (SPFC) macro on page. 132	3
76.25	Number of motors	Total number of motors used in the application, including the motor connected directly to the drive.	1
	1...4	Number of motors.	1 = 1
76.26	Min number of motors allowed	Minimum number of motors running simultaneously.	1
	0...4	Minimum number of motors.	1 = 1
76.27	Max number of motors allowed	Maximum number of motors running simultaneously.	1
	1...4	Maximum number of motors.	1 = 1
76.30	Start point 1	Defines the start speed (Hz/rpm) for the first auxiliary pump. As the motor speed or frequency exceeds the limit defined by this parameter, a new auxiliary pump is started. To avoid nuisance starts of the auxiliary pump, the speed of the variable speed pump should be higher than the start speed for the duration defined by parameter 76.55 Start delay . If the speed decreases below the start speed, the auxiliary pump is not started. To maintain the process conditions during the start of the auxiliary pump, a speed hold on time can be defined with parameter 76.57 PFC speed hold on . Certain pump types do not produce significant flow with low frequencies. The speed hold on time can be used to compensate the time needed to accelerate the auxiliary pump to a speed where it produces flow.	Vector: 1300 rpm; Scalar 48 Hz; 58 Hz (95.20 b0)
	0...32767 rpm/Hz	Speed/frequency.	1 = 1 unit
76.31	Start point 2	Defines the start speed (Hz/rpm) for the second auxiliary motor. See parameter 76.31 Start point 1 .	Vector: 1300 rpm; Scalar 48 Hz; 58 Hz (95.20 b0)
76.32	Start point 3	Defines the start speed (Hz/rpm) for the third auxiliary motor. See parameter 76.31 Start point 1 .	Vector: 1300 rpm; Scalar 48 Hz; 58 Hz (95.20 b0)
76.41	Stop point 1	Defines the stop speed (Hz/rpm) for the first auxiliary motor. When the speed of the motor connected directly to the drive falls below this value and one auxiliary motor is running, the stop delay defined by parameter 76.56 Stop delay is started. If the speed is still at the same level or lower when the stop delay elapses, the first auxiliary motor stops. The running speed of the drive is increased by [Start point 1 - Stop point 1] after the auxiliary motor stops	Vector: 800 rpm; Scalar 25 Hz; 30 Hz (95.20 b0)
	0...32767 rpm/Hz	Speed/frequency	1 = 1 unit

346 Parameters

No.	Name/Value	Description	Def/FbEq16
76.42	<i>Stop point 2</i>	Defines the stop speed (Hz/rpm) for the second auxiliary motor. See parameter 76.31 Stop point 1 .	Vector: 800 rpm; Scalar 25 Hz; 30 Hz (95.20 b0)
76.43	<i>Stop point 3</i>	Defines the stop speed (Hz/rpm) for the third auxiliary motor. See parameter 76.31 Stop point 1 .	Vector: 800 rpm; Scalar 25 Hz; 30 Hz (95.20 b0)
76.55	<i>Start delay</i>	Defines a start delay for auxiliary motors. See parameter 76.31 Start point 1 .	10.00 s
	0.00...12600.00 s	Time delay.	1 = 1 s
76.56	<i>Stop delay</i>	Defines a stop delay for auxiliary motors. See parameter 76.31 Stop point 1 .	10.00 s
	0.00...12600.00 s	Time delay.	1 = 1 s
76.57	<i>PFC speed hold on</i>	Hold time for auxiliary motor switch-on. See parameter 76.31 Start point 1 .	0.00 s
	0.00...1000.00 s	Time.	1 = 1 s
76.58	<i>PFC speed hold off</i>	Hold time for auxiliary motor switch-off. See parameter 76.31 Stop point 1 .	0.00 s
	0.00...1000.00 s	Time.	1 = 1 s
76.59	<i>PFC contactor delay</i>	Start delay for the motor that is directly controlled by the drive. This does not affect the starting of the auxiliary motors.  WARNING! There must always be a delay set if the motors are equipped with star-delta starters. The delay must be set longer than the time setting of the starter. After the motor is switched on by the relay output of the drive, there must be enough time for the star-delta starter to first switch to star and then back to delta before the motor is connected to the drive.	0.50 s
	0.20...600.00 s	Time delay.	1 = 1 s
76.60	<i>PFC ramp acceleration time</i>	Defines the acceleration time for the drive motor speed compensation, when an auxiliary motor is stopped. This ramp time is also used for the drive motor to accelerate after an autochange has occurred. The parameter sets the ramp-up time as seconds from zero to maximum frequency (not from the previous reference to the new reference).	1.00 s
	0.00...1800.00 s	Time.	1 = 1 s
76.61	<i>PFC ramp deceleration time</i>	Defines the deceleration time for the drive motor speed compensation, when an auxiliary motor is started. This ramp time is also used for the drive motor to decelerate after an autochange has occurred. The parameter sets the ramp-up time as seconds from maximum to zero frequency (not from the previous reference to the new reference).	1.00 s
	0.00...1800.00 s	Time.	1 = 1 s


No.	Name/Value	Description	Def/FbEq16
76.70	<i>PFC autochange</i>	<p>Defines the way the autochange is triggered.</p> <p>In all cases except <i>Even wear</i>, the start order is moved one step forward each time the autochange occurs. If the start order initially is 1-2-3-4, after the first autochange the order will be 2-3-4-1, etc.</p> <p>For <i>Even wear</i>, the start order will be determined so that the running times of all motors remain within the defined limit.</p> <p>Note: Autochange only occurs when the speed of the drive is below the speed defined by parameter <i>76.73 Autochange level</i>.</p> <p>See also section <i>Autochange</i> on page 126.</p>	<i>Not selected</i>
	Not selected	Autochange disabled.	0
	Selected	Rising edge starts the autochange if autochange conditions are met.	1
	DI1	Autochange triggered by the rising edge of digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2
	DI2	Autochange triggered by the rising edge of digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3
	DI3	Autochange triggered by the rising edge of digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4
	DI4	Autochange triggered by the rising edge of digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5
	DI5	Autochange triggered by the rising edge of digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6
	DI6	Autochange triggered by the rising edge of digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7
	Timed function 1	Autochange triggered by timed function 1 (bit 0 of <i>34.01 Timed functions status</i> (see page 271)).	8
	Timed function 2	Autochange triggered by timed function 2 (bit 1 of <i>34.01 Timed functions status</i> (see page 271)).	9
	Timed function 3	Autochange triggered by timed function 3 (bit 2 of <i>34.01 Timed functions status</i> (see page 271)).	10
	Fixed interval	Autochange is done when the interval determined in the parameter <i>76.71 PFC autochange interval</i> has elapsed.	11
	All stop	Autochange is done when all the motors are stopped. The PID sleep feature (parameters <i>40.43 Set 1 sleep level ... 40.48 Set 1 wake-up delay</i>) must be used for the drive to stop when the process demand is low.	12
	Even wear	<p>The running time of the motors are balanced by the drive. When the difference in running time between the motors with the least and most running hours exceeds the time defined by parameter <i>76.72 Maximum wear imbalance</i>, the autochange occurs.</p> <p>The running hours of the motors can be found in group <i>77 PFC maintenance and monitoring</i>.</p>	13
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
76.71	<i>PFC autochange interval</i>	Specifies the interval that is used in setting <i>Fixed interval</i> of parameter <i>76.70 PFC autochange</i> .	1.00 h
	0.00...42949672.95 h	Time.	1 = 1 h


348 Parameters

No.	Name/Value	Description	Def/FbEq16
76.72	<i>Maximum wear imbalance</i>	Specifies the maximum wear imbalance, or difference in running times between any motor, used by the <i>Even wear</i> setting of parameter <i>76.70 PFC autochange</i> .	10.00 h
	0.00...1000000.00 h	Time.	1 = 1 h
76.73	<i>Autochange level</i>	Upper speed limit for the Autochange to occur. The Autochange occurs when: <ul style="list-style-type: none"> the condition defined in <i>76.70 PFC autochange</i> is fulfilled and, the speed of the drive motor <i>01.03 Motor speed %</i> is below the speed limit defined in this parameter. Note: When the value is selected as 0%, this speed limit check is disabled.	100.0%
	0.0...300.0%	Speed/frequency in percentage of the nominal speed or frequency of the drive motor.	1 = 1%
76.74	<i>Autochange auxiliary PFC</i>	Selects whether only auxiliary motors or all motors are included in the Autochange function.	<i>Aux motors only</i>
	All motors	All motors, including the one connected to the drive participates in the autochange. The Autochange logic will connect the drive to each of the motors according to setting of parameter <i>76.70 PFC autochange</i> . Note: The first motor (PFC1) also requires the appropriate hardware contactor connections and PFC1 must be defined in one of the relay output source parameters.	0
	Aux motors only	Only auxiliary (direct-on-line) motors are affected by the autochange function. Note: PFC1 refers to the motor that is fixed to the drive and must not be selected in any of the relay output source parameters. Only the starting order of the auxiliary motors will be rotated.	1
76.81	<i>PFC interlock 1</i>	Defines if the PFC motor 1 can be started. An interlocked PFC motor cannot be started. 0 = Interlocked (not available), 1 = Available.	<i>Available. PFC motor is available</i>
	Interlocked. PFC motor is not in use	PFC motor is interlocked and not available.	0
	Available. PFC motor is available	PFC motor is available.	1
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	8
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	9
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	10
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-
76.82	<i>PFC interlock 2</i>	See parameter <i>76.82 PFC interlock 1</i> .	<i>Available. PFC motor is available</i>

No.	Name/Value	Description	Def/FbEq16
76.83	<i>PFC interlock 3</i>	See parameter 76.82 PFC interlock 1 .	<i>Available. PFC motor is available</i>
76.84	<i>PFC interlock 4</i>	See parameter 76.82 PFC interlock 1 .	<i>Available. PFC motor is available</i>
76.95	<i>Regulator bypass control</i>	Defines if direct-on-line pumps are automatically started and stopped. This setting can be used in applications with a low number of sensors and low accuracy requirements.	<i>Disable</i>
	Disable	Automatic starting and stopping is disabled.	0
	Enable	Automatic starting and stopping is enabled.	1
	<i>Other [bit]</i>	Source selection (see Terms and abbreviations on page 160).	-

77 PFC maintenance and monitoring		PFC (Pump and fan control) maintenance and monitoring parameters.	
77.10	<i>PFC runtime change</i>	Enables the reset, or arbitrary setting, of 77.11 Pump/fan 1 running time ... 77.14 Pump/fan 4 running time .	<i>Done</i>
	Done	The parameter automatically reverts back to this value.	0
	Set any PFC run time	Enables the setting of 77.11 Pump/fan 1 running time ... 77.14 Pump/fan 4 running time to an arbitrary value.	1
	Reset PFC1 run time	Resets parameter 77.11 Pump/fan 1 running time .	2
	Reset PFC2 run time	Resets parameter 77.12 Pump/fan 2 running time .	3
	Reset PFC3 run time	Resets parameter 77.13 Pump/fan 3 running time .	4
	Reset PFC4 run time	Resets parameter 77.14 Pump/fan 4 running time .	5
77.11	<i>Pump/fan 1 running time</i>	Running time counter of pump/fan 1. Can be set or reset by parameter 77.10 Pump/fan 1 running time .	0.00 h
	0.00...42949672.95 h	Time	1 = 1 h
77.12	<i>Pump/fan 2 running time</i>	See parameter 77.11 Pump/fan 1 running time .	0.00 h
77.13	<i>Pump/fan 3 running time</i>	See parameter 77.11 Pump/fan 1 running time .	0.00 h
77.14	<i>Pump/fan 4 running time</i>	See parameter 77.11 Pump/fan 1 running time .	0.00 h

No.	Name/Value	Description	Def/FbEq16
90 Feedback selection			
90.03	Load speed	Displays the estimated load speed. Load speed = $\left(\frac{90.62 \text{ Gear denominator}}{90.61 \text{ Gear numerator}} \right) \times 01.01 \text{ Motor speed used}$	
	-32768.00 ... 32767.00 rpm	Load speed.	1 = 1 rpm
90.52	LoadSpeed filter time	Defines a filter time for load speed feedback (90.03 Load speed).	10 ms
	0...10000 ms	Load speed filter time.	1 = 1 ms
90.61	Gear numerator	Parameter 90.61 and 90.62 define a gear function between the motor and load speed. $\frac{90.61 \text{ Gear numerator}}{90.62 \text{ Gear denominator}} = \frac{\text{Motor speed}}{\text{Load speed}}$	1
	-2147483648... 2147483647	Gear numerator (motor-side)	-
90.62	Gear denominator	See parameter 90.61 Gear numerator .	1
	-2147483648... 2147483647	Gear denominator (load - side)	-
90.99	Load speed unit	Selects the unit for parameter 90.03 Load speed .	<i>rpm</i>
	No unit	No unit	0
	rpm	rpm	7
	m/s	m/s	41
	m/min	m/min	42
	ft/s	ft/s	43
	ft/min	ft/min	45
95 HW configuration			
95.01	Supply voltage	Selects the supply voltage range. This parameter is used by the drive to determine the nominal voltage of the supply network. The parameter also affects the current ratings and the DC voltage control functions (trip and brake chopper activation limits) of the drive.  WARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload. Note: The selections shown depend on the hardware of the drive. If only one voltage range is valid for the drive in question, it is selected by default.	380...415 V
	Automatic / not selected	No voltage range selected. The drive will not start modulating before a range is selected, unless parameter 95.02 Adaptive voltage limits is set to <i>Enable</i> , in which case the drive estimates the supply voltage itself.	0
	380...415 V	380...415 V	2

No.	Name/Value	Description	Def/FbEq16																		
95.20	<i>HW options word 1</i>	Specifies hardware-related options that require differentiated parameter defaults. This parameter is not affected by a parameter restore.	0b0000																		
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Supply frequency 60 Hz</td> <td>If you change the value of this bit, you have to do a complete reset to the drive after the change. After reset you have to reselect the macro to be used. See section <i>Differences in the default values between 50 Hz and 60 Hz supply frequency settings</i> on page 369.0 = 50 Hz. 1 = 60 Hz.</td> </tr> <tr> <td>1...12</td> <td colspan="2">Reserved</td> </tr> <tr> <td>13</td> <td>du/dt filter activation</td> <td>When active, an external du/dt filter is connected to the drive/inverter output. The setting will limit the output switching frequency, and force the fan of the drive/inverter module to full speed. 0 = du/dt filter inactive. 1 = du/dt filter active.</td> </tr> <tr> <td>14...15</td> <td colspan="2">Reserved</td> </tr> </tbody> </table>				Bit	Name	Value	0	Supply frequency 60 Hz	If you change the value of this bit, you have to do a complete reset to the drive after the change. After reset you have to reselect the macro to be used. See section <i>Differences in the default values between 50 Hz and 60 Hz supply frequency settings</i> on page 369.0 = 50 Hz. 1 = 60 Hz.	1...12	Reserved		13	du/dt filter activation	When active, an external du/dt filter is connected to the drive/inverter output. The setting will limit the output switching frequency, and force the fan of the drive/inverter module to full speed. 0 = du/dt filter inactive. 1 = du/dt filter active.	14...15	Reserved				
Bit	Name	Value																			
0	Supply frequency 60 Hz	If you change the value of this bit, you have to do a complete reset to the drive after the change. After reset you have to reselect the macro to be used. See section <i>Differences in the default values between 50 Hz and 60 Hz supply frequency settings</i> on page 369.0 = 50 Hz. 1 = 60 Hz.																			
1...12	Reserved																				
13	du/dt filter activation	When active, an external du/dt filter is connected to the drive/inverter output. The setting will limit the output switching frequency, and force the fan of the drive/inverter module to full speed. 0 = du/dt filter inactive. 1 = du/dt filter active.																			
14...15	Reserved																				
0b0000...0b1111		Hardware options configuration word.	1 = 1																		
95.21	<i>HW options word 2</i>	Specifies more hardware-related options that require differentiated parameter defaults. See parameter <i>95.20 HW options word 2</i> .  WARNING! An incorrect setting may cause the motor to rush uncontrollably, or the brake chopper or resistor to overload.	0b0000																		
<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Value</th> </tr> </thead> <tbody> <tr> <td>0...4</td> <td colspan="2">Reserved</td> </tr> <tr> <td>5</td> <td>Bypass present</td> <td>1 = Bypass is used.</td> </tr> <tr> <td>6</td> <td>Cabinet drive</td> <td>0 = Inactive, 1 = Active. Only for drive frames R6 or larger.</td> </tr> <tr> <td>7</td> <td>Reserved</td> <td>0 = Inactive, 1 = Active. Only for drive frames R6 or larger.</td> </tr> <tr> <td>8...15</td> <td colspan="2">Reserved</td> </tr> </tbody> </table>				Bit	Name	Value	0...4	Reserved		5	Bypass present	1 = Bypass is used.	6	Cabinet drive	0 = Inactive, 1 = Active. Only for drive frames R6 or larger.	7	Reserved	0 = Inactive, 1 = Active. Only for drive frames R6 or larger.	8...15	Reserved	
Bit	Name	Value																			
0...4	Reserved																				
5	Bypass present	1 = Bypass is used.																			
6	Cabinet drive	0 = Inactive, 1 = Active. Only for drive frames R6 or larger.																			
7	Reserved	0 = Inactive, 1 = Active. Only for drive frames R6 or larger.																			
8...15	Reserved																				
0b0000...0b1111		Hardware options configuration word.	1 = 1																		
95.200	<i>Cooling fan mode</i>	Selects the fan control type. The fan control functionality enables heat dissipation from the drive and avoids dust accumulation in the drive.	<i>Auto</i>																		
Auto		Controls the fan automatically according to the temperature changes of the drive.	0																		
Always on		Fan runs continuously with the maximum speed (50Hz).	1																		
96 System		Language selection; access levels; macro selection; parameter save and restore; control unit reboot; user parameter sets; unit selection.																			
96.01	<i>Language</i>	Selects the language of the parameter interface and other displayed information when viewed on the control panel. Notes: <ul style="list-style-type: none"> Not all languages listed below are necessarily supported. This parameter does not affect the languages visible in the Drive composer PC tool. (Those are specified under View – Settings – Drive default language.) 	Not selected																		
Not selected		None.	0																		

No.	Name/Value	Description	Def/FbEq16																										
	English	English.	1033																										
	Hindi (India)	Hindi.	2052																										
96.02	Pass code	<p>Pass codes can be entered into this parameter to activate further access levels (see parameter 96.03 Access level status) or to configure the user lock.</p> <p>Entering "358" toggles the parameter lock, which prevents the changing of all other parameters through the control panel or the Drive composer PC tool.</p> <p>Entering the user pass code (by default, "10000000") enables parameters 96.100...96.102, which can be used to define a new user pass code and to select the actions that are to be prevented.</p> <p>Entering an invalid pass code will close the user lock if open, ie. hide parameters 96.100...96.102. After entering the code, check that the parameters are in fact hidden.</p> <p>Note: You must change the default user pass code to maintain a high level of cybersecurity. <u>Store the code in a safe place – the protection cannot be disabled even by ABB if the code is lost.</u></p> <p>See also section User lock (page 96).</p>	0																										
	0...99999999	Pass code.	-																										
96.03	Access level status	Shows which access levels have been activated by pass codes entered into parameter 96.02 Pass code .	0b0000																										
	0b0000...0b1111		1=1																										
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> </tr> </thead> <tbody> <tr><td>0</td><td>End user</td></tr> <tr><td>1</td><td>Service</td></tr> <tr><td>2</td><td>Advanced programmer</td></tr> <tr><td>3</td><td>Reserved</td></tr> <tr><td>4</td><td>Long menu</td></tr> <tr><td>5...9</td><td>Reserved</td></tr> <tr><td>10</td><td>Override parameter lock</td></tr> <tr><td>11</td><td>OEM access level 1</td></tr> <tr><td>12</td><td>OEM access level 2</td></tr> <tr><td>13</td><td>OEM access level 3</td></tr> <tr><td>14</td><td>Parameter lock</td></tr> <tr><td>15</td><td>Reserved</td></tr> </tbody> </table>	Bit	Name	0	End user	1	Service	2	Advanced programmer	3	Reserved	4	Long menu	5...9	Reserved	10	Override parameter lock	11	OEM access level 1	12	OEM access level 2	13	OEM access level 3	14	Parameter lock	15	Reserved	
Bit	Name																												
0	End user																												
1	Service																												
2	Advanced programmer																												
3	Reserved																												
4	Long menu																												
5...9	Reserved																												
10	Override parameter lock																												
11	OEM access level 1																												
12	OEM access level 2																												
13	OEM access level 3																												
14	Parameter lock																												
15	Reserved																												
	0b0000...0b1111	Active access levels.	-																										
96.04	Macro select	<p>Selects the control macro. See chapter Control macros (page 99) for more information.</p> <p>After a selection is made, the parameter reverts automatically to Done.</p>	Done																										
	Done	Macro selection complete; normal operation.	0																										
	ABB standard	Factory macro (see page 100). For scalar motor control.	1																										
	ABB standard (vector)	ABB standard (vector) macro (see page 103). For vector motor control.	17																										
	3-wire	3-wire macro (see page 106)																											
	Motor potentiometer	Motor potentiometer macro (see page 109).	13																										

No.	Name/Value	Description	Def/FbEq16
	PID	PID macro (see page 114).	14
	Panel PID	Panel PID macro (see page 117).	15
	PFC	PFC macro (see page 123).	16
	SPFC	SPFC macro (see page 132).	18
	Pharma Application	Pharma application (see page 141)	19
	Plastic Extrusion	Plastic extrusion (see page 144)	20
	Torque control	Torque control (see page 120)	28
	Jigar	Jigar macro (see page 147)	30
96.05	<i>Macro active</i>	Shows which control macro is currently selected. See chapter Control macros (page 99) for more information. To change the macro, use parameter 96.04 Macro select .	<i>ABB standard</i>
	ABB standard	Factory macro (see page 100). For scalar motor control.	1
	ABB standard (vector)	ABB standard (vector) macro (see page 103). For vector motor control.	17
	3-wire	3-wire macro (see page 106)	
	Motor potentiometer	Motor potentiometer macro (see page 109).	13
	PID	PID macro (see page 114).	14
	Panel PID	Panel PID macro (see page 117).	15
	PFC	PFC macro (see page 123).	16
	SPFC	SPFC macro (see page 132)	18
	Pharma Application	Pharma application (see page 141)	19
	Plastic Extrusion	Plastic extrusion (see page 144)	20
	Torque control	Torque control (see page 120)	28
	Jigar	Jigar macro (see page 147)	30
96.06	<i>Parameter restore</i>	Restores the original settings of the control program, ie. parameter default values. Note: This parameter cannot be changed while the drive is running.	<i>Done</i>
	Done	Restoring is completed.	0
	Reset motor data	Restore all motor rating ID run results to default values	2
	Restore defaults	Restores all editable parameter values to default values, except <ul style="list-style-type: none"> motor data and ID run results I/O extension module settings end user texts, such as customized warnings and faults, and the drive name control panel/PC communication settings fieldbus adapter settings control macro selection and the parameter defaults implemented by it parameter 95.20 HW options word 1 and the differentiated defaults implemented by it. 	8
	Reset all fieldbus settings	Restores all fieldbus and communication related settings to default values. Note: Fieldbus, control panel and PC tool communication are interrupted during the restore.	32

No.	Name/Value	Description	Def/FbEq16
	Clear all	Restores all editable parameter values to default values, except <ul style="list-style-type: none"> • end user texts, such as customized warnings and faults, and the drive name • control macro selection and the parameter defaults implemented by it • parameter 95.20 HW options word 1 and the differentiated defaults implemented by it • group 49 Panel port communication parameters. 	62
	Reset home view	Restores the home view layout back to show the values of the default parameters defined by the control macro in use	512
	Reset end user texts	Restores all end user texts to default values, including the drive name, contact info, customized fault and warning texts and currency unit. Note: PID unit is reset only if it is user editable text, that is, parameter 40.79 Set 1 units is set to User text.	1024
	All to factory defaults	Restores all drive parameters and settings back to initial factory values, except <ul style="list-style-type: none"> • parameter 95.20 HW options word 1 and the differentiated defaults implemented by it. 	34560
96.07	Parameter save manually	Saves the valid parameter values to the permanent memory on the drive control unit to ensure that operation can continue after cycling the power. Save the parameters with this parameter <ul style="list-style-type: none"> • to store values sent from the fieldbus • when using external +24 V DC power supply to the control unit: to save parameter changes before you power down the control unit. The supply has a very short hold-up time when powered off. Note: A new parameter value is saved automatically when changed from the PC tool or control panel but not when altered through a fieldbus adapter connection.	Done
	Done	Save completed.	0
	Save	Save in progress.	1
96.08	Control board boot	Changing the value of this parameter to 1 reboots the control unit (without requiring a power off/on cycle of the complete drive module). The value reverts to 0 automatically.	No action
	No action	1 = No action.	0
	Reboot	1 = Reboot the control unit.	1
96.10	User set status	Shows the status of the user parameter sets. This parameter is read-only. See also section User parameter sets (page 95).	n/a
	n/a	No user parameter sets have been saved.	0
	Loading	A user set is being loaded.	1
	Saving	A user set is being saved.	2
	Faulted	Invalid or empty parameter set.	3
	User1 IO active	User set 1 has been selected by parameters 96.12 User set I/O mode in1 and 96.13 User set I/O mode in2 .	4
	User2 IO active	User set 2 has been selected by parameters 96.12 User set I/O mode in1 and 96.13 User set I/O mode in2 .	5

No.	Name/Value	Description	Def/FbEq16															
	User3 IO active	User set 3 has been selected by parameters 96.12 User set I/O mode in1 and 96.13 User set I/O mode in2 .	6															
	User4 IO active	User set 4 has been selected by parameters 96.12 User set I/O mode in1 and 96.13 User set I/O mode in2 .	7															
	Reserved		8...19															
	User1 backup	User set 1 has been saved or loaded.	20															
	User2 backup	User set 2 has been saved or loaded.	21															
	User3 backup	User set 3 has been saved or loaded.	22															
	User4 backup	User set 4 has been saved or loaded.	23															
96.11	User set save/load	<p>Enables the saving and restoring of up to four custom sets of parameter settings. The set that was in use before powering down the drive is in use after the next power-up.</p> <p>Notes:</p> <ul style="list-style-type: none"> Some hardware configuration settings, such as I/O extension module and fieldbus configuration parameters (groups 14...16, 47, 50...58 and 92...93) are not included in user parameter sets. Parameter changes made after loading a set are not automatically stored – they must be saved using this parameter. This parameter cannot be changed while the drive is running 	<i>No action</i>															
	No action	Load or save operation complete; normal operation.	0															
	User set I/O mode	Load user parameter set using parameters 96.12 User set I/O mode in1 and 96.13 User set I/O mode in2 .	1															
	Load set 1	Load user parameter set 1.	2															
	Load set 2	Load user parameter set 2.	3															
	Load set 3	Load user parameter set 3.	4															
	Load set 4	Load user parameter set 4.	5															
	Save to set 1	Save user parameter set 1.	18															
	Save to set 2	Save user parameter set 2.	19															
	Save to set 3	Save user parameter set 3.	20															
	Save to set 4	Save user parameter set 4.	21															
96.12	User set I/O mode in1	<p>When parameter 96.11 User set save/load is set to User set I/O mode, selects the user parameter set together with parameter 96.13 User set I/O mode in2 as follows:</p> <table border="1" data-bbox="342 1182 850 1398"> <thead> <tr> <th>Status of source defined by par. 96.12</th> <th>Status of source defined by par. 96.13</th> <th>User parameter set selected</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>0</td> <td>Set 1</td> </tr> <tr> <td>1</td> <td>0</td> <td>Set 2</td> </tr> <tr> <td>0</td> <td>1</td> <td>Set 3</td> </tr> <tr> <td>1</td> <td>1</td> <td>Set 4</td> </tr> </tbody> </table>	Status of source defined by par. 96.12	Status of source defined by par. 96.13	User parameter set selected	0	0	Set 1	1	0	Set 2	0	1	Set 3	1	1	Set 4	<i>Not selected</i>
Status of source defined by par. 96.12	Status of source defined by par. 96.13	User parameter set selected																
0	0	Set 1																
1	0	Set 2																
0	1	Set 3																
1	1	Set 4																
	Not selected	0.	0															
	Selected	1.	1															


No.	Name/Value	Description	Def/FbEq16																					
	DI1	Digital input DI1 (<i>10.02 DI delayed status</i> , bit 0).	2																					
	DI2	Digital input DI2 (<i>10.02 DI delayed status</i> , bit 1).	3																					
	DI3	Digital input DI3 (<i>10.02 DI delayed status</i> , bit 2).	4																					
	DI4	Digital input DI4 (<i>10.02 DI delayed status</i> , bit 3).	5																					
	DI5	Digital input DI5 (<i>10.02 DI delayed status</i> , bit 4).	6																					
	DI6	Digital input DI6 (<i>10.02 DI delayed status</i> , bit 5).	7																					
	Timed function 1	Bit 0 of <i>34.01 Timed functions status</i> (see page 271).	18																					
	Timed function 2	Bit 1 of <i>34.01 Timed functions status</i> (see page 271).	19																					
	Timed function 3	Bit 2 of <i>34.01 Timed functions status</i> (see page 271).	20																					
	Supervision 1	Bit 0 of <i>32.01 Supervision status</i> (see page 264).	24																					
	Supervision 2	Bit 1 of <i>32.01 Supervision status</i> (see page 264).	25																					
	Supervision 3	Bit 2 of <i>32.01 Supervision status</i> (see page 264).	26																					
	<i>Other [bit]</i>	Source selection (see <i>Terms and abbreviations</i> on page 160).	-																					
96.13	<i>User set I/O mode in2</i>	See parameter 96.12 <i>User set I/O mode in1</i> .	<i>Not selected</i>																					
96.16	<i>Unit selection</i>	Selects the unit of parameters indicating power, temperature and torque.	0b0000																					
		<table border="1"> <thead> <tr> <th>Bit</th> <th>Name</th> <th>Information</th> </tr> </thead> <tbody> <tr> <td>0</td> <td>Power unit</td> <td>0 = kW 1 = hp</td> </tr> <tr> <td>1</td> <td>Reserved</td> <td></td> </tr> <tr> <td>2</td> <td>Temperature unit</td> <td>0 = °C 1 = °F</td> </tr> <tr> <td>3</td> <td>Reserved</td> <td></td> </tr> <tr> <td>4</td> <td>Torque unit</td> <td>0 = Nm (N·m) 1 = lbft (lb·ft)</td> </tr> <tr> <td>5...15</td> <td>Reserved</td> <td></td> </tr> </tbody> </table>	Bit	Name	Information	0	Power unit	0 = kW 1 = hp	1	Reserved		2	Temperature unit	0 = °C 1 = °F	3	Reserved		4	Torque unit	0 = Nm (N·m) 1 = lbft (lb·ft)	5...15	Reserved		
Bit	Name	Information																						
0	Power unit	0 = kW 1 = hp																						
1	Reserved																							
2	Temperature unit	0 = °C 1 = °F																						
3	Reserved																							
4	Torque unit	0 = Nm (N·m) 1 = lbft (lb·ft)																						
5...15	Reserved																							
	0b0000...0b1111	Unit selection word.	1 = 1																					
96.20	<i>Time sync primary source</i>	Defines the 1st priority external source for synchronization of the drive's time and date.	<i>Panel link</i>																					
	Internal	No external source selected.	0																					
	Fieldbus A	FENA/FPNO can get the time from SNTP server and set it as time for the drive.	3																					
	Embedded FB	EFB BACnet MS/TP time-sync service can be used to set the time for the drive.	6																					
	Panel link	You can set the time using control panel, or Drive composer PC tool connected to the control panel.	8																					
	Ethernet tool link	You can set the time manually by using DCP over Ethernet. The time can be set in the same way when you do it with USB and panel.	9																					
96.51	<i>Clear fault and event logger</i>	Clears all events from the drive's fault and event logs.	<i>Done</i>																					
	Done	1 = No action	0																					
	Reset	1 = Resets (clears) fault and event logger.	1																					


No.	Name/Value	Description	Def/FbEq16
96.78	550 compatibility mode	Enables/disables a Modbus user to access a select set of parameters using 550 register numbering.	Enable
	Disable	Using 550 compatibility mode is disabled.	0
	Enable	Using 550 compatibility mode is enabled.	1
96.100	Change user pass code	<i>(Visible when user lock is open)</i> To change the current user pass code, enter a new code into this parameter as well as 96.101 Confirm user pass code . A warning will be active until the new pass code is confirmed. To cancel changing the pass code, close the user lock without confirming. To close the lock, enter an invalid pass code in parameter 96.02 Pass code , activate parameter 96.08 Control board boot , or cycle the power. See also section User lock (page 96).	10000000
	10000000... 99999999	New user pass code.	-
96.101	Confirm user pass code	<i>(Visible when user lock is open)</i> Confirms the new user pass code entered in 96.100 Change user pass code .	
	10000000... 99999999	Confirmation of new user pass code.	-
96.102	User lock functionality	<i>(Visible when user lock is open)</i> Selects the actions or functionalities to be prevented by the user lock. Note that the changes made take effect only when the user lock is closed. See parameter 96.02 Pass code . Note: We recommend you select all the actions and functionalities unless otherwise required by the application.	0000h


Bit	Name	Information
0	Disable ABB access levels	1 = ABB access levels (service, advanced programmer, etc.; see 96.03) disabled
1	Freeze parameter lock state	1 = Changing the parameter lock state prevented, ie. pass code 358 has no effect
2	Disable file download	1 = Loading of files to drive prevented. This applies to <ul style="list-style-type: none"> • firmware upgrades • parameter restore • changing home view of control panel • editing drive texts • editing the favorite parameters list on control panel • configuration settings made through control panel such as time/date formats and enabling/disabling clock display.
3...6	Reserved	
7	Disable panel Bluetooth	1 = Bluetooth disabled on ACS-AP-W control panel. If the drive is part of a panel bus, Bluetooth is disabled on all panels.
8...10	Reserved	
11	Disable OEM access level 1	1 = OEM access level 1 disabled
12	Disable OEM access level 2	1 = OEM access level 2 disabled
13	Disable OEM access level 3	1 = OEM access level 3 disabled
14...15	Reserved	

No.	Name/Value	Description	Def/FbEq16
	0000h...FFFFh	Selection of actions to be prevented by user lock.	-
97 Motor control		Switching frequency; slip gain; voltage reserve; flux braking; anti-cogging (signal injection); IR compensation.	
97.01	<i>Switching frequency reference</i>	Defines the switching frequency of the drive that is used as long as the drive does not heat too much. See section <i>Switching frequency</i> on page 72. Higher switching frequency results in lower acoustic noise- Notes <ul style="list-style-type: none"> • If you have a multimotor system, contact your local ABB representative. • 2 kHz option is not available in R0...R2 frames. 	4 kHz
	2 kHz	2 kHz	2
	4 kHz	4 kHz	4
	8 kHz	8 kHz	8
	12 kHz	12 kHz	12
97.02	<i>Minimum switching frequency</i>	Lowest switching frequency that is allowed. Depends on the frame size.	1.5 kHz
	1.5 kHz	1.5 kHz (available only in R0...R2 frames)	1.5
	2 kHz	2 kHz.	2
	4 kHz	4 kHz.	4
	8 kHz	8 kHz.	8
	12 kHz	12 kHz	12
97.03	<i>Slip gain</i>	Defines the slip gain which is used to improve the estimated motor slip. 100% means full slip gain; 0% means no slip gain. The default value is 100%. Other values can be used if a static speed error is detected despite having the setting at full slip gain. Example (with nominal load and nominal slip of 40 rpm): A 1000 rpm constant speed reference is given to the drive. Despite having full slip gain (= 100%), a manual tachometer measurement from the motor axis gives a speed value of 998 rpm. The static speed error is 1000 rpm - 998 rpm = 2 rpm. To compensate the error, the slip gain should be increased to 105% (2 rpm / 40 rpm = 5%).	100%
	0...200%	Slip gain.	1 = 1%
97.04	<i>Voltage reserve</i>	Defines the minimum allowed voltage reserve. When the voltage reserve has decreased to the set value, the drive enters the field weakening area. Note: This is an expert level parameter and should not be adjusted without appropriate skill. If the intermediate circuit DC voltage $U_{dc} = 550 \text{ V}$ and the voltage reserve is 5%, the RMS value of the maximum output voltage in steady-state operation is $0.95 \times 550 \text{ V} / \sqrt{2} = 369 \text{ V}$ The dynamic performance of the motor control in the field weakening area can be improved by increasing the voltage reserve value, but the drive enters the field weakening area earlier.	-2%
	-4...50%	Voltage reserve.	1 = 1%

360 Parameters

No.	Name/Value	Description	Def/FbEq16
97.05	<i>Flux braking</i>	Defines the level of flux braking power. (Other stopping and braking modes can be configured in parameter group 21 Start/stop mode). Note: This is an expert level parameter and should not be adjusted without appropriate skill.	<i>Disabled</i>
	Disabled	Flux braking is disabled.	0
	Moderate	Flux level is limited during the braking. Deceleration time is longer compared to full braking.	1
	Full	Maximum braking power. Almost all available current is used to convert the mechanical braking energy to thermal energy in the motor.  WARNING! Using full flux braking heats up the motor especially in cyclic operation. Make sure that the motor can withstand this if you have a cyclic application.	2
97.08	<i>Optimizer minimum torque</i>	This parameter can be used to improve the control dynamics of a synchronous reluctance motor or a salient permanent magnet synchronous motor. As a rule of thumb, define a level to which the output torque must rise with minimum delay. This will increase the motor current and improve the torque response at low speeds.	0.0
	0.0...1600.0%	Optimizer torque limit.	10 = 1%


No.	Name/Value	Description	Def/FbEq16																														
97.13	<i>IR compensation</i>	<p>Defines the relative output voltage boost at zero speed (IR compensation). The function is useful in applications with a high break-away torque where vector control cannot be applied.</p>  <p>See also section IR compensation for scalar motor control on page 66.</p> <p>Typical IR compensation values are shown below.</p> <table border="1" data-bbox="397 805 901 949"> <thead> <tr> <th colspan="10">3-phase 380...415V drives</th> </tr> <tr> <th>P_N (kW)</th> <td>0,37</td> <td>0,75</td> <td>1,1</td> <td>2,2</td> <td>4</td> <td>7,5</td> <td>15</td> <td>37</td> <td>132</td> </tr> <tr> <th>IR compensation (%)</th> <td>3,5</td> <td>3,5</td> <td>3,2</td> <td>2,5</td> <td>2</td> <td>1,5</td> <td>1,3</td> <td>1,1</td> <td>0,6</td> </tr> </thead> </table> <p>⚠ WARNING! Set IR compensation value as low as possible. Large IR compensation value can lead to overheating of the motor and damage to the drive, if operated for longer periods at low speed.</p>	3-phase 380...415V drives										P _N (kW)	0,37	0,75	1,1	2,2	4	7,5	15	37	132	IR compensation (%)	3,5	3,5	3,2	2,5	2	1,5	1,3	1,1	0,6	3.50%
3-phase 380...415V drives																																	
P _N (kW)	0,37	0,75	1,1	2,2	4	7,5	15	37	132																								
IR compensation (%)	3,5	3,5	3,2	2,5	2	1,5	1,3	1,1	0,6																								
	0.00...50.00%	Voltage boost at zero speed in percent of nominal motor voltage.	1 = 1%																														
97.20	<i>U/f ratio</i>	Selects the form for the <i>U/f</i> (voltage to frequency) ratio below field weakening point. For scalar control only.	<i>Linear</i>																														
	Linear	Linear ratio for constant torque applications.	0																														
	Squared	Squared ratio for centrifugal pump and fan applications. With squared <i>U/f</i> ratio the noise level is lower for most operating frequencies. Not recommended for permanent magnet motors.	1																														



No.	Name/Value	Description	Def/FbEq16
97.49	<i>Slip gain for scalar</i>	Sets gain for slip compensation (in %) while drive is operating in scalar control mode. <ul style="list-style-type: none"> • A squirrel-cage motor slips under load. Increasing the frequency as the motor torque increases compensates for the slip. • Requires parameter <i>99.04 Motor control mode = Scalar</i>. 0 = No slip compensation. 1...200 = Increasing slip compensation. 100% means full slip compensation according to parameters <i>99.08 Motor nominal frequency</i> and <i>99.09 Motor nominal speed</i> .	0
	0...200 %	Slip compensation in %.	1 = 1%
97.94	<i>IR comp max frequency</i>	Sets the frequency at which IR compensation (set by parameter <i>97.13 IR compensation</i>) reaches 0 V. The unit is % of motor nominal frequency. <p>IR compensation</p> When enabled, IR compensation provides an extra voltage boost to the motor at low speeds. Use IR compensation, for example, in applications that require a high breakaway torque. 	80.0
	1.0...200.0 %	IR compensation maximum frequency in %.	1 = 1%
98 User motor parameters		Motor values supplied by the user that are used in the motor model. These parameters are useful for non-standard motors, or to just get more accurate motor control of the motor on site. A better motor model always improves the shaft performance.	
98.01	<i>User motor model mode</i>	Activates the motor model parameters <i>98.02...98.12</i> . <p>Notes:</p> <ul style="list-style-type: none"> • Parameter value is automatically set to zero when ID run is selected by parameter <i>99.13 ID run requested</i>. The values of parameters <i>98.02...98.12</i> are then updated according to the motor characteristics identified during the ID run. • Measurements made directly from the motor terminals during the ID run are likely to produce slightly different values than those on a data sheet from a motor manufacturer. • This parameter cannot be changed while the drive is running. 	<i>Not selected</i>
	Not selected	Parameters <i>98.02...98.12</i> inactive.	0

No.	Name/Value	Description	Def/FbEq16
	Motor parameters	The values of parameters 98.02... 98.12 are used as the motor model.	1
98.02	<i>Rs user</i>	Defines the stator resistance R_S of the motor model. With a star-connected motor, R_S is the resistance of one winding. With a delta-connected motor, R_S is one-third of the resistance of one winding.	0.00000 p.u.
	0.00000...0.50000 p.u.	Stator resistance in per unit.	-
98.03	<i>Rr user</i>	Defines the rotor resistance R_R of the motor model.	0.00000 p.u.
	0.00000...0.50000 p.u.	Rotor resistance in per unit.	-
98.04	<i>Lm user</i>	Defines the main inductance L_M of the motor model.	0.00000 p.u.
	0.00000...10.00000 p.u.	Main inductance in per unit.	-
98.05	<i>SigmaL user</i>	Defines the leakage inductance σL_S .	0.00000 p.u.
	0.00000...1.00000 p.u.	Leakage inductance in per unit.	-
98.09	<i>Rs user SI</i>	Defines the stator resistance R_S of the motor model.	0.00000 ohm
	0.00000...100.0000 0 ohm	Stator resistance.	-
98.10	<i>Rr user SI</i>	Defines the rotor resistance R_R of the motor model.	0.00000 ohm
	0.00000...100.0000 0 ohm	Rotor resistance.	-
98.11	<i>Lm user SI</i>	Defines the main inductance L_M of the motor model.	0.00 mH
	0.00...100000.00 mH	Main inductance.	1 = 10000 mH
98.12	<i>SigmaL user SI</i>	Defines the leakage inductance σL_S .	0.00 mH
	0.00...100000.00 mH	Leakage inductance.	1 = 10000 mH
99 Motor data		Motor configuration settings.	
99.03	<i>Motor type</i>	Selects the motor type. Note: This parameter cannot be changed while the drive is running.	<i>Asynchronous motor</i>
	Asynchronous motor	Standard squirrel cage AC induction motor (asynchronous induction motor).	0
99.04	<i>Motor control mode</i>	Selects the motor control mode.	<i>Scalar</i>
	Vector	Vector control. Vector control has better accuracy than scalar control but cannot be used in all situations (see selection <i>Scalar</i> below). Requires motor identification run (ID run). See parameter 99.13 <i>ID run requested</i> . Note: In vector control the drive performs a standstill ID run at the first start if ID run has not been previously performed. A new start command is required after standstill ID run. Note: To achieve a better motor control performance, you can perform a normal ID run without load. See also section <i>Operating modes of the drive</i> (page 37).	0

No.	Name/Value	Description	Def/FbEq16
	Scalar	<p>Scalar control. Suitable for most applications, if top performance is not required. Motor identification run is not required.</p> <p>Note: Scalar control must be used in the following situations:</p> <ul style="list-style-type: none"> with multimotor systems 1) if the load is not equally shared between the motors, 2) if the motors are of different sizes, or 3) if the motors are going to be changed after the motor identification (ID run) if the nominal current of the motor is less than 1/6 of the nominal output current of the drive if the drive is used with no motor connected (for example, for test purposes). <p>Note: Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the inverter.</p> <p>See also section Speed compensated stop (page 76), and section Operating modes of the drive (page 37).</p>	1
99.06	<i>Motor nominal current</i>	<p>Defines the nominal motor current. Must be equal to the value on the motor rating plate. If multiple motors are connected to the drive, enter the total current of the motors.</p> <p>Notes:</p> <ul style="list-style-type: none"> Correct motor operation requires that the magnetizing current of the motor does not exceed 90% of the nominal current of the drive. This parameter cannot be changed while the drive is running. 	1.8 A
	0.0...32767.0	<p>Nominal current of the motor. The allowable range:</p> <ul style="list-style-type: none"> vector control mode: $1/6 \dots 2 \times I_N$ of the drive scalar control mode: $0 \dots 2 \times I_N$ with scalar control mode. <p>Note: When using flying start in scalar control mode (see parameter 21.19 Scalar start mode), the nominal current must be in the range allowed for vector control mode.</p>	1 = 0.01 A See 46.05
99.07	<i>Motor nominal voltage</i>	<p>Defines the nominal motor voltage supplied to the motor. This setting must match the value on the rating plate of the motor.</p> <p>Notes:</p> <ul style="list-style-type: none"> With permanent magnet motors, the nominal voltage is the BackEMF voltage at nominal speed of the motor. If the voltage is given as voltage per rpm, e.g. 60 V per 1000 rpm, the voltage for a nominal speed of 3000 rpm is $3 \times 60 \text{ V} = 180 \text{ V}$. The stress on the motor insulation is always dependent on the drive supply voltage. This also applies to the case where the motor voltage rating is lower than that of the drive and the supply. This parameter cannot be changed while the drive is running. 	400.0 V
	0.0...32767.0 V	Nominal voltage of the motor.	10 = 1 V
99.08	<i>Motor nominal frequency</i>	<p>Defines the nominal motor frequency. This setting must match the value on the rating plate of the motor.</p> <p>Note: This parameter cannot be changed while the drive is running.</p>	50.00 Hz
	0.00...500.00 Hz	Nominal frequency of the motor.	10 = 1 Hz

No.	Name/Value	Description	Def/FbEq16
99.09	<i>Motor nominal speed</i>	Defines the nominal motor speed. The setting must match the value on the rating plate of the motor. Note: This parameter cannot be changed while the drive is running.	1430 rpm
	0...30000 rpm	Nominal speed of the motor.	1 = 1 rpm
99.10	<i>Motor nominal power</i>	Defines the nominal motor power. The setting must match the value on the rating plate of the motor. If multiple motors are connected to the drive, enter the total power of the motors. The unit is selected by parameter 96.16 Unit selection . Note: This parameter cannot be changed while the drive is running.	0.75 kW
	0.00... 10000.00 kW or hp	Nominal power of the motor.	1 = 1 unit
99.11	<i>Motor nominal cos ?</i>	Defines the cosphi of the motor for a more accurate motor model. The value is not obligatory, but is useful with an asynchronous motor, especially when performing a standstill identification run. With a permanent magnet or synchronous reluctance motor, this value is not needed. Notes: <ul style="list-style-type: none"> Do not enter an estimated value. If you do not know the exact value, leave the parameter at zero. This parameter cannot be changed while the drive is running. 	0.00
	0.00...1.00	Cosphi of the motor.	100 = 1
99.12	<i>Motor nominal torque</i>	Defines the nominal motor shaft torque for a more accurate motor model. Not obligatory. The unit is selected by parameter 96.16 Unit selection . Note: This parameter cannot be changed while the drive is running.	0.000 N·m or lb·ft
	0.000...4000000.000 N·m or 0.000...2950248.597 lb·ft	Nominal motor torque.	1 = 100 unit

No.	Name/Value	Description	Def/FbEq16
99.13	<i>ID run requested</i>	<p>Selects the type of the motor identification routine (ID run) performed at the next start of the drive. During the ID run, the drive will identify the characteristics of the motor for optimum motor control.</p> <p>If no ID run has been performed yet (or if default parameter values have been restored using parameter <i>96.06 Parameter restore</i>), this parameter is automatically set to <i>Standstill</i>, signifying that an ID run must be performed.</p> <p>After the ID run, the drive stops and this parameter is automatically set to <i>None</i>.</p> <p>Notes:</p> <ul style="list-style-type: none"> • To ensure that the ID run can work properly, the drive limits in group <i>30</i> (maximum speed and minimum speed, and maximum torque and minimum torque) must be large enough (the range specified by the limits must be wide enough. If e.g. speed limits are less than the motor nominal speed, the ID run cannot be completed). • For the <i>Advanced</i> ID run, the machinery must always be de-coupled from the motor. • With a permanent magnet or synchronous reluctance motor, a <i>Normal</i>, <i>Reduced</i> or <i>Standstill</i> ID run requires that the motor shaft is NOT locked and the load torque is less than 10%. • Once the ID run is activated, it can be canceled by stopping the drive. • The ID run must be performed every time any of the motor parameters (<i>99.04</i>, <i>99.06</i>...<i>99.12</i>) have been changed. • Ensure that the Safe Torque Off and emergency stop circuits (if any) are closed during the ID run. • Mechanical brake (if present) is not opened by the logic for the ID run. • This parameter cannot be changed while the drive is running. 	<i>None</i>
	None	<p>No motor ID run is requested. This mode can be selected only if the ID run (<i>Normal/Reduced/Standstill/Advanced</i>) has already been performed once.</p>	0
	Normal	<p>Normal ID run. Guarantees good control accuracy for all cases. The ID run takes about 90 seconds. This mode should be selected whenever it is possible.</p> <p>Notes:</p> <ul style="list-style-type: none"> • If the load torque will be higher than 20% of motor nominal torque, or if the machinery is not able to withstand the nominal torque transient during the ID run, then the driven machinery must be de-coupled from the motor during a Normal ID run. • Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction. <p> WARNING! The motor will run at up to approximately 50...100% of the nominal speed during the ID run. Make sure that it is safe to run the motor before performing the ID run.</p>	1

No.	Name/Value	Description	Def/FbEq16
	Reduced	<p>Reduced ID run. This mode should be selected instead of the <i>Normal</i> or <i>Advanced</i> ID Run if</p> <ul style="list-style-type: none"> mechanical losses are higher than 20% (ie. the motor cannot be de-coupled from the driven equipment), or if flux reduction is not allowed while the motor is running (ie. in case of a motor with an integrated brake supplied from the motor terminals). <p>With this ID run mode, the resultant motor control in the field weakening area or at high torques is not necessarily as accurate as motor control following a Normal ID run. Reduced ID run is completed faster than the Normal ID Run (< 90 seconds).</p> <p>Note: Check the direction of rotation of the motor before starting the ID run. During the run, the motor will rotate in the forward direction.</p> <p> WARNING! The motor will run at up to approximately 50...100% of the nominal speed during the ID run. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</p>	2
	Standstill	<p>Standstill ID run. The motor is injected with DC current. With an AC induction (asynchronous) motor, the motor shaft is not rotated. With a permanent magnet motor, the shaft can rotate up to half a revolution.</p> <p>Note: This mode should be selected only if the <i>Normal</i>, <i>Reduced</i> or <i>Advanced</i> ID run is not possible due to the restrictions caused by the connected mechanics (e.g. with lift or crane applications).</p>	3
	Advanced	<p>Advanced ID run. Only for frames R6...R8.</p> <p>Guarantees the best possible control accuracy. The ID run takes a very long time to complete. This mode should be selected when top performance is needed across the whole operating area.</p> <p>Note: The driven machinery must be de-coupled from the motor because of high torque and speed transients that are applied.</p> <p> WARNING! The motor may run at up to the maximum (positive) and minimum (negative) allowed speed during the ID run. Several accelerations and decelerations are done. The maximum torque, current and speed allowed by the limit parameters may be utilized. ENSURE THAT IT IS SAFE TO RUN THE MOTOR BEFORE PERFORMING THE ID RUN!</p>	6
	Adaptive	<p>Adaptive ID run. Initially, drive runs in Standstill ID run mode and then refines the motor parameters during the normal operation. This helps to achieve more optimal performance.</p> <p>Note: This is applicable for R0...R5 frames only.</p>	7
99.14	<i>Last ID run performed</i>	Shows the type of ID run that was performed last. For more information about the different modes, see the selections of parameter <i>99.13 ID run requested</i> .	<i>None</i>
	None	No ID run has been performed.	0
	Normal	<i>Normal</i> ID run.	1
	Reduced	<i>Reduced</i> ID run.	2
	Standstill	<i>Standstill</i> ID run.	3
	Advanced	<i>Advanced</i> ID run.	6
	Adaptive	<i>Adaptive</i> ID run.	7

368 Parameters

No.	Name/Value	Description	Def/FbEq16
99.15	<i>Motor polepairs calculated</i>	Calculated number of pole pairs in the motor.	0
	0...1000	Number of pole pairs.	1 = 1
99.16	<i>Motor phase order</i>	Switches the rotation direction of motor. This parameter can be used if the motor turns in the wrong direction (for example, because of the wrong phase order in the motor cable), and correcting the cabling is considered impractical. Note: <ul style="list-style-type: none"> Changing this parameter does not affect speed reference polarities, so positive speed reference will rotate the motor forward. The phase order selection just ensures that "forward" is in fact the correct direction. 	<i>U V W</i>
	U V W	Normal.	0
	U W V	Reversed rotation direction.	1

Differences in the default values between 50 Hz and 60 Hz supply frequency settings

Parameter *95.20 HW options word 1 bit 0 Supply frequency 60 Hz* changes the drive parameter default values according to the supply frequency, 50 Hz or 60 Hz. The bit is set according to the market before the drive is delivered.

If you need to change from 50 Hz to 60 Hz, or vice versa, change the value of the bit and then do a complete reset to the drive. After that you have to reselect the macro to be used.

The table below shows the parameters whose default values depend on the supply frequency setting. The supply frequency setting, with the type designation of the drive, also affects Group *99 Motor data* parameter values though these parameters are not listed in the table.

No	Name	95.20 HW options word 1 bit Supply frequency 60 Hz = 50 Hz	95.20 HW options word 1 bit Supply frequency 60 Hz = 60 Hz
11.45	<i>Freq in 1 at scaled max</i>	1500.000	1800.000
12.20	<i>AI1 scaled at AI1 max</i>	1500.000	1800.000
13.18	<i>AO1 source max</i>	1500.0	1800.0
22.26	<i>Constant speed 1</i>	300.00 rpm	360.00 rpm
22.27	<i>Constant speed 2</i>	600.00 rpm	720.00 rpm
22.28	<i>Constant speed 3</i>	900 .00 rpm	1080.00 rpm
22.29	<i>Constant speed 4</i>	1200.00 rpm	1440.00 rpm
22.30	<i>Constant speed 5</i>	1500.00 rpm	1800.00 rpm
22.30	<i>Constant speed 6</i>	2400.00 rpm	2880.00 rpm
22.31	<i>Constant speed 7</i>	3000.00 rpm	3600.00 rpm
28.26	<i>Constant frequency 1</i>	5.00 Hz	6.00 Hz
28.27	<i>Constant frequency 2</i>	10.00 Hz	12.00 Hz
28.28	<i>Constant frequency 3</i>	15.00 Hz	18.00 Hz
28.29	<i>Constant frequency 4</i>	20.00 Hz	24.00 Hz
28.30	<i>Constant frequency 5</i>	25.00 Hz	30.00 Hz
28.31	<i>Constant frequency 6</i>	40.00 Hz	48.00 Hz
28.32	<i>Constant frequency 7</i>	50.00 Hz	60.00 Hz
30.11	<i>Minimum speed</i>	-1500.00 rpm	-1800.00 rpm
30.12	<i>Maximum speed</i>	1500.00 rpm	1800.00 rpm
30.13	<i>Minimum frequency</i>	-50.00 Hz	-60.00 Hz
30.14	<i>Maximum frequency</i>	50.00 Hz	60.00 Hz
31.26	<i>Stall speed limit</i>	150.00 rpm	180.00 rpm
31.27	<i>Stall frequency limit</i>	15.00 Hz	18.00 Hz
31.30	<i>Overspeed trip margin</i>	500.00 rpm	500.00 rpm
46.01	<i>Speed scaling</i>	1500.00 rpm	1800.00 rpm
46.02	<i>Frequency scaling</i>	50.00 Hz	60.00 Hz

Parameters supported by Modbus backwards compatibility with 550

ACx550 compatibility mode is a way to communicate with an ACx580 drive in such a way that it looks like an ACx550 drive over Modbus RTU or Modbus TCP. This mode can be enabled by changing parameter [96.78 550 compatibility mode](#) to Enable.

In the 550 compatibility mode all supported parameters can be read as if the drive were an ACx550. Some parameters are read only and do not support writes. See the table below to see which parameters support writes.

ACx550 parameter	Name	Read/Write
01.01	SPEED & DIR	Read only
01.02	SPEED	Read only
01.03	OUTPUT FREQ	Read only
01.04	CURRENT	Read only
01.05	TORQUE	Read only
01.06	POWER	Read only
01.07	DC BUS VOLTAGE	Read only
01.09	OUTPUT VOLTAGE	Read only
01.10	DRIVE TEMP	Read only
01.14	RUN TIME	Read only
01.15	KWH COUNTER	Read only
01.18	DI 1-3 STATUS	Read only
01.19	DI 4-6 STATUS	Read only
01.20	AI 1	Read only
01.21	AI 2	Read only
01.22	RO 1-3 STATUS	Read only
01.24	AO 1	Read only
01.25	AO 2	Read only
01.28	PID 1 SETPNT	Read only
01.29	PID 2 SETPNT	Read only
01.30	PID 1 FBK	Read only
01.31	PID 2 FBK	Read only
01.32	PID 1 DEVIATION	Read only
01.33	PID 2 DEVIATION	Read only

ACx550 parameter	Name	Read/Write
01.34	COMM RO WORD	Read only
01.35	COMM VALUE 1	Read only
01.36	COMM VALUE 2	Read only
01.41	MWH COUNTER	Read only
01.45	MOTOR TEMP	Read only
03.01	FB CMD WORD 1	Read only
03.02	FB CMD WORD 2	Read only
03.03	FB STS WORD 1	Read only
03.04	FB STS WORD 2	Read only
03.05	FAULT WORD 1	Read only
03.06	FAULT WORD 2	Read only
03.07	FAULT WORD 3	Read only
03.08	ALARM WORD 1	Read only
03.09	ALARM WORD 2	Read only
04.01	LAST FAULT	Read only
04.12	PREVIOUS FAULT 1	Read only
04.13	PREVIOUS FAULT 2	Read only

ACx550 parameter	Name	Read/Write
11.05	REF1 MAX	Read/Write
11.08	REF2 MAX	Read/Write
16.02	PARAMETER LOCK	Read/Write
20.01	MINIMUM SPEED	Read/Write
20.02	MAXIMUM SPEED	Read/Write
20.03	MAX CURRENT	Read/Write
20.07	MINIMUM FREQ	Read/Write
20.08	MAXIMUM FREQ	Read/Write
22.02	ACCELER TIME 1	Read/Write
22.03	DECELER TIME 1	Read/Write
30.05	MOT THERM POT	Read/Write
30.06	MOT THERM TIME	Read/Write
30.07	MOT LOAD CURVE	Read/Write
33.01	FIRMWARE	Read only
33.02	LOADING PACKAGE	Read only
33.03	TEST DATE	Read only

ACx550 parameter	Name	Read/Write
33.04	DRIVE RATING	Read only
40.01	GAIN	Read/Write
40.02	INTEGRATION TIME	Read/Write
40.03	DERIVATION TIME	Read/Write
40.04	PID DERIV FILTER	Read/Write
40.27	PID 1 PARAM SET	Read/Write
41.01	GAIN	Read/Write
41.02	INTEGRATION TIME	Read/Write
41.03	DERIVATION TIME	Read/Write
41.04	PID DERIV FILTER	Read/Write
42.11	INTERNAL SETPNT	Read/Write
99.05	MOTOR NOM VOLT	Read/Write
99.06	MOTOR NOM CURR	Read/Write
99.07	MOTOR NOM FREQ	Read/Write
99.08	MOTOR NOM SPEED	Read/Write
99.09	MOTOR NOM POWER	Read/Write



Additional parameter data

What this chapter contains

This chapter lists the parameters with some additional data such as their ranges and 32-bit fieldbus scaling. For parameter descriptions, see chapter [Parameters](#) (page 159).

The ACS560 parameter list uses long and short menu structure. ACS560 parameter list adopts long and short menu structure. The short menu displays common parameter list and the long menu displays complete parameter list. The long and short menus are adjusted by parameter 96.02 password. The default value is short menu.

Parameters	Input password	Long and short menu
96.02 password	1	Short menu
	2	Long menu

Terms and abbreviations

Term	Definition
Actual signal	Signal measured or calculated by the drive. Usually can only be monitored but not adjusted; some counter-type signals can however be reset.
Analog src	Analog source: the parameter can be set to the value of another parameter by choosing "Other", and selecting the source parameter from a list. In addition to the "Other" selection, the parameter may offer other pre-selected settings.

Term	Definition
Binary src	Binary source: the value of the parameter can be taken from a specific bit in another parameter value ("Other"). Sometimes the value can be fixed to 0 (false) or 1 (true). In addition, the parameter may offer other pre-selected settings.
Data	Data parameter
FbEq32	32-bit fieldbus equivalent: The scaling between the value shown on the panel and the integer used in communication when a 32-bit value is selected for transmission to an external system. The corresponding 16-bit scalings are listed in chapter Parameters (page 159).
List	Selection list.
No.	Parameter number.
PB	Packed Boolean (bit list).
Real	Real number.
Type	Parameter type. See Analog src , Binary src , List , PB , Real .

Fieldbus addresses

Refer to the *User's manual* of the fieldbus adapter.

Parameter groups 1...9

No.	Name	Type	Range	Unit	FbEq32
01 Actual values					
01.01	Motor speed used	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
01.02	Motor speed estimated	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
01.03	Motor speed %	<i>Real</i>	-1000.00...1000.00	%	100 = 1%
01.06	Output frequency	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
01.07	Motor current	<i>Real</i>	0.00...30000.00	A	100 = 1 A
01.08	Motor current % of motor nom	<i>Real</i>	0.0...1000.0	%	10 = 1%
01.09	Motor current % of drive nom	<i>Real</i>	0.0...1000.0	%	10 = 1%
01.10	Motor torque	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
01.11	DC voltage	<i>Real</i>	0.00...2000.00	V	100 = 1 V
01.13	Output voltage	<i>Real</i>	0...2000	V	1 = 1 V
01.14	Output power	<i>Real</i>	-32768.00...32767.00	kW	100 = 1 unit
01.15	Output power % of motor nom	<i>Real</i>	-300.00...300.00	%	100 = 1%
01.16	Output power % of drive nom	<i>Real</i>	-300.00...300.00	%	100 = 1%
01.17	Motor shaft power	<i>Real</i>	-32768.00...32767.00	kW or hp	100 = 1 unit
01.18	Inverter GWh counter	<i>Real</i>	0...65535	GWh	1 = 1 GWh
01.19	Inverter MWh counter	<i>Real</i>	0...1000	MWh	1 = 1 MWh
01.20	Inverter kWh counter	<i>Real</i>	0...1000	kWh	1 = 1 kWh
01.24	Flux actual %	<i>Real</i>	0...200	%	1 = 1%
01.30	Nominal torque scale	<i>Real</i>	0.000...4000000	N·m	1000 = 1 unit
01.31	Ambient temperature	<i>Real</i>	-40...120	°C or °F	10 = 1 °
01.50	Current hour kWh	<i>Real</i>	0.00...1000000.00	kWh	100 = 1 kWh
01.51	Previous hour kWh	<i>Real</i>	0.00...1000000.00	kWh	100 = 1 kWh
01.52	Current day kWh	<i>Real</i>	0.00...1000000.00	kWh	100 = 1 kWh
01.53	Previous day kWh	<i>Real</i>	0.00...1000000.00	kWh	100 = 1 kWh
01.54	Cumulative inverter energy	<i>Real</i>	-200000000.0... 200000000.0	kWh	100 = 1 kWh
01.55	Inverter GWh counter (resettable)	<i>Real</i>	0...65535	GWh	1 = 1 GWh
01.56	Inverter MWh counter (resettable)	<i>Real</i>	0...1000	MWh	1 = 1 MWh
01.57	Inverter kWh counter (resettable)	<i>Real</i>	0...1000	kWh	1 = 1 kWh
01.58	Cumulative inverter energy (resettable)	<i>Real</i>	-200000000.0... 200000000.0	kWh	1 = 1 kWh
01.61	Abs motor speed used	<i>Real</i>	0.00...30000.00	rpm	100 = 1 rpm
01.62	Abs motor speed %	<i>Real</i>	0.00...1000.00%	%	100 = 1%
01.63	Abs output frequency	<i>Real</i>	0.00...500.00 Hz	Hz	100 = 1 Hz
01.64	Abs motor torque	<i>Real</i>	0.0...1600.0	%	10 = 1%
01.65	Abs output power	<i>Real</i>	0.00...32767.00	kW	100 = 1 kW
01.66	Abs output power % motor nom	<i>Real</i>	0.00...300.00	%	100 = 1%

356 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
01.67	Abs output power % drive nom	<i>Real</i>	0.00...300.00	%	100 = 1%
01.68	Abs motor shaft power	<i>Real</i>	0.00...32767.00	kW or hp	100 = 1 kW
03 Input references					
03.01	Panel reference	<i>Real</i>	-10000.00...100000.00	-	100 = 1
03.02	Panel reference remote	<i>Real</i>	-10000.00...100000.00	-	100 = 1
03.05	FB A reference 1	<i>Real</i>	-10000.00...100000.00	-	100 = 1
03.06	FB A reference 2	<i>Real</i>	-10000.00...100000.00	-	100 = 1
03.09	EFB reference 1	<i>Real</i>	-30000.00...30000.00	-	100 = 1
03.10	EFB reference 2	<i>Real</i>	-30000.00...30000.00	-	100 = 1
04 Warnings and faults					
04.01	Tripping fault	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.02	Active fault 2	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.03	Active fault 3	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.06	Active warning 1	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.07	Active warning 2	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.08	Active warning 3	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.11	Latest fault	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.12	2nd latest fault	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.13	3rd latest fault	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.16	Latest warning	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.17	2nd latest warning	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.18	3rd latest warning	<i>Data</i>	0x0000...0xffff	-	1 = 1
04.40	Event word 1	<i>PB</i>	0000h...FFFFh	-	1 = 1
04.40	Event word 1	<i>PB</i>	0000h...FFFFh	-	1 = 1
04.41	Event word 1 bit 0 code	<i>Data</i>	0x2310...FFFFh	-	1 = 1
04.43	Event word 1 bit 1 code	<i>Data</i>	0x3210...FFFFh	-	1 = 1
04.45, 04.47, 04.49,	
04.71	Event word 1 bit 15 code	<i>Data</i>	0x2330...FFFFh	-	1 = 1
05 Diagnostics					
05.01	On-time counter	<i>Real</i>	0...65535	d	1 = 1 d
05.02	Run-time counter	<i>Real</i>	0...65535	d	1 = 1 d
05.03	Hours run	<i>Real</i>	0.0...429496729.5	h	10 = 1 h
05.04	Fan on-time counter	<i>Real</i>	0...65535	d	1 = 1 d
05.10	Control board temperature	<i>Real</i>	-100...300	°C	10 = 1 °
05.11	Inverter temperature	<i>Real</i>	-40.0...160.0	%	10 = 1 %
05.20	Diagnostic word 1	<i>PB</i>	0b0000...0b1111	-	0b0000
05.21	Diagnostic word 2	<i>PB</i>	0b0000...0b1111	-	0b0000
05.22	Diagnostic word 3	<i>PB</i>	0b0000...0b1111	-	0b0000
05.80	Motor speed at fault	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm

No.	Name	Type	Range	Unit	FbEq32
05.81	Output frequency at fault	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
05.82	DC voltage at fault	<i>Real</i>	0.00...2000.00	V	100 = 1 V
05.83	Motor current at fault	<i>Real</i>	0.00...30000.00	A	100 = 1 A
05.84	Motor torque at fault	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
05.85	Main status word at fault	<i>PB</i>	0000h...FFFFh	-	1 = 1
05.86	DI delayed status at fault	<i>PB</i>	0b0000...0b1111	-	1 = 1
05.87	Inverter temperature at fault	<i>PB</i>	-40.0...160.0	°C	10 = 1°C
05.88	Reference used at fault	<i>Real</i>	-500.00...500.00 Hz/ -1600.0...1600.0%/ 30000.00...30000.00 rpm	Hz/ %/ rpm	100 = 1 Hz/ 10 = 1%/ 100 = 1 rpm
06 Control and status words					
06.01	Main control word	<i>PB</i>	0x0000...0xffff	-	1 = 1
06.11	Main status word	<i>PB</i>	0x0000...0xffff	-	1 = 1
06.16	Drive status word 1	<i>PB</i>	0b0000...0b1111	-	1 = 1
06.17	Drive status word 2	<i>PB</i>	0b0000...0b1111	-	1 = 1
06.18	Start inhibit status word	<i>PB</i>	0b0000...0b1111	-	1 = 1
06.19	Speed control status word	<i>PB</i>	0b0000...0b1111	-	1 = 1
06.20	Constant speed status word	<i>PB</i>	0b0000...0b1111	-	1 = 1
06.21	Drive status word 3	<i>PB</i>	0b0000...0b1111	-	1 = 1
06.29	MSW bit 10 selection	<i>Binary src</i>	0...2	-	1 = 1
06.30	MSW bit 11 selection	<i>Binary src</i>	-	-	1 = 1
06.31	MSW bit 12 selection	<i>Binary src</i>	-	-	1 = 1
06.32	MSW bit 13 selection	<i>Binary src</i>	-	-	1 = 1
06.33	MSW bit 14 selection	<i>Binary src</i>	-	-	1 = 1
07 System info					
07.03	Drive rating id	<i>List</i>	-	-	1 = 1
07.04	Firmware name	<i>List</i>	-	-	1 = 1
07.05	Firmware version	<i>Data</i>	0.00.0.0...255.255.255.255	-	1 = 1
07.06	Loading package name	<i>List</i>	-	-	1 = 1
07.07	Loading package version	<i>Data</i>	0.00.0.0...255.255.255.255	-	1 = 1
07.11	Cpu usage	<i>Real</i>	0...100	%	1 = 1%
07.35	Drive configuration	<i>Binary src</i>	-	-	1=1
07.36	Drive configuration 2	<i>Binary src</i>	-	-	1=1

Parameter groups 10...99

No.	Name	Type	Range	Unit	FbEq32
10 Standard DI, RO					
10.01	DI status	<i>PB</i>	0b0000...0b1111	-	1 = 1
10.02	DI delayed status	<i>PB</i>	0b0000...0b1111	-	1 = 1
10.03	DI force selection	<i>PB</i>	0b0000...0b1111	-	1 = 1
10.04	DI forced data	<i>PB</i>	0b0000...0b1111	-	1 = 1
10.05	DI1 ON delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.06	DI1 OFF delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.07	DI2 ON delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.08	DI2 OFF delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.09	DI3 ON delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.10	DI3 OFF delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.11	DI4 ON delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.12	DI4 OFF delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.13	DI5 ON delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.14	DI5 OFF delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.15	DI6 ON delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.16	DI6 OFF delay	<i>Real</i>	0.00...3000.00	s	10 = 1
10.21	RO status	<i>PB</i>	0b0000...0b1111	-	1 = 1
10.22	RO force selection	<i>PB</i>	0b0000...0b1111	-	1 = 1
10.23	RO forced data	<i>PB</i>	0b0000...0b1111	-	1 = 1
10.24	RO1 source	<i>Binary src</i>	-	-	1 = 1
10.25	RO1 ON delay	<i>Real</i>	0.0...3000.0	s	10 = 1 s
10.26	RO1 OFF delay	<i>Real</i>	0.0...3000.0	s	10 = 1 s
10.27	RO2 source	<i>Binary src</i>	-	-	1 = 1
10.28	RO2 ON delay	<i>Real</i>	0.0...3000.0	s	10 = 1 s
10.29	RO2 OFF delay	<i>Real</i>	0.0...3000.0	s	10 = 1 s
10.30	RO3 source	<i>Binary src</i>	-	-	1 = 1
10.31	RO3 ON delay	<i>Real</i>	0.0...3000.0	s	10 = 1 s
10.32	RO3 OFF delay	<i>Real</i>	0.0...3000.0	s	10 = 1 s
10.99	RO/DIO control word	<i>PB</i>	0b0000...0b1111	-	1 = 1
10.101	RO1 toggle counter	<i>Real</i>	0...4294967000	-	1 = 1
10.102	RO2 toggle counter	<i>Real</i>	0...4294967000	-	1 = 1
10.103	RO3 toggle counter	<i>Real</i>	0...4294967000	-	1 = 1
11 Standard DIO, FI, FO					
11.21	DI5 configuration	<i>List</i>	0...1	-	1 = 1
11.38	Freq in 1 actual value	<i>Real</i>	0...16000	Hz	1 = 1 Hz
11.39	Freq in 1 scaled value	<i>Real</i>	-32768.000...32767.000	-	1000 = 1

No.	Name	Type	Range	Unit	FbEq32
11.42	Freq in 1 min	<i>Real</i>	0...16000	Hz	1 = 1 Hz
11.43	Freq in 1 max	<i>Real</i>	0...16000	Hz	1 = 1 Hz
11.44	Freq in 1 at scaled min	<i>Real</i>	-32768.000...32767.000	-	1000 = 1
11.45	Freq in 1 at scaled max	<i>Real</i>	-32768.000...32767.000	-	1000 = 1
12 Standard AI					
12.02	AI force selection	<i>PB</i>	0b000...0b1111	-	1 = 1
12.03	AI supervision function	<i>List</i>	0...4	-	1 = 1
12.04	AI supervision selection	<i>PB</i>	0b000...0b1111	-	1 = 1
12.11	AI1 actual value	<i>Real</i>	0.000...11.000 V	V	1000 = 1 unit
12.12	AI1 scaled value	<i>Real</i>	-32768.000...32767.000	-	1000 = 1
12.13	AI1 forced value	<i>Real</i>	0.000...11.000 V	V	1000 = 1 unit
12.15	AI1 unit selection	<i>List</i>	2, 10	-	1 = 1
12.16	AI1 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
12.17	AI1 min	<i>Real</i>	0.000...11.000 V	V	1000 = 1 unit
12.18	AI1 max	<i>Real</i>	0.000...11.000 V	V	1000 = 1 unit
12.19	AI1 scaled at AI1 min	<i>Real</i>	-32768.000...32767.000	-	1000 = 1
12.20	AI1 scaled at AI1 max	<i>Real</i>	-32768.000...32767.000	-	1000 = 1
12.21	AI2 actual value	<i>Real</i>	0.000...22.000	mA	1000 = 1 unit
12.22	AI2 scaled value	<i>Real</i>	-32768.000...32767.000	-	1000 = 1
12.23	AI2 forced value	<i>Real</i>	0.000...22.000	mA	1000 = 1 unit
12.25	AI2 unit selection	<i>List</i>	2, 10	-	1 = 1
12.26	AI2 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
12.27	AI2 min	<i>Real</i>	0.000...22.000	mA	1000 = 1 unit
12.28	AI2 max	<i>Real</i>	0.000...22.000	mA	1000 = 1 unit
12.29	AI2 scaled at AI2 min	<i>Real</i>	-32768.000...32767.000	-	1000 = 1
12.30	AI2 scaled at AI2 max	<i>Real</i>	-32768.000...32767.000	-	1000 = 1
12.101	AI1 percent value	<i>Real</i>	0.00...100.00	%	100 = 1%
12.102	AI2 percent value	<i>Real</i>	0.00...100.00	%	100 = 1%
13 Standard AO					
13.02	AO force selection	<i>PB</i>	0b0000...0b1111	-	1 = 1
13.11	AO1 actual value	<i>Real</i>	0.000...22.000 or 0.000...11000 V	mA	1000 = 1 mA
13.12	AO1 source	<i>Analog src</i>	-	-	1 = 1
13.13	AO1 forced value	<i>Real</i>	0.000...22.000 or 0.000...11000 V	mA	1000 = 1 mA
13.15	AO1 unit selection	<i>List</i>	2, 10	-	1 = 1
13.16	AO1 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
13.17	AO1 source min	<i>Real</i>	-32768.0...32767.0	-	10 = 1
13.18	AO1 source max	<i>Real</i>	-32768.0...32767.0	-	10 = 1
13.19	AO1 out at AO1 src min	<i>Real</i>	0.000...22.000 or 0.000...11000 V	mA	1000 = 1 mA

360 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
13.20	AO1 out at AO1 src max	<i>Real</i>	0.000...22.000 or 0.000...11000 V	mA	1000 = 1 mA
13.21	AO2 actual value	<i>Real</i>	0.000...22.000	mA	1000 = 1 mA
13.22	AO2 source	<i>Analog src</i>	-	-	1 = 1
13.23	AO2 forced value	<i>Real</i>	0.000...22.000	mA	1000 = 1 mA
13.26	AO2 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
13.27	AO2 source min	<i>Real</i>	-32768.0...32767.0	-	10 = 1
13.28	AO2 source max	<i>Real</i>	-32768.0...32767.0	-	10 = 1
13.29	AO2 out at AO2 src min	<i>Real</i>	0.000...22.000	mA	1000 = 1 mA
13.30	AO2 out at AO2 src max	<i>Real</i>	0.000...22.000	mA	1000 = 1 mA
13.91	AO1 data storage	<i>Real</i>	-327.68...327.67	-	100 = 1
13.92	AO2 data storage	<i>Real</i>	-327.68...327.67	-	100 = 1
19 Operation mode					
19.01	Actual operation mode	<i>List</i>	-	-	1 = 1
19.11	Ext1/Ext2 selection	<i>Binary src</i>	-	-	1 = 1
19.12	Ext1 control mode	<i>List</i>	1...5	-	1 = 1
19.14	Ext2 control mode	<i>List</i>	1...5	-	1 = 1
19.16	Local control mode	<i>List</i>	0, 1	-	1 = 1
19.17	Local control disable	<i>List</i>	0...1	-	1 = 1
20 Start/stop/direction					
20.01	Ext1 commands	<i>List</i>	0...6, 4, 11, 12, 14	-	1 = 1
20.02	Ext1 start trigger type	<i>List</i>	0...1	-	1 = 1
20.03	Ext1 in1 source	<i>Binary src</i>	-	-	1 = 1
20.04	Ext1 in2 source	<i>Binary src</i>	-	-	1 = 1
20.05	Ext1 in3 source	<i>Binary src</i>	-	-	1 = 1
20.06	Ext2 commands	<i>List</i>	0...6, 4, 11, 12, 14	-	1 = 1
20.07	Ext2 start trigger type	<i>List</i>	0...1	-	1 = 1
20.08	Ext2 in1 source	<i>Binary src</i>	-	-	1 = 1
20.09	Ext2 in2 source	<i>Binary src</i>	-	-	1 = 1
20.10	Ext2 in3 source	<i>Binary src</i>	-	-	1 = 1
20.11	Run enable stop mode	<i>List</i>	0...2	-	1 = 1
20.12	Run enable 1 source	<i>Binary src</i>	-	-	1 = 1
20.19	Enable start command	<i>Binary src</i>	-	-	1 = 1
20.21	Direction	<i>List</i>	0...2	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
20.22	Enable to rotate	<i>Binary src</i>	-	-	1 = 1
20.25	Jogging enable	<i>Binary src</i>	-	-	1 = 1
20.26	Jogging 1 start source	<i>Binary src</i>	-	-	1 = 1
20.27	Jogging 2 start source	<i>Binary src</i>	-	-	1 = 1
21 Start/stop mode					
21.01	Start mode	<i>List</i>	0...2	-	1 = 1
21.02	Magnetization time	<i>Real</i>	0...10000	ms	1 = 1 ms
21.03	Stop mode	<i>List</i>	0...2	-	1 = 1
21.04	Emergency stop mode	<i>List</i>	0...2	-	1 = 1
21.05	Emergency stop source	<i>Binary src</i>	-	-	1 = 1
21.06	Zero speed limit	<i>Real</i>	0.00...30000.00	rpm	100 = 1 rpm
21.07	Zero speed delay	<i>Real</i>	0...30000	ms	1 = 1 ms
21.08	DC current control	<i>PB</i>	0b0000...0b1111	-	1 = 1
21.09	DC hold speed	<i>Real</i>	0.00...1000.00	rpm	100 = 1 rpm
21.10	DC current reference	<i>Real</i>	0.0...100.0	%	10 = 1%
21.11	Post magnetization time	<i>Real</i>	0...3000	s	1 = 1 s
21.14	Pre-heating input source	<i>Binary src</i>	-	-	1 = 1
21.15	Pre-heating time delay	<i>Real</i>	10...3000	s	1 = 1
21.16	Pre-heating current	<i>Real</i>	0.0...30.0	%	10 = 1%
21.18	Auto restart time	<i>Real</i>	0.0...10.0	s	10 = 1 s
21.19	Scalar start mode	<i>List</i>	0...6	-	1 = 1
21.21	DC hold frequency	<i>Real</i>	0.00...1000.00	Hz	100 = 1 Hz
21.22	Start delay	<i>Real</i>	0.00...60.00	s	100 = 1 s
21.26	Torque boost current	<i>Real</i>	15.0...300.0	%	100 = 1%
21.27	Torque boost time	<i>Real</i>	0.0...60.0	s	10 = 1 s
21.30	Speed compensated stop mode	<i>Real</i>	0...3	-	1 = 1
21.31	Speed comp stop delay	<i>Real</i>	0.00...1000.00	s	100 = 1 s
21.32	Speed comp stop threshold	<i>Real</i>	0...100	%	1 = 1%
21.34	Force auto restart	<i>List</i>	0...1	-	1 = 1
22 Speed reference selection					
22.01	Speed ref unlimited	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
22.11	Ext1 speed ref1	<i>Analog src</i>	-	-	1 = 1
22.12	Ext1 speed ref2	<i>Analog src</i>	-	-	1 = 1
22.13	Ext1 speed function	<i>List</i>	0...5	-	1 = 1

362 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
22.18	Ext2 speed ref1	Analog src	-	-	1 = 1
22.19	Ext2 speed ref2	Analog src	-	-	1 = 1
22.20	Ext2 speed function	List	0...5	-	1 = 1
22.21	Constant speed function	PB	0b0000...0b1111	-	1 = 1
22.22	Constant speed sel1	Binary src	-	-	1 = 1
22.23	Constant speed sel2	Binary src	-	-	1 = 1
22.24	Constant speed sel3	Binary src	-	-	1 = 1
22.26	Constant speed 1	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.27	Constant speed 2	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.28	Constant speed 3	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.29	Constant speed 4	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.30	Constant speed 5	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.31	Constant speed 6	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.32	Constant speed 7	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.41	Speed ref safe	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.42	Jogging 1 ref	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.43	Jogging 2 ref	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.51	Critical speed function	PB	0b0000...0b1111	-	1 = 1
22.52	Critical speed 1 low	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.53	Critical speed 1 high	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.54	Critical speed 2 low	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.55	Critical speed 2 high	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.56	Critical speed 3 low	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.57	Critical speed 3 high	Real	-30000.00...30000.00	rpm	100 = 1 rpm
22.71	Motor potentiometer function	List	0...3	-	1 = 1
22.72	Motor potentiometer initial value	Real	-32768.00...32767.00	-	100 = 1
22.73	Motor potentiometer up source	Binary src	-	-	1 = 1
22.74	Motor potentiometer down source	Binary src	-	-	1 = 1
22.76	Motor potentiometer min value	Real	-32768.00...32767.00	-	100 = 1
22.77	Motor potentiometer max value	Real	-32768.00...32767.00	-	100 = 1
22.78	Motor potentiometer ramp up	Real	0.0...3600.0	s	-
22.79	Motor potentiometer ramp down	Real	0.0...3600.0	s	-
22.80	Motor potentiometer ref act	Real	-32768.00...32767.00	-	100 = 1
22.86	Speed reference act 6	Real	-30000.00...30000.00	rpm	100 = 1 rpm

No.	Name	Type	Range	Unit	FbEq32
22.87	Speed reference act 7	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
23 Speed reference ramp					
23.01	Speed ref ramp input	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
23.02	Speed ref ramp output	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
23.11	Ramp set selection	<i>Binary src</i>	-	-	1 = 1
23.12	Acceleration time 1	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
23.13	Deceleration time 1	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
23.14	Acceleration time 2	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
23.15	Deceleration time 2	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
23.20	Acc time jogging	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
23.21	Dec time jogging	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
23.23	Emergency stop time	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
23.28	Variable slope	<i>List</i>	0...1	-	1 = 1
23.29	Variable slope rate	<i>Real</i>	2...30000	ms	1 = 1 ms
23.32	Shape time 1	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
23.33	Shape time 2	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
24 Speed reference conditioning					
24.01	Used speed reference	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
24.02	Used speed feedback	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
24.03	Speed error filtered	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
25 Speed control					
25.01	Torque reference speed control	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
25.02	Speed proportional gain	<i>Real</i>	0.00...250.00	-	100 = 1
25.03	Speed integration time	<i>Real</i>	0.00...1000.00	s	100 = 1 s
25.04	Speed derivation time	<i>Real</i>	0.000...10.000	s	1000 = 1 s
25.05	Derivation filter time	<i>Real</i>	0...10000	ms	1 = 1 ms
25.06	Acc comp derivation time	<i>Real</i>	0.00...1000.00	s	100 = 1 s
25.07	Acc comp filter time	<i>Real</i>	0.0...1000.0	ms	10 = 1 ms
25.30	Flux adaptation enable	<i>List</i>	0...1	-	-
25.33	Speed controller autotune	<i>List</i>	-	-	1 = 1
25.34	Speed controller autotune mode	<i>List</i>	-	-	1 = 1
25.37	Mechanical time constant	<i>Real</i>	0.00...1000.00	s	100 = 1 s
25.38	Autotune torque step	<i>Real</i>	0.00...100.00	%	100 = 1%
25.39	Autotune speed step	<i>Real</i>	0.00...100.00	%	100 = 1%
25.40	Autotune repeat times	<i>Real</i>	1...10	-	1 = 1
25.53	Torque prop reference	<i>Real</i>	-30000.0...30000.0	%	10 = 1%
25.54	Torque integral reference	<i>Real</i>	-30000.0...30000.0	%	10 = 1%
25.55	Torque deriv reference	<i>Real</i>	-30000.0...30000.0	%	10 = 1%
25.56	Torque acc compensation	<i>Real</i>	-30000.0...30000.0	%	10 = 1%

364 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
26 Torque reference chain					
26.01	Torque reference to TC	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
26.02	Torque reference used	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
26.08	Minimum torque ref	<i>Real</i>	-1000.0...0.0	%	10 = 1%
26.09	Maximum torque ref	<i>Real</i>	0.0...1000.0	%	10 = 1%
26.11	Torque ref1 source	<i>Analog src</i>	-	-	1 = 1
26.12	Torque ref2 source	<i>Analog src</i>	-	-	1 = 1
26.13	Torque ref1 function	<i>List</i>	0...5	-	1 = 1
26.14	Torque ref1/2 selection	<i>Binary src</i>	-	-	1 = 1
26.17	Torque ref filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
26.18	Torque ramp up time	<i>Real</i>	0.000...60.000	s	1000 = 1 s
26.19	Torque ramp down time	<i>Real</i>	0.000...60.000	s	1000 = 1 s
26.20	Torque reversal	<i>List</i>	-	-	1 = 1
26.21	Torque sel torque in	<i>Binary src</i>	-	-	1 = 1
26.22	Torque sel speed in	<i>Binary src</i>	-	-	1 = 1
26.70	Torque reference act 1	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
26.71	Torque reference act 2	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
26.72	Torque reference act 3	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
26.73	Torque reference act 4	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
26.74	Torque ref ramp out	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
26.75	Torque reference act 5	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
26.76	Torque reference act 6		-1600.0...1600.0	%	10 = 1%
26.81	Rush control gain	<i>Real</i>	0.0...10000.0	-	10=1
26.82	Rush control integration time	<i>Real</i>	0.0...10.0	s	10=1 s
28 Frequency reference chain					
28.01	Frequency ref ramp input	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.02	Frequency ref ramp output	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.11	Ext1 frequency ref1	<i>Analog src</i>	-	-	1 = 1
28.12	Ext1 frequency ref2	<i>Analog src</i>	0...5	-	1 = 1
28.13	Ext1 frequency function	<i>List</i>	0...5	-	1 = 1
28.15	Ext2 frequency ref1	<i>Analog src</i>	-	-	1 = 1
28.16	Ext2 frequency ref2	<i>Analog src</i>	-	-	1 = 1
28.17	Ext2 frequency function	<i>List</i>	0...5	-	1 = 1
28.21	Constant frequency function	<i>PB</i>	0b0000...0b1111	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
28.22	Constant frequency sel1	<i>Binary src</i>	-	-	1 = 1
28.23	Constant frequency sel2	<i>Binary src</i>	-	-	1 = 1
28.24	Constant frequency sel3	<i>Binary src</i>	-	-	1 = 1
28.26	Constant frequency 1	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.27	Constant frequency 2	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.28	Constant frequency 3	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.29	Constant frequency 4	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.30	Constant frequency 5	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.31	Constant frequency 6	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.32	Constant frequency 7	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.41	Frequency ref safe	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.42	Jogging 1 frequency ref	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.43	Jogging 2 frequency ref	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.51	Critical frequency function	<i>PB</i>	0b0000...0b1111	-	1 = 1
28.52	Critical frequency 1 low	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.53	Critical frequency 1 high	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.54	Critical frequency 2 low	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.55	Critical frequency 2 high	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.56	Critical frequency 3 low	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.57	Critical frequency 3 high	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.71	Freq ramp set selection	<i>Binary src</i>	-	-	1 = 1
28.72	Freq acceleration time 1	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
28.73	Freq deceleration time 1	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
28.74	Freq acceleration time 2	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
28.75	Freq deceleration time 2	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
28.76	Freq ramp in zero source	<i>Binary src</i>	-	-	1 = 1
28.82	Shape time 1	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
28.83	Shape time 2	<i>Real</i>	0.000...1800.000	s	1000 = 1 s
28.92	Frequency ref act 3	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.96	Frequency ref act 7	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
28.97	Frequency ref unlimited	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
30 Limits					
30.01	Limit word 1	<i>PB</i>	0b0000...0b1111	-	1 = 1
30.02	Torque limit status	<i>PB</i>	0b0000...0b1111	-	1 = 1
30.09	Current limit monitor time	<i>Real</i>	0.00...120.00	s	-
30.10	Current limit actions	<i>List</i>	0...2	-	1=1
30.11	Minimum speed	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm
30.12	Maximum speed	<i>Real</i>	-30000.00...30000.00	rpm	100 = 1 rpm

366 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
30.13	Minimum frequency	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
30.14	Maximum frequency	<i>Real</i>	-500.00...500.00	Hz	100 = 1 Hz
30.17	Maximum current	<i>Real</i>	0.00.3.24	A	100 = 1 A
30.18	Torq lim sel	<i>Binary src</i>	-	-	1 = 1
30.19	Minimum torque 1	<i>Real</i>	-1600.0...0.0	%	10 = 1%
30.20	Maximum torque 1	<i>Real</i>	0.0...1600.0	%	10 = 1%
30.21	Min torque 2 source	<i>Analog src</i>	-	-	1 = 1
30.22	Max torque 2 source	<i>Analog src</i>	-	-	1 = 1
30.23	Minimum torque 2	<i>Real</i>	-1600.0...0.0	%	10 = 1%
30.24	Maximum torque 2	<i>Real</i>	0.0...1600.0	%	10 = 1%
30.26	Power motoring limit	<i>Real</i>	0.00...600.00	%	100 = 1%
30.27	Power generating limit	<i>Real</i>	-600.00...0.00	%	100 = 1%
30.30	Overvoltage control	<i>List</i>	0...1	-	1 = 1
30.31	Undervoltage control	<i>List</i>	0...1	-	1 = 1
30.35	Thermal current limitation	<i>List</i>	0...1	-	1 = 1
30.36	Speed limit selection	<i>Binary src</i>	-	-	1 = 1
30.37	Min speed source	<i>Analog src</i>	-	-	1 = 1
30.38	Max speed source	<i>Analog src</i>	-	-	1 = 1
31 Fault functions					
31.01	External event 1 source	<i>Binary src</i>	-	-	1 = 1
31.02	External event 1 type	<i>List</i>	0...1	-	1 = 1
31.03	External event 2 source	<i>Binary src</i>	-	-	1 = 1
31.04	External event 2 type	<i>List</i>	0...1	-	1 = 1
31.05	External event 3 source	<i>Binary src</i>	-	-	1 = 1
31.06	External event 3 type	<i>List</i>	0...1	-	1 = 1
31.07	External event 4 source	<i>Binary src</i>	-	-	1 = 1
31.08	External event 4 type	<i>List</i>	0...1	-	1 = 1
31.09	External event 5 source	<i>Binary src</i>	-	-	1 = 1
31.10	External event 5 type	<i>List</i>	0...1	-	1 = 1
31.11	Fault reset selection	<i>Binary src</i>	-	-	1 = 1
31.12	Autoreset selection	<i>PB</i>	0x0000...0xffff	-	1 = 1
31.13	Selectable fault	<i>Real</i>	0x0000...0xffff	-	1 = 1
31.14	Number of trials	<i>Real</i>	0...5	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
31.15	Total trials time	<i>Real</i>	1.0...600.0	s	10 = 1 s
31.16	Delay time	<i>Real</i>	0.0...120.0	s	10 = 1 s
31.19	Motor phase loss	<i>List</i>	0...1	-	1 = 1
31.22	STO indication run/stop	<i>List</i>	0...5	-	1 = 1
31.23	Wiring or earth fault	<i>List</i>	0...1	-	1 = 1
31.24	Stall function	<i>List</i>	0...2	-	1 = 1
31.25	Stall current limit	<i>Real</i>	0.0...1600.0	%	10 = 1%
31.26	Stall speed limit	<i>Real</i>	0.00...10000.00	rpm	100 = 1 rpm
31.27	Stall frequency limit	<i>Real</i>	0.00...1000.00	Hz	100 = 1 Hz
31.28	Stall time	<i>Real</i>	0...3600	s	1 = 1 s
31.30	Overspeed trip margin	<i>Real</i>	0.00...10000.00	rpm	100 = 1 rpm
31.31	Frequency trip margin	<i>Real</i>	0.00...10000.00	Hz	100 = 1 Hz
31.36	Aux fan fault function	<i>List</i>	0...1	-	1 = 1
31.35	Main fan fault function	<i>List</i>	-	-	1 = 1
32 Supervision					
32.01	Supervision status	<i>PB</i>	0b0000...0b1111	-	1 = 1
32.05	Supervision 1 function	<i>List</i>	0...7	-	1 = 1
32.06	Supervision 1 action	<i>List</i>	0...3	-	1 = 1
32.07	Supervision 1 signal	<i>Analog src</i>	-	-	1 = 1
32.08	Supervision 1 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
32.09	Supervision 1 low	<i>Real</i>	-21474836.00... 21474836.00	-	-
32.10	Supervision 1 high	<i>Real</i>	-21474836.00... 21474836.00	-	-
32.11	Supervision 1 hysteresis	<i>Real</i>	0.00...100000.00	-	100 = 1
32.15	Supervision 2 function	<i>List</i>	0...7	-	1 = 1
32.16	Supervision 2 action	<i>List</i>	0...3	-	1 = 1
32.17	Supervision 2 signal	<i>Analog src</i>	-	-	1 = 1
32.18	Supervision 2 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
32.19	Supervision 2 low	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.20	Supervision 2 high	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.21	Supervision 2 hysteresis	<i>Real</i>	0.00...100000.00	-	100 = 1
32.25	Supervision 3 function	<i>List</i>	0...6	-	1 = 1
32.26	Supervision 3 action	<i>List</i>	0...3	-	1 = 1
32.27	Supervision 3 signal	<i>Analog src</i>	0, 1, 3, 4, 6...10, 23...27	-	1 = 1
32.28	Supervision 3 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
32.29	Supervision 3 low	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1

No.	Name	Type	Range	Unit	FbEq32
32.30	Supervision 3 high	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.31	Supervision 3 hysteresis	<i>Real</i>	0.00...100000.00	-	100 = 1
32.35	Supervision 4 function	<i>List</i>	0...7	-	1 = 1
32.36	Supervision 4 action	<i>List</i>	0...3	-	1 = 1
32.37	Supervision 4 signal	<i>Analog src</i>	-	-	1 = 1
32.38	Supervision 4 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
32.39	Supervision 4 low	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.40	Supervision 4 high	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.41	Supervision 4 hysteresis	<i>Real</i>	0.00...100000.00	-	100 = 1
32.45	Supervision 5 function	<i>List</i>	0...7	-	1 = 1
32.46	Supervision 5 action	<i>List</i>	0...3	-	1 = 1
32.47	Supervision 5 signal	<i>Analog src</i>	-	-	1 = 1
32.48	Supervision 5 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
32.49	Supervision 5 low	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.50	Supervision 5 high	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.51	Supervision 5 hysteresis	<i>Real</i>	0.00...100000.00	-	100 = 1
32.55	Supervision 6 function	<i>List</i>	0...7	-	1 = 1
32.56	Supervision 6 action	<i>List</i>	0...3	-	1 = 1
32.57	Supervision 6 signal	<i>Analog src</i>	-	-	1 = 1
32.58	Supervision 6 filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
32.59	Supervision 6 low	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.60	Supervision 6 high	<i>Real</i>	-21474836.00... 21474836.00	-	100 = 1
32.61	Supervision 6 hysteresis	<i>Real</i>	0.00...100000.00	-	100 = 1
34 Timed functions					
34.01	Timed functions status	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.02	Timer status	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.04	Season/exception day status	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.10	Timed functions enable	<i>Binary src</i>	0...7	-	1 = 1
34.11	Timer 1 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.12	Timer 1 start time	Time	00:00:00...23:59:59	-	1 = 1
34.13	Timer 1 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.14	Timer 2 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.15	Timer 2 start time	Time	00:00:00...23:59:59	-	1 = 1
34.16	Timer 2 duration	Duration	00 00:00...07 00:00	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
34.17	Timer 3 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.18	Timer 3 start time	Time	00:00:00...23:59:59	-	1 = 1
34.19	Timer 3 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.20	Timer 4 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.21	Timer 4 start time	Time	00:00:00...23:59:59	-	1 = 1
34.22	Timer 4 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.23	Timer 5 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.24	Timer 5 start time	Time	00:00:00...23:59:59	-	1 = 1
34.25	Timer 5 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.26	Timer 6 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.27	Timer 6 start time	Time	00:00:00...23:59:59	-	1 = 1
34.28	Timer 6 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.29	Timer 7 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.30	Timer 7 start time	Time	00:00:00...23:59:59	-	1 = 1
34.31	Timer 7 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.32	Timer 8 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.33	Timer 8 start time	Time	00:00:00...23:59:59	-	1 = 1
34.34	Timer 8 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.35	Timer 9 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.36	Timer 9 start time	Time	00:00:00...23:59:59	-	1 = 1
34.37	Timer 9 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.38	Timer 10 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.39	Timer 10 start time	Time	00:00:00...23:59:59	-	1 = 1
34.40	Timer 10 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.41	Timer 11 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.42	Timer 11 start time	Time	00:00:00...23:59:59	-	1 = 1
34.43	Timer 11 duration	Duration	00 00:00...07 00:00	-	1 = 1
34.44	Timer 12 configuration	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.45	Timer 12 start time	Time	00:00:00...23:59:59	-	1 = 1
34.46	Timer 12 duration	Duration	00 00:00...07 00:00	-	1 = 1 -
34.60	Season 1 start date	Date	-	-	1 = 1
34.61	Season 2 start date	Date	-	-	1 = 1
34.62	Season 3 start date	Date	-	-	1 = 1
34.63	Season 4 start date	Date	-	-	1 = 1
34.70	Number of active exceptions	<i>Real</i>	0...16	-	1 = 1
34.71	Exception types	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.72	Exception 1 start	Date	-	d	1 = 1 d
34.73	Exception 1 length	<i>Real</i>	0...60	d	1 = 1 d
34.74	Exception 2 start	Date	-	d	1 = 1 d
34.75	Exception 2 length	<i>Real</i>	0...60	d	1 = 1 d
34.76	Exception 3 start	Date	-	d	1 = 1 d

370 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
34.77	Exception 3 length	<i>Real</i>	0...60	d	1 = 1 d
34.78	Exception day 4	Date	-	d	1 = 1 d
34.79	Exception day 5	Date	-	d	1 = 1 d
34.80	Exception day 6	Date	-	d	1 = 1 d
34.81	Exception day 7	Date	-	d	1 = 1 d
34.82	Exception day 8	Date	-	d	1 = 1 d
34.83	Exception day 9	Date	-	d	1 = 1 d
34.84	Exception day 10	Date	-	d	1 = 1 d
34.85	Exception day 11	Date	-	d	1 = 1 d
34.86	Exception day 12	Date	-	d	1 = 1 d
34.87	Exception day 13	Date	-	d	1 = 1 d
34.88	Exception day 14	Date	-	d	1 = 1 d
34.89	Exception day 15	Date	-	d	1 = 1 d
34.90	Exception day 16	Date	-	d	1 = 1 d
34.100	Timed function 1	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.101	Timed function 2	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.102	Timed function 3	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.110	Boost time function	<i>PB</i>	0b0000...0b1111	-	1 = 1
34.111	Boost time activation source	<i>Binary src</i>	-	-	1 = 1
34.112	Boost time duration	Duration	00 00:00...07 00:00	min	1 = 1 min
35 Motor thermal protection					
35.01	Motor estimated temperature	<i>Real</i>	-60...1000 °C or -76...1832 °F	°C or °F	1 = 1 °
35.02	Measured temperature 1	<i>Real</i>	-60...5000 °C or -76...9032 °F	°C, °F	1 = 1 unit
35.03	Measured temperature 2	<i>Real</i>	-60...5000 °C or -76...9032 °F	°C, °F	1 = 1 unit
35.05	Motor overload level	<i>Real</i>	0.0...300.0	%	1 = 1 unit
35.11	Temperature 1 source	<i>List</i>	-	-	1 = 1
35.12	Temperature 1 fault limit	<i>Real</i>	-60...5000 °C or -76...9032 °F	°C, °F	1 = 1 unit
35.13	Temperature 1 warning limit	<i>Real</i>	-60...5000 °C or -76...9032 °F	°C, °F	1 = 1 unit
35.14	Temperature 1 AI source	<i>Analog src</i>	-	-	1 = 1
35.21	Temperature 2 source	<i>List</i>	-	-	1 = 1
35.22	Temperature 2 fault limit	<i>Real</i>	-60...5000 °C or -76...9032 °F	°C, °F	1 = 1 unit
35.23	Temperature 2 warning limit	<i>Real</i>	-60...5000 °C or -76...9032 °F	°C, °F	1 = 1 unit
35.24	Temperature 2 AI source	<i>Analog src</i>	-	-	1 = 1
35.50	Motor ambient temperature	<i>Real</i>	-60...100 °C or -76 ... 212 °F	°C, °F	1 = 1 °

No.	Name	Type	Range	Unit	FbEq32
35.51	Motor load curve	<i>Real</i>	50...150	%	1 = 1%
35.52	Zero speed load	<i>Real</i>	50...150	%	1 = 1%
35.53	Break point	<i>Real</i>	1.00 ... 500.00	Hz	100 = 1 Hz
35.54	Motor nominal temperature rise	<i>Real</i>	0...300 °C or 32...572 °F	°C or °F	1 = 1 °
35.55	Motor thermal time const	<i>Real</i>	100...10000	s	1 = 1 s
35.56	Motor overload action	<i>List</i>	0...2	-	1 = 1
35.57	Motor overload class	<i>List</i>	0...4	-	1 = 1
36 Load analyzer					
36.01	PVL signal source	<i>Analog src</i>	-	-	1 = 1
36.02	PVL filter time	<i>Real</i>	0.00...120.00	s	100 = 1 s
36.09	Reset loggers	<i>List</i>	0...3	-	1 = 1
36.10	PVL peak value	<i>Real</i>	-32768.00...32767.00	-	100 = 1
36.11	PVL peak date	<i>Data</i>	1/1/1980...6/5/2159	-	1 = 1
36.12	PVL peak time	<i>Data</i>	00:00:00...23:59:59	-	1 = 1
36.13	PVL current at peak	<i>Real</i>	-32768.00...32767.00	A	100 = 1 A
36.14	PVL DC voltage at peak	<i>Real</i>	0.00...2000.00	V	100 = 1 V
36.15	PVL speed at peak	<i>Real</i>	-30000.00-30000.00	rpm	100 = 1 rpm
36.16	PVL reset date	<i>Data</i>	1/1/1980...6/5/2159	-	1 = 1
36.17	PVL reset time	<i>Data</i>	00:00:00...23:59:59	-	1 = 1
37 User load curve					
37.01	ULC output status word	<i>PB</i>	0b0000...0b1111	-	1 = 1
37.02	ULC supervision signal	<i>Analog src</i>	-	-	1 = 1
37.03	ULC overload actions	<i>List</i>	0...3	-	1 = 1
37.04	ULC underload actions	<i>List</i>	0...3	-	1 = 1
37.11	ULC speed table point 1	<i>Real</i>	-30000.0...30000.0	rpm	10 = 1 rpm
37.12	ULC speed table point 2	<i>Real</i>	-30000.0...30000.0	rpm	10 = 1 rpm
37.13	ULC speed table point 3	<i>Real</i>	-30000.0...30000.0	rpm	10 = 1 rpm
37.14	ULC speed table point 4	<i>Real</i>	-30000.0...30000.0	rpm	10 = 1 rpm
37.15	ULC speed table point 5	<i>Real</i>	-30000.0...30000.0	rpm	10 = 1 rpm
37.21	ULC underload point 1	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.22	ULC underload point 2	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.23	ULC underload point 3	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.24	ULC underload point 4	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.25	ULC underload point 5	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.31	ULC overload point 1	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.32	ULC overload point 2	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.33	ULC overload point 3	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.34	ULC overload point 4	<i>Real</i>	-1600.0...1600.0	%	10 = 1%

372 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
37.35	ULC overload point 5	<i>Real</i>	-1600.0...1600.0	%	10 = 1%
37.41	ULC overload timer	<i>Real</i>	0.0...10000.0	s	10 = 1 s
37.42	ULC underload timer	<i>Real</i>	0.0...10000.0	s	10 = 1 s
40 Process PID set 1					
40.01	Process PID output actual	<i>Real</i>	-200000.00...200000.00	-	100 = 1 PID customer unit
40.02	Process PID feedback actual	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
40.03	Process PID setpoint actual	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
40.04	Process PID deviation actual	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
40.05	Process PID trim output act	<i>Real</i>	-32768...32767	PID customer units	100 = 1 PID customer unit
40.06	Process PID status word	<i>PB</i>	0b0000...0b1111	-	1 = 1
40.07	Process PID operation mode	<i>List</i>	0...2	-	1 = 1
40.08	Set 1 feedback 1 source	<i>Analog src</i>	-	-	1 = 1
40.09	Set 1 feedback 2 source	<i>Analog src</i>	-	-	1 = 1
40.10	Set 1 feedback function	<i>List</i>	0...11	-	1 = 1
40.11	Set 1 feedback filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
40.14	Set 1 setpoint scaling	<i>Real</i>	-200000.00...200000.00	-	-
40.15	Set 1 output scaling	<i>Real</i>	-200000.00...200000.00	-	-
40.16	Set 1 setpoint 1 source	<i>Analog src</i>	-	-	1 = 1
40.17	Set 1 setpoint 2 source	<i>Analog src</i>	-	-	1 = 1
40.18	Set 1 setpoint function	<i>List</i>	0...11	-	1 = 1
40.19	Set 1 internal setpoint sel1	<i>Binary src</i>	-	-	1 = 1
40.20	Set 1 internal setpoint sel2	<i>Binary src</i>	-	-	1 = 1
40.21	Set 1 internal setpoint 1	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
40.22	Set 1 internal setpoint 2	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
40.23	Set 1 internal setpoint 3	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
40.24	Set 1 internal setpoint 0	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit

No.	Name	Type	Range	Unit	FbEq32
40.26	Set 1 setpoint min	<i>Real</i>	-200000.00...200000.00	-	100 = 1
40.27	Set 1 setpoint max	<i>Real</i>	-200000.00...200000.00	-	100 = 1
40.28	Set 1 setpoint increase time	<i>Real</i>	0.0...1800.0	s	10 = 1 s
40.29	Set 1 setpoint decrease time	<i>Real</i>	0.0...1800.0	s	10 = 1 s
40.30	Set 1 setpoint freeze enable	<i>Binary src</i>	-	-	1 = 1
40.31	Set 1 deviation inversion	<i>Binary src</i>	-	-	1 = 1
40.32	Set 1 gain	<i>Real</i>	0.01...100.00	-	100 = 1
40.33	Set 1 integration time	<i>Real</i>	0.0...9999.0	s	10 = 1 s
40.34	Set 1 derivation time	<i>Real</i>	0.000...10.000	s	1000 = 1 s
40.35	Set 1 derivation filter time	<i>Real</i>	0.0...10.0	s	10 = 1 s
40.36	Set 1 output min	<i>Real</i>	-200000.00...200000.00	-	10 = 1
40.37	Set 1 output max	<i>Real</i>	-200000.00...200000.00	-	10 = 1
40.38	Set 1 output freeze	<i>Binary src</i>	-	-	1 = 1
40.39	Set 1 deadband range	<i>Real</i>	0.0...3600.0	-	10 = 1
40.40	Set 1 deadband delay	<i>Real</i>	0.0...200000.0	s	10 = 1 s
40.43	Set 1 sleep level	<i>Real</i>	0.0...200000.0	-	10 = 1
40.44	Set 1 sleep delay	<i>Real</i>	0.0...3600.0	s	10 = 1 s
40.45	Set 1 sleep boost time	<i>Real</i>	0.0...3600.0	s	10 = 1 s
40.46	Set 1 sleep boost step	<i>Real</i>	0.0...200000.0	PID customer units	10 = 1 PID customer unit
40.47	Set 1 wake-up deviation	<i>Real</i>	-20000000...200000.00	PID customer units	100 = 1 PID customer unit
40.48	Set 1 wake-up delay	<i>Real</i>	0.00...60.00	s	100 = 1 s
40.49	Set 1 tracking mode	<i>Binary src</i>	-	-	1 = 1
40.50	Set 1 tracking ref selection	<i>Analog src</i>	-	-	1 = 1
40.51	Set 1 trim mode	<i>List</i>	0...3	-	1 = 1
40.52	Set 1 trim selection	<i>List</i>	1...3	-	1 = 1
40.53	Set 1 trimmed ref pointer	<i>Analog src</i>	-	-	1 = 1
40.54	Set 1 trim mix	<i>Real</i>	0.000...1.000	-	1 = 1
40.55	Set 1 trim adjust	<i>Real</i>	-100.000...100.000	-	1 = 1
40.56	Set 1 trim source	<i>List</i>	1...2	-	1 = 1
40.57	PID set1/set2 selection	<i>Binary src</i>	0...7, 18...23	-	1 = 1
40.58	Set 1 increase prevention	<i>Binary src</i>	0...3	-	1 = 1
40.59	Set 1 decrease prevention	<i>Binary src</i>	0...3	-	1 = 1

374 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
40.60	Set 1 PID activation source	<i>Binary src</i>	-	-	1 = 1
40.61	Setpoint scaling actual	<i>Real</i>	--200000.00...200000.00	-	100 = 1
40.62	PID internal setpoint actual	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
40.65	Trim auto connection	TBD			
40.79	Set 1 units	<i>List</i>	0...31	Depends on selection	-
40.80	Set 1 PID output min source	<i>Analog src</i>	-	-	1 = 1
40.81	Set 1 PID output max source	<i>Analog src</i>	-	-	1 = 1
40.89	Set 1 setpoint multiplier	<i>Real</i>	-200000.00...200000.00	-	-
40.90	Set 1 feedback multiplier	<i>Real</i>	-200000.00...200000.00	-	100 = 1
40.91	Feedback data storage	<i>Real</i>	-327.68...327.67	-	100 = 1
40.92	Setpoint data storage	<i>Real</i>	-327.68...327.67	-	100 = 1
40.96	Process PID output%	<i>Real</i>	-100.00...100.00	%	-
40.97	Process PID feedback%	<i>Real</i>	-100.00...100.00	%	-
40.98	Process PID setpoint%	<i>Real</i>	-100.00...100.00	%	-
40.99	Process PID deviation%	<i>Real</i>	-100.00...100.00	%	-
41 Process PID set 2					
41.08	Set 2 feedback 1 source	<i>Analog src</i>	-	-	1 = 1
41.09	Set 2 feedback 2 source	<i>Analog src</i>	-	-	1 = 1
41.10	Set 2 feedback function	<i>List</i>	0...11	-	1 = 1
41.11	Set 2 feedback filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
41.14	Set 2 setpoint scaling	<i>Real</i>	-200000.00 ... 200000.00	-	100=1
41.15	Set 2 output scaling	<i>Real</i>	-200000.00 ... 200000.00	-	100=1
41.16	Set 2 setpoint 1 source	<i>Analog src</i>	-	-	1 = 1
41.17	Set 2 setpoint 2 source	<i>Analog src</i>	-	-	1 = 1
41.18	Set 2 setpoint function	<i>List</i>	0...11	-	1 = 1
41.19	Set 2 internal setpoint sel1	<i>Binary src</i>	-	-	1 = 1
41.20	Set 2 internal setpoint sel2	<i>Binary src</i>	-	-	1 = 1
41.21	Set 2 internal setpoint 1	<i>Real</i>	-200000.00 ... 200000.00	PID customer unit	100 = 1 PID customer unit
41.22	Set 2 internal setpoint 2	<i>Real</i>	-200000.00 ... 200000.00	PID customer units	100 = 1 PID customer unit

No.	Name	Type	Range	Unit	FbEq32
41.23	Set 2 internal setpoint 3	<i>Real</i>	-200000.00 ... 200000.00	PID customer units	100 = 1 PID customer unit
41.24	Set 2 internal setpoint 0	<i>Real</i>	-200000.00 ... 200000.00	PID customer units	100 = 1 PID customer unit
41.26	Set 2 setpoint min	<i>Real</i>	-200000.00 ... 200000.00	-	100 = 1
41.27	Set 2 setpoint max	<i>Real</i>	-200000.00 ... 200000.00	-	100 = 1
41.28	Set 2 setpoint increase time	<i>Real</i>	0.0...1800.0	s	10 = 1 s
41.29	Set 2 setpoint decrease time	<i>Real</i>	0.0...1800.0	s	10 = 1 s
41.30	Set 2 setpoint freeze enable	<i>Binary src</i>	-	-	1 = 1
41.31	Set 2 deviation inversion	<i>Binary src</i>	-	-	1 = 1
41.32	Set 2 gain	<i>Real</i>	0.01...100.00	-	100 = 1
41.33	Set 2 integration time	<i>Real</i>	0.0...9999.0	s	10 = 1 s
41.34	Set 2 derivation time	<i>Real</i>	0.000...10.000	s	1000 = 1 s
41.35	Set 2 derivation filter time	<i>Real</i>	0.0...10.0	s	10 = 1 s
41.36	Set 2 output min	<i>Real</i>	-200000.00 ... 200000.00	-	10 = 1
41.37	Set 2 output max	<i>Real</i>	-200000.00 ... 200000.00	-	10 = 1
41.38	Set 2 output freeze	<i>Binary src</i>	-	-	1 = 1
41.39	Set 2 deadband range	<i>Real</i>	0.0...3600.0	-	10 = 1
41.40	Set 2 deadband delay	<i>Real</i>	0.0...200000.0	s	10 = 1 s
41.43	Set 2 sleep level	<i>Real</i>	0.0...200000.0	-	10 = 1
41.44	Set 2 sleep delay	<i>Real</i>	0.0...3600.0	s	10 = 1 s
41.45	Set 2 sleep boost time	<i>Real</i>	0.0...3600.0	s	10 = 1 s
41.46	Set 2 sleep boost step	<i>Real</i>	0.0...200000.0	PID customer units	10 = 1 PID customer unit
41.47	Set 2 wake-up deviation	<i>Real</i>	-200000.00 ... 200000.00	PID customer units	100 = 1 PID customer unit
41.48	Set 2 wake-up delay	<i>Real</i>	0.00...60.00	s	100 = 1 s
41.49	Set 2 tracking mode	<i>Binary src</i>	-	-	1 = 1
41.50	Set 2 tracking ref selection	<i>Analog src</i>	-	-	1 = 1
41.51	Set 2 trim mode	<i>List</i>	0...3	-	1 = 1
41.52	Set 2 trim selection	<i>List</i>	1...3	-	1 = 1
41.53	Set 2 trimmed ref pointer	<i>Analog src</i>	-	-	1 = 1
41.54	Set 2 trim mix	<i>Real</i>	0.000...1.000	-	1 = 1
41.55	Set 2 trim adjust	<i>Real</i>	-100.000...100.000	-	1 = 1
41.56	Set 2 trim source	<i>List</i>	1...2	-	1 = 1

376 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
41.58	Set 2 increase prevention	<i>Binary src</i>	-	-	1 = 1
41.59	Set 2 decrease prevention	<i>Binary src</i>	-	-	1 = 1
41.60	Set 2 PID activation source	<i>Binary src</i>	-	-	1 = 1
41.79	Set 2 units	<i>Real</i>	0...31	Depends on selection	-
41.80	Set 1 PID output min source	<i>Analog src</i>	-	-	1 = 1
41.81	Set 1 PID output max source	<i>Analog src</i>	-	-	1 = 1
41.89	Set 2 setpoint multiplier	<i>Real</i>	-100000.00...100000.00	-	100 = 1
41.90	Set 2 feedback multiplier	<i>Real</i>	-100000.00...100000.00	-	100 = 1
43 Brake chopper					
43.01	Braking resistor temperature	<i>Real</i>	0.0...120.0	%	10 = 1%
43.06	Brake chopper enable	<i>List</i>	0...3	-	1 = 1
43.07	Brake chopper runtime enable	<i>Binary src</i>	0...1	-	1 = 1
43.08	Brake resistor thermal tc	<i>Real</i>	0...10000	s	1 = 1 s
43.09	Brake resistor Pmax cont	<i>Real</i>	0.00...10000.00	kW	100 = 1 kW
43.10	Brake resistance	<i>Real</i>	0.0...1000.0	Ohm	10 = 1 ohm
43.11	Brake resistor fault limit	<i>Real</i>	0...150	%	1 = 1%
43.12	Brake resistor warning limit	<i>Real</i>	0...150	%	1 = 1%
44 Mechanical brake control					
44.01	Brake control status	<i>PB</i>	0b0000...0b1111	-	1 = 1
44.06	Brake control enable	<i>Binary src</i>	-	-	1 = 1
44.08	Brake open delay	<i>Real</i>	0.00...5.00	s	100 = 1 s
44.13	Brake close delay	<i>Real</i>	0.00...60.00	s	100 = 1 s
44.14	Brake close level	<i>Real</i>	0.00...1000.00	rpm	100 = 1 rpm
45 Energy efficiency					
45.01	Saved GW hours	<i>Real</i>	0...65535	GWh	1 = 1 GWh
45.02	Saved MW hours	<i>Real</i>	0...999	MWh	1 = 1 MWh
45.03	Saved kW hours	<i>Real</i>	0.0...999.9	kWh	10 = 1 kWh
45.04	Saved energy	<i>Real</i>	0.0...214748364.0	kWh	10 = 1 kWh
45.05	Saved money x1000	<i>Real</i>	0...4294967295 thousands	INR	1 = 1
45.06	Saved money	<i>Real</i>	0.00...999.99	INR	100 = 1
45.07	Saved amount	<i>Real</i>	0.00...21474830.00	INR	100 = 1
45.08	CO2 reduction in kilotons	<i>Real</i>	0...65535	metric kiloton	1 = 1 metric kiloton
45.09	CO2 reduction in tons	<i>Real</i>	0.0...999.9	metric ton	10 = 1 metric ton

No.	Name	Type	Range	Unit	FbEq32
45.10	Total saved CO2	<i>Real</i>	0.0...214748300.0	metric ton	10 = 1 metric ton
45.11	Energy optimizer	<i>List</i>	0...1	-	1 = 1
45.12	Energy tariff 1	<i>Real</i>	0.000...4294966.296	INR	1000 = 1
45.13	Energy tariff 2	<i>Real</i>	0.000...4294966.296	INR	1000 = 1
45.14	Tariff selection	<i>Binary src</i>	-	-	1 = 1
45.17	Tariff currency unit	<i>List</i>	100, 101, 102	INR	1=1
45.18	CO2 conversion factor	<i>Real</i>	0.000...65.535	tn/ MWh	1000 = 1 tn/MWh
45.19	Comparison power	<i>Real</i>	0.00...10000000.00	kW	10 = 1 kW
45.21	Energy calculations reset	<i>List</i>	0...1	-	1 = 1
45.24	Hourly peak power value	<i>Real</i>	-3000.00 ... 3000.00	kW	1 = 1 kW
45.25	Hourly peak power time	<i>Real</i>			N/A
45.26	Hourly total energy (resettable)	<i>Real</i>	-3000.00 ... 3000.00	kWh	1 = 1 kWh
45.27	Daily peak power value (resettable)	<i>Real</i>	-3000.00 ... 3000.00	kW	1 = 1 kW
45.28	Daily peak power time	<i>Real</i>			N/A
45.29	Daily total energy (resettable)	<i>Real</i>	-30000.00 ... 30000.00	kWh	1 = 1 kWh
45.30	Last day total energy	<i>Real</i>	-30000.00 ... 30000.00	kWh	1 = 1 kWh
45.31	Monthly peak power value (resettable)	<i>Real</i>	-3000.00 ... 3000.00	kW	1 = 1 kW
45.32	Monthly peak power date	<i>Real</i>	1/1/1980...6/5/2159		N/A
45.33	Monthly peak power time	<i>Real</i>			N/A
45.34	Monthly total energy (resettable)	<i>Real</i>	-1000000.00 ... 1000000.00	kWh	1 = 1 kWh
45.35	Last month total energy	<i>Real</i>	-1000000.00 ... 1000000.00	kWh	1 = 1 kWh
45.36	Lifetime peak power value	<i>Real</i>	-3000.00 ... 3000.00	kW	1 = 1 kW
45.37	Lifetime peak power date	<i>Real</i>	1/1/1980...6/5/2159		N/A
45.38	Lifetime peak power time	<i>Real</i>			N/A
46 Monitoring/scaling settings					
46.01	Speed scaling	<i>Real</i>	0.00...30000.00	rpm	100 = 1 rpm
46.02	Frequency scaling	<i>Real</i>	0.10...1000.00	Hz	100 = 1 Hz
46.03	Torque scaling	<i>Real</i>	0.1...1000.0	%	10 = 1%
46.04	Power scaling	<i>Real</i>	0.10...30000.00 kW or 0.10...40200.00 hp	kW or hp	10 = 1 unit
46.05	Current scaling	<i>Real</i>	0...30000	A	1 = 1 A
46.06	Speed ref zero scaling	<i>Real</i>	0.00 ... 30000.00	rpm	100 = 1 rpm
46.07	Frequency ref zero scaling	<i>Real</i>	0.00 ... 1000.00	Hz	100 = 1 Hz
46.11	Filter time motor speed	<i>Real</i>	2...20000	ms	1 = 1 ms
46.12	Filter time output frequency	<i>Real</i>	2...20000	ms	1 = 1 ms
46.13	Filter time motor torque	<i>Real</i>	2...20000	ms	1 = 1 ms
46.14	Filter time power	<i>Real</i>	2...20000	ms	1 = 1 ms

378 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
46.21	At speed hysteresis	<i>Real</i>	0.00...30000.00	rpm	100 = 1 rpm
46.22	At frequency hysteresis	<i>Real</i>	0.00...1000.00	Hz	100 = 1 Hz
46.31	Above speed limit	<i>Real</i>	0.00...30000.00	rpm	100 = 1 rpm
46.32	Above frequency limit	<i>Real</i>	0.00...1000.00	Hz	100 = 1 Hz
46.33	Above torque limit	<i>Real</i>	0.0...1600.0	%	10 = 1%
46.41	kWh pulse scaling	<i>Real</i>	0.001...1000.000	kWh	1000 = 1 kWh
46.43	Power decimals	<i>Real</i>	0...3	-	1 = 1
46.44	Current decimals	<i>Real</i>	0...3	-	1 = 1
47 Data storage					
47.01	Data storage 1 real32	<i>Real</i>	-2147483.000... 2147483.000	-	1000 = 1
47.02	Data storage 2 real32	<i>Real</i>	-2147483.000... 2147483.000	-	1000 = 1
47.03	Data storage 3 real32	<i>Real</i>	-2147483.000... 2147483.000	-	1000 = 1
47.04	Data storage 4 real32	<i>Real</i>	-2147483.000... 2147483.000	-	1000 = 1
47.11	Data storage 1 int32	<i>Real</i>	-2147483648... 2147483647	-	1 = 1
47.12	Data storage 2 int32	<i>Real</i>	-2147483648... 2147483647	-	1 = 1
47.13	Data storage 3 int32	<i>Real</i>	-2147483648... 2147483647	-	1 = 1
47.14	Data storage 4 int32	<i>Real</i>	-2147483648... 2147483647	-	1 = 1
47.21	Data storage 1 int16	<i>Real</i>	-32768...32767	-	1 = 1
47.22	Data storage 2 int16	<i>Real</i>	-32768...32767	-	1 = 1
47.23	Data storage 3 int16	<i>Real</i>	-32768...32767	-	1 = 1
47.24	Data storage 4 int16	<i>Real</i>	-32768...32767	-	1 = 1
49 Panel port communication					
49.01	Node ID number	<i>Real</i>	1...32	-	1 = 1
49.03	Baud rate	<i>List</i>	1...5	-	1 = 1
49.04	Communication loss time	<i>Real</i>	0.3...3000.0	s	10 = 1 s
49.05	Communication loss action	<i>List</i>	0...3	-	1 = 1
49.06	Refresh settings	<i>List</i>	0...1	-	1 = 1
49.19	Basic panel home view 1	<i>List</i>	-	-	1 = 1
49.20	Basic panel home view 2	<i>List</i>	-	-	1 = 1
49.21	Basic panel home view 3	<i>List</i>	-	-	1 = 1
49.219	Basic panel home view 4	<i>List</i>	-	-	1 = 1
49.220	Basic panel home view 5	<i>List</i>	-	-	1 = 1
49.221	Basic panel home view 6	<i>List</i>	-	-	1 = 1
50 Fieldbus adapter (FBA)					
50.01	FBA A enable	<i>List</i>	0...1	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
50.02	FBAA comm loss func	List	0...5	-	1 = 1
50.03	FBAA comm loss t out	Real	0.3...6553.5	s	10 = 1 s
50.04	FBAA ref1 type	List	0... 5	-	1 = 1
50.05	FBAA ref2 type	List	0...2, 4, 5	-	1 = 1
50.06	FBAA SW sel	List	0...1	-	1 = 1
50.07	FBAA actual 1 type	List	0...5	-	1 = 1
50.08	FBAA actual 2 type	List	0...5	-	1 = 1
50.09	FBAA SW transparent source	Analog src	-	-	1 = 1
50.10	FBAA act1 transparent source	Analog src	-	-	1 = 1
50.11	FBAA act2 transparent source	Analog src	-	-	1 = 1
50.12	FBAA debug mode	List	0...1	-	1 = 1
50.13	FBAA control word	Data	0.0.0.0.0...FF.FF.FF.FF	-	1 = 1
50.14	FBAA reference 1	Real	-2147483648... 2147483647	-	1 = 1
50.15	FBAA reference 2	Real	-2147483648... 2147483647	-	1 = 1
50.16	FBAA status word	Data	0.0.0.0.0...FF.FF.FF.FF	-	1 = 1
50.17	FBAA actual value 1	Real	-2147483648... 2147483647	-	1 = 1
50.18	FBAA actual value 2	Real	-2147483648... 2147483647	-	1 = 1
51 FBAA settings					
51.01	FBAA type	List	0, 1, 32, 37, 128, 132, 135, 136, 485, 101, 47808	-	1 = 1
51.02	FBAA Par2	Real	0...65535	-	1 = 1
...	
51.26	FBAA Par26	Real	0...65535	-	1 = 1
51.27	FBAA par refresh	List	0...1	-	1 = 1
51.28	FBAA par table ver	Data	0x0000...0xffff	-	1 = 1
51.29	FBAA drive type code	Real	0...65535	-	1 = 1
51.30	FBAA mapping file ver	Real	0...65535	-	1 = 1
51.31	D2FBAA comm status	List	0...6	-	1 = 1
51.32	FBAA comm SW ver	Data	0x0000...0xffff	-	1 = 1
51.33	FBAA appl SW ver	Data	0x0000...0xffff	-	1 = 1
52 FBAA data in					
52.01	FBAA data in1	List	0...6, 11...16, 24	-	1 = 1
...	
52.12	FBAA data in12	List	0...6, 11...16, 24	-	1 = 1

380 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
53 FBA A data out					
53.01	FBA A data out1	<i>List</i>	0...3, 11...13, 21	-	1 = 1
...	
53.12	FBA A data out12	<i>List</i>	0...3, 11...13, 21	-	1 = 1
58 Embedded fieldbus					
58.01	Protocol enable	<i>List</i>	0...1	-	1 = 1
58.02	Protocol ID	<i>Real</i>	0000h...FFFFh	-	1 = 1
58.03	Node address	<i>Real</i>	0...255	-	1 = 1
58.04	Baud rate	<i>List</i>	0...7	-	1 = 1
58.05	Parity	<i>List</i>	0...3	-	1 = 1
58.06	Communication control	<i>List</i>	0...2	-	1 = 1
58.07	Communication diagnostics	<i>PB</i>	0000h...FFFFh	-	1 = 1
58.08	Received packets	<i>Real</i>	0...4294967295	-	1 = 1
58.09	Transmitted packets	<i>Real</i>	0...4294967295	-	1 = 1
58.10	All packets	<i>Real</i>	0...4294967295	-	1 = 1
58.11	UART errors	<i>Real</i>	0...4294967295	-	1 = 1
58.12	CRC errors	<i>Real</i>	0...4294967295	-	1 = 1
58.14	Communication loss action	<i>List</i>	0...5	-	1 = 1
58.15	Communication loss mode	<i>List</i>	1...2	-	1 = 1
58.16	Communication loss time	<i>Real</i>	0.0...6000.0	s	10 = 1 s
58.17	Transmit delay	<i>Real</i>	0...65535	ms	1 = 1 ms
58.18	EFB control word	<i>PB</i>	0000h...FFFFh	-	1 = 1
58.19	EFB status word	<i>PB</i>	0000h...FFFFh	-	1 = 1
58.25	Control profile	<i>List</i>	0, 5	-	1 = 1
58.26	EFB ref1 type	<i>List</i>	0...5	-	1 = 1
58.27	EFB ref2 type	<i>List</i>	0...5	-	1 = 1
58.28	EFB act1 type	<i>List</i>	0...5	-	1 = 1
58.29	EFB act2 type	<i>List</i>	0...5	-	1 = 1
58.31	EFB act1 transparent source	<i>Analog src</i>	-	-	1 = 1
58.32	EFB act2 transparent source	<i>Analog src</i>	-	-	1 = 1
58.33	Addressing mode	<i>List</i>	0...2	-	1 = 1
58.34	Word order	<i>List</i>	0...1	-	1 = 1
58.101	Data I/O 1	<i>Analog src</i>	-	-	1 = 1
58.102	Data I/O 2	<i>Analog src</i>	-	-	1 = 1
58.103	Data I/O 3	<i>Analog src</i>	-	-	1 = 1
58.104	Data I/O 4	<i>Analog src</i>	-	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
58.105	Data I/O 5	<i>Analog src</i>	-	-	1 = 1
58.106	Data I/O 6	<i>Analog src</i>	-	-	1 = 1
58.107	Data I/O 7	<i>Analog src</i>	-	-	1 = 1
...	
58.114	Data I/O 14	<i>Analog src</i>	-	-	1 = 1
70 Override					
70.01	Override status	<i>PB</i>	0b0000...0b1111	-	1 = 1
70.02	Override enable	<i>List</i>	-	-	1 = 1
70.03	Override activation source	<i>List</i>	-	-	1 = 1
70.04	Override reference source	<i>List</i>	-	-	1 = 1
70.05	Override direction	<i>List</i>	-	-	1 = 1
70.06	Override frequency	<i>Real</i>	-500.0...500.0	Hz	100 = 1 Hz
70.07	Override speed	<i>Real</i>	-30000.0...30000.0	rpm	100 = 1 rpm
70.20	Override fault handling	<i>List</i>	0...1	-	1 = 1
70.21	Override auto reset trials	<i>Real</i>	0...60	-	1 = 1
70.22	Override auto reset time	<i>Real</i>	0.1...120.0	s	10 = 1
71 External PID1					
71.01	External PID act value	<i>Real</i>	-200000.00...200000.00	%	100 = 1 PID customer unit
71.02	Feedback act value	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
71.03	Setpoint act value	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
71.04	Deviation act value	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
71.06	PID status word	<i>PB</i>	0000h...FFFFh	-	1 = 1
71.07	PID operation mode	<i>List</i>	0...2	-	1 = 1
71.08	Feedback 1 source	<i>Analog src</i>	-	-	1 = 1
71.11	Feedback filter time	<i>Real</i>	0.000...30.000	s	1000 = 1 s
71.14	Setpoint scaling	<i>Real</i>	-200000.00...200000.00	-	100 = 1
71.15	Output scaling	<i>Real</i>	-200000.00...200000.00	-	100 = 1
71.16	Setpoint 1 source	<i>Analog src</i>	-	-	1 = 1
71.19	Internal setpoint sel1	<i>Binary src</i>	-	-	1 = 1
71.20	Internal setpoint sel2	<i>Binary src</i>	-	-	1 = 1

382 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
71.21	Internal setpoint 1	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
71.22	Internal setpoint 2	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
71.23	Internal setpoint 3	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
71.26	Setpoint min	<i>Real</i>	-200000.00...200000.00	-	100 = 1
71.27	Setpoint max	<i>Real</i>	-200000.00...200000.00	-	100 = 1
71.31	Deviation inversion	<i>Binary src</i>	-	-	1 = 1
71.32	Gain	<i>Real</i>	0.10...100.00	-	100 = 1
71.33	Integration time	<i>Real</i>	0.0...9999.0	s	10 = 1 s
71.34	Derivation time	<i>Real</i>	0.000...10.000	s	1000 = 1 s
71.35	Derivation filter time	<i>Real</i>	0.0...10.0	s	1000 = 1 s
71.36	Output min	<i>Real</i>	-200000.00...200000.00	-	10 = 1
71.37	Output max	<i>Real</i>	-200000.00...200000.00	-	10 = 1
71.38	Output freeze enable	<i>Binary src</i>	-	-	1 = 1
71.39	Deadband range	<i>Real</i>	0.0...200000.0	-	10 = 1
71.40	Deadband delay	<i>Real</i>	0.0...3600.0	s	1000 = 1 s
71.58	Increase prevention	<i>Binary src</i>	-	-	1 = 1
71.59	Decrease prevention	<i>Binary src</i>	-	-	1 = 1
71.62	Internal setpoint actual	<i>Real</i>	-200000.00...200000.00	PID customer units	100 = 1 PID customer unit
71.79	External PID units	<i>List</i>	0...31	Depends on selection	-
76 PFC configuration					
76.01	PFC status	<i>PB</i>	0b0000...0b1111	-	1 = 1
76.02	PFC system status	<i>PB</i>	0...9, 100...103, 200...202, 300...302, 400, 500, 600, 700, 800, 801	-	1 = 1
76.11	Pump/fan status 1	<i>PB</i>	0b0000...0b1111	-	1 = 1
76.12	Pump/fan status 2	<i>PB</i>	0b0000...0b1111	-	1 = 1
76.13	Pump/fan status 3	<i>PB</i>	0b0000...0b1111	-	1 = 1
76.14	Pump/fan status 4	<i>PB</i>	0b0000...0b1111	-	1 = 1
76.21	PFC configuration	<i>List</i>	0, 2...3	-	1 = 1
76.25	Number of motors	<i>Real</i>	1...4	-	1 = 1
76.26	Min number of motors allowed	<i>Real</i>	0...4	-	1 = 1
76.27	Max number of motors allowed	<i>Real</i>	1...4	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
76.30	Start point 1	<i>Real</i>	0...32767	rpm/Hz	1 = 1 unit
76.31	Start point 2	<i>Real</i>	0...32767	rpm/Hz	1 = 1 unit
76.32	Start point 3	<i>Real</i>	0...32767	rpm/Hz	1 = 1 unit
76.41	Stop point 1	<i>Real</i>	0...32767	rpm/Hz	1 = 1 unit
76.42	Stop point 2	<i>Real</i>	0...32767	rpm/Hz	1 = 1 unit
76.43	Stop point 3	<i>Real</i>	0...32767	rpm/Hz	1 = 1 unit
76.55	Start delay	<i>Real</i>	0.00...12600.00	s	100 = 1 s
76.56	Stop delay	<i>Real</i>	0.00...12600.00	s	100 = 1 s
76.57	PFC speed hold on	<i>Real</i>	0.00...1000.00	s	100 = 1 s
76.58	PFC speed hold off	<i>Real</i>	0.00...1000.00	s	100 = 1 s
76.59	PFC contactor delay	<i>Real</i>	0.20...600.00	s	100 = 1 s
76.60	PFC ramp acceleration time	<i>Real</i>	0.00...1800.00	s	100 = 1 s
76.61	PFC ramp deceleration time	<i>Real</i>	0.00...1800.00	s	100 = 1 s
76.70	PFC autochange	<i>List</i>	0...13	-	1 = 1
76.71	PFC autochange interval	<i>Real</i>	0.00...42949672.95	h	100 = 1 h
76.72	Maximum wear imbalance	<i>Real</i>	0.00...1000000.00	h	100 = 1 h
76.73	Autochange level	<i>Real</i>	0.0...300.0	%	10 = 1%
76.74	Autochange auxiliary PFC	<i>List</i>	0...1	-	1 = 1
76.81	PFC interlock 1	<i>List</i>	0...10	-	1 = 1
76.82	PFC interlock 2	<i>List</i>	0...10	-	1 = 1
76.83	PFC interlock 3	<i>List</i>	0...10	-	1 = 1
76.84	PFC interlock 4	<i>List</i>	0...10	-	1 = 1
76.95	Regulator bypass control	<i>Binary src</i>	-	-	-
77 PFC maintenance and monitoring					
77.10	PFC runtime change	<i>List</i>	0...5	-	1 = 1
77.11	Pump/fan 1 running time	<i>Real</i>	0.00...42949672.95	h	100 = 1 h
77.12	Pump/fan 2 running time	<i>Real</i>	0.00...42949672.95	h	100 = 1 h
77.13	Pump/fan 3 running time	<i>Real</i>	0.00...42949672.95	h	100 = 1 h
77.14	Pump/fan 4 running time	<i>Real</i>	0.00...42949672.95	h	100 = 1 h
90 Feedback selection					
90.03	Load speed	<i>Real</i>	-32768.00...32768.00	rpm	100 = 1 rpm
90.52	LoadSpeed filter time	<i>Real</i>	0...10000	ms	1 = 1 ms
90.61	Gear numerator	<i>Real</i>	-2147483648... 2147483648	-	1 = 1
90.62	Gear denominator	<i>Real</i>	-2147483648... 2147483648	-	1 = 1
90.99	Load speed unit	<i>List</i>	-	rpm	1 = 1
95 HW configuration					
95.01	Supply voltage	<i>List</i>	0, 2	-	1 = 1
95.02	Adaptive voltage limits	<i>List</i>	0...1	-	1 = 1
95.03	Estimated AC supply voltage	<i>Real</i>	0...65535	V	1 = 1 V

384 Additional parameter data

No.	Name	Type	Range	Unit	FbEq32
95.04	Control board supply	List	0...1	-	1 = 1
95.15	Special HW settings	PB	0b0000...0b1111	-	1 = 1
95.20	HW options word 1	PB	0b0000...0b1111	-	1 = 1
95.21	HW options word 2	PB	0b0000...0b1111	-	1 = 1
95.200	Cooling fan mode	List	0, 1	-	1 = 1
96 System					
96.01	Language	List	0, 1033, 2052	-	1 = 1
96.02	Pass code	Data	-	-	1 = 1
96.03	Access level status	PB	0b0000...0b1111	-	1 = 1
96.04	Macro select	List	-	-	1 = 1
96.05	Macro active	List	-	-	1 = 1
96.06	Parameter restore	List	0, 2, 8, 32, 62, 512, 1024, 34560	-	1 = 1
96.07	Parameter save manually	List	0, 1	-	1 = 1
96.08	Control board boot	List	0, 1	-	1 = 1
96.10	User set status	List	0...11	-	1 = 1
96.11	User set save/load	List	0...5, 18...21	-	1 = 1
96.12	User set I/O mode in1	Binary src	-	-	1=1
96.13	User set I/O mode in2	Binary src	-	-	1=1
96.16	Unit selection	PB	0b0000...0b1111	-	1 = 1
96.20	Time sync primary source	List	-	-	1 = 1
96.51	Clear fault and event logger	Real	0...1	-	1 = 1
<i>(Parameters 96.100...96.102 only visible when enabled by parameter 96.02)</i>					
96.78	550 compatibility mode	List	0...1	-	1 = 1
96.100	Change user pass code	Data	10000000...99999999	-	1 = 1
96.101	Confirm user pass code	Data	10000000...99999999	-	1 = 1
96.102	User lock functionality	PB	0000h...FFFFh	-	1 = 1
97 Motor control					
97.01	Switching frequency reference	List	2, 4, 8, 12	kHz	1 = 1 kHz
97.02	Minimum switching frequency	List	1.5, 2, 4, 8, 12	kHz	1 = 1 kHz
97.03	Slip gain	Real	0...200	%	1 = 1%
97.04	Voltage reserve	Real	-4...50	%	1 = 1%
97.05	Flux braking	List	0...2	-	1 = 1
97.08	Optimizer minimum torque	Real	0.0...1600.0	%	1 = 1
97.13	IR compensation	Real	0.00...50.00	%	100 = 1%
97.20	U/F ratio	List	0...20	-	1 = 1
97.49	Slip gain for scalar	Real	0...200	%	1 = 1%
97.94	IR comp max frequency	Real	1.0...200.0	%	10 = 1%
98 User motor parameters					
98.01	User motor model mode	List	0...1	-	1 = 1

No.	Name	Type	Range	Unit	FbEq32
98.02	Rs user	<i>Real</i>	0.0000...0.50000	p.u.	100000 = 1 p.u.
98.03	Rr user	<i>Real</i>	0.0000...0.50000	p.u.	100000 = 1 p.u.
98.04	Lm user	<i>Real</i>	0.00000...10.00000	p.u.	100000 = 1 p.u.
98.05	SigmaL user	<i>Real</i>	0.00000...1.00000	p.u.	100000 = 1 p.u.
98.09	Rs user SI	<i>Real</i>	0.00000...100.00000	ohm	100000 = 1 p.u.
98.10	Rr user SI	<i>Real</i>	0.00000...100.00000	ohm	100000 = 1 p.u.
98.11	Lm user SI	<i>Real</i>	0.00...100000.00	mH	100 = 1 mH
98.12	SigmaL user SI	<i>Real</i>	0.00...100000.00	mH	100 = 1 mH
99 Motor data					
99.03	Motor type	<i>List</i>	0	-	1 = 1
99.04	Motor control mode	<i>List</i>	0...1	-	1 = 1
99.06	Motor nominal current	<i>Real</i>	0.0...32767.0	A	10 = 1 A
99.07	Motor nominal voltage	<i>Real</i>	0.0...32767.0	V	10 = 1 V
99.08	Motor nominal frequency	<i>Real</i>	0.00 ... 500.00	Hz	100 = 1 Hz
99.09	Motor nominal speed	<i>Real</i>	0 ... 30000	rpm	1 = 1 rpm
99.10	Motor nominal power	<i>Real</i>	0.00...100000.00 kW or 0.00 ... 13404.83 hp	kW or hp	100 = 1 unit
99.11	Motor nominal cos ?	<i>Real</i>	0.00 ... 1.00	-	100 = 1
99.12	Motor nominal torque	<i>Real</i>	0.000...4000000.000 N·m or 0.000...2950248.597 lb·ft	N·m or lb·ft	1000 = 1 unit
99.13	ID run requested	<i>List</i>	0...3, 6, 7	-	1 = 1
99.14	Last ID run performed	<i>List</i>	0...3, 6	-	1 = 1
99.15	Motor polepairs calculated	<i>Real</i>	0...1000	-	1 = 1
99.16	Motor phase order	<i>List</i>	0...1	-	1 = 1



Fault tracing

What this chapter contains

The chapter lists the warning and fault messages including possible causes and corrective actions. The causes of most warnings and faults can be identified and corrected using the information in this chapter. If not, contact an ABB service representative. If you have a possibility to use the Drive composer PC tool, send the Support package created by the Drive composer to the ABB service representative.

Warnings and faults are listed below in separate tables. Each table is sorted by warning/fault code.

Safety



WARNING! Only qualified electricians are allowed to service the drive. Read the instructions in chapter *Safety instructions* at the beginning of the *Hardware manual* of the drive before working on the drive.

Indications

■ Warnings and faults

Warnings and faults indicate an abnormal drive status. The codes of active warnings and faults are displayed on the control panel of the drive as well as in the Drive composer PC tool with warning and fault names. Only the codes of warnings and faults are available over fieldbus.

Warnings do not need to be reset; they stop showing when the cause of the warning ceases. Warnings do not latch and the drive will continue to operate the motor.

Faults latch inside the drive and cause the drive to trip, and the motor stops. After the cause of a fault has been removed, the fault can be reset from a selectable source (parameter [31.11 Fault reset selection](#)) such as the control panel, Drive composer PC tool, the digital inputs of the drive, or fieldbus. Resetting the fault creates an event [64FF Fault reset](#). After the reset, the drive can be restarted.

Note that some faults require a reboot of the control unit either by switching the power off and on, or using parameter [96.08 Control board boot](#) – this is mentioned in the fault listing wherever appropriate.

■ Pure events

In addition to warnings and faults, there are pure events that are only recorded in the event log of the drive. The codes of these events are included in the [Warning messages](#) table on page [\(390\)](#).

■ Editable messages

For external events, the action (fault or warning), name and the message text can be edited. To specify external events, use parameter [31 Fault functions](#).

Warning/fault history

■ Event log

All indications are stored in the event log with a time stamp and other information. The event log stores information on

- the last 8 fault recordings, that is, faults that tripped the drive or fault resets
- the last 10 warnings or pure events that occurred.

See section [Viewing warning/fault information](#) on page [388](#).







Auxiliary codes

Some events generate an auxiliary code that often helps in pinpointing the problem. On the control panel, the auxiliary code is stored as part of the details of the event; in the Drive composer PC tool, the auxiliary code is shown in the event listing.

■ Viewing warning/fault information

The drive is able to store a list of the active faults actually causing the drive to trip at the present time. The drive also stores a list of faults and warnings that have previously occurred.

For active faults and warnings, see

- **Menu**  - **Diagnostics**  - **Active faults**  0
- **Menu**  - **Diagnostics**  - **Active warnings**  0
- parameters in group [04 Warnings and faults](#) (page [167](#)).

For previously occurred faults, see

- **Menu**  - **Diagnostics**  - **Fault history** 
- parameters in group [04 Warnings and faults](#) (page [167](#)).

The event log can also be accessed (and reset) using the Drive composer PC tool. See *Drive composer PC tool user's manual* (3AUA0000094606 [English]).

Warning messages

Note: The list also contains events that only appear in the Event log.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
64FF	Fault reset	A fault has been reset from the panel, Drive composer PC tool, fieldbus or I/O.	Event. Informative only.
A2B1	Overcurrent	Output current has exceeded internal fault limit. In addition to an actual overcurrent situation, this warning may also be caused by an earth fault or supply phase loss.	<p>Check motor load.</p> <p>Check acceleration times in parameter group 23 Speed reference ramp (speed control), 26 Torque reference chain (torque control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling, 46.02 Frequency scaling and 46.03 Torque scaling.</p> <p>Check motor and motor cable (including phasing and delta/star connection). Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. See chapter <i>Electrical installation</i>, section <i>Checking the insulation of the assembly</i> in the <i>Hardware manual</i> of the drive.</p> <p>Check there are no contactors opening and closing in motor cable.</p> <p>Check that the start-up data in parameter group 99 Motor data corresponds to the motor rating plate.</p> <p>Check that there are no power factor correction capacitors or surge absorbers in motor cable.</p>
A2B3	Earth leakage	Drive has detected load unbalance typically due to earth fault in motor or motor cable.	<p>Check there are no power factor correction capacitors or surge absorbers in motor cable.</p> <p>Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. See chapter <i>Electrical installation</i>, section <i>Checking the insulation of the assembly</i> in the <i>Hardware manual</i> of the drive. If an earth fault is found, fix or change the motor cable and/or motor. If no earth fault can be detected, contact your local ABB representative.</p>

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A2B4	Short circuit	Short-circuit in motor cable(s) or motor.	Check motor and motor cable for cabling errors. Check motor and motor cable (including phasing and delta/star connection). Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. See chapter <i>Electrical installation</i> , section <i>Checking the insulation of the assembly</i> in the <i>Hardware manual</i> of the drive. Check there are no power factor correction capacitors or surge absorbers in motor cable.
A2BA	IGBT overload	Excessive IGBT junction to case temperature. This warning protects the IGBT(s) and can be activated by a short circuit in the motor cable.	Check motor cable. Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A3A1	DC link overvoltage	Intermediate circuit DC voltage too high (when the drive is stopped).	Check the supply voltage setting (parameter 95.01 Supply voltage). Note that the wrong setting of the parameter may cause the motor to rush uncontrollably, or may overload the brake chopper or resistor. Check the supply voltage. If the problem persists, contact your local ABB representative.
A3A2	DC link undervoltage	Intermediate circuit DC voltage too low (when the drive is stopped). See also section DC undervoltage (page 82).	
A3AA	DC not charged	The voltage of the intermediate DC circuit has not yet risen to operating level.	
A490	Incorrect temperature sensor setup	Sensor type mismatch	Check the settings of temperature source parameters 35.11 and 35.21 against 91.21 and 91.25 .
A491	External temperature 1 (Editable message text)	Measured temperature 1 has exceeded warning limit.	Check the value of parameter 35.02 Measured temperature 1 . Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.13 Temperature 1 warning limit .
A492	External temperature 2 (Editable message text)	Measured temperature 2 has exceeded warning limit.	Check the value of parameter 35.03 Measured temperature 2 . Check the cooling of the motor (or other equipment whose temperature is being measured). Check the value of 35.23 Temperature 2 warning limit .
A4A0	Control board temperature.	Control board temperature is excessive. 1 – Sensor fault.	Check the sensor and change the control board.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A4A1	IGBT overtemperature	Estimated drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A4A9	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40%/104 °F (frames R4...R8) or if it exceeds 50% /122 °F (frames R0...R8), ensure that load current does not exceed derated load capacity of drive. See chapter <i>Technical data</i> , section <i>Derating</i> in the <i>Hardware manual</i> of the drive. Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
A4B0	Excess temperature	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A4B1	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s).
A4F6	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
A580	PU communication	Communication errors between drive control unit and power unit.	Check connections between drive control unit and power unit and value of parameter 95.04 Control board supply .
A581	Fan	Cooling fan feedback missing.	Check the auxiliary code to identify the fan. Code 0 denotes main fan 1. Other codes (format XYZ): "X" specifies state code (1: ID run, 2: normal). "Y" = 0, "Z" specifies the index of the fan (1: Main fan 1, 2: Main fan 2, 3: Main fan 3). Check fan operation and connection. Replace fan if faulty.
A582	Auxiliary fan missing	An auxiliary cooling fan (connected to the fan connectors on the control board) is stuck or disconnected.	Check the auxiliary code. Check auxiliary fan(s) and connection(s). Replace faulty fan. Make sure the front cover of the drive is in place and tightened. If the commissioning of the drive requires that the cover is off, this warning will be generated even if the corresponding fault is defeated. See fault 5081 Auxiliary fan broken (page 405).
	0001	Auxiliary fan 1 missing.	
	0002	Auxiliary fan 2 missing.	

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A590	Drive HW initialization.	Drive hardware setup is initializing. 1 - Initializing HW settings for the first time.	See auxiliary code.
A591	Drive HW initialization	Initialization of the drive hardware.	Check the auxiliary code. See actions for each code below.
	0000	Drive hardware setup is initializing.	Wait for the setup to initialize.
	0001	Initializing HW settings for the first time.	Wait for the setup to initialize.
A5A0	Safe torque off Programmable warning: <i>31.22 STO indication run/stop</i>	Safe torque off function is active, ie safety circuit signal(s) connected to connector STO is lost.	Check safety circuit connections. For more information, chapter <i>The Safe torque off function</i> in the <i>Hardware manual</i> of the drive and description of parameter <i>31.22 STO indication run/stop</i> (page 259). Check the value of parameter <i>95.04 Control board supply</i> .
A5EA	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	Contact your local ABB representative.
A5EB	PU board powerfail	Power unit power supply failure.	Contact your local ABB representative.
A5ED	Measurement circuit ADC	Measurement circuit fault.	Contact your local ABB representative.
A5EE	Measurement circuit DFF	Measurement circuit fault.	Contact your local ABB representative.
A5EF	PU state feedback	State feedback from output phases does not match control signals.	Contact your local ABB representative.
A5F0	Charging feedback	Charging feedback signal missing.	Check the feedback signal coming from the charging system.
A5F1	Redundant measurement	Duplicated measurements are beyond limits.	Contact your local ABB representative.
A5F2	Overtemperature hw	Excessive hardware temperature.	Contact your local ABB representative.
A682	Flash erase speed	The flash memory (in the memory unit) has been erased too frequently, compromising the lifetime of the memory.	Avoid forcing unnecessary parameter saves by parameter <i>96.07 Parameter save manually</i> or cyclic parameter writes (such as user logger triggering through parameters). Check the auxiliary code (format XYYY YZZZ). "X" specifies the source of warning (1: generic flash erase supervision). "ZZZ" specifies the flash subsector number that generated the warning.
A684	Power fail saving	Power fail saving warning.	Contact your local ABB representative.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A6A4	Motor nominal value	The motor parameters are set incorrectly. The drive is not dimensioned correctly.	Check the auxiliary code. See actions for each code below.
		1 Slip frequency is too small.	
		2 Synchronous and nominal speeds differ too much.	Check the settings of the motor configuration parameters in groups 98 and 99. Check that the drive is sized correctly for the motor.
		3 Nominal speed is higher than synchronous speed with 1 pole pair.	
		4 Nominal current is outside limits	
		5 Nominal voltage is outside limits.	
		6 Nominal power is higher than apparent power.	
		7 Nominal power not consistent with nominal speed and torque.	
A6A5	No motor data	Parameters in group 99 have not been set.	Check that all the required parameters in group 99 have been set. Note: It is normal for this warning to appear during the start-up and continue until the motor data is entered.
A6A6	Voltage category unselected	The voltage category has not been defined.	Set voltage category in parameter 95.01 Supply voltage .
A6A7	System time not set	System time is not set.	
A6B0	User lock is open	The user lock is open, ie. user lock configuration parameters 96.100 .. 96.102 are visible.	Close the user lock by entering an invalid pass code in parameter 96.02 Pass code . See section User lock (page 96).
A6B1	User pass code not confirmed	A new user pass code has been entered in parameter 96.100 but not confirmed in 96.101 .	Confirm the new pass code by entering the same code in 96.101 . To cancel, close the user lock without confirming the new code. See section User lock (page 96).
A6D1	FBA A parameter conflict	The drive does not have a functionality requested by a PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) .

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A6E5	AI parametrization	The current/voltage hardware setting of an analog input does not correspond to parameter settings.	Check the event log for an auxiliary code. The code identifies the analog input whose settings are in conflict. Adjust either the hardware setting (on the drive control unit) or parameter 12.15/12.25 . Note: Control board reboot (either by cycling the power or through parameter 96.08 Control board boot) is required to validate any changes in the hardware settings.
A6E6	ULC configuration	User load curve configuration error.	Check the auxiliary code (format XXXX ZZZZ). "ZZZZ" indicates the problem (see actions for each code below).
	0000	Speed points inconsistent.	Check that each speed point (parameters 37.11...37.15) has a higher value than the previous point.
	0002	Underload point above overload point.	Check that each overload point (37.31...37.35) has a higher value than the corresponding underload point (37.21...37.25).
	0003	Overload point below underload point.	
AFFE	Override active	Override active warning.	Informative warning. See parameter 70.02 Override enable .
A780	Motor stall (Programmable warning: 31.24 Stall function)	Motor is operating in stall region.	Check motor load, drive ratings and fault function parameters.
A783	Motor overload	Motor current is too high.	Check for overloaded motor Adjust the parameters used for the motor overload function. (35.51...35.53 , 35.55 , 35.56)
A791	Brake resistor	Brake resistor fault.	Check brake resistor.
A792	Brake resistor wiring	Brake resistor short circuit or fault in brake chopper.	Check brake chopper and brake resistor connections.
A793	BR excess temperature	Brake resistor temperature has exceeded warning limit defined by parameter 43.12 Brake resistor warning limit .	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check warning limit setting, parameter 43.12 Brake resistor warning limit . Check that the resistor has been dimensioned correctly. Check that braking cycle meets allowed limits.
A794	BR data	Brake resistor data has not been given.	One or more of the resistor data settings (parameters 43.08...43.10) is incorrect. The parameter is specified by the auxiliary code.
	0000 0001	Resistance value too low.	Check value of 43.10 .

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
	0000 0002	Thermal time constant not given.	Check value of 43.08 .
	0000 0003	Maximum continuous power not given.	Check value of 43.09 .
A79C	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal warning limit.	<p>Let chopper cool down.</p> <p>Check for excessive ambient temperature.</p> <p>Check for cooling fan failure.</p> <p>Check for obstructions in the air flow.</p> <p>Check the dimensioning and cooling of the cabinet.</p> <p>Check resistor overload protection function settings (parameters 43.06...43.10).</p> <p>Check minimum allowed resistor value for the chopper being used.</p> <p>Check that braking cycle meets allowed limits.</p> <p>Check that drive supply AC voltage is not excessive.</p>
A7AB	Built in/Extension I/O configuration failure	The I/O built in/extension module is not connected to the device properly.	Make sure that the I/O built in/extension module is connected to the device.
A7AC	I/O Module internal error	Calibration data is not stored in the I/O module. Analog signals are not working with full accuracy.	Replace I/O module.
A7A1	Mechanical brake closing failed	Mechanical brake control warning.	<p>Check mechanical brake connection.</p> <p>Check mechanical brake settings in parameter group 44 Mechanical brake control.</p> <p>Check that acknowledgment signal matches the actual status of the brake.</p>
A7A2	Mechanical brake opening failed	Status of mechanical brake acknowledgment is not as expected during brake open.	<p>Check mechanical brake connection.</p> <p>Check mechanical brake settings in parameter group 44 Mechanical brake control.</p> <p>Check that acknowledgment signal matches the actual status of brake.</p>
A7A5	Mechanical brake opening not allowed	Open conditions of mechanical brake cannot be fulfilled.	<p>Check mechanical brake settings in parameter group 44 Mechanical brake control.</p> <p>Check that the acknowledgment signal (if used) matches the actual status of the brake.</p>

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do	
A7C1	FBA A communication Programmable warning: 50.02 FBA A comm loss func	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA) , 51 FBA A settings , 52 FBA A data in and 53 FBA A data out . Check cable connections. Check if communication master is able to communicate.	
A7CE	EFB comm loss Programmable warning: 58.14 Communication loss action	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the EIA-485/X5 terminals 29, 30 and 31 on the control unit.	
A7EE	Panel loss Programmable warning: 49.05 Communication loss action	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Check mounting platform if being used. Disconnect and reconnect the control panel.	
A88F	Cooling fan	Maintenance timer limit exceeded.	Replace the drive cooling fan. Parameter 05.04 Fan on-time counter shows the running time of the cooling fan.	
A8A0	AI supervision	Analog signal is beyond limits.	Check the signal level, input wiring, and the defined limits.	
				<table border="1"> <tr> <td data-bbox="219 919 591 938">0001 – AI1 less minimum</td> <td data-bbox="591 919 996 938">0003 – AI2 less minimum</td> </tr> <tr> <td data-bbox="219 938 591 967">0002 – AI1 greater maximum</td> <td data-bbox="591 938 996 967">0004 – AI2 greater maximum</td> </tr> </table>
0001 – AI1 less minimum	0003 – AI2 less minimum			
0002 – AI1 greater maximum	0004 – AI2 greater maximum			
A8A1	RO life warning	The relay has changed states more than the recommended number of times.	Change the control board or stop using the relay output.	
	0001	Relay output 1	Change the control board or stop using relay output 1.	
	0002	Relay output 2	Change the control board or stop using relay output 2.	
	0003	Relay output 3	Change the control board or stop using relay output 3.	
A8A2	RO toggle warning	The relay output is changing states faster than recommended, eg. if a fast changing frequency signal is connected to it. The relay lifetime will be exceeded shortly.	Replace the signal connected to the relay output source with a less frequently changing signal.	
	0001	Relay output 1	Select a different signal with parameter 10.24 RO1 source .	
	0002	Relay output 2	Select a different signal with parameter 10.27 RO2 source .	

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
	0003	Relay output 3	Select a different signal with parameter 10.30 RO3 source .
A8B0	Signal supervision 1 (Editable message text) Programmable warning: 32.06 Supervision 1 action	Warning generated by the signal supervision function 1.	Check the source of the warning (parameter 32.07 Supervision 1 signal).
A8B1	Signal supervision 2 (Editable message text) Programmable warning: 32.16 Supervision 2 action	Warning generated by the signal supervision function 2.	Check the source of the warning (parameter 32.17 Supervision 2 signal).
A8B2	Signal supervision 3 (Editable message text) Programmable warning: 32.26 Supervision 3 action	Warning generated by the signal supervision function 3.	Check the source of the warning (parameter 32.27 Supervision 3 signal).
A8B3	Signal supervision 4 (Editable message text) Programmable warning: 32.36 Supervision 4 action	Warning generated by the signal supervision function 4.	Check the source of the warning (parameter 32.37 Supervision 4 signal).
A8B4	Signal supervision 5 (Editable message text) Programmable warning: 32.46 Supervision 5 action	Warning generated by the signal supervision function 5.	Check the source of the warning (parameter 32.47 Supervision 5 signal).
A8B5	Signal supervision 6 (Editable message text) Programmable warning: 32.56 Supervision 6 action	Warning generated by the signal supervision function 6.	Check the source of the warning (parameter 32.57 Supervision 6 signal).
A8B6	Current limit	Motor actual current exceeded the limit defined in parameter 30.17 Maximum current .	Reduce the motor load. Check for any jam or stall in motor.
A8BE	ULC overload warning	User load curve: Signal has been too long over the overload curve.	See parameter 37.03 ULC overload actions .
	001	Overload occurred between speed point 37.11 ULC speed table point 1 and 37.12 ULC speed table point 2 .	Check the load.
	002	Overload occurred between speed point 37.12 ULC speed table point 2 and 37.13 ULC speed table point 3 .	Check the load.
	003	Overload occurred between speed point 37.13 ULC speed table point 3 and 37.14 ULC speed table point 4 .	Check the load.
	004	Overload occurred between speed point 37.14 ULC speed table point 4 and 37.15 ULC speed table point 5 .	Check the load.
A8BF	ULC underload warning	User load curve: Signal has been too long under the underload curve.	See parameter 37.04 ULC underload actions .

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
	001	Underload occurred between speed point 37.11 ULC speed table point 1 and 37.12 ULC speed table point 2 .	Check the load.
	002	Underload occurred between speed point 37.12 ULC speed table point 2 and 37.13 ULC speed table point 3 .	Check the load.
	003	Underload occurred between speed point 37.13 ULC speed table point 3 and 37.14 ULC speed table point 4 .	Check the load.
	004	Underload occurred between speed point 37.14 ULC speed table point 4 and 37.15 ULC speed table point 5 .	Check the load.
A8C0	ULC invalid speed table	User load curve: X-axis points (speed) are not valid.	Check that points fulfill conditions. See parameter 37.11 ULC speed table point 1 .
A8C5	ULC invalid underload table	User load curve: Underload curve points are not valid.	Check that points fulfill conditions. See parameter 37.21 ULC underload point 1 .
A8C6	ULC invalid overload table	User load curve: Overload curve points are not valid.	Check that points fulfill conditions. See parameter 37.31 ULC overload point 1 .
A981	External warning 1 (Editable message text) Programmable warning: 31.01 External event 1 source 31.02 External event 1 type	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source .
A982	External warning 2 (Editable message text) Programmable warning: 31.03 External event 2 source 31.04 External event 2 type	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 External event 2 source .
A983	External warning 3 (Editable message text) Programmable warning: 31.05 External event 3 source 31.06 External event 3 type	Fault in external device 3.	Check the external device. Check setting of parameter 31.05 External event 3 source .
A984	External warning 4 (Editable message text) Programmable warning: 31.07 External event 4 source 31.08 External event 4 type	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source .

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
A985	External warning 5 (Editable message text) Programmable warning: 31.09 External event 5 source 31.10 External event 5 type	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source .
A991	Safe motor temperature	You have configured a season which starts before the previous season.	Configure the seasons with increasing start dates, see parameters 34.60 Season 1 start date... 34.63 Season 4 start date .
AF88	Season configuration warning	You have configured a season which starts before the previous season.	Configure the seasons with increasing start dates, see parameters 34.60 Season 1 start date... 34.63 Season 4 start date .
AF90	Speed controller autotuning	The speed controller autotune routine did not complete successfully.	Check the auxiliary code (format XXXX YYYY). "YYYY" indicates the problem (see actions for each code below).
	0000	The drive was stopped before the autotune routine finished.	Repeat autotune until successful.
	0001	The drive was started but was not ready to follow the autotune command.	Make sure the prerequisites of the autotune run are fulfilled. See section Before activating the autotune routine (page 46).
	0002	Required torque reference could not be reached before the drive reached maximum speed.	Decrease torque step (parameter 25.38) or increase speed step (25.39).
	0003	Motor could not accelerate/decelerate to maximum/minimum speed.	Increase torque step (parameter 25.38) or decrease speed step (25.39).
	0005	Motor could not decelerate with full autotune torque.	Decrease torque step (parameter 25.38) or speed step (25.39).
AFAA	Autoreset	A fault is about to be autoreset.	Informative warning. See the settings in parameter group 31 Fault functions .
AFE1	Emergency stop (off2)	Drive has received an emergency stop (mode selection off2) command.	Check that it is safe to continue operation. Then return emergency stop push button to normal position. Restart drive.
AFE2	Emergency stop (off1 or off3)	Drive has received an emergency stop (mode selection off1 or off3) command.	If the emergency stop was unintentional, check the source selected by parameter 21.05 Emergency stop source .
AFE9	Start delay	The start delay is active and the drive will start the motor after a predefined delay.	Informative warning. See parameter 21.22 Start delay .
AFF5	Override new start required	The Safe torque off function was active and has been reset while in Override.	A new start signal is required to start the drive again.

Code (hex)	Warning / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
AFB8	Motor heating active	Pre-heating is being performed	Informative warning. Motor pre-heating is active. Current specified by parameter 21.16 Pre-heating current is being passed through the motor.
AFEB	Run enable missing	No run enable signal is received.	Check setting of parameter 20.12 Run enable 1 source . Switch signal on (e.g. in the fieldbus Control Word) or check wiring of selected source.
AFEC	External power signal missing	95.04 Control board supply is set to <i>External 24V</i> but no voltage is connected to the control unit.	Check the external 24 V DC power supply to the control unit, or change the setting of parameter 95.04 .
AFED	Enable to rotate	Signal to rotate has not been received within a fixed time delay of 120 s.	Switch enable to rotate signal on (eg. in digital inputs). Check the setting of (and source selected by) parameter 20.22 Enable to rotate .
AFF6	Identification run	Motor ID run will occur at next start.	Informative warning.
B5F6	Identification run	Motor ID run completed successfully.	Informative warning.
B5A0	STO event Programmable event: 31.22 STO indication run/stop	Safe torque off function is active, ie. safety circuit signal(s) connected to connector STO is lost.	Check safety circuit connections. For more information, see chapter <i>The Safe torque off function</i> in the <i>Hardware manual</i> of the drive and description of parameter 31.22 STO indication run/stop (page 259).
D501	No more available PFC motors	No more PFC motors can be started because they can be interlocked or in the Hand mode.	Check that there are no interlocked PFC motors, see parameters: 76.81...76.84 . If all motors are in use, the PFC system is not adequately dimensioned to handle the demand.
D502	All motors interlocked	All the motors in the PFC system are interlocked.	Check that there are no interlocked PFC motors, see parameters 76.81...76.84 .
D503	VSD controlled PFC motor interlocked	The motor connected to the drive is interlocked (unavailable).	Motor connected to the drive is interlocked and thus cannot be started. Remove the corresponding interlock to start the drive controlled PFC motor. See parameters 76.81...76.84 .
FA90	STO diagnostics failure	The software is not working properly.	Restart the control unit.

Fault messages

Code (hex)	Fault / Aux. code (<i>aux code visible only on assistant control panel and drive composer</i>)	Cause	What to do
1080	Backup/Restore timeout	Panel or PC tool has failed to communicate with the drive when backup was being made or restored.	Request backup or restore again.
1081	Rating ID fault	Drive software is not able to read the rating ID of the drive.	Reset the fault to make the drive try to reread the rating ID. If the fault reappears, cycle the power to the drive. You may have to repeat this. If the fault persists, contact your local ABB representative.
2281	Calibration	Measured offset of output phase current measurement or difference between output phase U2 and W2 current measurement is too great (the values are updated during current calibration).	Try performing the current calibration again. If the fault persists, contact your local ABB representative.
2310	Overcurrent	Output current has exceeded internal fault limit. In addition to an actual overcurrent situation, this fault may also be caused by an earth fault or supply phase loss.	Check motor load. Check acceleration times in parameter group 23 Speed reference ramp (speed control), 26 Torque reference chain (torque control) or 28 Frequency reference chain (frequency control). Also check parameters 46.01 Speed scaling , 46.02 Frequency scaling and 46.03 Torque scaling . Check motor and motor cable (including phasing and delta/star connection). Check there are no contactors opening and closing in motor cable. Check that the start-up data in parameter group 99 corresponds to the motor rating plate. Check that there are no power factor correction capacitors or surge absorbers in motor cable. Check for an earth fault in motor or motor cables by measuring the insulation resistances of motor and motor cable. See chapter <i>Electrical installation</i> , section <i>Checking the insulation of the assembly</i> in the <i>Hardware manual</i> of the drive.
2340	Short circuit	Short-circuit in motor cable(s) or motor	Check motor and motor cable for cabling errors. Check there are no power factor correction capacitors or surge absorbers in motor cable. Cycle the power to the drive.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
2381	IGBT overload	Excessive IGBT junction to case temperature. This fault protects the IGBT(s) and can be activated by a short circuit in the motor cable.	Check motor cable. Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
2392	BU earth leakage	Total earth leakage of inverter modules is excessive.	Check there are no power factor correction capacitors or surge absorbers in motor cable. Measure insulation resistances of motor cables and motor. Contact your local ABB representative.
3130	Input phase loss	Intermediate circuit DC voltage is oscillating due to missing input power line phase or blown fuse.	Check input power line fuses. Check for loose power cable connections. Check for input power supply imbalance.
3181	Wiring or earth fault Programmable fault: 31.23 Wiring or earth fault	Incorrect input power and motor cable connection (ie. input power cable is connected to drive motor connection).	Check input power connections.
3210	DC link overvoltage	Excessive intermediate circuit DC voltage.	Check that overvoltage control is on (parameter 30.30 Overvoltage control). Check that the supply voltage matches the nominal input voltage of the drive. Check the supply line for static or transient overvoltage. Check brake chopper and resistor (if present). Check deceleration time. Use coast-to-stop function (if applicable). Retrofit drive with brake chopper and brake resistor. Check that the brake resistor is dimensioned properly and the resistance is between acceptable range for the drive.
3220	DC link undervoltage	Intermediate circuit DC voltage is not sufficient because of a missing supply phase, blown fuse or fault in the rectifier bridge. See also section DC undervoltage (page 82).	Check supply cabling, fuses and switchgear.
3291	BU DC link difference	Difference in DC voltages between parallel-connected inverter modules.	Check the auxiliary code (format XXXY YYZZ). "XXX" specifies the source of the first error (see "YYY"). "YYY" specifies the module through which BCU control unit channel the fault was received (1: Channel 1, 2: Channel 2, 4: Channel 3, 8: Channel 4, ..., 800: Channel 12).

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
3381	Output phase loss Programmable fault: 31.19 Motor phase loss	Motor circuit fault due to missing motor connection (any of the three phases not connected). In scalar control mode, the drive detects fault only when the output frequency is above 10% of the motor nominal frequency.	Connect motor cable. If the drive is in scalar mode and nominal current of the motor is less than 1/6 of the nominal output current of the drive, set parameter 31.19 Motor phase loss to <i>No action</i> .
4110	Control board temperature	Control board temperature is too high.	Check proper cooling of the drive. Check the auxiliary cooling fan.
4210	IGBT overtemperature	Estimated drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4290	Cooling	Drive module temperature is excessive.	Check ambient temperature. If it exceeds 40%/104 °F (frames R4...R8) or if it exceeds 50% /122 °F (frames R0...R8), ensure that load current does not exceed derated load capacity of drive. See chapter <i>Technical data</i> , section <i>Derating</i> in the <i>Hardware manual</i> of the drive. Check drive module cooling air flow and fan operation. Check inside of cabinet and heatsink of drive module for dust pick-up. Clean whenever necessary.
42F1	IGBT temperature	Drive IGBT temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4310	Excess temperature	Power unit module temperature is excessive.	Check ambient conditions. Check air flow and fan operation. Check heatsink fins for dust pick-up. Check motor power against drive power.
4380	Excess temperature difference	High temperature difference between the IGBTs of different phases.	Check the motor cabling. Check cooling of drive module(s).
4981	External temperature 1	Measured temperature 1 has exceeded fault limit.	Check the value of parameter 35.02 Measured temperature 1 . Check the cooling of the motor (or other equipment whose temperature is being measured).
4982	External temperature 2	Measured temperature 2 has exceeded fault limit.	Check the value of parameter 35.03 Measured temperature 2 . Check the cooling of the motor (or other equipment whose temperature is being measured).

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
4991	Safe motor temperature	The CPTC-02 module indicates overtemperature: <ul style="list-style-type: none"> motor temperature is too high, or the thermistor is in shortcircuit. 	Check the cooling of the motor. Check the motor load and drive ratings. Check the wiring of the temperature sensor. Repair wiring if faulty. Measure the resistance of the sensor. Replace the sensor if faulty.
5080	Fan	Cooling fan is stuck or disconnected.	See A581 Fan (page 392).
5081	Auxiliary fan broken	An auxiliary cooling fan is stuck or disconnected.	Check auxiliary fan(s) and connection(s). Replace fan if faulty.
		0001 Auxiliary fan 1 broken.	
		0002 Auxiliary fan 2 broken.	
5089	SMT circuit malfunction	Safe motor temperature fault is generated and STO event/fault/warning is not generated.	Check connection between the relay output of the module and the STO terminal.
5090	STO hardware failure	STO hardware diagnostics has detected hardware failure.	Contact your local ABB representative for hardware replacement.
5091	Safe torque off Programmable fault: 31.22 STO indication run/stop	Safe torque off function is active, ie. safety circuit signal(s) connected to connector STO is broken during start or run.	Check safety circuit connections. For more information, see chapter <i>The Safe torque off function</i> in the <i>Hardware manual</i> of the drive and description of parameter 31.22 STO indication run/stop (page 259). Check the value of parameter 95.04 Control board supply .
5092	PU logic error	Power unit memory has cleared.	Contact your local ABB representative.
5093	Rating ID mismatch	The hardware of the drive does not match the information stored in the memory. This may occur eg. after a firmware update.	Cycle the power to the drive. You may have to repeat this.
5094	Measurement circuit temperature	Problem with internal temperature measurement of the drive.	Contact your local ABB representative.
5095	Redundant measurement	Duplicated measurements are beyond limits.	Contact ABB.
5096	Overtemperature hw	Excessive hardware temperature.	Contact your local ABB representative.
5098	I/O communication loss	Communication failure to standard I/O.	Try resetting the fault or cycle the power to the drive.
5681	PU communication	Communication errors detected between the drive control unit and the power unit.	Check the connection between the drive control unit and the power unit. Check the value of parameter 95.04 Control board supply .
5682	Power unit lost	Connection between the drive control unit and the power unit is lost.	Check the connection between the control unit and the power unit.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
5690	PU communication internal	Internal communication error.	Contact your local ABB representative.
5691	Measurement circuit ADC	Measurement circuit fault.	Contact your local ABB representative.
5692	PU board powerfail	Power unit power supply failure.	Contact your local ABB representative.
5693	Measurement circuit DFF	Measurement circuit fault.	Contact your local ABB representative.
5695	Reduced run	Configured power units not found.	Configure the power units.
5697	Charging feedback	Charging feedback signal missing.	Check the feedback signal coming from the charging system
5698	Unknown PU fault	The power unit logic generated a fault which is not known by software.	Check the logic and software compatibility.
50A0	Fan	Cooling fan stuck or disconnected.	Check fan operation and connection. Replace fan if faulty.
6181	FPGA version incompatible	Firmware and FPGA versions are incompatible.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative
6306	FBA A mapping file	Fieldbus adapter A mapping file read error.	Contact your local ABB representative.
6481	Task overload	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative
6487	Stack overflow	Internal fault.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.
64A3	Application loading	Application file incompatible or corrupted.	Check the auxiliary code. See actions for each code below.
	8006	Not enough memory for the application.	Reduce the size of the application. Reduce the number of parameter mappings. See the drive-specific log generated by Automation Builder.
	8007	The application contains the wrong system library version.	Update the system library or reinstall Automation Builder. See the drive-specific log generated by Automation Builder.
	8008	The application is empty.	In Automation Builder, give a "Clean" command and reload the application.
	8009	The application contains invalid tasks.	In Automation Builder, check application task configuration, give a "Clean all" command, and reload the application.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do		
	800A	The application contains an unknown target (system) library function.	Update the system library or reinstall Automation Builder. See the drive-specific log generated by Automation Builder.		
64A1	Internal file load	File read error.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative.		
64A4	Rating ID fault	Rating ID load error.	Contact ABB.		
64A6	Adaptive program	Fault in adaptive program.	Check the fault code extension.		
64B1	Internal SSW fault	A fatal error in the power-up phase of System Software (SSW).	SSW runs in partial functionality mode.		
				1 – Starting OS time tick failed	5 – Initializing WoRm volumes failed
				2 – Creating system tasks failed	6 – Loading FPGA configuration failed
				3 – Initializing file system failed	7 – Loading application program failed
				4 – Checking file system failed	
64B2	User set fault	Loading of user parameter set failed because <ul style="list-style-type: none"> • requested set does not exist • set is not compatible with control program • drive was switched off during loading. 	Ensure that a valid user parameter set exists. Reload if uncertain.		
64B3	Macro parameterization error	Macro parameterization failed, eg. Parameter default value that cannot be changed has been attempted to write.			
64E1	Kernel overload	Operating system error.	Reboot the control unit (using parameter 96.08 Control board boot) or by cycling power. If the problem persists, contact your local ABB representative		
6581	Parameter system	Parameter load or save failed.	Try forcing a save using parameter 96.07 Parameter save manually . Retry.		
6591	Backup/Restore timeout	During backup creating or restoring operation a panel or PC-tool has failed to communicate with the drive as part of this operation.	Check panel or PC-tool communication and if it is still in backup or restore state.		
65A1	FBA A parameter conflict	The drive does not have a functionality requested by PLC, or requested functionality has not been activated.	Check PLC programming. Check settings of parameter groups 50 Fieldbus adapter (FBA) and 51 FBA A settings .		
6681	EFB comm loss Programmable fault: 58.14 Communication loss action	Communication break in embedded fieldbus (EFB) communication.	Check the status of the fieldbus master (online/offline/error etc.). Check cable connections to the EIA-485/X5 terminals 29, 30 and 31 on the control unit.		

Code (hex)	Fault / Aux. code (<i>aux code visible only on assistant control panel and drive composer</i>)	Cause	What to do
6682	EFB config file	Embedded fieldbus (EFB) configuration file could not be read.	Contact your local ABB representative.
6683	EFB invalid parameterization	Embedded fieldbus (EFB) parameter settings inconsistent or not compatible with selected protocol.	Check the settings in parameter group 58 Embedded fieldbus .
6684	EFB load fault	Embedded fieldbus (EFB) protocol firmware could not be loaded.	Contact your local ABB representative.
		Version mismatch between EFB protocol firmware and drive firmware.	
6685	EFB fault 2	Fault reserved for the EFB protocol application.	Check the documentation of the protocol.
6686	EFB fault 3	Fault reserved for the EFB protocol application.	Check the documentation of the protocol.
6882	Text 32-bit table overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
6885	Text file overflow	Internal fault.	Reset the fault. Contact your local ABB representative if the fault persists.
7081	Control panel loss Programmable fault: 49.05 Communication loss action	Control panel or PC tool selected as active control location for drive has ceased communicating.	Check PC tool or control panel connection. Check control panel connector. Disconnect and reconnect the control panel.
7082	I/O module comm loss	Communication between I/O module and drive is not working properly.	Check the I/O module installation.
7085	Incompatible option module	Fieldbus option module not supported.	Replace the module with a supported type.
7086	I/O module AI overvoltage	Overvoltage detected in AI. AI is changed to voltage mode from mA mode. AI will return automatically back to mA mode when the AI signal level is within acceptable limits.	Check AI signal levels.
71A2	Mechanical brake closing failed	Mechanical brake control fault. Activated e.g., if brake acknowledgment is not as expected during brake closing.	Check mechanical brake connection. Check mechanical brake settings in parameter group 44 Mechanical brake control . Check that the acknowledgment signal matches the actual status of the brake.
71A5	Mechanical brake opening not allowed	Open conditions of mechanical brake cannot be fulfilled.	Check mechanical brake settings in parameter group 44 Mechanical brake control . Check that the acknowledgment signal (if used) matches the actual status of the brake.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
7100	Excitation current	Excitation current feedback low or missing	Contact your local ABB representative.
7121	Motor stall Programmable fault: 31.24 Stall function	Motor is operating in stall region because of e.g. excessive load or insufficient motor power.	Check motor load and drive ratings. Check fault function parameters.
7122	Motor overload	Motor current is too high.	Check for overloaded motor Adjust the parameters used for the motor overload function. (35.51...35.53 , 35.55 , 35.56)
7181	Brake resistor	Brake resistor broken or not connected.	Check that a brake resistor has been connected. Check the condition of the brake resistor. Check the dimensioning of the brake resistor.
7183	BR excess temperature	Brake resistor temperature has exceeded fault limit defined by parameter 43.11 Brake resistor fault limit .	Stop drive. Let resistor cool down. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check fault limit setting, parameter 43.11 Brake resistor fault limit . Check that braking cycle meets allowed limits.
7184	Brake resistor wiring	Brake resistor short circuit or brake chopper control fault.	Check brake chopper and brake resistor connection. Ensure brake resistor is not damaged.
7191	BC short circuit	Short circuit in brake chopper IGBT.	Ensure brake resistor is connected and not damaged. Check the electrical specifications of the brake resistor against chapter <i>Resistor braking</i> in the <i>Hardware manual</i> of the drive. Replace brake chopper (if replaceable).
7192	BC IGBT excess temperature	Brake chopper IGBT temperature has exceeded internal fault limit.	Let chopper cool down. Check for excessive ambient temperature. Check for cooling fan failure. Check for obstructions in the air flow. Check resistor overload protection function settings (parameter group 43 Brake chopper). Check that braking cycle meets allowed limits. Check that drive supply AC voltage is not excessive.
71A3	Mech brake opening failed	Mechanical brake control is faulty. Brake open acknowledgment is not matching the actual status.	Check connections, brake settings and brake acknowledgment signal.

410 Fault tracing

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
7310	Overspeed	Motor is turning faster than highest allowed speed due to incorrectly set minimum/maximum speed, insufficient braking torque or changes in load when using torque reference.	Check minimum/maximum speed settings, parameters 30.11 Minimum speed and 30.12 Maximum speed . Check adequacy of motor braking torque. Check applicability of torque control. Check need for brake chopper and resistor(s).
73B0	Emergency ramp failed	Emergency stop did not finish within expected time.	Check the predefined ramp times (23.11...23.15 , 23.12...23.13 for mode Off1, 23.23 for mode Off3).
73F0	Overfrequency	Maximum allowed output frequency exceeded.	Check the auxiliary code.
	00FA	Motor is turning faster than the highest allowed frequency due to incorrectly set minimum/maximum frequency or the motor rushes because of too high supply voltage or incorrect supply voltage selection in parameter 95.01 Supply voltage .	Check minimum/maximum frequency settings, parameters 30.13 Minimum frequency and 30.14 Maximum frequency . Check used supply voltage and voltage selection parameter 95.01 Supply voltage .
	Other	-	Contact your local ABB representative, quoting the auxiliary code.
7510	FBAA communication Programmable fault: 50.02 FBA A comm loss func	Cyclical communication between drive and fieldbus adapter module A or between PLC and fieldbus adapter module A is lost.	Check status of fieldbus communication. See user documentation of fieldbus interface. Check settings of parameter groups 50 Fieldbus adapter (FBA) , 51 FBA A settings , 52 FBA A data in and 53 FBA A data out . Check cable connections. Check if communication master is able to communicate.
8000	Unicos system error	System fault.	Power cycle.
8001	ULC underload fault	User load curve: Signal has been too long under the underload curve.	See parameter 37.04 ULC underload actions .
	001	Underload occurred between speed point 37.11 ULC speed table point 1 and 37.12 ULC speed table point 2 .	Check the load.
	002	Underload occurred between speed point 37.12 ULC speed table point 2 and 37.13 ULC speed table point 3 .	Check the load.
	003	Underload occurred between speed point 37.13 ULC speed table point 3 and 37.14 ULC speed table point 4 .	Check the load.

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do				
	004	Underload occurred between speed point 37.14 ULC speed table point 4 and 37.15 ULC speed table point 5 .	Check the load.				
8002	ULC overload fault	User load curve: Signal has been too long over the overload curve.	See parameter 37.03 ULC overload actions .				
	001	Overload occurred between speed point 37.11 ULC speed table point 1 and 37.12 ULC speed table point 2 .	Check the load.				
	002	Overload occurred between speed point 37.12 ULC speed table point 2 and 37.13 ULC speed table point 3 .	Check the load.				
	003	Overload occurred between speed point 37.13 ULC speed table point 3 and 37.14 ULC speed table point 4 .	Check the load.				
	004	Overload occurred between speed point 37.14 ULC speed table point 4 and 37.15 ULC speed table point 5 .	Check the load.				
8009	Current limit	Motor actual current exceeded the limit defined in parameter 30.17 Maximum current .	Reduce the motor load. Check for any jam or stall in motor. See parameter 30.17 Maximum current .				
80A0	AI supervision Programmable fault: 12.03 AI supervision function	An analog signal is outside the limits specified for the analog input	Check signal level at the analog input. Check the auxiliary code. Check the wiring connected to the input. Check the minimum and maximum limits of the input in parameter group 12 Standard AI .				
	<table border="1"> <tr> <td>1 – AI1LessMIN</td> <td>3 – AI2LessMIN</td> </tr> <tr> <td>2 – AI1GreaterMAX</td> <td>4 – AI2GreaterMAX</td> </tr> </table>		1 – AI1LessMIN	3 – AI2LessMIN	2 – AI1GreaterMAX	4 – AI2GreaterMAX	
1 – AI1LessMIN	3 – AI2LessMIN						
2 – AI1GreaterMAX	4 – AI2GreaterMAX						
80B0	Signal supervision 1 (Editable message text) Programmable fault: 32.06 Supervision 1 action	Fault generated by the signal supervision function 1.	Check the source of the fault (parameter 32.07 Supervision 1 signal).				
80B1	Signal supervision 2 (Editable message text) Programmable fault: 32.16 Supervision 2 action	Fault generated by the signal supervision function 2.	Check the source of the fault (parameter 32.17 Supervision 2 signal).				
80B2	Signal supervision 3 (Editable message text) Programmable fault: 32.26 Supervision 3 action	Fault generated by the signal supervision function 3.	Check the source of the fault (parameter 32.27 Supervision 3 signal).				
80B3	Signal supervision 4 (Editable message text) Programmable fault: 32.36 Supervision 4 action	Fault generated by the signal supervision function 4.	Check the source of the fault (parameter 32.37 Supervision 4 signal).				

Code (hex)	Fault / Aux. code (<i>aux code visible only on assistant control panel and drive composer</i>)	Cause	What to do
80B4	Signal supervision 5 (Editable message text) Programmable fault: 32.46 Supervision 5 action	Fault generated by the signal supervision function 5.	Check the source of the fault (parameter 32.47 Supervision 5 signal).
80B5	Signal supervision 6 (Editable message text) Programmable fault: 32.56 Supervision 6 action	Fault generated by the signal supervision function 6.	Check the source of the fault (parameter 32.57 Supervision 6 signal).
9081	External fault 1 (Editable message text) Programmable fault: 31.01 External event 1 source 31.02 External event 1 type	Fault in external device 1.	Check the external device. Check setting of parameter 31.01 External event 1 source .
9082	External fault 2 (Editable message text) Programmable fault: 31.03 External event 2 source 31.04 External event 2 type	Fault in external device 2.	Check the external device. Check setting of parameter 31.03 External event 2 source .
9083	External fault 3 (Editable message text) Programmable fault: 31.05 External event 3 source 31.06 External event 3 type	Fault in external device 3.	Check the external device. Check setting of parameter 31.05 External event 3 source .
9084	External fault 4 (Editable message text) Programmable fault: 31.07 External event 4 source 31.08 External event 4 type	Fault in external device 4.	Check the external device. Check setting of parameter 31.07 External event 4 source .
9085	External fault 5 (Editable message text) Programmable fault: 31.09 External event 5 source 31.10 External event 5 type	Fault in external device 5.	Check the external device. Check setting of parameter 31.09 External event 5 source .
A2A1	Current calibration	Current offset and gain measurement calibration will occur at next start.	Informative warning. (See parameter 99.13 ID run requested).
FA81	Safe torque off 1	Safe torque off function is active, ie. STO circuit 1 is broken.	Check safety circuit connections. For more information, see chapter <i>The Safe torque off function</i> in the <i>Hardware manual</i> of the drive and description of parameter 31.22 STO indication run/stop (page 259).
FA82	Safe torque off 2	Safe torque off function is active, ie. STO circuit 2 is broken.	Check the value of parameter 95.04 Control board supply .

Code (hex)	Fault / Aux. code (aux code visible only on assistant control panel and drive composer)	Cause	What to do
FF61	ID run	Motor ID run was not completed successfully.	<p>Check the nominal motor values in parameter group 99 Motor data.</p> <p>Check that no external control system is connected to the drive.</p> <p>Cycle the power to the drive (and its control unit, if powered separately).</p> <p>Check that no operation limits prevent the completion of the ID run. Restore parameters to default settings and try again.</p> <p>Check that the motor shaft is not locked.</p>
	0001	Maximum current limit too low.	<p>Check settings of parameters 99.06 Motor nominal current and 30.17 Maximum current. Make sure that 30.17 > 99.06.</p> <p>Check that the drive is dimensioned correctly according to the motor.</p>
	0002	Maximum speed limit or calculated field weakening point too low.	<p>Check settings of parameters</p> <ul style="list-style-type: none"> • 30.11 Minimum speed • 30.12 Maximum speed • 99.07 Motor nominal voltage • 99.08 Motor nominal frequency • 99.09 Motor nominal speed. <p>Make sure that</p> <ul style="list-style-type: none"> • 30.12 > (0.55 × 99.09) > (0.50 × synchronous speed) • 30.11 ≤ 0, and • supply voltage ≥ (0.66 × 99.07).
	0003	Maximum torque limit too low.	<p>Check settings of parameter 99.12 Motor nominal torque, and the torque limits in group 30 Limits.</p> <p>Make sure that the maximum torque limit in force is greater than 100%.</p>
	0004	Current measurement calibration did not finish within reasonable time	Contact your local ABB representative.
	0005...0008	Internal error.	Contact your local ABB representative.
	0009	(Asynchronous motors only) Acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000A	(Asynchronous motors only) Deceleration did not finish within reasonable time.	Contact your local ABB representative.
	000B	(Asynchronous motors only) Speed dropped to zero during ID run.	Contact your local ABB representative.
	000C	(Permanent magnet motors only) First acceleration did not finish within reasonable time.	Contact your local ABB representative.

414 Fault tracing

Code (hex)	Fault / Aux. code (<i>aux code visible only on assistant control panel and drive composer</i>)	Cause	What to do
	000D	(Permanent magnet motors only) Second acceleration did not finish within reasonable time.	Contact your local ABB representative.
	000E...0010	Internal error.	Contact your local ABB representative.
	0011	(Synchronous reluctance motors only) Pulse test error.	Contact your local ABB representative.
	0012	Motor too large for advanced standstill ID run.	Check that the motor and drive sizes are compatible. Contact your local ABB representative.
	0013	(Asynchronous motors only) Motor data error.	Check that the motor nominal value settings in the drive are the same as in the motor nameplate. Contact your local ABB representative.
FF63	STO diagnostics failure.	SW internal malfunction.	Reboot the control unit (using parameter 96.08 Control board boot or by cycling power.
FF81	FB A force trip	A fault trip command has been received through fieldbus adapter A.	Check the fault information provided by the PLC.
FF8E	EFB force trip	A fault trip command has been received through the embedded fieldbus interface.	Check the fault information provided by the PLC.

9

Fieldbus control through the embedded fieldbus interface (EFB)

What this chapter contains

The chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) using the embedded fieldbus interface.

System overview


The drive can be connected to an external control system through a communication link using either a fieldbus adapter or the embedded fieldbus interface.

The embedded fieldbus interface supports the Modbus RTU protocol. The drive control program can handle 10 Modbus registers in a 10-millisecond time level. For example, if the drive receives a request to read 20 registers, it will start its response within 22 ms of receiving the request – 20 ms for processing the request and 2 ms overhead for handling the bus. The actual response time depends on other factors as well, such as the baud rate (a parameter setting in the drive).

The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the embedded fieldbus interface and other available sources, for example, digital and analog inputs.

Connecting the fieldbus to the drive

Connect the fieldbus to terminal slot, which is attached on the control unit of the drive. The connection diagram is shown below.



The AC500 PLC has a free version library called 'PS553 drives' which help user to communicate and control between PLC and drives easily.

Setting up the embedded fieldbus interface

To configure the parameters automatically

1. Navigate to **Main menu**  → **Complete parameter list**  and set parameter **96.04** to *Modbus RTU* [21].

The following parameters change automatically.

Parameter	Setting
20.01 Ext1 commands	<i>Embedded fieldbus</i> [1]
20.03 Ext1 in1 source	<i>Always off</i> [0]
20.04 Ext1 in2 source	<i>Always off</i> [0]
22.11 Ext1 speed ref1	<i>EFB ref1</i> [8]
22.22 Constant speed sel1	<i>Always off</i> [0]
22.23 Constant speed sel2	<i>Always off</i> [0]
23.11 Ramp set selection	<i>Acc/Dec time 1</i> [0]
28.11 Ext1 frequency ref1	<i>EFB ref1</i> [8]
28.22 Constant frequency sel1	<i>Always off</i> [0]
28.23 Constant frequency sel2	<i>Always off</i> [0]
28.71 Freq ramp set selection	<i>Acc/Dec time 1</i> [0]
31.11 Fault reset selection	<i>D1</i> [2]
58.01 Protocol enable	<i>Modbus RTU</i> [1]

You can manually set the drive up for the embedded fieldbus communication with the parameters shown in the table below. The **Setting for fieldbus control** column gives either the value to use or the default value. The **Function/Information** column gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information
COMMUNICATION INITIALIZATION		
58.01 <i>Protocol enable</i>	<i>Modbus RTU</i> [1]	Initializes embedded fieldbus communication.
EMBEDDED MODBUS CONFIGURATION		
58.03 <i>Node address</i>	1 (default)	Node address. There must be no two nodes with the same node address online.
58.04 <i>Baud rate</i>	<i>19.2 kbps</i> (default) [3]	Defines the communication speed of the link. Use the same setting as in the master station.
58.05 <i>Parity</i>	<i>8 EVEN 1</i> (default) [2]	Selects the parity and stop bit setting. Use the same setting as in the master station.
58.14 <i>Communication loss action</i>	<i>Fault</i> (default) [1]	Defines the action taken when a communication loss is detected.
58.15 <i>Communication loss mode</i>	<i>Cw / Ref1 / Ref2</i> (default) [2]	Enables/disables communication loss monitoring and defines the means for resetting the counter of the communication loss delay.

Parameter	Setting for fieldbus control	Function/Information
58.16 <i>Communication loss time</i>	3.0 s (default)	Defines the timeout limit for the communication monitoring.
58.17 <i>Transmit delay</i>	0 ms (default)	Defines a response delay for the drive.
58.25 <i>Control profile</i>	<i>ABB Drives</i> [0] (default)	Selects the control profile used by the drive. See section <i>Basics of the embedded fieldbus interface</i> (page 421).
58.26 <i>EFB ref1 type</i> 58.27 <i>EFB ref2 type</i>	<i>Speed or frequency</i> (default for 58.26) [0], <i>Transparent, General, Torque</i> [3] (default for 58.27), <i>Speed</i> [4], <i>Frequency</i> [5]	Defines the types of fieldbus references 1 and 2. The scaling for each reference type is defined by parameters 46.01...46.03. With the <i>Speed or frequency</i> setting, the type is selected automatically according to the currently active drive control mode.
58.28 <i>EFB act1 type</i> 58.29 <i>EFB act2 type</i>	<i>Speed or frequency</i> (default for 58.28) [0], <i>Transparent</i> (default for 58.29) [1], <i>General</i> [2], <i>Torque</i> [3], <i>Speed</i> [4], <i>Frequency</i> [5]	Defines the types of actual values 1 and 2. The scaling for each actual value type is defined by parameters 46.01...46.03. With the <i>Speed or frequency</i> setting, the type is selected automatically according to the currently active drive control mode.
58.31 <i>EFB act1 transparent source</i> 58.32 <i>EFB act2 transparent source</i>	<i>Other</i>	Defines the source of actual values 1 and 2 when the 58.26 <i>EFB ref1 type</i> (58.27 <i>EFB ref2 type</i>) is set to <i>Transparent</i> .
58.33 <i>Addressing mode</i>	<i>Mode 0</i> (default) [0]	Defines the mapping between parameters and holding registers in the 400001...465536 (100...65535) Modbus register range.
58.34 <i>Word order</i>	<i>LO-HI</i> (default) [1]	Defines the order of the data words in the Modbus message frame.
58.101 <i>Data I/O 1</i> ... 58.114 <i>Data I/O 14</i>	For example, the default settings (I/Os 1...6 contain the control word, the status word, two references and two actual values) <i>RO/DIO control word</i> [31], <i>AO1 data storage</i> [32], <i>AO2 data storage</i> [33], <i>Feedback data storage</i> [40], <i>Setpoint data storage</i> [41]	Defines the address of the drive parameter which the Modbus master accesses when it reads from or writes to the register address corresponding to Modbus In/Out parameters. Select the parameters that you want to read or write through the Modbus I/O words. These settings write the incoming data into storage parameters 10.99 <i>RO/DIO control word</i> , 13.91 <i>AO1 data storage</i> , 13.92 <i>AO2 data storage</i> , 40.91 <i>Feedback data storage</i> or 40.92 <i>Setpoint data storage</i> .

Parameter	Setting for fieldbus control	Function/Information
58.06 <i>Communication control</i>	<i>Refresh settings</i>	Validates the settings of the configuration parameters.

The new settings will take effect when the drive is powered up the next time, or when they are validated by parameter [58.06 Communication control \(Refresh settings\)](#).

Setting the drive control parameters

After the embedded fieldbus interface has been set up, check and adjust the drive control parameters listed in the table below. The **Setting for fieldbus control** column gives the value or values to use when the embedded fieldbus signal is the desired source or destination for that particular drive control signal. The **Function/Information** column gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information
-----------	------------------------------	----------------------

CONTROL COMMAND SOURCE SELECTION

20.01 <i>Ext1 commands</i>	<i>Embedded fieldbus</i>	Selects fieldbus as the source for the start and stop commands when EXT1 is selected as the active control location.
20.06 <i>Ext2 commands</i>	<i>Embedded fieldbus</i>	Selects fieldbus as the source for the start and stop commands when EXT2 is selected as the active control location.

SPEED REFERENCE SELECTION

22.11 <i>Ext1 speed ref1</i>	<i>EFB ref1</i>	Selects a reference received through the embedded fieldbus interface as speed reference 1.
22.18 <i>Ext2 speed ref1</i>	<i>EFB ref1</i>	Selects a reference received through the embedded fieldbus interface as speed reference 2.

TORQUE REFERENCE SELECTION

26.11 <i>Torque ref1 source</i>	<i>EFB ref1</i>	Selects a reference received through the embedded fieldbus interface as torque reference 1.
26.12 <i>Torque ref2 source</i>	<i>EFB ref1</i>	Selects a reference received through the embedded fieldbus interface as torque reference 2.

FREQUENCY REFERENCE SELECTION


28.11 <i>Ext1 frequency ref1</i>	<i>EFB ref1</i>	Selects a reference received through the embedded fieldbus interface as frequency reference 1.
--	-----------------	--

Parameter	Setting for fieldbus control	Function/Information
28.15 Ext2 frequency ref1	EFB ref1	Selects a reference received through the embedded fieldbus interface as frequency reference 2.
OTHER SELECTIONS		
EFB references can be selected as the source at virtually any signal selector parameter by selecting <i>Other</i> , then either 03.09 EFB reference 1 or 03.10 EFB reference 2 .		
SYSTEM CONTROL INPUTS		
96.07 Parameter save manually	Save (reverts to Done)	Saves parameter value changes (including those made through fieldbus control) to permanent memory.

Basics of the embedded fieldbus interface

The cyclic communication between a fieldbus system and the drive consists of 16-bit data words or 32-bit data words (with a transparent control profile).

The diagram below illustrates the operation of the embedded fieldbus interface. The signals transferred in the cyclic communication are explained further below the diagram.



1. See also other parameters which can be controlled through fieldbus.
2. Data conversion if parameter **58.25 Control profile** is set to **ABB Drives**. See section **About the control profiles** (page 424).

■ Control word and Status word

The Control Word (CW) is a 16-bit or 32-bit packed boolean word. It is the principal means of controlling the drive from a fieldbus system. The CW is sent by the fieldbus controller to the drive. With drive parameters, the user selects the EFB CW as the source of drive control commands (such as start/stop, emergency stop, selection between external control locations 1/2, or fault reset). The drive switches between its states according to the bit-coded instructions of the CW.

The fieldbus CW is either written to the drive as it is or the data is converted. See section [About the control profiles](#) (page 424).

The fieldbus Status Word (SW) is a 16-bit or 32-bit packed boolean word. It contains status information from the drive to the fieldbus controller. The drive SW is either written to the fieldbus SW as it is or the data is converted. See section [About the control profiles](#) (page 424).

■ References

EFB references 1 and 2 are 16-bit or 32-bit signed integers. The contents of each reference word can be used as the source of virtually any signal, such as the speed, frequency, torque or process reference. In embedded fieldbus communication, references 1 and 2 are displayed by [03.09 EFB reference 1](#) and [03.10 EFB reference 2](#) respectively. Whether the references are scaled or not depends on the settings of [58.26 EFB ref1 type](#) and [58.27 EFB ref2 type](#). See section [About the control profiles](#) (page 424).

■ Actual values

Fieldbus actual signals (ACT1 and ACT2) are 16-bit or 32-bit signed integers. They convey selected drive parameter values from the drive to the master. Whether the actual values are scaled or not depends on the settings of [58.28 EFB act1 type](#) and [58.29 EFB act2 type](#). See section [About the control profiles](#) (page 424).

■ Data input/outputs

Data input/outputs are 16-bit or 32-bit words containing selected drive parameter values. Parameters [58.101 Data I/O 1 ... 58.114 Data I/O 14](#) define the addresses from which the master either reads data (input) or to which it writes data (output).

■ Register addressing

The address field of Modbus requests for accessing holding registers is 16 bits. This allows the Modbus protocol to support addressing of 65536 holding registers.

Historically, Modbus master devices used 5-digit decimal addresses from 40001 to 49999 to represent holding register addresses. The 5-digit decimal addressing limited to 9999 the number of holding registers that could be addressed.

Modern Modbus master devices typically provide a means to access the full range of 65536 Modbus holding registers. One of these methods is to use 6-digit decimal addresses from 400001 to 465536. This manual uses 6-digit decimal addressing to represent Modbus holding register addresses.

Modbus master devices that are limited to the 5-digit decimal addressing may still access registers 400001 to 409999 by using 5-digit decimal addresses 40001 to 49999. Registers 410000-465536 are inaccessible to these masters.

See parameter [58.33 Addressing mode](#).

Note: Register addresses of 32-bit parameters cannot be accessed by using 5-digit register numbers.

About the control profiles


A control profile defines the rules for data transfer between the drive and the fieldbus master, for example:

- if packed boolean words are converted and how
- if signal values are scaled and how
- how drive register addresses are mapped for the fieldbus master.

You can configure the drive to receive and send messages according to one of the two profiles:

- [ABB Drives](#)
- [DCU Profile](#).

For the ABB Drives profile, the embedded fieldbus interface of the drive converts the fieldbus data to and from the native data used in the drive. The DCU Profile involves no data conversion or scaling. The figure below illustrates the effect of the profile selection.



Control Word

Control Word for the ABB Drives profile

The table below shows the contents of the fieldbus Control Word for the ABB Drives profile. The embedded fieldbus interface converts this word to the form in which it is used in the drive. The upper case boldface text refers to the states shown in [State transition diagram for the ABB Drives profile](#) on page 432.

Bit	Name	Value	STATE/Description
0	OFF1_ CONTROL	1	Proceed to READY TO OPERATE.
		0	Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE ; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	OFF2_ CONTROL	1	Continue operation (OFF2 inactive).
		0	Emergency OFF, coast to stop. Proceed to OFF2 ACTIVE , proceed to SWITCH-ON INHIBITED .
2	OFF3_ CONTROL	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE ; proceed to SWITCH-ON INHIBITED . Warning: Ensure that the motor and driven machine can be stopped using this stop mode.
3	INHIBIT_ OPERATION	1	Proceed to OPERATION D . Note: Run enable signal must be active; see the drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to OPERATION INHIBITED .
4	RAMP_OUT_ ZERO	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT D .
		0	Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force).
5	RAMP_HOLD	1	ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR D .
		0	Halt ramping (Ramp Function Generator output held).
6	RAMP_IN_ ZERO	1	Normal operation. Proceed to OPERATING . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp Function Generator input to zero.
7	RESET	0=>1	Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.

Bit	Name	Value	STATE/Description
8	JOGGING_1	1	Request running at Jogging 1 speed. Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.
9	JOGGING_2	1	Request running at Jogging 2 speed. Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Continue normal operation.
10	REMOTE_CMD	1	Fieldbus control d.
		0	Control Word <> 0 or Reference <> 0: Retain last Control Word and Reference. Control Word = 0 and Reference = 0: Fieldbus control d. Reference and deceleration/acceleration ramp are locked.
11	EXT_CTRL_LOC	1	Select External Control Location EXT2. Effective if the control location is parameterized to be selected from the fieldbus.
		0	Select External Control Location EXT1. Effective if the control location is parameterized to be selected from the fieldbus.
12	USER_0		Writable control bits that can be combined with drive logic for application-specific functionality.
13	USER_1		
14	USER_2		
15	USER_3		

■ Control Word for the DCU Profile

The embedded fieldbus interface writes the fieldbus Control Word as is to the drive Control Word bits 0 to 15. Bits 16 to 32 of the drive Control Word are not in use.

Bit	Name	Value	State/Description
0	STOP	1	Stop according to the Stop Mode parameter or the stop mode request bits (7...9).
		0	(no op)
1	START	1	Start the drive.
		0	(no op)

Bit	Name	Value	State/Description											
2	REVERSE	1	Reverse direction of motor rotation. See in the table below how this bit and sign of the reference effect the direction of the motor direction. <table border="1" data-bbox="482 261 1023 368"> <thead> <tr> <th rowspan="2"></th> <th colspan="2">Sign of the reference</th> </tr> <tr> <th>Positive (+)</th> <th>Negative (-)</th> </tr> </thead> <tbody> <tr> <td>Bit REVERSE = 0</td> <td>Forward</td> <td>Reverse</td> </tr> <tr> <td>Bit REVERSE = 1</td> <td>Reverse</td> <td>Forward</td> </tr> </tbody> </table>		Sign of the reference		Positive (+)	Negative (-)	Bit REVERSE = 0	Forward	Reverse	Bit REVERSE = 1	Reverse	Forward
			Sign of the reference											
			Positive (+)	Negative (-)										
Bit REVERSE = 0	Forward	Reverse												
Bit REVERSE = 1	Reverse	Forward												
0	(no op)													
3	Reserved													
4	RESET	0=>1	Fault reset if an active fault exists.											
		0	(no op)											
5	EXT2	1	Select External control location EXT2. Effective if the control location is parameterized to be selected from the fieldbus.											
		0	Select External control location EXT1. Effective if the control location is parameterized to be selected from the fieldbus.											
6	RUN_DISABLE	1	Run disable. If the drive is set to receive the run enable signal from the fieldbus, this bit deactivates the signal.											
		0	Run enable. If the drive is set to receive the run enable signal from the fieldbus, this bit activates the signal.											
7	STOPMODE_RAMP	1	Normal ramp stop mode											
		0	(no op) Default to parameter stop mode if bits 7...9 are all 0.											
8	STOPMODE_EMERGENCY_RAMP	1	Emergency ramp stop mode.											
		0	(no op) Default to parameter stop mode if bits 7...9 are all 0.											
9	STOPMODE_COAST	1	Coast stop mode.											
		0	(no op) Default to parameter stop mode if bits 7...9 are all 0.											
10	RAMP_PAIR_2	1	Select ramp set 2 (Acceleration time 2 / Deceleration time 2) when parameter 23.11 Ramp set selection is set to EFB DCU CW bit 10 .											
		0	Select ramp set 1 (Acceleration time 1 / Deceleration time 1) when parameter 23.11 Ramp set selection is set to EFB DCU CW bit 10 .											
11	RAMP_OUT_ZERO	1	Force Ramp Function Generator output to zero. Drive ramps to stop (current and DC voltage limits in force).											
		0	Normal operation.											
12	RAMP_HOLD	1	Halt ramping (Ramp Function Generator output held).											
		0	Normal operation.											
13	RAMP_IN_ZERO	1	Force Ramp Function Generator input to zero.											
		0	Normal operation.											

Bit	Name	Value	State/Description
14	REQ_LOCAL_LOCK	1	Drive does not switch to local control mode (see parameter 19.17 Local control disable).
		0	Drive can switch between local and remote control modes.
15	Reserved		
16	FB_LOCAL_CTL	1	Local mode for control from the fieldbus is requested. Steal control from the active source.
		0	(no op)
17	FB_LOCAL_REF	1	Local mode for reference from the fieldbus is requested. Steal reference from the active source.
		0	(no op)
18	Reserved for RUN_DISABLE_1		Not yet implemented.
19	Reserved		
20	Reserved		
21	Reserved		
22	USER_0		Writable control bits that can be combined with drive logic for application-specific functionality.
23	USER_1		
24	USER_2		
25	USER_3		
26... 31	Reserved		

Status Word

■ Status Word for the ABB Drives profile

The table below shows the fieldbus Status Word for the ABB Drives control profile. The embedded fieldbus interface converts the drive Status Word into this form for the fieldbus. The upper case boldface text refers to the states shown in [State transition diagram for the ABB Drives profile](#) on page 432.

Bit	Name	Value	STATE/Description
0	RDY_ON	1	READY TO SWITCH ON.
		0	NOT READY TO SWITCH ON.
1	RDY_RUN	1	READY TO OPERATE.
		0	OFF1 ACTIVE.
2	RDY_REF	1	OPERATION D.
		0	OPERATION INHIBITED.
3	TRIPPED	1	FAULT.
		0	No fault.
4	OFF_2_STATUS	1	OFF2 inactive.
		0	OFF2 ACTIVE.
5	OFF_3_STATUS	1	OFF3 inactive.
		0	OFF3 ACTIVE.
6	SWC_ON_INHIB	1	SWITCH-ON INHIBITED.
		0	–
7	ALARM	1	Warning/Alarm.
		0	No warning/alarm.
8	AT_SETPOINT	1	OPERATING. Actual value equals Reference (is within tolerance limits, e.g. in speed control, speed error is 10% max. of nominal motor speed).
		0	Actual value differs from Reference (is outside tolerance limits).
9	REMOTE	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.
10	ABOVE_LIMIT	1	Actual frequency or speed equals or exceeds supervision limit (set by drive parameter). Valid in both directions of rotation.
		0	Actual frequency or speed within supervision limit.
11	USER_0		Status bits that can be combined with drive logic for application-specific functionality.
12	USER_1		
13	USER_2		
14	USER_3		
15	Reserved		

■ Status Word for the DCU Profile

The embedded fieldbus interface writes the drive Status Word bits 0 to 15 to the fieldbus Status Word as is. Bits 16 to 32 of the drive Status Word are not in use.


Bit	Name	Value	State/Description
0	READY	1	Drive is ready to receive the start command.
		0	Drive is not ready.
1	D	1	External run enable signal is active.
		0	External run enable signal is not active.
2	Reserved for D_TO_ROTATE		Not yet implemented.
3	RUNNING	1	Drive is modulating.
		0	Drive is not modulating.
4	ZERO_SPEED	1	Drive is at zero speed.
		0	Drive is not at zero speed.
5	ACCELERATING	1	Drive speed is increasing.
		0	Drive speed is not increasing.
6	DECELERATING	1	Drive speed is decreasing.
		0	Drive speed is not decreasing.
7	AT_SETPOINT	1	Drive is at setpoint.
		0	Drive is not at setpoint.
8	LIMIT	1	Drive operation is limited.
		0	Drive operation is not limited.
9	SUPERVISION	1	Actual value (speed, frequency or torque) is above a limit. Limit is set with parameters 46.31...46.33
		0	Actual value (speed, frequency or torque) is within limits.
10	REVERSE_REF	1	Drive reference is in the reverse direction.
		0	Drive reference is in the forward direction
11	REVERSE_ACT	1	Drive is running in the reverse direction
		0	Drive is running in the forward direction
12	PANEL_LOCAL	1	Panel/keypad (or PC tool) is in local control mode.
		0	Panel/keypad (or PC tool) is not in local control mode.
13	FIELDBUS_LOCAL	1	Fieldbus is in local control mode.
		0	Fieldbus is not in local control mode.
14	EXT2_ACT	1	External control location EXT2 is active.
		0	External control location EXT1 is active.
15	FAULT	1	Drive is faulted.
		0	Drive is not faulted.

Bit	Name	Value	State/Description
16	ALARM	1	Warning/Alarm is active.
		0	No warning/alarm.
17	Reserved		
18	Reserved for DIRECTION_LOCK		Not yet implemented.
19	Reserved		
20	Reserved		
21	Reserved		
22	USER_0		Status bits that can be combined with drive logic for application-specific functionality.
23	USER_1		
24	USER_2		
25	USER_3		
26	REQ_CTL	1	Control is requested in this channel.
		0	Control is not requested in this channel.
27... 31	Reserved		

State transition diagrams

■ State transition diagram for the ABB Drives profile

The diagram below shows the state transitions in the drive when the drive is using the ABB Drives profile and the drive is configured to follow the commands of the control word from the embedded fieldbus interface. The upper case texts refer to the states which are used in the tables representing the fieldbus Control and Status words. See sections [Control Word for the ABB Drives profile](#) on page 425 and [Status Word for the ABB Drives profile](#) on page 429.




References

■ References for the ABB Drives profile and DCU Profile

The ABB Drives profile supports the use of two references, EFB reference 1 and EFB reference 2. The references are 16-bit words each containing a sign bit and a 15-bit integer. A negative reference is formed by calculating the two's complement from the corresponding positive reference.

The references are scaled as defined by parameters [46.01...46.04](#); which scaling is in use depends on the setting of [58.26 EFB ref1 type](#) and [58.27 EFB ref2 type](#) (see page [334](#)).




The scaled references are shown by parameters [03.09 EFB reference 1](#) and [03.10 EFB reference 2](#).

Actual values

Actual values for the ABB Drives profile and DCU Profile

The ABB Drives profile supports the use of two fieldbus actual values, ACT1 and ACT2. The actual values are 16-bit words each containing a sign bit and a 15-bit integer. A negative value is formed by calculating the two's complement from the corresponding positive value.

The actual values are scaled as defined by parameters [46.01...46.04](#); which scaling is in use depends on the setting of parameters [58.28 EFB act1 type](#) and [58.29 EFB act2 type](#) (see page [335](#)).



Modbus holding register addresses

■ Modbus holding register addresses for the ABB Drives profile and DCU Profile

The table below shows the default Modbus holding register addresses for the drive data with the ABB Drives profile. This profile provides a converted 16-bit access to the drive data.

Note: Only the 16 least significant bits of the drive's 32-bit Control and Status Words can be accessed.

Note: Bits 16 through 32 of the DCU Control/Status word are not in use if 16-bit control/status word is used with the DCU Profile.

Register address	Register data (16-bit words)
400001	Default: Control word (<i>CW 16bit</i>). See sections <i>Control Word for the ABB Drives profile</i> (page 425) and <i>Control Word for the DCU Profile</i> (page 426). The selection can be changed using parameter <i>58.101 Data I/O 1</i> .
400002	Default: Reference 1 (<i>Ref1 16bit</i>). The selection can be changed using parameter <i>58.104 Data I/O 4</i> .
400003	Default: Reference 2 (<i>Ref2 16bit</i>). The selection can be changed using parameter <i>58.104 Data I/O 4</i> .
400004	Default: Status Word (<i>SW 16bit</i>). See sections <i>Status Word for the ABB Drives profile</i> (page 429) and <i>Status Word for the DCU Profile</i> (page 430). The selection can be changed using parameter <i>58.104 Data I/O 4</i> .
400005	Default: Actual value 1 (<i>Act1 16bit</i>). The selection can be changed using parameter <i>58.105 Data I/O 5</i> .
400006	Actual value 2 (<i>Act2 16bit</i>). The selection can be changed using parameter <i>58.106 Data I/O 6</i> .
400007...400014	Data in/out 7...14. Selected by parameters <i>58.107 Data I/O 7 ...58.114 Data I/O 14</i> .
400015...400089	Unused
400090...400100	Error code access. See section <i>Error code registers (holding registers 400090...400100)</i> (page 443).
400101...465536	Parameter read/write. Parameters are mapped to register addresses according to parameter <i>58.33 Addressing mode</i> .

Modbus function codes

The table below shows the Modbus function codes supported by the embedded fieldbus interface.

Code	Function name	Description
01h	Read Coils	Reads the 0/1 status of coils (0X references).
02h	Read Discrete Inputs	Reads the 0/1 status of discrete inputs (1X references).
03h	Read Holding Registers	Reads the binary contents of holding registers (4X references).
05h	Write Single Coil	Forces a single coil (0X reference) to 0 or 1.
06h	Write Single Register	Writes a single holding register (4X reference).
08h	Diagnostics	<p>Provides a series of tests for checking the communication, or for checking various internal error conditions.</p> <p>Supported subcodes:</p> <ul style="list-style-type: none"> • 00h Return Query Data: Echo/loopback test. • 01h Restart Comm Option: Restarts and initializes the EFB, clears communications event counters. • 04h Force Listen Only Mode • 0Ah Clear Counters and Diagnostic Register • 0Bh Return Bus Message Count • 0Ch Return Bus Comm. Error Count • 0Dh Return Bus Exception Error Count • 0Eh Return Slave Message Count • 0Fh Return Slave No Response Count • 10h Return Slave NAK (negative acknowledge) Count • 11h Return Slave Busy Count • 12h Return Bus Character Overrun Count • 14h Clear Overrun Counter and Flag
0Bh	Get Comm Event Counter	Returns a status word and an event count.
0Fh	Write Multiple Coils	Forces a sequence of coils (0X references) to 0 or 1.
10h	Write Multiple Registers	Writes the contents of a contiguous block of holding registers (4X references).
16h	Mask Write Register	Modifies the contents of a 4X register using a combination of an AND mask, an OR mask, and the register's current contents.
17h	Read/Write Multiple Registers	Writes the contents of a contiguous block of 4X registers, then reads the contents of another group of registers (the same or different than those written) in a server device.

Code	Function name	Description
2Bh / 0Eh	Encapsulated Interface Transport	<p>Supported subcodes:</p> <ul style="list-style-type: none"> • 0Eh Read Device Identification: Allows reading the identification and other information. <p>Supported ID codes (access type):</p> <ul style="list-style-type: none"> • 00h: Request to get the basic device identification (stream access) • 04h: Request to get one specific identification object (individual access) <p>Supported Object IDs:</p> <ul style="list-style-type: none"> • 00h: Vendor Name ("ABB") • 01h: Product Code (for example, "ASCLx or ASCDx") • 02h: Major Minor Revision (combination of contents of parameters 07.05 Firmware version and 58.02 Protocol ID). • 03h: Vendor URL ("www.abb.com") • 04h: Product name: ("ACS560").

Exception codes

The table below shows the Modbus exception codes supported by the embedded fieldbus interface.

Code	Name	Description
01h	ILLEGAL FUNCTION	The function code received in the query is not an allowable action for the server.
02h	ILLEGAL ADDRESS	The data address received in the query is not an allowable address for the server.
03h	ILLEGAL VALUE	The requested quantity of registers is larger than the device can handle. This error does not mean that a value written to the device is outside of the valid range.
04h	DEVICE FAILURE	An unrecoverable error occurred while the server was attempting to perform the requested action. See section Error code registers (holding registers 400090...400100) on page 443 .

Coils (0xxxx reference set)

Coils are 1-bit read/write values. Control Word bits are exposed with this data type. The table below summarizes the Modbus coils (0xxxx reference set). Note that the references are 1-based index which match the address transmitted on the wire.

Reference	ABB Drives profile	DCU Profile
000001	OFF1_CONTROL	STOP
000002	OFF2_CONTROL	START
000003	OFF3_CONTROL	Reserved
000004	INHIBIT_OPERATION	Reserved
000005	RAMP_OUT_ZERO	RESET
000006	RAMP_HOLD	EXT2
000007	RAMP_IN_ZERO	RUN_DISABLE
000008	RESET	STOPMODE_RAMP
000009	JOGGING_1	STOPMODE_EMERGENCY_RAMP
000010	JOGGING_2	STOPMODE_COAST
000011	REMOTE_CMD	Reserved
000012	EXT_CTRL_LOC	RAMP_OUT_ZERO
000013	USER_0	RAMP_HOLD
000014	USER_1	RAMP_IN_ZERO
000015	USER_2	Reserved
000016	USER_3	Reserved
000017	Reserved	FB_LOCAL_CTL
000018	Reserved	FB_LOCAL_REF
000019	Reserved	Reserved
000020	Reserved	Reserved
000021	Reserved	Reserved
000022	Reserved	Reserved
000023	Reserved	USER_0
000024	Reserved	USER_1
000025	Reserved	USER_2
000026	Reserved	USER_3
000027	Reserved	Reserved
000028	Reserved	Reserved
000029	Reserved	Reserved
000030	Reserved	Reserved
000031	Reserved	Reserved
000032	Reserved	Reserved

Reference	ABB Drives profile	DCU Profile
000033	Control for relay output RO1 (parameter <i>10.99 RO/DIO control word</i> , bit 0)	Control for relay output RO1 (parameter <i>10.99 RO/DIO control word</i> , bit 0)
000034	Control for relay output RO2 (parameter <i>10.99 RO/DIO control word</i> , bit 1)	Control for relay output RO2 (parameter <i>10.99 RO/DIO control word</i> , bit 1)
000035	Control for relay output RO3 (parameter <i>10.99 RO/DIO control word</i> , bit 2)	Control for relay output RO3 (parameter <i>10.99 RO/DIO control word</i> , bit 2)
000036	Control for relay output RO4 (parameter <i>10.99 RO/DIO control word</i> , bit 3)	Control for relay output RO4 (parameter <i>10.99 RO/DIO control word</i> , bit 3)
000037	Control for relay output RO5 (parameter <i>10.99 RO/DIO control word</i> , bit 4)	Control for relay output RO5 (parameter <i>10.99 RO/DIO control word</i> , bit 4)

Discrete inputs (1xxxx reference set)

Discrete inputs are 1-bit read-only values. Status Word bits are exposed with this data type. The table below summarizes the Modbus discrete inputs (1xxxx reference set). Note that the references are 1-based index which match the address transmitted on the wire.

Reference	ABB Drives profile	DCU Profile
100001	RDY_ON	READY
100002	RDY_RUN	D
100003	RDY_REF	Reserved
100004	TRIPPED	RUNNING
100005	OFF_2_STATUS	ZERO_SPEED
100006	OFF_3_STATUS	Reserved
100007	SWC_ON_INHIB	Reserved
100008	ALARM	AT_SETPOINT
100009	AT_SETPOINT	LIMIT
100010	REMOTE	SUPERVISION
100011	ABOVE_LIMIT	Reserved
100012	USER_0	Reserved
100013	USER_1	PANEL_LOCAL
100014	USER_2	FIELDBUS_LOCAL
100015	USER_3	EXT2_ACT
100016	Reserved	FAULT
100017	Reserved	ALARM
100018	Reserved	Reserved
100019	Reserved	Reserved
100020	Reserved	Reserved
100021	Reserved	Reserved
100022	Reserved	Reserved
100023	Reserved	USER_0
100024	Reserved	USER_1
100025	Reserved	USER_2
100026	Reserved	USER_3
100027	Reserved	REQ_CTL
100028	Reserved	Reserved
100029	Reserved	Reserved
100030	Reserved	Reserved
100031	Reserved	Reserved
100032	Reserved	Reserved

Reference	ABB Drives profile	DCU Profile
100033	Delayed status of digital input DI1 (parameter 10.02 DI delayed status , bit 0)	Delayed status of digital input DI1 (parameter 10.02 DI delayed status , bit 0)
100034	Delayed status of digital input DI2 (parameter 10.02 DI delayed status , bit 1)	Delayed status of digital input DI2 (parameter 10.02 DI delayed status , bit 1)
100035	Delayed status of digital input DI3 (parameter 10.02 DI delayed status , bit 2)	Delayed status of digital input DI3 (parameter 10.02 DI delayed status , bit 2)
100036	Delayed status of digital input DI4 (parameter 10.02 DI delayed status , bit 3)	Delayed status of digital input DI4 (parameter 10.02 DI delayed status , bit 3)
100037	Delayed status of digital input DI5 (parameter 10.02 DI delayed status , bit 4)	Delayed status of digital input DI5 (parameter 10.02 DI delayed status , bit 4)
100038	Delayed status of digital input DI6 (parameter 10.02 DI delayed status , bit 5)	Delayed status of digital input DI6 (parameter 10.02 DI delayed status , bit 5)

Error code registers (holding registers 400090...400100)

These registers contain information about the last query. The error register is cleared when a query has finished successfully.

Reference	Name	Description
400090	Reset Error Registers	1 = Reset internal error registers (91...95). 0 = Do nothing.
400091	Error Function Code	Function code of the failed query.
400092	Error Code	Set when exception code 04h is generated (see table above). <ul style="list-style-type: none"> • 00h No error • 02h Low/High limit exceeded • 03h Faulty Index: Unavailable index of an array parameter • 05h Incorrect Data Type: Value does not match the data type of the parameter • 65h General Error: Undefined error when handling query
400093	Failed Register	The last register (discrete input, coil, input register or holding register) that failed to be read or written.
400094	Last Register Written Successfully	The last register (discrete input, coil, input register or holding register) that was written successfully.
400095	Last Register Read Successfully	The last register (discrete input, coil, input register or holding register) that was read successfully.

10

Fieldbus control through a fieldbus adapter

What this chapter contains

This chapter describes how the drive can be controlled by external devices over a communication network (fieldbus) through an optional fieldbus adapter module.

The fieldbus control interface of the drive is described first, followed by a configuration example.

System overview


The drive can be connected to an external control system through an optional fieldbus adapter ("fieldbus adapter A" = FBA A) mounted onto the control unit of the drive. The drive can be configured to receive all of its control information through the fieldbus interface, or the control can be distributed between the fieldbus interface and other available sources such as digital and analog inputs, depending on how control locations EXT1 and EXT2 are configured.

Fieldbus adapters are available for various communication systems and protocols, for example:

- PROFIBUS DP (FPBA-01 adapter)
 - PROFINET (FPNO-21)
 - CANopen (FCAN-01 adapter)
 - EtherCAT (FECA-01 adapter)
 - EtherNet/IP (FEIP-21)
 - Modbus/TCP (FMBT-21)
 - EtherNet IPTM/PROFINET IO/Modbus/TCP (FENA-11/-21)
 - ModbusRTU (FSCA-01)
-

Notes:


- The text and examples in this chapter describe the configuration of one fieldbus adapter (FBA A) by parameters [50.01...50.18](#) and parameter groups [51 FBA A settings...53 FBA A data out](#).
- The AC 500 PLC has a free version library called PS553 drives which helps user to communicate and control between PLC and drives easily.



Basics of the fieldbus control interface

The cyclic communication between a fieldbus system and the drive consists of 16- or 32-bit input and output data words. The drive is able to support a maximum of 12 data words (16 bits) in each direction.

Data transmitted from the drive to the fieldbus controller is defined by parameters [52.01 FBA A data in1](#) ... [52.12 FBA A data in12](#). The data transmitted from the fieldbus controller to the drive is defined by parameters [53.01 FBA A data out1](#) [53.12 FBA A data out12](#).



■ Control word and Status word

The Control word is the principal means for controlling the drive from a fieldbus system. It is sent by the fieldbus master station to the drive through the adapter module. The drive switches between its states according to the bit-coded instructions in the Control word, and returns status information to the master in the Status word.

The contents of the Control word and the Status word are detailed on pages [452](#) and [454](#) respectively. The drive states are presented in the state diagram (page [455](#)).

Debugging the network words

If parameter [50.12 FBA A debug mode](#) is set to *Fast* [1], the Control word received from the fieldbus is shown by parameter [50.13 FBA A control word](#), and the Status word transmitted to the fieldbus network by [50.16 FBA A status word](#). This “raw” data is very useful to determine if the fieldbus master is transmitting the correct data before handing control to the fieldbus network.

References

References are 16-bit words containing a sign bit and a 15-bit integer. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference.


ABB drives can receive control information from multiple sources including analog and digital inputs, the drive control panel and a fieldbus adapter module. In order to have the drive controlled through the fieldbus, the module must be defined as the source for control information such as reference. This is done using the source selection parameters in groups [22 Speed reference selection](#), [26 Torque reference chain](#) and [28 Frequency reference chain](#).

Debugging the network words

If parameter [50.12 FBA A debug mode](#) is set to *Fast* [1], the references received from the fieldbus are displayed by [50.14 FBA A reference 1](#) and [50.15 FBA A reference 2](#).

Scaling of references

The references are scaled as defined by parameters [46.01...46.04](#); which scaling is in use depends on the setting of [50.04 FBA A ref1 type](#) and [50.05 FBA A ref2 type](#).



The scaled references are shown by parameters [03.05 FB A reference 1](#) and [03.06 FB A reference 2](#).

Actual values


Actual values are 16-bit words containing information on the operation of the drive. The types of the monitored signals are selected by parameters [50.07 FBA A actual 1 type](#) and [50.08 FBA A actual 2 type](#).

Debugging the network words

If parameter [50.12 FBA A debug mode](#) is set to *Fast* [1], the actual values sent to the fieldbus are displayed by [50.17 FBA A actual value 1](#) and [50.18 FBA A actual value 2](#).


Scaling of actual values

The actual values are scaled as defined by parameters [46.01...46.04](#); which scaling is in use depends on the setting of parameters [50.07 FBA A actual 1 type](#) and [50.08 FBA A actual 2 type](#).



■ Contents of the fieldbus Control word

The upper case boldface text refers to the states shown in the state diagram (page 455).

Bit	Name	Value	STATE/Description
0	Off1 control	1	Proceed to READY TO OPERATE .
		0	Stop along currently active deceleration ramp. Proceed to OFF1 ACTIVE ; proceed to READY TO SWITCH ON unless other interlocks (OFF2, OFF3) are active.
1	Off2 control	1	Continue operation (OFF2 inactive).
		0	Emergency OFF, coast to a stop. Proceed to OFF2 ACTIVE ; proceed to SWITCH-ON INHIBITED .
2	Off3 control	1	Continue operation (OFF3 inactive).
		0	Emergency stop, stop within time defined by drive parameter. Proceed to OFF3 ACTIVE ; proceed to SWITCH-ON INHIBITED .  WARNING: Ensure motor and driven machine can be stopped using this stop mode.
3	Run	1	Proceed to OPERATION D . Note: Run enable signal must be active; see drive documentation. If the drive is set to receive the Run enable signal from the fieldbus, this bit activates the signal.
		0	Inhibit operation. Proceed to OPERATION INHIBITED .
4	Ramp out zero	1	Normal operation. Proceed to RAMP FUNCTION GENERATOR: OUTPUT D .
		0	Force Ramp function generator output to zero. The drive will immediately decelerate to zero speed (observing the torque limits).
5	Ramp hold	1	ramp function. Proceed to RAMP FUNCTION GENERATOR: ACCELERATOR D .
		0	Halt ramping (Ramp Function Generator output held).
6	Ramp in zero	1	Normal operation. Proceed to OPERATING . Note: This bit is effective only if the fieldbus interface is set as the source for this signal by drive parameters.
		0	Force Ramp function generator input to zero.
7	Reset	0=>1	Fault reset if an active fault exists. Proceed to SWITCH-ON INHIBITED . Note: This bit is effective only if the fieldbus interface is set as the source of the reset signal by drive parameters.
		0	Continue normal operation.
8	Inching 1	1	Accelerate to inching (jogging) setpoint 1. Notes: • Bits 4...6 must be 0. • See also section <i>Rush control</i> (page 73).
		0	Inching (jogging) 1 disabled.
9	Inching 2	1	Accelerate to inching (jogging) setpoint 2. See notes at bit 8.
		0	Inching (jogging) 2 disabled.
10	Remote cmd	1	Fieldbus control d.
		0	Control word and reference not getting through to the drive, except for bits 0...2.
11	Ext ctrl loc	1	Select External Control Location EXT2. Effective if control location is parameterized to be selected from fieldbus.
		0	Select External Control Location EXT1. Effective if control location is parameterized to be selected from fieldbus.


Bit	Name	Value	STATE/Description
12	User bit 0	1	User configurable
		0	
13	User bit 1	1	
		0	
14	User bit 2	1	
		0	
15	User bit 3	1	
		0	

■ Contents of the fieldbus Status word

The upper case boldface text refers to the states shown in the state diagram (page 455).

Bit	Name	Value	STATE/Description
0	Ready to switch ON	1	READY TO SWITCH ON.
		0	NOT READY TO SWITCH ON.
1	Ready run	1	READY TO OPERATE.
		0	OFF1 ACTIVE.
2	Ready ref	1	OPERATION D.
		0	OPERATION INHIBITED.
3	Tripped	1	FAULT.
		0	No fault.
4	Off 2 inactive	1	OFF2 inactive.
		0	OFF2 ACTIVE.
5	Off 3 inactive	1	OFF3 inactive.
		0	OFF3 ACTIVE.
6	Switch-on inhibited	1	SWITCH-ON INHIBITED.
		0	-
7	Warning	1	Warning active.
		0	No warning active.
8	At setpoint	1	OPERATING. Actual value equals reference = is within tolerance limits (see parameters 46.21...46.22).
		0	Actual value differs from reference = is outside tolerance limits.
9	Remote	1	Drive control location: REMOTE (EXT1 or EXT2).
		0	Drive control location: LOCAL.
10	Above limit	-	See bit 10 of 06.17 Drive status word 2 .
11	User bit 0	-	See parameter 06.30 MSW bit 11 selection .
12	User bit 1	-	See parameter 06.31 MSW bit 12 selection .
13	User bit 2	-	See parameter 06.32 MSW bit 13 selection .
14	User bit 3	-	See parameter 06.33 MSW bit 14 selection .
15	Reserved		

■ The state diagram



Automatic drive configuration for fieldbus control

Automatic drive configuration for fieldbus control

The parameters set on module detection are shown in the table below. See also parameters [07.35 Drive configuration](#) and [07.36 Drive configuration 2](#).

Notes:

- The optional modules BIO-01 and RIIO-01 are applicable only for frames R0...R2.
- No parameter changes are done for C-series modules. c-series modules are only supported in frames R3...R8.

Option	10.24 RO1 source	10.27 RO2 source	10.30 RO3 source	20.01 Ext1 commands	20.03 Ext1 in1 source	20.04 Ext1 in2 source
BIO-01	-	-	-	2 (In1 Start, In2 Dir)	2 (DI1)	3 (DI2)
RIIO-01	-	-	-	2 (In1 Start, In2 Dir)	2 (DI1)	3 (DI2)
FENA-21	-	-	-	-	-	-
FECA-01	-	-	-	-	-	-
FPBA-01	-	-	-	-	-	-
FCAN-01	-	-	-	-	-	-
FSCA-01	-	-	-	-	-	-
FEIP-21	-	-	-	-	-	-
FMBT-21	-	-	-	-	-	-
FPNO-21	-	-	-	-	-	-
FEPL-02	-	-	-	-	-	-
FDNA-01	-	-	-	-	-	-
FCNA-01	-	-	-	-	-	-

Option	22.11 Ext1 speed ref1	22.22 Constant speed sel1	22.23 Constant speed sel2
BIO-01	1 (AI1 scaled)	4 (DI3)	5 (DI4)
RIIO-01	1 (AI1 scaled)	4 (DI3)	5 (DI4)
FENA-21	-	-	-
FECA-01	-	-	-
FPBA-01	-	-	-
FCAN-01	-	-	-
FSCA-01	-	-	-
FEIP-21	-	-	-
FMBT-21	-	-	-
FPNO-21	-	-	-
FEPL-02	-	-	-
FDNA-01	-	-	-
FCNA-01	-	-	-

Option	23.11 Ramp set selection	28.11 Ext1 frequency ref1	28.22 Constant frequency sel1	28.23 Constant frequency sel2
BIO-01	6 (DI5)	1 (AI1 scaled)	4 (DI3)	5 (DI4)
RIO-01	6 (DI5)	1 (AI1 scaled)	4 (DI3)	5 (DI4)
FENA-21	-	-	-	-
FECA-01	-	-	-	-
FPBA-01	-	-	-	-
FCAN-01	-	-	-	-
FSCA-01	-	-	-	-
FEIP-21	-	-	-	-
FMBT-21	-	-	-	-
FPNO-21	-	-	-	-
FEPL-02	-	-	-	-
FDNA-01	-	-	-	-
FCNA-01	-	-	-	-

Option	28.71 Freq ramp set selection	31.11 Fault reset selection
BIO-01	6 (DI5)	0
RIO-01	6 (DI5)	0
FENA-21	-	-
FECA-01	-	-
FPBA-01	-	-
FCAN-01	-	-
FSCA-01	-	-
FEIP-21	-	-
FMBT-21	-	-
FPNO-21	-	-
FEPL-02	-	-
FDNA-01	-	-
FCNA-01	-	-

Option	50.01 FBA A enable	50.02 FBA A comm loss func	51.02 FBA A Par2	51.04 FBA A Par4
BIO-01	0	0	-	-
RIO-01	0	0	-	-
FENA-21	1 (Enable)	0	11	0
FECA-01	1 (Enable)	0	0	-
FPBA-01	1 (Enable)	0	-	-
FCAN-01	1 (Enable)	0	-	-
FSCA-01	1 (Enable)	0	-	-

Option	50.01 FBA A enable	50.02 FBA A comm loss func	51.02 FBA A Par2	51.04 FBA A Par4
FEIP-21	1 (Enable)	0	100	0
FMBT-21	1 (Enable)	0	0	0
FPNO-21	1 (Enable)	0	11	0
FEPL-02	1 (Enable)	0	-	-
FDNA-01	1 (Enable)	0	-	-
FCNA-01	1 (Enable)	0	-	-

Option	51.05 FBA A Par5	51.06 FBA A Par6	51.07 FBA A Par7	51.08 FBA A Par8	51.09 FBA A Par9
BIO-01	-	-	-	-	-
RIIO-01	-	-	-	-	-
FENA-21	192	168	0	10	24
FECA-01	0	0	0	0	0
FPBA-01	1	-	-	-	0
FCAN-01	0	-	-	-	-
FSCA-01	-	10	1	-	-
FEIP-21	-	-	-	-	128
FMBT-21	-	-	-	1	-
FPNO-21	-	-	-	-	-
FEPL-02	-	-	-	-	-
FDNA-01	-	-	-	-	-
FCNA-01	-	-	-	-	-

Option	51.21 FBA A Par21	51.23 FBA A Par23	51.24 FBA A Par24
BIO-01	-	-	-
RIIO-01	-	-	-
FENA-21	-	-	-
FECA-01	-	-	-
FPBA-01	-	-	-
FCAN-01	-	-	-
FSCA-01	-	-	-
FEIP-21	-	128	128
FMBT-21	1	-	-
FPNO-21	-	-	-
FEPL-02	-	-	-
FDNA-01	-	-	-
FCNA-01	-	-	-

Option	52.01 FBA data in1	52.02 BA data in2	53.01 FBA data out1	53.02 FBA data out2	58.01 Protocol enable*
BIO-01	-	-	-	-	-
RIO-01	-	-	-	-	-
FENA-21	4	5	1	2	0
FECA-01	-	-	-	-	0
FPBA-01	4	5	1	2	0
FCAN-01	-	-	-	-	0
FSCA-01	-				0
FEIP-21	-	-	-	-	0
FMBT-21	-	-	-	-	0
FPNO-21	4	5	1	2	0
FEPL-02	-	-	-	-	0
FDNA-01	-	-	-	-	0
FCNA-01	-	-	-	-	0

*Parameter 58.01 is set to 0 in frames R0...R2.

Setting up the drive for fieldbus control manually

1. Install the fieldbus adapter module mechanically and electrically according to the instructions given in the *User's manual* of the module.
 2. Power up the drive.
 3. Enable the communication between the drive and the fieldbus adapter module with parameter [50.01 FBA A enable](#).
 4. With [50.02 FBA A comm loss func](#), select how the drive should react to a fieldbus communication break.
Note: This function monitors both the communication between the fieldbus master and the adapter module and the communication between the adapter module and the drive.
 5. With [50.03 FBA A comm loss t out](#), define the time between communication break detection and the selected action.
 6. Select application-specific values for the rest of the parameters in group [50 Fieldbus adapter \(FBA\)](#), starting from [50.04](#). Examples of appropriate values are shown in the tables below.
 7. Set the fieldbus adapter module configuration parameters in group [51 FBA A settings](#). As a minimum, set the required node address and the communication profile.
 8. Define the process data transferred to and from the drive in parameter groups [52 FBA A data in](#) and [53 FBA A data out](#).
Note: Depending on the communication protocol and profile being used, the Control word and Status word may already be configured to be sent/received by the communication system.
 9. Save the valid parameter values to permanent memory by setting parameter [96.07 Parameter save manually](#) to [Save](#).
 10. Validate the settings made in parameter groups 51, 52 and 53 by setting parameter [51.27 FBA A par refresh](#) to [Configure](#).
 11. Configure control locations EXT1 and EXT2 to allow control and reference signals to come from the fieldbus. Examples of appropriate values are shown in the tables below.
-

■ Parameter setting example: FPBA (PROFIBUS)

This example shows how to configure a basic speed control application that uses the PROFIdrive communication profile with PPO Type 2. The start/stop commands and reference are according to the PROFIdrive profile, speed control mode.

The reference values sent over the fieldbus have to be scaled within the drive so they have the desired effect. The reference value ± 16384 (4000h) corresponds to the range of speed set in parameter [46.01 Speed scaling](#) (both forward and reverse directions). For example, if [46.01](#) is set to 480 rpm, then 4000h sent over fieldbus will request 480 rpm.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control word	Speed reference	Acc time 1		Dec time 1	
In	Status word	Speed actual value	Motor current		DC voltage	

The table below gives the recommended drive parameter settings.

Drive parameter	Setting for ACS 560 drives	Description
50.01 FBA A enable	1 = [slot number]	Enables communication between the drive and the fieldbus adapter module.
50.04 FBA A ref1 type	4 = <i>Speed</i>	Selects the fieldbus A reference 1 type and scaling.
50.07 FBA A actual 1 type	0 = <i>Speed or frequency</i>	Selects the actual value type and scaling according to the currently active Ref1 mode defined in parameter 50.04 .
51.01 FBA A type	1 = FPBA ¹⁾	Displays the type of the fieldbus adapter module.
51.02 Node address	3 ²⁾	Defines the PROFIBUS node address of the fieldbus adapter module.
51.03 Baud rate	12000 ¹⁾	Displays the current baud rate on the PROFIBUS network in kbit/s.
51.04 MSG type	1 = PPO2 ¹⁾	Displays the telegram type selected by the PLC configuration tool.
51.05 Profile	0 = PROFIdrive	Selects the Control word according to the PROFIdrive profile (speed control mode).
51.07 RPBA mode	0 = Disabled	Disables the RPBA emulation mode.
52.01 FBA data in1	4 = SW 16bit ¹⁾	Status word
52.02 FBA data in2	5 = Act1 16bit	Actual value 1
52.03 FBA data in3	01.07 ²⁾	Motor current
52.05 FBA data in5	01.11 ²⁾	DC voltage
53.01 FBA data out1	1 = CW 16bit ¹⁾	Control word
53.02 FBA data out2	2 = Ref1 16bit	Reference 1 (speed)
53.03 FBA data out3	23.12 ²⁾	Acceleration time 1

Drive parameter	Setting for ACS 560 drives	Description
53.05 FBA data out5	23.13 ²⁾	Deceleration time 1
<i>51.27 FBA A par refresh</i>	1 = Configure	Validates the configuration parameter settings.
<i>19.12 Ext1 control mode</i>	2 = Speed	Selects speed control as the control mode 1 for external control location EXT1.
<i>20.01 Ext1 commands</i>	12 = Fieldbus A	Selects fieldbus adapter A as the source of the start and stop commands for external control location EXT1.
<i>20.02 Ext1 start trigger type</i>	1 = Level	Selects a level-triggered start signal for external control location EXT1.
<i>22.11 Ext1 speed ref1</i>	4 = FB A ref1	Selects fieldbus A reference 1 as the source for speed reference 1.


¹⁾ Read-only or automatically detected/set

²⁾ Example

The start sequence for the parameter example above is given below.

Control word:

- 477h (1143 decimal) → READY TO SWITCH ON
- 47Fh (1151 decimal) → OPERATING (Speed mode)

11

Control chain diagrams


Contents of this chapter

The chapter presents the reference chains of the drive. The control chain diagrams can be used to trace how parameters interact and where parameters have an effect within the drive parameter system.


For a more general diagram, see section [Operating modes of the drive](#) (page 37).

Note: The reference to group 24 parameters in control chain diagrams can be ignored. Group 24 Speed reference conditioning is not available in ACS560.


Frequency reference selection




Speed reference source selection I




Speed reference source selection II




Speed reference ramping and shaping




Speed feedback




Speed error calculation




Speed controller




Torque reference source selection and modification




Reference selection for torque controller



Torque limitation




Process PID setpoint and feedback source selection




Note! Process PID parameter set 2 is also available. See parameter group 41.

Process PID controller




External PID setpoint and feedback source selection




Note! Process PID parameter set 2 is also available. See parameter group 41.

External PID controller




Override

OVERRIDE



PID trim auto connection

PID TRIM AUTO CONNECTION



12

Parameterization with drive composer

Contents of this chapter

The chapter describes about the drive composer application and how drive parameters can be managed with the drive composer.

Drive composer

Drive composer is a 32-bit PC tool used for commissioning and maintaining ABB common architecture drives. The drive composer can be connected to a drive that has assistant panel or a dummy panel. The full version is called Drive composer pro and the free version is called Drive composer entry. The drive composer free version is available for download from [ABB website](#).

Note: The drive composer cannot be connected to the basic panel.

You can perform following actions with the drive composer:

- View and adjust drive parameters.
- Control a drive: start, stop, direction, speed/torque/frequency reference.
- Monitor the operation and status of a drive.
- Monitor signals in numerical and graphical (trending) format.
- Work simultaneously with multiple drives like master and follower drives (pro).
- Display control diagrams of a drive for parameter setting and diagnostic purposes (pro).
- Create user-specific workspaces by customizing parameter windows.
- Configure the optional FSO-11 and FSO-12 safety functions module (pro).
- Handle workspaces.
- Create and execute macro scripts (pro).

How to connect the drive composer

To establish a connection between the Drive composer and the drive you need to meet the following requirements:


- Computer with drive composer installed
- Assistant control panel or Dummy panel
- Mini USB cable (assistant control panel) or BCBL-01 cable (dummy panel)

Communication Connection

- Use BCBL-01 cable to connect the drive with a dummy panel. Connect BCBL-01 cable to the RJ 45 port of the panel and the other end to the USB port of your computer. You can order the BCBL-01 with the order ID *3AXD50000032449*.
- Use a mini USB cable to connect the drive with an assistant panel.
- Use Ethernet-based fieldbus adapter modules for PC tool communication (one-wire solution, Profinet, Ethernet IP) (pro) or a drive-embedded Ethernet port
- Use an OPC-based commissioning and maintenance tool (pro).

Both versions include a demo that allows testing user interface functionality, edit parameter files offline (pro) or open and analyze saved monitored files without connecting to a physical drive.

Connection Diagram (with assistant panel)



For more information, see *Drive composer start-up and maintenance PC tool user's manual* (3AUA0000094606[English]).

13

Parameterization with automation builder drive manager

Contents of this chapter

The chapter describes about the automation builder drive manager application and how drive parameters can be managed with the automation builder drive manager.

Automation builder drive manager

Automation builder drive manager is a software tool that enables you to configure ABB drives connected to the PLC through PROFIBUS or PROFINET.

You can perform the following actions with the automation builder drive manager:

- Monitor the drive status like Running, Stopped, EXT1/EXT2 and Running direction.
 - Monitor the drive parameter groups and parameters.
 - Monitor the drive firmware version and properties.
 - Monitor the drive parameter values along with the parameter attributes like parameter minimum and maximum settings, parameter units and parameter protection status.
 - User can edit parameters in offline view and then copy to drive when online.
 - Open the offline drive parameter settings (project view) and compare to the online drive parameters. The compare function shows the parameters with different
-

settings in offline and online mode. User can also download the parameter values which have differences in offline and online settings.

- Export the drive parameters from Drive Manager to the respective standalone drive tool parameter file formats (.dsp, mdwp, dcparamsbak).
- Import the drive parameters (.dsp, dwp, dcparamsbak) to the Drive Manager and compare the parameter values of the file with the project view file.
- Update and save a group or a single parameter to the drive.

Connection Diagram



Parameter view with drive manager

The screenshot displays the 'ACS880_PROFIBUS' configuration window. On the left, a navigation pane includes 'Process data', 'Drive Management', 'Monitoring', 'General', 'I/O mapping list', 'Check configuration', and 'Information'. The 'Configuration' section shows: Station address: 3, Drive type: ACS880, Drive firmware: AINP2.02.01.00, and Drive rating: Unconfigured. A 'Settings...' button is located below these fields. The 'Drive' section shows an 'Unknown' status with a red lightning bolt icon and a 'Connect' button. At the bottom, it indicates 'Last full refresh: never'. The 'Parameters' section on the right shows a list of parameters under the 'Project' tab. The parameters are organized into folders and include columns for 'Min', 'Max', and 'Default'. Buttons for 'Parameter locking' and 'Export to File' are at the bottom of the parameter list.

Parameter name	Project	Min	Max	Default
1 Actual values				
3 Input references				
4 Warnings and faults				
5 Diagnostics				
6 Control and status words				
7 System info				
10 Standard DI, RO				
11 Standard DIO, FI, FO				
12 Standard AI				
13 Standard AO				
14 I/O extension module 1				
15 I/O extension module 2				
16 I/O extension module 3				
19 Operation mode				
20 Start/stop/direction				
21 Start/stop mode				
22 Speed reference selection				

For more information on automation builder application download, purchase see <http://new.abb.com/plc/automationbuilder/platform/software>. The information about configuring automation builder with drive and other details are available in the online help of the application.

Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at abb.com/drives/documents.



abb.com/drives



3AXD50000042620F