

ReliaGear® neXT

Dual Main Lugs


WARNING

Danger of electrical shock or injury. Turn OFF power ahead of the panel board or switchboard before working inside the equipment or removing any component. Equipment is to be installed and maintained by properly trained and qualified personnel only.




					
Dual Mechanical lugs			Dual Compression lugs		
A		2X	H		2X
B		1X	I		1X
C		12X	J		1X
D		24X	K		6X
E		24X	L		2X
F		24X	M		12X
G		24X	N		12X
			O		8X
			P		8X
			Q		8X
			E		32X
			F		24X
			G		24X


1 Phase terminals




2 Mechanical lugs setup




3 Compression lugs adapter setup




4 Barrier




5 Side compression lugs




6 Center compression lugs



7 Barrier tab setup



8 Barrier tab covering



Disclaimer: These instructions do not cover all details or variations in equipment nor do they provide for every possible contingency that may be met in connection with installation, operation or maintenance. Should further information be desired or should particular problems arise that are not covered sufficiently for the purchaser's purposes, the matter should be referred to the ABB Company.

ABB Inc.
305 Gregson Drive
Cary, NC 27511

abb.com

ReliaGear® neXT | ABB

We reserve the right to make technical changes or modify the contents of this document without prior notice. With regard to purchase orders, the agreed particulars shall prevail. ABB AG does not accept any responsibility whatsoever for potential errors or possible lack of information in this document.

We reserve all rights in this document and in the subject matter and illustrations contained therein. Any reproduction, disclosure to third parties or utilization of its contents – in whole or in parts – is forbidden without prior written consent of ABB AG. Copyright © 2019 ABB. All rights reserved.

DOC. N.° 15QC900009M0201