

# ***INSTRUCTION MANUAL***

## **Universal Pneumatic Rotary Actuator Type UP**



PN25059A



---

## Trademarks and Registrations

Registrations and trademarks used in this document include:

- ® Dow Corning is a registered trademark of Dow Corning Corporation.
- ® GE and Silmate are registered trademarks of General Electric Corporation
- ® Loctite is a registered trademark of the Loctite Corporation.

**WARNING** notices as used in this manual apply to hazards or unsafe practices which could result in personal injury or death.

**CAUTION** notices apply to hazards or unsafe practices which could result in property damage.

**NOTES** highlight procedures and contain information which assist the operator in understanding the information contained in this manual.

All software, including design, appearance, algorithms and source codes, is copyrighted by ABB Inc. and is owned by ABB Inc. or its suppliers.

### WARNING

**POSSIBLE PROCESS UPSETS.** Maintenance must be performed only by qualified personnel and only after securing equipment controlled by this product. Adjusting or removing this product while it is in the system may upset the process being controlled. Some process upsets may cause injury or damage.

### NOTICE

The information contained in this document is subject to change without notice.

ABB Inc., its affiliates, employees, and agents, and the authors of and contributors to this publication specifically disclaim all liabilities and warranties, express and implied (including warranties of merchantability and fitness for a particular purpose), for the accuracy, currency, completeness, and/or reliability of the information contained herein and/or for the fitness for any particular use and/or for the performance of any material and/or equipment selected in whole or part with the user of/or in reliance upon information contained herein. Selection of materials and/or equipment is at the sole risk of the user of this publication.

This document contains proprietary information of ABB Inc., and is issued in strict confidence. Its use, or reproduction for use, for the reverse engineering, development or manufacture of hardware or software described herein is prohibited. No part of this document may be photocopied or reproduced without the prior written consent of ABB Inc..

---

# Table of Contents (continued)

	<i>Page</i>
<b>SECTION 1 - INTRODUCTION</b> .....	<b>1-1</b>
OVERVIEW .....	1-1
INTENDED USER .....	1-1
EQUIPMENT DESCRIPTION.....	1-1
FEATURES.....	1-2
EQUIPMENT APPLICATION.....	1-2
INSTRUCTION CONTENT.....	1-2
HOW TO USE THIS INSTRUCTION.....	1-3
REFERENCE DOCUMENTS .....	1-3
NOMENCLATURE.....	1-4
SPECIFICATIONS.....	1-6
OPTIONS AND ACCESSORIES.....	1-8
SHIPPING WEIGHTS.....	1-10
STROKE TIME GRAPHS.....	1-11
<b>SECTION 2 - DESCRIPTION AND OPERATION</b> .....	<b>2-1</b>
INTRODUCTION.....	2-1
Types UP__A and UP__B Actuators .....	2-2
Types UP__C and UP__D Actuators .....	2-2
Type UP__E Actuators.....	2-2
Types UP__5, UP__8 and UP__F Actuators .....	2-2
Types UP__6, UP__9 and UP__G Actuators .....	2-2
Type UP6_0 Actuators.....	2-3
<b>SECTION 3 - INSTALLATION</b> .....	<b>3-1</b>
INTRODUCTION.....	3-1
UNPACKING AND INSPECTION.....	3-1
LOCATION CONSIDERATIONS.....	3-1
ENCLOSURE REMOVAL.....	3-2
Type UP1 Actuator.....	3-2
Type UP2 Actuator.....	3-2
Side Panel .....	3-2
Top Cover.....	3-2
Types UP3 and UP4 Actuator.....	3-3
Side Cover.....	3-3
Top Cover.....	3-4
Types UP5 and UP6 Actuator.....	3-6
Bottom Side Cover.....	3-6
Top Cover.....	3-7
Top Side Cover.....	3-7
WIRING CONNECTIONS, TUBING CONNECTIONS AND CABLING.....	3-7
Connecting Tubing .....	3-7
Connecting Wiring.....	3-8
Grounding .....	3-8
Air Quality.....	3-10
Characterizable Pneumatic Positioner Tubing.....	3-11
Types UP1 And UP2 Actuators.....	3-11
Types UP3 And UP4 Actuators .....	3-12

---

## Table of Contents (continued)

	<i>Page</i>
Types UP5 AND UP6 Actuators .....	3-12
Characterizable I/P Positioner Tubing and Wiring .....	3-13
Types UP1 And UP2 Actuators .....	3-13
Types UP3 And UP4 Actuators .....	3-13
Types UP5 And UP6 Actuators .....	3-14
Solenoid Tubing and Wiring .....	3-14
Types UP1 And UP2 Actuators .....	3-14
Types UP3 And UP4 Actuators .....	3-14
Types UP5 And UP6 Actuators .....	3-15
Master/Slave Tubing Connections for Type UP6 Actuators .....	3-17
INSTALLATION OF OPTIONAL EQUIPMENT .....	3-19
Reserve Air Tank Tubing and Wiring .....	3-19
Type UP2 Actuators .....	3-19
Types UP3 Through UP6 Actuators .....	3-21
Air Failure Lock Tubing .....	3-22
Type UP1 Actuator .....	3-23
Type UP2 Actuator .....	3-24
Types UP3 And UP4 Actuators .....	3-26
Types UP5 And UP6 Actuators .....	3-29
Pneumatic Shaft Position Transmitter Tubing for Types UP2 through UP6 Actuators .. 3-30	
Types UP2, UP3 And UP4 Actuators .....	3-31
Types UP5 And UP6 Actuators .....	3-31
Volume Booster Tubing for Type UP6 Actuators .....	3-31
Alarm/Travel Switch Contact Wiring for Types UP1 through UP6 Actuators .....	3-31
Type UP1 Actuator .....	3-32
Type UP2 Actuator .....	3-33
Types UP3 And UP4 Actuators .....	3-33
Types UP5 And UP6 Actuators .....	3-33
Electric Shaft Position Transmitter Wiring for Types UP1 through UP6 Actuators .....	3-34
Type UP1 Actuator .....	3-35
Type UP2 Actuator .....	3-35
Types UP3 And UP4 Actuators .....	3-36
Types UP5 And UP6 Actuators .....	3-36
Reverse Loading Wiring For Electric Shaft Position Transmitters .....	3-37
Strip Heater Wiring for Types UP2 through UP6 Actuators .....	3-37
Type UP2 Actuator .....	3-38
Types UP3 And UP4 Actuators .....	3-38
Types UP5 And UP6 Actuators .....	3-38
PRE-OPERATING ADJUSTMENTS .....	3-38
Control Loading Arrangements .....	3-38
Positioner Control Loading Arrangements .....	3-38
Solenoid Valve Control Loading Arrangements .....	3-39
Operating Lever Adjustment .....	3-40
Type UP1 Actuator .....	3-40
Type UP2 Actuator .....	3-40
Types UP3/4/5/6 Actuators .....	3-41
Position Indicator .....	3-41
Types UP1 And UP2 Actuators .....	3-41

---

## Table of Contents (continued)

	<i>Page</i>
Types UP3/4/5/6 Actuators.....	3-41
Mechanical Stop Adjustment for Types UP1 and UP2 Actuators .....	3-42
<hr/>	
<b>SECTION 4 - CALIBRATION .....</b>	<b>4-1</b>
INTRODUCTION .....	4-1
EQUIPMENT REQUIRED FOR CALIBRATION.....	4-1
CALIBRATION PROCEDURES .....	4-1
Positioner Access.....	4-1
Zero Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators .....	4-1
Span Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators .....	4-2
Speed Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators .....	4-3
Gain Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators.....	4-3
OPTIONAL EQUIPMENT CALIBRATION .....	4-3
Electric Shaft Position Transmitter Calibration for Types UP1 through UP6 Actuators .	4-4
Alarm/Travel Switch Calibration .....	4-4
Pneumatic Shaft Position Transmitter Calibration.....	4-5
Reserve Air Tank Calibration .....	4-5
Volume Booster Calibration .....	4-5
Air Failure Lock Calibration .....	4-5
Trip Valve Adjustment For Types UP1 Through UP6 Actuators.....	4-6
Lock Valve Adjustment For Types UP3/4/5/6 Actuators.....	4-7
<hr/>	
<b>SECTION 5 - OPERATING PROCEDURES.....</b>	<b>5-1</b>
INTRODUCTION .....	5-1
NORMAL OPERATING CONSIDERATIONS.....	5-1
TYPES UP1 AND UP2 ACTUATOR OPERATION .....	5-2
Positioner-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation .....	5-2
Positioner-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation .....	5-4
Solenoid-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation .....	5-4
Solenoid-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation .....	5-4
Remote Reset Air Failure Lock Equipped Types UP1 and UP2 Actuators – Transfer from Automatic to Manual Operation .....	5-5
Remote Reset Air Failure Lock Equipped Types UP1 and UP2 Actuators – Transfer from Manual to Automatic Operation .....	5-5
TYPES UP3 AND UP4 ACTUATOR OPERATION .....	5-6
Positioner-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation .....	5-6
Positioner-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation .....	5-6
METHOD A – CHANGING THE INPUT SIGNAL TO MATCH THE ACTUATOR POSITION	5-7
Method B – Manually Positioning The Actuator To Match The Input Signal.....	5-7
Solenoid-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation .....	5-8
Solenoid-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer	

---

## Table of Contents (continued)

	<i>Page</i>
from Manual to Automatic Operation .....	5-9
Remote Reset Air Failure Lock Equipped Types UP3 and UP4 Actuators – Transfer from Automatic to Manual Operation .....	5-9
Remote Reset Air Failure Lock Equipped Types UP3 and UP4 Actuators – Transfer from Manual to Automatic Operation .....	5-10
TYPES UP5 AND UP6 ACTUATOR OPERATION .....	5-10
Positioner-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation .....	5-10
Positioner-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation .....	5-11
Method A – Changing The Input Signal To Match The Actuator Position .....	5-12
Method B – Manually Positioning The Actuator To Match The Input Signal ...	5-12
Solenoid-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation .....	5-12
Solenoid-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation .....	5-13
Remote Reset Air Failure Lock Equipped Types UP5 and UP6 Actuators – Transfer from Automatic to Manual Operation .....	5-13
Remote Reset Air Failure Lock Equipped Types UP5 and UP6 Actuators – Transfer from Manual to Automatic Operation .....	5-14

---

<b>SECTION 6 - TROUBLESHOOTING .....</b>	<b>6-1</b>
INTRODUCTION .....	6-1
PROBLEM DETERMINATION AND VERIFICATION PROCEDURE .....	6-1

---

<b>SECTION 7 - MAINTENANCE .....</b>	<b>7-1</b>
INTRODUCTION .....	7-1
PERIODIC MAINTENANCE .....	7-1
ANNUAL OR SEMIANNUAL MAINTENANCE .....	7-2
MAINTENANCE AS REQUIRED .....	7-3

---

<b>SECTION 8 - REPAIR AND REPLACEMENT PROCEDURES .....</b>	<b>8-1</b>
INTRODUCTION .....	8-1
ENCLOSURE REMOVAL .....	8-2
POSITIONER REMOVAL AND REPLACEMENT .....	8-2
SOLENOID VALVE REMOVAL AND REPLACEMENT .....	8-3
ROTARY VANE REMOVAL AND REPLACEMENT (TYPES UP1 AND UP2 ACTUATORS) 8-3	8-3
ROTARY VANE SEAL REPAIR AND HOUSING CLEANING .....	8-5
CYLINDER ASSEMBLY REPLACEMENT (TYPES UP3/4/5/6 ACTUATORS) .....	8-7
CYLINDER ASSEMBLY REPAIR AND CLEANING .....	8-7
CLUTCH FORK INSPECTION AND REPLACEMENT (TYPES UP5 AND UP6 ACTUA- TORS) .....	8-13
ROLLER CHAIN ADJUSTMENT (TYPES UP5 AND UP6 ACTUATORS) .....	8-14
OPTIONAL EQUIPMENT REPAIR/REPLACEMENT PROCEDURES .....	8-15
Reserve Air Tank Component Removal and Replacement (Types UP2 through UP6 Actuators) .....	8-16
Trip Valve Removal And Replacement .....	8-16

---

# Table of Contents (continued)

	<i>Page</i>
Pressure Switch Removal And Replacement .....	8-16
Air Failure Lock Component Removal and Replacement (Types UP1 and UP2 Actuators) .....	8-17
Trip Valve Replacement .....	8-17
Latching Spring Return Cylinder Replacement .....	8-17
Automatic Mechanically Actuated Equalizing Valve Replacement .....	8-18
Air Failure Lock Component Removal and Replacement (Types UP3 through UP6 Actuators) .....	8-18
Lock UPValves Removal And Replacement .....	8-19
Trip Valve Removal And Replacement .....	8-19
Pressure Switch Removal And Replacement .....	8-19
Electric Shaft Position Transmitter Assembly Removal and Replacement .....	8-20
Feedback Potentiometer Removal and Replacement .....	8-21
Alarm/Travel Switch Removal and Replacement .....	8-21
Pneumatic Shaft Position Transmitter Replacement (Types UP2 through UP6 Actuators) .....	8-22
Strip Heater Replacement (Types UP2 through UP6 Actuators) .....	8-23
Thermoswitch Replacement (Types UP2 through UP6 Actuators) .....	8-24
Volume Booster Replacement (Type UP6 Actuators) .....	8-24

---

## **SECTION 9 - SUPPORT SERVICES** .....

INTRODUCTION .....	9-1
REPLACEMENT PARTS .....	9-1
TRAINING .....	9-1
TECHNICAL DOCUMENTATION .....	9-1

---

## **APPENDIX A - SPARE PARTS** .....

INTRODUCTION .....	A-1
TYPE UP1 ACTUATORS .....	A-1
TYPE UP2 ACTUATORS .....	A-15
TYPES UP3 AND UP4 ACTUATORS .....	A-39
TYPES UP5 AND UP6 ACTUATORS .....	A-62
PARTS KITS FOR ALL ACTUATORS .....	A-96

---

## **APPENDIX B - DIMENSION DRAWINGS** .....

DIMENSION DRAWINGS .....	B-1
--------------------------	-----

## Table of Contents (continued)

	<b>Page</b>
1-1.	Stroke Times for Type UP1 Actuator Type AV2 Positioner - 5 to 95% of Stroke ..... 1-11
1-2.	Stroke Times for Type UP1 Actuator Type AV2 Positioner - 0 to 100% of Stroke ..... 1-12
1-3.	Stroke Times for Type UP2 Actuator Type AV2 Positioner - 5 to 95% of Stroke ..... 1-13
1-4.	Stroke Times for Type UP2 Actuator Type AV2 Positioner - 0 to 100% of Stroke ..... 1-14
1-5.	Stroke Times for Type UP2 Actuator with Solenoid Valve - 0 to 100% of Stroke ..... 1-15
1-6.	Stroke Times for Type UP3 Actuator Type AV2 Positioner - 5 to 95% of Stroke ..... 1-16
1-7.	Stroke Times for Type UP3 Actuator Type AV2 Positioner - 0 to 100% of Stroke ..... 1-17
1-8.	Stroke Times for Type UP3 Actuator Solenoid Valve - 0 to 100% of Stroke ..... 1-18
1-9.	Stroke Times for Type UP4 Actuator Type AV2 Positioner - 5 to 95% of Stroke ..... 1-19
1-10.	Stroke Times for Type UP4 Actuator Type AV2 Positioner - 0 to 100% of Stroke ..... 1-20
1-11.	Stroke Times for Type UP4 Actuator Solenoid Valve - 0 to 100% of Stroke ..... 1-21
1-12.	Stroke Times for Type UP5 Actuator Type AV2 Positioner - 5 to 95% of Stroke ..... 1-22
1-13.	Stroke Times for Type UP5 Actuator Type AV2 Positioner - 0 to 100% of Stroke ..... 1-23
1-14.	Stroke Times for Type UP5 Actuator Solenoid Valve - 0 to 100% of Stroke ..... 1-24
1-15.	Stroke Times for Type UP6 Actuator Type AV2 Positioner - 5 to 95% of Stroke ..... 1-25
1-16.	Stroke Times for Type UP6 Actuator Type AV2 Positioner - 0 to 100% of Stroke ..... 1-26
1-17.	Stroke Times for Type UP6 Actuator Solenoid Valve - 0 to 100% of Stroke ..... 1-27
3-1.	Type UP1 Actuator with Type AV Positioner, Electric Shaft Position Transmitter and Alarm/Travel Switches ..... 3-3
3-2.	Type UP2 Actuator with Type AV Positioner ..... 3-4
3-3.	Types UP3 and UP4 Actuators ..... 3-5
3-4.	Types UP5 and UP6 Actuators ..... 3-6
3-5.	Operating Torque Versus Air Supply Pressure (Types UP1 and UP2 Actuators) ..... 3-9
3-6.	Stall Torque Versus Air Supply Pressure (Types UP1 and UP2 Actuators) ..... 3-10
3-7.	Operating Torque Versus Air Supply Pressure (Types UP3, UP4, UP5 and UP6 Actuators) ..... 3-11
3-8.	Stall Torque at Midstroke Versus Air Supply Pressure (Types UP3, UP4, UP5 and UP6 Actuators) ..... 3-12
3-9.	Type UP1 Actuator with Solenoid Valve and Air Failure Lock ..... 3-15
3-10.	Type UP2 Actuator with Solenoid Valve ..... 3-16
3-11.	Master/Slave Tubing Connections ..... 3-17
3-12.	Reserve Air Tank Tubing for Type UP2 Actuators ..... 3-20
3-13.	Reserve Air Tank Tubing for Types UP3 through UP6 Actuators ..... 3-22
3-14.	Reset Switch for Air Failure Lock ..... 3-23
3-15.	Tubing Schematic for Type UP1 Actuator with Air Failure Lock ..... 3-25
3-16.	Tubing Schematic for Type UP2 Actuator with Air Failure Lock ..... 3-27
3-17.	Tubing Schematic for Types UP3 and UP4 Actuators with Air Failure Lock ..... 3-28
3-18.	Tubing Schematic for Types UP5 and UP6 Actuators with Air Failure Lock ..... 3-30
3-19.	Electric Shaft Position Transmitter and Alarm/Travel Switches (for nomenclature options 11 in the sixth and seventh positions) ..... 3-32
3-20.	Typical Wiring Loop Diagram for the Electric Shaft Position Transmitter ..... 3-35
3-21.	Supply Voltage and Load Resistance Limits for the Electric Shaft Position Transmitter ..... 3-36
3-22.	Electric Shaft Position Transmitter Circuit Board ..... 3-37
5-1.	Operating Controls - Types UP1 and UP2 Actuators ..... 5-3
5-2.	Operating Controls - Types UP3 and UP4 Actuators ..... 5-8
5-3.	Operating Controls - Types UP5 and UP6 Actuators ..... 5-10
8-1.	Rotary Vane Removal and Seal Replacement ..... 8-4
8-2.	Cylinder Assembly for Type UP3 Actuators ..... 8-8
8-3.	Cylinder Assembly for Type UP4 Actuators ..... 8-9
8-4.	Cylinder Assembly for UP6 Actuators ..... 8-10
8-5.	Cylinder Assembly for Type UP5 Actuators ..... 8-11
8-6.	Clutch and Clutch Fork Assembly ..... 8-13
8-7.	Roller Chain Adjustment for Types UP5 and UP6 Actuators ..... 8-15
A-1.	UP1 with Positioner, Tables <b>A-1</b> and <b>A-2</b> ..... A-2
A-2.	UP1 with Solenoid Valve, Tables <b>A-3</b> and <b>A-4</b> ..... A-6
A-3.	UP1 Alarm/Travel Switch Kit, Table <b>A-5</b> ..... A-9
A-4.	UP1 Electric Shaft Position Transmitter Kit, Table <b>A-6</b> ..... A-11

# Table of Contents (continued)

		<b>Page</b>
A-5.	UP1 Air Failure Lock Kit, Table <a href="#">A-7</a> .....	A-14
A-6.	UP2 with Positioner, Tables <a href="#">A-9</a> and <a href="#">A-10</a> .....	A-18
A-7.	UP2 with Solenoid Valve, Tables <a href="#">A-11</a> and <a href="#">A-12</a> .....	A-22
A-8.	UP2 with Electric Shaft Position Transmitter and/or Alarm/Travel Switches, Tables <a href="#">A-13</a> , <a href="#">A-14</a> , <a href="#">A-48</a> and <a href="#">A-49</a> .....	A-25
A-9.	UP2 with Pneumatic Shaft Position Transmitter, Table <a href="#">A-15</a> .....	A-27
A-10.	UP2 with Air Failure Lock, Table <a href="#">A-16</a> .....	A-31
A-11.	UP2 Reserve Air Tank Kit, Table <a href="#">A-17</a> .....	A-34
A-12.	UP2 with Heater, Table <a href="#">A-19</a> .....	A-37
A-13.	UP3 and UP4 with Positioner, Tables <a href="#">A-20</a> and <a href="#">A-21</a> .....	A-46
A-14.	UP3 and UP4 with Solenoid Valve, Tables <a href="#">A-22</a> and <a href="#">A-23</a> .....	A-52
A-15.	UP3 and UP4 with Electric Shaft Position Transmitter and/or Alarm/Travel Switches, Tables <a href="#">A-24</a> , <a href="#">A-25</a> , <a href="#">A-48</a> and <a href="#">A-49</a> .....	A-55
A-16.	UP3 and UP4 with Pneumatic Shaft Position Transmitter, Table <a href="#">A-26</a> .....	A-57
A-17.	UP3 with Air Failure Lock, Table <a href="#">A-27</a> .....	A-59
A-18.	UP4 with Air Failure Lock, Table <a href="#">A-28</a> .....	A-61
A-19.	UP3 with Reserve Air Tank, Table <a href="#">A-29</a> .....	A-63
A-20.	UP4 with Reserve Air Tank, Table <a href="#">A-30</a> .....	A-65
A-21.	UP3 and UP4 with Heater, Table <a href="#">A-31</a> .....	A-66
A-22.	UP5 and UP6 with Positioner, Tables <a href="#">A-34</a> and <a href="#">A-35</a> .....	A-70
A-23.	UP5 and UP6 with Solenoid Valve, Tables <a href="#">A-36</a> and <a href="#">A-37</a> .....	A-76
A-24.	UP5 and UP6 with Electric Shaft Position Transmitter and/or Alarm/Travel Switches, Tables <a href="#">A-38</a> , <a href="#">A-39</a> , <a href="#">A-48</a> and <a href="#">A-49</a> .....	A-79
A-25.	UP5 and UP6 with Pneumatic Shaft Position Transmitter, Table <a href="#">A-40</a> .....	A-82
A-26.	UP5 and UP6 with Air Failure Lock, Tables <a href="#">A-41</a> and <a href="#">A-42</a> .....	A-86
A-27.	UP5 and UP6 with Reserve Air Tank, Table <a href="#">A-43</a> .....	A-89
A-28.	UP5 and UP6 Actuators with Heater, Table <a href="#">A-46</a> .....	A-92
A-29.	UP6 Actuators with Volume Boosters, Table <a href="#">A-47</a> .....	A-95
A-30.	Alarm/Travel Switches and Electric Shaft Position Transmitter, Tables <a href="#">A-48</a> and <a href="#">A-49</a> .....	A-98
B-1.	Type UP1 Actuator with Type AV Positioner .....	B-1
B-2.	Type UP1 Actuator with Type AV Positioner and Air Failure Lock .....	B-2
B-3.	Type UP1 Actuator with Type AV Positioner, Electric Shaft Positioner and/or Alarm/Travel Switches .....	B-2
B-4.	Type UP1 Actuator with Solenoid Valve .....	B-3
B-5.	Type UP1 Actuator with Solenoid Valve and Air Failure Lock .....	B-3
B-6.	Type UP1 Actuator with Solenoid Valve, Electric Shaft Position Transmitter and/or Alarm/Travel Switches .....	B-4
B-7.	Type UP2 Actuator with Type AV Positioner or Solenoid Valve .....	B-4
B-8.	Types UP3 and UP4 Actuators .....	B-5
B-9.	Types UP3 and UP4 Actuators .....	B-6
B-10.	Types UP5 and UP6 Actuators .....	B-6
B-11.	20.8 Liter (5.5 Gallon) Reserve Air Tank Option for Type UP2 Actuators .....	B-7
B-12.	30.3 Liter (8.0 Gallon) Reserve Air Tank Option for Types UP3, UP4 and UP5 Actuators .....	B-7
B-13.	64.4 Liter (17.0 Gallon) Reserve Air Tank for Type UP6 Actuators .....	B-81-1. Reference Documents
1-2.	Nomenclature .....	1-4
1-3.	Specifications .....	1-6
1-4.	Options and Accessories .....	1-8
1-5.	Type UP Actuator Shipping Weights .....	1-10
1-6.	Option Shipping Weights .....	1-10
3-1.	Tubing Sizes, Air Filters and Air Supply Regulators .....	3-8
3-2.	Suggested Maximum Operating Torque at Minimum and Maximum Supply Pressure Limits .....	3-8

## Table of Contents (continued)

	<b>Page</b>
3-3. Master/Slave Installation Kit .....	3-18
3-4. Wire Color Codes for Direct Versus Reverse Loading on the Electric Shaft Position Transmitter .....	3-37
4-1. Zero Elevation .....	4-2
6-1. Fault Correction Chart .....	6-1
8-1. Parts List for Type UP3 Actuator Cylinder Assembly 1 .....	8-8
8-2. Parts List for Type UP4 Actuator Cylinder Assembly 1 .....	8-9
8-3. Parts List for Type UP6 Actuator Cylinder Assembly 1 .....	8-10
8-4. Parts List for Type UP5 Actuator Cylinder Assembly 1 .....	8-11
A-1. UP1 with Positioner, Figure A-1 .....	A-1
A-2. UP1 Positioners, Figure A-1 .....	A-3
A-3. UP1 with Solenoid Valve, Figure A-2 .....	A-5
A-4. UP1 Solenoid Valves, Figure A-2 .....	A-5
A-5. UP1 Alarm/Travel Switch Kit, Figure A-3 .....	A-8
A-6. UP1 Electric Shaft Position Transmitter Kit, Figure A-4 .....	A-10
A-7. UP1 Air Failure Lock Kit, Figure A-5 .....	A-12
A-8. UP1 Rotary Vane Seal Repair Kit, Figure 8-1 .....	A-15
A-9. UP2 Actuator with Positioner, Figure A-6 .....	A-16
A-10. UP2 Positioners, Figure A-6 .....	A-17
A-11. UP2 with Solenoid Valve, Figure A-7 .....	A-20
A-12. UP2 Solenoid Valves, Figure A-7 .....	A-23
A-13. UP2 Alarm/Travel Switch Kit, Figures A-8 and A-30 .....	A-24
A-14. UP2 Electric Shaft Position Transmitter Kit, Figures A-8 and A-30 .....	A-24
A-15. UP2 Pneumatic Shaft Position Transmitter Kit, Figure A-9 .....	A-24
A-16. UP2 Air Failure Lock Kit, Figure A-10 .....	A-29
A-17. UP2 Reserve Air Tank Kit, Figure A-11 .....	A-33
A-18. UP2 Rotary Vane Seal Repair Kit, Figure 8-1 .....	A-36
A-19. UP2 Heater Kits, Figure A-12 .....	A-36
A-20. UP3 and UP4 with Positioner, Figure A-13 .....	A-39
A-21. UP3 and UP4 Positioners and Unique Items, Figure A-13 .....	A-42
A-22. UP3 and UP4 with Solenoid Valve, Figure A-14 .....	A-49
A-23. UP3 and UP4 Solenoid Valves and Unique Items, Figure A-14 .....	A-54
A-24. UP3 and UP4 Alarm/Travel Switch Kit, Figures A-15 and A-30 .....	A-54
A-25. UP3 and UP4 Electric Shaft Position Transmitter Kit, Figures A-15 and A-30 .....	A-55
A-26. UP3 and UP4 Pneumatic Shaft Position Transmitter Kits, Figure A-16 .....	A-56
A-27. UP3 Air Failure Lock Kits, Figure A-17 .....	A-58
A-28. UP4 Air Failure Lock Kits, Figure A-18 .....	A-60
A-29. UP3 Reserve Air Tank Kits, Figure A-19 .....	A-62
A-30. UP4 Reserve Air Tank Kits, Figure A-20 .....	A-64
A-31. UP3 and UP4 Heater Kits, Figure A-21 .....	A-65
A-32. UP3 Cylinder Spare Parts Kit, Figure 8-2 .....	A-67
A-33. UP4 Cylinder Spare Parts Kit, Figure 8-3 .....	A-67
A-34. UP5 and UP6 Positioner, Figure A-22 .....	A-67
A-35. UP5 and UP6 Positioners and Unique Items, Figure A-22 .....	A-72
A-36. UP5 and UP6 with Solenoid Valve, Figure A-23 .....	A-73
A-37. UP5 and UP6 Solenoid Valves and Unique Items, Figure A-23 .....	A-75
A-38. UP5 and UP6 Alarm/Travel Switch Kit, Figure A-24 .....	A-78
A-39. UP5 and UP6 Electric Shaft Position Transmitter Kit, Figure A-24 .....	A-78
A-40. UP5 and UP6 Pneumatic Shaft Position Transmitter Kit, Figure A-25 .....	A-81
A-41. UP5 and UP6 with Positioner Air Failure Lock Kit, Figure A-26 .....	A-84
A-42. UP5 and UP6 with Solenoid Valve Air Failure Lock Kit, Figure A-26 .....	A-85
A-43. UP5 and UP6 Reserve Air Tank Kits, Figure A-27 .....	A-88
A-44. UP5 Cylinder Spare Parts Kit, Figure 8-5 .....	A-91
A-45. UP6 Cylinder Spare Parts Kit, Figure 8-4 .....	A-91

---

## Table of Contents (continued)

	<b>Page</b>
A-46. UP5 and UP6 Heater Kits, Figure A-28 .....	A-91
A-47. UP6 Volume Boosters Kit, Figure A-29 .....	A-93
A-48. Parts List for Alarm/Travel Switch Kit, Figure A-30 .....	A-96
A-49. Parts List for Electric Shaft Position Transmitter Kit, Figure A-30 .....	A-97

---

# Read First

---

## WARNING

### INSTRUCTION MANUALS

Do not install, maintain or operate this equipment without reading, understanding and following the proper factory-supplied instructions and manuals, otherwise injury or damage may result.

### RETURN OF EQUIPMENT

All equipment being returned to the factory for repair must be free of any hazardous materials (acids, alkalis, solvents, etc.). A Material Safety Data Sheet (MSDS) for all process liquids must accompany returned equipment. Contact the factory for authorization prior to returning equipment.

Read these instructions before starting installation;  
save these instructions for future reference.

## Contacting the Factory . . .

Should assistance be required with any of the company's products, contact the following:

### Telephone:

**24-Hour Call Center  
1-800-HELP-365**

### E-Mail:

**[ins.techsupport@us.abb.com](mailto:ins.techsupport@us.abb.com)**

---

# SECTION 1 - INTRODUCTION

---

## OVERVIEW

This instruction aims to acquaint all users with the Type UP Universal Pneumatic Rotary Actuators. It has explanations of description and operation, installation, calibration, operating procedures, troubleshooting, maintenance, repair/replacement procedures and support services. There are also appendices that have parts lists, drawings and other reference material. Upon completion of this instruction, you will have a working knowledge of the actuators.

It is important for safety and operating reasons to read and understand this instruction. Do not install or complete any tasks or procedures related to operation, calibration, maintenance or repair until doing so.

---

## INTENDED USER

The information in this instruction is a guide for technical personnel responsible for the installation, operation and upkeep of the Type UP Universal Pneumatic Rotary Actuators.

---

## EQUIPMENT DESCRIPTION

The actuators accept electric or pneumatic control signals. They provide modulating or on/off control power to position devices through mechanical linkage, or by direct coupling.

If the actuator has a positioner (ordered by nomenclature), it offers a selection of input ranges:

- 21 to 103 kilopascals (3 to 15 pounds per square inch gage), Type AV11 Positioner.
- 21 to 186 kilopascals (3 to 27 pounds per square inch gage), Type AV12 Positioner.
- 4 to 20-milliamps, Types AV23 and AV33 Positioners.
- Computer DDC, solid state, or contact input, Type AV44 Positioner.

The positioning function can be characterized for a unique application. Cams for linear, square or square root relationships exist. Custom shaping the cam provides for user specific positioning. A mechanical connection to the actuator shaft serves to feed back the shaft movement.

## INTRODUCTION

---

Actuators fitted with a solenoid valve provide on/off control. In this case, positioning is at either of the extreme positions of travel (zero percent or 100 percent).

---

## FEATURES

- **Wide Range of Torque Ratings.** Six actuator sizes available in ratings from 122 to 6,372 Newton meters (90 to 4,700 foot-pounds).
- **Easy and Flexible Installation.** Actuators can be placed in convenient locations and connected to the driven device by standard linkage components (refer to the **Connecting Linkage for Universal Rotary Actuators** product specification).
- **Suitable for High Temperature Environments.** Actuators can be used in ambient temperatures up to 82°C (180°F).
- **Adjustable Relationship Between Control Signal and Output Shaft Position.** Easily adjusted by use of standard positioner cam characteristics (for linear, square and square root relationship) or custom-shaped cam.
- **Wide Environmental Applications.** Complete metal enclosures offer superior strength, as well as high immunity to diverse atmospheres and process materials.
- **Quick and Smooth Transfer.** Easily shifted from automatic to manual control.
- **Wide Range of Options Available.** Factory-installed NEMA 4X enclosure, pneumatic or electric shaft position transmitter, alarm/travel switches, air failure lock, reserve air tank and heated enclosures are available.

---

## EQUIPMENT APPLICATION

The actuators provide regulation of dampers and fan inlet vanes. They also control lever-operated valves, turbine governors, fluid drives and other final control elements.

---

## INSTRUCTION CONTENT

<b>Introduction</b>	Provides a description of this instruction, its sections and their uses, and a brief description of the actuator. Also included are instructions on how to use this document, reference documents, nomenclature, specifications, options and accessories, shipping weights, and stroke time graphs (Figures 1-1 through 1-17).
<b>Description and Operation</b>	Provides an overview of the actuators. A broad description of each type appears in this section.

<b>Installation</b>	Contains instructions for unpacking and inspection; location and safety considerations; setup/physical installation including wiring, cabling and tubing connections; connections for optional equipment; and any required adjustments.
<b>Calibration</b>	Provides calibration procedures required before placing the actuators into operation and for optional equipment.
<b>Operating Procedures</b>	Contains procedures for normal operation of the actuators. Descriptions of the controls are found here.
<b>Troubleshooting</b>	Provides procedures for isolating problems. It helps determine if the driving mechanism or the driven device is at fault. A troubleshooting table appears in this section.
<b>Maintenance</b>	Contains maintenance information about the actuators and related equipment.
<b>Repair and Replacement Procedures</b>	Details the procedures for replacing actuator components.
<b>Support Services</b>	Includes information on how to order replacement parts.
<b>Parts Drawings and Parts Kits</b>	Contains information on available spare parts and kits.
<b>Dimension Drawings</b>	Provides dimension drawings to aid in the installation process.

---

### ***HOW TO USE THIS INSTRUCTION***

This instruction pertains to Types UP1 through UP6 actuators. Information pertains only to the actuators specified.

**NOTE:** This instruction applies only to the actuators and their related options. All procedures involving positioners appear in the appropriate positioner instruction.

The sections of this instruction are sequentially arranged as they relate to initial start-up; from unpacking to repair and replacement procedures. After initial start-up, refer to this instruction as needed by section.

The word actuator is used throughout this instruction. Actuator refers to **rotary vane** when discussing Types UP1 and UP2 actuators. Actuator refers to **cylinder** when discussing Types UP3 through UP6 actuators.

---

### ***REFERENCE DOCUMENTS***

Table 1-1 is a list of ABB documents referred to in this instruction.



Table 1-2. Nomenclature (continued)

Position	1	2	3	4	5	6	7	8	9
Type	U	P	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<b>Universal Rotary Actuators Type UP Pneumatic (All Metal Enclosure)</b>
	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	
	PreviousPage	F							On/off solenoid valve, 220 VAC at 50 Hz/240 VAC at 60 Hz, single coil
		G							On/off solenoid valve, 220 VAC at 50 Hz/240 VAC at 60 Hz, dual coil
									<b>Shaft Position Transmitter</b>
									None
									Electric, 4 to 20-mA (linear only) <sup>1</sup>
									4 to 20-mA output, Type RQ10 Position Transmitter (LVDT, non-contacting) <sup>2</sup>
									4 to 20-mA output, Type RQ20 Position Transmitter with limit switches (LVDT, non-contacting) <sup>1,2</sup>
									Potentiometric resistive output internal to Type AV positioner (Types AV1, AV2 and AV3) (for actuator Types UP__A through D only) <sup>3</sup>
									4 to 20-mA output internal to Type AV positioner (Types AV1, AV2 and AV3) (for actuator Types UP__A through D only) <sup>3</sup>
									21 to 103 kPa (3 to 15 psig) Type AV Pneumatic Position Transmitter output (for Type UP__A only) <sup>4,5</sup>
									21 to 186 kPa (3 to 27 psig) Type AV Pneumatic Position Transmitter output (for Type UP__B only) <sup>4,5</sup>
									<b>Alarm/Travel Switches</b>
									None
									Included (4 SPDT switches)
									<b>Air Control</b>
									None
									Air failure lock (for all but Type UP6_0 actuators)
									Volume boosters (to increase actuator stroke speed)
									Air failure lock and volume boosters
									Reserve air tank <sup>4</sup> (goes to 0 or 100% on loss of air supply)
									<b>Heaters</b>
									None
									120 VAC <sup>4</sup>
									240 VAC <sup>4</sup>

NOTES:

1. A 1 or 4 in the sixth position provides limit switches (included with the position transmitter) and requires a 1 in the seventh position.
2. Type RQ Position Transmitters are special orders. Contact an authorized ABB sales/service representative for more information.
3. 4 to 20-mA output position transmitter is built into the Type AV4 positioner as a standard feature.
4. Not available on Type UP1 actuators.
5. The environmental rating on Types UP2, UP3 and UP4 actuators with a Type AV Pneumatic Position Transmitter is a function of the environmental rating of the Type AV Pneumatic Position Transmitter, since it is mounted outside the actuator enclosure. Refer to the **Refer to the Characterizable Positioner Type AV1, AV2, AV3, AV4 specification for hysteresis, resolution, deadband, repeatability, etc.** for the environmental ratings.

## INTRODUCTION

### SPECIFICATIONS

Table 1-3 lists the specifications for the Type UP actuators.

Table 1-3. Specifications

Property	Characteristic/Value
Operating torque	Refer to Table 3-2 for maximum values. Refer to Figures 3-5 and 3-7 for operating torque versus air supply pressure.
Operating air supply pressure	276 to 690 kPa (40 to 100 psig)
Stroke times	Refer to Figures 1-1 through 1-17.
Volume displacement for 90° mechanical output rotation	
UP1	656 cm <sup>3</sup> (40 in. <sup>3</sup> ) rotary vane
UP2	1,966 cm <sup>3</sup> (120 in. <sup>3</sup> ) rotary vane
UP3	3,687 cm <sup>3</sup> (225 in. <sup>3</sup> ) cylinder [15 by 20 cm (6 by 8 in.)]
UP4	6,555 cm <sup>3</sup> (400 in. <sup>3</sup> ) cylinder [20 by 20 cm (8 by 8 in.)]
UP5	13,110 cm <sup>3</sup> (800 in. <sup>3</sup> ) cylinder [20 by 41 cm (8 by 16 in.)]
UP6	20,566 cm <sup>3</sup> (1,255 in. <sup>3</sup> ) cylinder [25 by 41 cm (10 by 16 in.)]
Temperature limits	-40° to 82°C (-40° to 180°F) <sup>1</sup>  The low temperature operative limit can be extended below 0°C (32°F) without heaters if the dew point of the air supply is maintained at least 10°C (18°F) below the minimum expected ambient temperature.
Mechanical rotation	
UP1 and UP2	Rotary vane stroke is nominally set for 90° rotation, but can be adjusted over a range from 80° to 92° via adjustable mechanical stop.
UP3, UP4, UP5 and UP6	Stroke of the cylinder provides a 90° rotation of the output lever.
Positioner	Refer to the <b>Characterizable Positioner Type AV1, AV2, AV3, AV4 specification</b> for details on Type AV positioners available for use with Type UP actuators.
Positioner input signal	AV1: 21 to 103 kPa (3 to 15 psig), 21 to 186 kPa (3 to 27 psig), 50% range suppression and/or zero elevation capability.  AV2: 4 to 20-mA (goes to 0% (normal acting) or 100% (reverse acting) on loss of input signal).  AV3: 4 to 20-mA (holds position on loss of input signal)  AV4: Computer DDC, solid state or switch contact (holds position on loss of input signal)
Air consumption (nominal) at balance with positioner	Typical 188.8 cm <sup>3</sup> /sec (0.4 scfm) at 517.1 kPa (75.0 psig) supply, 283.2 cm <sup>3</sup> /sec (0.6 scfm) maximum at null
Positioner action	Direct or reverse is standard
Performance specifications	Refer to the <b>Characterizable Positioner Type AV1, AV2, AV3, AV4 specification</b> for hysteresis, resolution, deadband, repeatability, etc.
Solenoid valve type and coil requirements	4-way, 2-position, 2-wire type (UP_5, UP_6 and UP_F) 4-way, 2-position, 4-wire type (UP_8, UP_9 and UP_G)
Types UP1 and UP2	NEMA 4X enclosure rating. CSA certified 120 VAC, 50/60 Hz, 10.5 W; 220 VAC at 50 Hz/240 VAC at 60 Hz, 5.25 W; or 125 VDC, 11.2 W
Types UP3, UP4, UP5 and UP6 <sup>2</sup>	NEMA 1 enclosure rating. CSA certified 120 VAC, 50/60 Hz, 10.5 W; 220 VAC at 50 Hz/240 VAC at 60 Hz, 5.25 W; or 125 VDC, 11.2 W

### SPECIFICATIONS

Table 1-3. Specifications (continued)

Property	Characteristic/Value
External connections	
Air supply	UP1, UP2, UP3 and UP4: ¼-18 NPT female UP5 and UP6: ½-14 NPT female
Pneumatic signal	¼-18 NPT female when using Types AV11 or AV12 positioners as the control input
External connections	
Air failure reset	¼-18 NPT female
Electrical conduit	Cutouts for ½-in. and ¾-in. female when using Types AV2, AV3 or AV4 positioners, or a solenoid valve for the control input
Manual operator	
UP1 and UP2	Lever type with manual locking bolt
UP3 and UP4	Split nut with locking ratchet
UP5 and UP6	Gear type with self-locking ratchet
Materials of construction	
Frame	Carbon steel
Output shaft	Carbon steel
Top covers	Sheet metal
End covers	Sheet metal
Actuators	UP1 and UP2: Die cast aluminum rotary vane housing UP3, UP4, UP5 and UP6: Carbon steel air cylinder housing and ductile iron cylinder end flanges
Seals on vane, vane shaft, piston and piston rod	Nitrile rubber
Coating on metal parts	Corrosion-resistant polyurethane
Storage	Store in a dry, indoor location not subject to rapid temperature changes that would cause condensation to form inside the unit.
Storage temperature limits	-40° to 93°C (-40° to 200°F)
Enclosure classification	NEMA 3R (standard) NEMA 4X (optional).
Agency approvals	Canadian Standards Association (CSA) certified for use in general purpose (nonhazardous) locations.
Weight	Refer to Tables 1-5 and 1-6

**NOTES:**

1. Some actuator/positioner combinations may have slightly higher minimum, and slightly lower maximum operating temperatures. Refer to the **Characterizable Positioner Type AV1, AV2, AV3, AV4 specification** for temperature limitations.
2. The solenoid valve is mounted inside the actuator enclosure on these models; therefore, the environmental rating of the entire unit is a function of the environmental rating of the actuator enclosure.

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE

**OPTIONS AND ACCESSORIES**

Table 1-4 lists the options and accessories available for use with the actuators.

*Table 1-4. Options and Accessories*

<b>Item</b>	<b>Description</b>
<p>Shaft Position Transmitter</p> <p>Electric (external to positioner)</p> <p>Electric (internal to positioner)</p> <p>Electric (Type RQ)</p> <p>Pneumatic</p> <p>Potentiometric Resistive</p>	<p>2-wire unit requiring a 12 to 42 VDC supply and providing a 4 to 20-mA linear output relative to the actuator shaft position.</p> <p>2-wire unit requiring a 12 to 34 VDC supply and producing a 4 to 20-mA linear output relative to the actuator shaft position.</p> <p>Characterizable, LVDT, non-contacting, 2-wire unit requiring a 12 to 42 VDC supply and producing a 4 to 20 mA linear output relative to the actuator shaft position.</p> <p>Produces a 21 to 103 kPa (3 to 15 psig) or 21 to 186 kPa (3 to 27 psig) linear output relative to the actuator shaft position. Minimum required air supply is 138 kPa (20 psig). The output may be characterized by the user (not available for Type UP1 actuators).</p> <p>A potentiometer internal to the Types AV1, AV2 and AV3 positioners. Gears connect the potentiometer to the positioner output shaft. The position of the potentiometer shaft indicates the actuator shaft position. The relationship between the potentiometer and the output shaft dictates that one degree of rotation of the output shaft corresponds to approximately 9.9 ohms of resistive change at the potentiometer. Refer to the appropriate Type AV positioner instruction for more information.</p>
<p>Adjustable Alarm/Travel Switches</p> <p>Contact ratings</p>	<p>Consists of four linkage-driven, cam-operated SPDT microswitches, adjustable over the full stroke of the actuator. Used as alarm contacts or for external indications.</p> <p>C1, C4: 9 A at 125 VAC or VDC at 60°C (140°F) C2, C3: 9 A at 125 VAC or 250 VDC at 60°C (140°F)</p>
<p>Air Failure Lock</p> <p>UP1 and UP2</p> <p>UP3, UP4, UP5 and UP6</p> <p>Alarm pressure switch contact ratings</p>	<p>Locks actuator in its last position when the air supply falls below a preset value. Each actuator includes a pneumatic pushbutton and contains hardware for local or remote reset connection.</p> <p>Mechanical latch device with a 3-way pneumatic trip valve as the air supply sensor.</p> <p>Uses a 3-way pneumatic trip valve as the air supply sensor, that trips one 4-way (Types UP3 and UP4 actuators) or two 3-way (Types UP5 and UP6 actuators) lock-up valves to lock the actuator in the last position. Includes a pressure switch used to signal an air failure alarm or for a status light.</p> <p>13.0 A at 115/230 VAC at 60°C (140°F) 0.5 A at 110/125 VAC at 60°C (140°F)</p> <p>Switch contacts must be derated 1.5 A for every 10°C (18°F) rise above 60°C (140°F).</p>

Table 1-4. Options and Accessories (continued)

Item	Description
Reserve Air Tank  UP2 UP3, UP4 and UP5 UP6	Available for all except Type UP1 actuators.  Drives actuator into the full open or full closed position when the air supply falls below a preset value. Uses a 3-way pneumatic trip valve as the air supply sensor.  20.8 l (5.5 gal.) air tank 30.3 l (8.0 gal.) air tank 64.4 l (17.0 gal.) air tank
Strip Heaters (thermostatically controlled)  UP2 UP3, UP4, UP5 and UP6	Available for all except Type UP1 actuators. The low temperature operative limit can be extended below 0°C (32°F) without heaters if the dew point of the air supply is maintained at least 10°C (18°F) below the minimum expected ambient temperature.  1 heater element, 500 W at 120 VAC or 240 VAC 2 heater elements, 500 W (1000 W total) at 120 VAC or 240 VAC
Volume Boosters and Exhaust Valves	To increase stroke speed. Available only for Type UP6 actuators. Refer to Table 1-2 and Figure 1-16.
Accessories Regulators <sup>1</sup>  Supply air filters   Pressure switch  Pressure gages  Speed control orifices	Part No. 1951029_5 (standard capacity) Part No. 1951439_1 (high capacity)  In-line coalescing filter for removal of solid and liquid contaminants in compressed air. Filter comes with universal mounting bracket and grade DX filter that is 93% efficient at 0.1 microns.  Part No. 5328563_1: 150 psig maximum inlet pressure, 54°C (130°F) maximum temperature, ½ NPT inlet/outlet connection size. Part No. 5328563_2: 250 psig maximum inlet pressure, 121°C (250°F) maximum temperature, ½ NPT inlet/outlet connection size. This filter has an anodized aluminum bowl guard.  Part No. 1941099_2 (Types UP1 and UP2 actuators) to sound an alarm or for status lights to signal loss of air supply.  Part No. 5326605_4: instrument Part No. 5326605_5: supply <sup>2</sup> Part No. 5326605_6: output (two required)  Regulate time constant of positioner and final control element. Installed directly into positioner output ports.  Part No. 5327327_1: 1 mm (0.04 in.) Part No. 5327327_2: blank (drill to suit)

**NOTES:**

1. A high capacity regulator is suggested for applications using Types UP5 and UP6 actuators where stroke speed is important. Refer to Table 3-1 for regulator capacity information.
2. The manifold on the positioner provides gage ports, one for instrument (internal input signal) and two output gages. A supply gage can be installed in the supply line (piping by customer).

**SHIPPING WEIGHTS**

Table 1-2 lists the shipping weights of the actuators including either a positioner or a solenoid valve. Table 1-6 lists the shipping weights of the various options.

*Table 1-5. Type UP Actuator Shipping Weights*

<b>Actuator Type</b>	<b>Shipping Weight kg (lb)</b>
UP1_A/1_B/1_C/1_D/1_E	25 (55)
UP1_5/1_6/1_8/1_9/1_F/1_G	23 (50)
UP2_A/2_B/2_C/2_D/2_E	45 (100)
UP2_5/2_6/2_8/2_9/2_F/2_G	43 (95)
UP3_A/3_B/3_C/3_D/3_E	145 (320)
UP3_5/3_6/3_8/3_9/3_F/3_G	143 (315)
UP4_A/4_B/4_C/4_D/4_E	163 (360)
UP4_5/4_6/4_8/4_9/4_F/4_G	161 (355)
UP5_A/5_B/5_C/5_D/5_E	336 (741)
UP5_5/5_6/5_8/5_9/5_F/5_G	334 (736)
UP6_A/6_B/6_C/6_D/6_E	369 (814)
UP6_5/6_6/6_8/6_9/6_F/6_G	367 (809)

*Table 1-6. Option Shipping Weights<sup>1</sup>*


<b>Option</b>	<b>Shipping Weight kg (lb)</b>
Electric Shaft Position Transmitter	1.8 (4.0)
Pneumatic Shaft Position Transmitter	5.0 (11.0)
Alarm/Travel Switches	1.1 (2.5)
Strip Heaters	
UP2	1.1 (2.5)
UP3, UP4, UP5 and UP6	2.0 (4.5)
Air Failure Lock	
UP1	3.6 (8.0)
UP2	5.0 (11.0)
UP3 and UP4	5.9 (13.0)
UP5 and UP6	6.8 (15.0)
Reserve Air Tank	
20.8 l (5.5 gal.) for UP2	10.0 (22.0)
30.3 l (8.0 gal.) for UP3, UP4 and UP5	13.6 (30.0)
64.4 l (17.0 gal.) for UP6	22.7 (50.0)
Volume Boosters (UP6 only)	4.5 (10.0)

**NOTE:**

1. Add these values to those listed in Table 1-5 where applicable.

**STROKE TIME GRAPHS**

Figures 1-1 through 1-17 show the stroke times for the various types of actuators with positioners and solenoid valves.



*Figure 1-1. Stroke Times for Type UP1 Actuator with Type AV2 Positioner - 5 to 95% of Stroke*

# INTRODUCTION




Figure 1-2. Stroke Times for Type UP1 Actuator with Type AV2 Positioner - 0 to 100% of Stroke




Figure 1-3. Stroke Times for Type UP2 Actuator with Type AV2 Positioner - 5 to 95% of Stroke

## STROKE TIME GRAPHS




Figure 1-4. Stroke Times for Type UP2 Actuator with Type AV2 Positioner - 0 to 100% of Stroke




Figure 1-5. Stroke Times for Type UP2 Actuator with Solenoid Valve - 0 to 100% of Stroke

# INTRODUCTION




Figure 1-6. Stroke Times for Type UP3 Actuator with Type AV2 Positioner - 5 to 95% of Stroke




Figure 1-7. Stroke Times for Type UP3 Actuator with Type AV2 Positioner - 0 to 100% of Stroke

## STROKE TIME GRAPHS




Figure 1-8. Stroke Times for Type UP3 Actuator with Solenoid Valve - 0 to 100% of Stroke




Figure 1-9. Stroke Times for Type UP4 Actuator with Type AV2 Positioner - 5 to 95% of Stroke

# INTRODUCTION




Figure 1-10. Stroke Times for Type UP4 Actuator with Type AV2 Positioner - 0 to 100% of Stroke




Figure 1-11. Stroke Times for Type UP4 Actuator with Solenoid Valve - 0 to 100% of Stroke




Figure 1-12. Stroke Times for Type UP5 Actuator with Type AV2 Positioner - 5 to 95% of Stroke




Figure 1-13. Stroke Times for Type UP5 Actuator with Type AV2 Positioner - 0 to 100% of Stroke

# INTRODUCTION




Figure 1-14. Stroke Times for Type UP5 Actuator with Solenoid Valve - 0 to 100% of Stroke




Figure 1-15. Stroke Times for Type UP6 Actuator with Type AV2 Positioner - 5 to 95% of Stroke




Figure 1-16. Stroke Times for Type UP6 Actuator with Type AV2 Positioner - 0 to 100% of Stroke




Figure 1-17. Stroke Times for Type UP6 Actuator with Solenoid Valve - 0 to 100% of Stroke

---

## SECTION 2 - DESCRIPTION AND OPERATION

---

### *INTRODUCTION*

This section gives an overview of the Type UP Universal Pneumatic Rotary Actuators. A broad description of each type is included.

Types UP1 and UP2 actuators have a double-acting rotary vane power unit. The power units of Types UP3 UP4, UP5 and UP6 actuators include a double-acting cylinder with a motion conversion mechanism. This device converts linear motion to rotary motion. A differential pressure from the positioner or solenoid valve, applied across the double-acting power unit, causes rotary motion of the output shaft.

Order the actuators with a positioner or an on/off solenoid valve.

The positioner is a push-pull action, force balance type control device. The positioner offers a variety of input ranges:

- 21 to 103 kilopascals (3 to 15 pounds per square inch gage), Type AV11 positioner.
- 21 to 186 kilopascals (3 to 27 pounds per square inch gage), Type AV12 positioner.
- 4 to 20-milliamps, Types AV23 and AV33 positioners.
- Computer DDC, solid state, or contact input, Type AV44 positioner.

The positioning function can be for a variety of applications. There are standard cams for linear, square or square root relationships. Custom shaping the cam provides application flexibility. A mechanical connection to the actuator shaft feeds back the shaft position movement. The positioner provides proportional control of the differential pressure across the rotary vane or cylinder. It moves the output shaft in accordance with the control signal.

Actuators with a solenoid valve provide on/off control. In this case, positioning of the actuator is at either of the extreme ends of travel (zero percent or 100 percent). There are solenoid valves for 220 VAC at 50 Hertz, 120 VAC or 240 VAC at 60 Hertz, or 115/125 VDC service, single or dual coil.

## DESCRIPTION AND OPERATION

---

---

### ***Types UP\_\_A and UP\_\_B Actuators***

In Types UP\_\_A and UP\_\_B actuators, the positioner receives a pneumatic analog input signal. It adjusts the pressure to the power unit. This moves the output shaft to the spot that matches the input signal.

---

### ***Types UP\_\_C and UP\_\_D Actuators***

These actuators change the four to 20-milliamp signal, applied at the positioner current to pneumatic signal converter, into a pneumatic signal. A connection to the actuator shaft feed back the shaft movement. When the controller calls for the actuator to change position, the positioner acts as a pneumatic relay. Through a separate air supply, it moves the actuator into position.

---

### ***Type UP\_\_E Actuators***

These actuators have a pulse input positioner. This combines the functions of a pulse-to-pneumatic signal converter, a pneumatic positioner and a position transmitter.

---

### ***Types UP\_\_5, UP\_\_8 and UP\_\_F Actuators***

These actuators have single coil solenoid valves. These move the actuator to either end of travel (zero percent or 100 percent). When the solenoid valve is energized, the rotary vane goes to the full closed position (Types UP1 and UP2 actuators) or the cylinder retracts completely (Types UP3 through UP6 actuators). The actuators stay in their positions until the solenoid is de-energized at which time the rotary vane goes to the full open position or the cylinder extends completely.

**NOTE:** This description is for direct acting and actuators (as shipped). The description for reverse acting applications would be opposite of that described here. Refer to Section 3 for more information on reverse acting actuators with solenoid valves.

---

### ***Types UP\_\_6, UP\_\_9 and UP\_\_G Actuators***

These actuators have dual coil solenoid valves. These move the actuator to either end of travel (zero percent to 100 percent). Energizing solenoid A causes the rotary vane to go to the full closed position (Types UP1 and UP2 actuators) or the cylinder to retract completely (Types UP3 through UP6 actuators). Energizing solenoid B causes the rotary vane to go to the full closed position or the cylinder to extend completely. The solenoids do not need to be kept energized to maintain the last position.

**NOTE:** Do not energize both coils at the same time. Doing so will cause unpredictable actuator movement.

### *Type UP6\_0 Actuators*

Type UP6\_0 master/slave actuators are for installations that need more torque than a single Type UP6 actuator supplies. Two or more Type UP6 actuators can be connected in parallel to drive the same load. This provides more torque than a single Type UP6 actuator. The master is a standard Type UP6 actuator with a Type AV positioner or solenoid valve. The slave drive is a standard Type UP6 actuator without a positioner or solenoid valve.

Order the master using the standard nomenclature for the actuator desired. For the additional slave drive, refer to nomenclature Type UP6\_0\_0\_ - slave actuator. An installation kit, supplied as part of the slave actuator (kit number 258548\_1), is required to install the master/slave arrangement.

The slave drive can be used alone for special applications using an external solenoid valve or other control device.

---

## SECTION 3 - INSTALLATION

---

### INTRODUCTION

This section contains procedures for unpacking and inspection, location, and safety considerations. There are also instructions for setup and physical installation, including wiring, cabling and tubing connections. Finally, it covers connections for optional equipment, and any adjustments that make the unit operational.

---

### UNPACKING AND INSPECTION

Before unpacking, check the outside of the shipping carton for signs of in-transit damage. Pay special attention to punctures, tears or other damage to the outer carton. Look for signs of water damage. If damaged, notify the carrier and ABB immediately.

Check the data on the nameplate, located on the actuator mounting frame. Be sure the unit is suited for the desired application.

---

### LOCATION CONSIDERATIONS

Locate the actuator according to the linkage arrangement desired (refer to **Connecting Linkage for Universal Rotary Actuators**). For dimensions and required clearances, refer to the dimension drawings in **DIMENSION DRAWINGS** in Appendix B.

<b>CAUTION</b>	<b>Protect the air lines and equipment from freezing in temperatures below 0°C (32°F). Failure to do so can damage the equipment.</b>
<b>ATTENTION</b>	<b>Protéger les conduites d'air et l'équipement contre le gel lorsque la température est inférieure à 0°C (32°F). Toute négligence à cet égard risque de provoquer des dommages matériels.</b>

Actuators are designed for use in ambient temperatures of -40 to 82 degrees Celsius (-40 to 180 degrees Fahrenheit).<sup>1</sup> Unless using air dryers or heaters, impose a low temperature operating limit of zero degrees Celsius (32 degrees Fahrenheit).

---

1. Some actuator/positioner combinations may have a slightly lower maximum or higher minimum operating temperature. Refer to the **Characterizable Positioner Type AV1, AV2, AV3, AV4 specification** for temperature limitations.

### ENCLOSURE REMOVAL

---

**WARNING**

Do not operate this equipment unless the covers are in place. The covers prevent access to moving components that pose a risk of entanglement of body parts.

**AVERTISSEMENT**

Ne faites fonctionner cet équipement que si les couvercles sont en place. Les couvercles empêchent l'accès à des composantes en mouvement qui présentent un risque d'emmêlement des membres.

Use the enclosure removal procedures in this section to access components for wiring and tubing installation, calibration, maintenance, repair and replacement.

---

#### *Type UP1 Actuator*

**NOTE:** Refer to Figure 3-1.

Only Type UP1 actuators with alarm/travel switches and/or the electric shaft position transmitter require disassembly to access components. The alarm/travel switches reside in an enclosure attached to the actuator frame.

1. Remove the four enclosure mounting screws holding the enclosure to the actuator frame.
2. Remove the enclosure.

---

#### *Type UP2 Actuator*

**NOTE:** Refer to Figure 3-2.

The Type UP2 actuator has a removable side panel and top cover.

---

##### ***SIDE PANEL***

1. There are six side panel screws that hold the side panel to the actuator frame. Remove these six screws.
2. Remove the side panel.

---

##### ***TOP COVER***

1. There are four link lock fasteners that secure the top cover to the actuator – two on each side near the top of the actuator. Unsnap the link lock fasteners.
2. Remove the top cover.




Figure 3-1. Type UP1 Actuator with Type AV Positioner, Electric Shaft Position Transmitter and Alarm/Travel Switches

### Types UP3 and UP4 Actuator

**NOTE:** Refer to Figure 3-3.

The Types UP3 and UP4 actuators have two removable side covers and a removable top cover.

#### SIDE COVER

1. Loosen the lock screws at the bottom of the side covers 1/4-turn.
2. Release the link lock fasteners that secure the top cover to the side covers.
3. Release the link lock fasteners that secure the side covers to the actuator frame.
4. Remove the side covers by pulling down and outward from the bottom.

# INSTALLATION




Figure 3-2. Type UP2 Actuator with Type AV Positioner

## TOP COVER

1. Remove the manual operator ratchet handle and the hand/auto transfer handle.
2. Unsnap the link lock fasteners holding the top cover to the side covers.
3. Remove the top cover.

## ENCLOSURE REMOVAL




Figure 3-3. Types UP3 and UP4 Actuators

# INSTALLATION


## 4. Types UP5 and UP6 Actuator Enclosure

**NOTE:** Refer to Figure 3-4.

Types UP5 and UP6 actuators have removable bottom side covers, top side covers, and a removable top cover.

### BOTTOM SIDE COVER

1. Loosen the bottom side cover bolts.



TF20107B

Figure 3-4. Types UP5 and UP6 Actuators

## ENCLOSURE REMOVAL

2. Unfasten the link lock fasteners that secure the bottom side covers to the top side covers.
3. Remove the bottom side covers by pulling down and outward on the panel.

---

**TOP COVER**

1. Unsnap the link lock fasteners that secure the top cover to the top side covers.
2. Remove the top cover.

---

**TOP SIDE COVER**

1. Remove the bottom side covers and top cover.
2. On the cylinder side of the actuator, loosen the top side cover bolts and lift the panel outward.
3. On the other side of the actuator, remove the manual operator ratchet handle and hand/auto transfer handle.
4. Loosen the top side cover bolts and lift the panel outward.

---

**WIRING CONNECTIONS, TUBING CONNECTIONS AND CABLING**

These procedures describe wiring, tubing and cabling necessary to make the actuators operable.

---

**Connecting Tubing**

Use suitable fittings and tubing sizes listed in Table 3-1 to make supply and signal connections. If supply regulation is needed, use the regulator data shown in Table 3-1. Refer to Figures 3-1 through 3-4 and 3-9 and 3-10 for the size and location of connections.

Refer to Table 3-2 for suggested maximum operating torque values versus minimum and maximum supply pressure. Refer to Figures 3-5 through 3-8 for data on operating torque and stall torque versus air supply pressure values. Use these graphs to select the air supply pressure necessary to get the required output torque. Keeping supply pressure at plus or minus five percent of the selected pressure requires no further supply regulation.

**NOTE:** The primary units in these graphs are Newton meters and kilopascals. American units are in parentheses.

Installing a regulator with a flow capacity greater than or equal to those listed in Table 3-1 protects the driven device. It also prevents exceeding the maximum supply or operative limit of the actuator.

## INSTALLATION

Table 3-1. Tubing Sizes, Air Filters and Air Supply Regulators

Actuator Type	Min Supply Line Size (in.)	Signal Line Size (in.)	Regulator Part No. <sup>1</sup>	Regulator Capacity Approx cm <sup>3</sup> /sec (scfm)	Supply Air Filter Part No. <sup>2</sup>
UP1 and UP2	¼	¼	1951029_5 (¼ NPT) or	2,830 (6)	5238563°1 5238563°2
UP3 through UP6	½	¼	1951439°1 (⅜ NPT)	14,160 (30)	5238563°1 5238563°2

**NOTES:**

1. A high capacity regulator is suggested for applications using Types UP5 and UP6 actuators where stroke speed is important.
2. In-line coalescing filter for removal of solid and liquid contaminants in compressed air. Filter comes with universal mounting bracket and grade DX filter that is 93% efficient at 0.1 microns. Part No. 5238563°2 has an anodized aluminum bowl guard.

Table 3-2. Suggested Maximum Operating Torque at Minimum and Maximum Supply Pressure Limits

Actuator Type	Min and Max Supply Pressure kPa (psig)	Max Operating Torque Nm (ft-lbs)
UP1	276 (40) 690 (100)	54 (40) 122 (90)
UP2	276 (40) 690 (100)	224 (165) 610 (450)
UP3	276 (40) 690 (100)	441 (325) 1,085 (800)
UP4	276 (40) 690 (100)	746 (550) 1,966 (1,450)
UP5	276 (40) 690 (100)	1,437 (1,060) 3,796 (2,800)
UP6	276 (40) 690 (100)	2,576 (1,900) 6,372 (4,700)

### Connecting Wiring

Be sure all wiring and electrical connections comply with the local, National Electrical Code or Canadian Electrical Code.

### Grounding

It is the responsibility of the customers and/or their installation/wiring contractor to insure that the actuator, other associated control or test equipment and all exposed conductive materials are properly grounded in accordance with local, National Electrical Code or Canadian Electrical Code regulations. In addition, insure that they are not a hazard, including under fault conditions, to operation and service personnel.




Figure 3-5. Operating Torque Versus Air Supply Pressure (Types UP1 and UP2 Actuators)

The actuators have a connection for a grounding conductor. Do not use it as a common point for other electrical equipment.

**NOTES:**

1. Because of the prevailing differences in soil conditions throughout the world and differences in acceptable practices, it is not within the scope of this instruction to describe grounding electrode systems. It is the responsibility of the customer to insure that a grounding electrode system that is acceptable to the local building and wiring codes exists at the facility where the actuator is to be installed.
2. The NEC, Article 250, Section H, details requirements for grounding electrode systems acceptable in the United States. The CEC, Section 10, paragraphs 700 through 712, details the requirements for grounding electrode systems acceptable in Canada.
3. The structural metal frame of a building shall not be used as the required equipment grounding conductor for the actuators.




Figure 3-6. Stall Torque Versus Air Supply Pressure (Types UP1 and UP2 Actuators)

## Air Quality

**NOTE:** Installing a filter in the air supply line prevents entrained moisture or dirt from entering the positioner. Refer to Table 3-1 for the air filter part number.

1. Follow the air quality guidelines of ISA S7.3, **Quality Standard for Instrument Air**.
2. Keep the oil content of the air as low as possible, with a maximum of one part per million.
3. Particle size in the air should not exceed three microns.
4. Keep the dew point at line pressure at least 10°C (18°F) below minimum ambient temperature.




Figure 3-7. Operating Torque Versus Air Supply Pressure (Types UP3, UP4, UP5 and UP6 Actuators)

**Characterizable Pneumatic Positioner Tubing**

Tubing for the Type AV1 Characterizable Pneumatic Positioner differs slightly depending on the actuator. If the actuator supplied includes the air failure lock, refer to **Air Failure Lock Tubing**.

**TYPES UP1 AND UP2 ACTUATORS**

**NOTE:** Refer to Figures 3-1 And 3-2.

1. Connect the supply pressure line directly to the S port on the positioner.
2. Connect the control loading pressure directly to the I port on the positioner (pneumatic input only).




Figure 3-8. Stall Torque at Midstroke Versus Air Supply Pressure (Types UP3, UP4, UP5 and UP6 Actuators)

**TYPES UP3 AND UP4 ACTUATORS**

**NOTE:** Refer to Figure 3-3.

1. Connect the supply pressure line directly to the S1 port at the base of the actuator.
2. Connect the control loading pressure directly to the E1 port at the base of the actuator.

**TYPES UP5 AND UP6 ACTUATORS**

**NOTE:** Refer to Figure 3-4.

1. Connect the supply pressure line directly to the S1 port at the base of the actuator.

2. Connect the control loading pressure directly to the E1 port at the base of the actuator.

---

**Characterizable I/P Positioner Tubing and Wiring**

Tubing for Types AV2 and AV3 Characterizable I/P Positioners differs slightly depending on the actuator. If the actuator supplied includes the air failure lock, refer to **Air Failure Lock Tubing**.

---

**TYPES UP1 AND UP2 ACTUATORS**

**NOTE:** Refer to Figures 3-1 And 3-2.

1. Connect the supply pressure line directly to the S port on the positioner.
2. The I port is plugged.
3. There is a conduit connection on the side of the positioner housing for signal wiring with a cross-sectional area of 0.32 to 1.30 square millimeters (22 to 16 AWG). A twisted shielded pair is recommended for signal wiring. Refer to the **Characterizable Positioner Type AV1, AV2, AV3, AV4 specification** for the wiring procedure.

---

**TYPES UP3 AND UP4 ACTUATORS**

**NOTE:** Refer to Figure 3-3.

1. Connect the supply pressure line directly to the S1 port at the base of the actuator.
2. A conduit connection, E1, is provided at the actuator base for signal wiring to the I/P positioner. All power to the positioner is supplied over the signal wiring. Use shielded or non-shielded wire with a cross-sectional area of 0.2 to 2.1 square millimeters (24 to 14 AWG) for the control signal to the positioner.
3. Remove the side cover on the positioner side of the actuator as described in **ENCLOSURE REMOVAL**.
4. Feed the wires through the conduit connection and connect them to the terminal block AV+ and AV- positions.
5. Replace the side cover.

---

### **TYPES UP5 AND UP6 ACTUATORS**

**NOTE:** Refer to Figure 3-4.

1. Connect the supply pressure line directly to the S1 port at the base of the actuator.
2. A conduit connection, E1, is provided at the actuator base for signal wiring to the I/P positioner. All power to the positioner is supplied over the signal wiring. Use shielded or non-shielded wire with a cross-sectional area of 0.2 to 2.1 square millimeters (24 to 14 AWG) for the control signal to the positioner.
3. Remove the bottom side cover as described in **ENCLOSURE REMOVAL**.
4. Feed the wires through the conduit connection and connect them to the terminal block AV+ and AV- positions.
5. Replace the bottom side cover.

---

### **Solenoid Tubing and Wiring**

Solenoid tubing and wiring differs slightly depending on the actuator. If the actuator supplied includes the air failure lock, refer to **Air Failure Lock Tubing**.

---

### **TYPES UP1 AND UP2 ACTUATORS**

**NOTE:** Refer to Figures 3-9 And 3-10.

1. Types UP1 and UP2 actuators have a conduit connection provided on the solenoid valve for electrical hookup.
2. The solenoid wires (AC or DC) have no color coding or polarity markings. Use either wire for positive (+).
3. Connect the supply pressure line directly to the P port on the solenoid valve.

---

### **TYPES UP3 AND UP4 ACTUATORS**

**NOTE:** Refer to Figure 3-3.

1. Connect the supply pressure line directly to the S1 port at the base of the actuator.
2. A conduit connection, E1, is provided at the actuator base for solenoid valve wiring (AC or DC).
3. Remove the side cover on the solenoid side of the actuator as described in **ENCLOSURE REMOVAL**.




Figure 3-9. Type UP1 Actuator with Solenoid Valve and Air Failure Lock

4. Feed the wires through the conduit connection and connect them to the terminal block solenoid positions. The solenoid wires are not color coded or marked for polarity. Either wire can be used for positive (+).
5. Connect a grounding wire to the termination provided.
6. Replace the side cover.

### TYPES UP5 AND UP6 ACTUATORS

**NOTE:** Refer to Figure 3-4.

1. Connect the supply pressure line directly to the S1 port at the base of the actuator.
2. A conduit connection, E1, is provided at the actuator base for solenoid valve wiring (AC or DC).
3. Remove the bottom side cover on the solenoid side of the actuator as described in **ENCLOSURE REMOVAL**.

# INSTALLATION




Figure 3-10. Type UP2 Actuator with Solenoid Valve

4. Feed the wires through the conduit connection and connect them to the terminal block solenoid positions. The solenoid wires are not color coded or marked for polarity. Either wire can be used for positive (+).
5. Connect a grounding wire to the termination provided.
6. Replace the bottom side cover.

**Master/Slave Tubing Connections for Type UP6 Actuators**

**NOTES:**

1. Refer to Figure 3-11 and Table 3-3.
  2. This installation requires the use of an installation kit (supplied as part of the slave drive), kit number 258458°1.
1. To drive a common load, connect the master and slave actuators in parallel.




Figure 3-11. Master/Slave Tubing Connections

2. Be sure both actuators are properly aligned so they work together, without binding, throughout the stroke.

*Table 3-3. Master/Slave Installation Kit (Kit No. 258458 \_1)*

<b>Item</b>	<b>Qty</b>	<b>Part No.</b>	<b>Description</b>
1	2	1952621_1	½ bulkhead fitting
2	2	8-8CBI2-B	½ tubing elbow
3	2	—	⅜-18 NPT brass female tee
4	2	—	⅜-18 NPT brass close nipple
5	2	R9021-0050	152 cm (60 in.) 0.50 OD tubing
8	2	5323705_1	½ tubing elbow

3. The total volume displacement for both actuators is 41,200 cm<sup>3</sup> (2,514 in.<sup>3</sup>).
4. A supply delivery capacity of 11,800 cm<sup>3</sup>/sec (25 scfm) or more is desirable, unless some decrease in stroke speed can be allowed.
5. Connect the supply air line directly to the S1 port at the base of the master actuator.
6. Refer to **ENCLOSURE REMOVAL** and remove the top and side covers of the master actuator.
7. If the master actuator has the air failure lock option, perform Steps 8 through 11. If the master actuator does not have the air failure lock option, go to Step 12.
8. Remove the bypass valve air line fittings from the tees in the cylinder air lines.
9. Install a second female tee into the two existing tees using the close nipples (supplied).
10. Connect the bypass valve air lines to one of the open ports in each added tee.
11. Go to Step 13.
12. Remove the pipe plugs from the tees in the cylinder air lines.
13. Install two bulkhead fittings in the two available conduit knockouts at the base of the master. The knockouts have ½-14 NPT internal threads.
14. Connect ½-inch OD nylon tubing between each bulkhead fitting and the tees in the cylinder air lines using the four elbow tube fittings supplied.
15. Route and tie down the tubing so it clears all moving parts.
16. Label the bulkhead fittings to identify the one that tees into the top of the cylinder and the one that tees into the bottom of the cylinder. The external ends of the bulkhead fittings are female ½ NPT.

17. Use ½-inch minimum air lines to connect the master and slave actuators.

18. Hook up the two air lines connecting the master and slave actuators so cylinder forces (output torques) aid each other. Polarity of this connection varies for each installation. It depends on the physical setup of the actuators and how the linkage connects.

19. On the slave actuator, S1 goes to the top of the cylinder, and S3 goes to the bottom of the cylinder.

Increased pressure on the top of the cylinder causes the output shaft on the left side (when facing the hand crank end) to rotate counter-clockwise. Rotation on the master actuator is the same. Increased pressure on the bottom of the cylinder causes the output on the right side (when facing the hand crank end) to rotate clockwise. Rotation on the master actuator is the same.

To change from direct to reverse loading, refer to **Control Loading Arrangements**.

---

## **INSTALLATION OF OPTIONAL EQUIPMENT**

These procedures describe the tubing, wiring and cabling necessary to make the various options operable.

---

### **Reserve Air Tank Tubing and Wiring**

**NOTE:** The reserve air tank option is not available for Type UP1 actuators.

All tubing connections inside the actuator for the optional reserve air tank are completed before shipment. External tubing consists of connecting the air tank to the supply air line and actuator.

---

### **TYPE UP2 ACTUATORS**

**NOTE:** Refer to Figures 3-12 and B-11

1. Securely install the reserve air tank as close to the actuator as possible in a vibration-free location where the reserve air tank and air lines will not be damaged.
2. Using ¼-inch OD tubing, connect the customer air supply to the tee fitting at the S port on the positioner or the P port on the solenoid valve.
3. Using ¼-inch OD tubing, connect the inlet port on the reserve air tank to the check valve fitting on the positioner or solenoid valve.

4. Using ¼-inch OD tubing, connect the outlet port on the reserve air tank to the C port on either the upper or lower 3-way valve. The output shaft of the actuator can be rotated to either the 0% or 100% position with either connection.

**NOTE:** The unused C port must remain open to vent air.




Figure 3-12. Reserve Air Tank Tubing for Type UP2 Actuators

5. A designation label is supplied with the reserve air tank kit. One half is marked 0% and the other half is marked 100%. Cut the label in half and apply the 0% and 100% designations below the bulkhead fittings on the actuator frame that correspond to the 0% and 100% output shaft travel limits.
6. An alarm pressure switch and terminal block are installed inside the actuator for an external air failure alarm, indicator, etc. Refer to **Type UP2 Actuator** and remove the cover necessary to access the terminal block.
7. Run the wires for the external alarm through one of the holes in the actuator enclosure and connect them as shown in Figure 3-12.
8. Replace the actuator cover.

---

### **TYPES UP3 THROUGH UP6 ACTUATORS**

**NOTE:** Refer to Figures 3-13, B-12 and B-13.

1. Securely install the reserve air tank as close to the actuator as possible in a vibration-free location where the air tank and air lines will not be damaged.
2. Using ½-inch OD tubing, connect the customer air supply directly to the S1 port on the actuator.
3. Using ½-inch OD tubing, connect the inlet port on the reserve air tank to the S2 port on the actuator.
4. Using ¼-inch OD tubing, connect the outlet port on the reserve air tank to the actuator. Select one of the following:
  - For the cylinder piston to be driven to the full down position upon loss of pressure from the supply line, connect to the CYL DN port on the actuator.

**NOTE:** The CYL UP connection must remain open to vent air from the bottom of the cylinder.

**- or -**

- For the cylinder piston to be driven to the full up position upon loss of pressure from the supply line, connect to the CYL UP port on the actuator.

**NOTE:** The CYL DN connection must remain open to vent air from the top of the cylinder.




Figure 3-13. Reserve Air Tank Tubing for Types UP3 through UP6 Actuators

5. An alarm pressure switch and terminal block are installed inside the actuator for an external air failure alarm, indicator, etc. Refer to **Types UP3 and UP4 Actuator** or **Types UP5 and UP6 Actuator Enclosure** and remove the covers necessary to access the terminal block.
6. A conduit connection, AFC, is provided at the actuator base for access to the air failure contacts. Feed the wiring through this connection.
7. Make the connections to the proper points on the terminal strip as shown in Figure 3-13.
8. Replace the actuator covers.

**Air Failure Lock Tubing**

There are two possible tubing arrangements for actuators with the optional air failure lock.

- **Automatic Reset.** The air failure lock automatically resets when the air supply exceeds the trip valve setting.
- **Remote Reset.** The air failure lock remains tripped until deliberately reset via a reset switch as supplied (shown in Fig. 3-14) or a normally closed solenoid valve (not supplied).




Figure 3-14. Reset Switch for Air Failure Lock (Part Number 19515895°1)

### TYPE UP1 ACTUATOR

**NOTES:**

1. Refer to Figures 3-9, 3-14 and 3-15.
2. The reset switch and pipe plug are located in a drawstring bag attached to the actuator frame.

### Automatic Reset

1. Connect the customer air supply directly to port B of the trip valve.
2. Connect the customer air supply also to port D on the trip valve.

---

### **Remote Reset**

1. Connect the customer air supply directly to port B of the trip valve.
2. Install the reset switch in a suitable location. Refer to Figure 3-14 for the dimensions.
3. Connect port 1 on the reset switch to port D on the trip valve.
4. Connect the customer air supply also to port 2 on the reset switch.
5. Install the pipe plug into port 4 of the reset switch.

---

### **Alarm Pressure Switch Installation**

**NOTE:** Refer to Figures 3-9 and 3-15.

If desired, connect a pressure switch (part number 1941099°2 or equivalent) to sound an alarm or for status lights to indicate a loss of air supply.

1. Connect a tee between port 1 of the reset switch and port D of the trip valve.
2. Run tubing from the open end of the tee to the pressure switch.
3. Wire the switch to a terminal block or directly to the alarm as shown in Figure 3-15.

---

### **TYPE UP2 ACTUATOR**

**NOTES:**

1. Refer to Figures 3-10, 3-14 and 3-16.
2. The reset switch and pipe plug are located in a drawstring bag attached to the actuator frame.

---

### **Automatic Reset**

1. Connect the customer air supply directly to the AF1 port on the actuator enclosure.
2. Connect the customer air supply also to the AF2 port on the actuator enclosure.




Figure 3-15. Tubing Schematic for Type UP1 Actuator with Air Failure Lock

**Remote Reset**

1. Install the pipe plug into port 4 of the reset switch.
2. Install the reset switch in a suitable location. Refer to Figure 3-14 for the dimensions.
3. Install a tee into the air supply line.
4. Run tubing from one outlet of the tee to port 2 of the reset switch and from the other outlet of the tee to the AF1 port on the actuator frame.

5. Run tubing from port 1 of the reset switch to the AF2 port on the actuator frame.

---

### ***Alarm Pressure Switch Installation***

**NOTE:** Refer to Figures 3-10 and 3-16. If desired, connect a pressure switch (part number 1941099\_2 or equivalent) to sound an alarm or for status lights to indicate a loss of air supply.

1. Connect a tee between port 1 of the reset switch and the AF2 port on the actuator frame.
2. Run tubing from the open end of the tee to the pressure switch.
3. Wire the switch to a terminal block or directly to the alarm as shown in Figure 3-16.

---

### ***TYPES UP3 AND UP4 ACTUATORS***

**NOTES:**

1. Refer to Figures 3-3 and 3-17.
2. The reset switch and pipe plug are located in a drawstring bag attached to the actuator frame.

---

### ***Automatic Reset***

1. Connect the customer air supply directly to the S1 port on the actuator enclosure.
2. Connect the customer air supply also to the AF1 port on the actuator enclosure.

---

### ***Remote Reset***

1. Install the pipe plug into port 4 of the reset switch.
2. Install the reset switch in a suitable location. Refer to Figure 3-14 for the dimensions.
3. Install a tee into the air supply line.
4. Run tubing from one outlet of the tee to port 2 of the reset switch and from the other outlet of the tee to the S1 port at the base of the actuator.
5. Run tubing from port 1 of the reset switch to the AF1 port at the base of the actuator.




Figure 3-16. Tubing Schematic for Type UP2 Actuator with Air Failure Lock

**Alarm Pressure Switch Wiring**

**NOTE:** Refer to Figures 3-3 and 3-17.

# INSTALLATION

Types UP3 and UP4 actuators come with the alarm pressure switch installed. If desired, connect an alarm or status lights to indicate a loss of air supply.

1. Remove the side covers on both sides of the actuator as described in **ENCLOSURE REMOVAL**.
2. A conduit connection, AFC, is provided at the actuator base for access to the air failure contacts. Feed the wiring through this connection.




Figure 3-17. Tubing Schematic for Types UP3 and UP4 Actuators with Air Failure Lock

3. Make the connections to the proper points on the terminal strip as shown in Figures 3-3 and 3-17.
4. Replace the side covers.

---

### **TYPES UP5 AND UP6 ACTUATORS**

**NOTES:**

1. Refer to Figures 3-4 and 3-18.
2. The reset switch and pipe plug are located in a drawstring bag attached to the actuator frame.

---

#### ***Automatic Reset***

1. Connect the customer air supply directly to the S1 port on the actuator enclosure.
2. Connect the customer air supply line to the AF1 port on the actuator enclosure.

---

#### ***Remote Reset***

1. Install the pipe plug into port 4 of the reset switch.
2. Install the reset switch in a suitable location. Refer to Figure 3-14 for the dimensions.
3. Install a tee into the air supply line.
4. Run tubing from one outlet of the tee to port 2 of the reset switch and from the other outlet of the tee to the S1 port at the base of the actuator.
5. Run tubing from port 1 of the reset switch to the AF1 port at the base of the actuator.

---

#### ***Alarm Pressure Switch Wiring***

**NOTE:** Refer to Figures 3-4 and 3-18.

Types UP5 and UP6 actuators come with the alarm pressure switch installed. If desired, connect an alarm or status lights to indicate a loss of air supply.

1. Remove both of the bottom side covers as described in **ENCLOSURE REMOVAL**.
2. A conduit connection, AFC, is provided at the actuator base for access to the air failure contacts. Feed the wiring through this connection.

# INSTALLATION

3. Make the connections to the proper points on the terminal strip as shown in Figures 3-4 and 3-18.
4. Replace the bottom side covers.

## Pneumatic Shaft Position Transmitter Tubing for Types UP2 through UP6 Actuators

**NOTE:** A pneumatic shaft position transmitter is not available for the Type UP1 actuator.




Figure 3-18. Tubing Schematic for Types UP5 and UP6 Actuators with Air Failure Lock

---

**TYPES UP2, UP3 AND UP4 ACTUATORS**

**NOTE:** Refer to Figures 3-2 and 3-3.

These actuators have the pneumatic shaft position transmitter mounted externally.

1. Connect the required air supply line directly to the S port of the shaft position transmitter.
2. Using ¼-inch tubing and suitable fittings, connect the output line to the street tee in the O2 port of the shaft position transmitter.
3. Maintain a supply pressure of at least 35 kPa (5 psig) above the maximum desired output pressure, but not higher than 345 kPa (50 psig).

---

**TYPES UP5 AND UP6 ACTUATORS**

**NOTE:** Refer to Figure 3-4.

These actuators have the pneumatic shaft position transmitter mounted internally.

1. Connect the required air supply directly to the S2 port at the base of the actuator.
2. Connect the output line directly to the E2 port at the base of the actuator.
3. Use ¼-inch tubing and suitable fittings.
4. Maintain a supply pressure of at least 35 kPa (5 psig) above the maximum desired output pressure, but not higher than 345 kPa (50 psig).

---

**Volume Booster Tubing for Type UP6 Actuators**

All tubing connections inside the Type UP6 actuator for the optional volume booster are completed before shipment. External tubing is the same as that for Type UP6 actuators described in this chapter, except the S1, S2 and S3 bulkhead connections on the actuator are ¾-14 NPT. Customer tubing should be one inch OD tubing or ¾-14 NPT schedule 40 pipe.

---

**Alarm/Travel Switch Contact Wiring for Types UP1 through UP6 Actuators**

**NOTE:** Refer to Figure 3-19.

If the actuator comes with alarm/travel switches, it includes four SPDT cam-actuated microswitches [two heavy-duty (C1 and C4) for DC or AC service, and two (C2 and C3) for AC service]. Switches can be used as alarm contacts or for an external indication.

**TYPE UP1 ACTUATOR**

**NOTE:** Refer to Figures 3-1 and 3-19.




Figure 3-19. Electric Shaft Position Transmitter and Alarm/Travel Switches (for nomenclature options 11 in the sixth and seventh positions)

The adjustable travel switches for UP1 actuators are located inside the cover mounted to actuator frame.

1. Remove the four enclosure mounting screws holding the cover to the actuator frame.
2. Make the electrical connections from the switches at the terminal block as shown in Figures 3-1 and 3-19.
3. Run the wires through the conduit connector in the cover and replace the cover.

---

***TYPE UP2 ACTUATOR***

**NOTE:** Refer to Figures 3-2 and 3-19.

1. Remove the side panel as described in **ENCLOSURE REMOVAL**.
2. Make the electrical connections from the switches at the terminal block as shown in Figures 3-2 and 3-19.
3. Run the wires through the conduit connector in the side of the actuator frame.
4. Replace the side panel and top cover.

---

***TYPES UP3 AND UP4 ACTUATORS***

**NOTE:** Refer to Figures 3-3 and 3-19.

1. Remove the side cover on the cylinder side of the actuator as described in **ENCLOSURE REMOVAL**.
2. Make the electrical connections from the switches at the terminal block as shown in Figures 3-3 and 3-19.
3. Run the wires through conduit connector V2 at the base of the actuator.
4. Replace the side cover.

---

***TYPES UP5 AND UP6 ACTUATORS***

**NOTE:** Refer to Figures 3-4 and 3-19.

1. Remove the bottom side cover and top side cover on the cylinder side of the actuator as described in **ENCLOSURE REMOVAL**.
2. Make the electrical connections from the switches at the terminal block as shown in Figures 3-4 and 3-19.

3. Run the wires through conduit connector V1 at the base of the actuator.
4. Replace the actuator covers.

---

### **Electric Shaft Position Transmitter Wiring for Types UP1 through UP6 Actuators**

**NOTE:** Refer to Figures 3-19 through 3-22.

#### **CAUTION**

Signal wiring connected in this box must be rated for at least 300 V. Failure to use the proper wire may cause a short circuit and/or a fire which would damage the equipment and upset the process.

#### **ATTENTION**

La capacité nominale du câblage de signaux relié à ce boîtier doit être d'au moins 300 V. L'utilisation de câbles inadéquats pourrait provoquer un court-circuit ou un incendie, ce qui endommagerait le matériel et perturberait le processus.

If the actuator comes with an electric shaft position transmitter (external to the characterizable positioner), it has a linkage-driven shaft position transmitter. It includes the alarm contacts described in **Alarm/Travel Switch Contact Wiring for Types UP1 through UP6 Actuators**.

The transmitter, a two-wire, four to 20-milliamp output device, operates on 12 to 42 VDC. The signal wiring supplies power to the transmitter. Refer to Figure 3-20 for a typical wiring loop diagram. Use wire with a cross-sectional area of 0.32 to 2.10 square millimeters (22 to 14 AWG) rated at a minimum of 300 volts.

A twisted pair or shielded wire reduces the chance of noise pickup. If needed, ground the signal wiring at any location in the loop, but not at more than one point. If there are several transmitters on a single power supply, make the ground connection at the power supply.

Do not run wiring near high power electrical equipment or in the same conduit or trays as the power wiring. Although power supply regulation is not vital, ripple should not exceed 0.5 volt peak-to-peak. This insures a stable output signal. Supply voltages and load changes during operation have no effect on accuracy, since the combined load resistance falls within the operating ranges as shown in Figure 3-21. Do not exceed the indicated maximum of the combined resistance of the load and the signal wiring.

If the electric shaft position transmitter is internal to the characterizable positioner, it is a two-wire unit requiring a 12 to 34 VDC supply. It produces a four to 20-milliamp linear output relative to the actuator shaft position.

**NOTES:**

1. The procedures for accessing the electric shaft position transmitter on the actuators are the same as those for accessing alarm/travel switch contacts (described in **ENCLOSURE REMOVAL**). After gaining access to the transmitter, continue with the wiring procedures.
2. The wiring procedures in this section describe only the connections to an electric shaft position transmitter if it is external to the characterizable positioner. To make the connections to the electric shaft position transmitter that is internal to the positioner, refer to the appropriate positioner instruction.




Figure 3-20. Typical Wiring Loop Diagram for the Electric Shaft Position Transmitter

**TYPE UP1 ACTUATOR**

**NOTE:** Refer to Figures 3-1 and 3-19 through 3-22.

1. Make the connections to the transmitter at the terminal block locations as shown in Figures 3-1 and 3-19.
2. Run the wires through the conduit opening in the cover.
3. Replace the cover.

**TYPE UP2 ACTUATOR**

**NOTE:** Refer to Figures 3-2 and 3-19 through 3-22.

1. Make the connections to the transmitter at the terminal block locations as shown in Figures 3-2 and 3-19.
2. Run the wires through the conduit opening in the actuator frame.
3. Replace the panel and cover.




Figure 3-21. Supply Voltage and Load Resistance Limits for the Electric Shaft Position Transmitter

---

### TYPES UP3 AND UP4 ACTUATORS

**NOTE:** Refer to Figures 3-3 and 3-19 through 3-22.

1. Make the connections to the transmitter at the terminal strip locations as shown in Figure 3-3.
2. Run the wires through the V1 conduit opening located at the actuator base.
3. Replace the actuator covers.

---

### TYPES UP5 AND UP6 ACTUATORS

**NOTE:** Refer to Figures 3-4 and 3-19 through 3-22.

1. Make the connections to the transmitter at the terminal strip locations as shown in Figure 3-4.
2. Run the wires through the V1 conduit opening located at the base of the actuator.
3. Replace the actuator covers.

**REVERSE LOADING WIRING FOR ELECTRIC SHAFT POSITION TRANSMITTERS**

1. Remove the cover from the electric shaft position transmitter assembly.
2. Reverse P1 and P2 on the transmitter circuit board (Fig. 3-22).
3. Refer to Table 3-4 for wire color codes on the transmitter circuit board, for direct versus reverse loading.
4. Replace the transmitter cover and calibrate as described in Section 4.




Figure 3-22. Electric Shaft Position Transmitter Circuit Board

Table 3-4. Wire Color Codes for Direct Versus Reverse Loading on the Electric Shaft Position Transmitter

Control Loading	P1	P2	P3
Direct	WHT/VIO	WHT/GRY	WHT/GRN
Reverse	WHT/GRY	WHT/VIO	WHT/GRN

**Strip Heater Wiring for Types UP2 through UP6 Actuators**

**NOTE:** Strip heaters are not available for Type UP1 actuators.

ABB recommends ordering actuators with heating elements installed for applications where the ambient temperature remains below zero degrees Celsius (32 degrees Fahrenheit) for extended periods. A thermoswitch automatically starts the heaters when the temperature drops below approximately four degrees Celsius (40 degrees Fahrenheit).

**NOTE:** Follow the procedures for gaining access to the terminal strips for the alarm/travel switches in **Alarm/Travel Switch Contact Wiring for Types UP1 through UP6 Actuators**.

---

### ***TYPE UP2 ACTUATOR***

**NOTE:** Refer to Figure 3-2.

1. Make the connections to the terminal strip L1 (hot) and L2 (neutral) as shown in Figure 3-2.
2. Run the wires through the conduit opening in the actuator frame.
3. Replace the actuator covers.

---

### ***TYPES UP3 AND UP4 ACTUATORS***

**NOTE:** Refer to Figure 3-3.

1. Make the connections to the terminal strip L1 (hot) and N (neutral) as shown in Figure 3-3.
2. Run the wires through the HTR conduit opening in the actuator frame.
3. Replace the actuator covers.

---

### ***TYPES UP5 AND UP6 ACTUATORS***

**NOTE:** Refer to Figure 3-4.

1. Make the connections to the terminal strip L1 (hot) and N (neutral) as shown in Figure 3-4.
2. Run the wires through the HTR conduit opening in the actuator frame.
3. Replace the actuator covers.

---

## ***PRE-OPERATING ADJUSTMENTS***

Use these procedures to make any adjustments necessary to make the actuator operational.

---

### ***Control Loading Arrangements***

The actuator normally comes with the tubing connections made for direct loading operation. If desired, change to reverse loading operation.

---

### ***POSITIONER CONTROL LOADING ARRANGEMENTS***

The two types of positioner control loading are direct loading and reverse loading. Direct loading allows movement from zero to 100 percent (position indicator reading) as the control signal to the positioner increases. The actuator leaves the factory in this configuration.

Reverse loading allows the actuator to move from 100 to zero percent as the control signal to the positioner increases. To change from direct loading to reverse loading, remove the actuator covers (if required) necessary to access the positioner as outlined in **ENCLOSURE REMOVAL**. Follow the instructions for reverse loading in the appropriate positioner instruction.

---

**SOLENOID VALVE CONTROL LOADING ARRANGEMENTS**

The actuator normally comes with the tubing connections made for direct loading operation. If desired, change to reverse loading operation.

Direct loading allows movement from zero to 100 percent when the solenoid is energized. The actuators leave the factory in this configuration.

Reverse loading allows movement from 100 to zero percent when the solenoid is energized. To switch from direct to reverse loading:

1. Remove the actuator covers (if required) to gain access to the solenoid valve as described in **ENCLOSURE REMOVAL**.
2. Loosen the air line connections at the A and B ports of the solenoid.
3. Reverse the air line connections and tighten these connections.

**NOTE:** For dual coil solenoid valves, reverse either the air lines or the electrical connections to the coils.

4. Replace the actuator covers.

### Operating Lever Adjustment

**WARNING**

Failure to tighten the lever assembly bolts to the torque specifications may cause the load to shift and bodily injury could result.

**AVERTISSEMENT**

Toute négligence à serrer les boulons du levier conformément au couple prescrit pourrait entraîner le déplacement de la charge et par conséquent provoquer des blessures.

---

#### TYPE UP1 ACTUATOR

**NOTE:** Refer to the drawings in **SPARE PARTS** in Appendix A and **DIMENSION DRAWINGS** in Appendix B.

1. Loosen the two socket hex-head cap screws in the lever hub using a  $\frac{5}{16}$ -inch socket wrench.
2. Determine at what angle to locate the lever for zero percent position (normally parallel to the driven lever).
3. Rotate the lever to the correct position.
4. Secure the lever assembly to the shaft by tightening the socket hex-head cap screws to 71 to 79 Newton meters (52 to 57 foot-pounds).
5. Connect the linkage to the lever in the desired arrangement.
6. Refer to **Connecting Linkage for Universal Rotary Actuators** for alternate linkage arrangements.

---

#### TYPE UP2 ACTUATOR

**NOTE:** Refer to the drawings in **SPARE PARTS** in Appendix A and **DIMENSION DRAWINGS** in Appendix B.

1. Loosen the two socket hex-head cap screws in the lever hub using a  $\frac{1}{2}$ -inch hex wrench.
2. Determine at what angle to locate the lever for zero percent position (normally parallel to the driven lever).
3. Rotate the lever to the correct position.
4. Secure the lever assembly to the shaft by tightening the socket hex-head cap screws to 85 to 91 Newton meters (63 to 67 foot-pounds).
5. Connect the linkage to the lever in the desired arrangement.
6. Refer to **Connecting Linkage for Universal Rotary Actuators** for alternate linkage arrangements.

---

**TYPES UP3/4/5/6 ACTUATORS**

**NOTE:** Refer to the drawings in **SPARE PARTS** in Appendix A and **DIMENSION DRAWINGS** in Appendix B.

1. Loosen the clamping screws in the lever hub.
2. Pull the lever off of the splined shaft.
3. Determine at what angle to locate the lever for zero percent position (normally parallel to the driven lever).

**NOTE:** The lever may be located on either end of the shaft.

4. Push the lever onto the shaft in the desired position.
5. Secure the lever to the shaft by tightening the clamping screws to 38 to 44 Newton meters (28 to 32 foot-pounds).
6. Connect the linkage to the lever in the desired arrangement.
7. Refer to **Connecting Linkage for Universal Rotary Actuators** for alternate linkage arrangements.

---

**Position Indicator**

Upon changing the control loading of the actuator, switch the scale for the position indicator to match the rotation of the actuator.

**NOTE:** Before mounting the position indicator, clean dust, dirt, oil, moisture, etc. from the mounting surface.

---

**TYPES UP1 AND UP2 ACTUATORS**

Types UP1 and UP2 actuators come with two adhesive-backed position indicator scales. They are graduated from zero to 100 percent in ten percent increments. One scale, fixed to the sector plate at the factory, reads zero to 100 percent from left to right. The second scale, taped to the rear side of the sector plate, reads zero to 100 percent from right to left. Install the latter scale on reverse acting actuators to match the rotation of the driven device. Simply remove the backing, and place the reverse indicating scale over the scale installed at the factory.

---

**TYPES UP3/4/5/6 ACTUATORS**

Types UP3, UP4, UP5 and UP6 actuators come with a shaft-mounted position indicator and indicator scales graduated from zero to 100 percent in 25 percent increments. One scale reads zero to 100 percent from right to left. The second scale reads zero to 100 percent from left to right. These scales come in a separate bag. Choose the scale that matches the closed versus open position of the driven device. Two punch marks on the actuator at the output shaft help position the scale

### ***Mechanical Stop Adjustment for Types UP1 and UP2 Actuators***

**NOTES:**

1. Refer to Figures **3-1** and **3-2**.
2. The mechanical stop is only available on the types UP1 and UP2 actuators.

The nominal setting of the stroke is for a rotation of 90 degrees. Adjustable mechanical stops, located on each end of the actuator, allow adjustment over a range of 80 to 92 degrees.

1. Loosen the  $\frac{5}{16}$  -18 hex nut located on the socket head stop-screw.
2. Hold the hex nut and adjust the stop-screw clockwise to decrease the rotation, or counterclockwise to increase rotation.
3. Tighten the hex nut.
4. Calibrate the positioner (if supplied) for the new output stroke. Refer to ***Zero Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators*** and ***Span Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators*** in Section 4.

---

## SECTION 4 - CALIBRATION

---

### **INTRODUCTION**

This section includes the calibration required before placing the actuator into operation. Calibration procedures for optional equipment appear here.

---

### **EQUIPMENT REQUIRED FOR CALIBRATION**

- A full complement of screwdrivers, hex wrenches and Allen wrenches.
- Instrument pressure gage - part number 5326605\_4, or equivalent.
- Two output pressure gages - part number 5326605\_6, or equivalent.
- Milliammeter capable of reading 4 to 20-milliamp output.

---

### **CALIBRATION PROCEDURES**

The positioner calibration procedures described in this section apply to the actuator only as a function of the positioner. The procedures for positioner calibration are printed in the appropriate instruction for the positioner in use and are not reprinted here.

---

#### ***Positioner Access***

Access to the positioner on Types UP1 and UP2 actuators is not restricted by an enclosure. Refer to the proper enclosure removal procedure in the installation section to access the positioner on Types UP3 through UP6 actuators.

---

#### ***Zero Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators***

The actuator comes set for full travel proportional to full range input signal. The positioner range spring assembly applies a proportional feedback force to the input signal diaphragm assembly. The zero adjustment nut in the positioner applies initial tension on the range spring and provides a zero adjustment. Install the actuator as directed, check the positioner zero and adjust if necessary.

If requiring another relationship between travel and input signal, set the zero before any other adjustment. This sets the cam zero relative to the minimum input signal [21 kilopascals (three pounds per square inch gage) or four milliamps].

For an elevated zero, an initial tension imposed on the range spring prevents the actuator from moving from its minimum position until the input signal increases above the elevated zero value. Refer to Table 4-1 for zero elevations.

Table 4-1. Zero Elevation

Actuator Type	Calibrated Zero	Elevated Zero
UP__A	21 kPa (3.0 psig)	Any value between 21 and 62 kPa (3 and 9 psig)
UP__B	21 kPa (3.0 psig)	Any value between 21 and 103 kPa (3 and 15 psig)
UP__C	4 mA	Any value between 4 and 12 mA by adjusting pneumatic zero
UP__D	4 mA	Any value between 4 and 12 mA by adjusting pneumatic zero

Some applications that might use an elevated zero are when two or more actuators are operated in sequence or when the characteristics of the device moved by the actuator need to match those of another regulated device.

1. Gain access to the positioner.
2. Take off the cover to the positioner by removing the two cover screws.
3. Refer to the appropriate positioner instruction for the step-by-step zero adjustment procedure.

---

### **Span Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators**

The span adjustment affords a variation of actuator motion for a given span of control signal pressure.

With any of the characterized cams, the span adjustment allows full actuator travel to occur with a signal change as small as 50 percent of its full span. This is referred to as split ranging. This is valuable when running two or more actuators in sequence. For example, one actuator could fully open a damper from a 21 to 62 kilopascals (three to nine pounds per square inch gage) signal, while the next opens fully from a 62 to 103 kilopascal (nine to 15 pounds per square inch gage) signal. In this case, the second actuator requires zero elevation.

At the other extreme, the span adjustment can be set to produce as little as 50 percent of the travel capability of the actuator over the full input signal span. This is referred to as travel limiting. This is valuable when the device the actuator regulates is oversized and a full open

position is not desirable. Before starting the procedure, determine the percentage of travel desired.

1. Gain access to the positioner.
2. Refer to the appropriate positioner instruction for the step-by-step span adjustment procedure.

---

***Speed Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators***

When the system involves only a single actuator, a high positioning speed is usually an advantage. However, in a complex control system it is generally desirable to operate all power devices at the same speed. This helps to avoid interaction between units that produce undesirable process conditions. If it is necessary to reduce the speed of operation, 1.02 millimeter (0.04 inch) speed control orifices (Part No. 5327327\_1) are available from ABB. If these orifices are too small, they may be drilled out to obtain the desired speed control. To reduce the speed even more, blank orifices (Part No. 5327327\_2) are also available.

**NOTE:** Do not use the speed control orifices to correct an instability (hunting action). Use the orifices only to vary the stroke time.

1. Gain access to the positioner.
2. Refer to the appropriate positioner instruction for the speed adjustment procedure.

---

***Gain Adjustment for Positioner-Equipped Types UP1 through UP6 Actuators***

Gain adjustment on positioner-equipped Types UP1 through UP6 actuators is accomplished by changing the positioner gain hinge spring. The hinge installed at the factory is suitable for most applications. However, if the gain is too great for an application, oscillation of the driven element could result. If this is the case, install a gain hinge spring that yields a lower gain.

1. Gain access to the positioner.
2. Take off the cover to the positioner by removing the two cover screws.
3. Refer to the appropriate positioner instruction for the gain adjustment procedure.

---

***OPTIONAL EQUIPMENT CALIBRATION***

Use the following procedures to calibrate any optional equipments that may be installed on the actuator.

### *Electric Shaft Position Transmitter Calibration for Types UP1 through UP6 Actuators*

**NOTES:**

1. Refer to Figure 3-19.
2. This procedure is for an electric shaft position transmitter external to the positioner. To calibrate transmitters internal to the positioner, refer to the appropriate positioner instruction.
1. Refer to the proper enclosure removal procedure in the installation section to access the electric shaft position transmitter.
2. Connect a milliammeter in series with the positive (+) or negative (-) leads of the transmitter output, or across the test jacks TP1 (+) and TP2 (-) (Fig. 3-19).
3. Activate the 12 to 42 VDC power in the transmitter loop.
4. Manually position the actuator to the zero percent travel position (100 percent for reverse acting) and observe the reading on the milliammeter.
5. Adjust the zero potentiometer (R4 - Fig. 3-19) until the milliammeter reads 4.0 mA.
6. Manually position the actuator to the 100 percent position (zero percent for reverse acting) and observe the reading on the milliammeter.
7. Adjust the span potentiometer (R5 - Fig. 3-19) until the milliammeter reads 20.0 mA.
8. Repeat Steps 4 through 7 until the milliammeter indicates the correct reading at both extremes of travel.
9. Manually position the actuator to the 50% position and verify that the milliammeter reads 12.0 mA.

---

### *Alarm/Travel Switch Calibration*

**NOTE:** Refer to Figure 3-19.

This option consists of four linkage-driven, cam-operated SPDT microswitches, adjustable over the full stroke of the actuator. Switches can be used as alarm contacts or for external indicators.

Set the microswitch alarm contacts that make up the alarm/ travel switch assembly to operate at any desired position. To do so, adjust the switch cam to make or break a contact at that point.

1. Refer to the proper enclosure removal procedure in the installation section to access the alarm/travel switches.

2. Manually position the actuator output shaft to the desired actuating position.
3. Loosen the cam setscrew holding the cam to the switch assembly shaft.
4. Rotate the microswitch cam to the desired actuating position.
5. Tighten the setscrew to lock the cam on the shaft.

---

***Pneumatic Shaft Position Transmitter Calibration***

**NOTE:** The pneumatic shaft position transmitter option is not available for Type UP1 actuators.

1. The pneumatic shaft position transmitter mounts on the outside of the Types UP2, UP3 and UP4 actuators. Refer to the proper enclosure removal procedure in the installation section to access the pneumatic shaft position transmitter on Types UP5 and UP6 actuators.
2. Refer to the appropriate positioner instruction to calibrate the pneumatic shaft position transmitter.

---

***Reserve Air Tank Calibration***

No adjustment is required for the trip valves or pressure switch. All adjustments are made before shipment.

---

***Volume Booster Calibration***

The volume booster has a bypass restriction adjustment for stable actuator performance. Refer to the appropriate volume booster instruction for the adjustment procedure.

---

***Air Failure Lock Calibration***

The trip and lock valves require adjustment based on the required or available air supply to obtain the required output torque.

Factory personnel set the trip valve at 240 kilopascals (35 pounds per square inch gage) for Types UP1 and UP2 actuators and 380 kilopascals (55 pounds per square inch gage) for Types UP3, UP4, UP5 and UP6 actuators. If the application requires a different setting, refer to Figures 3-5 and 3-7 for the suggested maximum operating torque versus air supply pressure. The stall torque graphs in Figures 3-6 and 3-8 show the minimum supply pressure needed to hold the actual load imposed on the actuators. Consider this pressure as the minimum trip valve setting. The maximum trip valve setting is 103 kilopascals (15 pounds per square inch gage) below the available or required air supply for actuators with positioners and 138 kilopascals (20 pounds per square inch gage) for actuators with solenoid valves.

The recommended lock valve setting is a minimum of 103 kilopascals (15 pounds per square inch gage) below the trip valve setting.

Types UP1 and UP2 actuators use a mechanical latch device with a three-way pneumatic trip valve as the air supply sensor. A customer-supplied pressure switch may be added to signal an air failure alarm or for a status light. Types UP3, UP4, UP5 and UP6 actuators come with lock valves along with the trip valve. They use a three-way pneumatic trip valve as the air supply sensor that trips one four-way (Types UP3 and UP4 actuators) or two three-way (Types UP5 and UP6 actuators) lock valves to lock the actuator in the last position. Types UP3 through UP6 actuators include a pressure switch that can be used to signal an air failure alarm or for a status light.

The trip valve mounts on the outside of the Type UP1 actuator. Refer to the proper enclosure removal procedure in the installation section to access the air failure lock on Types UP2 through UP6 actuators.

---

### **TRIP VALVE ADJUSTMENT FOR TYPES UP1 THROUGH UP6 ACTUATORS**

1. Install a supply pressure gage in the supply pressure line.

**NOTE:** If the air supply connected according to Figures 3-15 through 3-18 in Section 3 is not adjustable, or if adjustment would disrupt other processes, disconnect it and connect a 345 kPa (50 psig) up to 689 kPa (100 psig) air supply for Types UP1 and UP2 actuators, or a 482 kPa (70 psig) to 689 kPa (100 psig) air supply for Types UP3 through UP6 actuators.

2. Loosen the trip valve adjusting screw locknut (Fig. 3-9).
3. On positioner-equipped units, make sure the control loading signal is connected as described in the installation section.
4. Increase the air supply pressure to the operating value and press the remote pushbutton, if installed.
5. Decrease the air pressure to the desired trip value.
6. Turn the trip valve adjusting screw clockwise to increase the trip pressure or counterclockwise to decrease the trip pressure.
7. Repeat Steps 4 through 6 until the trip valve drops out at the desired trip pressure.
8. Tighten the adjusting screw locknut.

---

**LOCK VALVE ADJUSTMENT FOR TYPES UP3/4/5/6 ACTUATORS**

**NOTE:** Refer to Figures 3-17 and 3-18.

Types UP3 through UP6 actuators have lock valves along with the trip valve. The trip valve dumps the control pressure to the lock valves, trapping the air in the cylinder. Factory personnel set the lock valves at 138 kilopascals (20 pounds per square inch gage). If the trip valve setting is decreased below 345 kilopascals (50 pounds per square inch gage), adjust the lock valves to at least 103 kilopascals (15 pounds per square inch gage) below the trip valve setting. An increase in trip valve setting requires no change in lock valve setting.

1. Install a supply pressure gage in the supply pressure line.
2. Disconnect the tubing from the inlet port of the lock valve (S port for Types UP3 and UP4 actuators and D port for Types UP5 and UP6 actuators).
3. Connect the adjustable air supply to the inlet port and set the pressure for 103 to 137 kPa (15 to 20 psig) below the trip valve pressure setting.
4. Reduce the lock valve pressure adjustment until the lock switches.
5. Disconnect the adjustable air supply and connect the original tubing.

---

# SECTION 5 - OPERATING PROCEDURES

---

## INTRODUCTION

This section of the manual has procedures for normal operation of the Type UP Universal Pneumatic Rotary Actuators. Descriptions of the controls reside here.

<b>WARNING</b>	<b>Do not operate this equipment unless the covers are in place. The covers prevent access to moving components that pose a risk of entanglement of body parts.</b>
<b>AVERTISSEMENT</b>	<b>Ne faites fonctionner cet équipement que si les couvercles sont en place. Les couvercles empêchent l'accès à des composantes en mouvement qui présentent un risque d'emmêlement des membres.</b>

---

## NORMAL OPERATING CONSIDERATIONS

All actuators can operate in either an automatic or a manual mode.

Positioner-equipped actuators make use of the integral shutoff and equalizing valve (Figs. 5-1, 5-2 and 5-3) on the positioner. This allows either manual or automatic operation of the actuator power unit. When set for automatic operation, the valve is locked into position by a safety latch. This safety latch prevents the valve from being bumped or jarred out of position.

Changing to manual operation cuts off the supply pressure to the actuator and couples the O1 and O2 ports of the positioner to equalize pressure across the vane (Types UP1 and UP2 actuators) or cylinder (Types UP3, UP4, UP5 and UP6 actuators). This allows manual positioning of the actuator unit.

Solenoid-equipped actuators have an equalizing valve (Figs. 5-1, 5-2 and 5-3). On the Types UP1 and UP2 actuators, this valve equalizes pressure on both sides of the rotary vane paddle. This allows manual positioning of the vane paddle. On Types UP3, UP4, UP5 and UP6 actuators, the valve equalizes pressure on both sides of the cylinder. This allows manual positioning of the actuator using the hand operator ratchet handle.

The remote reset air failure lock (if supplied) locks the actuator in place on loss of air supply pressure. The pneumatic pushbutton allows release of the air failure lock from a local or remote location upon restoration of the air supply pressure.

On Types UP1 and UP2 actuators, the air failure lock consists of a latching spring return cylinder (nonadjustable) that is triggered from an adjustable trip valve. This latches a rack gear mechanism. When

the air supply fails, the latching spring return cylinder opens the equalizing valve across the vane power unit. This permits manual operation of the actuator. A customer-supplied pressure switch (Figs. 3-15 and 3-16) may be used to signal an air failure alarm or a status light.

On Types UP3, UP4, UP5 and UP6 actuators, the air failure lock is a pneumatic device that uses a three-way pneumatic trip valve as the air supply sensor. It trips a four-way lock-up valve on Types UP3 and UP4 actuators, or two three-way lock-up valves on Types UP5 and UP6 actuators. The actuators include a pressure switch for use as an air failure alarm or a status light.

---

### **TYPES UP1 AND UP2 ACTUATOR OPERATION**

Types UP1 and UP2 actuator operation differs slightly depending on whether control of the actuator comes from a positioner or a solenoid valve. The addition of the air failure lock option also varies the operation. The reserve air tank option (Type UP2 actuator only) has no effect on normal actuator operation.

---

#### ***Positioner-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation***

**NOTE:** Refer to Figure 5-1.

When a Type UP1 or UP2 actuator is supplied with a positioner and is in the automatic mode, the integral shutoff and equalizing valve on the positioner is in the *AUTO* position. When the application calls for manual operation:

1. Pull the manual lock bolt up tight.
2. Push down on the integral shutoff and equalizing valve on the positioner and turn it counterclockwise to the *MAN* position.
3. When not in the automatic mode, pull the manual lock bolt up tight. If it is necessary to reposition the load while in the manual mode:
  - a. Loosen the manual lock bolt.
  - b. Reposition the load using the extended handle on the linkage.
  - c. Tighten the manual lock bolt.
4. Note the position of the rotary vane on the position indicator.




Figure 5-1. Operating Controls - Types UP1 and UP2 Actuators

5. If the manual lock bolt does not lock the rotary vane unit in position, and the actuator must stay in that initial position, adjust the input signal to correspond with:

- a. The actuator position as indicated by the balanced positioner output pressures,

- or -

- b. A plot of the actuator position versus the input signal, developed from prior knowledge of the unit.

---

### ***Positioner-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation***

**NOTE:** Refer to Figure 5-1.

When a Type UP1 or UP2 actuator is supplied with a positioner and is in the manual mode, the integral shutoff and equalizing valve on the positioner is in the *MAN* position. When the application calls for automatic operation:

1. Before shifting to *AUTO*, the actuator position must agree, as close as possible, to the input signal. If not, the hand and actuator linkage lever jumps when the transfer takes place. Adjust the input signal to correspond to the actuator position (or vice versa). Estimate by watching the balanced positioner output pressures. If the setup needs more precision, use a previously prepared plot of the input signal versus the actuator position.
2. Turn the integral shutoff and equalizing valve on the positioner to the *AUTO* position.
3. Release the manual lock bolt slowly. Let the actuator move slightly to get a balanced condition.
4. The actuator positions itself automatically.

---

### ***Solenoid-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation***

**NOTE:** Refer to Figure 5-1.

When a Type UP1 or UP2 actuator is supplied with a solenoid valve and is in the automatic mode, the customer air supply shutoff valve is open and the solenoid equalizing valve is closed. When the application calls for manual operation:

1. Tighten the manual lock bolt.
2. Close the customer air supply shutoff valve.
3. Open the solenoid equalizing valve.
4. When the hand and actuator linkage lever is not being operated, the manual lock bolt is pulled up tight. Temporarily release the manual lock bolt and position the actuator by manual operation of the hand and actuator linkage lever.
5. If desired, lock the actuator pointer arm and hand and linkage lever in position with the manual lock bolt.

---

### ***Solenoid-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from***

***Manual to Automatic Operation***

**NOTE:** Refer to Figure 5-1.

When a Type UP1 or UP2 actuator is supplied with a solenoid valve and is in the manual mode, the customer air supply shutoff valve is closed and the solenoid equalizing valve is open. When the application calls for automatic operation:

1. Open the customer air supply shutoff valve.
2. Close the solenoid equalizing valve.
3. Slowly and carefully release the manual lock bolt.
4. Unless the actuator is already at the full end of travel dictated by the action of the solenoid valve, it will move in that direction.

---

***Remote Reset Air Failure Lock Equipped Types UP1 and UP2 Actuators – Transfer from Automatic to Manual Operation***

**NOTE:** Refer to Figure 5-1.

If the customer air supply fails, the latching spring return cylinder opens the equalizing valve across the vane power unit. This permits manual operation of the actuator. If desired, switch to manual operation even if the customer air supply has not failed.

1. Disengage the lock latch by use of the override lever.
2. Follow the instructions under ***Positioner-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation*** or ***Solenoid-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation***.

---

***Remote Reset Air Failure Lock Equipped Types UP1 and UP2 Actuators – Transfer from Manual to Automatic Operation***

**NOTE:** Refer to Figure 5-1.

If the actuator is in the manual mode and it is desired to switch to automatic operation, the customer air supply must be operational.

1. Press the remote release pushbutton (if used) to release the air failure lock.
2. Engage the lock latch by use of the override lever.

3. Follow the instructions under **Positioner-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation** or **Solenoid-Equipped Types UP1 and UP2 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation**.

---

### TYPES UP3 AND UP4 ACTUATOR OPERATION

Types UP3 and UP4 actuator operation differs slightly depending on whether control of the actuator comes from a positioner or a solenoid valve. The addition of the air failure lock option also varies the operation. The reserve air tank option has no effect on normal actuator operation.

---

#### **Positioner-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation**

**NOTE:** Refer to Figure 5-2.

When a Type UP3 or UP4 actuator is supplied with a positioner and is in the automatic mode, the positioner integral shutoff and equalizing valve is in the *AUTO* position, and the *HAND/AUTO* transfer handle is in the *AUTO* position. When the application calls for manual operation:

1. Move the *HAND/AUTO* transfer handle on top of the actuator to the *HAND* position.

**NOTE:** The *HAND/AUTO* transfer handle may not engage immediately with the split nut. Turn the hand operator ratchet handle in either direction until the split nut mechanism snaps in place.

2. Press in the safety latch on the positioner integral shutoff and equalizing valve. Turn the valve to the *HAND* position.
3. Move the actuator to the desired position by means of the hand operator ratchet handle.

**NOTE:** The manual operating mechanism is self-locking and holds any position to which it is set.

---

#### **Positioner-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation**

**NOTE:** Refer to Figure 5-2.

When a Type UP3 or UP4 actuator is supplied with a positioner and is in the manual mode, the positioner integral shutoff and equalizing valve is in the *HAND* position, and the *HAND/AUTO* transfer handle is in the *HAND* position. When the application calls for automatic operation:

**WARNING**

Undesirable motion of the drive arm and linkage may occur which could cause injury or upset the process if the transfer instructions are not followed.

**AVERTISSEMENT**

Danger d'un mouvement inopportun du bras de commande et de la tringlerie pouvant causer des blessures ou bouleverser le procede. Suivre attentivement les procedures du transfert de commande manuelle a automatique.

**NOTE:** If a *HAND/AUTO* remote-mounted control station exists, it should be in the *HAND* mode before attempting the transfer.

1. Before shifting to *AUTO*, the actuator position must agree, as close as possible, to the input signal. If not, the drive arm jumps when the transfer takes place.
2. Adjust the input signal to correspond to the actuator position (or vice versa if the system conditions permit). This can be closely approximated by using a previously prepared plot of the input signal versus the actuator position.
3. Two methods of transfer exist. **Method A** is most often used.

---

**METHOD A – CHANGING THE INPUT SIGNAL TO MATCH THE ACTUATOR POSITION**

**NOTE:** Use Method A if it is *not* possible to move the actuator without endangering the operation of the system.

- a. Turn the positioner shutoff and equalizing valve to the *AUTO* position.
- b. Slowly change the input signal to match the actuator position.
- c. Exert **moderate** force on the *HAND/AUTO* transfer handle toward the *AUTO* position while adjusting the input signal. Do this until the *HAND/AUTO* transfer handle moves freely to the *AUTO* position.

---

**METHOD B – MANUALLY POSITIONING THE ACTUATOR TO MATCH THE INPUT SIGNAL**

**NOTE:** Use Method B if it is possible to move the actuator position without endangering the operation of the system.

- a. Turn the positioner shutoff and equalizing valve to the *AUTO* position.
- b. Turn the hand operator ratchet handle to determine the direction of the least load resistance. Use the selector button at the hub of the ratchet to change the direction of rotation.




Figure 5-2. Operating Controls - Types UP3 and UP4 Actuators

- c. While turning the hand operator ratchet handle in the direction of least resistance, exert **moderate** force on the *HAND/AUTO* transfer handle toward the *AUTO* position. Do this until the *HAND/AUTO* transfer handle moves freely to the *AUTO* position.

After completing the transfer via Method A or Method B, the actuator positions itself automatically.

## **Solenoid-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation**

**NOTE:** Refer to Figure 5-2.

When a Type UP3 or UP4 actuator is supplied with a solenoid valve and is in the automatic mode, the customer air supply valve is open, the solenoid equalizing valve is closed and the *HAND/AUTO* transfer handle is in *AUTO*. When the application calls for manual operation:

1. Turn the *HAND/AUTO* transfer handle to *HAND*.
2. Open the solenoid equalizing valve.

3. Close the customer-installed air supply shutoff valve.

**NOTE:** The *HAND/AUTO* transfer handle may not engage immediately with the split nut. Turn the hand operator ratchet handle in either direction until the split nut snaps in.

4. Move the actuator to the desired position by means of the hand operator ratchet handle.

**NOTE:** The manual operating mechanism is self-locking and holds any position to which it is set.

---

***Solenoid-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation***

**NOTE:** Refer to Figure 5-2.

When a Type UP3 or UP4 actuator is supplied with a solenoid valve and is in the manual mode, the customer air supply shutoff valve is closed, the solenoid equalizing valve is open and the *HAND/AUTO* transfer handle is in *HAND*. When the application calls for automatic operation:

1. Manually position the actuator to the extreme end of travel corresponding to solenoid demand.
2. Close the solenoid equalizing valve.
3. Slowly open the customer air supply shutoff valve.
4. Turn the *HAND/AUTO* transfer handle to *AUTO*.

After completing the transfer, the actuator is under solenoid control.

---

***Remote Reset Air Failure Lock Equipped Types UP3 and UP4 Actuators – Transfer from Automatic to Manual Operation***

**NOTE:** Refer to Figure 5-2.

If the customer air supply fails, the actuator may be put into manual operation. It may also be desirable to switch to manual operation even if the customer air supply has not failed.

1. Open the air failure lock equalizing valve.
2. Follow the instructions under ***Positioner-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation*** or ***Solenoid-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation***.

## OPERATING PROCEDURES

### Remote Reset Air Failure Lock Equipped Types UP3 and UP4 Actuators – Transfer from Manual to Automatic Operation

**NOTE:** Refer to Figure 5-2.

If the actuator is in the manual mode and it is desired to switch to automatic operation, the customer air supply must be operational.

1. Press the remote release pushbutton (if used) to release the air failure lock.
2. Close the air failure lock equalizing valve.
3. Follow the instructions under **Positioner-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation** or **Solenoid-Equipped Types UP3 and UP4 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation**.

### TYPES UP5 AND UP6 ACTUATOR OPERATION

Types UP5 and UP6 actuator operation differs slightly depending on whether control of the actuator comes from a positioner or a solenoid valve. The addition of the air failure lock option also varies the operation. The reserve air tank option has no effect on actuator operation.

### Positioner-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation

**NOTE:** Refer to Figure 5-3.




Figure 5-3. Operating Controls - Types UP5 and UP6 Actuators

When a Type UP5 or UP6 actuator is supplied with a positioner and is in the automatic mode, the positioner integral shutoff and equalizing valve is in the *AUTO* position, and the *HAND/AUTO* transfer handle is in the *AUTO* position. When the application calls for manual operation:

1. Move the *HAND/AUTO* transfer handle to the *HAND* position.

**NOTE:** The *HAND/AUTO* transfer handle may not engage immediately with the clutch mechanism. Turn the hand operator ratchet handle in either direction until the clutch mechanism snaps in place.

2. Press in the safety latch on the positioner integral shutoff and equalizing valve (located on the side of the actuator). Turn the valve to the *HAND* position.

3. Move the actuator to the desired position by means of the hand operator ratchet handle.

**NOTE:** The manual operating mechanism is self-locking and holds any position to which it is set.

---

***Positioner-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation***

**NOTE:** Refer to Figure 5-3.

When a Type UP5 or UP6 actuator is supplied with a positioner and is in the manual mode, the positioner integral shutoff and equalizing valve is in the *HAND* position, and the *HAND/AUTO* transfer handle is in the *HAND* position.

<b>WARNING</b>	<b>Undesirable motion of the drive arm and linkage may occur which could cause injury or upset the process if the transfer instructions are not followed.</b>
<b>AVERTISSEMENT</b>	<b>Danger d'un mouvement inopportun du bras de commande et de la tringlerie pouvant causer des blessures ou bouleverser le procede. Suivre attentivement les procedures du transfert de commande manuelle a automatique.</b>

**NOTE:** If a *HAND/AUTO* remote mounted control station exists, it should be in the *HAND* mode before attempting the transfer.

When the application calls for automatic operation:

1. Before shifting to *AUTO*, the actuator position must agree, as close as possible, to the input signal. If not, the drive arm jumps when the transfer takes place.

2. Adjust the input signal to correspond to the actuator position (or vice versa if the system conditions permit). This can be closely approximated by using a previously prepared plot of the input signal versus the actuator position.

3. Two methods of transfer exist. **Method A** is most often used.

---

### **METHOD A – CHANGING THE INPUT SIGNAL TO MATCH THE ACTUATOR POSITION**

**NOTE:** Use Method A if it is *not* possible to move the actuator without endangering the operation of the system.

- a. Turn the positioner shutoff and equalizing valve to the *AUTO* position.
- b. Slowly change the input signal to match the actuator position.
- c. Exert **moderate** force on the *HAND/AUTO* transfer handle toward the *AUTO* position while adjusting the input signal. Do this until the *HAND/AUTO* transfer handle moves freely to the *AUTO* position.

---

### **METHOD B – MANUALLY POSITIONING THE ACTUATOR TO MATCH THE INPUT SIGNAL**

**NOTE:** Use Method B if it is possible to move the actuator position without endangering the operation of the system.

- a. Turn the positioner shutoff and equalizing valve to the *AUTO* position.
- b. Turn the hand operator ratchet handle to determine the direction of the least load resistance. Use the selector button at the hub of the ratchet to change the direction of rotation.
- c. While turning the hand operator ratchet handle in the direction of least resistance, exert **moderate** force on the *HAND/AUTO* transfer handle toward the *AUTO* position. Do this until the *HAND/AUTO* transfer handle moves freely to the *AUTO* position.

After completing the transfer via Method A or Method B, the actuator positions itself automatically.

---

### **Solenoid-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation**

**NOTE:** Refer to Figure 5-3.

When a Type UP5 or UP6 actuator is supplied with a solenoid valve and is in the automatic mode, the customer air supply valve is open, the solenoid equalizing valve is closed and the *HAND/AUTO* transfer handle is in *AUTO*. When the application calls for manual operation:

1. Turn the *HAND/AUTO* transfer handle to *HAND*.
2. Open the solenoid equalizing valve.

3. Close the customer-installed air supply shutoff valve.

**NOTE:** The *HAND/AUTO* transfer handle may not engage immediately with the clutch mechanism. Turn the hand operator ratchet handle in either direction until the clutch mechanism snaps into place.

4. Move the actuator to the desired position by means of the hand operator ratchet handle.

**NOTE:** The manual operating mechanism is self-locking and holds any position to which it is set.

---

***Solenoid-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation***

**NOTE:** Refer to Figure 5-3.

When a Type UP5 or UP6 actuator is supplied with a solenoid valve and is in the manual mode, the customer air supply valve is closed, the solenoid equalizing valve is open and the *HAND/AUTO* transfer handle is in *HAND*. When the application calls for automatic operation:

1. Manually position the actuator to the extreme end of travel corresponding to solenoid demand.
2. Close the solenoid equalizing valve.
3. Slowly open the customer air supply shutoff valve.
4. Turn the *HAND/AUTO* transfer handle to *AUTO*.

After completing the transfer, the actuator moves automatically.

---

***Remote Reset Air Failure Lock Equipped Types UP5 and UP6 Actuators – Transfer from Automatic to Manual Operation***

**NOTE:** Refer to Figure 5-3.

If the customer air supply fails, the actuator may be put into manual operation. It may also be desired to switch to manual operation even if the customer air supply has not failed.

1. Open the air failure lock equalizing valve.

2. Follow the instructions under ***Positioner-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation*** or ***Solenoid-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Automatic to Manual Operation***.

---

### ***Remote Reset Air Failure Lock Equipped Types UP5 and UP6 Actuators – Transfer from Manual to Automatic Operation***

**NOTE:** Refer to Figure 5-3.

If the actuator is in the manual mode and it is desired to switch to automatic operation, the customer air supply must be operational.

1. Press the remote release pushbutton to release the air failure lock.
2. Close the air failure lock equalizing valve.
3. Follow the instructions under ***Positioner-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation*** or ***Solenoid-Equipped Types UP5 and UP6 Actuators without Air Failure Lock – Transfer from Manual to Automatic Operation***.

---

## SECTION 6 - TROUBLESHOOTING

---

### INTRODUCTION

If an obvious fault occurs, check the supply pressure, input and output connections, gage connections, and mechanical linkage adjustments before removing the system from service.

#### WARNING

**Disconnect the supply signal source or remove the equipment from the process before servicing. Failure to do so can cause unexpected movement posing a risk of bodily injury.**

**Do not operate this equipment unless the covers are in place. The covers prevent access to moving components that pose a risk of entanglement of body parts.**

#### AVERTISSEMENT

**Débranchez le signal ou retirez l'équipement du processus avant de procéder à l'entretien. Toute négligence à cet égard risque de donner lieu à des mouvements inattendus pouvant provoquer des blessures.**

**Ne faites fonctionner cet équipement que si les couvercles sont en place. Les couvercles empêchent l'accès à des composantes en mouvement qui présentent un risque d'emmêlement des membres.**

---

### PROBLEM DETERMINATION AND VERIFICATION PROCEDURE

If a fault occurs with the actuator, refer to Table 6-1 and correct any problems that occur with the actuator, positioner or associated components.

Table 6-1. Fault Correction Chart

Fault	Probable Cause	Corrective Action
Final actuation element at one end of stroke and does not respond to change.	Air lines in wrong ports.	Reverse lines connected to positioner O1 and O2 ports.
	Reversed positioner cam rotation.	Install proper positioner cam. Refer to the appropriate positioner instruction.
	I/P not functioning. <sup>1</sup>	Monitor the I/P at the I port on the positioner manifold. If output changes from 21 to 103 kPa (3 to 15 psig) with input change of 4 to 20 mA, the I/P is working. If not, replace I/P as outlined in the appropriate positioner instruction.

## TROUBLESHOOTING

Table 6-1. Fault Correction Chart (continued)

Fault	Probable Cause	Corrective Action
Excessive air consumption (exhaust loud).	Leakage at joints of manifold assembly of positioner.	Remove positioner manifold and check O-rings.
	Positioner pilot valve leaking excessively or stuck in place.	Remove pilot valve body. Refer to the appropriate positioner instruction.
	Check for continuity of solenoid coils.	Replace solenoid coils or entire solenoid.
Oscillation of final actuation element.	Gain too high.	Change gain hinge spring to greater thickness. Refer to the appropriate positioner instruction.
	Drive arm not securely attached to final actuation element.	Tighten or correct linkage as necessary.
Slow response.	Positioner pilot valve blocked.	Remove and clean pilot valve. Refer to the appropriate positioner instruction.
	Leaky seals in rotary vane or cylinder.	Replace seals.
	Supply input drops when actuator moves.	Monitor supply input pressure. Correct if necessary.
Final actuation element at either travel stop and will not respond to input change.	Air lines in wrong ports.	Check air line connections.
	Incorrect cam installed for application.	Determine application (direct or reverse acting) and check cam.
	Signal diaphragm leaking.	Replace diaphragm. Refer to the appropriate positioner instruction.
	No output from I/P assembly.	Verify air supply to the I/P as $138 \pm 10$ kPa ( $20 \pm 1.5$ psig). If input is correct replace the I/P assembly as outlined in the appropriate positioner instruction. If not, check the regulator and replace if necessary.
Uprange zero shift that cannot be adjusted.	Signal diaphragm leakage.	Check and replace if necessary. Refer to appropriate positioner instruction.
	No output from I/P assembly.	Verify air supply to the I/P as $138 \pm 10$ kPa ( $20 \pm 1.5$ psig). If input is correct, replace the I/P assembly as outlined in the appropriate positioner instruction. If not, check the regulator and replace if necessary.
Full range cannot be obtained with adjustment.	Signal diaphragm leaking.	Check and replace if necessary. Refer to the appropriate positioner instruction.
Actuator will not operate below freezing.	Trapped moisture frozen in air lines.	If supplied with heaters, check for continuity across heater or thermoswitch leads. If defective, refer to <a href="#">Section 8</a> . If not supplied with heaters, check instrument air drying equipment.
Pneumatic shaft position transmitter will not operate.	Pneumatic transmitter defective.	Repair or replace transmitter. Refer to <a href="#">Section 8</a> .
Electric shaft position transmitter will not operate	Transmitter board assembly defective.	Replace transmitter board assembly. Refer to <a href="#">Section 8</a> .
	Feedback potentiometer defective.	Check potentiometer resistance. If open, replace feedback potentiometer. Refer to <a href="#">Section 8</a> . If not defective, check transmitter board.

*Table 6-1. Fault Correction Chart (continued)*

<b>Fault</b>	<b>Probable Cause</b>	<b>Corrective Action</b>
Alarm/travel switch unit will not operate.	Loose microswitch cam.	Tighten cam.
	Microswitches defective.	Replace microswitches. Refer to <b>Section 8</b> .
Air failure lock will not operate.	Trip valve or lock valve improperly set.	Refer to <b>Section 4</b> and properly adjust the trip or lock valve.
	Trip valve or lock valve defective.	Replace trip valve or lock valves. Refer to <b>Section 8</b> .
	Latching spring return cylinder defective (Types UP1 and UP2 actuators only).	Replace latching spring return cylinder. Refer to <b>Section 8</b> .
Reserve air tank will not operate the actuator.	Trip valve defective.	Replace the trip valve. Refer to <b>Section 8</b> .
	Check valve to air tank defective.	Replace the check valve. Refer to <b>Section 8</b> .
	Air lines from reserve air tank to actuator are plugged or leaking.	Clean or replace air lines from the air tank to the actuator.

**NOTE:**

1. Types AV2 and AV3 positioners only.

---

## SECTION 7 - MAINTENANCE

---

### INTRODUCTION

This section contains maintenance procedures to be performed on a scheduled and as needed basis.

**WARNING**

Stay clear of moving components when performing procedures that require the equipment to be energized. The equipment can operate automatically. There is a risk of entanglement of body parts when performing these procedures.

**AVERTISSEMENT**

Restez à l'écart des composantes en mouvement lorsque vous effectuez des procédures nécessitant que l'équipement soit sous tension. L'équipement peut se déplacer de façon automatique. Ces procédures présentent un risque d'emmêlement des membres.

---

### PERIODIC MAINTENANCE

**WARNING**

Disconnect the supply signal source or remove the equipment from the process before servicing. Failure to do so can cause unexpected movement posing a risk of bodily injury.

**AVERTISSEMENT**

Débranchez le signal ou retirez l'équipement du processus avant de procéder à l'entretien. Toute négligence à cet égard risque de donner lieu à des mouvements inattendus pouvant provoquer des blessures.

**CAUTION**

If the connections require tightening, do not exceed the maximum torque of 6.8 Nm (60 in.-lbs) for 1/4-18 NPT connections, or 3.4 Nm (30 in.-lbs) for 1/8-27 NPT connections. Do not use teflon tape to seal threaded fittings. Use only liquid or paste pipe sealant. Use of Loctite® sealants, which are polyacrylate or acrylic diesters based, is not recommended. Water based Loctite sealant, such as Vibra Seal No. 503, is acceptable.

**ATTENTION**

Si les connecteurs exigent us serrage, ne pas dépasser le couple maximal de 6.8 Nm (60 pouces-livres) pour filetage 1/4-18 NPT ou 3.4 Nm (30 pouces-livres) pour filetage 1/8-27 NPT. Ne pas employer du ruban de teflon pour sceller les raccords filetés. Employer seulement un scelle-joint liquide ou en pâte pour tuyauterie. L'emploi de scelle-joint Loctite à base de polyacrylique ou d'acrylique n'est pas recommandé. Le scelle-joint Loctite base d'eau, tel que Vibra-Seal No. 503 est acceptable.

1. Check all air connections for leakage. While under pressure, pour soapsuds solution on the connections. If the solution bubbles, tighten the connections.
2. Check the linkage for mechanical wear or binding. Lubricate as often as required as determined by equipment use (refer to **Connecting Linkage for Universal Rotary Actuators**).
3. Periodically check for loose bolts. If needed, torque the bolts to the required specifications. Refer to the drawings in **Appendix B** for torque specifications.
4. Maintain a clean air supply (free of dirt, oil and moisture) to insure sound operation of the positioner.
5. If the supply line has the suggested filter, remove and clean it if needed. Refer to **Air Quality** in **Section 3**.
6. Whenever the positioner is out of service (or when needed), perform the maintenance procedures outlined in the maintenance section of the appropriate positioner instruction.

---

### ANNUAL OR SEMIANNUAL MAINTENANCE

1. Check the adjustment and calibration of the positioner and the final actuator element. The procedure is outlined in the calibration section of the appropriate positioner instruction.
2. Verify that the reserve air tank option can drive the cylinder or rotary vane to the end of its stroke. Drain moisture from air tank if required, through a drain provided in the bottom of the tank.
3. Check the adjustment of the air failure brake as described in **Air Failure Lock Calibration** in **Section 4**.
4. Every six months, apply a streak of dry, graphite-based lubricant to the Types UP5 and UP6 actuator shaft bearings, roller chain and air cylinder. Remove the rear panel and side covers to see the grease fittings and chain.
5. On Types UP5 and UP6 actuators, check the roller chain for undue slack. Do not let slack exceed ½-inch on either side (one inch total). Refer to **ROLLER CHAIN ADJUSTMENT (TYPES UP5 AND UP6 ACTUATORS)** in **Section 8**.
6. Once a year (or when needed), apply dry, graphite-based lubricant to the drag pins of the Types UP5 and UP6 actuator clutch assembly.

7. Check the clutch for undue wear. Refer to **CLUTCH FORK INSPECTION AND REPLACEMENT (TYPES UP5 AND UP6 ACTUATORS)** in Section 8 for the procedure.

**NOTE:** Inspect the clutch yearly for an actuator exposed to normal use, and more often if exposed to harsh conditions.

8. Check that the positioner integral shutoff and equalizing valve moves easily. If not, refer to the appropriate positioner instruction for cleaning procedures.

9. Lubricate the grease fittings on the cylinders for Types UP4 through UP6 actuators until the grease comes out the relief. See Figures 8-3 through 8-5 for the location of these fittings. For Type UP3 actuators, lubricate the inside diameter of the bushing as shown in Figure 8-2.

**MAINTENANCE AS REQUIRED**

<b>WARNING</b>	<p>Use solvents only in well-ventilated areas. Avoid prolonged or repeated breathing of vapors. Avoid prolonged or repeated contact with the skin. Solvents can cause nausea, dizziness and skin irritation. In some cases, overexposure to solvents has caused nerve and brain damage. Solvents are flammable – do not use near extreme heat or open flame.</p>
<b>AVERTISSEMENT</b>	<p>N'utilisez des solvants que dans des zones bien aérées. Evitez de respirer les vapeurs de façon prolongée ou répétée. Evitez les contacts prolongés ou répétés avec la peau. Les solvants peuvent provoquer des nausées, des étourdissements et l'irritation cutanée. Dans certains cas, une surexposition aux solvants provoque des dommages au système nerveux ou au cerveau. Les solvants sont inflammables – il ne faut pas les utiliser près d'une source de chaleur ou d'une flamme ouverte.</p>

1. Completely disassemble and clean the positioner. Refer to the appropriate positioner instruction for cleaning procedures.

2. Completely disassemble and clean the actuator as described in Section 8.

3. Unless detecting excessive leakage, do not service the air cylinder or rotary vane. If needed, refer to **ROTARY VANE SEAL REPAIR AND HOUSING CLEANING** or **CYLINDER ASSEMBLY REPAIR AND CLEANING** in Section 8.

---

## SECTION 8 - REPAIR AND REPLACEMENT PROCEDURES

---

### INTRODUCTION

Occasionally, the actuator may need to have components replaced. Use these procedures if a fault is found as determined by the methods described in the troubleshooting section.

**WARNING**

Disconnect the supply signal source or remove the equipment from the process before servicing. Failure to do so can cause unexpected movement posing a risk of bodily injury.

**AVERTISSEMENT**

Débranchez le signal ou retirez l'équipement du processus avant de procéder à l'entretien. Toute négligence à cet égard risque de donner lieu à des mouvements inattendus pouvant provoquer des blessures.

**CAUTION**

If the connections require tightening, do not exceed the maximum torque of 6.8 Nm (60.0 in.-lbs) for 1/4-18 NPT connections, or 3.4 Nm (30.0 in.-lbs) for 1/8-27 NPT connections. Do not use teflon tape to seal threaded fittings. Use only liquid or paste pipe sealant. Use of Loctite sealants, which are polyacrylate or acrylic diesters based, is not recommended. Water based Loctite sealant, such as Vibra-Seal No. 503, is acceptable.

**ATTENTION**

Si les connecteurs exigent us serrage, ne pas dépasser le couple maximal de 6.8 Nm (60.0 pouces-livres) pour filetage 1/4-18 NPT ou 3.4 Nm (30.0 pouces-livres) pour filetage 1/8-27 NPT. Ne pas employer du ruban de teflon pour sceller les raccords filetés. Employer seulement un scelle-joint liquide ou en pâte pour tuyauterie. L'emploi de scelle-joint Loctite à base de polyacrylique ou d'acrylique n'est pas recommandé. Le scelle-joint Loctite base d'eau, tel que Vibra-Seal No. 503 est acceptable.

### ENCLOSURE REMOVAL

---

**WARNING**

Do not operate this equipment unless the covers are in place. The covers prevent access to moving components that pose a risk of entanglement of body parts.

**AVERTISSEMENT**

Ne faites fonctionner cet équipement que si les couvercles sont en place. Les couvercles empêchent l'accès à des composants en mouvement qui présentent un risque d'emmêlement des membres.

Refer to the proper enclosure removal procedure in [Section 3](#) to access the components referred to in this section.

### POSITIONER REMOVAL AND REPLACEMENT

---

**NOTE:** Refer to the applicable parts drawings in [Appendix A](#).

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Place the positioner integral shutoff and equalizing valve in the manual position to shut off the air supply to the positioner.
3. Allow the air pressure to subside completely.
4. Remove the covers (if necessary) to access the positioner.
5. For Type AV1 positioners, disconnect and label the O1, O2, signal and supply lines from the positioner.
6. For Types AV2, AV3 and AV4 positioners, disconnect and label the O1, O2 and supply line from the positioner, remove the cover and disconnect and label the two wires from the input terminal block.
7. For Types UP1 and UP2 actuators, perform [Step 7a](#). For Types UP3 through UP6 actuators, perform [Steps 7b](#) and [7c](#).
  - a. Remove the three ¼-inch fasteners that hold the positioner to the actuator.
  - b. Remove the linkage from the positioner.
  - c. Remove the mounting screws securing the positioner to its mounting bracket.
8. Remove the positioner.
9. To repair the positioner, refer to the appropriate positioner instruction.

10. Reverse the procedure to install the positioner. Use the torque values specified in the drawings in [Appendix A](#) to tighten all fasteners when assembling.

---

### **SOLENOID VALVE REMOVAL AND REPLACEMENT**

**NOTE:** Refer to the applicable parts drawings in [Appendix A](#).

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the solenoid equalizing valve to shut off the air supply.
3. Allow the air pressure to subside completely.
4. Remove the covers (if necessary) to access the solenoid valve.
5. For Types UP1 and UP2 actuators, perform Step [5a](#). For Types UP3 through UP6 actuators, perform Step [5b](#).
  - a. Disconnect and label the solenoid valve leads from the solenoid valve.
  - b. Disconnect and label the solenoid valve leads from the terminal strip inside the actuator (refer to Figures [3-3](#) and [3-4](#)).
6. Disconnect and label the supply air line from port P and the outlet air lines from ports A and B.
7. Remove the screws holding the solenoid valve to the mounting bracket.
8. Remove the solenoid valve.
9. Reverse the procedure to install the new solenoid valve.

---

### **ROTARY VANE REMOVAL AND REPLACEMENT (TYPES UP1 AND UP2 ACTUATORS)**

**NOTE:** Refer to Figure [8-1](#).

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air pressure to subside completely.
4. Remove the covers (if necessary) to access the rotary vane.
5. Disconnect and label the two air lines from the rotary vane at the connecting elbows.




Figure 8-1. Rotary Vane Removal and Seal Replacement

6. Feed the lines through the actuator frame.
7. Refer to **POSITIONER REMOVAL AND REPLACEMENT** or **SOLENOID VALVE REMOVAL AND REPLACEMENT** and remove the positioner or solenoid valve.
8. Loosen the cap screw holding the hand and actuator linkage lever to the actuator shaft.
9. Remove the hand and actuator linkage lever.
10. Remove the cap screws holding the brake arm to the bottom of the actuator shaft.
11. Remove the bolt securing the top of the brake arm to the mounting plate.

12. Remove the brake arm.
13. Loosen the three large bolts holding the mounting plate to the actuator frame.
14. Loosen the two smaller bolts securing the mounting plate to the actuator frame.
15. Loosen the cap screw holding the mounting plate to the actuator frame.
16. Remove the mounting plate.
17. Remove the five bolts holding the actuator shaft cover plate in place.
18. Remove the actuator shaft cover plate.
19. Remove the three large bolts holding the actuator to the actuator frame.
20. Lift the actuator out of the actuator frame.
21. Reverse this procedure to install the rotary vane.

---

### ROTARY VANE SEAL REPAIR AND HOUSING CLEANING

<b>WARNING</b>	<p>Use solvents only in well ventilated areas. Avoid prolonged or repeated breathing of vapors or contact with skin. Solvents can cause nausea, dizziness and skin irritation. In some cases, overexposure to solvents has caused nerve and brain damage. Solvents are flammable - do not use near extreme heat or open flame.</p>
<b>AVERTISSEMENT</b>	<p>N'utilisez des solvants que dans des zones bien aérées. Evitez de respirer les vapeurs de façon prolongée ou répétée. Evitez les contacts prolongés ou répétés avec la peau. Les solvants peuvent provoquer des nausées, des étourdissements et l'irritation cutanée. Dans certains cas, une surexposition aux solvants provoque des dommages au système nerveux ou au cerveau. Les solvants sont inflammables - il ne faut pas les utiliser près d'une source de chaleur ou d'une flamme ouverte.</p>

**NOTE:** Refer to Figure 8-1.

1. Refer to **ROTARY VANE REMOVAL AND REPLACEMENT (TYPES UP1 AND UP2 ACTUATORS)** and remove the rotary vane from the actuator frame.

## REPAIR AND REPLACEMENT PROCEDURES

---

2. Remove the screws holding the housing together.
3. Separate the covers and remove the paddle.
4. Clean the inside surface of the rotary vane housing with a suitable grease solvent.
5. Remove the sealant on the joining surfaces of the housing with lacquer thinner.
6. Lubricate the internal surfaces with lubricant, Part No. 199354\_1 (No. 55M Dow Corning® Grease).
7. Replace the large O-ring on the paddle assembly.
8. Replace the seal rings on each side of the paddle shaft.
9. Lubricate the O-ring and seal rings with lubricant, Part No. 199354\_1.
10. Place the paddle in the housing.
11. Coat the housing joining surfaces with sealant Part No. 199926\_1 (GE® Silmate® RTV 1473 Sealant).
12. Replace the housing.
13. With the paddle turned to the right side, snug down the bolts on the left side.
14. Rotate the paddle to the left side of the rotary vane and snug down the screws on the right side.
15. Tighten all screws and bolts securely.
16. Rotate the shaft several times through a full 90 degree rotation to remove any excess sealant inside the housing.

**NOTE:** Do not place the rotary vane in service for at least four hours to allow the sealant to set up completely.

17. Refer to **ROTARY VANE REMOVAL AND REPLACEMENT (TYPES UP1 AND UP2 ACTUATORS)** to install the rotary vane in the actuator housing.

### **CYLINDER ASSEMBLY REPLACEMENT (TYPES UP3/4/5/6 ACTUATORS)**

**NOTE:** Refer to the drawings in [Appendix A](#).

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air pressure to subside completely.
4. Remove the covers necessary to access the cylinder assembly.
5. Disconnect and label the air lines from the top and bottom of the cylinder.
6. Remove the pin assembled through the piston rod end and the crank arm assembly.
7. Remove the pin attaching the cylinder to the actuator stand.
8. Lift the assembly out of the stand.
9. Reverse this procedure to install the cylinder assembly.

---

### **CYLINDER ASSEMBLY REPAIR AND CLEANING**

**NOTE:** Refer to Tables [8-1](#) through [8-4](#) and Figures [8-3](#) through [8-5](#).

1. Refer to **CYLINDER ASSEMBLY REPLACEMENT (TYPES UP3/4/5/6 ACTUATORS)** and remove the cylinder from the actuator frame.
2. Remove the hex full nuts (on Type UP3 actuators), or retaining rings (on Types UP4 through UP6 actuators).
3. Remove the bottom end flange.
4. To remove the piston assembly, rod and top flange, pull the piston out of the cylinder.
5. Remove the retaining ring from the top flange assembly.
6. Extract the bushing.
7. Remove the O-rings from the end flanges.
8. Remove the rod seals from the bushing.
9. Remove the rod wiper from the bushing.
10. Inspect the O-rings for signs of wear and replace them if necessary.

## REPAIR AND REPLACEMENT PROCEDURES

Table 8-1. Parts List for Type UP3 Actuator Cylinder Assembly (Part Number 5328775°1)<sup>1</sup>

Item	Qty	Part No.	Description	Item	Qty	Part No.	Description
1	1	5327215_1	Bottom flange	12	1	1951416_218	O-ring
2	2	1951416_256	O-ring	13	1	5327205_1	Bushing
3	1	5328773_1	Piston	14	1	197164_150	Retaining ring
4	2	5328772_1	Back-up plate	15	1	1951401_1	Wiper ring
5	2	5328776_1	Spacer	16	1	5328778_1	Piston rod
6	1	195825_15	O-ring	17	1	199355_1	Lube label not shown
7	1	5328777_1	Spacer	18	1	197120_22	Elastic stop nut
8	8	19781_6	Stud	19	16	0.375-16	Hex full nut
9	1	53406ac1	Cylinder body	21	2	1/8"-27	Plastic pipe plug
10	1	1951399_214	O-ring	22	4	1/8"-27	Steel Hex head pipe plug
11	1	5327214_1	Upper flange	23	A/R	199354_1	Lube not shown

**NOTE:**

1. Order cylinder spare parts kit by Part No. 258240°1. Refer to [Appendix A](#) for parts list.




Figure 8-2. Cylinder Assembly for Type UP3 Actuators (Part Number 5328775°1)

Table 8-2. Parts List for Type UP4 Actuator Cylinder Assembly (Part Number 5328769°1)<sup>1</sup>

Item	Qty	Part No.	Description	Item	Qty	Part No.	Description
1	2	5311428_41	O-ring	10	1	5316536_1	Stop spacer
2	2	197736_1	Retaining ring	11	1	5328695_1	Top flange assembly
3	2	5328697_1	Ring lock	12	1	5328692_1	Piston rod
4	1	5328671_1	Bottom flange	13	1	5319921_1	Cylinder body
5	1	197132_7	Locknut	14	2	195148_1	Pipe plug
6	2	5328744_1	Back-up plate	15	4	NIDAC16005	Pan head sems
7	1	5328743_1	Spacer	16	1	NLHAC38000	Hex Jam Nut
8	1	195825_9	O-ring	17	2	—	¼ pipe thread protector
9	1	5328768_1	Piston	18	A/R	199354_1	Lube not shown

**NOTE:**

1. Order cylinder spare parts kit by Part No. 258241°1. Refer to [Appendix A](#) for parts list.




Figure 8-3. Cylinder Assembly for Type UP4 Actuators (Part Number 5328769°1)

## REPAIR AND REPLACEMENT PROCEDURES

Table 8-3. Parts List for Type UP5 Actuator Cylinder Assembly (Part Number 5328952°1)<sup>1</sup>

Item	Qty	Part No.	Description	Item	Qty	Part No.	Description
1	2	5311428_41	O-ring	10	1	5316536_1	Stop spacer
2	2	197736_1	Retaining ring	11	1	5328695_1	Top flange assembly
3	2	5328697_1	Ring lock	12	1	5328943_2	Piston rod
4	1	5328951_1	Bottom flange	13	1	5319921_2	Cylinder body
5	1	197132_7	Locknut	14	3	195148_2	Pipe plug
6	2	5328744_1	Back-up plate	15	4	NIDAC16005	Pan head sems
7	1	5328743_1	Spacer	16	1	NLHAC38000	Hex jam nut
8	1	195825_9	O-ring	17	A/R	199354_1	Lube not shown
9	1	5328768_1	Piston				

**NOTE:**

1. Order cylinder spare parts kit by Part No. 258241°1. Refer to [Appendix A](#) for parts list.




Figure 8-4. Cylinder Assembly for Type UP5 Actuators (Part Number 5328952°1)

Table 8-4. Parts List for Type UP6 Actuator  
Cylinder Assembly (Part Number 5328945°1)<sup>1</sup>

Item	Qty	Part No.	Description	Item	Qty	Part No.	Description
1	2	5328697_1	Ring lock	9	1	5328743_1	Spacer
2	1	197132_7	Locknut	10	1	195825_9	O-ring
3	1	5328944_1	Bottom flange	11	1	5328946_1	Top flange assembly
4	2	197737_1	Retaining ring	12	1	5328943_1	Piston rod
5	2	5311428_39	O-ring	13	2	1951421_2	Pipe plug
6	2	5328942_1	Back-up plate	14	4	0.190-32	Pan head sems ext
7	1	5317659_1	Cylinder body	15	1	1.000-14	Hex pull nut
8	1	5328941_1	Piston	16	A/R	199354_1	Lube not shown

**NOTE:**

1. Order cylinder spare parts kit by Part No. 258242°1. Refer to [Appendix A](#) for parts list.




Figure 8-5. Cylinder Assembly for UP6  
Actuators (Part Number 5328945°1)

11. Inspect the piston seal for signs of wear and replace if necessary.
12. Clean the cylinder and the empty O-ring grooves with a suitable grease solvent.

**WARNING**

**Use solvents only in well ventilated areas. Avoid prolonged or repeated breathing of vapors or contact with skin. Solvents can cause nausea, dizziness and skin irritation. In some cases, overexposure to solvents has caused nerve and brain damage. Solvents are flammable - do not use near extreme heat or open flame.**


**AVERTISSEMENT**

**N'utilisez des solvants que dans des zones bien aérées. Evitez de respirer les vapeurs de façon prolongée ou répétée. Evitez les contacts prolongés ou répétés avec la peau. Les solvants peuvent provoquer des nausées, des étourdissements et l'irritation cutanée. Dans certains cas, une surexposition aux solvants provoque des dommages au système nerveux ou au cerveau. Les solvants sont inflammables - il ne faut pas les utiliser près d'une source de chaleur ou d'une flamme ouverte.**

13. Lubricate the piston seal and O-rings with lubricant. Part No. 199354\_1 (No. 55M Dow Corning Grease).
14. Place the piston seal and O-rings into the piston rod, end flanges and bushing.
15. Inspect the insides of the cylinder, piston rod and upper flange for signs of scoring or wear.
16. Replace the scored or worn parts, as they might damage the seals.
17. Lubricate the inside of the cylinder, upper flange and bushing with lubricant, Part No. 199354°1.
18. Paying added attention not to damage the O-rings, reassemble the cylinder assembly.
19. This step applies only to Type UP3 actuators. Tighten the hex full nuts to 8.1 Nm (72 in.-lbs).
20. This step applies only to Types UP4 through UP6 actuators. Install the retaining rings and the bottom end flange.
21. Check the assembly for leaks using soapsuds solution by applying 345 to 690 kPa (50 to 100 psi).
22. Refer to **CYLINDER ASSEMBLY REPLACEMENT (TYPES UP3/4/5/6 ACTUATORS)** to install the cylinder assembly.

**CLUTCH FORK INSPECTION AND REPLACEMENT (TYPES UP5 AND UP6 ACTUATORS)**

**NOTE:** Refer to Figure 8-6.



*Figure 8-6. Clutch and Clutch Fork Assembly*

The clutch assembly disengages the gear from the output shaft during manual operation. The clutch has two drag pins, subject to wear. Excessive wear causes the clutch to approach the stop, resulting in engagement of the manual operator gears. This engagement prevents normal automatic operation of the control drive, i.e., it locks in place.

Lubricating extends the life of the drag pins. Lubricate the pins, and the plate they bear upon, with dry graphite-based lubricant. Inspect the clutch assembly once a year for a drive subject to normal operation or more often to one exposed to harsh conditions.

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers to allow access to the clutch fork assembly.
5. Place the clutch assembly in the lock position.
6. Measure the distance between the clutch and stop with feeler gages, or equivalent.

## REPAIR AND REPLACEMENT PROCEDURES

---

7. If the gage shows less than 1.0 mm (0.04 in.), remove the clutch fork assembly and measure the drag pins directly. Refer to Figure 8-6 for proper inspection of the clutch clearance and the drag pins.
8. Remove the push on rings at each end of the clevis pin at the top of the clutch fork assembly.
9. Remove the clevis pin.
10. Remove the retaining rings at each end of the fork pivot shaft at the bottom of the clutch fork assembly.
11. Remove the fork pivot shaft.
12. Remove the clutch fork assembly.
13. Normally, a drag pin measures 7.9 mm (0.31 in.) in diameter. If the diameter measures less than 6.4 mm (0.25 in.), replace the clutch fork assembly. The diameter is represented as x in Figure 8-6 and must be between 6.4 and 7.9 mm (0.25 and 0.31 in.) to pass the inspection.
14. If the drag pins pass the inspection, lubricate them with Plastilube NLG-1, Grade 1.
15. Reverse Steps 12 through 8 to install the new clutch fork assembly.

---

### ROLLER CHAIN ADJUSTMENT (TYPES UP5 AND UP6 ACTUATORS)

**NOTE:** Refer to Figure 8-7.

#### WARNING

**Turn off the air supply and allow the pressure to bleed off completely before adjusting the chain. Do not attempt to connect or disconnect the chain. Due to the risk of entanglement of body parts, ABB recommends that replacement of the chain be done only by ABB personnel.**

#### AVERTISSEMENT


**Interrompez le débit d'air et assurez-vous qu'il n'y a plus aucune pression avant d'ajuster la chaîne. Ne tentez pas de fixer ou de retirer la chaîne. Compte tenu des risques d'emmêlement des membres, nous recommandons que seul un employé de ABB procède au remplacement de la chaîne conformément aux directives du fabricant.**

The Types UP5 and UP6 actuators come with the roller chain adjusted for proper operation in the manual mode. Should the slack in the chain ever exceed ½-inch movement on either side (one inch total), the chain needs adjusting.

1. Secure the driven load to prevent sudden movement of the actuator.

---

### ROLLER CHAIN ADJUSTMENT (TYPES UP5 AND UP6 ACTUATORS)



*Figure 8-7. Roller Chain Adjustment for Types UP5 and UP6 Actuators*

2. Place the actuator in the manual mode to prevent the load from shifting.
  3. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
  4. Allow the air supply to subside completely.
  5. Remove the covers to allow access to the roller chain assembly.
  6. Loosen the setscrew in the chain anchor.
  7. Turn the socket hex head cap screw clockwise to remove undue chain slack (tighten chain).
- NOTE:** The suggested chain slack is between  $\frac{1}{4}$ -inch and  $\frac{1}{2}$ -inch per side ( $\frac{1}{2}$ -inch to one inch total).
8. After removing undue slack, tighten the setscrew in the chain anchor. Replace the actuator cover.
  9. Restore the air supply to the actuator.

---

### OPTIONAL EQUIPMENT REPAIR/REPLACEMENT PROCEDURES

**NOTE:** Refer to the drawings in [Appendix A](#) for part numbers and locations of optional equipment.

## REPAIR AND REPLACEMENT PROCEDURES

---

### ***Reserve Air Tank Component Removal and Replacement (Types UP2 through UP6 Actuators)***

The Types UP2 through UP6 actuators have trip valves and pressure switch. Use these procedures if it is necessary to remove any of the reserve air tank kit components.

---

#### ***TRIP VALVE REMOVAL AND REPLACEMENT***

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers necessary to allow access to the trip valve (Types UP3 through UP6 actuators only).
5. Label and disconnect the air lines attached to the trip valve.
6. Remove the bolts holding the trip valve to the mounting bracket.
7. Remove the trip valve.
8. Reverse this procedure to install the new trip valve.

---

#### ***PRESSURE SWITCH REMOVAL AND REPLACEMENT***

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers necessary to allow access to the pressure switch.
5. Label and disconnect the air lines attached to the pressure switch.
6. Remove the pressure switch assembly from the mounting plate.
7. Remove the cover plate from the pressure switch housing.

8. Disconnect the red (normally open), black (common), and blue (normally closed) wires from the microswitch in the pressure switch housing.
9. Reverse this procedure to install the new pressure switch.

---

### ***Air Failure Lock Component Removal and Replacement (Types UP1 and UP2 Actuators)***

Use these procedures if it is necessary to remove or replace any of the air failure lock components on Types UP1 and UP2 actuators.

---

### ***TRIP VALVE REPLACEMENT***

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers (if necessary) to access the trip valve.
5. Remove and label the air lines from the trip valve.
6. Remove the two screws securing the trip valve to the mounting bracket.
7. Remove the trip valve.
8. Reverse the procedure to install the new trip valve.

---

### ***LATCHING SPRING RETURN CYLINDER REPLACEMENT***

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers (if necessary) to access the latching spring return cylinder.
5. Remove the air line from the latching spring return cylinder.
6. Loosen the 0.500-20 hex jam nut holding the piston to the adapter (Type UP1 actuator) or clevis arm (Type UP2 actuator).

## REPAIR AND REPLACEMENT PROCEDURES

---

7. For Type UP1 actuators, perform Step **7a**. For Type UP2 actuators, perform Step **7b**.
  - a. Remove the clevis pin and retaining ring holding the base of the latching spring return cylinder to the mounting yoke.
  - b. Remove the retaining ring holding the base of the latching spring return cylinder to the support stud.
8. Remove the latching spring return cylinder.
9. Reverse the procedure to install the new latching spring return cylinder.

---

### ***AUTOMATIC MECHANICALLY ACTUATED EQUALIZING VALVE REPLACEMENT***

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers (if necessary) to access the automatic mechanically actuated equalizing valve.
5. Remove and label the air lines from ports 1 and 4 of the automatic mechanically actuated equalizing valve.
6. Remove the nut and washer holding the automatic mechanically actuated equalizing valve to the mounting bracket.
7. Remove the automatic mechanically actuated equalizing valve.
8. To install the new automatic mechanically actuated equalizing valve, reverse the procedure.

**NOTE:** Be sure the plug is installed in port 2 of the new automatic mechanically actuated equalizing valve.

---

### ***Air Failure Lock Component Removal and Replacement (Types UP3 through UP6 Actuators)***

The Types UP3 and UP4 actuators have a trip valve and a lock valve. Types UP5 and UP6 actuators have a trip valve and two lock valves. Use these procedures if it is necessary to remove any of the air failure lock components on Types UP3 through UP6 actuators.

---

### ***LOCK VALVES REMOVAL AND REPLACEMENT***

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers necessary to allow access to the lock valves.
5. Label and disconnect the air lines attached to the lock valves.
6. Remove the bolts that hold the lock valves to the mounting bracket.
7. Remove the lock valves.
8. Reverse this procedure to install the new lock valves.

---

### ***TRIP VALVE REMOVAL AND REPLACEMENT***

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers necessary to allow access to the trip valve.
5. Label and remove the air lines attached to the trip valve.
6. Remove the bolts holding the trip valve to the mounting bracket.
7. Remove the trip valve.
8. Reverse this procedure to install the new trip valve.

---

### ***PRESSURE SWITCH REMOVAL AND REPLACEMENT***

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers necessary to allow access to the pressure switch.

## REPAIR AND REPLACEMENT PROCEDURES

---

5. Label and remove the air lines attached to the pressure switch.
6. Remove the pressure switch assembly from the lock and trip valve mounting plate.
7. Remove the cover plate from the pressure switch housing.
8. Remove the red (normally open), black (common), and blue (normally closed) wires from the microswitch in the pressure switch housing.
9. Reverse this procedure to install the new pressure switch.

---

### ***Electric Shaft Position Transmitter Assembly Removal and Replacement***

**NOTE:** Refer to Figures 3-19, 3-22 and the drawings in [Appendix A](#).

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers necessary to allow access to the electric shaft position transmitter.
5. This step applies only to Types UP3 and UP4 actuators. If the actuator has the air failure lock option, remove it by:
  - a. Removing the mounting screws holding the air failure lock assembly to the actuator mounting frame.
  - b. Removing the entire assembly, attached to its mounting bracket.
6. This step applies only to Types UP3 through UP6 actuators:
  - a. Remove the cotter pins that hold the cylinder to the lever.
  - b. Remove the dowel pin that holds the cylinder to the lever.
  - c. Place the dowel pin between the cylinder and the actuator frame to avoid damage to the supply line and its fitting.
7. Remove the cover from the top of the electric shaft position transmitter assembly.
8. Remove and label the two wires connected to TB5 (+) and TB5 (-).
9. Remove and label the wires from P1, P2 and P3.

10. Remove the three screws holding the electric shaft position transmitter assembly to its mounting bracket.
11. If defective, replace the electric shaft position transmitter assembly.
12. Adjust as described in **OPTIONAL EQUIPMENT CALIBRATION** in **Section 4**.
13. Reverse this procedure to put the unit back together.

---

### ***Feedback Potentiometer Removal and Replacement***

**NOTE:** Refer to Figures 3-19, 3-22 and the drawings in **Appendix A**.

1. Perform Steps 1 through 5 in **Electric Shaft Position Transmitter Assembly Removal and Replacement**.
2. Remove the pan head mounting screws (0.1875-32 x 0.250) holding the electric shaft position transmitter board assembly mounting bracket to the alarm unit mounting bracket.
3. Rotate the transmitter mounting bracket clockwise to expose the setscrews holding the feedback potentiometer to the coupler.
4. Slide the electric transmitter board assembly, with feedback potentiometer attached, out of the coupler.
5. Pull the assembly out of the actuator frame.
6. Remove the locknut holding the feedback potentiometer to the electric transmitter board assembly mounting bracket.
7. Disconnect and label the wire leads from P1, P2 and P3 on the electric transmitter board.
8. Install the new feedback potentiometer.
9. Reverse this procedure to assemble the unit – make sure to center the feedback potentiometer, with the actuator at the 50% position, before tightening the coupling setscrews.

---

### ***Alarm/Travel Switch Removal and Replacement***

**NOTE:** Refer to Figures 3-19, 3-22 and the drawings in **Appendix A**.

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.

## REPAIR AND REPLACEMENT PROCEDURES

---

4. Remove the covers necessary to allow access to the alarm/travel switches.
5. Remove the electric shaft position transmitter assembly and feedback potentiometer assembly, with its mounting bracket, from the alarm mounting bracket. Refer to *Electric Shaft Position Transmitter Assembly Removal and Replacement* and *Feedback Potentiometer Removal and Replacement*.
6. Locate the mounting bracket that is part of the actuator frame.
7. Remove the three mounting screws securing the alarm unit mounting bracket to the actuator frame mounting bracket.
8. Disconnect the linkage from the alarm unit mounting bracket.
9. Take the alarm unit assembly out of the actuator frame.
10. Remove the pan head screws (0.112-40 x 2.0) holding the microswitches to the alarm unit mounting bracket.
11. Remove the cover from terminal block TB3.
12. Disconnect the microswitch wiring from the terminal block.
13. Replace the microswitches.
14. Wire the microswitches according to the corresponding markings on the switches and the terminal block (NO=Normally Open, NC=Normally Closed, and C=Common).
15. With the spacer blocks arranged so that the switch rollers align with the cam, mount the microswitch assemblies to the alarm unit mounting bracket.
16. Adjust the microswitches as outlined in *Alarm/Travel Switch Calibration* in [Section 4](#).
17. Reverse this procedure to assemble the rest of the unit.

---

### ***Pneumatic Shaft Position Transmitter Replacement (Types UP2 through UP6 Actuators)***

**NOTES:**

1. The Pneumatic Shaft Position Transmitter is not available for Type UP1 actuators.
  2. Refer to the drawings in [Appendix A](#).
1. To prevent the load from shifting, place the actuator in the manual mode.
  2. Shut off the air supply to the pneumatic shaft position transmitter.
  3. Allow the air supply to subside completely.

4. Remove the covers (if necessary) to allow access to the pneumatic shaft position transmitter.
5. Disconnect the S supply line from the pneumatic shaft position transmitter.
6. Disconnect the O1 output line from the pneumatic shaft position transmitter.
7. Disconnect the linkage from the pneumatic shaft position transmitter.
8. Remove the mounting bolts.
9. Reverse this procedure to install the new pneumatic position shaft transmitter.

---

### ***Strip Heater Replacement (Types UP2 through UP6 Actuators)***

#### **NOTES:**

1. Strip heaters are not available for the Type UP1 actuator.
  2. Refer to the drawings in [Appendix A](#).
1. Place the actuator in the manual mode to prevent the load from shifting.
  2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
  3. Allow the air supply to subside completely.
  4. Remove the covers necessary to allow access to the strip heaters.
  5. Remove the mounting screws holding the heaters in place.
  6. Remove the mounting screws holding the harness to the actuator frame.
  7. Pull the heater assembly away from the actuator frame.
  8. Remove the cover from the heater terminal block.
  9. Disconnect the wiring harness.
  10. Install the new heaters.
  11. Reverse this procedure to put the unit back together.

### *Thermoswitch Replacement (Types UP2 through UP6 Actuators)*

**NOTES:**

1. Strip heaters are not available for the Type UP1 actuator.
  2. Refer to the drawings in [Appendix A](#).
- 
1. Place the actuator in the manual mode to prevent the load from shifting.
  2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
  3. Allow the air supply to subside completely.
  4. Remove the covers necessary to access the thermostwitch.
  5. Slide the thermostwitch out of its mounting bracket.
  6. Label the thermostwitch wires.
  7. The new thermostwitch comes with a length of wire attached. Cut the old thermostwitch wires at a point that leaves a length of wire attached to the old thermostwitch that is shorter than that attached to the new thermostwitch.
  8. Splice the wires from the new thermostwitch to the wires cut in [Step 7](#).
  9. Slide the new thermostwitch into the mounting bracket.
  10. Replace the actuator covers.

### *Volume Booster Replacement (Type UP6 Actuators)*

**NOTE:** Refer to the drawings in [Appendix A](#).

1. Place the actuator in the manual mode to prevent the load from shifting.
2. Use the positioner integral shutoff and equalizing valve or the solenoid equalizing valve to shut off the air supply.
3. Allow the air supply to subside completely.
4. Remove the covers necessary to access the volume booster.
5. Label and disconnect the air lines connected to the volume booster.
6. Remove the three bolts that secure the volume booster to its mounting bracket. Do not remove the mounting bracket from the actuator.

7. Mount the new volume booster onto the mounting bracket with the three bolts removed in Step 6.
8. Connect the air lines to the volume booster.
9. Replace the actuator covers.

---

## SECTION 9 - SUPPORT SERVICES

---

### **INTRODUCTION**

ABB is ready to help in the use, application and repair of its products. Contact your nearest sales office to make requests for sales, applications, installation, repair, overhaul and maintenance contract services.

The parts drawings in **Appendix A** cover the actuators. These drawings normally apply to the units furnished. However, there may be individual differences in specific assemblies due to:

1. Design changes made since the printing of this product instruction.
2. Special design of equipment furnished to make it suitable for a special application.

Therefore, when ordering individual parts, insure correct replacement by specifying the complete nomenclature and series number of equipment for which parts are desired, and the title and number of the parts drawing on which each part is illustrated.

---

### **REPLACEMENT PARTS**

Recommended spare parts for each actuator assembly are listed in the tables in **Appendix A**.

---

### **TRAINING**

ABB has a modern training facility available for training your personnel. On-site training is also available. Contact a ABB sales office for specific information and scheduling.

---

### **TECHNICAL DOCUMENTATION**

Additional copies of this instruction as well as copies of other ABB documents are available at the nearest sales office at a reasonable charge.

# APPENDIX A - SPARE PARTS

## INTRODUCTION

This appendix has spare parts information as it relates to the various actuators. There are tables as well as figures illustrating the part numbers, descriptions and locations of these parts. It includes complete spare parts kits and option kits.

Each figure has the corresponding ABB engineering drawing number printed in its lower right-hand corner. Use this number if requesting a full-size copy of that drawing. The engineering drawings include the NEMA 4X versions of the actuators as well as the standard versions included in this appendix.

## TYPE UP1 ACTUATORS

Refer to Tables A-1 through A-8, A-48, and A-49; and Figures A-1 through A-5 and A-30 for spare parts information for Type UP1 actuators.

Table A-1. UP1 with Positioner, Figure A-1 (Drawing No. 5328573)

Item	Qty	Part No.	Description
1	1	5328574_1	Lever
2	1	5328575_1	Vane actuator
3	4	4-4CBI2-B	Elbow
4	1	5328576_3	Brake arm
5	1	Refer to Table A-2	Positioner
6	1	5328577_3	Mounting plate
7	1	5328578_3	Frame
8	1	1963353__01	Label, universal, CSA
10	1	197452_3	Long-lok set screw
12	1	1963302_1	Scale
13	1	5328585_1	Insert
14	1	—	Plain Zn plated steel washer (0.500 x 1.250 x 0.083)
15	1	1963302_2	Scale
17	3	—	Hex head Zn plated steel cap screw (0.250-20 x 0.750)
18	3	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
20	61 cm (24 in.)	R1021-0022	0.250 OD x 0.040 wall Al tubing with polyethylene jacket
21	7	—	Hex head Zn plated steel cap screw (0.375-16 x 0.750)
22	7	—	Zn plated steel reg spring lockwasher (0.375)
23	1	—	Hex head Zn plated steel cap screw (0.375-16 x 1.250)
24	1	1963318__	Nameplate
25	1	1962207_1	Styleplate

# SPARE PARTS

Table A-1. UP1 with Positioner, Figure A-1 (Drawing No. 5328573) (continued)

Item	Qty	Part No.	Description
28	3	NLJHA21000	Hex full nut (0.250-20)
29	3	452219_8	Seal screw
30	1	NTCHA11000	Flat washer (0.250)
31	1	NBJAU21010	0.250-20 hex washer head screw (whiz lock)




Figure A-1. UP1 with Positioner, Tables A-1 and A-2 (Sheet 1 of 3)




Figure A-1. UP1 with Positioner, Tables A-1 and A-2 (Sheet 2 of 3)

Table A-2. UP1 Positioners, Figure A-1

Type	Item 5	Type	Item 5	Type	Item 5
UP1□A	AV1121□3	UP1□C	AV2321□3	UP1□E	AV442103
UP1□B	AV1221□3	UP1□D	AV3321□3		




Figure A-1. UP1 with Positioner, Tables A-1 and A-2 (Sheet 3 of 3)

Table A-3. UP1 with Solenoid Valve, Figure A-2 (Drawing No. 5328581)

Item	Qty	Part No.	Description
1	1	5328574_1	Lever
2	1	5328575_1	Vane actuator
3	1	4-4FBI2-B	Straight fitting
4	1	Refer to Table A-4	Solenoid valve
5	1	5328577_3	Mounting plate
6	2	4-4CBI2-B	Elbow
7	1	5328578_3	Frame
8	1	5328576_3	Brake arm
9	1	5328580_1	Plate
10	1	4-4DBI2-B	Elbow
11	1	195161_¼	Needle valve
12	1	197452_3	Long-lok set screw
13	1	1963302_1	Scale
14	1	5328585_1	Insert
15	7	—	Hex head Zn plated steel cap screw (0.375-16 x 0.750)
16	7	—	Zn plated steel reg spring lockwasher (0.375)
18	1	—	Plain Zn plated steel washer (0.500 x 1.250 x 0.083)
20	8	—	Hex head Zn plated steel cap screw (0.250-20 x 0.750)
22	8	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
23	1	4-4-4RBI2-B	Male run tee
24	1	¼ RRS-B	Male tee
25	1	—	Hex head Zn plated steel cap screw (0.375-16 x 1.250)
26	84 cm (33 in.)	R1021-0022	0.25 OD Al tubing polyethylene jacket
27	1	1963318_	Nameplate
28	1	1962207_1	Styleplate
29	1	1963353_01	Label, universal, CSA
30	1	1963302_2	Scale

Table A-4. UP1 Solenoid Valves, Figure A-2

Type	Item 5	Type	Item 5
UP1□5	5322137□8 (120 VAC), single coil	UP1□9	1951672□2 (115/125 VDC), dual coil
UP1□6	5322137□9 (115/125 VDC), single coil	UP1□F	5322137□10 (220VAC at 50 Hz/240 VAC at 60 Hz), single coil
UP1□8	1951672□1 (120 VAC), dual coil	UP1□G	1951672□3 (220VAC at 50 Hz/240 VAC at 60 Hz), dual coil

# SPARE PARTS




Figure A-2. UP1 with Solenoid Valve, Tables A-3 and A-4 (Sheet 1 of 2)




Figure A-2. UP1 with Solenoid Valve, Tables A-3 and A-4 (Sheet 2 of 2)

## SPARE PARTS

Table A-5. UP1 Alarm/Travel Switch Kit, Figure A-3 (Kit No. 5328745\_1)

Item	Qty	Part No.	Description
1	12	1943825_1	Terminal lug
2	1	194956_12	Terminal block
3	1	1947282_1	Desig plate assembly
4	4	6614403_1	Cam
5	1	5312449_13	Connecting link
6	1	5328742_1	Link arm
7	1	5328596_1	Arm
8	1	5328801_1	Support bracket
9	1	5328701_1	Bracket
10	1	5328589_1	Switch mounting bracket
11	4	1942989_1	Microswitch
12	2	1947261_1	Shield
13	1	1963353_12	Label, universal, CSA
14	1	5328700_1	Shaft
15	2	5328703_1	Spacer block
16	2	197164_37	Retaining ring
17	1	5328741_1	Cover
18	81 cm (32 in.)	5327724_3H	Sealing strip
19	1	197676_1	Ground screw
20	1	197675_1	Washer
21	1	1963318_	Nameplate
22	6	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
23	6	—	Hex head Zn plated steel cap screw (0.250-20 x 0.750)
25	4	—	Pan head Zn plated steel screw (0.138-32 x 0.750)
26	2	—	Hex socket head Zn plated steel cap screw (0.112-40 x 0.625)
27	6	1204-00	Zn plated steel shakeproof lockwasher
28	1	—	Hex socket head Zn plated steel cap screw (0.138-32 x 0.500)
29	2	—	Pan head Zn plated steel sems int (0.190-32 x 0.312)
30	2	—	Pan head Zn plated steel sems int (0.190-32 x 0.875)
31	3	—	Plain Zn plated steel washer (0.4375 x 1.000 x 0.083)
33	4	—	Pan head stainless steel machine screw (0.112-40 x 2.000)
34	4	—	Pan head Zn plated steel sems int (0.190-32 x 0.625)
35	18 cm (7 in.)	R2041-0070	18 AWG brown leadwire
36	18 cm (7 in.)	R2041-0035	18 AWG red leadwire
37	18 cm (7 in.)	R2041-0050	18 AWG orange leadwire
38	18 cm (7 in.)	R2041-0075	18 AWG yellow leadwire
39	18 cm (7 in.)	R2041-0055	18 AWG blue leadwire
40	18 cm (7 in.)	R2041-1712	18 AWG white/blue leadwire
41	1	5328745	Print
42	1	No. 10	Carton





Figure A-3. UP1 Alarm/Travel Switch Kit, Table A-5 (Sheet 1 of 2)



D5328745  
TP20470A

Figure A-3. UP1 Alarm/Travel Switch Kit, Table A-5 (Sheet 2 of 2)

Table A-6. UP1 Electric Shaft Position Transmitter Kit,  
Figure A-4 (Kit No. 5328748\_1)

Item	Qty	Part No.	Description
1	1	5328745_1	Alarm unit kit
2	1	5328702_1	Coupler
3	2	197723_1	Set screw, brass tip
4	1	5328704_1	Transmitter bracket
5	1	5839B01P0001	Feedback potentiometer
6	3	197727_6	Support

Table A-6. UP1 Electric Shaft Position Transmitter Kit,  
Figure A-4 (Kit No. 5328748\_1) (continued)

Item	Qty	Part No.	Description
7	1	6633390_2	4 to 20-mA transmitter board assembly
8	3	1946162_1	Pin receptacle
9	1	5328594_1	Cover
10	3	197688_3	Threaded spacer
11	1	1963318_	Nameplate
13	11.0 cm (4.5 in.)	R2041-1664	22 AWG wht/grn leadwire
14	11.0 cm (4.5 in.)	R2041-1666	22 AWG wht/vio leadwire
15	11.0 cm (4.5 in.)	R2041-1667	22 AWG wht/gra leadwire
16	3	—	Pan head Zn plated steel sems ext (0.138-32 x 0.250)
19	4.0 cm (1.5 in.)	R9023-0175	Insulation tubing tubing</td
20	2	—	Pan head Zn plated steel sems int (0.190-32 x 0.312)
22	1	5328748	Print




Figure A-4. UP1 Electric Shaft Position Transmitter Kit, Table A-6 (Sheet 1 of 2)

**SPARE PARTS**




Figure A-4. UP1 Electric Shaft Position Transmitter Kit, Table A-6 (Sheet 2 of 2)

Table A-7. UP1 Air Failure Lock Kit, Figure A-5 (Kit No. 5328826\_1)

Item	Qty	Part No.	Description
1	1	5329023_1	Rack gear assembly
2	1	5329022_1	Saddle
3	1	5328811_1	Toggle assembly
4	1	5328810_1	Toggle link assembly
5	1	5328753_1	Spacer
6	1	5328816_1	Center pivot
7	1	5328818_1	Adapter
8	1	5328726_1	Drive link
9	1	5328725_1	Eccentric assembly
10	1	—	Semi-fin stainless steel reg hex (0.375-16) full nut
11	1	—	Hex socket head steel cap screw (0.375-16 x 0.875)
12	1	5328751_1	Hand lever
13	1	5328763_1	Hand lock clamp
14	1	5328721_1	Clevis pin
15	2	5327327_3	Adapter
16	1	5328766_1	Rack cover

Table A-7. UP1 Air Failure Lock Kit, Figure A-5 (Kit No. 5328826\_1) (continued)

Item	Qty	Part No.	Description
17	1	5328728_1	Locking rack
18	1	5328730_1	Rack plate
19	1	5328729_1	Mounting yoke
20	4	197164_37	Retaining ring
21	1	1951589_2	Air valve
22	1	1951589_1	Air valve
23	1	1951610_1	Air cylinder
24	3	197120_8	Elastic stop nut
25	1	197259_1	Hex lock nut
26	1	1951606_1	3-way valve
27	1	5328788_1	Mounting bracket
28	1	4-4CB12-B	Male elbow
29	2	4-4FB12-B	Male connector
30	3	4-4-4RB12-B	Male run tee
31	1	—	¼ NPT brass tee
32	1	—	¼ NPT brass close nipple
33	1	5328825_1	Felt washer
34	1	197745_1	Extension spring
35	1.2 m (4.0 ft)	R1021-0022	0.250 OD x 0.040 Wall Al tubing
36	1	1951041_2	⅛ NPT socket head pipe plug
37	2	—	Pan head stainless steel machine screw (0.164-32 x 0.188)
38	2	—	Pan head ph Zn plated steel rolok (0.190-32 x 0.625)
39	1	—	Hex head Zn plated steel cap screw (0.250-20 x 1.000)
40	5	—	Hex socket head Zn plated steel cap screw (0.190-32 x 0.500)
41	3	—	Hex socket head Zn plated steel cap screw (.0250-20 x 0.750)
42	6	—	Pan head Zn plated steel sems int (0.190-32 x 0.625)
43	1	—	Zn plated steel reg spring lockwasher (0.250)
44	1	—	Steel milled stud (0.375-16 x 1.500)
45	5	—	Hex head Zn plated steel cap screw (0.250-20 x 0.750)
46	7	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
47	1	—	Plain Zn plated steel washer (0.312 x 0.734 x 0.065)
48	1	—	Semi-fin Zn plated steel reg hex jam nut (0.500-20)
49	1	1224-00	Zn plated steel shakeproof lockwasher
50	2	—	Pan head Zn plated steel threaded ctg type 1 screw (0.190-32 x 1.500)
51	1	—	3 x 5 cotton draw string bag
52	1	5328826	Print
53	1	No. 24	Carton
54	1	—	Hex socket head stainless steel cap screw (0.250-20 x 1.250)
55	2	4CB12-B	Male elbow
56	1	197164_31	Retaining ring

# SPARE PARTS

Table A-7. UP1 Air Failure Lock Kit, Figure A-5 (Kit No. 5328826\_1) (continued)

Item	Qty	Part No.	Description
57	1	1963318__	Nameplate
58	1	—	Zn plated steel reg spring lockwasher (0.375)
59	1	—	1/8 NPT brass pipe plug
60	1	3053306	Print
61	3	—	Zn plated steel reg spring lockwasher (0.190)




Figure A-5. UP1 Air Failure Lock Kit, Table A-7 (Sheet 1 of 2)




Figure A-5. UP1 Air Failure Lock Kit, Table A-7 (Sheet 2 of 2)

Table A-8. UP1 Rotary Vane Seal Repair Kit, Figure 8-1 (Kit No. 285244\_1)

Item	Qty	Part No.	Description
1	2	341816_212	O-ring (shaft)
2	1	1951631_425	O-ring (vane)
	A/R	199354_1	Lubricant
	A/R	199926_1	Sealant

**TYPE UP2 ACTUATORS**

Refer to Tables A-9 through A-18, A-48 and A-49, and Figures A-6 through A-11 and A-30 for spare parts information for Type UP2 actuators.

## SPARE PARTS

Table A-9. UP2 Actuator with Positioner, Figure A-6 (Drawing No. 5328874)

Item	Qty	Part No.	Description
1 <sup>1</sup>	1	5329141_1	Side cover
2	1	5328642_3	Case assembly
3	1	5328838_1	Vane actuator
4	2	5328862_1	Spacer
5	2	5328863_1	Spacer
6	1	5328860_2	Brake plate
7	1	5328871_1	Cover plate
8	1	5328864_1	Drive plate
9	1	197452_4	Set screw, locking
10	1	Refer to Table A-10	Positioner
11	1	5328868_2	Shaft assembly
12	2	4-4CBI2-B	Male elbow
13 <sup>1</sup>	1	5329157_2	Top cover
14	4	6613970_1	Link lock fastener
15	1	5328869_2	Shaft extension
16	1	5328872_1	Cover plate
17	1	5328841_1	Drive lever
18	7	19981_30	Plug button
19	1	19981_1	Plug button
20	1	1963485_1	Scale
21	1	5328873_1	Pointer
22	1	5328845_1	Brake arm
23	1	1963318_	Nameplate
24	2	67125_15	Rubber grommet
25	1	19981_11	Plug button
26	2	19981_31	Plug button
27	3	5328862_2	Spacer
28	1	1951611_2	Shaft seal
29	1	1951611_1	Shaft seal
30	2	1943785_4	Cable tie
31	2	1951569_9	Plug button
32	5	1114-00	Zn plated steel shakeproof lockwasher
33	5	—	Hex head Zn plated steel cap screw (.0250-20 x 0.375)
34	8	NIDAC09005	Pan head sems ext (0.112)
36	2	—	Hex head Zn plated steel cap screw (0.250-20 x 1.250)
37	2	—	Hex socket head stainless steel cap screw (.0250-20 x 1.250)
38	6	—	Hex head Zn plated steel cap screw (0.500-13 x 1.000)
39	2	—	Hex head Zn plated steel cap screw (0.500-13 x 2.250)
40	1	1963485_2	Scale
41	2	—	Ext lockwasher Zn plated steel hex keps nut (0.250-20)
42	1	—	Semi-fin Zn plated steel heavy hex full nut (0.500-13)

*Table A-9. UP2 Actuator with Positioner, Figure A-6 (Drawing No. 5328874) (continued)*

<b>Item</b>	<b>Qty</b>	<b>Part No.</b>	<b>Description</b>
43	6	—	Zn plated steel reg spring lockwasher (0.500)
44	1	—	Plain Zn plated steel washer (0.562 x 1.375 x 0.109)
45	1	—	Round head Zn plated steel threaded frmg screw type U (0.060 x 0.188)
46	132 cm (52 in.)	R1021-0022	0.250 OD x 0.040 wall Al tubing with polyethylene jacket
47	9	—	Pan head Zn plated steel sems int (0.138-32 x 0.437)
48	9	—	Zn plated steel hex nut (0.138-32)
49	1	5328865_1	Retainer
50	1	—	Hex socket head Zn plated steel cap screw (0.250-20 x 1.500)
51	1	—	Plain Zn plated steel washer (0.281 x 0.625 x 0.065)
52	3	—	Semi-fin Zn plated steel reg hex full nut (0.250-20)
53	1	—	Hex socket head stainless steel cap screw (0.112-40 x 0.250)
54	1	—	Stainless steel reg spring lockwasher (0.112)
55	1	5328914_1	Transfer shaft bushing
56	2	4-4FBI2-B	Male connector
57	1	1963353_	Label, universal, CSA
58	3	NTMHA21000	Int sems lockwasher (0.250)
59	3	NBAHA21016	Hex socket head screw (0.250-20)
60	3	NTCHA11000	Flat washer (0.250)
61	3	NNBHA21000	Hex keps nut (0.250-20)
64	1	MF274-593	Warning label
65	1	1964034_1	Ground label
66	1	NNBAC16000	Hex keps nut (0.190)

**NOTE:**

1. Older models have plastic covers. To order a plastic side cover, use part no. 5328660\_1. To order a plastic top cover, use part no. 5328670\_1.

*Table A-10. UP2 Positioners, Figure A-6*

<b>Type</b>	<b>Item 5</b>
UP2□A	AV1121□3
UP2□B	AV1221□3
UP2□C	AV2321□3
UP2□D	AV3321□3
UP2□E	AV442103

**SPARE PARTS**




Figure A-6. UP2 with Positioner, Tables A-9 and A-10 (Sheet 1 of 3)




Figure A-6. UP2 with Positioner, Tables A-9 and A-10 (Sheet 2 of 3)

## SPARE PARTS




Figure A-6. UP2 with Positioner, Tables A-9 and A-10 (Sheet 3 of 3)

Table A-11. UP2 with Solenoid Valve,  
Figure A-7 (Drawing No. 5328891)

Item	Qty	Part No.	Description
1 <sup>1</sup>	1	5329141_1	Side cover
2	1	5328642_3	Case assembly
3	1	5328838_1	Vane actuator
4	2	5328862_1	Spacer
5	2	5328863_1	Spacer
6	1	5328860_1	Brake plate
7	1	5328871_1	Cover plate
8	1	5328864_1	Drive plate
9	1	Refer to Table A-12	Solenoid valve
10	1	5328868_2	Shaft assembly
11	3	4-4CBI2-B	Male elbow
12 <sup>1</sup>	1	5329157_2	Top cover
13	4	6613970_1	Link lock fastener
14	1	5328869_2	Shaft extension
15	1	5328872_1	Cover plate
16	1	1951611_1	Shaft seal
17	1	5328841_1	Drive lever

Table A-11. UP2 with Solenoid Valve,  
Figure A-7 (Drawing No. 5328891) (continued)

Item	Qty	Part No.	Description
18	7	19981_30	Plug button
19	1	19981_1	Plug button
20	1	5328865_1	Retainer
21	1	1963485_1	Scale
22	1	5328873_1	Pointer
23	1	5328845_1	Brake arm
24	1	1963318_	Nameplate
25	1	1951611_2	Shaft seal
26	2	67125_15	Rubber grommet
27	2	19981_31	Plug button
28	1	19981_11	Plug button
29	3	5328862_2	Spacer
30	1	5328580_1	Mounting plate
31	1	195161_¼	Needle valve
32	1	¼RRS-B	Male pipe tee
33	1	4-4DBI2-B	Female elbow
34	1	4-4-4RBI2-B	Male run tee
35	1	1963485_2	Scale
36	2.1 m (7.0 ft)	R1021-0022	0.250 OD x 0.040 Wall Al tubing
37	8	NIDAC09005	Pan head sems ext (0.112)
38	5	—	Hex head Zn plated steel cap screw (0.250-20 x 0.750)
39	3	—	Hex head Zn plated steel cap screw (.0250-20 x 1.250)
40	5	—	Hex head Zn plated steel cap screw (0.250-20 x 0.375)
41	2	—	Hex socket head stainless steel cap screw (0.250-20 x 1.250)
42	6	—	Hex head Zn plated steel cap screw (0.500-13 x 1.000)
43	2	—	Hex head Zn plated steel cap screw (0.500-13 x 2.250)
44	2	1951569_9	Plug button
45	8	—	Ext lockwasher Zn plated steel hex keps nut (0.250-20)
46	1	—	Semi-fin Zn plated steel heavy hex full nut (0.500-13)
47	7	—	Zn plated steel reg spring lockwasher (0.500)
48	1	—	Plain Zn plated steel washer (0.562 x 1.375 x 0.109)
49	1	—	Round head Zn plated steel threaded frmng screw type U (0.060 x 0.188)
50	5	1214-00	Zn plated steel shakeproof lockwasher
51	9	—	Pan head Zn plated steel sems int (0.138-32 x 0.437)
52	9	—	Zn plated steel hex nut (0.138-32)
53	1	—	Hex socket head stainless steel cap screw (0.112-40 x 0.250)
54	1	—	Stainless steel reg spring lockwasher (0.112)
55	1	—	Hex socket head Zn plated steel cap screw (0.250-20 x 1.500)
56	1	—	Plain Zn plated steel washer (0.281 x 0.625 x 0.065)

# SPARE PARTS

Table A-11. UP2 with Solenoid Valve,  
Figure A-7 (Drawing No. 5328891) (continued)

Item	Qty	Part No.	Description
57	3	—	Semi-fin Zn plated steel Reg hex full nut (0.250-20)
58	1	5328914_1	Transfer shaft bearing
59	1	1963353__01	Label, universal, CSA
60	1	197452_4	Set screw
64	1	MF274-593	Warning label
65	1	1964034_1	Ground label
66	1	NNBAC16000	Hex keps nut (0.190)

**NOTE:**

1. Older models have plastic covers. To order a plastic side cover, use part no. 5328660\_1. To order a plastic top cover, use part no. 5328670\_1.




Figure A-7. UP2 with Solenoid Valve, Tables A-11 and A-12 (Sheet 1 of 2)




Figure A-7. UP2 with Solenoid Valve, Tables A-11 and A-12 (Sheet 2 of 2)

Table A-12. UP2 Solenoid Valves, Figure A-7

Type	Item 5
UP2□5	5322137□8 (120 VAC), single coil
UP2□6	5322137□9 (115/125 VDC), single coil
UP2□8	1951672□1 (120 VAC), dual coil
UP2□9	1951672□2 (115/125 VDC), dual coil
UP2□F	5322137□10 (220 VAC at 50 Hz /240 VAC at 60 Hz), single coil
UP2□G	1951672□3 (220VAC at 50 Hz/240 VAC at 60 Hz), dual coil

## SPARE PARTS

Table A-13. UP2 Alarm/Travel Switch Kit, Figures A-8 and A-30 (Kit No. 5328932\_1)

Item	Qty	Part No.	Description
1	1	5328596_1	Arm
2	1	5328931_1	Linkage assembly
3	3	19934_198	Spacer
4	1	5328698_1	Alarm unit
5	1	1963318__	Nameplate
9	1	—	Pan head Zn plated steel sems int (0.190-32 x 0.625)
11	1	—	Pan head screw (0.190-32)
12	3	NBZHA16028	Hex keps nut (0.190-32)
13	3	NNBHA16000	Zn plated steel hex nut (0.190-32)
14	1	No. 20	Carton
15	1	5328932	Print

Table A-14. UP2 Electric Shaft Position Transmitter Kit, Figures A-8 and A-30 (Kit No. 5328932\_2)

Item	Qty	Part No.	Description
1	1	5328596_1	Arm
2	1	5328931_1	Linkage assembly
3	3	19934_198	Spacer
4	1	5328698_2	Electric shaft position transmitter
5	1	1963318__	Nameplate
9	1	—	Pan head Zn plated steel sems int (0.190-32 x 0.625)
11	1	—	Hex socket head stainless steel cap screw (0.138-32 x 0.500)
12	3	NBZHA16028	Pan head screw (0.190-32)
13	3	NNBHA16000	Hex keps nut (0.190-32)
15	1	5328932	Print

Table A-15. UP2 Pneumatic Shaft Position Transmitter Kit, Figure A-9 (Kit No. 5328936\_2/3)

Item	Qty	Part No.	Description
1	1	AV112000	Pneumatic shaft position transmitter for Type UP2_AC__ (kit no. 5328936_2)
		AV122000	Pneumatic shaft position transmitter for Type UP2_BD__ (kit no. 5328936_3)
2	1	5312449_21	Connecting link
3	1	5328846_2	Positioner mounting bracket
4	1	19934_110	Spacer
5	1	197120_5	Elastic stop nut
6	1	1963318__	Nameplate
7	1	1951041_1	¼ NPT socket head pipe plug
8	1	4-4-4RBI2-B	¼ male run tee






Figure A-8. UP2 with Electric Shaft Position Transmitter and/or Alarm/Travel Switches, Tables A-13, A-14, A-48 and A-49 (Sheet 2 of 2)




Figure A-9. UP2 with Pneumatic Shaft Position Transmitter, Table A-15 (Sheet 1 of 2)

## SPARE PARTS




Figure A-9. UP2 with Pneumatic Shaft Position Transmitter, Table A-15 (Sheet 2 of 2)

Table A-15. UP2 Pneumatic Shaft Position Transmitter Kit,  
Figure A-9 (Kit No. 5328936\_2/3) (continued)

Item	Qty	Part No.	Description
10	4	—	Hex head Zn plated steel cap screw (0.250-20 x 1.000)
11	4	—	Ext lockwasher Zn plated steel hex keps nut (0.250-20)
13	1	—	Hex head Zn plated steel cap screw (0.190-32 x 1.375)
14	1	1210-00	Zn plated steel shakeproof lockwasher
15	15 cm (6 in.)	R1021-0022	0.250 OD x 0.040 wall Al tubing w/polyethylene jacket
16	1	FORM MP290	Warning tag
17	1	5328936	Print
18	1	No. 24	Carton
19	1	5329040_1	Link mounting bracket
20	1	—	Stainless steel roll pin (0.094 dia x 0.438)
21	1	—	Plain Zn plated steel washer (0.203 x 0.406 x 0.040)
22	2	—	Hex head Zn plated steel cap screw (0.190-32 x 0.750)
23	4	19934_107	Spacer

Table A-15. UP2 Pneumatic Shaft Position Transmitter Kit,  
Figure A-9 (Kit No. 5328936\_2/3) (continued)

Item	Qty	Part No.	Description
25	3	NTMHA21000	Int sems lockwasher (0.250)
26	3	NBAHA21016	Hex socket head screw (0.250-20)
27	3	NTCHA11000	Flat washer (0.250)
28	3	NNBHA21000	Hex keps nut (0.250-20)

Table A-16. UP2 Air Failure Lock Kit,  
Figure A-10 (Kit No. 5328925\_1)

Item	Qty	Part No.	Description
1	2	1951609_1	Bulkhead fitting
2	1	5328917_1	Manual lock
3	1	5328863_2	Spacer
4	1	5328938_1	Transfer shaft assembly
5	1	5328909_1	Pin
6	3	197164_37	Retaining ring
7	1	5328915_1	Lever
8	2	1941718_1	Conduit gasket
9	2	5328918_1	Pin
10	5	197164_50	Retaining ring
11	1	5328929_1	Eccentric assembly
12	6	NNBHA21000	Hex keps nut (0.250-20)
13	1	5328912_1	Link
14	1	5328861_1	Rack cover
15	1	5328921_1	Rack
16	1	5328910_1	Rack gear
17	1	5328922_1	Sector plate
18	1	5328927_1	Eccentric assembly
19	1	1951589_2	Air valve
20	1	5328788_1	Mounting bracket
21	1	1951606_1	3-way valve
22	1	5328911_1	Support stud
23	1	1951610_1	Air cylinder
24	1	5328919_1	Clevis arm
25	2	5327327_3	Adapter
26	1	197745_1	Extension spring
27	3	4-4-4RBI2-B	Male run tee
28	2	4CB12-B	Male elbow
29	5	4-4CB12-B	Male elbow
30	1	—	¼ street elbow
31	1	1951589_1	Air valve
32	1	197120_10	Elastic stop nut

## SPARE PARTS

Table A-16. UP2 Air Failure Lock Kit,  
Figure A-10 (Kit No. 5328925\_1) (continued)

Item	Qty	Part No.	Description
33	1	1963487_1	Label
34	2	—	Plain Zn plated steel washer (0.0312 x 0.734 x 0.065)
35	1.8 m (6.0 ft)	R1021-0022	0.250 OD x 0.040 wall Al tubing
36	1	—	¼ close brass nipple
37	1	195273_¼	Tee
38	1	—	⅛ brass pipe plug
39	2	—	Pan head stainless steel cap screw (0.164-32 x 0.188)
40	2	NAUHA21006	Hex head cap screw (0.250-20)
41	2	NAUHA21032	Hex head cap screw (0.250-20)
42	1	—	Hex head Zn plated steel cap screw (0.250-20 x 0.500)
43	7	—	Pan head Zn plated steel machine screw (0.190-32 x 0.875)
44	3	—	Hex socket head Zn plated steel cap screw (0.250-20 x 1.500)
45	1	6618445_2	Nylon washer
46	1	—	Hex head Zn plated steel cap screw (0.250-20 x 0.750)
47	3	—	Plain Zn plated steel flat washer (0.250 x 0.562 x 0.065)
48	1	—	Hex socket head Zn plated steel cap screw (0.250-20 x 1.000)
49	2	—	Rolled split spacer cem
50	2	—	Pan head Zn plated steel machine screw (0.164-32 x 2.750)
51	1	1963318_	Nameplate
52	2	NTJHA15030	Spring lockwasher (0.500)
53	1	NLHHA29000	Hex jam nut (0.500-13)
55	1	—	Cotton draw string bag 7.6 x 12.7 cm (3.0 x 5.0 in.)
56	1	5328925	Print
57	4	NTMHA21000	Int lockwasher (0.250)
58	1	—	Semi-fin Zn plated steel reg hex jam nut (0.500-20)
59	1	—	⅛ brass pipe plug
60	1	3053306	Print
61	2	—	Ext lockwasher Zn plated steel hex keps (0.164-32)
62	1	NLJHA21000	Hex nut (0.250-20)





Figure A-10. UP2 with Air Failure Lock, Table A-16 (Sheet 1 of 2)

**SPARE PARTS**



D5328925  
TP20485A

Figure A-10. UP2 with Air Failure Lock, Table A-16 (Sheet 2 of 2)

Table A-17. UP2 Reserve Air Tank Kit, Figure A-11 (Kit No. 5328925\_2)

Item	Qty	Part No.	Description
1	1	5328642_4	Case assembly
2	2	5328788_1	Mounting bracket
3	2	1951606_1	3-way pneumatic valve
4	1	1941099_2	Pressure switch
5	1	1941147_1	½ molded bushing
6	1	5328782_1	Air failure lock harness
7	1	194956_3	Terminal block
8	1	5329189_1	Terminal designation assembly
9	1	5329190_1	Switch mounting plate
10	1	67125_15	Rubber grommet
11	4	4-4-4SBI2-B	Male branch tee
12	10	4-4CBI2-B	Male elbow
13	2	1951609_1	Bulkhead fitting
14	2	1941817_1	Conduit gasket
15	1	1951712_1	Check valve
16	1	1963318__	Universal nameplate
17	1	1963489_4	Designation plate
18	1	1951785_5	20.8 liter (5.5 gallon) air tank assembly (Fig. B-11)
19	2	4-4FBI2-B	Male connector
20	1	1951608_1	Shutoff valve
21	1	1963478_1	Instruction plate
23	2	NIDAC13008	Pan head ext sems (0.138)
24	2	NIDAC13012	Pan head ext sems (0.138)
25	2	NBJAC16010	Hex washer head screw (0.190)
26	4	NTMAC19000	Int lockwasher (0.190)
27	4	NBZAC17014	Pan head screw (0.190-24)
28	2	NAUAC21006	Hex cap screw (0.250)
29	2	NTLAC25000	Ext lockwasher (0.250)
30	4	NBJAC21008	Hex whiz lock (0.250)
31	1	NTLAC50000	Ext lockwasher (0.500)
32	1	—	¼ NPT brass street elbow
33	2	—	¼ NPT brass tee
34	1	—	¼ NPT x 1.250 long brass nipple
36	3 m (10 ft)	R1021-0022	0.250 OD x 0.040 wall Al tubing with black poly jacket
38	1	C3053544 - sh3	Print




Figure A-11. UP2 Reserve Air Tank Kit, Table A-17 (Sheet 1 of 2)




Figure A-11. UP2 Reserve Air Tank Kit, Table A-17 (Sheet 2 of 2)

## SPARE PARTS

Table A-18. UP2 Rotary Vane Seal Repair Kit,  
Figure 8-1 (Kit No. 258244\_2)

Item	Qty	Part No.	Description
1	2	341816_218	O-ring (shaft)
2	1	1951631_443	O-ring (vane)
	A/R	199354_1	Lubricant
	A/R	199926_1	Sealant

Table A-19. UP2 Heater Kits, Figure A-12 (Kit Nos. 5328935\_1/2)

Item	Qty	Part No.	Description
1	1	6612345_2	Desig plate assembly
2	1	194956_3	Terminal block
3	2	1943825_8	Terminal lug
4	2	19934_87	Spacer
5	1	1943002_1	Strip heater (500 W) for 120 VAC operation
		1943002_2	Strip heater (500 W) for 240 VAC operation
6	1	662460_1	Thermoswitch
7	1	195105_10	Tube clamp
8	2	1941401_2	Solderless terminal
11	1	197118_2	Conduit connector
12	3	NBZHA13012	Pan head stainless steel screw (0.138)
13	5	NNBAC13000	Hex keps nut (0.138-32)
14	36 cm (14 in.)	5318366_1U	Fiberglass insulation
15	1	NBZHA16010	Pan head stainless steel screw (0.190)
16	4	NNBHA16000	Stainless steel hex keps (0.190)
17	2	NBZHA16020	Pan head stainless steel machine screw (0.190-32)
18	1	5328935	Print
19	1	No. 84	Mailer
20	1.2 m (4.0 ft)	R2049-0100	14 AWG natural leadwire
21	2	NTCHA09000	Plain stainless steel washer (0.190)
22	1	195105_6	Tube clamp
23	2	1943825_11	Terminal lug
24	2	NBZHA13016	Pan head stainless steel sems ext (0.138)
25	1	1963318_	Nameplate
26	5	197496_6	Sealing washer
27	3	197496_10	Sealing washer




Figure A-12. UP2 with Heater, Table A-19 (Sheet 1 of 2)




Figure A-12. UP2 with Heater, Table A-19 (Sheet 2 of 2)

**TYPES UP3 AND UP4 ACTUATORS**

Refer to Tables A-20 through A-31, A-48 and A-49; Figures A-13 through A-21, and A-30 for spare parts information for Types UP3 and UP4 actuators.

Table A-20. UP3 and UP4 with Positioner, Figure A-13  
(Drawing No. 5328749)

Item	Qty	Part No.	Description
Refer to sheets 1 and 2 of Figure A-13.			
1	1	5328740_3	Frame assembly
2	4	197730_1	Cotter pin
3	8	1951569_9	Plug button
4	1	194956_17	Terminal block
5	1	1947271_2	Desig plate
6	8	197743_3	Ty-wrap
7	1	Refer to Tables A-21, 8-1, 8-2 and Figures 8-2 and 8-3	Cylinder assembly
8	1	5328779_1	Arm and shaft assembly
9	1	—	Zn plated roll pin (0.500 dia x 3.500)
10	1	5328735_1	Drive pin
11	2	5328774_1	Roller bearing
12	2	197164_75	Retaining ring
13	2	5328737_1	Retainer plate
14	1	5328789_1	Spring plunger
15	1	5328732_1	Spring keeper
16	1	5328785_1	Spring
17	1	5328733_1	Spring guide
18	1	5328734_1	Cam
19	2	5328754_3	Support panel
20	1	5328747_1	Split nut
21	1	5328736_1	Operator rod
22	1	5328738_1	H wheel shaft
23	1	Refer to Table A-21	Positioner
24	1	Refer to Table A-21	Desig plate
25	1	194956_7	Terminal block
26	2	5328770_1	Clevis pin
27	Refer to Table A-21	1951407_1	Male connector
28	1	5328718_1	Bearing support
29	1	5328771_1	Clevis
30	1	5328765_2	Gasket
31	6	5313297_1	Washer
32	2	5313299_1	Thrust bearing
33	2	5311759_1	Ball joint

## SPARE PARTS

Table A-20. UP3 and UP4 with Positioner, Figure A-13  
(Drawing No. 5328749) (continued)

Item	Qty	Part No.	Description
Refer to sheets 1 and 2 of Figure A-13.			
34	1	5400311_1	Connecting link (AV)
35	Refer to Table A-21	1951609_1	Bulkhead fitting
36	Refer to Table A-21	19981_31	Plug button
37	1	197676_1	Ground screw
38	1	197675_1	Washer
39	Refer to Table A-21	4-4CBI2-B	Male elbow
40	Refer to Table A-21	4CBI2-B	Male elbow
41	Refer to Table A-21	4-4FBI2-B	Male connector
42	1	5328793_1	Sleeve
43	1	1963318_	Nameplate
44	1	5328758_2	Instruction plate
45	2	—	Hex head Zn plated steel cap screw (0.500-13 x 0.625)
46	2	—	Hex head Zn plated steel cap screw (0.250-20 x 3.000)
47	Refer to Table A-21	—	¼ NPT brass street elbow
48	Refer to Table A-21	—	¼ NPT x 1.250 long brass nipple
49	4	—	Hex head Zn plated steel cap screw (0.250-20 x 0.500)
50	4	—	Hex head Zn plated steel machine screw (0.250-20 x 0.750)
51	2	—	Semi-fin Zn plated steel heavy hex full nut (0.500-13)
52	2	—	Hex head Zn plated steel cap screw (0.500-13 x 1.500)
53	2	1224-00	Zn plated steel shakeproof lockwasher
54	Refer to Table A-21	1943825_1	Terminal lug
55	1	—	Hex jam nut (1.000-14)
56	1	—	Hex nut (0.750-16)
57	Refer to Table A-21	R1021-0022	0.250 OD x 0.040 wall Al tubing with polyethylene jacket
58	1	5400313_1	Mounting plate
59	8	SSP-68	Zn plated steel rivet
60	4	—	Pan head Zn plated steel machine screw (0.138-32 x 1.000)
61	4	—	Pan head Zn plated steel machine screw (0.138-32 x 0.625)
62	1	5329067_1	Stop plate
63	1	5329066_1	Shaft extension
64	10	1214-00	Zn plated steel shakeproof int lockwasher
65	1	5320156_1	Spring

Table A-20. UP3 and UP4 with Positioner, Figure A-13  
(Drawing No. 5328749) (continued)

Item	Qty	Part No.	Description
Refer to sheets 1 and 2 of Figure A-13.			
66	1	5329065_1	Shaft seal
67	1	—	¼ NPT brass tee
68	1	—	¼ NPT brass pipe plug
69	3	—	MDP spiral pin (0.188 dia x 1.000)
70	1	1963503_1	Designation label
71	1	1963503_2	Designation label
72	1	1963503_3	Designation label
73	1	1963503_4	Designation label
74	8	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
75	Refer to Table A-21	R2041-0030	18 AWG white leadwire
76	Refer to Table A-21	R2041-0010	18 AWG black leadwire
77	A/R	6634752_1	Shim
79	4	—	Indented hex washer Zn plated steel (0.250-20 x 0.500)
80	Refer to Table A-21	4VBI2-B	45° male elbow
81	Refer to Table A-21	—	¼ NPT brass elbow
82	1	197120_5	Elastic stop nut
84	2	19734_45	Small washer
85	1	5311459_1	Handle valve
86	1	—	Zn plated steel roll pin (0.125 x 0.750)
87	1	4808-09-01-4102	Stainless steel shakeproof lockwasher
88	1	—	Plain Zn plated steel washer (0.188 x 0.438 x 0.049)
89	4	1114-00	Zn plated steel shakeproof lockwasher
90	1	—	Pan head Zn plated steel machine screw (0.164-32 x 0.625)
91	Refer to Table A-21	1943825_3	Terminal lug
92	A/R	1963353__01	Label, universal, CSA
93	Refer to Table A-21	1951408_1	Male elbow
94	Refer to Table A-21	R9021-0050	0.500 OD x 0.062 wall nylon tubing
96	3	NTJHA11030	Spring lockwasher (0.250)
97	3	NBAHA21014	Hex socket head screw (0.250-20)
98	Refer to Table A-21	1941147_1	Bushing
99	Refer to Table A-21	R2041-1576	22 AWG black leadwire
100	1	NNBAC20000	Hex keps nut (0.250-28)
101	2	NTLAC19000	Ext shakeproof lockwasher (0.250)
107	76.2 cm (30.0 in.)	R2041-1577	22 AWG brown leadwire
108	76.2 cm (30.0 in.)	R2041-1578	22 AWG red leadwire
109	76.2 cm (30.0 in.)	R2041-1580	22 AWG yellow leadwire

## SPARE PARTS

Table A-20. UP3 and UP4 with Positioner, Figure A-13  
(Drawing No. 5328749) (continued)

Item	Qty	Part No.	Description
110	76.2 cm (30.0 in.)	R2041-1581	22 AWG blue leadwire
111	76.2 cm (30.0 in.)	R2041-1700	22 AWG green leadwire
Refer to sheet 3 of Figure A-13.			
1	1	5328792_1	Handle
2	1	198517_2	Handle and ratchet assembly
6 <sup>1</sup>	1	5328759_8	Side cover
7	1	1963339_1	Scale
8	1	5328609_2	Pointer
9 <sup>1</sup>	1	5328759_7	Side cover
10 <sup>1</sup>	1	5329164_2	Top cover assembly
12	1	1962207_1	Style plate
13	1	5328797_1	Operating lever
14	1	5324259_1	Hand/auto nameplate
15	1	198531_1	Woodruff key
16	1	1963339_2	Scale
24	1	NRNHA19016	Spiral pin (0.188)
29	4.3 m (14.0 ft)	1951480_1U	Sealing strip
31	1	NAUHA21008	Hex cap screw (0.250-20)
33	1	NTJHA11030	Spring lockwasher (0.250)
34	6.3 cm (2.5 in.)	R9410-0025	Vinyl tape (0.250 X 0.375)

**NOTE:**

1. Older models have plastic covers. To order a plastic side cover, use part nos. 5328759\_2 (Item 9). To order a plastic top cover, use part no. 5328795\_1 (Item 10).

Table A-21. UP3 and UP4 Positioners and Unique Items, Figure A-13

Type	Item 7	Item 23	Item 24	Item 27	Item 35	Item 36	Item 39	Items 40,80
UP3_A0	5328775_1	AV112100	1947271_8	Omit	2	4	4	1
UP3_A11	5328775_1	AV112100	1947271_8	Omit	2	4	4	1
UP3_AA	5328775_1	AV112110	1947271_8	Omit	2	4	4	1
UP3_AB	5328775_1	AV112120	1947271_8	Omit	2	4	4	1
UP3_AC	5328775_1	AV112100	1947271_8	Omit	2	4	4	1
UP3_B0	5328775_1	AV122100	1947271_8	Omit	2	4	4	1
UP3_B11	5328775_1	AV122100	1947271_8	Omit	2	4	4	1
UP3_BA	5328775_1	AV122110	1947271_8	Omit	2	4	4	1
UP3_BB	5328775_1	AV122120	1947271_8	Omit	2	4	4	1
UP3_BD	5328775_1	AV122100	1947271_8	Omit	2	4	4	1
UP3_C0	5328775_1	AV232100	1947271_8	Omit	1	5	3	1
UP3_C11	5328775_1	AV232100	1947271_8	Omit	1	5	3	1
UP3_CA	5328775_1	AV232110	1947271_8	Omit	1	5	3	1
UP3_CB	5328775_1	AV232120	1947271_8	Omit	1	5	3	1
UP3_D0	5328775_1	AV332100	1947271_8	Omit	1	5	3	1

Table A-21. UP3 and UP4 Positioners and Unique Items, Figure A-13 (continued)

Type	Item 7	Item 23	Item 24	Item 27	Item 35	Item 36	Item 39	Items 40,80
UP3_D11	5328775_1	AV332100	1947271_8	Omit	1	5	3	1
UP3_DA	5328775_1	AV332110	1947271_8	Omit	1	5	3	1
UP3_DB	5328775_1	AV332120	1947271_8	Omit	1	5	3	1
UP3_E0	5328775_1	AV442100	1947271_9	Omit	1	5	3	1
UP3_E11	5328775_1	AV442100	1947271_9	Omit	1	5	3	1
UP4_A0	5328769_1	AV112100	1947271_8	2	2	4	1	Omit
UP4_A11	5328769_1	AV112100	1947271_8	2	2	4	1	Omit
UP4_AA	5328769_1	AV112110	1947271_8	2	2	4	1	Omit
UP4_AB	5328769_1	AV112120	1947271_8	2	2	4	1	Omit
UP4_AC	5328769_1	AV112100	1947271_8	2	2	4	1	Omit
UP4_B0	5328769_1	AV122100	1947271_8	2	2	4	1	Omit
UP4_B11	5328769_1	AV122100	1947271_8	2	2	4	1	Omit
UP4_BA	5328769_1	AV122110	1947271_8	2	2	4	1	Omit
UP4_BB	5328769_1	AV122120	1947271_8	2	2	4	1	Omit
UP4_BD	5328769_1	AV122100	1947271_8	2	2	4	1	Omit
UP4_C0	5328769_1	AV232100	1947271_8	2	1	5	Omit	Omit
UP4_C11	5328769_1	AV232100	1947271_8	2	1	5	Omit	Omit
UP4_CA	5328769_1	AV232110	1947271_8	2	1	5	Omit	Omit
UP4_CB	5328769_1	AV232120	1947271_8	2	1	5	Omit	Omit
UP4_D0	5328769_1	AV332100	1947271_8	2	1	5	Omit	Omit
UP4_D11	5328769_1	AV332100	1947271_8	2	1	5	Omit	Omit
UP4_DA	5328769_1	AV332110	1947271_8	2	1	5	Omit	Omit
UP4_DB	5328769_1	AV332120	1947271_8	2	1	5	Omit	Omit
UP4_E0	5328769_1	AV442100	1947271_9	2	1	5	Omit	Omit
UP4_E11	5328769_1	AV442100	1947271_9	2	1	5	Omit	Omit

Table A-21. UP3 and UP4 Positioners and Unique Items, Figure A-13

Type	Item 41	Items 47, 81	Item 48	Item 54	Item 57	Items 75, 76	Items 91, 98	Item 93
UP3_A0	2	Omit	1	0	2.4 m (8.0 ft)	Omit	Omit	Omit
UP3_A11	2	Omit	1	0	2.4 m (8.0 ft)	Omit	Omit	Omit
UP3_AA	2	Omit	1	7	2.4 m (8.0 ft)	Omit	1	Omit
UP3_AB	2	Omit	1	5	2.4 m (8.0 ft)	Omit	1	Omit
UP3_AC	2	Omit	1	0	2.4 m (8.0 ft)	Omit	Omit	Omit
UP3_B0	2	Omit	1	0	2.4 m (8.0 ft)	Omit	Omit	Omit
UP3_B11	2	Omit	1	0	2.4 m (8.0 ft)	Omit	Omit	Omit
UP3_BA	2	Omit	1	7	2.4 m (8.0 ft)	Omit	1	Omit
UP3_BB	2	Omit	1	5	2.4 m (8.0 ft)	Omit	1	Omit
UP3_BD	2	Omit	1	0	2.4 m (8.0 ft)	Omit	Omit	Omit
UP3_C0	1	Omit	1	5	2.1 m (7.0 ft)	0.6 m (2.0 ft)	1	Omit
UP3_C11	1	Omit	1	5	2.1 m (7.0 ft)	0.6 m (2.0 ft)	1	Omit

## SPARE PARTS

Table A-21. UP3 and UP4 Positioners and Unique Items, Figure A-13 (continued)

Type	Item 41	Items 47, 81	Item 48	Item 54	Item 57	Items 75, 76	Items 91, 98	Item 93
UP3_CA	1	Omit	1	11	2.1 m (7.0 ft)	0.6 m (2.0 ft)	1	Omit
UP3_CB	1	Omit	1	9	2.1 m (7.0 ft)	0.6 m (2.0 ft)	1	Omit
UP3_D0	1	Omit	1	5	2.1 m (7.0 ft)	0.6 m (2.0 ft)	1	Omit
UP3_D11	1	Omit	1	5	2.1 m (7.0 ft)	0.6 m (2.0 ft)	1	Omit
UP3_DA	1	Omit	1	11	2.1 m (7.0 ft)	0.6 m (2.0 ft)	1	Omit
UP3_DB	1	Omit	1	9	2.1 m (7.0 ft)	0.6 m (2.0 ft)	1	Omit
UP3_E0	1	Omit	1	11	2.1 m (7.0 ft)	1.8 m (6.0 ft)	1	Omit
UP3_E11	1	Omit	1	11	2.1 m (7.0 ft)	1.8 m (6.0 ft)	1	Omit
UP4_A0	1	1	2	0	0.3 m (1.0 ft)	Omit	Omit	4
UP4_A11	1	1	2	0	0.3 m (1.0 ft)	Omit	Omit	4
UP4_AA	1	1	2	7	0.3 m (1.0 ft)	Omit	1	4
UP4_AB	1	1	2	5	0.3 m (1.0 ft)	Omit	1	4
UP4_AC	1	1	2	0	0.3 m (1.0 ft)	Omit	Omit	4
UP4_B0	1	1	2	0	0.3 m (1.0 ft)	Omit	Omit	4
UP4_B11	1	1	2	0	0.3 m (1.0 ft)	Omit	Omit	4
UP4_BA	1	1	2	7	0.3 m (1.0 ft)	Omit	1	4
UP4_BB	1	1	2	5	0.3 m (1.0 ft)	Omit	1	4
UP4_BD	1	1	2	0	0.3 m (1.0 ft)	Omit	Omit	4
UP4_C0	Omit	1	2	5	Omit	0.6 m (2.0 ft)	1	4
UP4_C11	Omit	1	2	5	Omit	0.6 m (2.0 ft)	1	4
UP4_CA	Omit	1	2	11	Omit	0.6 m (2.0 ft)	1	4
UP4_CB	Omit	1	2	9	Omit	0.6 m (2.0 ft)	1	4
UP4_D0	Omit	1	2	5	Omit	0.6 m (2.0 ft)	1	4
UP4_D11	Omit	1	2	5	Omit	0.6 m (2.0 ft)	1	4
UP4_DA	Omit	1	2	11	Omit	0.6 m (2.0 ft)	1	4
UP4_DB	Omit	1	2	9	Omit	0.6 m (2.0 ft)	1	4
UP4_E0	Omit	1	2	11	Omit	1.8 m (6.0 ft)	1	4
UP4_E11	Omit	1	2	11	Omit	1.8 m (6.0 ft)	1	4

Table 21. UP3 and UP4 Positioners and Unique Items, Figure A-13 (continued)

Type	Item 94	Item 99	Item 107	Item 108	Item 109	Item 110	Item 111
UP3_A0	Omit	Omit	Omit	Omit	Omit	Omit	Omit
UP3_A11	Omit	Omit	Omit	Omit	Omit	Omit	Omit
UP3_AA	Omit	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP3_AB	Omit	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	0.5 m (1.7 ft)
UP3_AC	Omit	Omit	Omit	Omit	Omit	Omit	Omit
UP3_B0	Omit	Omit	Omit	Omit	Omit	Omit	Omit
UP3_B11	Omit	Omit	Omit	Omit	Omit	Omit	Omit
UP3_BA	Omit	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP3_BB	Omit	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	0.5 m (1.7 ft)

*Table 21. UP3 and UP4 Positioners and Unique Items, Figure A-13 (continued)*

Type	Item 94	Item 99	Item 107	Item 108	Item 109	Item 110	Item 111
UP3_BD	Omit	Omit	Omit	Omit	Omit	Omit	Omit
UP3_C0	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	Omit	0.5 m (1.7 ft)
UP3_C11	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	Omit	0.5 m (1.7 ft)
UP3_CA	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP3_CB	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	Omit	0.5 m (1.7 ft)
UP3_D0	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	Omit	0.5 m (1.7 ft)
UP3_D11	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	Omit	0.5 m (1.7 ft)
UP3_DA	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP3_DB	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	Omit	0.5 m (1.7 ft)
UP3_E0	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP3_E11	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP4_A0	2.1 m (7.0 ft)	Omit	Omit	Omit	Omit	Omit	Omit
UP4_A11	2.1 m (7.0 ft)	Omit	Omit	Omit	Omit	Omit	Omit
UP4_AA	2.1 m (7.0 ft)	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP4_AB	2.1 m (7.0 ft)	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	0.5 m (1.7 ft)
UP4_AC	2.1 m (7.0 ft)	Omit	Omit	Omit	Omit	Omit	Omit
UP4_B0	2.1 m (7.0 ft)	Omit	Omit	Omit	Omit	Omit	Omit
UP4_B11	2.1 m (7.0 ft)	Omit	Omit	Omit	Omit	Omit	Omit
UP4_BA	2.1 m (7.0 ft)	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP4_BB	2.1 m (7.0 ft)	Omit	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	0.5 m (1.7 ft)
UP4_BD	2.1 m (7.0 ft)	Omit	Omit	Omit	Omit	Omit	Omit
UP4_C0	2.1 m (7.0 ft)	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	Omit	0.5 m (1.7 ft)
UP4_C11	2.1 m (7.0 ft)	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	Omit	0.5 m (1.7 ft)
UP4_CA	2.1 m (7.0 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP4_CB	2.1 m (7.0 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	Omit	0.5 m (1.7 ft)
UP4_D0	2.1 m (7.0 ft)	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	Omit	0.5 m (1.7 ft)
UP4_D11	2.1 m (7.0 ft)	0.8 m (2.5 ft)	Omit	0.8 m (2.5 ft)	Omit	Omit	0.5 m (1.7 ft)
UP4_DA	2.1 m (7.0 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP4_DB	2.1 m (7.0 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	Omit	0.5 m (1.7 ft)
UP4_E0	2.1 m (7.0 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)
UP4_E11	2.1 m (7.0 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.8 m (2.5 ft)	0.5 m (1.7 ft)






Figure A-13. UP3 and UP4 with Positioner, Tables A-20 and A-21 (Sheet 1 of 3)

USE FIG. A FOR UP3/4□AA/BA/CA/DA  
 USE FIG. B FOR UP3/4□AB/BB/CB/DB  
 USE FIG. C FOR UP3/4□C/C1/C1A/C1B/C100/C11/DA/DB  
 USE FIG. D FOR UP3/4□CE/E11



WIRING DIAGRAMS



D6328749  
T00239A

Figure A-13. UP3 and UP4 with Positioner, Tables A-20 and A-21 (Sheet 2 of 3)




Figure A-13. UP3 and UP4 with Positioner, Tables A-20 and A-21 (Sheet 3 of 3)

Table A-22. UP3 and UP4 with Solenoid Valve,  
Figure A-14 (Drawing No. 5328799)

Item	Qty	Part No.	Description
Refer to sheet 1 of Figure A-14.			
1	1	5328740_3	Frame assembly
2	4	197730_1	Cotter pin
3	8	1951569_9	Plug button
4	1	194956_17	Terminal block
5	1	1947271_2	Desig plate
6	8	197743_3	Ty-wrap
7	1	Refer to Tables A-23, 8-1, 8-2 and 8-3	Cylinder assembly
8	1	5328779_1	Arm and shaft assembly
9	1	—	Zn plated roll pin (0.500 dia x 3.500)
10	1	5328735_1	Drive pin
11	2	5328774_1	Roller bearing
12	2	197164_75	Retaining ring
13	2	5328737_1	Retainer plate
14	1	5328789_1	Spring plunger
15	1	5328732_1	Spring keeper
16	1	5328785_1	Spring
17	1	5328733_1	Spring guide
18	1	5328734_1	Cam
19	2	5328754_3	Support panel
20	1	5328747_1	Split nut
21	1	5328736_1	Operator rod
22	1	5328738_1	H wheel shaft
23	1	Refer to Table A-23	Solenoid valve
24	1	Refer to Table A-23	Desig plate
25	1	194956_7	Terminal block
26	2	5328770_1	Clevis pin
27	Refer to Table A-23	1951407_1	Male connector
28	1	5328718_1	Bearing support
29	1	5328771_1	Clevis
30	1	5328800_1	Cover plate
31	6	5313297_1	Washer
32	2	5313299_1	Thrust bearing
33	1	5400313_1	Mounting plate
34	1	1951608_1	Shut off valve
35	1	1951609_1	Bulkhead fitting
36	5	19981_31	Plug button
37	1	197676_1	Ground screw
38	1	197675_1	Washer

## SPARE PARTS

Table A-22. UP3 and UP4 with Solenoid Valve,  
Figure A-14 (Drawing No. 5328799) (continued)

Item	Qty	Part No.	Description
Refer to sheet 1 of Figure A-14.			
39	Refer to Table A-23	4CBI2-B	Male elbow
40	Refer to Table A-23	4-4CBI2-B	Male elbow
41	Refer to Table A-23	4FBI2-B	Male connector
42	Refer to Table A-23	4-4FBI2-B	Male connector
43	1	—	Hex head Zn plated steel cap screw (0.500-13 x 0.625)
44	4	—	Pan head Zn plated steel machine screw (0.136-32 x 1.000)
45	4	—	Pan head Zn plated steel machine screw (0.136-32 x 0.625)
46	2	—	Hex head Zn plated steel cap screw (0.250-20 x 3.000)
47	Refer to Table A-23	—	¼ NPT x 1.250 brass nipple
48	Refer to Table A-23	—	¼ NPT brass street elbow
49	4	—	Hex head Zn plated steel cap screw (0.250-20 x 0.500)
50	2	NBJAC21012	Hex washer head screw (0.250-20)
51	1	—	Semi-fin Zn plated steel heavy hex full nut (0.500-13)
52	2	—	Hex head Zn plated steel cap screw (0.500-13 x 1.500)
53	2	1224-00	Zn plated steel shakeproof lockwasher
54	A/R	6634752_1	Shim, as required
55	1	—	Hex jam nut (1.000-14)
56	1	—	Hex nut (0.750-16)
57	8	SSP-68	Zn plated steel rivet
58	Refer to Table A-23	—	¼ NPT brass elbow
59	Refer to Table A-23	R1021-0022	0.250 OD x 0.040 wall Al tubing with polyethylene jacket
60	1	1963318__	Nameplate
61	1	5328793_1	Sleeve
62	1	5328765_2	Cover gasket
63	Refer to Table A-23	R2041-1594	14 AWG black leadwire
64	1	195273_¼	¼ NPT brass tee
65	Refer to Table A-23	1943825_7	Terminal lug
66	Refer to Table A-23	1941401_2	Solderless terminal
67	1	194879-½	Insulating bushing
68	1	1963478_1	Instruction plate
69	1	—	¼ NPT brass pipe plug
70	3	—	MDP spiral pin (0.188 DIA x 1.000)
71	1	1963503_1	Designation label
72	1	1963503_2	Designation label
73	1	1963503_3	Designation label
74	1	1963503_4	Designation label
75	10	1114-00	Shakeproof int lockwasher
76	8	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
77	91 cm (36 in.)	R9090-0030	Spiral wrap

Table A-22. UP3 and UP4 with Solenoid Valve,  
Figure A-14 (Drawing No. 5328799) (continued)

Item	Qty	Part No.	Description
Refer to sheet 1 of Figure A-14.			
78	Refer to Table A-23	4VBI2-B	45° male elbow
79	Refer to Table A-23	1951408_1	Male elbow
80	Refer to Table A-23	1951406_1	Male connector
81	4	—	Indented hex washer Zn plated steel (0.250-20 x 0.500)
82	4	—	Hex head Zn plated steel cap screw (0.250-20 x 0.750)
83	1	1963353_01	Label, universal, CSA
84	Refer to Table A-23	R9021-0050	0.500 OD x 0.062 wall nylon with polyester tubing
85	Refer to Table A-23	—	( $\frac{3}{8}$ x $\frac{1}{4}$ ) brass reducing bushing
Refer to sheet 2 of Figure A-14.			
1	1	5328792_1	Handle
2	1	198517_2	Handle and ratchet assembly
6 <sup>1</sup>	1	5328759_8	Side cover
7	1	1963339_1	Scale
8	1	5328609_2	Pointer
9 <sup>1</sup>	1	5328759_7	Side cover
10 <sup>1</sup>	1	5329164_2	Top cover assembly
12	1	1962207_1	Style plate
13	1	5328797_1	Operating lever
14	1	5324259_1	Hand/auto nameplate
15	1	198531_1	Woodruff key
16	1	1963339_2	Scale
24	1	NRNHA19016	MDP spiral pin (0.188)
29	4.3 m (14.0 ft)	1951480_1U	Sealing strip
31	1	NAUHA21008	Hex cap screw (0.250-20)
32	1	—	20 x 33 cm (8 x 13 in.) poly bag
33	1	NTJHA11030	Spring lockwasher (0.250)
34	6.3 cm (2.5 in.)	R9410-0025	Vinyl tape

**NOTE:**

1. Older models have plastic covers. To order a plastic side cover, use part nos. 5328759\_2 (Item 9). To order a plastic top cover, use part no. 5328795\_1 (Item 10).




Figure A-14. UP3 and UP4 with Solenoid Valve, Tables A-22 and A-23 (Sheet 1 of 2)




Figure A-14. UP3 and UP4 with Solenoid Valve, Tables A-22 and A-23 (Sheet 2 of 2)

**SPARE PARTS**

Table A-23. UP3 and UP4 Solenoid Valves and Unique Items, Figure A-14

Type	Item 7	Item 23	Rating	Item 24	Items 27, 48, 79	Item 39	Items 40, 47, 58, 85	Items 41, 48
UP3_5	5328775_1	5322137_3	120 VAC	1947271_1	1 req	2 req	Omit	1 req
UP3_6	5328775_1	5322137_2	115/125 VDC	1947271_1	1 req	2 req	Omit	1 req
UP3_8	5328775_1	1951433_1	120 VAC	1947271_6	1 req	2 req	Omit	1 req
UP3_9	5328775_1	1951433_2	115/125 VDC	1947271_6	1 req	2 req	Omit	1 req
UP3_F	5328775_1	5322137_6	220/240 VAC	1947271_1	1 req	2 req	Omit	1 req
UP3_G	5328775_1	1951433_5	220/240 VAC	1947271_6	1 req	2 req	Omit	1 req
UP4_5	5328769_1	1951013_1	120 VAC	1947271_1	2 req	Omit	1 req	Omit
UP4_6	5328769_1	1951013_3	115/125 VDC	1947271_1	2 req	Omit	1 req	Omit
UP4_8	5328769_1	1951135_1	120 VAC	1947271_6	2 req	Omit	1 req	Omit
UP4_9	5328769_1	1951135_2	115/125 VDC	1947271_6	2 req	Omit	1 req	Omit
UP4_F	5328769_1	1951013_2	220/240 VAC	1947271_1	2 req	Omit	1 req	Omit
UP4_G	5328769_1	1951135_4	220/240 VAC	1947271_6	2 req	Omit	1 req	Omit

Type	Item 42	Item 59	Item 63	Items 65, 66	Item 78	Item 80	Item 84
UP3_5	2 req	2.4 m (8.0 ft)	183 cm (72 in.)	2 req	1 req	Omit	Omit
UP3_6	2 req	2.4 m (8.0 ft)	183 cm (72 in.)	2 req	1 req	Omit	Omit
UP3_8	2 req	2.4 m (8.0 ft)	366 cm (144 in.)	4 req	1 req	Omit	Omit
UP3_9	2 req	2.4 m (8.0 ft)	366 cm (144 in.)	4 req	1 req	Omit	Omit
UP3_F	2 req	2.4 m (8.0 ft)	183 cm (72 in.)	2 req	1 req	Omit	Omit
UP3_G	2 req	2.4 m (8.0 ft)	366 cm (144 in.)	4 req	1 req	Omit	Omit
UP4_5	1 req	0.9 m (3.0 ft)	183 cm (72 in.)	2 req	Omit	2 req	1.5 m (5.0 ft)
UP4_6	1 req	0.9 m (3.0 ft)	183 cm (72 in.)	2 req	Omit	2 req	1.5 m (5.0 ft)
UP4_8	1 req	0.9 m (3.0 ft)	366 cm (144 in.)	4 req	Omit	2 req	1.5 m (5.0 ft)
UP4_9	1 req	0.9 m (3.0 ft)	366 cm (144 in.)	4 req	Omit	2 req	1.5 m (5.0 ft)
UP4_F	1 req	0.9 m (3.0 ft)	183 cm (72 in.)	2 req	Omit	2 req	1.5 m (5.0 ft)
UP4_G	1 req	0.9 m (3.0 ft)	366 cm (144 in.)	4 req	Omit	2 req	1.5 m (5.0 ft)

Table A-24. UP3 and UP4 Alarm/Travel Switch Kit, Figures A-15 and A-30 (Kit No. 5328787\_1)

Item	Qty	Part No.	Description
1	1	5328786_1	Wiring harness
2	1	5328698_1	Alarm unit
4	1	1942978_2	Spacer
5	1	5312449_13	Connecting link
6	1	5328596_2	Arm
7	1	1963318__	Nameplate
8	3	—	Hex head Zn plated steel sems ext (0.190-32 x 0.500)
11	2	1210-00	Zn plated steel shakeproof lockwasher
12	2	—	Hex head Zn plated steel machine screw (0.190-32 x 0.750)
13	1	—	Hex socket head Zn plated steel cap screw (0.138-32 x 0.500)




Figure A-15. UP3 and UP4 with Electric Shaft Position Transmitter and/or Alarm/Travel Switches, Tables A-24, A-25, A-48 and A-49

Table A-25. UP3 and UP4 Electric Shaft Position Transmitter Kit, Figures A-15 and A-30 (Kit No. 5328787\_2)

Item	Qty	Part No.	Description
1	1	5328786_1	Wiring harness
2	1	5328698_2	Electric shaft position transmitter
3	6	1943785_3	Cable tie
4	1	1942978_2	Spacer
5	1	5312449_13	Connecting link
6	1	5328596_2	Arm
7	1	1963318_	Nameplate
8	3	—	Hex head Zn plated steel sems ext (0.190-32 x 0.500)
9	93 cm (37 in.)	R2041-1582	22 AWG white/violet leadwire
10	93 cm (37 in.)	R2041-1583	22 AWG white/gray leadwire
11	2	1210-00	Zn plated steel shakeproof lockwasher

## SPARE PARTS

Table A-25. UP3 and UP4 Electric Shaft Position Transmitter Kit,  
Figures A-15 and A-30 (Kit No. 5328787\_2) (continued)

Item	Qty	Part No.	Description
12	2	—	Hex head Zn plated steel machine screw (0.190-32 x 0.750)
13	1	—	Hex socket head Zn plated steel cap screw (0.138-32 x 0.500)
15	4	1943825_1	Terminal lug
17	122 cm (48 in.)	R9090-0030	Spiral wrapping

Table A-26. UP3 and UP4 Pneumatic Shaft Position Transmitter Kits,  
Figure A-16 (Kit Nos. 5328798\_315/327)

Item	Qty	Part No.	Description
1	1	5329089_1	Clevis pin
2	1	5312449_10	Connecting link
3	1	5329090_1	Drive lever
4	1	197120_5	Elastic stop nut
5	1	AV112000	Shaft position transmitter for kit no. 5328798_315
		AV122000	Shaft position transmitter for kit no. 5328798_327
8	1	5329144_1	Mounting plate
10	2	—	Zn plated steel cotter pin (0.063 dia x 0.375)
13	1	1963318__	Nameplate
14	1	—	Brass hex head pipe plug (1/4-18 NPT)
22	1	5329091_1	Pointer
23	1	FORM MP290	Warning tag
24	1	1945750_1	Pull plug
25	1	5400307_1	Airline connector assembly
26	1	195167_4	1/4-18 male connector
27	1	195171_3	1/4-18 male run tee
28	3	NTMHA21000	Int shakeproof lockwasher (0.250)
29	3	NBAHA21016	Hex socket head screw (0.250-20)
30	3	NBJAU21010	Hex wshr head screw (0.250-20)
31	4	NNBHA21000	Hex keps nut (0.250-20)
32	1	NBPAC16014	Slotted hex head screw (0.190-32)




Figure A-16. UP3 and UP4 with Pneumatic Shaft Position Transmitter, Table A-26

Table A-27. UP3 Air Failure Lock Kits, Figure A-17 (Kit Nos. 5328781\_1/2)

Item	Qty	Part No.	Description
1	1	1951607_1	Trip valve
2	1	1941099_2	Pressure switch
3	1	1951606_1	3-way valve
4	1	1941147_1	½ molded bushing
5	1	1951608_1	Shutoff valve for UP3 with positioner (kit no. 5328781_1)
	Omit	—	Omit for UP3 with solenoid valve (kit no. 5328781_2)
6	1	5328782_1	Air failure lock harness
7	1	1951589_1	Air valve
8	1	5328788_1	Mounting bracket
9	1	4-4FBI2-B	Male connector
10	8	4-4CBI2-B	Male elbow
11	2	4-4-4RBI2-B	Male run tee
12	1	—	Brass tee (¼ NPT)

## SPARE PARTS

Table A-27. UP3 Air Failure Lock Kits,  
Figure A-17 (Kit Nos. 5328781\_1/2) (continued)

Item	Qty	Part No.	Description
13	6	4CBI2-B	Male elbow
14	1	1951609_1	Bulkhead fitting
15	1	5328674_1	Valve mounting bracket
16	1	1963318__	Nameplate
17	4 m (13 ft)	R1021-0022	0.250 OD x 0.040 wall tubing
18	1	—	Brass street elbow (¼ NPT)
19	1	5327327_3	Adaptor
20	2	—	Pan head Zn plated steel machine screw (0.190-24 x 0.875)
21	9	—	Hex head Zn plated steel cap screw (0.250-20 x 0.875)
22	1	—	Hex head Zn plated steel cap screw (0.250-20 x 4.000)
23	10	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
24	2	1210-00	Zn plated steel shakeproof lockwasher
25	2	—	Brass pipe plug (¼ NPT)
26	1	—	Close brass nipple (¼ NPT)
27	1	I-P81-20	Instruction
28	1	—	Cotton drawstring bag
29	1	5328781	Print
30	1	No. 100	Carton
31	2	—	Brass reducing bushing (¼ x ⅛)
32	1	—	Brass pipe plug (⅛ NPT)
33	1	3053306	Print




Figure A-17. UP3 with Air Failure Lock, Table A-27

## SPARE PARTS

Table A-28. UP4 Air Failure Lock Kits, Figure A-18 (Kit Nos. 5328781\_3/4)

Item	Qty	Part No.	Description
1	1	1951607_1	Trip valve
2	1	1941099_2	Pressure switch
3	1	1951606_1	3-way valve
4	1	1941147_1	½ molded bushing
5	1	5328781_3	Shutoff valve for UP4 with positioner (kit no. 5328781_3)
	Omit	—	Omit for UP4 with solenoid valve (kit no. 5328781_4)
6	1	5328782_1	Air failure lock harness
7	1	1951589_1	Air valve
8	1	5328788_1	Mounting bracket
9	1	4-4FB12-B	Male connector
10	8	4-4CB12-B	Male elbow
11	2	4-4-4RB12-B	Male run tee
12	1	—	Brass tee (¼ NPT)
13	4	1951408_1	Male elbow
14	1	1951609_1	Bulkhead fitting
15	1	5328674_1	Valve mounting bracket
16	1	1963318_	Nameplate
17	0.9 m (3 ft)	R1021-0022	0.250 OD x 0.040 wall tubing
18	4	1951407_1	Male connector
19	1	5327327_3	Adaptor
20	2	—	Pan head Zn plated steel machine screw (0.190-24 x 0.875)
21	9	—	Hex head Zn plated steel cap screw (0.250-20 x 0.875)
22	1	—	Hex head Zn plated steel cap screw (0.250-20 x 4.000)
23	10	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
24	2	1210-00	Zn plated steel shakeproof lockwasher
25	2	—	Brass pipe plug (¼ NPT)
26	2	—	Close brass nipple (¼ NPT)
27	1	I-P81-20	Instruction
28	1	—	Cotton drawstring bag
29	1	5328781	Print
30	1	No. 100	Carton
31	4	—	¼ NPT brass street elbow
32	1	—	Brass pipe plug ( ⅛ NPT)
33	1	3053306	Print
34	3	—	¼ NPT brass elbow
35	1	—	¼ NPT x 1.250 long brass nipple
36	2.9 m (9.5 ft)	R9021-0050	0.500 OD x 0.062 wall polyester reinforced nylon tubing
37	1	—	¼ NPT x 2.000 long brass nipple
38	1	—	¼ NPT x 1.500 long brass nipple




Figure A-18. UP4 with Air Failure Lock, Table A-28

## SPARE PARTS

Table A-29. UP3 Reserve Air Tank Kits, Figure A-19 (Kit Nos. 5328781\_31/32)

Item	Qty	Part No.	Description
1	1	1951712_1	Check valve
2	1	1941099_2	Pressure switch
3	2	1951606_1	3-way pneumatic valve
4	1	1941147_1	½ molded bushing
5	1	1951608_1	Shut-off valve for UP3 with positioner (kit no. 5328787_31)
	Omit	—	Omit for UP3 with solenoid valve (kit no. 5328787_32)
6	1	5328782_1	Air failure lock harness
8	2	5328788_1	Mounting bracket
9	6	4-4FB12-B	Male connector
10	9	4-4CB12-B	Male elbow
11	2	4-4-4SB12-B	Male branch tee
12	2	—	¼ NPT brass tee
13	4	4CB12-B	Male elbow
14	4	1951609_1	Bulkhead fitting
15	1	5328674_1	Valve mounting bracket
16	1	1963318_	Universal nameplate
17	4 m (13 ft)	R1021-0022	0.250 OD x 0.040 wall Al tubing with black poly jacket
20	4	NBZAC17014	Pan head screw (0.190-24)
21	10	NAUAC21016	Hex cap screw (0.250-20)
22	10	NTCAC11000	Flat washer (0.250)
23	10	NNBAC21000	Hex keps nut (0.250-20)
24	4	NTMAC19000	Int sems lockwasher (0.190)
33	1	C3053544-Sh 1	Print
34	2	—	¼ NPT brass elbow
35	2	—	¼ NPT x 1.250 long brass nipple
39	4	1941817_1	Conduit gasket
40	1	1963489_4	Designation plate
41	1	1951785_8	30.3 liter (8.0 gallon) air tank assembly (Fig. B-12)
42	1	1963478_1	Shut-off valve for UP3 with positioner (kit no. 5328787_31)
	Omit	—	Omit for UP3 with solenoid valve (kit no. 5328787_32)

### TYPES UP5 AND UP6 ACTUATORS

Refer to Tables A-34 through A-49, and Figures A-22 through A-30 for spare parts information for Types UP5 and UP6 actuators.




Figure A-19. UP3 with Reserve Air Tank, Table A-29

Table A-30. UP4 Reserve Air Tank Kits, Figure A-20 (Kit Nos. 5328781\_41/42)

Item	Qty	Part No.	Description
1	1	1951712_1	Check valve
2	1	1941099_2	Pressure switch
3	2	1951606_1	3-way pneumatic valve
4	1	1941147_1	½ molded bushing
5	1	1951608_1	Shut-off valve for UP4 with positioner (kit no. 5328787_41)
	Omit	—	Omit for UP4 with solenoid valve (kit no. 5328787_42)
6	1	5328782_1	Air failure lock harness
8	2	5328788_1	Mounting bracket
9	1	4-4FB12-B	Male connector
10	4	4-4CB12-B	Male elbow
11	2	4-4-4SB12-B	Male branch tee
12	2	—	¼ NPT brass tee
13	7	1951408_1	Male elbow
14	4	1951609_1	Bulkhead fitting
15	1	5328674_1	Valve mounting bracket
16	1	1963318_	Universal nameplate

## SPARE PARTS

Table A-30. UP4 Reserve Air Tank Kits, Figure A-20 (Kit Nos. 5328781\_41/42) (continued)

Item	Qty	Part No.	Description
17	0.9 m (3.0 ft)	R1021-0022	0.250 OD X 0.040 wall Al tubing with black poly jacket
18	7	1951407_1	Male connector
20	4	NBZAC17014	Pan head screw (0.190-24)
21	10	NAUAC21016	Hex cap screw (0.250-20)
22	10	NTCAC11000	Flat washer (0.250)
23	10	NNBAC21000	Hex keps nut (0.250-20)
24	4	NTMAC19000	Int sems lockwasher (0.190)
31	1	—	¼ NPT brass street elbow
33	1	C3053544-Sh 1	Print
34	1	—	¼ NPT brass elbow
35	2	—	¼ NPT X 1.250L brass nipple
36	3.1 m (10.0 ft)	R9021-0050	0.500 OD X 0.062 wall poly reinforced black nylon tubing
38	1	—	¼ NPT X 1.500L brass nipple
39	4	1941817_1	Conduit gasket
40	1	1963489_4	Designation plate
41	1	1951785_8	30.0 liter (8.0 gallon) air tank assembly (Fig. B-12)
42	1	1963478_1	Shut-off valve for UP3 with positioner (kit no. 5328787_31)
	Omit	—	Omit for UP3 with solenoid valve (kit no. 5328787_32)




Figure A-20. UP4 with Reserve Air Tank, Table A-30

Table A-31. UP3 and UP4 Heater Kits, Figure A-21  
(Kit Nos. 5328784\_1/2)

Item	Qty	Part No.	Description
1	6	1943825_11	Stud terminal
2	2	1943825_8	Stud terminal
3	3	195586_1	Plastic clamp
4	2	1941401_2	Solderless terminal
5	10	1943785_3	Cable tie
7	1	662460_1	Thermoswitch
8	1	195105_10	Tube clamp
9	2.9 m (9.5 ft)	5318366_1U	Fiberglass insulation
10	2	197118_2	Conduit connector
11	4	19934_87	Spacer
12	2	1943002_1	Strip heater for 120 VAC operation
		1943002_2	Strip heater for 240 VAC operation
13	1	1963318_	Nameplate
16	4.6 m (15.0 ft)	R2049-0100	14 AWG natural leadwire

# SPARE PARTS

Table A-31. UP3 and UP4 Heater Kits, Figure A-21  
(Kit Nos. 5328784\_1/2) (continued)

Item	Qty	Part No.	Description
17	4	—	Pan head Zn plated steel sems int (0.190-32 x 0.375)
18	4	NTKAC19000	Shakeproof lockwasher (0.190)
21	4	NBZAC16016	0.190-32 pan head screw
22	2.1 m (7.0 ft)	R9090-0030	Spiral wrapping
24	1	5328784	Print
25	1	No. 17	Carton




Figure A-21. UP3 and UP4 with Heater, Table A-31

Table A-32. UP3 Cylinder Spare Parts Kit, Figure 8-2 (Kit No. 258240\_1)

Qty	Part No.	Description	Qty	Part No.	Description
2	1951416_256	O-ring	1	1951401_1	Wiper ring
1	5328773_1	Piston	A/R	199354_1	Lubricant
1	195825_15	O-ring	1	No. 62A	Carton
1	1951399_214	O-ring	1	258240	Print
1	1951416_218	O-ring			

Table A-33. UP4 Cylinder Spare Parts Kit, Figure 8-3 (Part No. 258241\_1)

Qty	Part No.	Description	Qty	Part No.	Description
2	5311428_41	O-ring	1	195852_1	Wiper ring
1	195825_9	O-ring	1	5311428_24	O-ring
1	5328768_15	Piston	A/R	199354_1	Lubricant
1	1951359_220	O-ring	1	No. 39	Carton
2	195851_1	Back up ring	1	258241	Print

Table A-34. UP5 and UP6 Positioner, Figure A-22 (Drawing No. 5328960)

Item	Qty	Part No.	Description
1	1	6631317_1	Operating lever
2	1	5328953_2	Gear carrier
3	1	1963318_	Nameplate
4	Refer to Table A-35	19981_31	Plug button
5	1	5328877_1	Frame
6	2	5328890_1	Support panel
7	1	1951612_1	½ bulkhead fitting
8	2	1951408_1	Elbow
9	1	194956_8	Terminal block
10	Refer to Table A-35	1947578_3	Desig plate
11	1	5328905_2	Bottom side cover
12	8	197743_3	Ty-wrap
14	1	1951611_4	Shaft seal
15	1	197120_22	Elastic stop nut
16	1	198517_2	Ratchet assembly
17	1	5325349_1	Clutch lever
18	1	1951611_3	Shaft seal
20	1	5328930_1	Pointer
21	1	5328934_2	Drive shaft
22	1	5328967_2	Top side cover
23	Refer to Table A-35	R2041-0030	18 AWG white leadwire
24 <sup>1</sup>	1	5329162_1	Top cover assembly
25	1	5329067_1	Stop plate
26	1	5329010_1	Roller chain

## SPARE PARTS

Table A-34. UP5 and UP6 Positioner, Figure A-22 (Drawing No. 5328960) (continued)

Item	Qty	Part No.	Description
28	1	5324693_2	Bushing
29	1	5328956_2	Chain sector
30	2	197754_1	Retaining ring
31	1	197164_275	Retaining ring
32	2	193221_1	Bearing
33	2	197105_4	Alemite fitting
34	1	198512_2	Key
35	1	1963488_1	Scale
36	1	5329008_1	Chain anchor
37	4	197730_1	Cotter pin
38	1	5311459_1	Valve handle
41	1	5329059_1	Top side cover
42	1	Refer to Tables A-35, 8-3, 8-4 and Figures 8-4 and 8-5	Cylinder
43	1	1947271_2	Desig plate
44	1	194956_17	Terminal block
45	1	197676_1	Ground screw
46	1	197675_1	Washer
47	4	5328949_1	Bolt plate
48	3	1951569_5	Button plug
49	2	5328889_1	Clevis pin
50	1	1963489_2	Desig plate
51	1	1963489_1	Desig plate
52	1	1951569_4	Button plug
53	1	5329083_1	Shaft extension
54	2	—	Pan head Zn plated steel sems ext (0.190-32 x 0.438)
55	2	5328436_1	Cap screw
56	1	198531_1	Woodruff key
57	1	5328892_1	Instruction plate
58	1	5328765_2	Gasket
59	2	19934_135	Spacer
60	1	Refer to Table A-35	Positioner
61	4	—	Hex head Zn plated steel cap screw (0.625-11 x 2.750)
62	4	—	Semi-fin steel reg hex full nut (0.625-11)
63	4	—	Zn plated steel reg spring lockwasher (0.625)
64	21	—	Hex head Zn plated steel cap screw (0.250-20 x 0.500)
65	20	—	Indented hex washer, Zn plated steel threaded cutting screw (0.250-20 x 0.500)
66	8	—	Pan head Zn plated steel machine screw (0.138-32 x 1.000)
67	8	SSP-68	Zn plated steel rivet

Table A-34. UP5 and UP6 Positioner, Figure A-22 (Drawing No. 5328960) (continued)

<b>Item</b>	<b>Qty</b>	<b>Part No.</b>	<b>Description</b>
68	1	—	Zn plated steel roll pin (0.125 x 0.750)
69	4	—	Plain Zn plated steel washer (0.812 x 1.469 x 0.134)
70	1	—	Zn plated steel type 1 groove pin (0.250 dia x 1.250)
71	1	—	Pan head Zn plated steel machine screw (0.164-32 x 0.625)
73	2	—	$\frac{3}{8}$ -18 NPT pipe plug
74	1	—	Hex socket head steel cap screw (0.625-11 x 3.500)
75	1	—	Soc hex hdls Zn plated steel set screw (0.190-32 x 0.312)
76	1	4808-09-01-4102	Stainless steel shakeproof lockwasher
77	1	—	Zn plated steel washer (0.188 x 0.433 x 0.049)
78	2	8OB12-B	Female branch tee
79	Refer to Table A-35	8-8CB12-B	Elbow
80	Refer to Table A-35	5323705_1	Elbow




Figure A-22. UP5 and UP6 with Positioner, Tables A-34 and A-35 (Sheet 1 of 2)




Figure A-22. UP5 and UP6 with Positioner, Tables A-34 and A-35 (Sheet 2 of 2)

## SPARE PARTS

Table A-34. UP5 and UP6 Positioner, Figure A-22  
(Drawing No. 5328960) (continued)

Item	Qty	Part No.	Description
81	Refer to Table A-35	4-4FBI2-B	Male connector
82	Refer to Table A-35	1951609_1	Bulkhead fitting
83	Refer to Table A-35	4CBI2-B	Elbow
84	1	5328905_1	Bottom side cover
85	1	1951407_1	Male connector
86	1	5328957_1	Positioner drive rod
87	2	5311759_1	Ball joint
88	1	5328968_1	Stud
89	Refer to Table A-35	—	Brass coupling ( $\frac{3}{8}$ )
90	Refer to Table A-35	—	Brass close nipple ( $\frac{3}{8}$ )
91	Refer to Table A-35	1943825_1	Terminal lug
92	Refer to Table A-35	R2041-0010	18 AWG black leadwire
93	183 cm (72 in.)	R9021-0050	0.500 OD nylon tubing
94	Refer to Table A-35	R1021-0022	0.250 OD x 0.040 wall Al tubing
96	4	—	Zn plated steel spring lockwasher (0.750)
97	1	5328902_1	Crank arm
98	1	1963488_2	Scale
99	1	—	Poly bag
100	Refer to Table A-35	1943825_3	Terminal lug
101	21	1114-00	Zn plated steel shakeproof int lockwasher
102	Refer to Table A-35	1947578_4	Desig plate
103	8	1206-00	Zn plated steel shakeproof int lockwasher
104	10.4 m (34.0 ft)	1951480_1U	Sealing strip
109	1	1963353__	Label, universal, CSA

**NOTE:**

1. Older models have plastic top covers. To order a plastic top cover, use Part No. 5329053\_1.

Table A-35. UP5 and UP6 Positioners and Unique Items, Figure A-22

Type	Item 4	Item 10	Item 23	Item 42	Item 60	Item 79	Item 80	Item 81
UP5_A	7 req	1 req	Omit	5328952_1	AV1121_0	1 req	2 req	1 req
UP5_B	7 req	1 req	Omit	5328952_1	AV1221_0	1 req	2 req	1 req
UP5_C	8 req	1 req	46 cm (18 in.)	5328952_1	AV2321_0	1 req	2 req	Omit
UP5_D	8 req	1 req	46 cm (18 in.)	5328952_1	AV3321_0	1 req	2 req	Omit
UP5_E	8 req	Omit	91 cm (36 in.)	5328952_1	AV442100	1 req	2 req	Omit
UP6_A	7 req	1 req	Omit	5328945_1	AV1121_0	3 req	Omit	1 req
UP6_B	7 req	1 req	Omit	5328945_1	AV1221_0	3 req	Omit	1 req
UP6_C	8 req	1 req	46 cm (18 in.)	5328945_1	AV2321_0	3 req	Omit	Omit
UP6_D	8 req	1 req	46 cm (18 in.)	5328945_1	AV3321_0	3 req	Omit	Omit
UP6_E	8 req	Omit	91 cm (36 in.)	5328945_1	AV442100	3 req	Omit	Omit

Table A-35. UP5 and UP6 Positioners and Unique Items, Figure A-22 (continued)

Type	Item 82	Item 83	Items 89,90	Item 91	Item 92	Item 94	Item 100	Item 102
UP5_A	1 req	1 req	1 req	Omit	Omit	38 cm (15 in.)	Omit	Omit
UP5_B	1 req	1 req	1 req	Omit	Omit	38 cm (15 in.)	Omit	Omit
UP5_C	Omit	Omit	1 req	4 req	46 cm (18 in.)	Omit	Omit	Omit
UP5_D	Omit	Omit	1 req	4 req	46 cm (18 in.)	Omit	Omit	Omit
UP5_E	Omit	Omit	1 req	5 req	137 cm (54 in.)	Omit	5 req	1 req
UP6_A	1 req	1 req	Omit	Omit	Omit	38 cm (15 in.)	Omit	Omit
UP6_B	1 req	1 req	Omit	Omit	Omit	38 cm (15 in.)	Omit	Omit
UP6_C	Omit	Omit	Omit	4 req	46 cm (18 in.)	Omit	Omit	Omit
UP6_D	Omit	Omit	Omit	4 req	46 cm (18 in.)	Omit	Omit	Omit
UP6_E	Omit	Omit	Omit	5 req	137 cm (54 in.)	Omit	5 req	1 req

Table A-36. UP5 and UP6 with Solenoid Valve, Figure A-23 (Drawing No. 5328961)

Item	Qty	Part No.	Description
1	1	6631317_1	Operating lever
2	1	5328953_2	Gear carrier
3	1	1963318__	Nameplate
4	8	19981_31	Plug button
5	1	5328877_1	Frame
6	2	5328890_1	Support panel
7	1	1951612_1	½ bulkhead fitting
8	Refer to Table A-37	8-8CB12-B	Elbow
9	1	194956_8	Terminal block
10	1	Refer to Table A-37	Desig plate
11	2	5328905_1	Bottom side cover
12	8	197743_3	Ty-wrap
14	1	1951611_4	Shaft seal
15	1	197120_22	Elastic stop nut
16	1	198517_2	Ratchet assembly
17	1	5325349_1	Clutch lever
18	1	1951611_3	Shaft seal
20	1	5328930_1	Pointer
21	1	5328934_2	Drive shaft
22	1	5328967_2	Top side cover
23	1	1963478_1	Instruction plate
24 <sup>1</sup>	1	5329162_1	Top cover assembly
26	1	5329010_1	Roller chain
28	1	5324693_2	Bushing
29	1	5328956_2	Chain sector
30	2	197754_1	Retaining ring

## SPARE PARTS

Table A-36. UP5 and UP6 with Solenoid Valve,  
Figure A-23 (Drawing No. 5328961) (continued)

Item	Qty	Part No.	Description
31	1	197164_275	Retaining ring
32	2	193221_1	Bearing
33	2	197105_4	Alemite fitting
34	1	198512_2	Key
35	1	1963488_1	Scale
36	1	5329008_1	Chain anchor
37	4	197730_1	Cotter pin
41	1	5329059_1	Top side cover
42	1	Refer to Tables A-37, 8-3, 8-4 and Figures 8-4 and 8-5	Cylinder
43	1	1947271_2	Desig plate
44	1	194956_17	Terminal block
45	1	197676_1	Ground screw
46	1	197675_1	Washer
47	4	5328949_1	Bolt plate
48	2	1951569_5	Button plug
49	2	5328889_1	Clevis pin
50	1	1963489_2	Desig plate
51	1	1963489_1	Desig plate
52	1	1951608_1	Shut off valve
53	Refer to Table A-37	1943825_8	Terminal lug
54		1941401_2	Solderless terminal
55	2	5328436_1	Cap screw
56	1	198531_1	Woodruff key
57	1	Refer to Table A-37	Solenoid valve
58	Refer to Table A-37	5323705_1	Elbow
59	1	5328435_1	Mounting plate
60	140 cm (55 in.)	R9021-0050	0.500 OD nylon tubing
61	4	—	Hex head Zn plated steel cap screw (0.625-11 x 2.750)
62	4	—	Semi-fin steel reg hex full nut (0.625-11)
63	4	—	Zn plated steel reg spring lockwasher (0.625)
64	17	—	Hex head Zn plated steel cap screw (0.250-20 x 0.500)
65	20	—	Indented hex washer, Zn plated steel threaded cutting screw (0.250-20 x 0.500)
66	8	—	Pan head Zn plated steel machine screw (0.138-32 x 1.000)
67	8	SSP-68	Zn plated steel rivet
68	152 cm (60 in.)	R1021-0022	0.250 OD Al tubing
69	4	—	Plain Zn plated steel washer (0.812 x 1.469 x 0.134)

Table A-36. UP5 and UP6 with Solenoid Valve, Figure A-23 (Drawing No. 5328961) (continued)

Item	Qty	Part No.	Description
70	1	—	Zn plated steel type 1 groove pin (0.250 dia x 1.250)
71	2	—	Zn plated steel reg spring lockwasher (0.750)
73	Refer to Table A-37	—	$\frac{3}{8}$ NPT brass coupling
74	1	—	Hex socket head steel cap screw (0.625-11 x 3.500)
75	1	—	Soc hex hdls Zn plated steel set screw (0.190-32 x 0.312)
76	91 cm (36 in.)	R2041-1594	14 AWG black leadwire
77	6	—	Pan head Zn plated steel machine screw (0.250-20 x 0.750)
78	6	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
79	Refer to Table A-37	488907_9	Grommet
80	2	4-4FB12-B	Male connector
81	Refer to Table A-37	—	Brass close nipple ( $\frac{3}{8}$ )
82	2	8-4OB12-B	Female branch tee
83	1	5328902_1	Crank arm
84	1	1963488_2	Scale
85	1	—	8 x 13 poly bag
86	17	1214-00	Zn plated steel shakeproof int lockwasher
87	8	1206-00	Zn plated steel shakeproof int lockwasher
88	9.5 m (34.0 ft)	1951480_1U	Sealing strip
91	1	1963353_01	Label, universal, CSA

**NOTE:**

1. Older models have plastic top covers. To order a plastic top cover, use Part No. 5329053\_1.

Table A-37. UP5 and UP6 Solenoid Valves and Unique Items, Figure A-23

Type	Voltage	Item 8	Item 10	Item 42	Items 53, 54	Item 57	Item 58	Item 73	Item 79	Item 81
UP5_5	120 VAC	1 req	1947578_1	5328952_1	2 req	1951013_1	5 req	1 req	1 req	1 req
UP5_6	115/125 VDC	1 req	1947578_1	5328952_1	2 req	1951013_3	5 req	1 req	1 req	1 req
UP5_8	120 VAC	1 req	1947711_1	5328952_1	4 req	1951135_1	5 req	1 req	2 req	1 req
UP5_9	115/125 VDC	1 req	1947711_1	5328952_1	4 req	1951135_2	5 req	1 req	2 req	1 req
UP5_F	220/240 VAC	1 req	1947578_1	5328952_1	2 req	1951013_2	5 req	1 req	1 req	1 req
UP5_G	220/240 VAC	1 req	1947711_1	5328952_1	4 req	1951135_4	5 req	1 req	2 req	1 req
UP6_5	120 VAC	3 req	1947578_1	5328945_1	2 req	1951013_1	3 req	Omit	1 req	Omit
UP6_6	115/125 VDC	3 req	1947578_1	5328945_1	2 req	1951013_3	3 req	Omit	1 req	Omit
UP6_8	120 VAC	3 req	1947711_1	5328945_1	4 req	1951135_1	3 req	Omit	2 req	Omit
UP6_9	115/125 VDC	3 req	1947711_1	5328945_1	4 req	1951135_2	3 req	Omit	2 req	Omit
UP6_F	220/240 VAC	3 req	1947578_1	5328945_1	2 req	1951013_2	3 req	Omit	1 req	Omit
UP6_G	220/240 VAC	3 req	1947711_1	5328945_1	4 req	1951135_4	3 req	Omit	2 req	Omit

**SPARE PARTS**




Figure A-23. UP5 and UP6 with Solenoid Valve, Tables A-36 and A-37 (Sheet 1 of 2)




Figure A-23. UP5 and UP6 with Solenoid Valve, Tables A-36 and A-37 (Sheet 2 of 2)

## SPARE PARTS

Table A-38. UP5 and UP6 Alarm/Travel Switch Kit, Figure A-24 (Kit No. 5328962\_1)

Item	Qty	Part No.	Description
1	1	19934_208	Spacer
2	2	—	Pan head Zn plated steel machine screw (0.190-32 x 1.000)
3	1	5328596_2	Arm
4	1	5312449_12	Connecting link
6	1	5328698_1	Alarm unit
7	1	—	Steel dowel pin (0.375 x 1.500)
8	1	5328924_1	Coupler
12	3	—	Hex head Zn plated steel sems ext (0.190-32 x 0.500)
13	2	—	Hex socket hdl's Zn plated steel cup pt set screw (0.190-32 x 0.312)
14	1	—	Hex socket head Zn plated steel cap screw (0.138-32 x 0.500)
15	1	5328933_1	Wiring harness
16	2	1210-00	Zn plated steel shakeproof int lockwasher
17	1	1963318_	Nameplate
18	1	No. 20	Carton
19	1	5328962	Print

Table A-39. UP5 and UP6 Electric Shaft Position Transmitter Kit, Figure A-24 (Kit No. 5328962\_2)

Item	Qty	Part No.	Description
1	1	19934_208	Spacer
2	2	—	Pan head Zn plated steel machine screw (0.190-32 x 1.000)
3	1	5328596_2	Arm
4	1	5312449_12	Connecting link
6	1	5328698_2	Electric shaft position transmitter
7	1	—	Steel dowel pin (0.375 x 1.500)
8	1	5328924_1	Coupler
9	4	1943825_1	Stud terminal
10	1.5 m (5.0 ft)	R2041-1583	22 AWG white/gray leadwire
11	1.5 m (5.0 ft)	R2041-1582	22 AWG white/violet leadwire
12	3	—	Hex head Zn plated steel sems ext (0.190-32 x 0.500)
13	2	—	Hex socket hdl's Zn plated steel cup pt set screw (0.190-32 x 0.312)
14	1	—	Hex socket head Zn plated steel cap screw (0.138-32 x 0.500)
15	1	5328933_1	Wiring harness
16	2	1210-00	Zn plated steel shakeproof int lockwasher
17	1	1963318_	Nameplate
18	1	No. 20	Carton
19	1	5328962	Print





Figure A-24. UP5 and UP6 with Electric Shaft Position Transmitter and/or Alarm/Travel Switches, Tables A-38, A-39, A-48 and A-49 (Sheet 1 of 2)




D6328962  
T00255A

Figure A-24. UP5 and UP6 with Electric Shaft Position Transmitter and/or Alarm/Travel Switches, Tables A-38, A-39, A-48 and A-49 (Sheet 2 of 2)


Table A-40. UP5 and UP6 Pneumatic Shaft Position Transmitter Kit, Figure A-25(Kit No. 5328963\_1)

Item	Qty	Part No.	Description
1	2	1951609_1	Bulkhead fitting
2	2	5311759_1	Ball joint
3	1	5328958_1	Transmitter drive rod
4	4	1114-00	Zn plated steel shakeproof lockwasher
5	4	—	Pan head Zn plated steel cap screw (0.250-20 x 0.500)
6	3	4-4CBI2-B	Male elbow
7	1	4-4FBI2-B	Male connector
8	1	4-4-4RBI2-B	Male run tee
9	122 cm (4 ft)	R1021-0022	0.250 OD x 0.040 wall Al tubing
10	1	FORM MP290	Warning tag
11	1	—	¼-18 NPT brass pipe plug
12	1	197120_5	Elastic stop nut
13	1	AV1_2000	Positioner assembly
14	1	1963318__	Nameplate
16	1	No. 24	Carton
17	1	5328963	Print
18	2	—	Ext lockwasher Zn plated steel hex keps (0.250-28)
19	1	1210-00	Zn plated steel shakeproof lockwasher



D5328963  
T00342A

Figure A-25. UP5 and UP6 with Pneumatic Shaft Position Transmitter, Table A-40 (Sheet 1 of 2)



D5328963  
T00343A

Figure 25. UP5 and UP6 with Pneumatic Shaft Position Transmitter, Table A-40 (Sheet 2 of 2)

## SPARE PARTS

Table A-41. UP5 and UP6 with Positioner Air Failure Lock Kit, Figure A-26 (Kit No. 5328964\_1)

Item	Qty	Part No.	Description
1	1	1941099_2	Pressure switch
2	1	1941147_1	½ molded bushing
3	1	1951608_1	Shutoff valve
4	1	5328959_1	Valve mounting bracket
5	3	5318451_2	3-way pneumatic valve
6	1	1963478_1	Instruction plate
7	1	1951609_1	Bulkhead fitting
8	1	5328782_2	Air failure lock harness
9	1	1951589_1	Air valve
10	1	1963318__	Nameplate
11	1	—	¼ NPT brass tee
12	1	—	Brass reducing bushing (½ x ¼)
13	2	4-4CBI2-B	Male elbow
14	4	1951407_1	Male connector
15	2	8-8CBI2-B	Male elbow
16	4	4-4-4SBI2-B	Male branch tee
17	1	—	¼ NPT brass close nipple
18	2	—	Brass reducing bushing (⅜ x ¼)
19	4	4-4FBI2-B	Male connector
20	4.3 m (14.0 ft)	R9021-0050	½ OD nylon tubing
21	4.3 m (14.0 ft)	R1021-0022	0.250 OD x 0.040 wall Al tubing
22	10	—	Hex head Zn plated steel cap screw (0.250-20 x 1.000)
23	10	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
24	3	—	½ std brass pipe plug
25	1	—	Cotton draw string bag
26	1	No. 100	Carton
27	1	5328964	Print
28	6	—	Plain Zn plated steel washer (0.312 x 0.734 x 0.065)
29	1	—	⅛ brass pipe plug
30	1	3053306	Print

Table A-42. UP5 and UP6 with Solenoid Valve Air  
Failure Lock Kit, Figure A-26  
(Kit No. 5328964\_2)

Item	Qty	Part No.	Description
1	1	1941099_2	Pressure switch
2	1	1941147_1	½ molded bushing
4	1	5328959_1	Valve mounting bracket
5	3	5318451_2	3-way pneumatic valve
6	1	1963478_1	Instruction plate
7	1	1951609_1	Bulkhead fitting
8	1	5328782_2	Air failure lock harness
9	1	1951589_1	Air valve
10	1	1963318__	Nameplate
11	1	—	¼ NPT brass tee
12	1	—	Brass reducing bushing (½ x ¼)
13	2	4-4CBI2-B	Male elbow
14	4	1951407_1	Male connector
15	2	8-8CBI2-B	Male elbow
16	4	4-4-4SBI2-B	Male branch tee
17	1	—	¼ NPT brass close nipple
18	2	—	Brass reducing bushing (⅜ x ¼)
19	4	4-4FBI2-B	Male connector
20	4.3 m (14.0 ft)	R9021-0050	½ OD nylon tubing
21	4.3 m (14.0 ft)	R1021-0022	0.250 OD x 0.040 wall Al tubing
22	10	—	Hex head Zn plated steel cap screw (0.250-20 x 1.000)
23	10	—	Ext lockwasher Zn plated steel hex keps (0.250-20)
24	3	—	½ std brass pipe plug
25	1	—	Cotton draw string bag
26	1	No. 100	Carton
27	1	5328964	Print
28	6	—	Plain Zn plated steel washer (0.312 x 0.734 x 0.065)
29	1	—	⅛ brass pipe plug
30	1	3053306	Print

**SPARE PARTS**





Figure A-26. UP5 and UP6 with Air Failure Lock, Tables A-41 and A-42 (Sheet 1 of 2)



D5328964  
T00345A

Figure A-26. UP5 and UP6 with Air Failure Lock, Tables A-41 and A-42 (Sheet 2 of 2)

## SPARE PARTS

Table A-43. UP5 and UP6 Reserve Air Tank Kits,  
Figure A-27 (Kit Nos. 5328964 \_\_)

Item	Qty	Part No.	Description
1	1	1941099_2	Pressure switch
2	1	1941147_1	½ molded bushing
3	1	1951608_1	Shut-off valve for UP5 and UP6 with positioner (kit no. 5328964_1). Omit for UP5 and UP6 with solenoid valve (kit no. 5328964_2).
4	1	5328959_1	Valve mounting bracket
5	2	5318451_2	3-way pneumatic valve
6	1	1963478_1	Instruction plate
7	1	1951609_1	Bulkhead fitting
8	1	5328782_1	Air failure lock harness
9	1	1951712_1	Check valve
10	1	1963318__	Universal nameplate
11	1	—	¼ NPT brass tee
12	1	—	(½ x ¼) brass reducing bushing
13	3	4-4CB12-B	Male elbow
14	4	1951407_1	Male connector
15	7	8-8CB12-B	Male elbow
16	2	4-4-4SB12-B	Male branch tee
17	1	—	¼ NPT brass close nipple
18	2	—	( $\frac{3}{8}$ x ¼) brass reducing bushing for UP5 and UP6 with positioner (kit no. 5328964_1). Omit for UP5 and UP6 with solenoid valve (kit no. 5328964_2).
19	2	4-4FB12-B	Male connector for UP5 and UP6 with positioner (kit no. 5328964_1). Omit for UP5 and UP6 with solenoid valve (kit no. 5328964_2).
20	4.3 m (14 ft)	R9021-0050	0.500 OD nylon tubing
21	4.3 m (14 ft)	R1021-0022	0.250 OD x 0.040 wall tubing
22	8	NAUAC21016	Hex cap screw (0.250-20)
23	8	NNBAC21000	Hex keps nut (0.250-20)
24	1	—	½ NPT brass tee
25	1	—	½ NPT brass close nipple
27	1	1951408_1	Male elbow
28	4	NTCAC11000	Flat washer (0.250)
29	1	1941817_1	Conduit gasket
30	2	1941817_3	Conduit gasket
31	2	1951612_1	Bulkhead fitting
32	1	1963489_4	Designation plate
33	1	1951785_8	30.3 liter (8.0 gallon) air tank assembly for UP5 (kit no. 5328964_5_) (Fig. B-11).
		1951785_17	64.4 liter (17.0 gallon) air tank assembly for UP6 (kit no. 5328964_6_) (Fig. B-12)
34	1	C3053544-Sh2	Print




Figure A-27. UP5 and UP6 with Reserve Air Tank, Table A-43 (Sheet 1 of 2)

D5328954  
T00346A




Figure A-27. UP5 and UP6 with Reserve Air Tank, Table A-43 (Sheet 2 of 2)

Table A-44. UP5 Cylinder Spare Parts Kit, Figure 8-4 (Kit No. 258241\_1)

Qty	Part No.	Description	Qty	Part No.	Description
2	5311428_41	O-ring	1	195852_1	Wiper ring
1	195825_9	O-ring	1	5311428_24	O-ring
1	5328768_1	Piston	A/R	199354_1	Lubricant
1	1951359_220	O-ring	1	No. 39	Carton
2	195851_1	Back up ring	1	258241	Print

Table A-45. UP6 Cylinder Spare Parts Kit, Figure 8-5 (Kit No. 258242\_1)

Qty	Part No.	Description	Qty	Part No.	Description
2	5311428_39	O-ring	1	5311428_24	O-ring
1	5328941_1	Piston	1	195852_1	Wiper ring
1	195825_9	O-ring	A/R	199354_1	Lubricant
2	195851_1	Back up ring	1	No. 18	Carton
1	1951359_220	O-ring	1	258242	Print

Table A-46. UP5 and UP6 Heater Kits, Figure A-28 (Kit Nos. 5328965\_1/3)

Item	Qty	Part No.	Description
1	1	662460_1	Thermoswitch
2	2	1941401_2	Solderless terminal
3	1	195105_10	Tube clamp
4	2	1943825_8	Stud terminal
5	2	197118_2	Conduit connector
6	6	1943825_11	Stud terminal
7	2	1943002_1	Strip heater for 120 VAC operation (kit no. 5328965_1)
		1943002_2	Strip heater for 240 VAC operation (kit no. 5328965_3)
8	4	19934_87	Spacer
9	2.6 m <sup>2</sup> (28.0 ft <sup>2</sup> )	5318366_1U	Fiberglass insulation
10	1	1963318__	Nameplate
12	3 m (10 ft)	R2049-0100	14 AWG natural leadwire
13	1	—	Pan head Zn plated steel sems int (0.190-32 x 0.375)
14	4	NBZAC21016	slotted pan head screw (0.250-20)
15	4	NTKAC25000	Shakeproof lockwasher (0.250)
16	1	5328965	Print
17	1	No. 17	Carton




Figure A-28. UP5 and UP6 Actuators with Heater, Table A-46 (Sheet 1 of 2)

Table A-47. UP6 Volume Boosters Kit, Figure A-29 (Kit No. 5329155)

Item	Qty	Part No.	Description
1	1	5328566_1	Mounting plate
2	2	5329020_1	Mounting bracket
3	2	5328021_2	Volume booster
4	1	5328018_1	Supply manifold
5	2	5328018_2	Supply manifold
6	1	5329016_1	Bottom flange
7	1	5329017_1	Top flange
8	2	1951772_1	Hose fitting (male)
9	8	1951773_1	Hose fitting (female)
11	5	5328013_1	SAE/NPT male elbow
12	3	5328014_1	SAE/NPT male connector
13	1	5323705_1	Elbow
14	2	1951407_1	Male connector
15	4	195426_1	¾ brass close nipple
17	3	195153_¾	¾ brass tee
18	2	1951408_1	Male elbow
19	4	195137_¾	90_ street elbow
20	1	1963318__	Nameplate
21	A/R	197743_3	Ty-wrap
23	2	—	¾-14 NPT brass pipe plug
24	6.1 m (20.0 ft)	R9025-0033	0.750 ID black synthetic rubber hose with textile braid reinforcement
25	2.4 m (8.0 ft)	R9021-0050	0.062 wall x 0.500 OD polyester reinforced nylon tubing
26	A/R	NPTAC18032	Cherry N rivet
27	6	NIEAC16008	Hex sems ext (0.190-32)
28	6	NTCAC09000	Flat washer (0.190)
29	6	NAUAC21012	Hex cap screw (0.250-20)
30	12	NTAAC11000	Flat washer (0.250)
31	6	NNBAC21000	Hex keps nut (0.250-20)
32	1	3053268 Sh 2	Print




Figure A-28. UP5 and UP6 Actuators with Heater, Table A-46 (Sheet 2 of 2)




Figure A-29. UP6 Actuators with Volume Boosters, Table A-47

## SPARE PARTS

### PARTS KITS FOR ALL ACTUATORS

Tables A-48 and A-49 and Figure A-30 apply to all types of actuators.

Table A-48. Parts List for Alarm/Travel Switch Kit, Figure A-30 (Part No. 5328698 \_1)

Item	Qty	Part No.	Description
1	1	5328699_1	Mounting bracket
2	1	197675_1	Washer
3	1	197676_1	Ground screw
4	12	1943825_1	Terminal lug
5	1	1947256_1	Desig plate assembly
6	4	6614403_1	Switch cam
7	2	1942768_1	Microswitch
8	1	5328700_1	Shaft
9	1	194956_16	Terminal block
11	2	1947261_1	Shield
12	1	5328701_1	Bracket
13	2	197164_37	Retaining ring
21	2	5328703_1	Spacer block
22	2	1942989_1	Microswitch
25	1.1 cm (4.5 in.)	R2041-0070	18 AWG brown leadwire
26	1.1 cm (4.5 in.)	R2041-0075	18 AWG yellow leadwire
27	1.1 cm (4.5 in.)	R2041-0050	18 AWG orange leadwire
28	1.1 cm (4.5 in.)	R2041-0055	18 AWG blue leadwire
29	1.1 cm (4.5 in.)	R2041-1712	18 AWG white/blue leadwire
30	1.1 cm (4.5 in.)	R2041-0035	18 AWG red leadwire
35	2	—	Pan head Zn plated steel sems ext (0.138-32 x 0.500)
36	2	—	Pan head Zn plated steel sems ext (0.138-32 x 0.750)
37	4	—	Pan head Zn plated steel machine screw (0.114-40 x 2.000)
38	8	1104-00	Zn plated steel shakeproof lockwasher
39	3	—	Plain Zn plated steel washer (0.4375 x 1.0000 x 0.0830)
42	4	—	Hex socket head Zn plated steel cap screw (0.112-40 x 0.625)
45	1	No. 62	Carton

Table A-49. Parts List for Electric Shaft Position Transmitter Kit, Figure A-30 (Part No. 5328698\_2)<sup>1</sup>

Item	Qty	Part No.	Description
14	1	5328702_1	Coupler
15	2	197723_1	Brass tip set screw
16	1	5839B01P0001	Feedback potentiometer
17	1	5328704_1	Transmitter bracket
18	3	197688_3	Threaded spacer
19	1	6633390_2	Transmitter board assembly
23	3	1946162_1	Pin receptacle
24	3	197688_6	Hex standoff
31	10 cm (4 in.)	R2041-1664	22 AWG white/green leadwire
32	10 cm (4 in.)	R2041-1666	22 AWG white/violet leadwire
33	10 cm (4 in.)	R2041-1667	22 AWG white/gray leadwire
34	3	—	Pan head Zn plated steel sems ext (0.138-32 x 0.250)
41	2	—	Pan head Zn plated steel sems int (0.190-32 x 0.250)
43	2.5 cm (1.0 in.)	R9023-0165	Insulation tubing
46	1	67125_3	Grommet
47	1	6637721_1	EMI bottom cover
48	1	6637740_1	EMI top cover
49	3	NTMAC13000	Lockwasher
50	3	NLMAC13000	Hex nut

**NOTE:**

1. Use alarm/travel switch kit part no. 5328698\_1 (refer to Table A-48) as a base and add the parts listed in this table to complete the electric shaft position transmitter kit.




Figure A-30. Alarm/Travel Switches and Electric Shaft Position Transmitter, Tables A-48 and A-49

# APPENDIX B - DIMENSION DRAWINGS

## DIMENSION DRAWINGS






Figure B-1. Type UP1 Actuator with Type AV Positioner

**DIMENSION DRAWINGS**



*Figure B-2. Type UP1 Actuator with Type AV Positioner and Air Failure Lock*



*Figure B-3. Type UP1 Actuator with Type AV Positioner, Electric Shaft Positioner and/or Alarm/Travel Switches*




Figure B-4. Type UP1 Actuator with Solenoid Valve






Figure B-5. Type UP1 Actuator with Solenoid Valve and Air Failure Lock

**DIMENSION DRAWINGS**



*Figure B-6. Type UP1 Actuator with Solenoid Valve, Electric Shaft Position Transmitter and/or Alarm/Travel Switches*



*Figure B-7. Type UP2 Actuator with Type AV Positioner or Solenoid Valve*




Figure B-8. Types UP3 and UP4 Actuators (Page 1 of 2)

**DIMENSION DRAWINGS**




Figure B-9. Types UP3 and UP4 Actuators (Page 2 of 2)




Figure B-10. Types UP5 and UP6 Actuators




Figure B-11. 20.8 Liter (5.5 Gallon) Reserve Air Tank Option for Type UP2 Actuators




Figure B-12. 30.3 Liter (8.0 Gallon) Reserve Air Tank Option for Types UP3, UP4 and UP5 Actuators

**DIMENSION DRAWINGS**




Figure B-13. 64.4 Liter (17.0 Gallon) Reserve Air Tank for Type UP6 Actuators

# Index

## A

AC safety ground .....	3-8
Air failure lock	
Automatic operation with UP1 .....	5-5
Automatic operation with UP2 .....	5-5
Automatic operation with UP3 .....	5-9
Automatic operation with UP4 .....	5-9
Automatic operation with UP5 .....	5-14
Automatic operation with UP6 .....	5-14
Description .....	1-8, 4-5, 5-1
Lock valve adjustment .....	4-7
Manual operation .....	5-1
Manual operation with UP1 .....	5-5
Manual operation with UP2 .....	5-5
Manual operation with UP3 .....	5-9
Manual operation with UP4 .....	5-9
Manual operation with UP5 .....	5-13
Manual operation with UP6 .....	5-13
Remote reset .....	3-23
Replacement for UP1 .....	8-17
Replacement for UP2 .....	8-17
Replacement for UP3 .....	8-18
Replacement for UP4 .....	8-18
Replacement for UP5 .....	8-18
Replacement for UP6 .....	8-18
Shipping weight .....	1-10
Trip valve adjustment .....	4-6
Troubleshooting .....	6-3
Tubing .....	3-22
Tubing for UP1 .....	3-23
Tubing for UP2 .....	3-24
Tubing for UP3 .....	3-26
Tubing for UP4 .....	3-26
Tubing for UP5 .....	3-29
Tubing for UP6 .....	3-29
Tubing schematic for UP1 .....	3-25
Tubing schematic for UP2 .....	3-27
Tubing schematic for UP3 .....	3-28
Tubing schematic for UP4 .....	3-28
Tubing schematic for UP5 .....	3-30
Tubing schematic for UP6 .....	3-30
UP1 .....	1-8
UP2 .....	1-8
UP3 .....	1-8
UP4 .....	1-8
UP5 .....	1-8
UP6 .....	1-8
Air filters .....	1-9
Air quality .....	3-10
Air supply	
Maintenance .....	7-2
Operating pressure .....	1-6
Pneumatic shaft position transmitter .....	3-31
Regulation .....	3-7
Regulators .....	3-8
UP1 .....	3-8, 3-9, 3-10
UP2 .....	3-8, 3-9, 3-10
UP3 .....	3-8, 3-11
UP4 .....	3-8, 3-11
UP5 .....	3-8, 3-11
UP6 .....	3-8, 3-11
Versus operating torque .....	3-8
Alarm pressure switch	
Contact ratings .....	1-8
Alarm/travel switches	
Adjustment procedure .....	4-4
Calibration .....	4-4
Description .....	1-8
Illustration .....	3-32
Removal and replacement .....	8-21
Shipping weight .....	1-10
Troubleshooting .....	6-3
Wiring .....	3-31
Wiring for UP1 .....	3-32
Wiring for UP2 .....	3-33
Wiring for UP3 .....	3-33
Wiring for UP4 .....	3-33
Wiring for UP5 .....	3-33
Wiring for UP6 .....	3-33
Annual or semiannual maintenance .....	7-2
As required maintenance .....	7-3
Automatic operation	
Air failure lock .....	5-1
Positioner .....	5-1
Solenoid valve .....	5-1
UP1 with air failure lock .....	5-5
UP1 with positioner .....	5-4
UP1 with solenoid valve .....	5-5
UP2 with air failure lock .....	5-5
UP2 with positioner .....	5-4
UP2 with solenoid valve .....	5-5
UP3 with air failure lock .....	5-9
UP3 with positioner .....	5-6
UP3 with solenoid valve .....	5-9
UP4 with air failure lock .....	5-9
UP4 with positioner .....	5-6
UP4 with solenoid valve .....	5-9
UP5 with air failure lock .....	5-14
UP5 with positioner .....	5-11
UP5 with solenoid valve .....	5-13
UP6 with air failure lock .....	5-14
UP6 with positioner .....	5-11
UP6 with solenoid valve .....	5-13

# Index (continued)

## C

Calibration	
Air failure lock .....	4-5
Lock valve adjustment .....	4-7
Trip valve adjustment .....	4-6
Alarm/travel switches .....	4-4
Electric shaft position transmitter .....	4-4
Equipment required .....	4-1
Pneumatic shaft position transmitter .....	4-5
Positioner gain adjustment .....	4-3
Positioner span adjustment .....	4-2
Positioner speed adjustment .....	4-3
Positioner zero adjustment .....	4-1
Reserve air tank .....	4-5
Clutch	
Clutch fork removal, inspection and replacement for UP5 .....	8-13
Illustration .....	8-13
Clutch fork removal, inspection and replacement for UP6 .....	8-13
Illustration .....	8-13
Maintenance .....	7-2
Control loading	
Direct loading .....	3-38, 3-39
Electric shaft position transmitter .....	3-37
Positioner .....	3-38
Reverse loading .....	3-39
Solenoid valve .....	3-39
Cylinder	
Cleaning .....	8-7
Maintenance .....	7-3
Parts list for UP3 .....	8-8
Parts list for UP4 .....	8-9
Parts list for UP5 .....	8-10
Parts list for UP6 .....	8-11
Removal and replacement for UP3 .....	8-7
Removal and replacement for UP4 .....	8-7
Removal and replacement for UP5 .....	8-7
Removal and replacement for UP6 .....	8-7
Repair .....	8-7

## E

Electric shaft position transmitter	
Adjustment procedure .....	4-4
Calibration .....	4-4
Circuit board illustration .....	3-37
Description .....	1-8
Illustration .....	3-32
Removal and replacement .....	8-20
Shipping weight .....	1-10
Supply voltage and load resistance limits .....	3-36

Troubleshooting .....	6-2
UP1 .....	8-20
UP2 .....	8-20
UP3 .....	8-20
UP4 .....	8-20
UP5 .....	8-20
UP6 .....	8-20
Wiring .....	3-34
Wiring for reverse loading .....	3-37
Wiring for UP1 .....	3-35
Wiring for UP2 .....	3-35
Wiring for UP3 .....	3-36
Wiring for UP4 .....	3-36
Wiring for UP5 .....	3-36
Wiring for UP6 .....	3-36
Wiring loop diagram .....	3-35
Enclosure removal	
Installation .....	3-2
UP1 .....	3-2
UP2 .....	3-2
UP3 .....	3-3
UP4 .....	3-3
UP5 .....	3-6
UP6 .....	3-6
Equipment application .....	1-2
Equipment description .....	1-1
Equipment required for calibration .....	4-1

## F

Features .....	1-2
Feedback potentiometer	
Removal and replacement .....	8-21
Functional operation	
UP5 .....	2-1
Functional operation	
Master/slave .....	2-3
Positioner .....	2-1
Solenoid valve .....	2-1
UP1 .....	2-1
UP2 .....	2-1
UP3 .....	2-1
UP4 .....	2-1
UP6 .....	2-1

## G

Gain adjustment	
Positioner .....	4-3
Grounding electrode system .....	3-9

<b>I</b>		
Input ranges		
Positioner.....	1-6	
Input ranges, positioner.....	1-1, 1-4	
Installation		
Enclosure removal.....	3-2	
Grounding.....	3-8	
Location considerations.....	3-1	
UP1 enclosure removal.....	3-2	
UP2 enclosure removal.....	3-2	
UP3 enclosure removal.....	3-3	
UP4 enclosure removal.....	3-3	
UP5 enclosure removal.....	3-6	
UP6 enclosure removal.....	3-6	
Instruction content.....	1-2	
Intended user.....	1-1	
Intended users.....	1-1	
ISA S7.3.....	3-10	
<b>L</b>		
Linkage Maintenance.....	7-2	
Location considerations.....	3-1	
<b>M</b>		
Maintenance		
Air supply.....	7-2	
Annual or semiannual.....	7-2	
As required.....	7-3	
Clutch.....	7-2	
Cylinder.....	7-3	
Linkage.....	7-2	
Periodic.....	7-1	
Positioner.....	7-2, 7-3	
Reserve air tank.....	7-2	
Roller chain.....	7-2	
Rotary vane.....	7-3	
Manual operation		
Air failure lock.....	5-1	
Positioner.....	5-1	
Solenoid valve.....	5-1	
UP1 with air failure lock.....	5-5	
UP1 with positioner.....	5-2	
UP1 with solenoid valve.....	5-4	
UP2 with air failure lock.....	5-5	
UP2 with positioner.....	5-2	
UP2 with solenoid valve.....	5-4	
UP3 with air failure lock.....	5-9	
UP3 with positioner.....	5-6	
UP3 with solenoid valve.....	5-8	
UP4 with air failure lock.....	5-9	
UP4 with positioner.....	5-6	
UP4 with solenoid valve.....	5-8	
UP5 with air failure lock.....	5-14	
UP5 with positioner.....	5-11	
UP5 with solenoid valve.....	5-13	
UP6 with air failure lock.....	5-14	
UP6 with positioner.....	5-11	
UP6 with solenoid valve.....	5-12	
UP6 with positioner.....	5-10	
UP6 with solenoid valve.....	5-12	
UP5 with solenoid valve.....	5-12	
UP5 with positioner.....	5-10	
UP5 with air failure lock.....	5-13	
UP4 with solenoid valve.....	5-8	
UP4 with positioner.....	5-6	
UP4 with air failure lock.....	5-6	
UP4 with positioner.....	5-6	
UP4 with solenoid valve.....	5-8	
UP5 with air failure lock.....	5-14	
UP5 with positioner.....	5-11	
UP5 with solenoid valve.....	5-13	
UP6 with air failure lock.....	5-14	
UP6 with positioner.....	5-11	
UP6 with solenoid valve.....	5-12	
Master/slave		
Illustration.....	3-17	
Mechanical stop		
Adjustment for UP1.....	3-42	
Adjustment for UP2.....	3-42	
<b>N</b>		
Nomenclature.....	1-4	
<b>O</b>		
Operating lever		
Adjustment.....	3-40	
UP1.....	3-40	
UP2.....	3-40	
UP3.....	3-41	
UP4.....	3-41	
UP5.....	3-41	
UP6.....	3-41	
Operation		
Automatic.....	5-1, 5-4, 5-5, 5-6, 5-9, 5-11, 5-13, 5-14	
Air failure lock.....	5-1	
Positioner.....	5-1	
Solenoid valve.....	5-1	
UP1 with air failure lock.....	5-5	
UP1 with positioner.....	5-4	
UP1 with solenoid valve.....	5-5	
UP2 with air failure lock.....	5-5	
UP2 with positioner.....	5-4	
UP2 with solenoid valve.....	5-5	
UP3 with air failure lock.....	5-9	
UP3 with positioner.....	5-6	
UP3 with solenoid valve.....	5-9	
UP4 with air failure lock.....	5-9	
UP4 with positioner.....	5-6	
UP4 with solenoid valve.....	5-9	
UP5 with air failure lock.....	5-14	
UP5 with positioner.....	5-11	
UP5 with solenoid valve.....	5-13	
UP6 with air failure lock.....	5-14	
UP6 with positioner.....	5-11	
UP6 with solenoid valve.....	5-12	

# Index (continued)

Manual....	5-1, 5-2, 5-4, 5-5, 5-6, 5-8, 5-9, 5-10, 5-12, 5-13
Air failure lock .....	5-1
Positioner.....	5-1
Solenoid valve .....	5-1
UP1 with air failure lock .....	5-5
UP1 with positioner.....	5-2
UP1 with solenoid valve .....	5-4
UP2 with air failure lock .....	5-5
UP2 with positioner.....	5-2
UP2 with solenoid valve .....	5-4
UP3 with air failure lock .....	5-9
UP3 with positioner.....	5-6
UP3 with solenoid valve .....	5-8
UP4 with air failure lock .....	5-9
UP4 with positioner.....	5-6
UP4 with solenoid valve .....	5-8
UP5 with air failure lock .....	5-13
UP5 with positioner.....	5-10
UP5 with solenoid valve .....	5-12
UP6 with air failure lock .....	5-13
UP6 with positioner.....	5-10
UP6 with solenoid valve .....	5-12
UP1 operating controls - illustration .....	5-3
UP2 operating controls - illustration .....	5-3
UP3 operating controls - illustration .....	5-8
UP4 operating controls - illustration .....	5-8
UP5 operating controls - illustration .....	5-10
UP6 operating controls - illustration .....	5-10
<b>P</b>	
Periodic maintenance.....	7-1
Pneumatic shaft position transmitter	
Adjustment procedure .....	4-5
Air supply.....	3-31
Calibration .....	4-5
Removal and replacement .....	8-22
Shipping weight.....	1-10
Troubleshooting.....	6-2
Tubing .....	3-30
Tubing for UP2 .....	3-31
Tubing for UP3 .....	3-31
Tubing for UP4 .....	3-31
Tubing for UP5 .....	3-31
Tubing for UP6 .....	3-31
Position indicator	
Changing.....	3-41
UP1 .....	3-41
UP2 .....	3-41
UP3 .....	3-41
UP4 .....	3-41
UP5 .....	3-41
UP6 .....	3-41
Positioner	
Automatic operation .....	5-1
Automatic operation with UP1 .....	5-4
Automatic operation with UP2 .....	5-4
Automatic operation with UP3 .....	5-6
Automatic operation with UP4 .....	5-6
Automatic operation with UP5 .....	5-11
Automatic operation with UP6 .....	5-11
Control loading.....	3-38
Gain adjustment.....	4-3
Input ranges.....	1-1, 1-6
Maintenance .....	7-2, 7-3
Manual operation .....	5-1
Manual operation with UP1.....	5-2
Manual operation with UP2.....	5-2
Manual operation with UP3.....	5-6
Manual operation with UP4.....	5-6
Manual operation with UP5.....	5-10
Manual operation with UP6.....	5-10
Removal and replacement for UP1.....	8-2
Removal and replacement for UP2.....	8-2
Removal and replacement for UP3.....	8-2
Removal and replacement for UP4.....	8-2
Removal and replacement for UP5.....	8-2
Removal and replacement for UP6.....	8-2
Span adjustment .....	4-2
Speed adjustment.....	4-3
Troubleshooting .....	6-1, 6-2
Tubing.....	3-11, 3-13
Tubing for UP1.....	3-11, 3-13
Tubing for UP2.....	3-11, 3-13
Tubing for UP3.....	3-12, 3-13
Tubing for UP4.....	3-12, 3-13
Tubing for UP5.....	3-12, 3-14
Tubing for UP6.....	3-12, 3-14
Wiring.....	3-13
Wiring for UP1 .....	3-13
Wiring for UP2 .....	3-13
Wiring for UP3 .....	3-13
Wiring for UP4 .....	3-13
Wiring for UP5 .....	3-14
Wiring for UP6 .....	3-14
Zero adjustment.....	4-1
Pressure gage .....	1-9
Pressure switch .....	1-9
<b>R</b>	
Reference documents .....	1-4
Regulators .....	1-9

## Index (continued)

Regulators, air supply.....	3-8	Rotary vane housing cleaning for UP2.....	8-5
Repair/replacement.....	8-16	Rotary vane removal and replacement for UP1 ....	8-3
Air failure lock for UP1.....	8-17	Illustration.....	8-4
Air failure lock for UP2.....	8-17	Rotary vane removal and replacement for UP2 ....	8-3
Air failure lock for UP3.....	8-18	Illustration.....	8-4
Air failure lock for UP4.....	8-18	Rotary vane seals for UP1.....	8-5
Air failure lock for UP5.....	8-18	Illustration.....	8-4
Air failure lock for UP6.....	8-18	Rotary vane seals for UP2.....	8-5
Alarm/travel switches.....	8-21	Illustration.....	8-4
Clutch fork for UP5.....	8-13	Solenoid valve removal and replacement for UP1	8-3
Illustration.....	8-13	Solenoid valve removal and replacement for UP2	8-3
Clutch fork for UP6.....	8-13	Solenoid valve removal and replacement for UP3	8-3
Illustration.....	8-13	Solenoid valve removal and replacement for UP4	8-3
Cylinder cleaning for UP3.....	8-7	Solenoid valve removal and replacement for UP5	8-3
Cylinder cleaning for UP4.....	8-7	Solenoid valve removal and replacement for UP6	8-3
Cylinder cleaning for UP5.....	8-7	Replacement parts.....	9-1
Cylinder cleaning for UP6.....	8-7	Reserve air tank.....	3-19, 8-16
Cylinder for UP3.....	8-7	Calibration.....	4-5
Cylinder for UP4.....	8-7	Description.....	1-9
Illustration.....	8-9	Dimension drawing.....	B-7
Cylinder for UP5.....	8-7	Maintenance.....	7-2
Illustration.....	8-10	Repair/replacement.....	8-16
Cylinder for UP6.....	8-7	Replacement for UP1.....	8-16
Illustration.....	8-11	Replacement for UP2.....	8-16
Cylinder parts list for UP3.....	8-8	Replacement for UP3.....	8-16
Cylinder parts list for UP4.....	8-9	Replacement for UP4.....	8-16
Cylinder parts list for UP5.....	8-10	Replacement for UP5.....	8-16
Cylinder parts list for UP6.....	8-11	Replacement for UP6.....	8-16
Cylinder removal and replacement for UP3.....	8-7	Shipping weight.....	1-10
Cylinder removal and replacement for UP4.....	8-7	Troubleshooting.....	6-3
Cylinder removal and replacement for UP5.....	8-7	UP2.....	3-19
Cylinder removal and replacement for UP6.....	8-7	UP3.....	1-9, 3-21
Electric shaft position transmitter.....	8-20	UP4.....	1-9, 3-21
Feedback potentiometer.....	8-21	UP5.....	1-9, 3-21
Pneumatic shaft position transmitter.....	8-22	UP6.....	1-9, 3-21
Positioner removal and replacement for UP1.....	8-2	Roller chain.....	
Positioner removal and replacement for UP2.....	8-2	Adjustment for UP5.....	8-14
Positioner removal and replacement for UP3.....	8-2	Illustration.....	8-15
Positioner removal and replacement for UP4.....	8-2	Adjustment for UP6.....	8-14
Positioner removal and replacement for UP5.....	8-2	Illustration.....	8-15
Positioner removal and replacement for UP6.....	8-2	Maintenance.....	7-2
Reserve air tank.....	8-16	Rotary vane.....	
Reserve air tank for UP2.....	8-16	Housing cleaning.....	8-5
Reserve air tank for UP3.....	8-16	Maintenance.....	7-3
Reserve air tank for UP4.....	8-16	Removal and replacement for UP1.....	8-3
Reserve air tank for UP5.....	8-16	Illustration.....	8-4
Reserve air tank for UP6.....	8-16	Removal and replacement for UP2.....	8-3
Roller chain adjustment for UP5.....	8-14	Illustration.....	8-4
Illustration.....	8-15	Seal repair.....	8-5
Roller chain adjustment for UP6.....	8-14	Illustration.....	8-4
Illustration.....	8-15	Rotation.....	1-6
Rotary vane housing cleaning for UP1.....	8-5		

# Index (continued)

## S

Shipping weights .....	1-10
Solenoid valve	
Automatic operation .....	5-1
Automatic operation with UP1 .....	5-5
Automatic operation with UP2 .....	5-5
Automatic operation with UP3 .....	5-9
Automatic operation with UP4 .....	5-9
Automatic operation with UP5 .....	5-13
Automatic operation with UP6 .....	5-13
Control loading .....	3-39
Manual operation .....	5-1
Manual operation with UP1 .....	5-4
Manual operation with UP2 .....	5-4
Manual operation with UP3 .....	5-8
Manual operation with UP4 .....	5-8
Manual operation with UP5 .....	5-12
Manual operation with UP6 .....	5-12
Removal and replacement for UP1 .....	8-3
Removal and replacement for UP2 .....	8-3
Removal and replacement for UP3 .....	8-3
Removal and replacement for UP4 .....	8-3
Removal and replacement for UP5 .....	8-3
Removal and replacement for UP6 .....	8-3
Tubing .....	3-14
Tubing for UP1 .....	3-14
Tubing for UP2 .....	3-14
Tubing for UP3 .....	3-14
Tubing for UP4 .....	3-14
Tubing for UP5 .....	3-15
Tubing for UP6 .....	3-15
Types .....	1-4
Wiring .....	3-14
Wiring for UP1 .....	3-14
Wiring for UP2 .....	3-14
Wiring for UP3 .....	3-14
Wiring for UP4 .....	3-14
Wiring for UP5 .....	3-15
Wiring for UP6 .....	3-15
Span adjustment	
Positioner .....	4-2
Speed adjustment	
Positioner .....	4-3
Speed control orifice .....	1-9
Split ranging	
Span adjustment .....	4-2
Strip heaters	
Description .....	1-9
Removal and replacement .....	8-23
Shipping weights .....	1-10
Troubleshooting .....	6-2

UP2 .....	1-9
UP3 .....	1-9
UP4 .....	1-9
UP5 .....	1-9
UP6 .....	1-9
Wiring .....	3-37
Wiring for UP2 .....	3-38
Wiring for UP3 .....	3-38
Wiring for UP4 .....	3-38
Wiring for UP5 .....	3-38
Wiring for UP6 .....	3-38
Stroke times .....	1-6

## T

Technical documentation .....	9-1
Temperature limits	
Operating .....	1-6, 3-1, 3-37
Thermoswitch	
Removal and replacement .....	8-24
Torque	
Maximum operating .....	3-8
Operating .....	1-6
UP1 .....	1-4, 3-8, 3-9, 3-10
UP2 .....	1-4, 3-8, 3-9, 3-10
UP3 .....	1-4, 3-8, 3-11
UP4 .....	1-4, 3-8, 3-11
UP5 .....	1-4, 3-8, 3-11
UP6 .....	1-4, 3-8, 3-11
Training .....	9-1
Travel limiting	
Span adjustment .....	4-2
Troubleshooting	
Air failure lock .....	6-3
Alarm/travel switches .....	6-3
Electric shaft position transmitter .....	6-2
Frozen air lines .....	6-2
Loud exhaust .....	6-2
Oscillation .....	6-2
Pneumatic shaft position transmitter .....	6-2
Range .....	6-2
Reserve air tank .....	6-3
Slow response .....	6-2
Uprange zero .....	6-2
Tubing	
Air failure lock .....	3-22
Master/slave installations .....	3-17
Positioner, I/P .....	3-13
Positioner, pneumatic .....	3-11
Schematic for UP1 with air failure lock .....	3-25
Schematic for UP2 with air failure lock .....	3-27
Schematic for UP3 with air failure lock .....	3-28

## Index (continued)

Schematic for UP4 with air failure lock .....	3-28	Alarm/travel switches removal and replacement .....	8-21
Schematic for UP5 with air failure lock .....	3-30	Automatic operation with air failure lock .....	5-5
Schematic for UP6 with air failure lock .....	3-30	Automatic operation with positioner .....	5-4
Solenoid .....	3-14	Automatic operation with solenoid valve .....	5-5
UP1 .....	3-8	Electric shaft position transmitter calibration .....	4-4
UP1 with air failure lock .....	3-23	Electric shaft position transmitter removal and replacement .....	8-20
UP1 with alarm pressure switch .....	3-24	Enclosure removal .....	3-2
UP1 with I/P positioner .....	3-13	Feedback potentiometer removal and replacement .....	8-21
UP1 with pneumatic positioner .....	3-11	I/P positioner tubing .....	3-13
UP1 with solenoid .....	3-14	I/P positioner wiring .....	3-13
UP2 .....	3-8	Illustration .....	3-3, 3-15
UP2 with air failure lock .....	3-24	Manual operation with air failure lock .....	5-5
UP2 with alarm pressure switch .....	3-26	Manual operation with positioner .....	5-2
UP2 with I/P positioner .....	3-13	Manual operation with solenoid valve .....	5-4
UP2 with pneumatic positioner .....	3-11	Mechanical stop adjustment .....	3-42
UP2 with pneumatic shaft position transmitter .....	3-31	Operating controls - illustration .....	5-3
UP2 with solenoid .....	3-14	Operating lever adjustment .....	3-40
UP3 .....	3-8	Operating torque versus air supply .....	3-8
UP3 with air failure lock .....	3-26	Pneumatic positioner tubing .....	3-11
UP3 with I/P positioner .....	3-13	Position indicator .....	3-41
UP3 with pneumatic positioner .....	3-12	Positioner removal and replacement .....	8-2
UP3 with pneumatic shaft position transmitter .....	3-31	Rated torque .....	1-4
UP3 with solenoid .....	3-14	Rotary vane housing cleaning .....	8-5
UP4 .....	3-8	Rotary vane removal and replacement .....	8-3
UP4 with air failure lock .....	3-26	Illustration .....	8-4
UP4 with I/P positioner .....	3-13	Rotary vane seal repair .....	8-5
UP4 with pneumatic positioner .....	3-12	Illustration .....	8-4
UP4 with pneumatic shaft position transmitter .....	3-31	Rotation .....	1-6
UP4 with solenoid .....	3-14	Shipping weights .....	1-10
UP5 .....	3-8	Solenoid tubing .....	3-14
UP5 with air failure lock .....	3-29	Solenoid valve removal and replacement .....	8-3
UP5 with I/P positioner .....	3-14	Solenoid wiring .....	3-14
UP5 with pneumatic positioner .....	3-12	Stall torque versus air supply .....	3-9, 3-10
UP5 with pneumatic shaft position transmitter .....	3-31	Tubing .....	3-8
UP5 with solenoid .....	3-15	Tubing schematic for air failure lock .....	3-25
UP6 .....	3-8	Volume displacement .....	1-6
UP6 with air failure lock .....	3-29	Wiring for electric shaft position transmitter .....	3-35
UP6 with I/P positioner .....	3-14		
UP6 with pneumatic positioner .....	3-12		
UP6 with pneumatic shaft position transmitter .....	3-31		
UP6 with solenoid .....	3-15		
<b>U</b>			
Unpacking and Inspection .....	3-1		
UP1		UP2	
Air failure lock .....	1-8	Air failure lock .....	1-8
Trip valve adjustment .....	4-6	Trip valve adjustment .....	4-6
Air failure lock tubing .....	3-23	Air failure lock tubing .....	3-24
Alarm pressure switch tubing and wiring .....	3-24	Alarm pressure switch tubing and wiring .....	3-26
Alarm/travel switch calibration .....	4-4	Alarm/travel switch calibration .....	4-4
Alarm/travel switch wiring .....	3-32	Alarm/travel switch wiring .....	3-33
		Alarm/travel switches removal and replacement .....	8-21
		Automatic operation with air failure lock .....	5-5
		Automatic operation with positioner .....	5-4
		Automatic operation with solenoid valve .....	5-5
		Electric shaft position transmitter calibration .....	4-4
		Electric shaft position transmitter removal and re-	

## Index (continued)

placement.....	8-20	Automatic operation with positioner .....	5-6
Enclosure removal.....	3-2	Automatic operation with solenoid valve.....	5-9
Feedback potentiometer removal and replacement... 8-21		Cylinder cleaning .....	8-7
I/P positioner tubing.....	3-13	Cylinder parts list .....	8-8
I/P positioner wiring.....	3-13	Cylinder removal and replacement .....	8-7
Illustration .....	3-16	Cylinder repair .....	8-7
Manual operation with air failure lock.....	5-5	Electric shaft position transmitter calibration .....	4-4
Manual operation with positioner.....	5-2	Electric shaft position transmitter removal and re- placement .....	8-20
Manual operation with solenoid valve .....	5-4	Enclosure removal .....	3-3
Mechanical stop adjustment.....	3-42	Feedback potentiometer removal and replacement .. 8-21	
Operating controls - illustration.....	5-3	I/P positioner tubing .....	3-13
Operating lever adjustment .....	3-40	I/P positioner wiring .....	3-13
Operating torque versus air supply .....	3-8	Manual operation with air failure lock .....	5-9
Pneumatic positioner tubing.....	3-11	Manual operation with positioner .....	5-6
Pneumatic shaft position transmitter calibration....	4-5	Manual operation with solenoid valve.....	5-8
Pneumatic shaft position transmitter removal and re- placement.....	8-22	Operating controls - illustration .....	5-8
Pneumatic shaft position transmitter tubing .....	3-31	Operating lever adjustment.....	3-41
Position indicator .....	3-41	Operating torque versus air supply .....	3-8
Positioner removal and replacement.....	8-2	Pneumatic positioner tubing .....	3-12
Rated torque.....	1-4	Pneumatic shaft position transmitter calibration ...	4-5
Reserve air tank .....	3-19, 8-16	Pneumatic shaft position transmitter removal and re- placement .....	8-22
Rotary vane housing cleaning .....	8-5	Pneumatic shaft position transmitter tubing .....	3-31
Rotary vane removal and replacement .....	8-3	Position indicator .....	3-41
Illustration .....	8-4	Positioner removal and replacement .....	8-2
Rotary vane seal repair .....	8-5	Rated torque .....	1-4
Illustration .....	8-4	Reserve air tank.....	1-9, 3-21
Rotation .....	1-6	Dimension drawing.....	B-7
Shipping weight.....	1-10	Rotation .....	1-6
Solenoid tubing.....	3-14	Shipping weight .....	1-10
Solenoid valve removal and replacement .....	8-3	Solenoid tubing .....	3-14
Solenoid wiring.....	3-14	Solenoid valve removal and replacement.....	8-3
Stall torque versus air supply .....	3-9, 3-10	Solenoid wiring .....	3-14
Strip heaters.....	1-9	Stall torque versus air supply.....	3-11
Strip heaters removal and replacement .....	8-23	Strip heaters .....	1-9
Thermoswitch removal and replacement .....	8-24	Strip heaters removal and replacement.....	8-23
Tubing .....	3-8	Thermoswitch removal and replacement.....	8-24
Tubing schematic for air failure lock.....	3-27	Tubing.....	3-8
Volume displacement .....	1-6	Tubing schematic for air failure lock .....	3-28
Wiring for electric shaft position transmitter .....	3-35	Volume displacement .....	1-6
Wiring for strip heaters .....	3-38	Wiring for electric shaft position transmitter .....	3-36
UP3 .....	2-1	Wiring for strip heaters.....	3-38
.....	8-16	UP4	
Air failure lock.....	1-8	Air failure lock .....	1-8
Lock valve adjustment.....	4-7	Lock valve adjustment.....	4-7
Air failure lock tubing.....	3-26	Trip valve adjustment.....	4-6
Alarm pressure switch tubing and wiring.....	3-27	Air failure lock tubing .....	3-26
Alarm/travel switch calibration.....	4-4	Alarm pressure switch tubing and wiring .....	3-27
Alarm/travel switch wiring.....	3-33	Alarm/travel switch calibration .....	4-4
Alarm/travel switches removal and replacement.....	8-21	Alarm/travel switch wiring .....	3-33
Automatic operation with air failure lock.....	5-9		

Alarm/travel switches removal and replacement	8-21	Air failure lock tubing	3-29
Automatic operation with air failure lock	5-9	Alarm pressure switch tubing and wiring	3-29
Automatic operation with positioner	5-6	Alarm/travel switch calibration	4-4
Automatic operation with solenoid valve	5-9	Alarm/travel switch wiring	3-33
Cylinder cleaning	8-7	Alarm/travel switches removal and replacement	8-21
Cylinder parts list	8-9	Automatic operation with air failure lock	5-14
Cylinder removal and replacement	8-7	Automatic operation with positioner	5-11
Cylinder repair	8-7	Automatic operation with solenoid valve	5-13
Illustration	8-9	Clutch fork removal, inspection and replacement	8-13
Electric shaft position transmitter calibration	4-4	Illustration	8-13
Electric shaft position transmitter removal and replacement	8-20	Cylinder cleaning	8-7
Enclosure removal	3-3	Cylinder parts list	8-10
Feedback potentiometer removal and replacement	8-21	Cylinder removal and replacement	8-7
I/P positioner tubing	3-13	Cylinder repair	8-7
I/P positioner wiring	3-13	Illustration	8-10
Manual operation with air failure lock	5-9	Electric shaft position transmitter calibration	4-4
Manual operation with positioner	5-6	Electric shaft position transmitter removal and replacement	8-20
Manual operation with solenoid valve	5-8	Enclosure removal	3-6
Operating controls - illustration	5-8, 5-10	Feedback potentiometer removal and replacement	8-21
Operating lever adjustment	3-41	I/P positioner tubing	3-14
Operating torque versus air supply	3-8	I/P positioner wiring	3-14
Pneumatic positioner tubing	3-12	Illustration	3-6
Pneumatic shaft position transmitter calibration	4-5	Manual operation with air failure lock	5-13
Pneumatic shaft position transmitter removal and replacement	8-22	Manual operation with positioner	5-10
Pneumatic shaft position transmitter tubing	3-31	Manual operation with solenoid valve	5-12
Position indicator	3-41	Operating controls - illustration	5-10
Positioner removal and replacement	8-2	Operating lever adjustment	3-41
Rated torque	1-4	Operating torque versus air supply	3-8
Reserve air tank	1-9, 3-21	Pneumatic positioner tubing	3-12
Dimension drawing	B-7	Pneumatic shaft position transmitter calibration	4-5
Repair/replacement	8-16	Pneumatic shaft position transmitter removal and replacement	8-22
Rotation	1-6	Pneumatic shaft position transmitter tubing	3-31
Shipping weight	1-10	Position indicator	3-41
Solenoid tubing	3-14	Positioner removal and replacement	8-2
Solenoid valve removal and replacement	8-3	Rated torque	1-4
Solenoid wiring	3-14	Reserve air tank	1-9, 3-21
Stall torque versus air supply	3-11	Dimension drawing	B-7
Strip heaters	1-9	Repair/replacement	8-16
Strip heaters removal and replacement	8-23	Roller chain adjustment	8-14
Thermoswitch removal and replacement	8-24	Illustration	8-15
Tubing	3-8	Rotation	1-6
Tubing schematic for air failure lock	3-28	Shipping weight	1-10
Volume displacement	1-6	Solenoid tubing	3-15
Wiring for electric shaft position transmitter	3-36	Solenoid valve removal and replacement	8-3
Wiring for strip heaters	3-38	Solenoid wiring	3-15
UP5		Stall torque versus air supply	3-11
Air failure lock	1-8	Strip heaters	1-9
Lock valve adjustment	4-7	Strip heaters removal and replacement	8-23
Trip valve adjustment	4-6	Thermoswitch removal and replacement	8-24



---

# Index (continued)

---

UP2 with solenoid .....	3-14
UP3 with alarm pressure switch .....	3-27
UP3 with alarm/travel switches .....	3-33
UP3 with electric shaft position transmitter .....	3-36
UP3 with I/P positioner .....	3-13
UP3 with solenoid .....	3-14
UP4 with alarm pressure switch .....	3-27
UP4 with alarm/travel switches .....	3-33
UP4 with electric shaft position transmitter .....	3-36
UP4 with I/P positioner .....	3-13
UP4 with solenoid .....	3-14
UP5 with alarm pressure switch .....	3-29
UP5 with alarm/travel switches .....	3-33
UP5 with electric shaft position transmitter .....	3-36

UP5 with I/P positioner .....	3-14
UP5 with solenoid .....	3-15
UP6 with alarm pressure switch .....	3-29
UP6 with alarm/travel switches .....	3-33
UP6 with electric shaft position transmitter .....	3-36
UP6 with I/P positioner .....	3-14
UP6 with solenoid .....	3-15

## Z

Zero adjustment	
Positioner .....	4-1
Zero elevation .....	4-2

PN25059A



The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

© Copyright 2004 ABB. All rights reserved.  
[May, 2004]

Printed in USA

**ABB Automation Inc.**  
Instrumentation Division  
125 East County Line Road  
Warminster, PA 18974 USA  
Tel. 215-674-6000  
FAX: 215-674-7183

**ABB Instrumentation Ltd**  
Howard Road, St. Neots  
Cams. England, PE19 3EU  
Tel. +44 (0) 1480-475-321  
FAX: +44 (0) 1480-217-948

**ABB Instrumentation S.p.A**  
Via Sempione 243  
20016 Pero (Milano) Italy  
Tel: +39 (02) 33928 1  
Fax: +39 (02) 33928 240

**ABB Automation Products GmbH**  
Industriestr. 28  
D-65760 Eschborn Germany  
Tel: +49 (0) 6196 800 0  
Fax: +49 (0) 6196 800 1849