

Process Power Manager 5 Library for 800xA PMS 5.6.5 Restart & Reacceleration Library Manual

Version 5.6-5





Process Power Manager 5

Library for 800xA PMS 5.6.5 Restart & Reacceleration Library Manual

Version 5.6-5

NOTICE

This document contains information about one or more ABB products and may include a description of or a reference to one or more standards that may be generally relevant to the ABB products. The presence of any such description of a standard or reference to a standard is not a representation that all of the ABB products referenced in this document support all of the features of the described or referenced standard. In order to determine the specific features supported by a particular ABB product, the reader should consult the product specifications for the particular ABB product.

ABB may have one or more patents or pending patent applications protecting the intellectual property in the ABB products described in this document.

The information in this document is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this document.

In no event shall ABB be liable for direct, indirect, special, incidental or consequential damages of any nature or kind arising from the use of this document, nor shall ABB be liable for incidental or consequential damages arising from use of any software or hardware described in this document.

This document and parts thereof must not be reproduced or copied without written permission from ABB, and the contents thereof must not be imparted to a third party nor used for any unauthorized purpose.

This product is designed to be connected to and to communicate information and data via a network interface. It is the reader's sole responsibility to provide and continuously ensure a secure connection between the product and the reader's network or any other network (as the case may be). The reader shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB is not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

The software or hardware described in this document is furnished under a license and may be used, copied, or disclosed only in accordance with the terms of such license. This product meets the requirements specified in EMC Directive 2004/108/EC and in Low Voltage Directive 2006/95/EC.

TRADEMARKS

All rights to copyrights, registered trademarks, and trademarks reside with their respective owners.

Copyright © 2002 – 2022 by ABB. All Rights Reserved.

Release: September 2022 Document number: 3BNP100234-0396 B

Table of Contents

Contents

Table of Contents	5		
Contents	5		
List of Figures			
List of Tables			
About This User Manual	9		
General	9		
Document Conventions			
Warning, Caution, Information, and Tip Icons			
Terminology			
Related Documentation			
Compatibility			
System Security			
Section 1 General	14		
Section 2 Function	15		
2.1 Idle state			
2.1 Idle State			
2.2 Anning State			
2.6 Operational state			
2.4.1 Non-coordinated reacceleration function			
Section 3 Control Module			
3.1 Detailed Engineering			
3.1.1 Voltage monitoring			
3.1.2 Load monitoring			
3.1.3 Blocking			
3.1.4 Configuration2			
3.1.5 Operator interface			
3.1.6 History reporting			
3.1.7 Alarm & Event handling			
3.1.0 Voltage monitoring			
3 1 10 Operator commands			
3.1.11 Reconnect. output command			
3.1.12 Alarm & Event disabling			
3.1.13 Blocking	33		
3.1.14 External priority			
3.1.15 Configuration	35		
3.1.16 Operator interface			
3.1.17 Reporting			
3.1.18 Alarms			
3.1.19 EVENTS			
Section 4 Conscitu & Derformence			
4.1 Hoop utilization			
4. I Tieap uulizauoli			

54
55
· · ·

List of Figures

Figure 45 Variables to be added in pmsNode1 and ioNode1	69
Figure 46 Connecting the LoadPar to the instance	70
Figure 47 Reading Load status values	71
Figure 48 Setting Close command outputs	72
Figure 49 Variable for external parameter.	72
Figure 50 Connection of the external parameter variable	73
Figure 51 Setting external parameters from code or other inputs	73
Figure 52 Load parameters that can be set by application code/external	74
Figure 53 Global parameters	75
Figure 54 Priority parameters	75
Figure 55 Example of code for settings parameters	76

List of Tables

Table 1 Terminology	. 10
Table 2 Related Documentation	. 13
Table 3 Control module parameters	. 18
Table 4 Parameters configuration for undervoltage	. 22
Table 5 Parameter configuration for recovery voltage	.23
Table 6 Parameter configuration for voltage measurement	. 24
Table 7 Prioritized voltage signal related to function stage	. 25
Table 8 Parameter configuration for feedback monitoring	.26
Table 9 faceplate configuration of load configuration timers	. 28
Table 10 Parameter configuration of load configuration timers	. 28
Table 11 Faceplate configuration for priority definition	. 29
Table 12 Faceplate configuration for inhibit interaction	. 30
Table 13 Parameter for load status	.31
Table 14 Parameter for external disabling of alarms & events	. 32
Table 15 Main faceplate block interaction	. 33
Table 16 Main faceplate automatic block interaction	. 34
Table 17 Faceplate configuration of Global settings	. 35
Table 18 Parameter configuration of GlobalPrioConfigGlobal	. 36
Table 19 Main faceplate automatic block interaction	. 38
Table 20 Faceplate element Main View description	. 39
Table 21 Faceplate element Busbar A & B description	.41
Table 22 Alarm configuration	.48
Table 23 Event configuration	. 50
Table 24 Required I/O connections to the parameters	. 53
Table 25 Firmware version downloaded in AC800M controllers	. 54
Table 26 Heap utilization of pmsReAccSub in AC800M controller	. 54
Table 27 Execution time of pmsReAccSub in AC800M controller	. 54
Table 28 Examples of parameters set by application code	.77
Table 29 User interaction permissions	.78

About This User Manual

General

This User Manual provides the configuration information for the Restart & Reacceleration control modules that are part of the PMS Library. The information in this manual is directed towards the project engineers. The user should be familiar with the Control IT for AC 800M/C and Operate IT environment.

Document Conventions

Microsoft Windows conventions are normally used for the standard presentation of material when entering text, key sequences, prompts, messages, menu items, screen elements, and so on.

The following conventions are used for the presentation of material:

- The words in names of screen elements (for example, the title in the title bar of a window, the label for a field in a dialog box) are initially capitalized.
- Capital letters are used for the name of a keyboard key if it is labelled on the keyboard. For example, press the ENTER key.
- Lowercase letters are used for the name of a keyboard key that is not labelled on the keyboard. For example, the space bar, comma key, and so on.
- Press CTRL+C indicates that you must hold down the CTRL key while pressing the C key (to copy a selected object in this case).
- The names of push and toggle buttons are boldfaced. For example, click OK.
- The names of menus and menu items are boldfaced. For example, the File menu.
- The following convention is used for menu operations: MenuName > MenuItem > CascadedMenuItem. For example: choose File > New > Type.
- The Start menu name always refers to the Start menu on the Windows Task Bar.
- System prompts/messages are shown in the Courier font, and user responses/input in boldfaced Courier font. For example, if you enter a value out of range, the following message is displayed:

Entered value is not valid. The value must be 0 to 30.

 You may be instructed to enter the string TIC132 in a field. The string is shown as follows in the procedure:

TIC132

• Variables are shown in italics:

IOPar.Govmode8.value

Faceplate tabs are boldfaced:

AVR Mode handler

Warning, Caution, Information, and Tip Icons

This publication includes **Warning**, **Caution**, and **Information** if/where appropriate to point out safety related or other important information. It also includes **Tip** to point out useful hints to the reader. The corresponding symbols should be interpreted as follows:



Electrical warning icon indicates the presence of a hazard which could result in *electrical shock*.



Warning icon indicates the presence of a hazard which could result in *personal injury*.

Caution icon indicates important information or warning related to the concept discussed in the text. It might indicate the presence of a hazard which could result in *corruption of software or damage to equipment/property*.



Information icon alerts the reader to pertinent facts and conditions.

Tip icon indicates advice on, for example, how to design your project or how to use a certain function.

Although **Warning** hazards are related to personal injury, and **Caution** hazards are associated with equipment or property damage, it should be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process performance leading to personal injury or death. Therefore, comply fully with all **Warning** and **Caution** notices.

Terminology

 Table 1 lists terms used in this document and associated with the Process Power Manager 5.

 The reader should be familiar with these terms before proceeding further in this user manual.

Term	Description		
AC 800M/C Connect	Name of the connection/integration between Control IT for AC 800M/C and Operate IT. The following software packages are included under this name:		
	- Aspect System for AC 800M/C		
	- Graphics Object Type Library for AC 800M/C		
Aspect	A description of some properties of an Aspect Object. Some examples of aspects are name, circuit diagram, process display and control logic.		
Aspect Object	A computer representation of a real object, such as a pump, a valve, an order or a virtual object, such as a service or an object type. An Aspect Object is described by its aspects and these aspects are organized in structures.		
Aspect System for AC 800M/C	One part of the AC 800M/C Controller Integration product (the other part is the Graphic System for C 800M/C Operate IT Process Portal from Control Builder Professional.		
Connectivity Server	nectivity Provides the integration between the Operate IT system and a controller or a device capable of sourcing data.		

Table 1 Terminology

Term	Description	
Contingency	An electrical network within the plant consists of at least one load busbar to which loads generation and the public grid can be connected. Several of these electrical networks can exist at the same time within the plant electrical network. Each combination is called a contingency.	
Control	Name of the Control Builder M software products. Available in three versions: Control Builder Basic, Control Builder Standard and Control Builder Professional.	
Builder M	These are fully integrated Windows 2000 Professional / Windows XP applications for efficient configuration and programming of the ABB controllers AC 800M, AC 800C and Advant Controller 250.	
Control Builder The powerful programming version of the Control Builder M software. Professional		
Control Builder Project Explorer	rol ler The name of the project navigator in the Control Builder M software, which is used to navigate through, create or modify an automation project. orer	
Control IT for AC 800M/C	The name of the collection of ABB hardware and software products for AC 800M/C.	
Control Product name of the ABB network between AC 800M/C controllers, tools and Operato workplaces.		
Critical breaker A breaker the position of which determines the electrical network configuration		
Display Element	DisplayA graphical element, which illustrates an object (motor, regulator etc.). In general, clicking on the element will show a faceplate for supervision and control of the object	
Electrical network	A combination of components such as load busbars, generators, transformers and cables connected electrically. A network contains at least one load busbar.	
FaceplateA configurable type of graphic interface normally used by operators for process supervision and control.		
Graphics Type Library for AC 800M/C	One part of the AC 800M/C Controller Integration product (the other part is the Aspect System for AC 800M/C, see above). Graphic aspects such as display elements, faceplates and dialogs are available for use in Operate IT Workplace. The graphic aspects correspond to the types delivered in the Control Builder library.	
HSI	Human System Interface.	
Instance	An individual description of the type. Every instance has the characteristics defined by the type, but each instance has its own individual behaviour.	
I/O	Input / Output signals.	
IT	Information Technologies.	
LVS	Low Voltage Switchgear.	
MCC	Motor Control Centre.	
MMS	Manufacturing Message Specification. Specifies the structure of messages used for industrial communication (manufacturing, process robotics, etc.). This is the application layer used within MAP (Manufacturing Automation Protocol), a specification for open communication based on the OSI model. MMS for AC 800M/C is a protocol used in ABB Control Network communication.	

Term	Description			
Object	Objects represent the combination of data and associated procedures (operations that can be applied to the data) are represented. Objects represent significant elements or functions in the process control/process automation domain. Combining these objects creates applications.			
OPC	OLE for Process Control. The Control IT for AC 800M/C software contains an OPC Server for AC 800M/C.			
Operate IT	erate IT The name of the collection of ABB products for daily operation and supervision of an automated process. These products provide an environment for different user categories, such as engineer operators and maintenance personnel.			
Plant Explorer	The name of the project or plant navigator in the Operate IT workplace for creating the Aspect Objects that are used for assembling the various components of the plant. Can also be used for browsing and searching the structures of the plant.			
PMS	Power Management System.			
PPM	PM Process Power Manager.			
Process Panel	The name of the ABB product for local process monitoring and control. The key functionality is presentation of process information (numerical, text or graphical) on loc operator or process panels including functional control keys.			
Process Portal A	The name of the ABB product for process monitoring and control. The key functionality is presentation of process graphics, usage of faceplates, presentation of trends, and presentation of alarms.			
Structure	A hierarchical tree organization of Aspect Objects that describes the dependencies between the real objects. An Aspect Object can exist in multiple structures, e.g. both in functional structure and in a location structure.			
System Extension	A plug-in software package, which provides the Operate IT system with extended functions and properties.			
Туре	A general description of a unit that defines the behaviour of an individual unit called Instance. See also Instance.			
DCS	Distributed Control System.			
ENMC	Electrical Network Monitoring & Control.			

Related Documentation

Related documentation includes, but is not limited to, the table below. Other ABB 800xA documentation may also be relevant when configuring an 800xA Process Power Manager.

Document ID	Title	
3BNP100234-0390	PMS Library 5.6-5 Release Notes	
3BNP100234-0391	PMS Library 5.6-5 Circuit Breaker Control	
3BNP100234-0392	PMS Library 5.6-5 Generator Control	
3BNP100234-0393	PMS Library 5.6-5 Transformer Control	
3BNP100234-0394	PMS Library 5.6-5 Loadshedding	
3BNP100234-0395	PMS Library 5.6-5 Power Control	
3BNP100234-0396	PMS Library 5.6-5 Restart & Reacceleration	
3BNP100234-0397	PMS Library 5.6-5 Report Data Collector	
3BNP100234-0398	PMS Library 5.6-5 Synchronization	
3BSE037410	Administration and Security	

Table 2 Related Documentation

Target Audience

This user manual is primarily intended for technical sales personnel, application, system engineers and maintenance personnel within ABB, external users and customers.



This user manual does not contain last-minute product information and updates which might affect functionality and/or performance. For information on last revisions, late changes and restrictions the user shall refer to *Release Notes*.



Some graphics have been carried over from previous loadshedding manuals, hence Windows frames, and aspect names, library versions, etc. might be different than in current 800xA and PMS version. (e.g. PG2 suffix in aspect names is no longer present, etc.)

Compatibility

For compatibility with previous versions of the product, refer to the *Release Notes* 3BNP100234-0390.

System Security

The supplier of automation systems, based on PMS libraries, is responsible for the system integrity and security. We strongly recommend that strict password policies are applied.



Reference is made to document *Administration and Security*. The whole manual must be carefully consulted, with special attention given to *Security Planning* and *Security Configurations* for guidelines regarding system security, user authentication, and password policies and setting up audit trails.

Section 1 General

When an industrial electrical network experiences severe voltage sags or short duration power interruptions, a certain number of motors (MV or LV) can be tripped by their electrical and mechanical protections, resulting in a plant upset. To minimize process disturbance or even avoid complete plant shutdown, motors used for critical services must be re-accelerated quickly, automatically and sequentially, assuming that they were running before occurrence of the voltage sag and were tripped during it.

The voltage-controlled time-staggered restart of electrical motor groups following a trip due to voltage sags is labeled as "reacceleration schedule".

If voltage is recovered in a short time after a fault, the shafts of the motors that got tripped during the undervoltage stage might still rotate (depending on their driven load, duration of voltage sag, etc.) and they can be reaccelerated in a certain sequence, in order to minimize disturbance to the plants process flow.

Not all the motors are part of the reacceleration sequence. The need for automatic reacceleration is specified by process designers using the following pattern:

- necessary motor driven equipment required to keep the unit operating without equipment damage and without safety equipment operating, but not necessary on product specification
- desirable additional motor driven equipment required to keep units products on specification.
- unnecessary operator restart is sufficient without adverse effect on unit or product specification.

Only the necessary and desirable motors should be part of the reacceleration sequence.

Section 2 Function

The reacceleration function is an automatic function which does not require operator intervention in order to operate. For a better understanding of its operation, the reacceleration function can be divided into 3 states/sequences:

- idle state, where it normally operates.
- **arming** state, that recognizes all inputs which would cause an initiation of the reacceleration sequence
- operational state, which covers the actual reconnection of the loads

2.1 Idle state

The idle state represents the most usual state for the reacceleration function, as it is corresponding to a normal voltage level within the electrical network. In idle state the function monitor:

- undervoltage stage activation
- running status of the motors

2.2 Arming state

The arming state starts from detection of an undervoltage stage (that is expected to determine the loads tripped) and it lasts until the voltage has recovered above a certain limit or cancelled. From that point onward, the function could enter into operational state or turn back to idle state.

Detection of an undervoltage stage can happen while the function is in idle state or even when it is in operational state, if a 2nd undervoltage stage occurs during operational state due to motors' reacceleration. In arming state the function monitors:

- undervoltage stage activation
- voltage recovery stage activation
- running status of the motors for trip indication

If voltage has recovered within the allowed voltage recovery time, then arming state is over and the function enters the operational state. Otherwise, reacceleration sequence is cancelled and function enters idle state. An overview of the functional flow from detection of undervoltage stage and voltage recovery to transition between the three states is shown in Figure 1.



Figure 1 Overview of function flow

2.3 Operational state

Operational state fulfills the task of reconnecting the motors which have tripped during arming state and were running in idle state. As the operational state of the function is activated, the function will compute a priority table for the respective busbar(s). This table represents the reconnection sequence of the motors, according to its priorities. A motor is part of this table if:

- has a reacceleration priority
- not manual or system inhibited
- motor was running before arming state

The reconnection sequence is based solely on the priority number of each motor. Therefore, one reconnection step implies reconnection of one reacceleration group, which is given by all the motors with same reacceleration priority. Based on the reacceleration table, the function will address each priority from the lowest to the highest one by one. Additional, the operation state monitor the following:

- undervoltage stage activation
- voltage recovery stage activation
- reconnected\disconnected load that was scheduled in the arming stage

Once all the loads are reconnected, has failed to reconnect or timed out, the sequence is complete. The function returns to idle state and the historical data is transferred to a report.

2.4 System constraints

The restart and reacceleration function have several system constraints that should be considered at the beginning of the detailed engineering. The function is limited to the following constraints:

- coordination of 2 single busbars in the substation type
- 50 loads on each single busbar
- 20 configurable priority groups
- the report function can handle 4 voltage sags\recoveries
- non-coordinated outside the substation type

2.4.1 Non-coordinated reacceleration function

The function is implemented as a non-coordinated approach which implies that reconnection sequence is restricted to the substation configuration with 2 single busbars as illustrated in Figure 3. The substation type only looks upon its own voltage level and priority assignments and does not take other substations into consideration. This could lead to an overload state of certain components of the electrical network.



The restart and reacceleration functionality does not pay any respect to availability of active and reactive power within an electrical subnetwork when it decides the reconnection of a priority group.

Section 3 Control Module

The *pmsReAccSub* control module is included in the pmsReAccelLib library. A block presentation of the control module is shown in Figure 2.



Figure 2 Control module pmsReaccSub

Parameter	Parameter Direction	Significance
Enable	Input	Enabling of the function. If TRUE the control module is executed.
Name	Input	Name of the object. With the name upload tool of the process portal, this property will be used for identifying the object in the 800xA system. The name will be used for grouping the alarms and events and identifying the faceplate of an object. The name must be unique in the project.
Description	Input	Description of the object.

Parameter	Parameter Direction	Significance
		With the name upload tool of the process portal, this property will be used for identifying the object in the 800xA system.
AlSeverity	Input	Alarm severity. The alarm severity can be used for filtering the alarm list. Range 1-1000.
EvSeverity	Input	Event severity. The event severity can be used for filtering the event list. Range 1-1000.
Class	Input	Alarm and Event Class. This parameter can be used for grouping objects to appear in separate alarm/event lists. Range 1-9999.
TaskNormal	Input	Execution cycle for HSI logic
BusA	Input	Busbar text. Default set to Busbar A and displayed in the Main faceplate element.
BusB	Input	Busbar text. Default set to Busbar B and displayed in the Main faceplate element.
FunctionMode	Input	Text configuration of the faceplate for either restart or reacceleration.
LBBA_ID	Input	Index of the load busbar to which the A side of the substation is connected to (for future use).
LBBB_ID	Input	Index of the load busbar to which the B side of the substation is connected to (for future use).
LoadsANOF	Input	Number of loads connected to the A side of the substation (max 50).
LoadsBNOF	Input	Number of loads connected to the B side of the substation (max 50).
BusAUnderVoltage	Input	Undervoltage indication on busbar A as an extended DI datatype with provision for external timestamp of signal (IO from undervoltage relay).
BusBUnderVoltage	Input	Undervoltage indication on busbar B as an extended DI datatype with provision for external timestamp of signal (IO from undervoltage relay).
BusARecoveryVoltage	Input	Recovery voltage indication on busbar A as an extended DI datatype with provision for external timestamp of signal (IO from overvoltage relay).
BusBRecoveryVoltage	Input	Recovery voltage indication on busbar B as an extended DI datatype with provision for external timestamp of signal (IO from overvoltage relay).
BusAVoltage	Input	Voltage measurement on bus A.
BusBVoltage	Input	Voltage measurement on bus B.
EnableSecUnderVoltCheck	Input	Enable undervoltage check if undervoltage DI is in error.
EnableSecRecVoltCheck	Input	Enable recoveryvoltage check if overvoltage DI is in error.
GlobalPrioConfig	Input	Structured parameter for global configuration of the function and priority configuration.
ExtPar	Input	External parameters for application interaction. With this parameter it is possible to disable alarm and events and block the function from executing.

Parameter	Parameter Direction	Significance
ExtPrio	Input	Structured parameter for external priority commands (for future use).
CBA_C	Input	Checked closed position of the A incomer of the substation.
CBB_C	Input	Checked closed position of the B incomer of the substation.
CBT_C	Input	Checked closed position of the tie breaker of the substation.
LoadA	Input & Output	Structured parameter which contains all the data for load objects connected to panel A of the substation.
LoadB	Input & Output	Structured parameter which contains all the data for load objects connected to panel B of the substation.
Status	Output	Structured parameter for status indications.

The control module pmsReAccSub is suitable for handling the type of substation configurations, as shown in Figure 3.



Figure 3. Substation configuration for pmsReAccSub

3.1 Detailed Engineering

The restart & reacceleration function in the PMS Library is based on the control module type pmsReAccSub. The control module monitors voltage on each bus section and running loads in a substation configuration. The following features are supported:

3.1.1 Voltage monitoring

The pmsReAccSub control module can monitor voltage on both bus sections in a substation configuration. The following features are supported:

- o undervoltage monitoring from undervoltage relay.
- o recovery voltage monitoring from overvoltage relay.
- o monitor analogue voltage value

3.1.2 Load monitoring

Up to 50 loads on each bus section can be interfaced with one pmsReAccSub control module. The following interactions are provided to the operator:

- o priority configuration
- o operator Inhibit
- o individual load configuration

3.1.3 Blocking

There are three ways to block the restart and reacceleration function:

- o operator blocking
- o external blocking
- o internal condition

3.1.4 Configuration

Configuration may be done on three levels, individual load configuration supersedes the other:

- o global configuration
- o priority configuration
- o load configuration

3.1.5 Operator interface

The operator interface is provided through a dedicated faceplate for the *pmsReaccSub* module.

3.1.6 History reporting

When reacceleration function has completed or cancelled its sequence, the pmsReAccSub control module can generate a report with historical data about the sequence. The following features are supported:

- o up to 4 voltage sags and/or recoveries.
- o failed to restart
- o inhibited loads
- o successful restart
- o loads not running

3.1.7 Alarm & Event handling

Critical operational changes that affect the reacceleration sequence are recorded and presented in Alarm and Event lists.

3.1.8 Voltage monitoring

The control module pmsReAccSub provides input for detection of voltage stages both for voltage sags or deeper disruptions and normalized voltage levels on both bus sections of the substation.

3.1.8.1 Undervoltage

To detect an undervoltage stage the pmsReAccSub provides two extended BoolIO data types of *pmsReAccBoolIOExt* that provide the option to external timestamp event via DI830 digital input card. The data type *pmsReAccBoolIOExt* allows monitoring of the I/O channel status, which is important for the signal error handling inside the control module logic. In cases where the measurement is not BoolIO, logic outside the control module must be made for the signal quality status.

Parameter configuration	Description
BusAUnderVoltage.Value	Detection of undervoltage on bus A.
BusAUnderVoltage.ExtTimeStamp	External timestamp configuration.
BusAUnderVoltage.SignalID	Signal mapping to IO module.
BusBUnderVoltage.Value	Detection of undervoltage on bus B.
BusBUnderVoltage.ExtTimeStamp	External timestamp configuration.
BusBUnderVoltage.SignalID	Signal mapping to IO module.

Table 4	Parameters	configuration	for une	dervoltage

In all function states the activation of undervoltage stage will always alter the function state from idle to arming or from operational to arming. When the undervoltage stage is activated the voltage below decay level LED transitions from grey to red, the no. of voltage decay count increases, and an alarm is raised and the active stage changes to arming. See Figure 4 for details.



Figure 4 faceplate with busbar status of undervoltage state



The function can be configured for maximum number of voltage sags that could take place before cancelling the sequence. This can be accessed via parameter GlobalPrioConfig.Global.MaxNrVoltageDecays or from Max no. of voltage decay setting in **Priority settings** tab in the extended faceplate.

3.1.8.2 Recovery voltage

To detect a normalized voltage level the pmsReAccSub provides two extended BoolIO data types of *pmsReAccBoolIOExt* that provide the option to external timestamp event via DI830 digital input card. The data type *pmsReAccBoolIOExt* allows monitoring of the I/O channel status, which is important for the signal error handling inside the control module logic. In cases where the measurement is not BoolIO, logic outside the control module must be made for the signal quality status.

Parameter configuration	Description
BusARecoveryVoltage.Value	Detection of recovery voltage or normalized voltage on bus A.
BusARecoveryVoltage.ExtTimeStamp	External timestamp configuration.
BusARecoveryVoltage.SignalID	Signal mapping to IO module.
BusBRecoveryVoltage.Value	Detection of recovery voltage or normalized voltage on bus B.
BusBRecoveryVoltage.ExtTimeStamp	External timestamp configuration.
BusBRecoveryVoltage.SignalID	Signal mapping to IO module.

Tabl	~ ~	Doromoti	ar aanf	inversi	ian far	KO O O VO KI	valtaga
Tapi	e o	Paramete		iuurau		recoverv	voilage

In both arming and operational states of the function an activation of the recovery voltage stage will always alter the function state from arming to operational and a loss of recovery voltage signals will alter the function state from operational to arming. When recovery voltage stage is activated the voltage above recovery level LED transitions from grey to green and the active stage change to operational.



Figure 5 Faceplate with busbar status of voltage recovery state

The function can be configured for maximum allowed voltage recovery time. This can be accessed via parameter *GlobalPrioConfig.Global.AllowedVoltRecoveryTime* or from Allowed voltage recovery time setting from **Priority settings** tab in the extended faceplate.

3.1.8.3 Analogue voltage measurement

Two parameters of data type RealIO are provided for analogue measurement. The data type RealIO allows monitoring of the I/O channel status, which is important for the signal error handling inside the control module logic. In cases where the measurement is not RealIO, logic outside the control module must be made for the signal quality status.

Both measurements are used as a backup solution for detection of both undervoltage and recovery voltage.

Parameter configuration	Description
BusAVoltage.Value	Analogue voltage measurement for bus A
BusBVoltage.Value	Analogue voltage measurement for bus B

Table 6	Parameter	configuration	for voltage	measurement
		ooning an a dorn	ioi ioitago	

If primary undervoltage detection parameter is faulty and *EnableSecUnderVoltCheck* is set to True the function considers an undervoltage stage to be active on the bus when the voltage measurement is less or equal to Voltage decay level setting. This setting can be configured via parameter *GlobalPrioConfig.Global.VoltageDecayLevel* or from Voltage decay level setting in **Priority settings** tab in the extended faceplate.

If primary recovery voltage detection parameter is faulty and *EnableSecRecVoltCheck* is set to True the function considers a recovery voltage stage to be active on the bus when the voltage measurement is higher or equal to Voltage recovery level setting. This setting can be configured via parameter *GlobalPrioConfig.Global.VoltageRecoveryLevel* or from Voltage recovery level setting in **Priority settings** tab in the extended faceplate.

3.1.8.4 Signal transition

In the event of a signal transition period where both undervoltage and recovery voltage signals are high, the module will act as following;

- Block of the function and cancelation of the sequence if GlobalPrioConfig.Global.SignalTransitionT is set to 0s(disable)
- For a *GlobalPrioConfig.Global.SignalTransitionT* of more than 0s; it is assumed that the latest signal are up-to-date and the "older" signal suppress (i.e. In Idle state where recovery voltage signal is high and for some cycles later also the undervoltage is high, the function will suppress the voltage recovery signal and enter into arming stage). The signal is only suppressed while both are high and SignalTransitionT has not elapsed. If both signals remain high after SignalTransitionT has elapsed, the function is blocked and the sequence cancelled. See Table 7 for prioritized signal.

Function stage	Priority signal in transition period
Idle	Undervoltage
Arming	Recovery Voltage
Operational	Undervoltage

Table 7 Prioritized voltage signal related to function stage

3.1.8.5 Built-in Error handling

The function has built-in signal error handling. Both undervoltage and recovery voltage parameters are of data types that allow monitoring of the I/O channel status, which is important for the signals handling. In a substation configuration when the tie breaker is closed, the healthy signal will be transferred to the bus with faulty measurement. If both are faulty and a backup solution with secondary undervoltcheck\recoveryvoltcheck is disabled, the function will go into blocking condition. For more details about blocking, see chapter 3.1.3. The project can specify the healthy condition signal from the **project constants**->**pmsConstants**->**cStatusOK** and **cStatusMask** for masking of signal before comparison check with **cStatusOK**.

3.1.9 Load monitoring

The control module handles 50 loads connected to each half-panel of a substation configuration. The supported functions for each load are:

3.1.9.1 Running status monitoring

The pmsReAccSub module monitors the running feedback for determining which load was running prior to an undervoltage. The running feedback signal can be based on a simple "breaker closed feedback" or be based on operation conditions of the motor (speed, torque, current, etc.).

3.1.9.2 Individual configuration timers

Each load has provision for individual configuration within a priority group. For the ease of configuration each load can also be assigned to inherit the configuration settings for the priority group settings.

3.1.9.3 Operator interaction and status

The pmsReAccSub control module provides the following features for operator interface:

- o definition of priority for a load
- inhibiting of close commands and thus preventing the load from being restarted.
- o monitoring of load value and automatic inhibited loads

3.1.9.4 Reconnect, output command

If a load was connected to the busbar prior to an undervoltage, the load is scheduled for restart. When the operational stage executes the scheduled loads priority group, the control module shall activate a pulsed digital output for reconnecting the assumed tripped load.

3.1.9.5 Alarms and Events

Critical operational changes that affect the loads are recorded and presented in Alarm and Event lists.

3.1.9.6 Feedback monitoring

The structured *LoadPar* parameter of the control module pmsReAccSub must be configured to receive the running feedback signal that confirms that the load is connected to a load busbar and the circuit breaker is in remote point of control (i.e. PMS control) to restart the load. These parameters are structured data types and the components applicable are shown in Table 8.

Parameter configuration	Description		
Load.LoadPar.RunningStatus	Feedback signal for Load running		
Load.LoadPar.POCLoc	Circuit breaker point of control		

 Table 8 Parameter configuration for feedback monitoring

Both *LoadPar.RunningStatus* and *LoadPar.POCLoc* are of an extended BoolIO type – *pmsReAccBoolIOex* that provide the option to external timestamp event via DI830 digital input card. The data type allows monitoring of the I/O channel status, which is important for the signal handling inside the control module logic. If one of the feedback signals is faulty the load is automatically inhibited and will not be restarted.

The project will have to choose functionality behind the signal Load.LoadPar.RunningStatus, as follows:

- Based on a simple breaker closed feedback signal.
- Based on operation conditions of the motor (speed, torque, current, etc.). The signal will then contain the information that motor reached a stable operation state and its transient period has ended.

The functionality behind the running status will affect how the group delay timers are configured, see chapter 3.1.15.2 for more details.

3.1.9.7 Individual configuration timers

Each load can be configured individually whilst belonging to a priority group. Configuration settings can be completed from the faceplate extended view tab **Load settings**. A user with *Configure* permission can configure all settings except for priority which requires *Tune* permission.

🙀 RR_Sub : Faceplate 📃 🖂 🗙	🚧 RR_Sub : Faceplate	
RR_Sub	RR_Sub	
Load settings Priority settings	Load settings Priority settings	
Busbar A Busbar B Load 01 Image: Description of the settings	Busbar A Busbar B	1
Settings for Busbar A Load 01	Settings for Busbar A Load 01	2
Load 1 Open circuit time constant 500ms Max allowed restart time 20s Running feedback time 2s Close command pulse time 1s Max no. of restart attempts 3	Load Priority 1 Open circuit time constant 100ms Max allowed restart time 2m Running feedback time 2s Close command pulse time 500ms Max no. of restart attempts 3	3 4 5 6 7 8
<u>کر</u> ۵۰۰ د	<u>کر</u> ۲۰۰ د	

Figure 6 Faceplate configuration of Load settings

Field	Indication	ltem	Description
1	Load selection	Drop down menu	Selection of load configuration
2	Inherited settings	Check box	Checkbox to inherit settings for selected priority group
3	Priority	Input field	Configuration of the priority for the restarting function
4	Open circuit time constant	Input field	Time from detection of undervoltage to reconnection of motor to electrical network is restricted.
5	Max allowed restart time	Input field	Time from undervoltage to reacceleration should succeed
6	Running feedback time	Input field	Time from close command is given to running feedback is expected
7	Close command pulse time	Input field	Pulse length for close command
8	Max no. of restart attempts	Input field	Max number of restart attempts

Table	9 faceplat	e configuration	of load	configuration timers
1 abio	o racopiar	o oonngaraaon	01 10000	oornigaraaon arrioro



It is also possible to configure the load settings from an application code via the input parameter *Load.LoadPar* listed in table below. It is only possible to utilize application logic to set the load settings when *GlobalPrioConfig.Global.OperatorSettable* is set to False.

Table 10 Parameter configuration of load configuration timers

Parameter configuration	Description
Load.LoadParXx.OpenCircuit_time	Time from detection of undervoltage to reconnection of motor to electrical network is restricted.
Load.LoadParXx.AllowedReaccel_time	Time from undervoltageto reacceleration should succeed
Load.LoadParXx.CloseCMD_time	Pulse length for close command
Load.LoadParXx.RunningFb_timeout	Time from close command is given to running feedback is expected
Load.LoadParXx.MaxNrOfAttempts	Max number of restart attempts
Load.LoadParXx.Grouped	Individual settings to be decided by group settings

3.1.10 Operator commands

3.1.10.1 Priority definitions

The priority definition can be configured via the **Busbar A and\or B** faceplate tab, as shown in Figure 7. A user with *Tune* permission can configure the property.

RR_Sub : Faceplate				🛛 🗶 R	R_Sub : Faceplate						
	RR_Sub			2	Y	R	R_Sub			<u>A</u>	
Main Busbar A Bu	usbar B Alarms			Mai	n Busbar A Bu	usbar B Alarms					
	Load Driority	Inhibit				Load D	riority	Inhibit			
Load	kW	Manual Auto	Running Alarm		Load	kW		fanual Auto	Running) Alarm	
01 Load01A	0 11			01	Load01A	0	1		0		
02 Load02A	0 2		0 0	02	Load02A	0	2		0		
03 Load03A	0 2	0	0 0	03	Load03A	0	2	0	0	0	-2
04 Load04A	0 3		00	04	Load04A	0	3		0		
05 Load05A	0 3		0 0	05	Load05A	0	3		0		
06 Load06A	0 3		0 0	06	Load06A	0	3		0		
07 Load07A	0 3		• •	07	Load07A	0	3		0	0	
08 Load08A	0 2		•	08	Load08A	0	2		0	0	
09 Load09A	0 2		0 0	09	Load09A	0	2		0		
10 Load10A	0 2		0 0	10	Load10A	0	2		0		
11 Load11A	0 4		0 0	11	Load11A	0	4		0		
12 Load12A	0 4		0 0	12	Load12A	0	4		0	0	
13 Load13A	0 4		0 0	13	Load13A	0	4		0		
14 Load14A	0 5		0 0	14	Load14A	0	5		0		
15 Load15A	0 5		00	15	Load15A	0	5		0	0.	
	<u>هه</u>	000	وير			٥	00	000		B	

Figure 7 faceplate configuration of priority configuration

Table 11 Faceplate configuration for priority definitio

Field	Indication	ltem	Description
1	Priority	Input field	Configuration of the priority for the restarting function
2	External priority	Numerical field	Externally set priority from application code.



It is also possible to configure the priorities from an application code via the input parameter *Load.LoadPar*:

- When the input parameter *Load.LoadPar.ExtPrioSel* is true, the priority will follow the values from the input parameters *Load.LoadPar.Prio* respectively and the faceplate interaction will be restricted, as shown in Figure 7.
- After the parameter *Load.LoadPar.ExtPrioSel* returns to false, the priorities will remain to their current values and the faceplate interaction will be enabled.

3.1.10.2 Inhibit restart commands

The load can be manually inhibited from a user, via Manual inhibit checkbox, through faceplate interaction from **Busbar tab**. If signal quality of running feedback, close command or circuit breaker point of control is in error, the load will automatically be inhibited.

RR_Sub : Face	plate			<u>۲</u>	RR_Sub : Facepl	ate				_ 🗆 🗙	
	RR_S	ıb		2	$\overline{\mathbf{N}}$		RR_Sub)			
Main Busbar	Busbar B Alarms			M	ain Busbar A	Busbar B Alarms	5				
	Load Driori	, Inhibit		1		Load	Driority	Inhibit			
Load	kW	^{,y} Manual Auto	Running Alarm		Load	kW	FILITIES	Manual Auto	Running	g Alarm	
01 Load01A	0 1		0 0 -	01	Load01A	0	1		0		
02 Load02A	0 2		• •	02	Load02A	0	2				'
03 Load03A	0 2		• • •	03	Load03A	0	2		0	07	H^2
04 Load04A	0 3	🗹 Inhib	it on Inhibit off	04	Load04A	0	3		•		
05 Load05A	0 3		0 0 _	05	Load05A	0	3		0		
06 Load06A	0 3		• •]	06	Load06A	0	3		0	0	
07 Load07A	0 3		• •]	07	' Load07A	0	3		0		
08 Load08A	0 2		• •]	08	Load08A	0	2		0		
09 Load09A	0 2		• •]	09	Load09A	0	2		0		
10 Load10A	0 2		• •]	10	Load10A	0	2		0		
11 Load11A	0 4		• •]	11	Load11A	0	4		0		
12 Load12A	0 4		• •]	12	Load12A	0	4		0		
13 Load13A	0 4		• •	13	Load13A	0	4		0		
14 Load14A	0 5			14	Load14A	0	5		0	0	
15 Load15A	0 5		0 0].	15	Load15A	0	5		0		
	<u>ه</u>	000	R			♦	*	000		ß	

Figure 8 Faceplate configuration for inhibit interaction

Field	Indication	ltem	Description
1	Manual Inhibit	Check box	Inhibit load from restarting sequence.
2	Automatic Inhibit	Indication	Automatic inhibit of load from restarting sequence; 1) I/O Error (RunningStatus or Close_CMD or POCLoc status is in error) 2) External inhibit

Table 12 Faceplate	configuration	for inhibit	interaction
--------------------	---------------	-------------	-------------

A user with *Tune* permission can set this property.



It is also possible to automatically inhibit the load via external application code by setting input parameter *Load.LoadPar.ExternalInhibit* to True.

3.1.11 Reconnect, output command

Based on the reacceleration table, the function will address each priority from the lowest to the highest, one by one and the following conditions will be checked before the load is issued a reconnect command:

- time elapsed from disconnection is greater than the load's open circuit time constant
- time elapsed from disconnection is lower than max allowed reacceleration time
- load is not inhibited (external, operator or I/O error) from participation in the reacceleration sequence. (i.e. the stand-by unit has started in the meantime, DCS process flow restriction)
- number of max reconnection attempts are not reached
- circuit breaker is in Remote point of control (the function will not pay any respect to mode of the breaker within ENMC system: manual or automatic)

If the only condition not fulfilled is the load's open circuit time constant, then the function will wait for that time to elapse and proceed with close command, if the rest are met. If one of the last four conditions is not fulfilled, the load will be removed from reacceleration sequence but the overall reacceleration function will continue. Hence that condition related to open circuit time constant may delay the command for other reacceleration groups in cases where time constants of motors are different. This is due to the delay timer starts after the last executed load in a priority group has completed or failed.

If all the above conditions are fulfilled, the reacceleration function will give a close command to all load breakers within the current reacceleration group. The function can be configured to perform a certain number of close command attempts if the motor running feedback is not received after the first command. At the moment when the first close command is given for the current reacceleration group, a timer is started to:

- monitor the time from close command is given to running status is received (*Running feedback time*)
- monitor the time interval between different acceleration priorities (*Reacceleration groups' timers*)

3.1.11.1 Load Status

Each load has several status indications that can be helpful for a project to build application logic. The parameters can be found in table below.

Parameter configuration	Description
Load.LoadParXx.Disabled	Load status, load is disabled for restart
Load.LoadParXx.Signal_Err	Load signal error indication
Load.LoadParXx.FailedReaccel	Load status, failed to restart
Load.LoadParXx.InhibitStatus	Load status, Automatic\Operator inhibit active

Table 13 Parameter for load status

3.1.11.2 Alarms and Events

For more details see chapter 3.1.18 for alarms and chapter 3.1.19 for events.

3.1.12 Alarm & Event disabling

The control module pmsReAccSub provides the possibility to disable alarms & events from the configuration parameter *ExtPar*. The alarm and events that can be disabled are described in table below.

Parameter configuration	Description
ExtPar.DisUnderVoltAlarm	Disables undervoltage alarm
ExtPar.DisRepVoltSagAlarm	Disables repeating voltage sag alarm
ExtPar.DislOErrorAlarm	Disables IO error alarm
ExtPar.DisSpuriousAlarm	Disables spurious condition alarm
ExtPar.DisConfigError	Disables configuration error alarm
ExtPar.DisActiveStageEvent	Disables active function stage event
ExtPar.DisEnableEvent	Disables enable\disable event
ExtPar.DisBlockEvent	Disables block event
ExtPar.DisAbortRestartEvent	Disables abort restart sequence event
ExtPar.DisResetEvent	Disables reset event
ExtPar.DisReleasePrioEvent	Disables released priority event
ExtPar.DisLoadEvOpInhibit	Disables load manual inhibit event
ExtPar.DisLoadEvAutoInhibit	Disables load auto inhibit event
ExtPar.DisLoadEvFailedRestart	Disables load failed restart event
ExtPar.DisLoadEvPrioChange	Disables load priority change event
ExtPar.DisLoadEvRunningFb	Disables load running feedback event
ExtPar.DisLoadEvRunningFbLost	Disables load running feedback lost event
ExtPar.DisLoadEvCMD	Disables load close command event
ExtPar.DisLoadIOErrorAlarm	Disables load IO error alarm
ExtPar.DisLoadConfigErrorAlarm	Disables load configuration error alarm

Table 14 Parameter for external disabling of alarms & events



Disabling of events *ExtPar.DisLoadEvCMD*, *ExtPar.DisLoadEvRunningFb* and *ExtPar.DisLoadEvRunningFbLost* have will more than half the execution time of the module and should be considered if fast execution time is required.

3.1.13 Blocking

The restart and reacceleration function is subject to blocking condition and there are three blocking conditions available;

- manual block
- automatic block
- external block

	🔀 RR_Sub : Faceplate	🕍 RR_Sub : Faceplate	
	RR_Sub	RR_Sub	
	Main Busbar A Busbar B Alarms	Main Busbar A Busbar B Alarms	
	Restart status	Restart status	
_	Enabled Enable	Enabled Enable	
(1)	Blocked status Disable	Blocked status	6
	Bushar A Operator	Bushar A External Reset	
	Busbar B Not blocked B Block Linblock	Busbar B Not blocked Block Busbar A	-0
3	Block Bushar B	Block Busbar B	
\bigcirc	Circuit breaker status	Circuit breaker status	
	Incomer A	Incomer A	
	Incomer B	Incomer B	
	O Bus tie	O Bus tie	
	Busbar Status	Busbar Status	
	Busbar A Busbar B	Busbar A Busbar B	
	Idle Idle Active stage	Idle Idle Active stage	
	Voltage above recovery level	Voltage above recovery level	
	Voltage below decay level	Voltage below decay level	
	0 of 5 0 of 5 No. of voltage decays	0 of 5 0 of 5 No. of voltage decays	
	<u>کر</u> 💀 د	<u>ه</u> وم	

Figure 9 faceplate configuration of block

Field	Indication	ltem	Description
1	Blocking status	Indication field	Busbar blocked status – blocked by operator.
2	Block command	Command button	Command option to Block or Unblock.
3	Block indication	Indication field	Indication of block operator action.
4	Block indication	Indication field	Busbar blocked status – blocked by external logic.

Manual block operation is available to users with Operate permission.



It is also possible to block the function from executing via external application code by setting input parameter *ExtPar.ExBlock_BusbarX* to True. The external block text presented in the main faceplate is configured via parameter *ExtPar.ExBlock_BusbarXEvent*.



Figure 10 Faceplate indication of automatic block

Table 16 Main	faceplate	automatic	block	interaction
---------------	-----------	-----------	-------	-------------

Field	Indication	Item	Description	
1	I/O error	Indication field	Internal block caused by I\O error	
2	No. of voltage decays	Indication field	Internal block caused by Maximum voltage decays	
3	Spurious condition	Indication field	Internal block caused by spurious condition	
4	Block indication	Indication fieldBusbar blocked status – blocked by internal logic;1) I/O Error (on both busbar if interconnected)		
			 Spurious condition (on both busbar if interconnected) No. of voltage decays >= Max no. of voltage decays 	

3.1.14 External priority

The *ExtPrio* parameter is set aside for future use.

3.1.15 Configuration

3.1.15.1 Global configuration

The control module pmsReAccSub provides two options when configuring the global settings. All settings are configurable via parameter connection *GlobalPrioConfig*. Most settings which could be subject to tuning are available via the faceplate Priority settings.

	🕍 RR_Sub : Faceplate	🕊 RR_Sub : Faceplate
	RR_Sub	RR_Sub
	Load settings Priority settings	Load settings Priority settings
1 2 3 4 5 6 7 8 9 10	Global Image: Constraint of the second s	Global • Global • Priority 01* • Priority 02 ation Priority 03 ation Priority 04 / level Priority 05 evel Priority 06 / hysteresis Priority 07 / hysteresis Priority 08 recovery time Priority 10 ge decays Priority 12 • Priority 13 1s Priority 14 • Priority 15 • Priority 16 • Priority 17 e constant Priority 18 atrt time Priority 20 • k time 2s Close command pulse time 500ms
11	Max no. of restart attempts 3	Max no. of restart attempts 3
<u> </u>		
12	ر الار الم	<u>کر</u> ۲۰۰۰ د

Figure 11 Faceplate configuration of Global settings

An asterisk (*) indication behind a priority group in dropdown menu, indicates that the priority does not inherit the global settings.

Field	Indication	ltem	Description
1	Configuration selection	Dropdown menu	Selection of Global configuration or individual priority.configuration.
2	Voltage recovery level	Input field	Comparator for analogue voltage measurement to determine sufficient voltage recovery.
3	Voltage decay level	Input field	Comparator for analogue voltage measurement to determine voltage decay level is reached.
4	Voltage recovery hysteresis	Input field	The amount of time voltage should keep above voltage recovery level before actual voltage recovery should be considered and continuation of the sequence can commence.
5	Allowed voltage recovery time	Input field	The amount of time that should be considered before the sequence is cancelled and reverted back to idle due to failed voltage recovery.

Table 17 Faceplate configuration of Global settings

6	Max no. of voltage decays	Input field	The max number of voltage decays allowed from initial decay (also counted) to the sequence can be completed. After a completed sequence, the number of voltage decays is reset back to 0.
7	Restart delay	Input field	Restart delay is the delay that should be considered from last running feedback signal is received to the next priority group can be started.
8	Open circuit time constant	Input field	Time from detection of undervoltage to reconnection of motor to electrical network is restricted.
9	Max allowed restart time	Input field	Time from undervoltageto reacceleration should succeed.
10	Running feedback time	Input field	Time from close command is given to running feedback is expected.
11	Close command pulse time	Input field	Pulse length for close command.
12	Max no. of restart attempts	Input field	Max number of restart attempts.



The Global settings are only configurable from the faceplate if *GlobalPrioConfig.Global.OperatorSettable* is set to True and for users with Configure permission.

Not all configuration settings are available from the faceplate, but are only configurable from application logic. The *GlobalPrioConfig.Global* has the configuration parameters detailed in the table below.

Parameter configuration	Description		
EnableReporting	Enable reporting feature, see chapter 3.1.17 for more details.		
EnableOpReporting	For future use.		
BusbarConfiguration	The BusbarConfiguration hides busbar in main faceplate according to this setting.		
CBConfigured	The CBConfigured hides circuit breakers in the main faceplate according to this setting.		
MaxPriority	Specify max priority group utilized in the project.		
HideManualInhibit	This setting hides manual inhibit checkbox in faceplate element Busbar A and B.		
HideLoadValue	This setting hides manual inhibit checkbox in faceplate element Busbar A and B.		
OperatorSettable	This setting controls if settings should be set from application logic or faceplate.		
VoltageDecayLevel	Comparator for analogue voltage measurement to determine voltage decay level is reached.		
VoltageRecoveryLevel	Comparator for analogue voltage measurement to determine sufficient voltage recovery.		

Table 18	8 Parameter	configuration	of GlobalPr	ioConfigGlobal
----------	-------------	---------------	-------------	----------------
Parameter configuration	Description			
-------------------------	---			
VoltageRecoveryHyst	The amount of time voltage should keep above voltage recovery level before actual voltage recovery should be considered and continuation of the sequence can commence.			
AllowedVoltRecoveryTime	The amount of time that should be considered before the sequence is cancelled and reverted back to idle due to failed voltage recovery.			
MaxNrVoltageDecays	The max number of voltage decays allowed from initial decay (also counted) to the sequence can be completed. After a completed sequence, the number of voltage decays is reset back to 0.			
MaxLimit_IncomerA	For future use.			
MaxLimit_IncomerB	For future use.			
ReAccGroupDelayTime	Restart delay is the delay that should be considered from last running feedback signal is received to the next priority group can be started.			
OpenCircuit_time	Time from detection of undervoltageto reconnection of motor to electrical network is restricted.			
AllowedReaccel_time	Time from undervoltageto reacceleration should succeed.			
CloseCMD_time	Pulse length for close command.			
RunningFb_timeout	Time from close command is given to running feedback is expected.			
MaxNrOfAttempts	Max number of restart attempts.			
UpdateRunningFbT	Update rate for scanning running feedback in Idle state.			
SignalTransitionT	Transition time for undervoltage and recovery voltage signals.			



The project should consider the restart delay time setting depending on what the functionality behind the signal "Motor running status" is based on:

- If it is based on a simple "breaker closed feedback", then the delay between priorities is meant to wait for electrical network response after reconnection of a group of loads and proceed to next group if network stability allows it (voltage above recovery level at the end of group delay time). It is then assumed that response of the network will come within the priority delay time.
- If it is based on operation conditions of the motor (speed, torque, current, etc.), then that signal will contain the information that motor reached a stable operation state and its transient period due to acceleration has ended. Therefore, waiting for group delay to elapse is no longer needed and those timers become obsolete.



The project should consider at which point the trip of a motor was due to undervoltage. The order the signals are received by the control module might be misleading. The motors that have lost the "Motor running status" moments before an undervoltage, should be scheduled and subsequently restarted. The loads are scheduled if Motor running status was high 1-2s (UpdateRunningFbT) before undervoltage occurred.

3.1.15.1 Load configuration

See chapter 3.1.9.7 for details.

3.1.15.2 Priority configuration

Each priority group can be configured separately to specify time settings and required delay time for that specific priority group, otherwise settings may be inherited from global settings.

RR_Sub R	R_Sub
Load settings Priority settings Load settings Priority settings	
Priority 01 *	
1 Inherit global settings	
Priority group	
Restart delay Is Restart delay	1s
Coad Load	
Open circuit time constant Open circuit time constant Open circuit time constant	100ms
4 Max allowed restart time 30s Max allowed restart time	30s
Running feedback time 2s Running feedback time	2s
5 Close command pulse time 500ms Close command pulse time	500ms
Max no. of restart attempts 3 Max no. of restart attempts	3
اد	اکر 👐 👀

Figure 12 Faceplate configuration of priority group settings

Table 19 Main	faceplate	automatic	block i	nteraction
---------------	-----------	-----------	---------	------------

Field	Indication	ltem	Description
1	Inherit global settings	Check box	Enables or disables inheritance of global settings.
2	Restart delay	Input field	Delay from last running feedback signal is received to the next priority group can be started.
3	Open circuit time constant	Input field	Time from detection of undervoltage to reconnection of motor to electrical network is restricted.
4	Max allowed restart time	Input field	Time from undervoltage to reacceleration should succeed.
5	Running feedback time	Input field	Time from close command is given to running feedback is expected.
6	Close command pulse time	Input field	Pulse length for close command.
7	Max no. of restart attempts	Input field	Max number of restart attempts.



The Global settings are only configurable from the faceplate if

GlobalPrioConfig.Global.OperatorSettable is set to True and for users with Configure permission.

It is also possible to configure each priority via parameter *GlobalPrioConfig.PrioGroup01-20*. See Table 18 for similar description of the parameters.

3.1.16 Operator interface



3.1.16.1 Main view

Figure 13 Faceplate element Main view

Field	Indication	ltem	Description
1	Operator note editor link	Push button link	Push button link to the operator note editor
2	Operator note editor	Input area	This is an aspect in the 800xA for operator to make notes. Only users with <i>Operate</i> permission can write notes.
3	Operator note holds information	lcon	A letter icon indicates that the operator note holds data. Empty operator notes are indicated as empty field.
4	Function status	Text Indication	Indicates the function statues (Enable or disabled)
5	Blocked status busbar A	Text Indication	If configured in the <i>GlobalPrioConfig.Global. BusbarConfiguration</i> parameter, this field indicates the block status of busbar A (the status could be any of these four; Not blocked, Operator, Internal, External)

Table 20	Faceplate	element Main	View	description
	i accpiate		V/C/V	acscription

Field	Indication	Item	Description
6	Blocked status busbar B	Text Indication	If configured in the <i>GlobalPrioConfig.Global. BusbarConfiguration</i> parameter, this field indicates the block status of busbar B (the status could be any of these four; Not blocked, Operator, Internal, External)
7	Circuit breaker status	Indication symbols	The configured circuit breakers according to <i>GlobalPrioConfig.Global.</i> <i>CBConfigured</i> will indicate closed position with a green filled circle. Grey filled circle indicates the circuit breaker is in open position. The circuit breaker text is configurable via General Property aspect BreakerText.
8	Active stage	Text Indication	The busbars configured in the <i>GlobalPrioConfig.Global</i> . <i>BusbarConfiguration</i> , indicates the currently active stage in the sequence. (the status could be any of these three; Idle, Arming, Operational)
9	Voltage above recovery level	Text Indication	The busbars configured in the <i>GlobalPrioConfig.Global</i> . <i>BusbarConfiguration</i> , indicates voltage above recovery level with a green filled circle. Grey filled circle indicates voltage is below recovery level.
10	Voltage below decay level	Text Indication	The busbars configured in the <i>GlobalPrioConfig.Global</i> . <i>BusbarConfiguration</i> , indicates under voltage with a red filled circle. Grey filled circle indicates voltage is above under voltage level.
11	No. of voltage decays	Text Indication	The busbars configured in the <i>GlobalPrioConfig.Global</i> . <i>BusbarConfiguration</i> , indicates how many voltage decays has occurred since last completed sequence. If no. of voltage decays reaches max no. of voltage decays, the function is blocked (Internal) and a reset is required to normalize.
12	Enable	Command button	This command button set the function to enable state. Only users with <i>Operate</i> permission can access the button.
13	Disable	Command button	This command button set the function to disabled state. Only users with <i>Operate</i> permission can access the button.
14	Reset	Command button	This command button resets the no. of voltage decays. Only users with <i>Operate</i> permission can access the button.
15	Block busbar A	Check box	If configured in the <i>GlobalPrioConfig.Global. BusbarConfiguration,</i> there is a command option to Block or Unblock the busbar. If both busbars are connected together, a block on one busbar will block both busbars. Only users with <i>Operate</i> permission can access the checkbox.
16	Block busbar B	Check box	If configured in the <i>GlobalPrioConfig.Global. BusbarConfiguration</i> , there is a command option to Block or Unblock the busbar. If both busbars are connected together, a block on one busbar will block both busbars. Only users with <i>Operate</i> permission can access the checkbox.



The texts in the faceplate elements are configurable via the NLS Resource Manager aspect in Plant Explorer under Library Structure > Preferences & Customizations > pms_NLS > pmsReAccelLib_PG2 \ pmsBasicText_PG2 > NLS_pmsReAccelLib_PG2 \ NLS_BasicText_PG2.

R	R_Sub : Facep	late					_ 🗆 🗙	3 <u>641</u> 1	RR_Sub : F	aceplate							×
2	Y		RR_Sul	0					Ŋ			RR_Sub	•				
						[Ī							T I I L		1
Mai	n Busbar A	Busbar B Alarms	;					Ма	in Bus	bar A Busbar B	Alarms	1					
		Load	Priority	, Inhil	bit						Load	Priority	Inhib	it			
	Load	kW		Manual	Auto I	Running	Alarm	1 —	Load		kW		Manual A	uto R	lunning	Alarm	
01	Load01A	0	1		0	0		01	Load01	.B	0	_1		0	•		-
02	Load02A	0	_2		0	0	•	02	Load02	2B	0	1		0	0		
03	Load03A	0	2		0	0		03	Load03	BB	0	1		0	0	0	
04	Load04A	0	3		0	0	0	04	Load04	łВ	0	1		0	0		
05	Load05A	0	3		0	0	0	05	Load05	БB	0	1		0	0	0	J
06	Load06A	0	3		0	0		06	Load06	ъ́В	0	1		0	0	0	
07	Load07A	0	3		0	0	0	07	Load07	'B	0	1		0	0	0	
08	Load08A	0	2		0	0	0	08	Load08	BB	0	1		0	0	0	
09	Load09A	0	2		0	0	0	09	Load09	ЭB	0	1		0	0	0	
10	Load10A	0	2		0	0		10	Load10)B	0	1		0	0	0	
11	Load11A	0	4		\bigcirc	0		11	Load11	.В	0	1		0	0	0	
12	Load12A	0	4		0	0		12	Load12	2B	0	1		0	0	0	
13	Load13A	0	4		\bigcirc	0		13	Load13	B	0	1		0	0	0	
14	Load14A	0	5		0	0		14	Load14	łВ	0	1		0	0	0	
15	Load15A							1 15	Load15	īВ	0	1		0	0		-1
		•	••				ß				<u>ه</u>	<u> </u>	***			13	1
	4		L.	4	Д	$ \bot $	L L										
	$\left(1\right)$	2	3	4	5	6	$\overline{\mathcal{O}}$										

3.1.16.2 Busbar A&B

Figure 14 Faceplate element Busbar A&B

Field	Indication	Item	Description
1	Load tag	Text Indication	This identifies each load from parameter Load.LoadPar.SrcName.
2	Load value	Text Indication	If configured in the <i>GlobalPrioConfig.Global. HideLoadValue</i> parameter, this field indicates the value assign to <i>Load.LoadPar.PLoad</i> .
3	Priority definition	Checkbox	Configuration of the priority for the restarting function. Only users with <i>Tune</i> permission can access the button.
4	Manual Inhibit	Checkbox	Inhibit load from restarting sequence. Only users with <i>Tune</i> permission can access the button.
5	Auto Inhibit	Indication symbol	Automatic inhibit of load from restarting sequence (External Inhibit, I/O Error,).
6	Running Feedback	Indication symbol	A green filled circle indicates the load is running. A grey filled circle indicates the load is not running and a yellow filled circle indicates the signal is forced from the I/O channel.
7	General Alarm	Indication symbol	A red filled circle indicates a general alarm is high (Configuration error or I/O error).A grey filled circle indicates that no alarm is active.

Table 21	Facenlate	element	Rushar A	& R	description
	racepiale	elenieni	DUSDAI A	αD	uescription

3.1.16.3 Alarm tab

У	Restart_Sub01	4
in Í Bu	sbar A Busbar B Alarms	la successi de la
Alarms	status	
-lains	- C .:	
0	limer configuration error	
Busb	ar A	
0	Spurious alarm	
0	I/O error	
0	Undervoltage alarm	
0	Exceeded max. allowed voltage decays	
Busb	ar B	
õ	J/O error	
õ	Lindenvoltage alarm	
õ	Exceeded max, allowed voltage decays	
0	Exceeded max, allowed voltage decays	

Figure 15 Faceplate element Alarms

See chapter 3.1.11.2 Alarms for more details.

3.1.16.4 Load Setting

See chapter 3.1.9.7 Individual configuration timers.

3.1.16.5 Priority Setting

See chapter 3.1.15 Configuration.

3.1.17 Reporting

The restart & reacceleration function provides a reporting feature to supplement the event list for troubleshooting and monitoring of the function. This chapter describes the step to setup a report for control module pmsReAccSub.

3.1.17.1 PMS data collector

How to install and configure the PMS data collector service is described in the PMS Report Data Collector User Manual. Please ignore steps in the manual about setting up the PMS Report Data Configuration aspect as the chapters below describe the steps for control module pmsReAccSub.

3.1.17.2 Setup reporting aspect

From the installation package, the library provides a preconfigured *Reporting_Template* aspect of type PMS report data configuration that has all necessary OPC variables available for the report.

This *Reporting_Template* aspect is only available in the Object Type Structure in 800xA PPA environment. The following steps must be completed for the reporting function to be available for the projects application instance of pmsReAccSub.

Step 1) Go to Object Type Structure and right click on the aspect *Reporting_Template* and click copy, as shown in Figure 16.

MPMSDevSVSSP2 // Plant Explorer Workplace									
No Filter		💌 🖻 Replac	:e 🗾 🔂	0 i	N 🐴 🖻	N 🎦 🖾 🖄	a 12a 45 0 ? 12a .		
E Object Type Structure	Aspects of 'pmsReAco	:Sub50'	Modified		Desc	Inherited	Category name		
MTMCommLib 1.0-11, Library Version	🐯 fpeBusbarA_50		2/23/2011 09	:49:48	Obje	False	Faceplate Element PG2		
MytestLib 1.0-0. Library Version	🐯 fpeBusbarB		12/13/2010 1	5:1	Obje	False	Faceplate Element PG2		
🕀 🔛 pmsBasicLib 5.3-1, Library Version	🐯 fpeBusbarB_15		2/24/2011 10	:16:31	Obje	False	Faceplate Element PG2		
🗄 🎬 pmsCommLib 5.3-1, Library Version	🐯 fpeBusbarB_50		2/23/2011 09	:52:17	Obje	False	Faceplate Element PG2		
🕀 🎒 pmsCustomLib 5.3-1, Library Version	🐯 fpeLoad		12/13/2010 1	4:2	Obje	False	Faceplate Element PG2		
🕀 🔣 pmsLSLib 5.3-1, Library Version	🐯 fpeLoad_new		2/23/2011 08	:24:06	Obje	False	Faceplate Element PG2		
😥 🔛 pmsNetSim 4.0-0, Library Version	🐯 fpeLoadSettings		2/9/2011 16:4	19:52	Obje	False	Faceplate Element PG2		
😥 💓 pmsObjLib 5.3-1, Library Version	🐯 fpeMain		2/11/2011 15	:15:58	Obje	False	Faceplate Element PG2		
🕀 💓 pmsPQLib 5.3-1, Library Version	🐯 fpePrioSettings 🔄		2/9/2011 16:4	47:03	Obje	False	Faceplate Element PG2		
E 👘 pmsReAccelLib 5.3-1, Library Version	🐯 fpeSettings	Config View	14	:26:40	Obje	False	Faceplate Element PG2		
Control Module Types, Control Module Types	🔊 geBlockStatus P	New Accect	15	:07:29	Grap	False	Graphic Element PG2		
Source of the second seco	🔊 geReaccLegend	Cut	12	:28:36	Grap	False	Graphic Element PG2		
pmsCalcPrioGroupAB, Control Module Typ	🔊 geReaccLoadBar	Copy	11:1	19:07	Grap	False	Graphic Element PG2		
	🔊 geReaccLoadBa	Racha	D6:0	08:54	Grap	False	Graphic Element PG2		
Source And Anthen State An	🕅 geReaccTable	Delete	14:0	03:41	Grap	False	Graphic Element PG2		
Image prisoroupbelay, Control Module Type	👿 geScroll	Delete	12	:54:54	Grap	False	Graphic Element PG2		
Source of Control Module Type	🕱 geStatus PG2	Querride	15	:12:56	Grap	False	Graphic Element PG2		
	Hidden Alarm Lis -	overnde	13:5	51:07	This	True	Alarm and Event List		
	Library Member	P - 6	13:0	09:19		False	Library Member		
T Instantial Control Module Type	🔉 LockControl 🛛 🗕	References	18	:36:21	Grap	True	Graphic Element PG2		
😥 🛃 pmsOperationalStage, Control Module Ty	V Name	Reserve	14:5	53:11	The	False	Name		
🕀 💽 pmsPrioGroupConfig, Control Module Typ	lobject Icon	Release	19:3	31:20	Obje	False	Object Icon		
🕀 🛃 pmsPrioLoadConfig, Control Module Type	Sold Type Stri	Manage	▶ 19:3	31:20	[Obj	False	Object Type Structure		
🕀 🐯 pmsReAccReport, Control Module Type	Sold Type Stri	Add To Aspect M	enu 19::	31:20	[Obj	False	Object Type Structure		
😥 🛃 pmsReAccStaticPrio, Control Module Type	Voperator Note	Engineering Repo	sitory 🕨 17	:47:58	Oper	False	Operator Note		
🕀 🐼 pmsReAccSub50, Control Module Type	pmsReAccSub50		14:5	53:11		False	Object Type Definition		
🕀 🛃 pmsResetFunction, Control Module Type	Reporting Temp	Details	2:	18:39	Load	False	PMS Report Data Configu		
Data Types, Data Types									
				_	_				
						8 -	PMS ABB		

Figure 16 Export reporting template

Step 2) Go to Control Structure where the pmsReAccSub is instantiated, right click and select Paste. It should look similar to Figure 17.

MSDevelopment // Plant Explorer Workplace				
I (Enter search name)	🛜 Replace 💽 👫 🥝 🔃 🎘	🕻 🖆 🔁 🖾 🖄 🖆	¥a 🗊 🔛	
E Control Structure	Aspects of 'Restart_Sub01'	Modified	Desc Inherit	ted Category name
PMS Application, Control Project	geBlockStatus PG2	2010-09-27 3:07:	Grap True	Graphic Elemen
Applications, Application Group	X geScroll	2010-06-23 12:5	Grap True	Graphic Elemen
PMS_Application, Control Application	geStatus PG2	2010-09-27 3:12:	Grap True	Graphic Elemen
E-B Control Modules, Control Module Group	Hidden Alarm List	2006-04-06 1:51:	This True	Alarm and Even
🕀 🔁 Objects, Objects	X LockControl	2010-05-14 11:2	Grap True	Graphic Elemen
🕀 🔁 PQcontrol, PQcontrol	Name	2012-07-02 8:51:	The False	Name
🖃 🔚 Restart_Reacc, Single Control Module Type	😨 Object Icon	2010-04-01 7:31:	Obje True	Object Icon
Restart_Sub01, pmsReAccSub	Poperator Note	2012-07-02 8:51:	Oper False	Operator Note
E Z Synchronization, Synchronization	pmsReAccSub Type Reference	2012-07-02 8:51:	False	pmsReAccSub
Programs, Program Group	RR_Sub01_Reporting_Template	2012-07-05 2:36:	Load False	PMS Report Dat
☐ Diagrams, Diagram Group	Shelved Alarm List	2009-05-13 10:4	This True	Alarm and Even

Figure 17 Copied reporting template

Step 3) Right click on the newly copied *Reporting_Template* (Sub01_Reporting_Template in this example) and click on Config View to edit Report paths, as shown Figure 18.

🙀 Restart_Sub01 : RR_Sub01_Reporting_Template 📃	
🛛 🕢 🔊 🖪 🗸 Restart_Sub01:RR_Sub01_Reporting 💽 🏂 🖉 😓 🖅 🗸 🗍 👻	
Data property names Propterty Selection	
Property references:	
Generate report:	
vGenReport	
Acknowledge report created:	
vReportGenerated	
Report paths:	
Report Template:	
C:\Report\Template\RestartReport_Template.xlsm	
Produced Reports Basename:	
C:\Report\Reports\RestartReport_Sub01.xlsm	
Cancel Apply Help	

Figure 18 Reporting template Config view



Do not change Generate report or Acknowledge report created as this will lead to failure to report.

Step 4) Create folders for the Microsoft Excel template and reports as configured in the previous step and copy the excel template provided to the template folder.

🚰 Template				- O ×
File Edit View Favorites Tools Help				27
G Back + 🕥 - 🏂 🔎 Search 📂 Folders		ه 🗙 🖌 👘		
Address 🗁 C:\Report\Template				💌 芛 Go
Folders	×	Name 🔺	Size	Type D
ABB Industrial IT Data ABB Setup Package ABB Setup Package SV 5.0 SP2 REV D Backup Cournents and Settings Inetpub OperateITData1 Program Files Report Report Template Temp	*	RestartReport_Template.xlsm	82 KB	Microsoft Office Exc 3
E 🚞 WINDOWS	-	•	9	Þ

Figure 19 Excel reporting template

Step 5) Trigger the report and find the generated report in the report folder as shown Figure 20.

🚰 Reports							
File Edit View Favorites Tools Help 🥂							
🔆 Back + 🕥 - 🏂 🔎 Search 🎼 Folders 🕼 🎲 🗙 崎 🏢 -							
Address C:\Report\Reports				· -	Go		
Folders	× Name -	Size	Туре	Date Modified			
ABB Industrial IT Data ABB Setup Package ABB Setup Package SV 5.0 SP2 REV D Backup Backup Documents and Settings Documents and	 RestartReport-2011-04-20-15-43-44,013.xlsm RestartReport-2011-04-20-15-43-02.668.xlsm RestartReport-2011-04-20-15-43-20.821.xlsm RestartReport-2011-04-20-15-41-31.994.xlsm RestartReport-2011-04-20-15-40-48.555.xlsm RestartReport-2011-04-20-13-40-48.555.xlsm RestartReport-2011-04-20-13-49-20.557.xlsm RestartReport-2011-04-20-13-49-20.557.xlsm RestartReport-2011-04-20-13-40-37.299.xlsm RestartReport-2011-04-20-13-16-12.55.xlsm RestartReport-2011-04-20-13-16-12.451.xlsm RestartReport-2011-04-20-13-16-12.451.xlsm RestartReport-2011-04-20-13-16-12.451.xlsm 	81 KB 81 KB 81 KB 82 KB 82 KB 82 KB 82 KB 82 KB 82 KB 82 KB 82 KB	Microsoft Office Exc Microsoft Office Exc	4/20/2011 17:43 4/20/2011 17:43 4/20/2011 17:43 4/20/2011 17:41 4/20/2011 17:40 4/20/2011 15:45 4/20/2011 15:42 4/20/2011 15:17 4/20/2011 15:16 4/20/2011 15:16			
	RestartReport-2011-04-20-12-26-20.072.xlsm PoetartDenort-2011_04-20_00_05_18_600_vlcm	81 KB 82 KB	Microsoft Office Exc Microsoft Office Exc	4/20/2011 14:26 4/20/2011 11:05	-		

Figure 20 Completed reports

Step 6) Double-click the excel file to view. The report is divided into several sections; Voltage sag occurrence, Failed to reconnect, Inhibited from restart sequence, Completed restart sequence and Not running prior to voltage sag. See Figure 21 for an example of one of the sections.

	RestartReport-2011-04-25-08-25-42.668.xlsm - Microsoft Excel														
•	Hor	ne Insert Page	e Layou	it Formul	las Data Rei	riew View								0	_ = ×
1	x	Calibri v 11	•	<u>^</u>	· = - 2017	Wran Tayt	General				+	× 🖽	Σ AutoSum ·	A	an l
	0						General						🕃 Fill 👻	ZI	
Paste	1	B I U · ⊞ ·		· <u>A</u> ·		👥 Merge & Center ≁	\$ - %	, 00 .00	Formatting *	as Table * Styles *	insert D	velete Pormat	🖉 Clear 🕶	Filter * S	elect *
Clipboa	rd 🖻	Font		6	Alignme	nt 🕞	Numb	er 🕞		Styles		Cells	Ed	iting	
	A45	5 • (fs	e											×
				C		1 1 1 4 1 1 1 1 1	5	1		7			1 1 10		11
		A	В	C	U	C .		r		6			n		
		ARR											4/2	5/2011 -	10:26
		/~IPIP													
98	1														
99						Complete	ed rest	art seo	quence						
100															
101						B	Busbar A	status							
103								Tim	e						
104		Tag	Prio	Inhibited	Failed attempts	Tripped		Command	issued	Complet	ted				
105		Load04A	1		0	2011-04-25-10:24:56	5.742 201	1-04-25-10:	25:00.743	2011-04-25-10:25	5:03.040				
106		Load11A	2		0	2011-04-25-10:24:56	5.742 201	1-04-25-10:	25:04.040	2011-04-25-10:25	5:06.243				
107		Load12A	2		0	2011-04-25-10:24:56	5.742 201	1-04-25-10:	25:04.040	2011-04-25-10:25	5:06.243				
108		Load07A	3		0	2011-04-25-10:24:56	5.742 201	1-04-25-10:	25:07.243	2011-04-25-10:25	5:09.446				
109		Load05A	3		0	2011-04-25-10:24:56	5.742 201	1-04-25-10:	25:07.243	2011-04-25-10:25	5:09.446				
110		Load06A	3		0	2011-04-25-10:24:56	5.742 201	1-04-25-10:	25:07.243	2011-04-25-10:25	5:09.446				
111		Load13A	4		0	2011-04-25-10:24:56	.742 201	1-04-25-10:	25:10.446	2011-04-25-10:25	5:12.743				
112		Load14A	4		0	2011-04-25-10:24:56	742 201	1-04-25-10:	25:10.440	2011-04-25-10:25	5:16.040	+			
113		Load09A	5		0	2011-04-25-10:24:56	742 201	1-04-25-10:	25:13.743	2011-04-25-10:25	5:16.040				
115		Load15A	5		0	2011-04-25-10:24:56	5.742 201	1-04-25-10:	25:13.743	2011-04-25-10:25	5:16.040				
116		Load10A	7		0	2011-04-25-10:24:56	5.742 201	1-04-25-10:	25:19.447	2011-04-25-10:25	5:21.744				
117			÷			D	Juchar P	etatue							
118							busbar b	status							
119			_					Tim	e						
120		Tag	Prio	Inhibited	Failed attempts	Tripped		Command	issued	Complet	ted				
121		Load01B	1		0	2011-04-25-10:24:57	7.352 201	1-04-25-10:	25:00.743	2011-04-25-10:25	5:03.040				
122		Load02B	1		0	2011-04-25-10:24:57	7.352 201	1-04-25-10:	25:00.743	2011-04-25-10:25	5:03.040	-			
123		Load04B	2		0	2011-04-25-10:24:57	7 352 201	1-04-25-10:	25:00.743	2011-04-25-10:25	5:06 242			_	
124		Load05B	2		0	2011-04-25-10:24:57	7.352 201	1-04-25-10:	25:04.040	2011-04-25-10:25	5:06.243				
126		Load06B	2		0	2011-04-25-10:24:57	7.352 201	1-04-25-10:	25:04.040	2011-04-25-10:25	5:06.243	1			
127		Load07B	2		0	2011-04-25-10:24:57	7.352 201	1-04-25-10:	25:04.040	2011-04-25-10:25	5:06.243				-
	R	estart Report 🏾 🗐	,				lee.								▶
Ready													100% 😑 —		:

Figure 21 Opened report in Excel

3.1.17.3 Report delay configuration

To achieve a correct data collection for all the necessary internally timestamped data, the project must configure two delay setting in Project constants. Both can be found under **pmsConstants -> cRestartReportDelayT and cRestartReportDelayT 2**, see Figure 22.

© cIntNil int:0	 Insert in Sublevel
C cLogicFalse bool:0	
CLogicTrue bool:1	Insert After
- CNII dint:U	
CRestartReportDelayT time:20s CRestartReportDelayT2 time:10s	Delete
CStatusMask dword:16#E7	Bename
C cStatusOK dword:16#C0	Themame
🕼 cUnit_kvar_string:' NLSID_Unit_kvar\'	
Cunit_kW_string:' NLSID_Unit_kW\'	
CUnit_PF_string:"INLSID_Unit_PF\	
	•
Selected Project Constant	
/alue :	Туре:
Default value :	

Figure 22 Faceplate element Alarms



If these settings are set too "fast" the data collector will collect data before the timestamps are written to the variables, hence the long default delay

The delay timer cRestartReportDelayT sets the delay from when the sequence is completed to report trigger is given to the reporting service. The delay timer cRestartReportDelayT2 sets the delay between two reports in cases where there are several reports waiting in temporary storage before being sent to the data collector.

The reporting function can temporarily store up to four reports before the oldest is overridden.



Enable the Reporting via GlobalPrioConfig.Global.EnableReporting.

3.1.18 Alarms

The control module pmsReAccSub shall monitor the alarm conditions and will generate the alarm messages, as described in table below.

No	Description	Alarm condition	Alarm message (Resource Id)
1	Undervoltage busbar A	When undervoltage is detected either via parameter <i>BusAUnderVoltage</i> OR analogue voltage measurement < Voltage decay level (EnableSecUndervoltageCheck must be enabled).	<i>BusbarA</i> + ' ' + NLSID_RestartUnderVoltage
2	Undervoltage busbar B	When undervoltage is detected either via parameter <i>BusBUnderVoltage</i> OR analogue voltage measurement < Voltage decay level (EnableSecUndervoltageCheck must be enabled).	<i>BusbarB</i> + ' ' + NLSID_RestartUnderVoltage
3	Spurious busbar A	When the Undervoltage and recovery voltage is detected at the same time. This results in an internal block for busbar A. If both busbars are interconnected both have to experience the problem to block the function.	<i>BusbarA</i> + ' ' + NLSID_RestartSpuriousCond
4	Spurious busbar B	When the Undervoltage and recovery voltage is detected at the same time. This results in an internal block for busbar B. If both busbars are interconnected both have to experience the problem to block the function.	<i>BusbarB</i> + ' ' + NLSID_RestartSpuriousCond
5	Exceeded max. allowed voltage decays busbar A	When the No. of voltage decays on busbar A is equal to Max no. of voltage decays.	<i>BusbarA</i> + ' ' + NLSID_RestartMaxVoltDecay
6	Exceeded max. allowed voltage decays busbar B	When the No. of voltage decays on busbar B is equal to Max no. of voltage decays.	BusbarB + ' ' + NLSID_RestartMaxVoltDecay

Table	22	Alarm	configura	ation
-------	----	-------	-----------	-------

No	Description	Alarm condition	Alarm message (Resource Id)
7	Configuration error	When GlobalPrioConfig.Global.AllowedReaccel_time < GlobalPrioConfig.Global.OpenCircuit_time OR GlobalPrioConfig.Global.AllowedReaccel_time < GlobalPrioConfig.Global.CloseCMD_time + GlobalPrioConfig.Global.RunningFb_timeout OR GlobalPrioConfig.Global.MaxPriority < 1 OR GlobalPrioConfig.Global.MaxPriority > 20 OR GlobalPrioConfig.Global.VoltageDecayLevel > GlobalPrioConfig.Global.VoltageRecoveryLevel OR GlobalPrioConfig.Global.VoltageRecoveryLevel OR GlobalPrioConfig.Global.AllowedVoltRecoveryTime OR GlobalPrioConfig.Global.AllowedVoltRecoveryTime OR	NLSID_RestartConfigurationEror
8	IO Error busbar A	When BusAUnderVoltage.Status AND pmsConstants.cStatusMask OR BusARecoveryVoltage.Status AND pmsConstants.cStatusMask OR BusAVoltage.Status AND pmsConstants.cStatusMask is not equal pmsConstants.cStatusOK	<i>BusbarA</i> + ' ' + NLSID_IOError
9	IO Error busbar B	When BusBUnderVoltage.Status AND pmsConstants.cStatusMask OR BusBRecoveryVoltage.Status AND pmsConstants.cStatusMask OR BusBVoltage.Status AND pmsConstants.cStatusMask is not equal pmsConstants.cStatusOK	BusbarB + ' ' + NLSID_IOError
10	Load IO error	When Close_CMD.Status AND pmsConstants.cStatusMask OR RunningStatus.Status AND pmsConstants.cStatusMask OR POCLoc.Status AND pmsConstants.cStatusMask is not equal pmsConstants.cStatusOK	<i>Load.SrcName</i> + ' ' NLSID_IOError
11	Load configuration error	When Max allowed restart time < Open circuit time constant OR Max allowed restart time < Close command pulse time + Running feedback time.	<i>Load.SrcName</i> + ' ' NLSID_ConfigError



The text messages (i.e. in Alarm List) for the above alarms are configurable via the Alarm and Event Translator aspect in Plant Explorer under Library Structure > **Preferences & Customizations > PmsLibrary_NLS_Alarm&Event**. These messages can be changed from English language to another language by modifying the relevant Resource Id (i.e. NLSID_....) to a desired message (a text string up to 60 characters).

3.1.19 Events

The control module pmsReAccSub shall monitor the event conditions and will generate the event messages, as described in Table 23.

No	Description	Event condition	Event message (Resource Id)
1	Report generated	When acknowledge report created is received.	<i>BusbarA</i> + ' ' + NLSID_ReportGenerated
2	Active stage busbar A	When undervoltage is detected on busbar A the active stage is set to arming. When recovery voltage is detected and filter time has elapsed after an undervoltage, the active stage is set to operational. When the sequence is complete (i.e all loads has either started or failed to start) or cancelled due to voltage failed to recover within allowed voltage recovery time, the active stage is set to idle.	BusbarA + ' ' + NLSID_RestartArmingState OR BusbarA + ' ' + NLSID_RestartOperationState OR BusbarA + ' ' + NLSID_RestartIdleState
3	Active stage busbar B	When undervoltage is detected on busbar B the active stage is set to arming. When recovery voltage is detected on busbar B and filter time has elapsed after an undervoltage, the active stage is set to operational. When the sequence is complete (i.e all loads has either started or failed to start) or cancelled due to voltage failed to recover within allowed voltage recovery time, the active stage is set to idle.	BusbarB + ' ' + NLSID_RestartArmingState OR BusbarB + ' ' + NLSID_RestartOperationState OR BusbarB + ' ' + NLSID_RestartIdleState
4	Voltage recovery timeout bus A	When voltage has not recovered on busbar A before Max allowed voltage recovery time setting.	<i>BusbarA</i> + ' ' + NLSID_RestartOperationAbort – NLSID_RestartVoltageTO
5	Voltage recovery timeout bus B	When voltage has not recovered on busbar B before Max allowed voltage recovery time setting.	<i>BusbarB</i> + ' ' + NLSID_RestartOperationAbort – NLSID_RestartVoltageTO

Table	23	Event	configuration	n
-------	----	-------	---------------	---

No	Description	Event condition	Event message (Resource Id)
6	Block bus A	When operator check block busbar A in faceplate element Main is set, the block event is set to operator block. When <i>ExtPar.ExBlock_BusbarA</i> is set, the block event is set to <i>ExtPar.ExBlock_BusbarAEvent</i> . When I/O Error (on both busbar if interconnected) OR spurious condition (on both busbar if interconnected) OR no. of voltage decays > Max no. of voltage decays then the block event is set to Internal	Busbar A + ' ' + NLSID_RestartIntBlock OR Busbar A + ' ' + NLSID_RestartOpBlock OR Busbar A + ' ' + ExtPar.ExBlock_BusbarAEvent Busbar A + ' ' + NLSID_RestartUnBlocked
7	Block bus B	When operator check block busbar B in faceplate element Main is set, the block event is set to operator block. When <i>ExtPar.ExBlock_BusbarB</i> is set, the block event is set to <i>ExtPar.ExBlock_BusbarBEvent</i> . When I/O Error (on both busbar if interconnected) OR spurious condition (on both busbar if interconnected) OR no. of voltage decays > Max no. of voltage decays then the block event is set to Internal.	Busbar B + ' ' + NLSID_RestartIntBlock OR Busbar B + ' ' + NLSID_RestartOpBlock OR Busbar B + ' ' + ExtPar.ExBlock_BusbarAEvent Busbar B + ' ' + NLSID_RestartUnBlocked
8	Function active	When parameter <i>Enable</i> is activated or deactivated.	NLSID_RREnableOn on activation and NLSID_RREnableOff on deactivation
9	Priority released bus A	When priority is released for busbar A in operational stage.	<i>Busbar A</i> + ' ' + NLSID_RestartPrioRelease + ' ' + X
10	Priority released bus B	When priority is released for busbar A in operational stage.	<i>Busbar B</i> + ' ' + NLSID_RestartPrioRelease + ' ' + X
11	Load – Operator inhibit	When manually inhibited is checked via faceplate element busbar A\B.	<i>LoadSrc</i> + " " + NLSID_RestartInhOpOn AND <i>LoadSrc</i> + " " + NLSID_RestartInhOpOff
12	Load – Auto inhibit	When RunningStatus or Close_CMD or POCLoc feedback signals are in error condition OR when Load.ExternalInhibit.	LoadSrc + " " + NLSID_RestartInhSysOn AND LoadSrc + " " + NLSID_RestartInhSysOff
13	Load – Failed to restart	When either 1) Number of restart attempts has been reached 2) Time since disconnection > Max allowed restart time 3) Sequence Cancelled	1) LoadSrc + ' ' + NLSID_RestartFailed + ' ' + NLSIDFailCause2 2) LoadSrc + ' ' + NLSID_RestartFailed + ' ' + NLSIDFailCause1 3) LoadSrc + ' ' + NLSID_RestartFailed + ' ' + NLSIDFailCause3

No	Description	Event condition	Event message (Resource Id)		
14	Load –When parameterRunningLoad.RunningStatus is True orstatusFalse.		NLSID_RestartRunningFbOn AND NLSID_RestartRunningFbOff		
15	Load – command issued	When parameter <i>Load.Close_CMD</i> is set high.	<i>LoadSrc</i> + ' ' + NLSID_CmdClose		
16	Load – Priority change	When operator or external logic change priority setting.	<i>LoadSrc</i> + ' ' + NLSID_RestartPrioChange + ' ' + X		



The text messages (i.e. in Event List) for the above events are configurable via the Alarm and Event Translator aspect in Plant Explorer under Library Structure > Preferences & Customizations > PmsLibrary_NLS_Alarm&Event. These messages can be changed from English language to another language by modifying the relevant Resource Id (i.e. NLSID_....) to a desired message (a text string up to 60 characters).

3.1.20 Required I/O

An overview of the required I/O is described in Table 24 with respect to significance when setting up the interface connections for the pmsReAccSub control module. The description "mandatory" implies that the internal logic of the control modules requires data from the variable in order to function properly. The description "optional" implies that the internal logic of the control modules can also handle data from the variable, but it could be omitted without affecting the functionality of the module.

Field	Parameter	Description	Туре	Importance
1 BusAUnderVoltage BusBUnderVoltage		Undervoltage stage activation of the busbars, which have connected loads, that are part of the reacceleration function – used for detection of undervoltage stage.	Digital Input	Mandatory
2	BusARecoveryVoltage BusBRecoveryVoltage	Recoveryvoltage stage activation of the busbars, which have connected loads that are part of the reacceleration function – used for detection voltage recovery.	Digital Input	Mandatory
3	BusAVoltage BusBVoltage	Voltage of the busbars, which have connected loads, that are part of the reacceleration function.	Analogue Input	Optional
4	LoadPar.Running status	Running status for the motors, that are part of the reacceleration sequence.	Digital Input	Mandatory
5	LoadPar.Close_CMD Breaker close command for the motors, that are part of the reacceleration sequence.		Digital Output	Mandatory
6	LoadPar.POCLoc	Circuit breaker local point of control.	Digital Input	Optional
7	CBA,CBB,CBT	Circuit breaker confirmed close position.	Digital Input	Mandatory

|--|

Item 2: the functionality of an overvoltage type signal is preferred opposed to an undervoltage type as it is considered a safer approach for reacceleration to enter operational state based on a high (true) value of the input.

Item 3: from above table is used only when a secondary check of reacceleration triggering condition is desired.

Item 4: should give the information that motor has normal operating parameters (speed, torque, etc.). If this cannot be supplied, then motor breaker close status should be connected as minimum.

Item 5: must be field/hardwired. A software signal to PMS breaker control module would introduce undesired delays in the reconnection function.

Section 4 Capacity & Performance

Table 25 Firmware version downloaded in AC800M controllers

Unit	Firmware version
PM866	FW866 5.1.48.40 2010-07-02 (BasicHwLib 5.1-0)
PM891	FW891 5.1.48.40 2010-07-02 (BasicHwLib 5.1-0)

4.1 Heap utilization

4.1.1 pmsReAccSub

Table 26 Heap utilization of pmsReAccSub in AC800M controller

	First instance	2 nd and following instances	
Heap utilization(MB) in PM866	1.457	0.847	
Heap utilization(MB) in PM891	1.452	0.841	

4.2 Execution Time

4.2.1 pmsReAccSub

Table 27 Execution time of pmsReAccSub in AC800M controller

Execution time (ms)	Configuration	Notes	
9 ms(idle) – 38 ms(peak)	100 loads, all prio 1, no disabled events	For one instance in PM866	
9 ms(idle) – 15 ms(peak)	100 loads, all prio 1, 3 disabled events *	For one instance in PM866	
6 ms(idle) – 24 ms(peak)	60 loads, all prio 1, no disabled events	For one instance in PM866	
6 ms(idle) – 10 ms(peak)	60 loads, all prio 1, 3 disabled events *	For one instance in PM866	
4 ms(idle) – 23 ms(peak)	40 loads, all prio 1, no disabled events	For one instance in PM866	
4 ms(idle) – 7 ms(peak)	40 loads, all prio 1, 3 disabled events *	For one instance in PM866	
3 ms(idle) – 13 ms(peak)	100 loads, all prio 1, no disabled events	For one instance in PM891	
3 ms(idle) – 4 ms(peak)	100 loads, all prio 1, 3 disabled events *	For one instance in PM891	
2 ms(idle) – 8 ms(peak)	60 loads, all prio 1, no disabled events	For one instance in PM891	
2 ms(idle) – 3 ms(peak)	60 loads, all prio 1, 3 disabled events *	For one instance in PM891	
1 ms(idle) – 6 ms(peak)	40 loads, all prio 1, no disabled events	For one instance in PM891	
1 ms(idle) – 2 ms(peak)	40 loads, all prio 1, 3 disabled events *	For one instance in PM891	

* Disabled events; *ExtPar.DisLoadEvCMD*, *ExtPar.DisLoadEvRunningFb* and *ExtPar.DisLoadEvRunningFbLost*

Section 5 Application Notes

A configuration example of a restart/reacceleration application will be described in the following sections. The substation shown in figure below will be used as a basis.



Figure 23 Substation configuration for pmsReAccSub

One instance of the type pmsReAccSub will be configured, denoted Restart_Substation01, configured with 20 loads, 10 on bus A and 10 on bus B.

5.1 Project Structure

A PMS project configured with the Control Builder M Professional is shown in Figure 24. The examples described in the following sections will be based on this project structure:



Figure 24 Example of project structure and instantiation

5.2 Instantiation and application data types

The control module type pmsReAccSub is instantiated in CMT (Control module type) under library application named *Restart_Reacceleration*, as shown in Figure 25.



Figure 25 Instantiated type in application library

Create instances and name them e.g. *Restart_Substation01*. One instance must be created for each substation.

To connect the parameters of the instances it is recommended to create application specific data types. The application example in Figure 26 shows the data types named *pmsNode* and *ioNode*. *pmsNode* holds data types and configuration values, while *ioNode* holds IO variables.

These must be configured as global variables in the application:

R /	🚦 Application - PMS_Application 📃 🗖								
Edit	Editor Edit View Insert Tools Window Help								
: 6	ि 🔜 🗟 🔌 🖶 🔎 🤊 🕅 🔏 🛍 🗋 🐣 🌺 🗛 加 🗛 🚅 🖓 🛔								
	Name	Data Type	Attributes	Initial Value					
1	ioNode1	ioNode	retain						
2	pmsNode1	pmsNode	retain						
3	TaskNormal	string	constant	'PMS_Controller.TaskNormal'					
4									
5									
6	Global Variable	es / Variables /)						

Figure 26 Defining global variables of the application

Add these to the External Variables list of the single control module:

E Co	Control module type - PMS_ApplicationLib.Restart_Reacceleration							
Editor	r Edit View Inse	rt Tools Window	Help					
	🗟 🔌 🖨	D 7 P 🔏 i	à 🗋 🦀 🍓	🗚 🎓 🚃				
	Name	Data Type	Attributes	Description				
1	ioNode1	ioNode						
2	pmsNode1	pmsNode						
3	TaskNormal	string	constant					
• •	∖ Parameters)	Variables 👌 Ext	ternal Variables					



A separate task RRFast is created for the execution of the restart/reacceleration instances; connect the control module Restart_Reacc to this task.

5.2.1 Configuration of parameters

Below is shown the connections of the first instance, items in *pmsNode1* must be created to provide the parameters shown, described in the following sections.

	Connections - Restart_Substation01 pmsReAccelLib.pmsReAccSub50							
Edit	or Edit View Insert Tools W	/indow Help						
	Name	Data Type	Initial Value	Parameter	Attributes Direc	tion Description		
1	Enabled	bool	Default	pmsNode1.Restart_SS01Enable	in_o	IN: Enable Function		
2	Name	String[30]	'SubstationName'	'Restart_SS01'	in_o	t IN EDIT: Name		
3	Description	String[40]	'SubstationDescr'	'Restart_SS01'	in_o	t IN EDIT: Description		
4	AlSeverity	dint	900		in_o	t IN EDIT: Alarm severity		
5	EvSeverity	dint	500		in_o	t IN EDIT: Event severity		
6	Class	dint	50		in_o	IN EDIT: Alarm and Event Class		
7	TaskNormal	string	Default	TaskNormal	in_o	IN EDIT: Normal task for initial running loads and HSI (connection		
8	BusA	String[10]	'Busbar A'		in_o	IN EDIT: Text for busbar A		
9	BusB	String[10]	'Busbar B'		in_o	IN EDIT: Text for busbar B		
10	FunctionMode	dint	1	1.	in_o	IN EDIT: [1=Restart][2=Reacceleration]		
11	LBBA_ID	dint	1	pmsNode1.Restart_SS01_LBBA_ID	in_o	IN EDIT: ID of the Load Bus Bar which the substation A-side is		
12	LBBB_ID	dint	2	pmsNode1.Restart_SS01_LBBA_ID	in_o	IN EDIT: ID of the Load Bus Bar which the substation B-side is		
13	LoadsANOF	dint	5	pmsNode1.Restart_SS01_NumberOfLoadBusA	in_o	IN EDIT: Number of Loads in Bus A		
14	LoadsBNOF	dint	5	pmsNode1.Restart_SSD1_NumberOfLoadBusB	in_o	IN EDIT: Number of Loads in Bus B		
15	BusAUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.Restart_SS01_BusAUnderVoltage	in_o	t IN: Bus A Undervoltage		
16	BusBUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.Restart_SS01_BusBUnderVoltage	in_o	t IN: Bus B Undervoltage		
17	BusARecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.Restart_SS01_BusARecVoltage	in_o	IN: Bus A recovery voltage level		
18	BusBRecovery∀oltage	pmsReAccBoollOex	Default	pmsNode1.Restart_SS01_BusBRecVoltage	in_o	t IN: Bus B recovery voltage level		
19	BusAVoltage	RealIO	Default	pmsNode1.Restart_SS01_BusAVoltage	in_o	t IN: Bus A Voltage		
20	BusBVoltage	ReallO	Default	pmsNode1.Restart_SS01_BusBVoltage	in_o	t IN: Bus B Voltage		
21	EnableSecUnderVoltCheck	bool	Default	pmsNode1.Restart_SS01_SecUnderVoltCheck	in_o	IN: Enables Bus A secondary Voltage check.		
22	EnableSecRecVoltCheck	bool	Default	pmsNode1.Restart_SSD1_SecRecVoltCheck	in_o	IN: Enables Bus B secondary Voltage check.		
23	GlobalPrioConfig	pmsReAccConfigPar	Default	pmsNode1.Restart_SS01_GlobalPrioConfig	in_o	t IN: Priority Group configuration parameters		
24	ExtPar	pmsReAccExtPar	Default	pmsNode1.Restart_SSD1_ExtPar	in_o	t IN: External parameters		
25	ExtPrio	pmsReAccExtPrio	Default		in_o	t IN: External Priority (Future)		
26	CBA_C	bool	Default	pmsNode1.Restart_SS01_CBA_Closed	in_o	t IN: Circuit breaker SS_A checked closed pos		
27	CBB_C	bool	Default	pmsNode1.Restart_SS01_CBB_Closed	in_o	IN: Circuit breaker SS_B checked closed pos		
28	CBT_C	bool	Default	pmsNode1.Restart_SS01_CBT_Closed	in_or	t IN: Circuit breaker SS_T checked closed pos		
29	LoadA	pmsReAccLoadParAll	Default	pmsNode1.Restart_SS01_LoadParA	in_o	IN_OUT: Load parameters, up to 50 Loads in substation A-side		
30	LoadB	pmsReAccLoadParAll	Default	pmsNode1.Restart_SS01_LoadParB	in_o	IN_OUT: Load parameters, up to 50 Loads in substation B-side		
31	Status	pmsReAccStatusPar	Default		in o	t OUT: Function Status		

Figure 28. The connections of the instance Restart_Substation01

5.2.1.1 Name, Description and tasks

For the parameters Name, Description, use e.g. these strings:

1										
I	E Connections - Restart_Sub01 pmsReAccelLib.pmsReAccSub									
	Edito	r Edit View Insert Tools Wi	indow Help							
	i 🗟 🖟 🔌 🖶 🖉 🧐 🕅 🤾 👍 🗋 🐥 🐥 ⊒ A., ⇔ 🌝									
ſ		Name	Data Type	Initial Value	Parameter	Attributes	Direction			
ľ	1	Enabled	bool	Default	pmsNode1.RR_SS01_Enable		in			
I	2	Name	String[30]	'SubstationName'	'SS01_Restart'		in			
I	3	Description	String[40]	'SubstationDescr'	'SS01_Restart'		in			
ľ	4	AlSeverity	dint	900			in			
I	5	EvSeverity	dint	500			in			
I	6	Class	dint	50			in			
ľ	7	TaskNormal	string	Default	TaskNormal	1	in			

Figure 29 Name, Description and Task settings

The parameter "*TaskNormal*" should be connected to the global variable TaskNormal. In the application *RestartReaccAppl* shown above, there must then be defined a global variable that connects this string to the Normal task of the controller:

8	E Application - PMS_Application								
Ed	Editor Edit View Insert Tools Window Help								
1	: 😡 🗑 🏈 🖶 🔎 🤊 🕅 🔏 🛍 📋 🎒 🌺 🗛 🎓 🚍 🗛 📌 🍸 🛃								
	Name	Data Type	Attributes	Initial Value					
1	l ioNode1	ioNode	retain						
2	2 pmsNode1	pmsNode	retain						
3	B TaskNormal	string	constant	'PMS_Controller.TaskNormal'					
4	1								
5	5								
6									
•	Global Variable	es <u>(</u> Variables)	/						

Figure 30 Task Normal

This task is used by the sub module HSI. The task "Normal" has typically an interval time of 1000 ms.

5.2.1.2 Configuration parameters

Parameter for enabling the instance, setting the load bus bar IDs, the number of loads on each bus bar must be created and connected; in this example also the optional secondary voltage checks are used:

Ec	Connections - Restart_Sub01 pmsReAccellib.pmsReAccSub							
Edito	r Edit View Insert Tools W	indow Help						
: 🛃	B B 🖉 🖶 🗿 🗐 🖱 🐇 🖄 📋 🚇 🚇 🎓 🔚 🙏 🗢 😮							
	Name	Data Type	Initial Value	Parameter	Attributes	Direction	Description	
1	Enabled	bool	Default	pmsNode1.RR_SS01_Enable		in	IN: Enable Function	
2	Name	String[30]	'SubstationName'	'SS01_Restart'		in	IN EDIT: Name	
3	Description	String[40]	'SubstationDescr'	'SS01_Restart'		in	IN EDIT: Description	
4	AlSeverity	dint	900			in	IN EDIT: Alarm severity	
5	EvSeverity	dint	500			in	IN EDIT: Event severity	
6	Class	dint	50			in	IN EDIT: Alarm and Event Class	
7	TaskNormal	string	Default	TaskNormal		in	IN EDIT: Normal task for initial running loads ar	
8	BusA	String[10]	'Busbar A'			in	IN EDIT: Text for busbar A	
9	BusB	String[10]	'Busbar B'			in	IN EDIT: Text for busbar B	
10	FunctionMode	dint	1			in	IN EDIT: [1=Restart][2=Reacceleration]	
11	LBBA_ID	dint	1	0		in	IN EDIT: ID of the Load Bus Bar which the subs	
12	LBBB_ID	dint	2	0		in	IN EDIT: ID of the Load Bus Bar which the subs	
13	LoadsANOF	dint	5	pmsNode1.RR_SS01_LoadsANOF		in	IN EDIT: Number of Loads in Bus A	
14	LoadsBNOF	dint	5	pmsNode1.RR_SS01_LoadsBNOF		in	IN EDIT: Number of Loads in Bus B	
15	BusAUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusAUnderVoltage		in	IN: Bus A Undervoltage	
16	BusBUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBUnderVoltage		in	IN: Bus B Undervoltage	
17	BusARecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusARecVoltage		in	IN: Bus A recovery voltage level	
18	BusBRecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBRecVoltage		in	IN: Bus B recovery voltage level	
19	BusAVoltage	RealIO	Default	pmsNode1.RR_SS01_BusA_Voltage		in	IN: Bus A Voltage	
20	BusBVoltage	RealIO	Default	pmsNode1.RR SS01 BusB Voltage		in	IN: Bus B Voltage	
21	EnableSecUnderVoltCheck	bool	Default	true		in	IN: Enables Bus A secondary Voltage check.	
22	EnableSecRecVoltCheck	bool	Default	true		in	IN: Enables Bus B secondary Voltage check.	
23	GlobalPrioConfig	pmsReAccConfigPar	Default	pmsNode1.RR_SS01_GlobalPrioConfig		in_out	IN: Priority Group configuration parameters	
24	ExtPar	pmsReAccExtPar	Default	pmsNode1.RR_SS01_ExtPar		in	IN: External parameters	
25	ExtPrio	pmsReAccExtPrio	Default	pmsNode1.RR_SS01_ExtPrio		in	IN: External Priority (Future)	
26	CBA_C	bool	Default	pmsNode1.RR_SS01_CBA_Closed		in	IN: Circuit breaker SS_A checked closed pos	
27	CBB_C	bool	Default	pmsNode1.RR_SS01_CBB_Closed		in	IN: Circuit breaker SS_B checked closed pos	
28	CBT_C	bool	Default	pmsNode1.RR_SS01_CBT_Closed		in	IN: Circuit breaker SS_T checked closed pos	
29	LoadA	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadA		in_out	IN_OUT: Load parameters, up to 50 Loads in s	
30	LoadB	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadB		in_out	IN_OUT: Load parameters, up to 50 Loads in s	
31	Status	pmsReAccStatusPar	Default	pmsNode1.RR_SS01_Status		out	OUT: Function Status	

Figure 3	31 Pa	arameter	connections
----------	-------	----------	-------------

📥 Da	💑 Data Type - PMS_ApplicationLib.pmsNode 📃 🖂					
Editor	Edit View Insert Tools Window	Help				
: 🔜	🖥 🥙 🎘 🖶 🔎 🛯 🤊 🕅 🐇	🛍 📋 🦀 🍓 🗛 🌋	- 🔜 🗛 🚽	▼ ‡↓ ‡†		
	Name	Data Type	Attributes	Initial Value		
63	RR_SS01_Enable	bool	retain	true		
64	RR_SS01_LoadsANOF	dint	retain			
65	RR_SS01_LoadsBNOF	dint	retain			
66	RR_SS01_BusAUnderVoltage	pmsReAccBoollOex	retain		_	
67	RR_SS01_BusBUnderVoltage	pmsReAccBoollOex	retain			
68	RR_SS01_BusARecVoltage	pmsReAccBoollOex	retain		_	
69	RR_SS01_BusBRecVoltage	pmsReAccBoollOex	retain			
70	RR_SS01_BusA_Voltage	ReallO	retain		_	
71	RR_SS01_BusB_Voltage	ReallO	retain			
72	RR_SS01_GlobalPrioConfig	pmsReAccConfigPar	retain			
73	RR_SS01_ExtPar	pmsReAccExtPar	retain			
74	RR_SS01_ExtPrio	pmsReAccExtPrio	retain			
75	RR_SS01_CBA_Closed	bool	retain			
76	RR_SS01_CBB_Closed	bool	retain			
77	RR_SS01_CBT_Closed	bool	retain			
78	RR_SS01_LoadA	pmsReAccLoadParAll	retain			
79	RR_SS01_LoadB	pmsReAccLoadParAll	retain			
80	RR_SS01_Status	pmsReAccStatusPar	retain		-	
• •	Components /		1		· [//	
	Bow 44 Co					

These variables must first be created in pmsNode1:

Figure 32 Configuration parameters in pmsNode1

Code must be added to the single control module RestartReacc to set these parameters:



Figure 33 Code for setting configuration parameters

When these parameters are changed, it is sufficient with a warm download to the controller.

The global configuration parameters are here defined in *pmsNode1.Restart_SS01_GlobalPrioConfig.* These consists of one parameter set of global

parameters for the substation, and one parameter set for each priority group of the substation (20 priority groups). The parameters of the latter (type pmsReAccGroupPar) are all set in the faceplate:

• D	Data Type - pmsBasicLib.pmsReAccGroupPar [Read-only]							
Edit	or Edit View Insert Tools	Window Help						
	 % % 5 ×		0 A A A	At .				
	Name	Data Type	Attributes	Initial Value	Description			
1	ReAccGroupDelayTime	time	coldretain nosort	1s	IN: Delay before this priority start			
2	OpenCircuit_time	time	coldretain nosort	0.5s	IN: Waiting time before reconnection can be attempted			
3	AllowedReaccel_time	time	coldretain nosort	10s	IN: Time from power outage to reacceleration could succeed			
4	CloseCMD_time	time	coldretain nosort	1s	IN: Pulse length for close command			
5	RunningFb_timeout	time	coldretain nosort	2s	IN: Time from close command until running feedback is expected			
6	MaxNrOfAttempts	dint	coldretain nosort	3	IN: Max number of reaccel attempts.			
7	Prio	dint	coldretain nosort	1	IN: Load Reaccel/Restart priority			
8	Grouped	bool	coldretain nosort	true	IN: Individual settings are decided by Global settings			

Figure 34 Priority group parameters – set in the faceplate

The parameters of the global parameters, are partly set in the faceplate, the rest must be set in the code:

🚰 Data Type - pmsBasicLib.pmsReAccGlobalPar							
Editor Edit View Insert Tools	Editor Edit View Insert Tools Window Help						
: 🗟 🗟 🔌 🖶 🧕 🔊	で メ 宅 白)	🎒 🍓 🗚 🎓 🗔	A. 8	7 ⊉↓ ⊉↑			
Name	Data Type	Attributes	Initial Value	ISP Value	Description		
1 EnableReporting	bool	coldretain nosort	false		IN: Enable reporting function		
2 EnableOpReporting	bool	coldretain nosort	false		IN: Enable manual reoporting by operator		
3 PrioRestartMethod	dint	coldretain nosort	0		IN EDIT: Static Restart = 0, Dynamic Restart = 1		
4 BusbarsConfigured	dint	coldretain nosort	0		IN EDIT: BusbarA & BusbarB = 0 BusbarA = 1, BusbarB = 2		
5 CBConfigured	dint	coldretain nosort	0		IN EDIT: CBA,CBB&CBT = 0, CBA&CBB = 1, CBA = 2, CBB = 3		
6 MaxPriority	dint	coldretain nosort	20		IN: Max number of priorities used.		
7 CoordinateRestart	bool	coldretain nosort	false		IN: Coordinate restart of Busbar A & B		
8 HideManualInhibit	bool	coldretain nosort	false		IN: True will hide manual inhibit column		
9 HideLoadValue	bool	coldretain nosort	false		IN: True will hide Load value column		
10 OperatorSettable	bool	coldretain nosort	true		IN: Operator from changing settings from faceplate		
11 VoltageDecayLevel	real	coldretain nosort	0		IN: Voltage decay level in present		
12 VoltageRecoveryLevel	real	coldretain nosort	0		IN: Voltage Recovery level in present		
13 VoltageRecoveryHyst	time	coldretain nosort	1s		IN: Minimum time for voltage recovery to be stable before restart		
14 AllowedVoltRecoveryTime	time	coldretain nosort	20s		IN: Max allowed voltage recovery time before operation is canceled		
15 MaxNrVoltageDecays	dint	coldretain nosort	5		IN: Max number of Voltage decays before operation is canceled		
16 MaxLimit_IncomerA	real	coldretain nosort	0		IN: Max limit for Incomer A		
17 MaxLimit_IncomerB	real	coldretain nosort	0		IN: Max limit for Incomer B		
18 ReAccGroupDelayTime	time	coldretain nosort	1s		IN: Delay before this priority start		
19 OpenCircuit_time	time	coldretain nosort	0.5s		IN: Waiting time before reconnection can be attempted		
20 AllowedReaccel_time	time	coldretain nosort	10s		IN: Time from power outage to reacceleration could succeed		
21 CloseCMD_time	time	coldretain nosort	1s		IN: Pulse length for close command		
22 RunningFb_timeout	time	coldretain nosort	2s		IN: Time from close command until running feedback is expected		
23 MaxNrOfAttempts	dint	coldretain nosort	3		IN: Max number of reaccel attempts.		
24 UpdateRunningFbT	time	coldretain nosort	2s		IN: Update rate for scanning running feedback in Idle state		
25 SignalTransitionT	time	coldretain nosort	1s		IN: Transition time for undervoltage and recovervoltage signals		
< > Components /					•		

Figure 35 Global parameters

5.2.1.1 Input variables – Voltage values

Now the variables for the voltage inputs must be connected:

E	Connections - Restart_Sub01 p	msReAccelLib.pmsReAcc	Sub				
Edit	or Edit View Insert Tools W	'indow Help					
: 6	l 🖬 🥬 🖶 🔎 🔊 🖭 🐰	🖄 📋 🕭 🎂 🎓	🔜 🗛 🗢 🐮				
	Name	Data Type	Initial Value	Parameter	Attributes	Direction	Description
1	Enabled	bool	Default	pmsNode1.RR_SS01_Enable		in	IN: Enable Function
2	Name	String[30]	'SubstationName'	'SS01_Restart'		in	IN EDIT: Name
3	Description	String[40]	'SubstationDescr'	'SS01_Restart'		in	IN EDIT: Description
4	AlSeverity	dint	900			in	IN EDIT: Alarm severity
5	EvSeverity	dint	500			in	IN EDIT: Event severity
6	Class	dint	50			in	IN EDIT: Alarm and Event Class
7	TaskNormal	string	Default	TaskNormal		in	IN EDIT: Normal task for initial running loads a
8	BusA	String[10]	'Busbar A'			in	IN EDIT: Text for busbar A
9	BusB	String[10]	'Busbar B'			in	IN EDIT: Text for busbar B
10	FunctionMode	dint	1			in	IN EDIT: [1=Restart][2=Reacceleration]
11	LBBA_ID	dint	1	0		in	IN EDIT: ID of the Load Bus Bar which the sub
12	LBBB_ID	dint	2	0		in	IN EDIT: ID of the Load Bus Bar which the sub
13	LoadsANOF	dint	5	pmsNode1.RR_SS01_LoadsANOF		in	IN EDIT: Number of Loads in Bus A
14	LoadsBNOF	dint	5	pmsNode1.RR_SS01_LoadsBNOF		in	IN EDIT: Number of Loads in Bus B
15	BusAUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusAUnderVoltage		in	IN: Bus A Undervoltage
16	BusBUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBUnderVoltage		in	IN: Bus B Undervoltage
17	BusARecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusARecVoltage		in	IN: Bus A recovery voltage level
18	BusBRecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBRecVoltage		in	IN: Bus B recovery voltage level
19	BusAVoltage	RealIO	Default	pmsNode1.RR_SS01_BusA_Voltage		in	IN: Bus A Voltage
20	BusBVoltage	RealIO	Default	pmsNode1.RR_SS01_BusB_Voltage		in	IN: Bus B Voltage
21	EnableSecUnderVoltCheck	bool	Default	true		in	IN: Enables Bus A secondary Voltage check.
22	EnableSecRecVoltCheck	bool	Default	true		in	IN: Enables Bus B secondary Voltage check.
23	GlobalPrioConfig	pmsReAccConfigPar	Default	pmsNode1.RR_SS01_GlobalPrioConfig		in_out	IN: Priority Group configuration parameters
24	ExtPar	pmsReAccExtPar	Default	pmsNode1.RR_SS01_ExtPar		in	IN: External parameters
25	ExtPrio	pmsReAccExtPrio	Default	pmsNode1.RR_SS01_ExtPrio		in	IN: External Priority (Future)
26	CBA_C	bool	Default	pmsNode1.RR_SS01_CBA_Closed		in	IN: Circuit breaker SS_A checked closed pos
27	CBB_C	bool	Default	pmsNode1.RR_SS01_CBB_Closed		in	IN: Circuit breaker SS_B checked closed pos
28	CBT_C	bool	Default	pmsNode1.RR_SS01_CBT_Closed		in	IN: Circuit breaker SS_T checked closed pos
29	LoadA	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadA		in_out	IN_OUT: Load parameters, up to 50 Loads in s
30	LoadB	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadB		in_out	IN_OUT: Load parameters, up to 50 Loads in s
31	Status	pmsReAccStatusPar	Default	pmsNode1.RR_SS01_Status		out	OUT: Function Status

Figure 36 Connecting variables for voltage inputs

The related variables must be created in pmsNode1 and ioNode1. The values in ioNode1 are connected to the channels on the IO cards, while the values in pmsNode1 are reading these IO values.

Add these variables to ioNode1:

🦺 Data Type - PMS_ApplicationLib.ioNode [Read-only]							
Editor Edit View Insert Tools Window Help							
: 💀 🕫 🏈 🖶 🔎 🔊 🖻 🎖 🏦 🗋 🖗 🌺 🗛 🎓 🗔 🗛 🔗 🍸							
	Name	Data Type	Attributes				
89	RR_SS01_BusAUnderVoltage	BoollO	retain				
90	RR_SS01_BusBUnderVoltage	BoollO	retain				
91	RR_SS01_BusARecoveryVoltage	BoollO	retain 🔤				
92	RR_SS01_BusBRecoveryVoltage	BoollO	retain 🗖				
93	RR_SS01_BusAVoltage	ReallO	retain				
94	RR_SS01_BusBVoltage	ReallO	retain 🖵				
• •	Components /	•	• //.				



Add these variables to pmsNode1:

🦺 Da	🦺 Data Type - PMS_ApplicationLib.pmsNode 📃 🗖 🗙				
Editor	Edit View Insert Tools Window	Help			
:	🗟 🤌 🖶 🙆 🖣 🗞	🛍 📋 🦀 🍓 🛤 🌋	- 🔜 🗛 🖌 🝸		
	Name	Data Type	Attributes		
64	RR_SS01_LoadsANOF	dint	retain		
65	RR_SS01_LoadsBNOF	dint	retain		
66	RR_SS01_BusAUnderVoltage	pmsReAccBoollOex	retain		
67	RR_SS01_BusBUnderVoltage	pmsReAccBoollOex	retain		
68	RR_SS01_BusARecVoltage	pmsReAccBoollOex	retain		
69	RR_SS01_BusBRecVoltage	pmsReAccBoollOex	retain		
70	RR_SS01_BusA_Voltage	ReallO	retain		
71	RR_SS01_BusB_Voltage	ReallO	retain		
72	RR_SS01_GlobalPrioConfig	pmsReAccConfigPar	retain		
73	RR_SS01_ExtPar	pmsReAccExtPar	retain 📃		
74	RR_SS01_ExtPrio	pmsReAccExtPrio	retain		
75	RR_SS01_CBA_Closed	bool	retain		
76	RR_SS01_CBB_Closed	bool	retain		
77	RR_SS01_CBT_Closed	bool	retain		
78	RR_SS01_LoadA	pmsReAccLoadParAll	retain		
79	RR_SS01_LoadB	pmsReAccLoadParAll	retain		
80	RR_SS01_Status	pmsReAccStatusPar	retain		
81					
• •	Components /	•			
			11		

Figure 38 Variables for voltage values in pmsNode1

The digital and analogue voltage values will be read into pmsNode1 from ioNode1; add this code to code block "Input":

E	Co	trol module type - PMS_ApplicationLib.Restart_Reacceleration	_ 🗆 🗙
E	ditor	Edit View Insert Tools Window Help	
1	N	a 🏈 ờ 🖶 🔎 🤊 🖻 🔏 🛍 🆀 🌺 🏔 🎥 🔜 🏭 🗛 🙀 🕜 🔁 🍸 ½ ‡ ‡ †	
ſ	(*	***************************************	
	(* (* (*	*) Analogue Voltage and digital voltage levels input *) *) ********************************	
	(*	Busbar A *)	
	(*	Analogue Voltage measurement *)	
		pmsNode1.RR_SS01_BusA_Voltage := ioNode1.RR_SS01_BusAVoltage;	
	(*	Undervoltage *)	
		pmsNode1.RR_SS01_BusAUnderVoltage.Value:= ioNode1.RR_SS01_BusAUndervoltage.Value;pmsNode1.RR_SS01_BusAUnderVoltage.IOValue:= ioNode1.RR_SS01_BusAUndervoltage.IOValue;pmsNode1.RR_SS01_BusAUnderVoltage.Forced:= ioNode1.RR_SS01_BusAUndervoltage.Forced;pmsNode1.RR_SS01_BusAUnderVoltage.Status:= ioNode1.RR_SS01_BusAUndervoltage.Status;	
		pmsNode1.RR_SS01_BusAUnderVoltage.ExtTimeStamp := vSS01_ExtTimestrap_UVEn; pmsNode1.RR_SS01_BusAUnderVoltage.SignalID := vSS01_BusAUnderVoltage_Adress;	
	(*	Recovery voltage *)	
		pmsNode1.RR_SS01_BusARecVoltage.Value := ioNode1.RR_SS01_BusARecoveryVoltage.Value; pmsNode1.RR_SS01_BusARecVoltage.IOValue := ioNode1.RR_SS01_BusARecoveryVoltage.IOValue; pmsNode1.RR_SS01_BusARecVoltage.Forced := ioNode1.RR_SS01_BusARecoveryVoltage.Forced; pmsNode1.RR_SS01_BusARecVoltage.Status := ioNode1.RR_SS01_BusARecoveryVoltage.Forced;	
		pmsNode1.RR_SS01_BusARecVoltage.ExtTimeStamp := vSS01_ExtTimestrap_UVEn; pmsNode1.RR_SS01_BusARecVoltage.SignalID := vSS01_BusARecoveryVoltage_Adress;	
	(*	Busbar B *)	
	(*	Analogue Voltage measurement *)	
		pmsNode1.RR_SS01_BusB_Voltage := ioNode1.RR_SS01_BusBVoltage;	
	(*	Undervoltage *)	
		pmsNode1.RR_SS01_BusBUnderVoltage.Value:= ioNode1.RR_SS01_BusBUndervoltage.Value;pmsNode1.RR_SS01_BusBUnderVoltage.IOValue:= ioNode1.RR_SS01_BusBUndervoltage.IOValue;pmsNode1.RR_SS01_BusBUnderVoltage.Forced:= ioNode1.RR_SS01_BusBUndervoltage.Forced;pmsNode1.RR_SS01_BusBUnderVoltage.Status:= ioNode1.RR_SS01_BusBUndervoltage.Status;	
		pmsNode1.RR_SS01_BusBUnderVoltage.ExtTimeStamp := vSS01_ExtTimestrap_UVEn; pmsNode1.RR_SS01_BusBUnderVoltage.SignalID := vSS01_BusBUnderVoltage_Adress;	
	(*	Recovery voltage *)	
		pmsNode1.RR_SS01_BusBRecVoltage.Value:= ioNode1.RR_SS01_BusBRecoveryVoltage.Value;pmsNode1.RR_SS01_BusBRecVoltage.IOValue:= ioNode1.RR_SS01_BusBRecoveryVoltage.IOValue;pmsNode1.RR_SS01_BusBRecVoltage.Forced:= ioNode1.RR_SS01_BusBRecoveryVoltage.Forced;pmsNode1.RR_SS01_BusBRecVoltage.Status:= ioNode1.RR_SS01_BusBRecoveryVoltage.Status;	
		pmsNode1.RR_SS01_BusBRecVoltage.ExtTimeStamp := vSS01_ExtTimestrap_UVEn; pmsNode1.RR_SS01_BusBRecVoltage.SignalID := vSS01_BusBRecoveryVoltage_Adress;	_
H		Config Input / Output /	

Figure 39 Code for reading voltage inputs

The Restart_SS01_BusAVoltage and Restart_SS01_BusBVoltage have the same type, while the other have different types and their sub-values must then be set separately. Also create these variables, and change them to the correct values for your project:

E Co	🔚 Control module type - PMS_ApplicationLib.Restart_Reacceleration					
Editor	r Edit View Insert Tools Window Help					
: 🔜	🖬 🍏 🏷 🖶 🔯 🤊 🖻 🔏 🛍 📋	🏘 🍓 👫 🔺	🔜 if 🗛 🛺	🔊 🕅 🍸	Ż.	
	Name	Data Type	Attributes	Initial Value		
1	vSS01_BusAUnderVoltage_Adress	string[10]	retain	'0.11.2.1'		
2	vSS01_BusBUnderVoltage_Adress	string[10]	retain	'0.11.2.2'		
3	vSS01_BusARecoveryVoltage_Adress	string[10]	retain	'0.11.2.3'		
4	vSS01_BusBRecoveryVoltage_Adress	string[10]	retain	'0.11.2.4'	-	
• •	Parameters Variables External V	ariables 入 Fur	•	•		
				Row 6, Col 4		
_					_	
E Co	ntrol module type - PMS_ApplicationLib.Re	start_Reaccelera	tion		×	
Editor	Edit View Insert Tools Window Help					
: 😡 🖯 🚿 🏷 🖶 🔎 🤊 🗠 🔏 💼 🖉 🌺 🗛 🎓 🔜 🏣 🗛 🐗 🖋 🙌 🍸 🛃						
: 🐯	🖥 🎯 🤣 🖶 🙆 🤊 🖻 🔏 🛍 📋	👜 🍓 🛍 🔺	then 2. 19	\$ 🖉 tt9 🝸	Ż	
: 18	🕞 🏈 ờ 🖶 🔎 👘 🥙 🦉 🦉 📋 Name	👜 🍓 👬 🗼 Data Type	Attributes	Initial Value	ź.	

Fiaure 40	Variables	for setting	10	values

bool

External Variables

constant

Fur 4

true

Row 6, Col 4

The string values represent the IO structure for the corresponding IO variable, where the last value represents the channel number on the IO card.

5.2.1.2 Input variables – Circuit breaker status

vSS01_ExtTimestrap_RVEn

Parameters \lambda Variables 🔬

46

1 1

Create the IO variables for the circuit breaker status that shall be connected to the IO cards:

嬇 Dat	🦺 Data Type - PMS_ApplicationLib.ioNode 📃 🗖 🗙						
Editor	Edit View Insert Tools Window Help						
: 🛃 🛛	🗟 🏈 🏷 🖶 🙆 🍠 🕅 🔏 🛍 📋	🎒 🍓 🐴 🔺	🔜 🙏 💉 🍸				
	Name	Data Type	Attributes				
13	CB01_DI_FeedBackClosed	BoollO	retain				
14	CB01_DI_FeedBackOpened	BoollO	retain				
15	CB01_DI_FeedBackInService	BoollO	retain				
16	CB01_DI_FeedBackLockedOut	BoollO	retain				
17	CB02_DI_FeedBackClosed	BoollO	retain				
18	CB02_DI_FeedBackOpened	BoollO	retain				
19	CB02_DI_FeedBackInService	BoollO	retain				
20	CB02_DI_FeedBackLockedOut	BoollO	retain				
21	CB03_DI_FeedBackClosed	BoollO	retain				
22	CB03_DI_FeedBackOpened	BoollO	retain				
23	CB03_DI_FeedBackInService	BoollO	retain				
24	CB03_DI_FeedBackLockedOut	BoollO	retain 🗸				
• •	Components /						

Figure 41 IO variables for reading CB status

bat Editor	Data Type - PMS_ApplicationLib.pmsNode					
	🖬 🏽 🤌 🖶 🔎 🧐 🕅 🐇	110p	🔜 🗛 💉 🍸			
	Name	Data Type	Attributes			
64	RR_SS01_LoadsANOF	dint	retain			
65	RR_SS01_LoadsBNOF	dint	retain			
66	RR_SS01_BusAUnderVoltage	pmsReAccBoollOex	retain			
67	RR_SS01_BusBUnderVoltage	pmsReAccBoollOex	retain			
68	RR_SS01_BusARecVoltage	pmsReAccBoollOex	retain			
69	RR_SS01_BusBRecVoltage	pmsReAccBoollOex	retain			
70	RR_SS01_BusA_Voltage	ReallO	retain			
71	RR_SS01_BusB_Voltage	ReallO	retain			
72	RR_SS01_GlobalPrioConfig	pmsReAccConfigPar	retain			
73	RR_SS01_ExtPar	pmsReAccExtPar	retain			
74	RR_SS01_ExtPrio	pmsReAccExtPrio	retain			
75	RR_SS01_CBA_Closed	bool	retain			
76	RR_SS01_CBB_Closed	bool	retain			
77	RR_SS01_CBT_Closed	bool	retain			
78	RR_SS01_LoadA	pmsReAccLoadParAll	retain			
79	RR_SS01_LoadB	pmsReAccLoadParAll	retain			
80	RR_SS01_Status	pmsReAccStatusPar	retain			
81			-			
• •	Components /	•				
			1			

Create the closed feedback variables in pmsNode1:

Figure 42 Variables for CB closed status

Add this code to set the confirmed closed status:



Figure 43 Code for setting CB closed status

Then the status of the circuit breakers can be connected to the Restart_Substation01 instance:

E Connections - Restart_Sub01 pmsReAccelLib.pmsReAcc5ub						
Editor Edit View Insert Tools Window Help						
i 🔜 🖬 🚿 🖶 🔎 🕐 .	K 🕸 📋 🕭 🎂 🎓	🔜 🗛 🗢 🗞				
Name	Data Type	Initial Value	Parameter	Attributes	Direction	Description
1 Enabled	bool	Default	pmsNode1.RR_SS01_Enable		in	IN: Enable Function
2 Name	String[30]	'SubstationName'	'SS01_Restart'		in	IN EDIT: Name
3 Description	String[40]	'SubstationDescr'	'SS01_Restart'		in	IN EDIT: Description
4 AlSeverity	dint	900			in	IN EDIT: Alarm severity
5 EvSeverity	dint	500			in	IN EDIT: Event severity
6 Class	dint	50			in	IN EDIT: Alarm and Event Class
7 TaskNormal	string	Default	TaskNormal		in	IN EDIT: Normal task for initial running loads ar
8 BusA	String[10]	'Busbar A'			in	IN EDIT: Text for busbar A
9 BusB	String[10]	'Busbar B'			in	IN EDIT: Text for busbar B
10 FunctionMode	dint	1			in	IN EDIT: [1=Restart][2=Reacceleration]
11 LBBA_ID	dint	1	0		in	IN EDIT: ID of the Load Bus Bar which the sub-
12 LBBB_ID	dint	2	0		in	IN EDIT: ID of the Load Bus Bar which the sub-
13 LoadsANOF	dint	5	pmsNode1.RR_SS01_LoadsANOF		in	IN EDIT: Number of Loads in Bus A
14 LoadsBNOF	dint	5	pmsNode1.RR_SS01_LoadsBNOF		in	IN EDIT: Number of Loads in Bus B
15 BusAUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusAUnderVoltage		in	IN: Bus A Undervoltage
16 BusBUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBUnderVoltage		in	IN: Bus B Undervoltage
17 BusARecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusARecVoltage		in	IN: Bus A recovery voltage level
18 BusBRecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBRecVoltage		in	IN: Bus B recovery voltage level
19 BusAVoltage	RealIO	Default	pmsNode1.RR_SS01_BusA_Voltage		in	IN: Bus A Voltage
20 BusBVoltage	RealIO	Default	pmsNode1.RR_SS01_BusB_Voltage		in	IN: Bus B Voltage
21 EnableSecUnderVoltCheck	bool	Default	true		in	IN: Enables Bus A secondary Voltage check.
22 EnableSecRecVoltCheck	bool	Default	true		in	IN: Enables Bus B secondary Voltage check.
23 GlobalPrioConfig	pmsReAccConfigPar	Default	pmsNode1.RR_SS01_GlobalPrioConfig		in_out	IN: Priority Group configuration parameters
24 ExtPar	pmsReAccExtPar	Default	pmsNode1.RR_SS01_ExtPar		in	IN: External parameters
25 ExtPrio	pmsReAccExtPrio	Default	pmsNode1.RR_SS01_ExtPrio		in	IN: External Priority (Future)
26 CBA_C	bool	Default	pmsNode1.RR_SS01_CBA_Closed		in	IN: Circuit breaker SS_A checked closed pos
27 CBB_C	bool	Default	pmsNode1.RR_SS01_CBB_Closed		in	IN: Circuit breaker SS_B checked closed pos
28 CBT_C	bool	Default	pmsNode1.RR_SS01_CBT_Closed		in	IN: Circuit breaker SS_T checked closed pos
29 LoadA	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadA		in_out	IN_OUT: Load parameters, up to 50 Loads in s
30 LoadB	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadB		in_out	IN_OUT: Load parameters, up to 50 Loads in s
31 Status	pmsReAccStatusPar	Default	pmsNode1.RR SS01 Status		out	OUT: Function Status

Figure 44 Connecting values for CB closed status

5.2.1.1 Connection of LoadA and LoadB

Create these	variables	in	pmsNode1	and	ioNode1:
010010 110000	1 can load to b		principador		10110401.

🛃 Data Type - PMS_ApplicationLib.pmsNode					
Editor Edit View Insert Tools Window Help					
:	- 🗟 🖬 🏈 🏈 🖶 🖉 🤊 🕾 🔏 🛍 🆓 🖓 🗛 🎓 🚍 🗛 🖋 🤋				
	Name	Data Type	Attributes		
64	RR_SS01_LoadsANOF	dint	retain		
65	RR_SS01_LoadsBNOF	dint	retain		
66	RR_SS01_BusAUnderVoltage	pmsReAccBoollOex	retain		
67	RR_SS01_BusBUnderVoltage	pmsReAccBoollOex	retain		
68	RR_SS01_BusARecVoltage	pmsReAccBoollOex	retain		
69	RR_SS01_BusBRecVoltage	pmsReAccBoollOex	retain		
70	RR_SS01_BusA_Voltage	ReallO	retain		
71	RR_SS01_BusB_Voltage	ReallO	retain		
72	RR_SS01_GlobalPrioConfig	pmsReAccConfigPar	retain		
73	RR_SS01_ExtPar	pmsReAccExtPar	retain		
74	RR_SS01_ExtPrio	pmsReAccExtPrio	retain		
75	RR_SS01_CBA_Closed	bool	retain		
76	RR_SS01_CBB_Closed	bool	retain		
77	RR_SS01_CBT_Closed	bool	retain		
78	RR_SS01_LoadA	pmsReAccLoadParAll	retain		
79	RR_SS01_LoadB	pmsReAccLoadParAll	retain		
80	RR_SS01_Status	pmsReAccStatusPar	retain		
81			•		
Components					

是 Data Type - PMS_ApplicationLib.ioNode			
Editor Edit View Insert Tools Window Help			
🗟 🖬 🚿 ờ 🖶 🔎 🥑 🖱 🔏 👜 🍓	🏔 🐊 🚍 🗛 💉 🍸		
Name Data Tvp	e Attributes		
95 RR SS01 LoadA01 CloseCMD BoolIO	💑 Data Type - PMS_ApplicationLib.ioNode		
96 RR SS01 LoadA02 CloseCMD BoollO	Editor Edit View Insert Tools Window Help		
97 RR_SS01_LoadA03_CloseCMD BoolIO	: 🔜 🗑 🎯 🐎 i 📾 🔎 🔮 🗠 🗶 🖄 📋	A A A A A A A A A A A A A A A A A A A	
98 RR_SS01_LoadA04_CloseCMD BoolIO	Name		
99 RR_SS01_LoadA05_CloseCMD BoolIO	115 DD SS01 LoadA01 DOCLocal	Baallo Baal	
100 RR_SS01_LoadA06_CloseCMD BoolIO	116 PR SS01 LoadA02 POCLocal	Boolio Data Type - PMS_ApplicationLib.ioNode	
101 RR_SS01_LoadA07_CloseCMD BoolIO	117 PR SS01 LoadA03 POCLocal	Boolio Editor Edit View Insert Tools Window Help	
102 RR_SS01_LoadA08_CloseCMD BoolIO	118 RR SS01 LoadA04 POCLocal	BaallO	31
103 RR_SS01_LoadA09_CloseCMD BoolIO	119 BR SS01 LoadA05 POCLocal	Boolio Name Data Type Attributes	
104 RR_SS01_LoadA10_CloseCMD BoolIO	120 BB SS01 LoadA06 POCLocal	Boolio 135 RR_SS01_LoadA01_RunningStatus Boolio retain	
105 RR_SS01_LoadB01_CloseCMD BoolIO	121 BR SS01 LoadA07 POCLocal	BoollO 136 RR_SS01_LoadA02_RunningStatus BoollO retain	
106 RR_SS01_LoadB02_CloseCMD BoolIO	122 RR SS01 LoadA08 POCLocal	BoollO 137 RR_SS01_LoadA03_RunningStatus BoollO retain	
107 RR_SS01_LoadB03_CloseCMD BoolIO	123 RB_SS01_LoadA09_POCLocal	BoollO 138 RR_SS01_LoadA04_RunningStatus BoollO retain	
108 RR_SS01_LoadB04_CloseCMD BoolIO	124 RR_SS01 LoadA10 POCLocal	BoollO 139 RR_SS01_LoadA05_RunningStatus BoollO retain	
109 RR_SS01_LoadB05_CloseCMD BoolIO	125 RR SS01 LoadB01 POCLocal	BoollO 140 RR_SS01_LoadA06_RunningStatus BoollO retain	
110 RR_SS01_LoadB06_CloseCMD BoolIO	126 RR SS01 LoadB02 POCLocal	BoolIO 141 RR_SS01_LoadA07_RunningStatus BoolIO retain	
111 RR_SS01_LoadB07_CloseCMD BoolIO	127 BB SS01 LoadB03 POCLocal	BoollO 142 RR_SS01_LoadA08_RunningStatus BoollO retain	
112 RR_SS01_LoadB08_CloseCMD BoolIO	128 RR SS01 LoadB04 POCLocal	BoollO 143 RR_SS01_LoadA09_RunningStatus BoollO retain	
113 RR_SS01_LoadB09_CloseCMD BoolIO	129 RR SS01 LoadB05 POCLocal	BoolIO 144 RR_SS01_LoadA10_RunningStatus BoolIO retain	
114 RR_SS01_LoadB10_CloseCMD BoolIO	130 BR SS01 LoadB06 POCLocal	BoolIO 145 RR_SS01_LoadB01_RunningStatus BoolIO retain	
Components	131 RR SS01 LoadB07 POCLocal	BoollO 146 RR_SS01_LoadB02_RunningStatus BoollO retain	
	132 RR SS01 LoadB08 POCLocal	BoollO 147 RR_SS01_LoadB03_RunningStatus BoollO retain	
	133 RR SS01 LoadB09 POCLocal	BoollO 148 RR_SS01_LoadB04_RunningStatus BoollO retain	
	134 RR SS01 LoadB10 POCLocal	BoollO 149 RR_SS01_LoadB05_RunningStatus BoollO retain	
	() Components /	150 RR_SS01_LoadB06_RunningStatus BoolIO retain	
	- Componente	151 RR_SS01_LoadB07_RunningStatus BoolIO retain	
		152 RR_SS01_LoadB08_RunningStatus BoolIO retain	
		153 RR_SS01_LoadB09_RunningStatus BoollO retain	
		154 RR_SS01_LoadB10_RunningStatus BoolIO retain	
		Components	•

Figure 45 Variables to be added in pmsNode1 and ioNode1

In Figure 45 is shown the IO variables for 20 loads, 10 on A and 10 on B. Connect them for the instance:

Connections - Restart_Sub01 pmsReAccelLib.pmsReAccSub						
Editor Edit View Insert Tools Window Help						
i 🔒 🖶 🚿 i 🖶 🔎 i 🤊 🕅 J	(🕸 📋 🚇 🍓 🎓	🔜 🗛 🗢 🗞				
Name	Data Type	Initial Value	Parameter	Attributes	Direction	Description
1 Enabled	bool	Default	pmsNode1.RR_SS01_Enable		in	IN: Enable Function
2 Name	String[30]	'SubstationName'	'SS01_Restart'		in	IN EDIT: Name
3 Description	String[40]	'SubstationDescr'	'SS01_Restart'		in	IN EDIT: Description
4 AlSeverity	dint	900			in	IN EDIT: Alarm severity
5 EvSeverity	dint	500			in	IN EDIT: Event severity
6 Class	dint	50			in	IN EDIT: Alarm and Event Class
7 TaskNormal	string	Default	TaskNormal		in	IN EDIT: Normal task for initial running loads an
8 BusA	String[10]	'Busbar A'			in	IN EDIT: Text for busbar A
9 BusB	String[10]	'Busbar B'			in	IN EDIT: Text for busbar B
10 FunctionMode	dint	1			in	IN EDIT: [1=Restart][2=Reacceleration]
11 LBBA_ID	dint	1	0		in	IN EDIT: ID of the Load Bus Bar which the sub
12 LBBB_ID	dint	2	0		in	IN EDIT: ID of the Load Bus Bar which the sub
13 LoadsANOF	dint	5	pmsNode1.RR_SS01_LoadsANOF		in	IN EDIT: Number of Loads in Bus A
14 LoadsBNOF	dint	5	pmsNode1.RR_SS01_LoadsBNOF		in	IN EDIT: Number of Loads in Bus B
15 BusAUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusAUnderVoltage		in	IN: Bus A Undervoltage
16 BusBUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBUnderVoltage		in	IN: Bus B Undervoltage
17 BusARecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusARecVoltage		in	IN: Bus A recovery voltage level
18 BusBRecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBRecVoltage		in	IN: Bus B recovery voltage level
19 BusAVoltage	ReallO	Default	pmsNode1.RR_SS01_BusA_Voltage		in	IN: Bus A Voltage
20 BusBVoltage	RealIO	Default	pmsNode1.RR_SS01_BusB_Voltage		in	IN: Bus B Voltage
21 EnableSecUnderVoltCheck	bool	Default	true		in	IN: Enables Bus A secondary Voltage check.
22 EnableSecRecVoltCheck	bool	Default	true		in	IN: Enables Bus B secondary Voltage check.
23 GlobalPrioConfig	pmsReAccConfigPar	Default	pmsNode1.RR_SS01_GlobalPrioConfig		in_out	IN: Priority Group configuration parameters
24 ExtPar	pmsReAccExtPar	Default	pmsNode1.RR_SS01_ExtPar		in	IN: External parameters
25 ExtPrio	pmsReAccExtPrio	Default	pmsNode1.RR_SS01_ExtPrio		in	IN: External Priority (Future)
26 CBA_C	bool	Default	pmsNode1.RR_SS01_CBA_Closed		in	IN: Circuit breaker SS_A checked closed pos
27 CBB_C	bool	Default	pmsNode1.RR_SS01_CBB_Closed		in	IN: Circuit breaker SS_B checked closed pos
28 CBT_C	bool	Default	pmsNode1.RR_SS01_CBT_Closed		in	IN: Circuit breaker SS_T checked closed pos
29 LoadA	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadA		in_out	IN_OUT: Load parameters, up to 50 Loads in s
30 LoadB	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadB		in_out	IN_OUT: Load parameters, up to 50 Loads in s
31 Status	pmsReAccStatusPar	Default	pmsNode1.RR SS01 Status		out	OUT: Function Status

Figure 46 Connecting the LoadPar to the instance

5.2.1.1 Input/output variables - Load status/POCLoc/Close_CMD

The status from the loads, RunningStatus and POCLoc (local point of control), must be read from IO variables into pmsNode1 dataset:



Figure 47 Reading Load status values

In Figure 47 is shown code for LoadA01, similar code must be added for LoadA02-10 and LoadB01-10. The necessary variables that must be created for these inputs are also shown in the figure. The close commands to the loads should be set in the Output code block (the variables in pmsNode1 and ioNode1 are of the same type (BooIIO)):

🔁 Control module type - PMS_ApplicationLib.Restart_Reacceleration	
Editor Edit View Insert Tools Window Help	
: 😡 🔒 🏈 🗁 🚇 🖉 🤲 🖉 🖄 📋 🖓 🌺 🏔 🏠 🎥 🔚 🏭 🏭 🔐 🚱 🕐 🍸 💱 針	
(* *)	
(* Load - Close command output *) (* *)	
(*************************************	
(* Busbar A *)	
ioNode1.RR_SS01_LoadA01_CloseCMD := pmsNode1.RR_SS01_LoadA.LoadPar01.Close_CMD;	
<pre>ioNode1.KK_SSU1_LoadAU2_CloseCMD := pmsNode1.KK_SSU1_LoadA.LoadParU2.Close_CMD; ioNode1.RR_SSU1_LoadA03_CloseCMD := pmsNode1.RR_SSU1_LoadA.LoadParU3.Close_CMD;</pre>	
ioNode1.RR_SS01_Load&04_CloseCMD := pmsNode1.RR_SS01_Load&.LoadPar04.Close_CMD; ioNode1_RR_SS01_Load&05_CloseCMD := pmsNode1_RR_SS01_Load&_LoadPar05_Close_CMD;	
ioNode1.RR_SS01_LoadA06_CloseCMD := pmsNode1.RR_SS01_LoadA.LoadPar06.Close_CMD;	
ioNodel.RR_SSU1_LoadA07_CloseCMD := pmsNodel.RR_SS01_LoadA.LoadPar07.Close_CMD; ioNodel.RR_SS01_LoadA08_CloseCMD := pmsNodel.RR_SS01_LoadA.LoadPar08.Close_CMD;	
ioNode1.RR_SS01_LoadA09_CloseCMD := pmsNode1.RR_SS01_LoadA.LoadPar09.Close_CMD; ioNode1.RR SS01_LoadA10_CloseCMD := pmsNode1.RR_SS01_LoadA.LoadPar10.Close_CMD;	
(* Duchan R *)	
(* busbar b *)	
ioNode1.RR_SS01_LoadB01_CloseCMD := pmsNode1.RR_SS01_LoadB.LoadPar01.Close_CMD; ioNode1.RR SS01_LoadB02_CloseCMD := pmsNode1.RR_SS01_LoadB.LoadPar02.Close_CMD;	
ioNode1.RR_SS01_LoadB03_CloseCMD := pmsNode1.RR_SS01_LoadB.LoadPar03.Close_CMD; ioNode1_RR_SS01_LoadB04_CloseCMD := pmsNode1_RR_SS01_LoadB_LoadPar04_Close_CMD;	
ioNode1.RR_SS01_LoadB05_CloseCMD := pmsNode1.RR_SS01_LoadB.LoadPar05.Close_CMD;	
<pre>ioNode1.RR_SS01_LoadB06_CloseCMD := pmsNode1.RR_SS01_LoadB.LoadPar06.Close_CMD; ioNode1.RR_SS01_LoadB07_CloseCMD := pmsNode1.RR_SS01_LoadB.LoadPar07.Close_CMD;</pre>	
ioNode1.RR_SS01_LoadB08_CloseCMD := pmsNode1.RR_SS01_LoadB.LoadPar08.Close_CMD; ioNode1_RR_SS01_LoadB09_CloseCMD := pmsNode1_RR_SS01_LoadB_LoadPar09_Close_CMD;	
ioNode1.RR_SS01_LoadB10_CloseCMD := pmsNode1.RR_SS01_LoadB.LoadPar10.Close_CMD;	
	-
Config Input Output	

Figure 48 Setting Close command outputs

5.2.1.1 Connection of ExtPar

Create this variable in pmsNode1:

뤚 Data Type - PMS_ApplicationLib.pmsNode 📃 🗆 🗙					
Editor	Edit View Insert Tools Window	Help			
ि 😡 🗑 🏈 🖶 🙆 🔊 🖭 🔏 🛍 🛯 🐥 🖀 🖌 🎓 🖃 🕺 📝					
	Name	Data Type	Attributes		
64	RR_SS01_LoadsANOF	dint	retain		
65	RR_SS01_LoadsBNOF	dint	retain		
66	RR_SS01_BusAUnderVoltage	pmsReAccBoollOex	retain		
67	RR_SS01_BusBUnderVoltage	pmsReAccBoollOex	retain		
68	RR_SS01_BusARecVoltage	pmsReAccBoollOex	retain		
69	RR_SS01_BusBRecVoltage	pmsReAccBoollOex	retain		
70	RR_SS01_BusA_Voltage	ReallO	retain		
71	RR_SS01_BusB_Voltage	ReallO	retain		
72	RR_SS01_GlobalPrioConfig	pmsReAccConfigPar	retain		
73	RR_SS01_ExtPar	pmsReAccExtPar	retain		
74	RR_SS01_ExtPrio	pmsReAccExtPrio	retain		
75	RR_SS01_CBA_Closed	bool	retain		
76	RR_SS01_CBB_Closed	bool	retain		
77	RR_SS01_CBT_Closed	bool	retain		
78	RR_SS01_LoadA	pmsReAccLoadParAll	retain		
79	RR_SS01_LoadB	pmsReAccLoadParAll	retain		
80	RR_SS01_Status	pmsReAccStatusPar	retain		
81			-		
Components					

Figure 49 Variable for external parameter.
E	Connections - Restart_Sub01 pmsReAccelLib.pmsReAcceSub								
Edit	Editor Edit View Insert Tools Window Help								
: 6	l 🖬 🥬 🖶 🔎 🤊 🖭 🔏	🕸 🗋 🕭 🎂 🎓	🔜 🗛 🗢 🐄						
	Name	Data Type	Initial Value	Parameter	Attributes	Direction	Description		
1	Enabled	bool	Default	pmsNode1.RR_SS01_Enable		in	IN: Enable Function		
2	Name	String[30]	'SubstationName'	'SS01_Restart'		in	IN EDIT: Name		
3	Description	String[40]	'SubstationDescr'	'SS01_Restart'		in	IN EDIT: Description		
4	AlSeverity	dint	900			in	IN EDIT: Alarm severity		
5	EvSeverity	dint	500			in	IN EDIT: Event severity		
6	Class	dint	50			in	IN EDIT: Alarm and Event Class		
7	TaskNormal	string	Default	TaskNormal		in	IN EDIT: Normal task for initial running loads an		
8	BusA	String[10]	'Busbar A'			in	IN EDIT: Text for busbar A		
9	BusB	String[10]	'Busbar B'			in	IN EDIT: Text for busbar B		
10	FunctionMode	dint	1			in	IN EDIT: [1=Restart][2=Reacceleration]		
11	LBBA_ID	dint	1	0		in	IN EDIT: ID of the Load Bus Bar which the subs		
12	LBBB_ID	dint	2	0		in	IN EDIT: ID of the Load Bus Bar which the subs		
13	LoadsANOF	dint	5	pmsNode1.RR_SS01_LoadsANOF		in	IN EDIT: Number of Loads in Bus A		
14	LoadsBNOF	dint	5	pmsNode1.RR_SS01_LoadsBNOF		in	IN EDIT: Number of Loads in Bus B		
15	BusAUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusAUnderVoltage		in	IN: Bus A Undervoltage		
16	BusBUnderVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBUnderVoltage		in	IN: Bus B Undervoltage		
17	BusARecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusARecVoltage		in	IN: Bus A recovery voltage level		
18	BusBRecoveryVoltage	pmsReAccBoollOex	Default	pmsNode1.RR_SS01_BusBRecVoltage		in	IN: Bus B recovery voltage level		
19	BusAVoltage	RealIO	Default	pmsNode1.RR_SS01_BusA_Voltage		in	IN: Bus A Voltage		
20	BusBVoltage	RealIO	Default	pmsNode1.RR_SS01_BusB_Voltage		in	IN: Bus B Voltage		
21	EnableSecUnderVoltCheck	bool	Default	true		in	IN: Enables Bus A secondary Voltage check.		
22	EnableSecRecVoltCheck	bool	Default	true		in	IN: Enables Bus B secondary Voltage check.		
23	GlobalPrioConfig	pmsReAccConfigPar	Default	pmsNode1.RR_SS01_GlobalPrioConfig		in_out	IN: Priority Group configuration parameters		
24	ExtPar	pmsReAccExtPar	Default	pmsNode1.RR_SS01_ExtPar		in	IN: External parameters		
25	ExtPrio	pmsReAccExtPrio	Default	pmsNode1.RR_SS01_ExtPrio		IN	IN: External Priority (Future)		
26	CBA_C	bool	Default	pmsNode1.RR_SS01_CBA_Closed		in	IN: Circuit breaker SS_A checked closed pos		
27	CBB_C	bool	Default	pmsNode1.RR_SS01_CBB_Closed		in	IN: Circuit breaker SS_B checked closed pos		
28	CBT_C	bool	Default	pmsNode1.RR_SS01_CBT_Closed		in	IN: Circuit breaker SS_T checked closed pos		
29	LoadA	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadA		in_out	IN_OUT: Load parameters, up to 50 Loads in s		
30	LoadB	pmsReAccLoadParAll	Default	pmsNode1.RR_SS01_LoadB		in_out	IN_OUT: Load parameters, up to 50 Loads in s		
31	Status	pmsReAccStatusPar	Default	pmsNode1.RR_SS01_Status		out	OUT: Function Status		

Then connect the variable to the instance:

Figure 50 Connection of the external parameter variable.

The code for setting the external parameters is placed in the code block "Input":

Control module type - PMS_ApplicationLib.Restart_Reacceleration	'×
Editor Edit View Insert Tools Window Help	
E 💀 🖬 🏈 🖉 🗐 🤨 K 🖄 🗈 🛛 🖓 🆓 🗛 🖕 📾 🖬 🐇 🖓 🚮	f
(* External Configuration *) pmsNode1.RR_SS01_ExtPar.DisResetEvent := True; pmsNode1.RR_SS01_ExtPar.DisSpuriousAlarm := True;	
Config Input Output	

Figure 51 Setting external parameters from code or other inputs



The purpose of disabling events is to reduce the load on the controller during possible event bursts when many loads start at the same time, refer section 4.2

5.2.1.2 Setting parameters from application code

To set parameters from application code, the *GlobalPrioConfig.Global.OperatorSettable* must be set to false, as described in section 3.1.15. This dims certain parameter fields in the faceplate and then prevents these parameters to be changed by the operator.

Load parameters, global parameters and priority parameters can then be set by application code.

The load parameters that can be changed are shown in Figure 52:

	😓 Data Type - pmsBasicLib.pmsReAccLoadPar [Read-only]								
Edito	Editor Edit View Insert Tools Window Help								
	R R 🊿 🏈 🖶 🗩 👘 🕐 🐇 🟦 📋 🚇 🍓 AA 🕼 🔛 🗛 🚽 🔽 🛃								
	Name	Data Type	Attributes	Initial Value	ISP Value	Description			
1	SrcName	string[30]	coldretain nosort	'Load01'		IN: Load Name			
2	SrcDesc	string[60]	coldretain nosort	'Load01 desc'		IN: Load Description			
3	ExternalSettings	bool	coldretain nosort	false		IN: External load settings			
4	OpenCircuit_time	time	coldretain nosort	0.2s		IN: Waiting time before reconnection can be attempted			
5	AllowedReaccel_time	time	coldretain nosort	10s		IN: Time from power outage to reacceleration could succeed			
6	CloseCMD_time	time	coldretain nosort	1s		IN: Pulse length for close command			
7	RunningFb_timeout	time	coldretain nosort	2s		IN: Time from close command until running feedback is expected			
8	MaxNrOfAttempts	dint	coldretain nosort	3		IN: Max number of reaccel attempts.			
9	PLoad	real	coldretain nosort	1.0		IN: Load value (MW,Current,In rush current)			
10	Grouped	bool	coldretain nosort	true		IN: Individual settings are decided by Group settings			
11	Prio	dint	coldretain nosort	1		IN: Load Reaccel/Restart priority			
12	ExtPrioSel	bool	nosort	false		IN: External Reaccel/Restart priority selected			
13	ExternalInhibit	bool	nosort	false		IN: External Inhibit			
14	POCLoc	pmsReAccBoollOex	nosort			IN: Circuit breaker point of control			
15	RunningStatus	pmsReAccBoollOex	nosort			IN: Load running status.			
16	Close_CMD	BoollO	nosort			OUT: Reaccel/Restart command			
17	Disabled	bool	nosort	false		OUT: Load status, load is disabled for reaccel/restart			
18	Signal_Err	bool	nosort	false		OUT: Load signal error indication			
19	FailedReaccel	bool	nosort	false		OUT: Failed reaccel			
20	InhibitStatus	bool	nosort	false		OUT: AutoInhibit\Operator Inhibit Active			
• •	Components								

Figure 52 Load parameters that can be set by application code/external

To change the Prio from code, first set the parameter *ExtPrioSel* to true. The other parameters marked as red in Figure 52 can be set directly.

	ata Type - pmsBasicLib.pmsF	ReAccGlobalPar								
Edito	Editor Edit View Insert Tools Window Help									
:	Be Be Se an									
	Name	Data Type	Attributes	Initial Value	ISP Value	Description				
1	EnableReporting	bool	coldretain nosort	false		IN: Enable reporting function				
2	EnableOpReporting	bool	coldretain nosort	false		IN: Enable manual reoporting by operator				
3	PrioRestartMethod	dint	coldretain nosort	0		IN EDIT: Static Restart = 0, Dynamic Restart = 1				
4	BusbarsConfigured	dint	coldretain nosort	0		IN EDIT: BusbarA & BusbarB = 0 BusbarA = 1, BusbarB = 2				
5	CBConfigured	dint	coldretain nosort	0		IN EDIT: CBA,CBB&CBT = 0, CBA&CBB = 1, CBA = 2, CBB = 3				
6	MaxPriority	dint	coldretain nosort	20		IN: Max number of priorities used.				
7	CoordinateRestart	bool	coldretain nosort	false		IN: Coordinate restart of Busbar A & B				
8	HideManualInhibit	bool	coldretain nosort	false		IN: True will hide manual inhibit column				
9	HideLoadValue	bool	coldretain nosort	false		IN: True will hide Load value column				
10	OperatorSettable	bool	coldretain nosort	true		IN: Operator from changing settings from faceplate				
11	VoltageDecayLevel	real	coldretain nosort	0		IN: Voltage decay level in present				
12	VoltageRecoveryLevel	real	coldretain nosort	0		IN: Voltage Recovery level in present				
13	VoltageRecoveryHyst	time	coldretain nosort	1s		IN: Minimum time for voltage recovery to be stable before restart				
14	AllowedVoltRecoveryTime	time	coldretain nosort	20s		IN: Max allowed voltage recovery time before operation is canceled				
15	MaxNrVoltageDecays	dint	coldretain nosort	5		IN: Max number of Voltage decays before operation is canceled				
16	MaxLimit_IncomerA	real	coldretain nosort	0		IN: Max limit for Incomer A				
17	MaxLimit_IncomerB	real	coldretain nosort	0		IN: Max limit for Incomer B				
18	ReAccGroupDelayTime	time	coldretain nosort	1s		IN: Delay before this priority start				
19	OpenCircuit_time	time	coldretain nosort	0.5s		IN: Waiting time before reconnection can be attempted				
20	AllowedReaccel_time	time	coldretain nosort	10s		IN: Time from power outage to reacceleration could succeed				
21	CloseCMD_time	time	coldretain nosort	1s		IN: Pulse length for close command				
22	RunningFb_timeout	time	coldretain nosort	2s		IN: Time from close command until running feedback is expected				
23	MaxNrOfAttempts	dint	coldretain nosort	3		IN: Max number of reaccel attempts.				
24	UpdateRunningFbT	time	coldretain nosort	2s		IN: Update rate for scanning running feedback in Idle state				
25	SignalTransitionT	time	coldretain nosort	1s		IN: Transition time for undervoltage and recovervoltage signals				
1)	Components									

Global parameters; the global parameters are shown in table below.

Figure 53 Global parameters

	ine prie	ny paran		priority gre	
Da	ata Type - pmsBasicLib.pm	IsReAccGrou	upPar [Read-only]		
Edito	r Edit View Insert Tools	Window H	telp		
	• • • • • • • • • • • • • • • • • • •		6 6 6 8 4		at ● 拳 ▽ <u>\$</u>↓ <u>\$</u>↓
	Name	Data Type	Attributes	Initial Value	Description
1	ReAccGroupDelayTime	time	coldretain nosort	1s	IN: Delay before this priority start
2	OpenCircuit_time	time	coldretain nosort	0.5s	IN: Waiting time before reconnection can be attempted
3	AllowedReaccel_time	time	coldretain nosort	10s	IN: Time from power outage to reacceleration could succeed
4	CloseCMD_time	time	coldretain nosort	1s	IN: Pulse length for close command

The priority parameters for each priority group are shown in table below.

RunningFb_timeout	time	coldretain nosort	2s	IN: Time from close command until running feedback is expected
MaxNrOfAttempts	dint	coldretain nosort	3	IN: Max number of reaccel attempts.
Prio	dint	coldretain nosort	1	IN: Load Reaccel/Restart priority
Grouped	bool	coldretain nosort	true	IN: Individual settings are decided by Global settings
			-	

Figure 54 Priority parameters

4 5

6

7 Prio

8

An example of setting some parameters by application code is given Figure 55.



Figure 55 Example of code for settings parameters

Field	Description
1	Setting this variable true disables operator changes of certain values in the faceplate.
2	This example sets the priority of Load01 and Load02 to the highest for a certain condition.
3	Load01-05 are inhibited for start-up for a certain condition at another substation.
4	Reporting is enabled by a global variable. The manual inhibit field is hidden for substation 1 for a certain condition.
5	The time delay of priority group 1 of substation 1 is changed for a certain condition.

Table 28 Examples of parameters set by application code

Appendix A Interaction & Permissions

Name	Permission	Faceplate element
Enable	Operate	Main
Disable	Operate	Main
Reset	Operate	Main
Block bus A	Operate	Main
Block bus B	Operate	Main
Priority	Tune	Busbar A∖B
Manual Inhibit	Tune	Busbar A∖B
Inherit priority group settings	Configure	Load settings
Priority	Tune	Load settings
Open circuit time constant	Configure	Load settings
Max allowed restart time	Configure	Load settings
Running feedback time	Configure	Load settings
Close command pulse time	Configure	Load settings
Max no. Of restart attempts	Configure	Load settings
Voltage recovery level	Configure	Global
Voltage decay level	Configure	Global
Voltage recovery hysteresis	Configure	Global
Allowed voltage recovery time	Configure	Global
Max no. Of voltage decays	Configure	Global
(Priority group) Restart delay	Configure	Global
(Load) Open circuit time constant	Configure	Global
(Load) Max allowed restart time	Configure	Global
(Load) Running feedback time	Configure	Global
(Load) Close command pulse time	Configure	Global
(Load) Max no. of restart attempts	Configure	Global

Table 29 User interaction permissions

Appendix A Revision table

Rev. ind.	Page (P) / Chapter ©	Description	Date
А		Initial document release for 5.6-5	2022.08.30/KAA

Contact us

ABB AS

PA Energy Industries Fornebu, Norway E-mail: power.management@no.abb.com ABB Oil and Gas Copyright $\ensuremath{\textcircled{C}}$ 2002 – 2022 by ABB. All Rights Reserved.

