

Combined Overvoltage and Undervoltage Relay REU 523

Technical Reference Manual



ABB

Contents

1. About this manual	5
1.1. Copyrights	5
1.2. Trademarks	5
1.3. Guarantee	5
1.4. General	5
1.5. Use of symbols	6
1.6. Terminology	6
1.7. Related documents	6
1.8. Document revisions	6
2. Safety Information	7
3. Introduction	9
3.1. Use of the relay	9
3.2. Features	9
4. Instructions	11
4.1. Application	11
4.2. Requirements	11
4.3. Configuration	11
5. Technical description	13
5.1. Functional description	13
5.1.1. Product functions	13
5.1.1.1. Schema of product functions	13
5.1.1.2. Overvoltage, undervoltage and positive- phase-sequence	13
5.1.1.3. Inputs	14
5.1.1.4. Outputs	14
5.1.1.5. Circuit-breaker failure protection unit	14
5.1.1.6. Disturbance recorder	14
5.1.1.7. HMI module	14
5.1.1.8. Non-volatile memory	15
5.1.1.9. Self-supervision	15
5.1.2. Measurements	16
5.1.3. Configuration	16
5.1.4. Protection	17
5.1.4.1. Block diagram	17
5.1.4.2. Overvoltage unit	17
5.1.4.3. Undervoltage unit	18
5.1.4.4. Positive-phase-sequence protection	19
5.1.4.5. Time/voltage characteristics	20
5.1.4.6. Settings	23

5.1.4.7. Technical data on protection functions	31
5.1.5. Indicator LEDs and alarm indication messages	32
5.1.6. Monitoring of demand values	33
5.1.7. Commissioning test	33
5.1.8. Disturbance recorder	33
5.1.8.1. Function	33
5.1.8.2. Disturbance recorder data	33
5.1.8.3. Control and indication of disturbance recorder status	34
5.1.8.4. Triggering	35
5.1.8.5. Settings and unloading	35
5.1.8.6. Event code of the disturbance recorder	35
5.1.9. Recorded data of the last events	35
5.1.10. External serial communication	36
5.1.10.1. Communication ports	36
5.1.10.2. IEC 60870-5-103 remote communication protocol	37
5.1.10.3. Event codes	40
5.1.10.4. SPA bus communication protocol parameters ..	42
5.1.11. Self-supervision (IRF) system	49
5.1.12. Relay parameterization	50
5.2. Design description	50
5.2.1. Input/output connections	50
5.2.2. Serial communication connections	52
5.2.3. Technical data	54
6. Ordering information	59
7. Abbreviations	61
8. Check lists	63
9. Service	67
10. Index	69
11.	

1. About this manual

1.1. Copyrights

The information in this document is subject to change without notice and should not be construed as a commitment by ABB Oy. ABB Oy assumes no responsibility for any errors that may appear in this document.

In no event shall ABB Oy be liable for direct, indirect, special, incidental or consequential damages of any nature or kind arising from the use of this document, nor shall ABB Oy be liable for incidental or consequential damages arising from use of any software or hardware described in this document.

This document and parts thereof must not be reproduced or copied without written permission from ABB Oy, and the contents thereof must not be imparted to a third party nor used for any unauthorized purpose.

The software or hardware described in this document is furnished under a license and may be used, copied, or disclosed only in accordance with the terms of such license.

Copyright © 2005 ABB Oy
All rights reserved.

1.2. Trademarks

ABB is a registered trademark of ABB Group.

All other brand or product names mentioned in this document may be trademarks or registered trademarks of their respective holders.

1.3. Guarantee

Please inquire about the terms of guarantee from your nearest ABB representative.

1.4. General

The purpose of this manual is to provide the user with thorough information on the protection relay REU 523 and its applications, focusing on giving a technical description of the relay.

Refer to the Operator's Manual for instructions on how to use the Human-Machine Interface (HMI) of the relay, also known as the Man-Machine Interface (MMI), and to the Installation Manual for installation of the relay.

1.5. Use of symbols

This document includes warning, caution, and information icons that point out safety-related conditions or other important information. The corresponding icons should be interpreted as follows:



The electrical warning icon indicates the presence of a hazard which could result in electrical shock.



The caution icon indicates important information or warning related to the concept discussed in the text. It might indicate the presence of a hazard which could result in corruption of software or damage to equipment or property.



The information icon alerts the reader to relevant facts and conditions.

Although warning hazards are related to personal injury, and caution hazards are associated with equipment or property damage, it should be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process performance leading to personal injury or death. Therefore, comply fully with all warning and caution notices.

1.6. Terminology

The following is a list of terms that you should be familiar with. The list contains terms that are unique to ABB or have a usage or definition that is different from standard industry usage.

Term	Description
IEC_103	IEC 60870-5-103, a communication protocol standardized by the International Electrotechnical Commission
SPA	A data communication protocol developed by ABB



1.7. Related documents

Name of the manual	MRS number
REU 523 Operator's Manual	1MRS750157-MUM
RE_5__ Installation Manual	1MRS750526-MUM

1.8. Document revisions

Version	Date	History
C	25.05.2004	Address field updated. Customer Feedback form removed
D	16.11.2005	Relay face plate updated. Manual layout updated.
E	15.9.2011	Pictures updated in chapter 5.1.4.5.

2. Safety Information

	Dangerous voltages can occur on the connectors, even though the auxiliary voltage has been disconnected.
	Non-observance can result in death, personal injury or substantial property damage.
	Only a competent electrician is allowed to carry out the electrical installation.
	National and local electrical safety regulations must always be followed.
	The frame of the device has to be carefully earthed.
	The device contains components which are sensitive to electrostatic discharge. Unnecessary touching of electronic components must therefore be avoided.
	Breaking the sealing tape on the rear panel of the device will result in loss of warranty and proper operation will no longer be guaranteed.

3. Introduction

3.1. Use of the relay

The voltage relay REU 523 is intended for over and undervoltage protection in medium voltage distribution networks but can also be used for protection of generators, motors and transformers.

The REU 523 is based on a microprocessor environment. A self-supervision system continuously monitors the operation of the relay.

The HMI includes a Liquid Crystal Display (LCD) which makes the local use of the relay safe and easy.

Local control of the relay via serial communication can be carried out with a portable computer connected to the front connector and remote control via the rear connector connected to the distribution automation system through the serial interface and the fibre-optic bus.

3.2. Features

- Single or three-phase use
- High-set overvoltage stage with definite-time or inverse definite minimum time (IDMT) characteristic
- Low-set overvoltage stage with definite-time or IDMT characteristic
- High-set undervoltage stage with definite-time or IDMT characteristic
- Low-set undervoltage stage with definite-time or IDMT characteristic
- Positive-phase-sequence protection
- Adjustable drop-off/pick-up ratio for the low-set stages
- Circuit-breaker failure protection (CBFP)
- Disturbance recorder
 - recording time up to 12 seconds
 - triggering by a start or a trip signal from a protection stage and/or by a binary input signal
 - records three analogue channels and eight digital channels
 - adjustable sampling rate
- Non-volatile memory for
 - up to 60 event codes
 - setting values
 - disturbance recorder data
 - recorded data of the five last events with time stamp
 - number of starts for each stage
 - alarm indication messages and LEDs showing the status at the moment of power failure
- Three accurate voltage inputs
- Galvanically isolated binary input with a wide input voltage range

- All settings can be modified with a personal computer
- HMI with an alphanumeric LCD and manoeuvring buttons
- IEC 60870-5-103 and SPA bus communication protocols
- Two normally open power output contacts
- Two change-over signal output contacts
- Output contact functions freely configurable for desired operation
- Optical PC-connector for two-way data communication (front)
- RS-485 connector (rear) for system communication
- Continuous self-supervision of electronics and software. At an internal relay fault (IRF), all protection stages and outputs are blocked.
- User-selectable rated frequency 50/60 Hz
- User-selectable password protection for the HMI
- User-selectable nominal voltage 100/110/115/120 V
- Display of primary voltage values
- Demand values
- Multi-language support

4. Instructions

4.1. Application

The over and undervoltage relay REU 523 is a secondary relay which is connected to the voltage transformers of the object to be protected. The over and the undervoltage unit continuously measure the fundamental wave of the phase-to-phase voltages of the object. On detection of a fault, the relay will start, trip the circuit breaker, provide alarms, record fault data, etc., in accordance with the application and the configured relay functions.

The overvoltage unit includes low-set stage $U>$ and high-set stage $U>>$ and the undervoltage unit low-set stage $U<$ and high-set stage $U<<$. The high-set undervoltage stage can alternatively be set to evaluate the positive-phase-sequence voltage. In addition, the high-set undervoltage stage can be configured to evaluate only one instead of three phase-to-phase voltages.

The protection functions are independent of each other and have their own setting groups and data recordings. The over and undervoltage functions use conventional voltage transformer measurement. The high-set undervoltage stage can alternatively be set to be based on the calculated positive-phase-sequence voltage.

An output contact matrix allows start or trip signals from the protection stages to be routed to the desired output contact.

4.2. Requirements

When the REU 523 is operating under the conditions specified below (see also Technical data), it will be practically maintenance-free. The relay includes no parts or components subject to abnormal physical or electrical wear under normal operating conditions.

Environmental conditions


- Specified ambient service temperature range -10...+55 °C
- Temperature influence on the operation accuracy of the protection relay within the specified ambient service temperature range 0.1% / °C
- Transport and storage temperature range -40...+70 °C

4.3. Configuration

Setting and connection example

The appropriate configuration of the output contact matrix enables the use of the signals from the under/overvoltage units as contact functions. The start signals can be used for blocking co-operating protection relays, signalling and initiating auto-reclosing.

Fig. 4.3.-1 represents the REU 523 with the default configuration.



A051867


Fig. 4.3.-1 Connection diagram

5. Technical description

5.1. Functional description

5.1.1. Product functions

5.1.1.1. Schema of product functions



A051868

Fig. 5.1.1.1.-1 Product functions

5.1.1.2. Overvoltage, undervoltage and positive-phase-sequence

Refer to sections:

- 5.1.4.2. “Overvoltage unit”
- 5.1.4.3. “Undervoltage unit”
- 5.1.4.4. “Positive-phase-sequence protection”

5.1.1.3.**Inputs**

The REU 523 includes three energizing inputs and one external binary input controlled by an external voltage. For details, refer to section Input/output connections and tables 5.1.4.6-6, 5.2.1-1 and 5.2.1-5. The function of the binary input is determined with the SGB switches.

5.1.1.4.**Outputs**

The REU 523 is provided with two power outputs (PO1 and PO2) and two signal outputs (SO1 and SO2). Switchgroups SGR1...8 are used for routing start and trip signals from the protection stages to the desired signal or power output. PO1 and PO2 can be configured to be latched and the minimum pulse length to 40 or 80 ms.

5.1.1.5.**Circuit-breaker failure protection unit**

The REU 523 features a circuit-breaker failure protection (CBFP) unit. The CBFP unit will generate a trip signal via output PO2 if the fault has not been cleared on expiration of the set operate time 0.10 s...1.00 s.

Normally, the CBFP unit controls the upstream circuit breaker. It can also be used for tripping via redundant trip circuits of the same circuit breaker. The CBFP unit is activated with a switch of switchgroup SGF1.

5.1.1.6.**Disturbance recorder**

The REU 523 includes an internal disturbance recorder which records the momentary measured values, or the RMS curves of the measured signals, and eight digital signals: the external binary input signal and the states of the internal protection stages. The disturbance recorder can be set to be triggered by a start or a trip signal from any protection stage and/or by an external binary input signal, and either on the falling or rising triggering edge.

5.1.1.7.**HMI module**

The HMI of the REU 523 is equipped with six push-buttons and an alphanumeric 2x16 characters' LCD. The push-buttons are used for navigating in the menu structure and for adjusting set values.


An HMI password can be set to protect all user-changeable values from being changed by an unauthorised person. The HMI password will remain inactive and will thus not be required for altering parameter values until the default HMI password has been replaced. Entering the HMI password successfully can be selected to generate an event code. This feature can be used to indicate interaction activities via the local HMI. For further information on the HMI, refer to the Operator's Manual.

5.1.1.8. Non-volatile memory

The REU 523 can be configured to store various data in the non-volatile memory, which will retain its data also in case of loss of auxiliary voltage. Alarm indication messages and LEDs, the number of starts, disturbance recorder data, event codes and recorded data can all be configured to be stored in the non-volatile memory whereas setting values will always be stored.

5.1.1.9. Self-supervision

The self-supervision system of the REU 523 manages run-time fault situations and informs the user about an existing fault. When the self-supervision system detects a permanent internal relay fault, the READY indicator LED will start to blink. At the same time the self-supervision alarm relay (also referred to as the IRF relay), which is normally picked up, will drop off and a fault code will appear on the LCD. The fault code is numerical and identifies the fault type. For fault codes, refer to section Internal fault in the Operator's Manual.



A051289

Fig. 5.1.1.9.-1 Internal fault

Fault codes can indicate:

- no response on the output contact test
- faulty program, work or parameter memory
- too high or too low a reference voltage value

5.1.2. Measurements


The table below presents the measured values which can be accessed through the HMI, expressed as multiples of the rated voltage, U_n , of the energizing input.

Table 5.1.2-1 Measured values

Indicator	Measured data
U_{12}	Main voltage U_{12}
U_{23}	Main voltage U_{23}
U_{31}	Main voltage U_{31}
U_{1s}	Positive-phase-sequence voltage
U_{max}	Maximum voltage of the three main voltages
U_{min}	Minimum voltage of the three main voltages
U_{1min}	Average voltage of the three main voltages during one minute
U_{10min}	Average voltage of the three main voltages during ten minutes

5.1.3. Configuration

The figure below illustrates how the start, trip and binary input signals can be configured to obtain the required protection functionality.




A051870

Fig. 5.1.3.-1 Signal diagram

The functions of the blocking and start signals are selected with the switches of switchgroups SGF, SGB and SGR. The checksums of the switchgroups are found under "SETTINGS" in the HMI menu. The functions of these switches are explained in detail in the corresponding SG_ -tables.

5.1.4. Protection

5.1.4.1. Block diagram



A051871

Fig. 5.1.4.1.-1 Block diagram

5.1.4.2. Overvoltage unit

When the voltage values exceed the set start value of low-set stage $U_{>}$, the overvoltage unit will start to deliver a start signal after a ~ 60 ms' start time. When the set operate time at definite-time characteristic or the calculated operate time at IDMT characteristic elapses, the overvoltage unit will deliver a trip signal.

When the voltage values exceed the set start value of high-set stage $U_{>>}$, the overvoltage unit will start to deliver a start signal after a ~ 50 ms' start time. When the set operate time at definite-time characteristic or the calculated operate time at IDMT characteristic elapses, the overvoltage unit will deliver a trip signal.

It is possible to block the tripping of an overvoltage stage by applying an external binary input signal to the relay.

The high-set stage can be set out of operation. This state will be indicated by dashes on the LCD and by "999" when the set start value is read via serial communication.

5.1.4.3.**Undervoltage unit**

When the voltage values fall below the set start value of low-set stage $U_{<}$, the undervoltage unit will start to deliver a start signal after a ~ 80 ms' start time. When the set operate time at definite-time characteristic or the calculated operate time at IDMT characteristic elapses, the undervoltage unit will deliver a trip signal.


The high-set undervoltage stage, $U_{<<}$, can be set to start and trip either based on conventional undervoltage measurement or on the calculated positive-phase-sequence voltage, U_{1s} . Selecting either of these two will automatically deselect the other.

When the conventional protection mode has been selected and the voltage values fall below the set start value of the high-set stage, the undervoltage unit will start to deliver a start signal after a ~ 50 ms' start time.

When the positive-phase-sequence protection mode has been selected and the calculated positive-phase-sequence voltage value, U_{1s} , falls below the set start value of the high-set stage, the undervoltage unit will start to deliver a start signal after a ~ 50 ms' start time. When the set operate time at definite-time characteristic or the calculated operate time at IDMT characteristic elapses, the undervoltage unit will deliver a trip signal.

The start and the tripping of an undervoltage stage can be set to be internally blocked when the measured value falls below $0.2 \times U_n$ with a switch of switchgroup SGF2. In addition, the tripping of stage $U_{<}$ can be set to be blocked by the start of stage $U_{<<}$. The tripping of an undervoltage stage can also be blocked by applying an external binary input signal to the relay.

The high-set stage can be set out of operation. This state will be indicated by dashes on the LCD and by "999" when the set start value is read via serial communication.



A051872

Fig. 5.1.4.3.-1 Start and tripping of the high-set and the low-set undervoltage stage when internally blocked due to the voltage falling below $0.2 \times U_n$

5.1.4.4.

Positive-phase-sequence protection

The high-set undervoltage stage can be set to be based on the calculated positive-phase-sequence voltage in addition to on phase-to-phase voltage measurement. The relay will then calculate the voltage based on the two phase-to-phase voltages, U_{12} and U_{23} .

The positive-phase-sequence protection function can be applied to disconnecting a smaller power plant from the outside network, as when there is a fault in the network which may prove critical for the power plant, e.g. a short circuit either at the transmission or distribution network level.

A situation of this kind may be critical for different reasons. The power plant may be left to feed an isolated network due to a trip caused by a fault. In this case, there is a risk that the isolated network, in an asynchronous state compared to the rest of the network, will be reconnected to the network, e.g. as a result of an autoreclosure. In addition, the power plant may also fall into an asynchronous state in a fault situation. These critical situations may be prevented by disconnecting the power plant from the network fast enough by tripping the connecting circuit breaker.

The benefit of this function is that the voltage value measured during or after a network fault is a good measure of how critical the fault is for a smaller power plant. When the positive-phase-sequence voltage falls below the critical limit, the power plant will have to be disconnected from the network.

The REU 523 measuring the positive-phase-sequence voltage complements other methods used to disconnect smaller power plants. The application of these methods is based on frequency and voltage measurement.

The positive-phase-sequence protection function requires that the relay is in three-phase and not in single-phase use.

5.1.4.5.

Time/voltage characteristics

Each of the over and undervoltage stages can be given either a definite-time or an inverse definite minimum time (IDMT) characteristic. The settings of switches SGF4/1 and SGF4/2 determine the operation mode of stage U>, those of switches SGF4/3 and SGF4/4 that of stage U>>, those of switch SGF4/5 that of stage U< and those of switch SGF4/6 that of stage U<<. Refer to section Settings for further information.

At IDMT characteristic, the operate time of the stage is dependent on the voltage value: the greater the deviation from the setting value, the shorter the operate time. Three time/voltage curve groups are available: A, B and C.

The recording of the operate time does not start until the deviation between the measured voltage and the setting value exceeds six percent. The operate time accuracy stated in the technical data applies when the deviation is ten percent or higher.

Characteristics of the overvoltage stages

The IDMT characteristic curve groups A and B are designed for overvoltage stages U> and U>>. Stages U> and U>> can be configured to use different characteristics. The relationship between time and voltage at IDMT characteristic can be expressed as follows:

$$t[s] = \frac{k \times a}{\left(b \times \frac{U - U_{>}}{U_{>}} - 0.5\right)^p} + c$$

where

t = operate time

k = time multiplier k> or k>>

U = measured voltage

U> = set start value for U> or U>>

a = constant 480

b = constant 32

c = constant 0.035

p = constant (see table 5.1.4.5-1)

The A- and B-type characteristics are illustrated in Fig. 5.1.4.5.-1 and Fig. 5.1.4.5.-2.

Characteristic of the undervoltage stages

The IDMT characteristic curve group C is designed for undervoltage stages U< and U<<. Stages U< and U<< can be configured to use different characteristics. The relationship between time and voltage at IDMT characteristic can be expressed as follows:

$$t[s] = \frac{k \times a}{\left(b \times \frac{U_{<} - U}{U_{<}} - 0.5\right)^p}$$

where

t = operate time

k = time multiplier k< or k<<

U = measured voltage

U< = set start value for U< or U<<

a = constant 480


b = constant 32

p = constant (see table 5.1.4.5-1)

The C-type characteristic is illustrated in Fig. 5.1.4.5.-3.


Table 5.1.4.5-1 Values of constant p

Time/voltage characteristic	A	B	C
p	2	3	2




A051873

Fig. 5.1.4.5.-1 Characteristic of type A



A051874

Fig. 5.1.4.5.-2 Characteristic of type B



A051875

Fig. 5.1.4.5.-3 Characteristic of type C

5.1.4.6.**Settings**

There are two alternative setting groups available, setting groups 1 and 2. Either of these setting groups can be used as the actual settings, one at a time. Both groups have their related registers. By switching between the setting groups a whole group of settings can be changed at the same time. This can be done in any of the following ways:

Group configuration:

- via the HMI
- entering parameter V150 via serial communication

Group selection:

- switching between Group1 and Group2 is accomplished by means of the external binary input

The setting values can be altered via the HMI or with a personal computer provided with the Relay Setting Tool. Before the relay is connected to a system it must be assured that the relay has been given the correct settings. If there is any doubt, the setting values should be read with the relay trip circuits disconnected or tested with voltage injection; refer to section Check lists for additional information.

Table 5.1.4.6-1 Setting values

Setting	Description	Setting range	Default setting
$U_{>}/U_n$	Set start value of stage $U_{>}$ as a multiple of the rated voltage of the energizing input • definite and inverse time	$0.60...1.40 \times U_n$	$1.20 \times U_n$
$t_{>}$	Operate time of stage $U_{>}$ in seconds at definite-time characteristic	0.06...600 s	0.06 s
$k_{>}$	Time multiplier $k_{>}$ of stage $U_{>}$ at IDMT characteristic	0.05...2.00	0.05
$D/P_{>}$	Drop-off/pick-up ratio for $U_{>}$	0.95...0.99	0.97
$U_{>>}/U_n$	Set start value of stage $U_{>>}$ as a multiple of the rated voltage of the energizing input • definite and inverse time	$0.80...1.60 \times U_n$ ¹⁾	$1.20 \times U_n$
$t_{>>}$	Operate time of stage $U_{>>}$ in seconds	0.05...600 s	0.05 s
$k_{>>}$	Time multiplier $k_{>>}$ of stage $U_{>>}$ at IDMT characteristic	0.05...2.00	0.05
$D/P_{>>}$	Drop-off/pick-up ratio for $U_{>>}$	0.95...0.99	0.97
$U_{<}/U_n$	Set start value of stage $U_{<}$ as a multiple of the rated voltage of the energizing input • definite and inverse time	$0.30...1.20 \times U_n$	$0.30 \times U_n$
$t_{<}$	Operate time of stage $U_{<}$ in seconds at definite-time characteristic	0.10...600 s	0.10 s
$k_{<}$	Time multiplier $k_{<}$ of stage $U_{<}$ at IDMT characteristic	0.10...2.00	0.10
$D/P_{<}$	Drop-off/pick-up ratio of $U_{<}$	1.01...1.05	1.03
$U_{<<}/U_n$	Set start value of stage $U_{<<}$ as a multiple of the rated voltage of the energizing input • definite and inverse time	$0.30...1.20 \times U_n$ ¹⁾	$0.30 \times U_n$
$t_{<<}$	Operate time of stage $U_{<<}$ in seconds at definite-time characteristic.	0.10...600 s	0.10 s
$k_{<<}$	Time multiplier $k_{<<}$ of stage $U_{<<}$ at IDMT characteristic.	0.10...2.00	0.10
$D/P_{<<}$	Drop-off/pick-up ratio of $U_{<<}$	1.01...1.05	1.03
CBFP	Circuit-breaker failure protection	0.10...1.00 s	0.10 s

¹⁾ The stage can be set out of operation in SGF. This state will be indicated by dashes on the LCD and by "999" when parameters are read via the SPA bus.

Switchgroups and parameter masks

The settings can be altered and the operation characteristics of the relay in various applications selected in the SG_ selector switchgroups. The switchgroups are software based and thus not physical switches to be found in the hardware of the relay. The switches can be set one by one.

A checksum is used for verifying that the switches have been properly set. The figure below shows an example of manual checksum calculation.

Switch No	Position		Weighting factor		Value
1	1	x	1	=	1
2	0	x	2	=	0
3	1	x	4	=	4
4	0	x	8	=	0
5	1	x	16	=	16
6	0	x	32	=	0
7	1	x	64	=	64
8	0	x	128	=	0
Checksum			SG_{Σ}	=	85

Fig. 5.1.4.6.-1 An example of calculating the checksum of a SG_ selector switchgroup

When the checksum, calculated according to the example above, equals the checksum of the relay, the switches in the switchgroup have been properly set.

The factory default settings of the switches and the corresponding checksums are presented in the tables below.

SGF1...SGF4

Switchgroups SGF1...SGF4 are used for configuring the desired function as follows:

Table 5.1.4.6-2 SGF1

Switch	Function	Default setting
SGF1/1	Selection of the latching feature for power output PO1	0
SGF1/2	Selection of the latching feature for power output PO2 <ul style="list-style-type: none"> • When the switch is in position 0 and the measuring signal which caused the trip falls below the set start value, the output contact will return to its initial state. • When the switch is in position 1, the output contact will remain active although the measuring signal which caused the trip falls below the set start value. A latched output contact can be unlatched either via the HMI, the external binary input or the serial bus.	0
SGF1/3	Minimum pulse length for signal outputs SO1 and SO2 <ul style="list-style-type: none"> • 0=80 ms • 1=40 ms 	0
SGF1/4	Minimum pulse length for power outputs PO1 and PO2 <ul style="list-style-type: none"> • 0=80 ms • 1=40 ms Note! The latching function of PO1 and PO2 will overrun this function.	0
SGF1/5	CBFP <ul style="list-style-type: none"> • When the switch is in position 0, the CBFP is not in use. • When the switch is in position 1, the signal to output PO1 will start a timer which will generate a delayed signal to output PO2, provided that the fault is not cleared before the CBFP operate time has elapsed. 	0
SGF1/6	Not in use	0
SGF1/7	Not in use	0
SGF1/8	Not in use	0
Σ SGF1		0

Table 5.1.4.6-3 SGF2

Switch	Function	Default setting
SGF2/1	Single or three-phase use <ul style="list-style-type: none"> • 0 = three-phase use • 1 = single-phase use In single-phase use, the measured voltage has to be connected to inputs X1.1/1 and X1.1/3 for proper functioning and the set start value of stage U<< set $0.1 \times U_n$ below the set start value of stage U<.	0
SGF2/2	Selection of conventional undervoltage measurement or positive-phase-sequence protection for stage U<< <ul style="list-style-type: none"> • 0 = conventional undervoltage measurement in use • 1 = positive-phase-sequence U_{1S} in use 	0

Table 5.1.4.6-3 SGF2 (Continued)

Switch	Function	Default setting
SGF2/3	Tripping of stage U<< when conventional undervoltage measurement is in use <ul style="list-style-type: none"> • 0 = normal use for detecting loss of voltage when all voltages fall below the set value • 1 = more sensitive tripping: the stage starts the moment one of the phases falls below the set start value. To avoid unnecessary start situations, the start voltage of stage U<< is to be set to $0.6 \times U_n$ or below. 	0
SGF2/4	Internal blocking of stage U< when the measured voltage falls below $0.2 \times U_n$ <ul style="list-style-type: none"> • 0 = internal blocking of U< • 1 = no internal blocking of U< 	0
SGF2/5	Internal blocking of stage U<< when the measured voltage falls below $0.2 \times U_n$ <ul style="list-style-type: none"> • 0 = internal blocking of U<< • 1 = no internal blocking of U<< 	0
SGF2/6	Inhibition of stage U>> <ul style="list-style-type: none"> • 0 = stage U>> is not inhibited • 1 = stage U>> is inhibited 	0
SGF2/7	Inhibition of stage U<< <ul style="list-style-type: none"> • 0 = stage U<< is not inhibited • 1 = stage U<< is inhibited 	0
SGF2/8	Blocking of the tripping of stage U< by the start of stage U<< <ul style="list-style-type: none"> • 0 = tripping of stage U< is not blocked • 1 = tripping of stage U< is blocked 	0
Σ SGF2		0

Table 5.1.4.6-4 SGF3

Switch	Function	Default setting
SGF3/1	The operation mode of the start indication of stage U> <ul style="list-style-type: none"> • 0 = the start indication will automatically be cleared once the fault has disappeared • 1 = latching. The start indication will remain active although the fault has disappeared. 	0
SGF3/2	The operation mode of the trip indication of stage U> <ul style="list-style-type: none"> • 0 = the trip indication will automatically be cleared once the fault has disappeared • 1 = latching. The trip indication will remain active although the fault has disappeared. 	1
SGF3/3	The operation mode of the start indication of stage U>> <ul style="list-style-type: none"> • 0 = the start indication will automatically be cleared once the fault has disappeared • 1 = latching. The start indication will remain active although the fault has disappeared. 	0
SGF3/4	The operation mode of the trip indication of stage U>> <ul style="list-style-type: none"> • 0 = the trip indication will automatically be cleared once the fault has disappeared • 1 = latching. The trip indication will remain active although the fault has disappeared. 	1

Table 5.1.4.6-4 SGF3 (Continued)

Switch	Function	Default setting
SGF3/5	The operation mode of the start indication of stage U< • 0 = the start indication will automatically be cleared once the fault has disappeared • 1 = the start indication will remain active although the fault has disappeared	0
SGF3/6	The operation mode of the trip indication of stage U< • 0 = the trip indication will automatically be cleared once the fault has disappeared • 1 = the trip indication will remain active although the fault has disappeared	1
SGF3/7	The operation mode of the start indication of stage U<< • 0 = the start indication will automatically be cleared once the fault has disappeared • 1 = the start indication will remain active although the fault has disappeared	0
SGF3/8	The operation mode of the trip indication of stage U<< • 0 = the trip indication will automatically be cleared once the fault has disappeared • 1 = the trip indication will remain active although the fault has disappeared	1
Σ SGF3		170

Table 5.1.4.6-5 SGF4: Time characteristics

SGF4/1	SGF4/2	SGF4/3	SGF4/4	SGF4/5	SGF4/6	SGF4/7	SGF4/8	Operation
0	0	0	0	0	0	0	0	Definite time ¹⁾
1	0	-	-	-	-	-	-	U> A Curve
0	1	-	-	-	-	-	-	U> B Curve
-	-	1	0	-	-	-	-	U>> A Curve
-	-	0	1	-	-	-	-	U>> B Curve
-	-	-	-	1	-	-	-	U< C Curve
-	-	-	-	-	1	-	-	U<< C Curve

¹⁾ Default setting



Only one type of characteristic can be selected at a time. If more than one switch is selected, the characteristic with the lowest weighting factor of the selected switches will be activated. This only applies to the overvoltage stages..

SGB1


Table 5.1.4.6-6 SGB1 Resetting/blocking with BI

Switch	Function	Default setting
SGB1/1	<ul style="list-style-type: none"> • 0 = indications are not cleared by the binary input signal • 1 = indications are cleared by the binary input signal 	0
SGB1/2	<ul style="list-style-type: none"> • 0 = indications are not cleared and latched output contacts are not unlatched by the binary input signal • 1 = indications are cleared and latched output contacts are unlatched by the binary input signal 	0
SGB1/3	<ul style="list-style-type: none"> • 0 = indications and memorized values are not cleared and latched output contacts are not unlatched by the binary input signal • 1 = indications and memorized values are cleared and latched output contacts are unlatched by the binary input signal 	0
SGB1/4	Switching between setting groups 1 and 2 using the external binary input <ul style="list-style-type: none"> • 0 = the setting group cannot be changed using the external binary input • 1 = the currently used setting group is determined by the binary input. When the binary input is energized, setting group 2 will be activated. Note! When SGB1/4 is set to 1, it is important that the switch has the same setting in both setting groups.	0
SGB1/5	Blocking of stage U> by the binary input signal	0
SGB1/6	Blocking of stage U>> by the binary input signal	0
SGB1/7	Blocking of stage U< by the binary input signal	0
SGB1/8	Blocking of stage U<< by the binary input signal <ul style="list-style-type: none"> • When SGB1/5...8=0, tripping of the stage will not be blocked by the external binary input signal. • When SGB1/5...8=1, tripping of the stage will be blocked by the external binary input signal. 	0
Σ SGB1		0

SGR1...SGR8

The start and trip signals from the protection stages are connected to the output contacts with the switches of switchgroups SGR1...SGR8.

The matrix below can be of help when making the desired selections. The start and trip signals from the different protection stages are combined with the output contacts by encircling the desired intersection point. Each intersection point is marked with a switch number, and the corresponding weighting factor of the switch is shown on the bottom line of the matrix. The switchgroup checksum is obtained by horizontally adding the weighting factors of all the selected switches of the switchgroup.



A051876

Fig. 5.1.4.6.-2 Output signal matrix

Table 5.1.4.6-7 SGR1...SGR8

Switch	Function	Default setting
SGR1/1...4	U> signal to output contacts PO1, PO2, SO1 and SO2	12
SGR2/1...4	t> signal to output contacts PO1, PO2, SO1 and SO2	3
SGR3/1...4	U>> signal to output contacts PO1, PO2, SO1 and SO2	12
SGR4/1...4	t>> signal to output contacts PO1, PO2, SO1 and SO2	3
SGR5/1...4	U< signal to output contacts PO1, PO2, SO1 and SO2	12
SGR6/1...4	t< signal to output contacts PO1, PO2, SO1 and SO2	3
SGR7/1...4	U<< signal to output contacts PO1, PO2, SO1 and SO2	12
SGR8/1...4	t<< signal to output contacts PO1, PO2, SO1 and SO2	3

New trip indication timer

The new trip indication timer can be configured to allow a second trip indication on the LCD. When several protection stages trip, the first trip indication will be displayed until the time, as specified by the “NEW TRIP IND.” setting value, has expired. After this, a new trip indication can displace the old one. The basic protection functions are not affected by the “NEW TRIP IND.” setting.

Table 5.1.4.6-8 New trip indication timer

Setting	Description	Setting range	Default setting
New trip indication	New trip indication timer in minutes No new trip indication allowed until the previous one has been manually cleared	0...998 999	60

Non-volatile memory settings

The table below presents data which can be configured to be stored in the non-volatile memory. All of the functions mentioned below can be selected separately with switches 1...5 in "MEMORY SETTINGS".

Table 5.1.4.6-9 Memory settings

Switch	Function	Default setting
1	<ul style="list-style-type: none"> • 0 = alarm indication messages and LEDs will be cleared • 1 = alarm indication messages and LEDs will be retained 	1
2	<ul style="list-style-type: none"> • 1 = information on the "NUMBER OF STARTS" of the protection stages will be retained 	1
3	<ul style="list-style-type: none"> • 1 = disturbance recorder data will be retained 	1
4	<ul style="list-style-type: none"> • 1 = event codes will be retained 	1
5	<ul style="list-style-type: none"> • 1 = recorded data will be retained 	1
6	Not in use	0
7	Not in use	0
8	Not in use	0
checksum		31

5.1.4.7.

Technical data on protection functions

Table 5.1.4.7-1 Stages U> and U>>

Feature	Stage U>	Stage U>>
Set start value <ul style="list-style-type: none"> • at definite-time and IDMT characteristic 	$0.60 \dots 1.40 \times U_n$	$0.80 \dots 1.60 \times U_n^{1))}$
Start time, typical	60 ms	50 ms
Time/voltage characteristics <ul style="list-style-type: none"> • definite time operate times $t_{>}$ and $t_{>>}$ • IDMT time multipliers $k_{>}$ and $k_{>>}$ 	0.06...600 s A-curve B-curve 0.05...2.00	0.05...600 s A-curve B-curve 0.05...2.00
Resetting time, typical	70 ms	70 ms
Drop-off/pick-up ratio	0.95...0.99	0.95...0.99
Operate time accuracy at definite-time characteristic	±2% of the set start value or ±25 ms	±2% of the set start value or ±25 ms
Operate time accuracy at IDMT characteristic	±25 ms or the accuracy appearing when the measured voltage varies ±3%	±25 ms or the accuracy appearing when the measured voltage varies ±3%
Operation accuracy <ul style="list-style-type: none"> • definite-time and IDMT characteristic 	±1.5% of the set start value	±1.5% of the set start value

Table 5.1.4.7-2 Stages U< and U<<

Feature	Stage U<	Stage U<<
Set start value • at definite-time and IDMT characteristic	0.30...1.20 x U _n	0.30...1.20 x U _n ¹⁾⁾
Start time, typical	80 ms	50 ms
Time/voltage characteristics • definite time operate times t< and t<< • IDMT time multipliers k< and k<<	0.10...600 s C-curve 0.10...2.00	0.10...600 s C-curve 0.10...2.00
Resetting time, typical	70 ms	70 ms
Drop-off/pick-up ratio	1.01...1.05	1.01...1.05
Operate time accuracy at definite-time characteristic	±2% of the set start value or ±25 ms	±2% of the set start value or ±25 ms
Operate time accuracy at IDMT characteristic	±25 ms or the accuracy appearing when the measured voltage varies ±3%	±25 ms or the accuracy appearing when the measured voltage varies ±3%
Operation accuracy • definite-time and IDMT characteristic • positive-phase-sequence with definite-time and IDMT characteristic	±1.5% of the set start value	±1.5% of the set start value ±5% of the set start value

¹⁾ The stage can be set out of operation in SGF. This state will be indicated by dashes on the LCD and by "999" when parameters are read via the SPA bus.

5.1.5.

Indicator LEDs and alarm indication messages

The operation of the REU 523 can be monitored by means of three indicators on the front panel of the relay: a green READY indicator LED, a yellow START indicator LED and a red TRIP indicator LED (refer to the Operator’s Manual for a more thorough presentation).

In addition, in case of an alarm from a protection stage, a text message will appear on the LCD.

The messages on the LCD have a certain priority order. If different types of indications are activated simultaneously, the message with the highest priority will appear on the LCD.

The priority order of the messages:

1. CBFP
2. TRIP
3. START

5.1.6. Monitoring of demand values

The REU 523 provides four different kinds of demand values. The first value shows the maximum voltage whereas the second value shows the minimum voltage of the three main voltages. The third value shows the average voltage of the three main voltages during one minute whereas the fourth value shows the average voltage during ten minutes.

The demand values can be set to zero by performing a master reset or through communication using a V parameter.

5.1.7. Commissioning test

The function test is used for testing the configuration as well as the connections to and from the relay. By selecting this test the eight internal signals from the protection stages and the IRF function can be activated and tested one by one. Provided that the internal signals from the protection stages have been set to be routed to the output contacts (PO1, PO2, SO1 and SO2) with the switches of SGR1...8, the output contacts will be activated and the corresponding event codes generated when the test is run. The test will not generate protection function event codes. Additionally, if the CBFP function is in use and PO1 is activated, PO2 will be activated, too.

The state of the binary input can be monitored by selecting the binary input test, and the LEDs can be turned on by selecting the LED test. Refer to the Operator's Manual for more detailed instructions on how to perform the tests.

5.1.8. Disturbance recorder**5.1.8.1. Function**

The REU 523 features an integrated disturbance recorder for recording monitored quantities. The recorder continuously captures the curve forms of the voltages as well as the status of both the internal signals and the external binary input signal and stores these in the memory.

Triggering of the recorder will generate an event code. After the recorder has been triggered, it will continue to record data for a pre-defined post-triggering time. An asterisk will be shown on the LCD on completion of the recording. The status of the recording can also be viewed using a SPA parameter.

As soon as the recorder has been triggered and the recording has finished, the recording can be uploaded and analyzed by means of a PC provided with a special program.

5.1.8.2. Disturbance recorder data

One recording contains data from the three analogue channels and the eight digital channels for a preselected time. The analogue channels, whose data is stored either as RMS curves or momentary measured values, are the voltages measured by the relay. The digital channels, referred to as digital signals, are the start and trip signals from the protection stages and the external binary input signal linked to the relay.

The recording length varies according to the selected sampling frequency. The RMS curve is recorded by selecting the sampling frequency to be the same as the nominal frequency of the relay. The sampling frequency is selected with parameter M15; see the table below for details.

Table 5.1.8.2-1 Sampling frequency

Nominal frequency Hz	Sampling frequency Hz	Cycles
50	800	40
	400	80
	50 ¹⁾	640
60	960	40
	480	80
	60 ¹⁾	640

¹⁾ RMS curve.

Recording length:

$$[s] = \frac{\text{Cycles}}{\text{Nominal frequency}[Hz]}$$

Changing the setting values of parameter M15 is allowed only when the recorder has not been triggered.

The post-triggering recording length defines the time during which the recorder continues to store data after it has been triggered. The length can be changed with parameter V240. If the post-triggering recording length has been defined to be the same as the total recording length, no data stored prior to the triggering will be retained in the memory. By the time the post-triggering recording finishes, a complete recording will have been created.

Triggering of the recorder immediately after it has been cleared or the auxiliary voltage connected may result in a shortened total recording length. Disconnection of the auxiliary voltage after the recorder has been triggered but before the recording has finished, on the other hand, may result in a shortened post-triggering recording length. This, however, will not affect the total recording length.

At a power reset, triggered recorder data will be retained in the memory provided that it has been defined non-volatile.

5.1.8.3.

Control and indication of disturbance recorder status

It is possible to control and monitor the recording status of the disturbance recorder by writing to and reading parameters M1, M2 and V246. Reading parameter V246 will return either the value 0 or 1, indicating whether the recorder has not been triggered or triggered and ready to be uploaded. Event code E31 will be generated the moment the disturbance recorder has been triggered. If the recorder is ready to be uploaded, this will also be indicated by an asterisk shown in the lower right-hand corner of the LCD when it is in the idle mode.

Writing the value 1 to parameter M2 will clear the recorder memory, restart the storing of new data and enable the triggering of the recorder. Recorder data can be cleared by performing a master reset. Writing the value 2 to parameter V246 will restart the unloading process by setting the time stamp and the first data ready to be read.

5.1.8.4. Triggering

The user can select the start or trip signal from any protection stage, except for the trip signal from high-set stage U>>, and/or the external binary input signal to trigger the disturbance recorder, either on the rising or falling edge of the signal(s). Triggering on the rising edge means that the post-triggering recording sequence will start when the signal is activated. Correspondingly, triggering on the falling edge means that the post-triggering recording sequence will start when the active signal is reset. The trigger signal(s) and the edge are selected with parameters V241...V244; see tables 5.1.10.4-5 and 5.1.10.4-6. The recorder can also be triggered manually using parameter M1.

Triggering of the disturbance recorder is only possible if the recorder has not already been triggered.

5.1.8.5. Settings and unloading

The setting parameters for the disturbance recorder are V parameters V240...V244 and V246, and M parameters M15, M18, M20 and M80...M82.

Unloading the recorder requires that M80 has been set. Unloading is done using a PC application. The uploaded recorder data is stored in separate files defined by the comtrade[®] format.

5.1.8.6. Event code of the disturbance recorder

The disturbance recorder generates an event code (E31) on triggering of the recorder by default. The event mask is defined using serial parameter V158.

5.1.9. Recorded data of the last events

The REU 523 records up to five events. This enables the user to analyze the last five fault situations in the electrical power network. Each event includes the maximum and the minimum value of the measured main voltages, the voltage measured at the time of the trip, the minimum positive-phase-sequence value, start durations, and the time stamp. Additionally, information on the number of starts is provided.

Recorded data and the number of starts are non-volatile by default. A master reset will erase the contents of the recorded events and the number of starts.

The REU 523 will collect different data depending on whether an over or an undervoltage stage has started. The collected data and the time stamp will be stored in the first event register and the four previously stored events will move one step forward. When a sixth event is stored, the oldest event will be cleared.

When an overvoltage stage starts, the REU 523 will start to collect the maximum voltage value and measure the start duration, expressed as a percentage of the set operate time. If the stage is reset before the operate time has elapsed, the maximum voltage value captured during the start and the start duration will be stored.

When an overvoltage stage trips, both the measured voltage at the time of the trip and the maximum voltage captured during the start will be stored.

The above applies to the undervoltage stages, too. Stored values are the minimum voltage value, the measured voltage at the time of the trip, the minimum positive-phase-sequence value and start durations.

Table 5.1.9-1 Recorded data

REGISTER	Recorded data
EVENT1	<ul style="list-style-type: none"> • The maximum voltage value measured during the start sequence of an overvoltage stage as a multiple of the rated voltage, U_n. • The minimum voltage value measured during the start sequence of an undervoltage stage as a multiple of the rated voltage, U_n. • The voltage measured at the time of the trip as a multiple of the rated voltage, U_n. • The minimum value of the positive-phase-sequence voltage during the start sequence of an undervoltage stage as a multiple of the rated voltage, U_n. • Duration of the last starts of stages $t_>$, $t_{>>}$, $t_<$ and $t_{<<}$, expressed as a percentage of the set operate time, or of the calculated operate time at IDMT characteristic. The timing will start when a stage starts. A value other than zero means that the corresponding stage has started whereas a value which is 100% of the set or calculated operate time indicates that the stage has tripped. If the operate time for a stage has elapsed but the stage is blocked, the value will be 99% of the set or calculated operate time. • Time stamp for the event. The time when the last stage drops off will be stored. The time stamp is displayed in two registers, one including the date expressed as yy-mm-dd, and the other including the time expressed as HH.MM; SS.sss.
EVENT 2	Same as EVENT 1.
EVENT 3	Same as EVENT 1.
EVENT 4	Same as EVENT 1.
EVENT 5	Same as EVENT 1.
Number of starts	<ul style="list-style-type: none"> • The number of times each protection stage, i.e. $U_>$, $U_{>>}$, $U_<$ and $U_{<<}$, has started, counting up to 999.

5.1.10.

External serial communication


5.1.10.1.

Communication ports

The REU 523 is provided with two serial communication ports: an optical PC-connection on the front panel and an RS-485 connection on the rear panel.

The D9S-type RS-485 connector is used to connect the relay to the distribution automation system. This connection enables the use of either the SPA bus communication protocol or the IEC 60870-5-103 communication protocol. The fibre-optic interface module RER 103 is used to connect the relay to the fibre-optic communication bus.

Although the RER 103 supports LON bus communication, the REU 523 does not support the LON protocol. LON communication requires a separate LSG device.



A051299

Fig. 5.1.10.1.-1 Front connector (1) for local communication

The relay is connected to a PC used for setting via the optical PC-connector on the front panel. The front interface uses the SPA bus protocol.

The optical PC-connector galvanically isolates the PC from the relay. The connection consists of a transmitter stage and a receiver stage. The front connector is standardized for ABB relay products and requires a specific opto-cable (ABB art. no 1MKC950001-2). The cable is connected to the serial RS-232C port of the PC. The optical stage of the cable is powered by RS-232C control signals.

The following serial communication parameters are to be used for RS-232C:

- Number of data bits 7
- Number of stop bits 1
- Parity even
- Baud rate 9.6 kbps as default

Relay data such as events, setting values and all input data and memorized values can be read via the optical PC-interface.

When setting values are altered via the optical PC-interface, the relay will check that the entered parameter values are within the permitted setting range. If an entered value is too high or too low, the setting value will remain unchanged.

The REU 523 has an internal counter which can be accessed via “COMMUNICATION” under “CONFIGURATION” in the HMI menu. The counter value is set to 0 when the relay receives a valid message.

5.1.10.2.

IEC 60870-5-103 remote communication protocol

The REU 523 supports the IEC 60870-5-103 remote communication protocol (henceforward referred to as the IEC_103) in the unbalanced transmission mode. The IEC_103 protocol is used to transfer measurand and status data from the slave to the master. However, the IEC_103 protocol cannot be used to transfer disturbance recorder data.

The IEC_103 protocol can be used only through the RS-485 connection on the rear panel. Connecting the REU 523 to the fibre-optic communication bus requires the use of the fibre-optic interface module RER 103.




Fig. 5.1.10.2.-1 REU 523 communication using the IEC_103 protocol

The REU 523 will use the SPA bus protocol as default when the rear connection is in use. The IEC_103 protocol can be selected through the HMI of the relay. The selection is memorized and will therefore always be activated when the rear connection is in use. The use of the IEC_103 protocol in the REU 523 requires a baud rate of 9.6 kbps. When the IEC_103 protocol has been selected, event masks are not in use. Therefore, all events in the configuration set are included in the event reporting.

The REU 523 is provided with two different selectable configuration sets, of which configuration set 1 is used by default. Configuration set 1 provides full compatibility according to the IEC_103 standard. Configuration set 2 provides all applicable information of the protection equipment. However, some information elements have been mapped to a private range. Configuration set 255 is reserved for future use.

The tables below indicate the information mapping of the corresponding configuration sets. The column GI indicates whether the status of the specified information object is transmitted within the general interrogation cycle. The relative time in messages with the type identification 2 is calculated as a time difference between the occurred event and the event specified in the column Relative time. The measurand multiplied by the normalize factor is proportional to the rated value. Therefore, the maximum value of each measurand is the normalize factor multiplied by the rated value.

Table 5.1.10.2-1 Information mapping of configuration set 1

Event reason	Event code	Function type	Information number	Standard description of the information number (IEC 60870-5-103)	GI	Relative time	Type identification
PO1 Activated/Reset	E17/ E18	160	27	auxiliary input 1	X	-	1
PO2 Activated/Reset	E19/ E20	160	28	auxiliary input 2	X	-	1
SO1 Activated/Reset	E21/ E22	160	29	auxiliary input 3	X	-	1
SO2 Activated/Reset	E23/ E24	160	30	auxiliary input 4	X	-	1

Table 5.1.10.2-2 Information mapping of configuration set 1

Measurand	Normalize factor	Rated value	Function type	Information number	Standard description of the information number (IEC 60870-5-103)	Type identification
Current I_{L2} (not measured)	-	-	160	145	measurand I	3.2
Voltage U_{12}	2.40	U_n				

Table 5.1.10.2-3 Information mapping of configuration set 2

Event reason	Event code	Function type	Information number	Standard description of the information number (IEC 80870-5-103)	GI	Relative time	Type identification
U> Start Activated/Reset	E1/ E2	165	84	-	X	E1	2
U> Trip Activated/Reset	E3/ E4	165	90	-	-	E1	2
U>> Start Activated/Reset	E5/ E6	165	94	-	X	E5	2
U>> Trip Activated/Reset	E7/ E8	165	91	-	-	E5	2
U< Start Activated/Reset	E9/ E10	166	84	-	X	E9	2
U< Trip Activated/Reset	E11/ E12	166	90	-	-	E9	2
U<< Start Activated/Reset	E13/ E14	166	94	-	X	E13	2

Table 5.1.10.2-3 Information mapping of configuration set 2 (Continued)

Event reason	Event code	Function type	Information number	Standard description of the information number (IEC 80870-5-103)	GI	Relative time	Type identification
U<< Trip Activated/Reset	E15/ E16	166	91	-	-	E13	2
PO1 Activated/Reset	E17/ E18	165	27	auxiliary input 1	X	-	1
PO2 Activated/Reset	E19/ E20	165	28	auxiliary input 2	X	-	1
SO1 Activated/Reset	E21/ E22	165	29	auxiliary input 3	X	-	1
SO2 Activated/Reset	E23/ E24	165	30	auxiliary input 4	X	-	1
Disturbance recorder triggered	E31	165	100	-	-	-	1
HMI Password Opened/Closed	E32/ E33	165	101	-	-	-	1

Table 5.1.10.2-4 Information mapping of configuration set 2

Measurand	Normalize factor	Rated value	Function type	Information number	Standard description of the information number (IEC 60870-5-103)	Type identification
Voltage U ₁₂	2.40	U _n	135	142	-	9
Voltage U ₂₃	2.40	U _n				
Voltage U ₃₁	2.40	U _n				
Positive-phase-sequence voltage	2.40	U _n				

5.1.10.3. Event codes

Special codes have been determined to represent certain events, such as start and tripping of protection stages and different states of output signals.

Events E1...E51 are stored in the event register of the relay. The maximum capacity of the register is 60 events. Under normal conditions the register is empty.

The contents of the register can be read using the L command, five events at a time. Using the L command erases the previously read events from the register, with the exception of events E50 and E51 which have to be reset using the C command. Should a fault occur, for example in data communication, these events can be re-read using the B command. If needed, the B command can also be repeated.

Events to be included in the event reporting are marked with multiplier 1. The event mask is formed by the sum of the weighting factors of all those events which are to be included in the event reporting.

Table 5.1.10.3-1 Event masks

Event mask	Code	Setting range	Default setting
V155	E1...E8	0...255	85
V156	E9...E16	0...255	85
V157	E17...E24	0...255	3
V158	E31...E33	0...7	1

Table 5.1.10.3-2 Event codes E1...E8

Code	Event	Weighting factor	Default value
E1	Start of stage U>	1	1
E2	Start of stage U> reset	2	0
E3	Trip of stage U>	4	1
E4	Trip of stage U> reset	8	0
E5	Start of stage U>>	16	1
E6	Start of stage U>> reset	32	0
E7	Trip of stage U>>	64	1
E8	Trip of stage U>> reset	128	0
Default value of event mask V155			85

Table 5.1.10.3-3 Event codes E9...E16

Code	Event	Weighting factor	Default value
E9	Start of stage U<	1	1
E10	Start of stage U< reset	2	0
E11	Trip of stage U<	4	1
E12	Trip of stage U< reset	8	0
E13	Start of stage U<<	16	1
E14	Start of stage U<< reset	32	0
E15	Trip of stage U<<	64	1
E16	Trip of stage U<< reset	128	0
Default value of event mask V156			85

Table 5.1.10.3-4 Event codes E17...E24

Code	Event	Weighting factor	Default value
E17	PO1 activated	1	1
E18	PO1 reset	2	1
E19	PO2 activated	4	0
E20	PO2 reset	8	0
E21	SO1 activated	16	0
E22	SO1 reset	32	0
E23	SO2 activated	64	0
E24	SO2 reset	128	0
Default value of event mask V157			3

Table 5.1.10.3-5 Event codes E31...33

Code	Event	Weighting factor	Default value
E31	Disturbance recorder triggered	1	1
E32	HMI password opened	2	0
E33	HMI password reclosed	4	0
Default value of event mask V158			1

Explanations of the default values:

0 = not included in the event reporting

1 = included in the event reporting

Table 5.1.10.3-6 Event codes E50 and E51

Code	Event
E50	Restart of relay
E51	Overflow of event register

Events E50 and E51 are always included in the event reporting.

5.1.10.4.

SPA bus communication protocol parameters

In some cases, altering parameter values via serial communication requires the use of the SPA password. The password is a number within the range 1...999, the default value being 1.

To enter the setting mode, enter the password into parameter V160. To quit the setting mode, enter the same password into parameter V161. The password protection is also reactivated in case of loss of auxiliary voltage.

The HMI password can be changed via parameter V162, but it is not possible to read the password via this parameter.

Abbreviations used in the following tables:

- R = readable data
- W = writeable data
- P = password protected writeable data
- I = input data
- S = setting value
- V = recorded data/parameter
- M = disturbance recorder parameter
- O = output data

Settings

Table 5.1.10.4-1 Settings

Variable	Actual settings (R)	Group 1 (R, W, P)	Group 2 (R, W, P)	Setting range
Set start value of stage U>	S1	S41	S81	0.60...1.40 x U _n
Operate time of stage U>	S2	S42	S82	0.06...600 s
Time multiplier k>	S3	S43	S83	0.05...2.00
Drop-off/pick-up ratio D/P> of stages U> and U>>	S4	S44	S84	0.95...0.99
Set start value of stage U>>	S5 ¹⁾	S45	S85	0.80...1.60 x U _n
Operate time of stage U>>	S6	S46	S86	0.05...600 s
Time multiplier k>>	S7	S47	S87	0.05...2.00
Set start value of stage U<	S8	S48	S88	0.30..1.20 x U _n
Operate time of stage U<	S9	S49	S89	0.10...600 s
Time multiplier k<	S10	S50	S90	0.10...2.00
Drop-off/pick-up ratio D/P< of stages U< and U<<	S11	S51	S91	1.01...1.05
Set start value of stage U<<	S12 ¹⁾	S52	S92	0.30..1.20 x U _n
Operate time of stage U<<	S13	S53	S93	0.10...600 s
Time multiplier k<<	S14	S54	S94	0.10...2.00
Checksum, SGF1	S15	S55	S95	0...31
Checksum, SGF2	S16	S56	S96	0...255
Checksum, SGF3	S17	S57	S97	0...255
Checksum, SGF4	S18	S58	S98	0...63
Checksum, SGB1	S19	S59	S99	0...255
Checksum, SGR1	S20	S60	S100	0...15
Checksum, SGR2	S21	S61	S101	0...15
Checksum, SGR3	S22	S62	S102	0...15
Checksum, SGR4	S23	S63	S103	0...15
Checksum, SGR5	S24	S64	S104	0...15
Checksum, SGR6	S25	S65	S105	0...15
Checksum, SGR7	S26	S66	S106	0...15
Checksum, SGR8	S27	S67	S107	0...15
Operate time of CBFP	-	S121	S121	0.10...1.00 s
Time setting for disabling new trip indications on the LCD	-	S122	S122	0...999 min

¹⁾ If the protection stage has been set out of operation, the number indicating the currently used value will be displaced by "999" when parameters are read via the SPA bus and by dashes on the LCD.

Recorded data

Parameter V1 shows the maximum and parameter V2 the minimum voltage value measured as a multiple of the rated voltage, U_n , since the last master reset. Parameter V3 shows the average voltage value measured during one minute. The value is updated once a minute. Parameter V4 shows the average voltage during a ten minutes' period. This value is updated ten minutes after the relay start-up, after which it is updated once a minute. Parameters V5...V8 show the number of starts of the protection stages, parameter V9 shows the trip indication code and parameter V10 the stage which has tripped.

Table 5.1.10.4-2 Recorded data: Parameters V1...V10

Recorded data	Parameter	R, W	Value
Maximum voltage measured	V1	R	$0...2 \times U_n$
Minimum voltage measured	V2	R	$0...2 \times U_n$
Average voltage during 1 minute	V3	R	$0...2 \times U_n$
Average voltage during 10 minutes	V4	R	$0...2 \times U_n$
Number of starts of stage U>	V5	R	0...999
Number of starts of stage U>>	V6	R	0...999
Number of starts of stage U<	V7	R	0...999
Number of starts of stage U<<	V8	R	0...999
Trip indication code	V9	R	0 = --- 1 = start of stage U> 2 = trip of stage t> 3 = start of stage U>> 4 = trip of stage t>> 5 = start of stage U< 6 = trip of stage t< 7 = start of stage U<< 8 = trip of stage t<< 9 = trip of the CBFP unit
Stage/voltage which caused the trip; the value may also be a combination of two or more of the individual values, e.g. 24 (=8 + 16)	V10	R	1= $U_{12}>$ 2= $U_{23}>$ 4= $U_{31}>$ 8= $U_{12}>>$ 16= $U_{23}>>$ 32= $U_{31}>>$ 64= $U_{12}<$ 128= $U_{23}<$ 256= $U_{31}<$ 512= $U_{12}<<$ 1024= $U_{23}<<$ 2048= $U_{31}<<$ 4096= U_{1S}

The last five recorded values can be read with parameters V11...V100. Event n denotes the last recorded value, n-1 the next one, and so forth.

Table 5.1.10.4-3 Recorded data

Recorded data	Event (R)					Value
	n	n-1	n-2	n-3	n-4	
Maximum voltage measured at the start of stage U> or U>>	V11	V31	V51	V71	V91	0...2 x U _n
Minimum voltage measured at the start of stage U< or U<<	V12	V32	V52	V72	V92	0...2 x U _n
Voltage measured at the moment of tripping	V13	V33	V53	V73	V93	0...2 x U _n
The minimum value of the positive-phase-sequence voltage at the start of stage U< or U<<	V14	V34	V54	V74	V94	0...2 x U _n
Start duration, stage U>	V15	V35	V55	V75	V95	0...100%
Start duration, stage U>>	V16	V36	V56	V76	V96	0...100%
Start duration, stage U<	V17	V37	V57	V77	V97	0...100%
Start duration, stage U<<	V18	V38	V58	V78	V98	0...100%
Time stamp of the registered value, date	V19	V39	V59	V79	V99	YY-MM-DD
Time stamp of the registered value, time	V20	V40	V60	V80	V100	HH.MM; SS.sss

Disturbance recorder**Table 5.1.10.4-4 Parameters for the disturbance recorder**

Description	Parameter	R, W	Value/Note
Manual triggering	M1 ²⁾	W	1
Clear recorder memory	M2	W	1
Sampling rate	M15 ³⁾	R, W	800/960 Hz 400/480 Hz 50/60 Hz
Station identification/unit number	M18	R, W	0...9999
Rated frequency	M19	R	50 or 60 Hz
Station name	M20	R, W	Max 16 characters
Digital channel texts	M40...47	R	
Analogue channel texts	M60...62	R	
Analogue channel(s): rated voltage and unit of primary voltage transformer(s)	M80 ¹⁾ M81, 82	R, W R	Factor 0.00...600, unit (V, kV), e.g. 20.0, kV
Post-triggering recording length	V240	R, W	0...100%
Internal trigger signals' checksum	V241	R, W	0...127, see table 5.1.10.4-5
Internal trigger signal's edge	V242	R, W	0...127, 0 = rising, 1 = falling
External trigger signal (BI)	V243	R, W	0/1, see table 5.1.10.4-6
External trigger signal's edge	V244	R, W	0/1, 0 = rising, 1 = falling
Triggering state, clearing and restart	V246	R, W	R: 0 = recorder not triggered 1 = recorder triggered and recording stored in the memory W: 0 = clear recorder memory 2 = download restart; sets the first information and time stamp for triggering ready to be read 4 = manual triggering

¹⁾ The disturbance recorder requires this parameter to be set. If this parameter has been given the default value 0, dashes will be shown on the LCD instead of the primary values and the recorded data will be redundant. This value is copied to parameters M81 and M82.

²⁾ M1 can be used for broadcast triggering by using the unit address "900".

³⁾ Parameters can be written when the recorder has not been triggered.

Table 5.1.10.4-5 Disturbance recorder internal triggering

Event	Weighting factor	Default value of triggering mask, V241	Default value of triggering edge, V242
Start of stage U>	1	0	0
Trip of stage U>	2	1	0
Start of stage U>>	4	0	0
Start of stage U<	8	0	0
Trip of stage U<	16	1	0
Start of stage U<<	32	0	0
Trip of stage U<<	64	1	0
Not in use	-	0	0
Checksum		82	0

Table 5.1.10.4-6 Disturbance recorder external triggering

Event	Weighting factor	Default value of triggering mask, V243	Default value of triggering edge, V244
External BI ^{*)}	1	1	0
Not in use	-	0	0
Not in use	-	0	0
Not in use	-	0	0
Not in use	-	0	0
Not in use	-	0	0
Not in use	-	0	0
Not in use	-	0	0
Checksum		1	0

^{*)} Note that the value of SGB1/3 has to be 0 (indications, output contacts and memorized values will not be reset by the binary input signal).

Control parameters

Table 5.1.10.4-7 Control parameters

Description	Parameter	R, W	Value
Unlatching output contacts	V101	W	1 = unlatch
Clearing registers and unlatching output contacts	V102	W	1 = clear and unlatch
Rated frequency	V133	R, W (P)	50=50 Hz 60=60 Hz
Nominal voltage	V134	R, W (P)	100, 110, 115, 120 (V)
Remote control of settings	V150	R, W	0 = setting group 1 1 = setting group 2
Non-volatile memory settings	V152	R, W	0...31
Event mask for U> and U>>	V155	R, W	0...255, see Event codes
Event mask for U< and U<<	V156	R, W	0...255, see Event codes
Event mask for output contacts' events	V157	R, W	0...255, see Event codes
Event mask for the disturbance recorder and the HMI password	V158	R, W	0...7, see Event codes
Entering the SPA password for settings	V160	W	1...999
Changing the SPA password or reinstating the password protection	V161	W (P)	1...999
Changing the HMI password	V162	W	1...999 999 = password disabled
Activating the self-supervision	V165	W	1 = the self-supervision output contact is activated and the READY indicator LED starts to blink 0 = normal operation
LED test for start and trip indicators	V166	W (P)	0 = start and trip LEDs off 1 = trip LED on, start LED off 2 = start LED on, trip LED off 3 = start and trip LEDs on

Table 5.1.10.4-7 Control parameters (Continued)

Description	Parameter	R, W	Value
Default settings	V167	W (P)	2 = restore factory settings
Internal fault code	V169	R	0...255
Unit address of the relay	V200	R, W	1...254
Data transfer rate, kbps	V201	R, W	4.8 or 9.6
Rear communication	V202	W	1 = rear connector activated
Relay serial number	V230	R	ERxxxxxx
CPU serial number	V231	R	MRxxxxxx
Article number	V232	R	1MRS091409-BAA
Test date	V233	R	YYYYMMDD
Software number	V234	R	1MRS118017
Software revision	V235	R	A...Z
Date reading and setting (RED 500 format)	V250	R, W	YY-MM-DD
Time reading and setting (RED 500 format)	V251	R, W	HH.MM; SS.sss
Reading of an event register	L	R	Time, channel number and event code
Re-reading of an event register	B	R	Time, channel number and event code
Type designation of the relay	F	R	REU 523
Reading of relay state data	C	R	0 = normal state 1 = the relay has been subject to an automatic reset 2 = overflow of an event register 3 = both events 1 and 2
Resetting of relay state data	C	W	0 = resetting all events 1 = reset only E50 2 = reset only E51 4 = reset all events including E51 except for E50
Time reading and setting	T	R, W	00.000...59.999 s
Date and time reading and setting	D	R, W	YY-MM-DD HH.MM;SS.sss

Input and output signals

The measured voltages and the status of the binary input signal can be read (R) with parameters I1...I4. When the value of parameter I4 is 1, the binary input will be energized. The value of the calculated positive-phase-sequence voltage can be read with parameter I5.

Table 5.1.10.4-8 Inputs

Description	Parameters (R)	Value
Voltage U_{12}	I1	0...2 x U_n
Voltage U_{23}	I2	0...2 x U_n
Voltage U_{31}	I3	0...2 x U_n
Binary input signal	I4	0 or 1
Positive-phase-sequence voltage	I5	0...2 x U_n

Each protection stage has its internal output signal. These signals can be read (R) with parameters O1...O8. The state of the output contacts can be read (R) or changed (W) with parameters O9...O12. When the value of any of parameters O1...O12 is changed from 0 to 1, it will be recorded in the corresponding parameter O21...O32.

Table 5.1.10.4-9 Output signals

Status of the protection stages	State of stage (R)	Recorded functions (R)	Value
Start of stage U>	O1	O21	0 or 1
Trip of stage U>	O2	O22	0 or 1
Start of stage U>>	O3	O23	0 or 1
Trip of stage U>>	O4	O24	0 or 1
Start of stage U<	O5	O25	0 or 1
Trip of stage U<	O6	O26	0 or 1
Start of stage U<<	O7	O27	0 or 1
Trip of stage U<<	O8	O28	0 or 1

Table 5.1.10.4-10 Outputs

Operation of output contacts	State of output (R, W, P)	Recorded functions (R)	Value
Output PO1	O9	O29	0 or 1
Output PO2	O10	O30	0 or 1
Output SO1	O11	O31	0 or 1
Output SO2	O12	O32	0 or 1
Enabling output contacts PO1, PO2, SO1 and SO2	O41	-	0 or 1



Parameters O9...O12 and O41 control the physical output contacts which can be connected to e.g. circuit breakers.

5.1.11.

Self-supervision (IRF) system

The REU 523 is provided with an extensive self-supervision system which continuously supervises the software and the electronics of the relay. It handles run-time fault situations and informs the user about an existing fault via a LED on the HMI and a text message on the LCD.

When a fault is detected, the relay will first try to eliminate it by restarting. Only after the fault has been found to be permanent, the READY indicator LED will start to blink and the self-supervision output contact will be activated. All other output contacts are blocked during an internal fault. Further, a fault indication message will appear on the LCD.

Fault indications have the highest priority on the HMI. None of the other HMI indications can override the IRF indication. As long as the READY indicator LED is blinking, the fault indication can not be cleared. In case an internal fault disappears, the READY indicator LED will stop blinking and the IRF relay will be returned to the normal service state, but the fault indication message will remain on the LCD.

The IRF code is the code of the last internal fault detected by the self-supervision system and describes the type of fault. When a fault appears, the code is to be recorded and given to an authorised repair shop when overhaul is ordered. For fault codes, refer to the Operator's Manual.

5.1.12.

Relay parameterization

Local parameterization

The parameters of the relay can be set either locally via the HMI or externally via serial communication with the Relay Setting Tool. When the parameters are set locally, the setting parameters can be chosen via the hierarchical menu structure. The desired language can be selected for the parameter descriptions. Refer to the Operator's Manual for further information.

External parameterization

The Relay Setting Tool is used for parameterizing the relay units. Adjusting the parameter values using the Relay Setting Tool is done off-line, after which the parameters can be downloaded to the relay via a communication port.

5.2.

Design description

5.2.1.

Input/output connections

The energizing voltages are connected to terminals X1.1/1-3, X1.1/4-6 and X1.1/7-9. The nominal voltage (100/110/115/120 V) of the matching transformers has to be selected with SPA parameter V134 or via the HMI. The REU 523 can also be used in single-phase applications by setting switch 1 in switchgroup SGF2.

The binary input X2.1/17-18 can be used to generate an external blocking signal, to unlatch the output contacts or for remote control of relay settings. The requested function is selected in SGB. The binary input can also be used as a trigger signal for the disturbance recorder; this function is selected with SPA parameter V243.


The auxiliary voltage of the relay is connected to terminals X2.1/1-2. At DC supply, the positive lead is connected to terminal X2.1/1. For details, refer to the description of the auxiliary voltage. The permitted auxiliary voltage range of the relay is marked on the front panel of the relay.

Output contacts PO1 and PO2 are heavy-duty trip contacts capable of controlling most circuit breakers. The trip signals from the different protection stages are routed to the output contacts with switches 1 and 2 of SGR1...SGR8. On delivery from the factory, the trip signals from all the protection stages are routed to both PO1 and PO2.

Output contacts SO1 and SO2 can be used for signalling on start and tripping of the relay. The signals to be routed to output contacts SO1 and SO2 are selected with switches 3 and 4 of SGR1...SGR8. On delivery from the factory, the start signals from all the protection stages are routed to both SO1 and SO2.

Output contact IRF functions as an output contact for the self-supervision system of the protection relay. The IRF relay is energized under normal operating conditions and contact gap X2.1/13-15 is closed. When a fault is detected by the self-supervision system or the auxiliary voltage is disconnected, the output contact will drop off and contact X2.1/13-14 will close.

The following picture presents a rear view of the REU 523, showing three connecting sockets: one for matching transformers, one for power supply and one for serial communication.



A051413

Fig. 5.2.1.-1 Rear view of the relay

Table 5.2.1-1 Inputs for voltages

Terminal	Function
X1.1-1	$U_{12}^{*)}$
X1.1-3	U_{12}
X1.1-4	$U_{23}^{*)}$
X1.1-6	U_{23}
X1.1-7	$U_{31}^{*)}$
X1.1-9	U_{31}

**) Note that the wiring has to be done identically for each of the matching transformers used.*

Table 5.2.1-2 Auxiliary supply voltage

Terminal	Function
X2.1-1	Input+
X2.1-2	Input-

Table 5.2.1-3 Output contacts

Terminal	Function
X2.1-3	PO1, closing contact
X2.1-4	
X2.1-5	PO2, closing contact
X2.1-6	
X2.1-7	SO1, common
X2.1-8	SO1, NC
X2.1-9	SO1, NO
X2.1-10	SO2, common
X2.1-11	SO2, NC
X2.1-12	SO2, NO

Table 5.2.1-4 IRF contact

Terminal	Function
X2.1-13	Internal relay fault, common
X2.1-14	Closed; IRF, or U_{aux} disconnected
X2.1-15	Closed; no IRF, and U_{aux} connected

Table 5.2.1-5 Binary input

Terminal	Function
X2.1-17	Input+
X2.1-18	Input-

5.2.2.**Serial communication connections**

The REU 523 is interfaced with a fibre-optic bus by means of the bus connection module RER 103 via the D9S-type connector X2 located on the rear panel of the device. The terminals of the fibre-optic cables are connected to the counter terminals Rx (Receiver) and Tx (Transmitter) of the bus connection module. The fibre-optic cables are linked from one protection relay to another and to the substation level communication unit, e.g. SRIO 1000M and the RER 125.

The optical PC-connection on the front panel of the relay is used to connect the relay to a fibre-optic SPA bus via opto-cable 1MKC950001-2.

Table 5.2.2-1 RS-485 connector X2 for the RER 103

Terminal	Function
X.2.2-1	Data A (data signal +)
X.2.2-2	Data B (data signal -)
X.2.2-3	RTS A (request to send +)
X.2.2-4	RTS B (request to send -)
X.2.2-5	COL A (2.8 V on relay)
X.2.2-6	COL B (2.2 V on relay)
X.2.2-7	GND
X.2.2-8	NC
X.2.2-9	+5 V DC, auxiliary voltage (max. 200 mA)

5.2.3.

Technical data

Table 5.2.3-1 Dimensions ¹⁾

Width, frame 111.4 mm, box 94 mm
Height, frame 265.9 mm (6U), box 249.8 mm
Depth 235 mm (245.1 mm with a protective rear cover, available as an option)
Enclosure size 1/4 (x 19")
Weight of the relay ~3.2 kg

¹⁾ For dimension drawings, refer to the Installation Manual (1MRS 750526-MUM).

Table 5.2.3-2 Power supply

U_{aux} rated	$U_r=110/120/220/240$ V AC $U_r=48/60/110/125/220$ V DC
U_{aux} variation	80...265 V AC 38...265 V DC
Relay power start-up time, typical	300 ms
Burden of auxiliary voltage supply under quiescent/ operating condition	~ 4 W/~10 W
Ripple in the DC auxiliary voltage	Max 12% of the DC value
Interruption time in the auxiliary DC voltage without resetting the relay	< 30 ms at 48 V DC < 100 ms at 110 V DC < 500 ms at 220 V DC

Table 5.2.3-3 Energizing inputs

Rated frequency	50/60 Hz \pm 5 Hz
Rated voltage, U_n	100/110/115/120 V
Maximum input voltage	
• continuously	$2 \times U_n$
• for 10 s	$3 \times U_n$
Power consumption at U_n	< 0.1 VA (typical 0.03 VA)
Thermal withstand capability	
• continuously	$2 \times U_n$
• for 10 s	$3 \times U_n$
Input impedance	> 4.7 M Ω

Table 5.2.3-4 Measuring range

Measured voltages on phases U_{12} , U_{23} and U_{31} as multiples of the rated voltages of the energizing inputs	$0...2 \times U_n$
Measuring accuracy ($f_n \pm 5$ Hz) at $0.20...2.00 \times U_n$	$\pm 1.5\%$

Table 5.2.3-5 Binary input

Operating range	18...265 V DC
Rated voltage	24/48/60/110/220 V DC
Current drain	~ 2...25 mA
Power consumption	< 0.8 W

Table 5.2.3-6 Signal outputs (SO1, SO2) and self-supervision (IRF) output

Rated voltage	250 V AC/DC
Continuous carry	5 A
Make and carry for 3.0 s	8 A
Make and carry for 0.5 s	10 A
Breaking capacity when the control circuit time-constant L/R < 40 ms, at 48/110/220 V DC	1 A/0.25 A/0.15 A
Minimum contact load	100 mA at 24 V AC/DC

Table 5.2.3-7 Power outputs (PO1, PO2)

Rated voltage	250 V AC/DC
Continuous carry	5 A
Make and carry for 3.0 s	15 A
Make and carry for 0.5 s	30 A
Breaking capacity when the control circuit time-constant L/R < 40 ms, at 48/110/220 V DC	5 A/3 A/1 A
Minimum contact load	100 mA at 24 V AC/DC

Table 5.2.3-8 Enclosure class

Front side	IP 54 (flush-mounted)
Rear side, connection terminals	IP20
<p>Note! A rear protective cover (accessory part) can be used to protect and shield the rear of the case.</p>	

Table 5.2.3-9 Environmental tests

Specified service temperature range	-10...+55 °C
Transport and storage temperature range	-40...+70 °C according to the IEC 60068-2-48
Dry heat test	According to the IEC 60068-2-2
Dry cold test	According to the IEC 60068-2-1
Damp heat test, cyclic	According to the IEC 60068-2-30

Table 5.2.3-10 Electromagnetic compatibility tests

EMC immunity test level requirements consider the demands in the generic standard EN 50082-2.	
1 MHz burst disturbance test, class III	According to the IEC 60255-22-1
• Common mode	2.5 kV
• Differential mode	1.0 kV
Electrostatic discharge test, class III	According to the IEC 61000-4-2 and IEC 60255-22-2
• For contact discharge	6 kV
• For air discharge	8 kV

Table 5.2.3-10 Electromagnetic compatibility tests (Continued)

Radio frequency interference tests <ul style="list-style-type: none"> • Conducted, common mode • Radiated, amplitude-modulated • Radiated, pulse-modulated • Radiated, test with a portable transmitter 	According to the IEC 61000-4-6 10 V (rms), f=150 kHz...80 MHz According to the IEC 61000-4-3 10 V/m (rms), f=80...1000 MHz According to the ENV 50204 10 V/m, f=900 MHz According to the IEC 60255-22-3, method C; f=77.2 MHz, P=6 W; f=172.25 MHz, P=5W
Fast transient disturbance tests <ul style="list-style-type: none"> • Other terminals • Binary input 	According to the IEC 60255-22-4 and IEC 61000-4-4 4 kV 2 kV
Surge immunity test <ul style="list-style-type: none"> • Power supply • I/O ports 	According to the IEC 61000-4-5 4 kV, line-to-earth 2 kV, line-to-line 2 kV, line-to-earth 1 kV, line-to-line
Power frequency (50 Hz) magnetic field	According to the IEC 61000-4-8 100 A/m continuous
Voltage dips and short interruptions	According to the IEC 61000-4-11 30%/10 ms 60%/100 ms >95%/5000 ms
Electromagnetic emission tests <ul style="list-style-type: none"> • Conducted, RF-emission (Mains terminal) • Radiated RF-emission 	According to the EN 55011 and EN 50081-2 EN 55011, class A, IEC 60255-25 EN 55011, class A, IEC 60255-25
CE approval	Complies with the EMC directive 89/336/EEC and the LV directive 73/23/EEC

Table 5.2.3-11 Standard tests

Insulation tests	
Dielectric tests <ul style="list-style-type: none"> • Test voltage 	According to the IEC 60255-5 2 kV, 50 Hz, 1 min
Impulse voltage test <ul style="list-style-type: none"> • Test voltage 	According to the IEC 60255-5 5 kV, unipolar impulses, waveform 1.2/50 μ s, source energy 0.5 J
Insulation resistance measurements <ul style="list-style-type: none"> • Isolation resistance 	According to the IEC 60255-5 > 100 M Ω , 500 V DC
Mechanical tests	
Vibration tests (sinusoidal)	According to the IEC 60255-21-1, class I
Shock and bump test	According to the IEC 60255-21-2, class I

Table 5.2.3-12 Data communication

<p>Rear interface, connector X2.2</p> <ul style="list-style-type: none"> • RS-485 connection for the fibre-optic interface module RER 103 • SPA-bus or IEC 60870-5-103 protocol • 4.8 or 9.6 kbps
<p>Front interface</p> <ul style="list-style-type: none"> • Optical RS-232 connection for the opto-cable • SPA bus protocol • 4.8 or 9.6 kbps

Auxiliary voltage

The REU 523 requires a secured auxiliary voltage supply to operate. The internal power supply of the relay forms the voltages required by the relay electronics. The power supply is a galvanically isolated (flyback-type) DC/DC converter. When the auxiliary voltage is connected, the READY indicator LED on the front panel will be on. For detailed information on power supply, refer to table 5.2.3-2.

The primary side of the power supply is protected with a fuse located on the PCB of the relay. The fuse size is 3.15 A (slow).

6. **Ordering information**

Order number	REU523B 409BAA
Article number	1MRS091409-BAA
Protective cover for rear connectors	1MRS060132
Flush mounting kit	1MRS050209
Semi-flush mounting kit	1MRS050253
Wall mounting kit	1MRS050240
Side-by-side mounting kit	1MRS050241
19" Rack mounting kit	1MRS050257
Optic bus connection module	RER103-XX
Opto-cable	1MKC950001-2

7. Abbreviations

BI	Binary input
CBFP	Circuit-breaker failure protection
CPU	Central processing unit
IDMT	Inverse definite minimum time characteristic
IEC_103	Standard IEC 60870-5-103
IRF	Internal relay fault
LCD	Liquid Crystal Display
LED	Light-emitting diode
LSG	LON [®] /SPA Gateway, SPA-ZC 102
HMI	Human-Machine Interface
PCB	Printed Circuit Board
PO1, PO2	Power outputs
SGB	Switchgroup for binary input
SGF	Switchgroups for functions
SGR	Switchgroups for output contacts
SO1, SO2	Signal outputs
U_{12} , U_{23} , U_{31}	Phase-to-phase voltages
U_{1s}	Positive-phase-sequence voltage

8.

Check lists

Table 8.-1 Setting group 1

Variable	Group 1 (R, W, P)	Setting range	Default setting	Customer's setting
Set start value of stage U>	S41	0.60...1.40 x U _n	1.20 x U _n	
Operate time of stage U>	S42	0.06...600 s	0.06 s	
Time multiplier k>	S43	0.05...2.00	0.05	
Drop-off/pick-up ratio D/P> of stages U> and U>>	S44	0.95...0.99	0.97	
Set start value of stage U>>	S45	0.80...1.60 x U _n	1.20 x U _n	
Operate time of stage U>>	S46	0.05...600 s	0.05 s	
Time multiplier k>>	S47	0.05...2.00	0.05	
Set start value of stage U<	S48	0.30...1.20 x U _n	0.30 x U _n	
Operate time of stage U<	S49	0.10...600 s	0.10 s	
Time multiplier k<	S50	0.10...2.00	0.10	
Drop-off/pick-up ratio D/P< of stages U< and U<<	S51	1.01...1.05	1.03	
Set start value of stage U<<	S52	0.30...1.20 x U _n	0.30 x U _n	
Operate time of stage U<<	S53	0.10...600 s	0.10 s	
Time multiplier k<<	S54	0.10...2.00	0.10	
Checksum, SGF1	S55	0...31	0	
Checksum, SGF2	S56	0...255	0	
Checksum, SGF3	S57	0...255	170	
Checksum, SGF4	S58	0...63	0	
Checksum, SGB1	S59	0...255	0	
Checksum, SGR1	S60	0...15	12	
Checksum, SGR2	S61	0...15	3	
Checksum, SGR3	S62	0...15	12	
Checksum, SGR4	S63	0...15	3	
Checksum, SGR5	S64	0...15	12	
Checksum, SGR6	S65	0...15	3	
Checksum, SGR7	S66	0...15	12	
Checksum, SGR8	S67	0...15	3	

Table 8.-2 Setting group 2

Variable	Group 2 (R, W, P)	Setting range	Default setting	Customer's setting
Set start value of stage U>	S81	0.60...1.40 x U _n	1.20 x U _n	
Operate time of stage U>	S82	0.06...600 s	0.06 s	
Time multiplier k>	S83	0.05...2.00	0.05	
Drop-off/pick-up ratio D/P> of stages U> and U>>	S84	0.95...0.99	0.97	
Set start value of stage U>>	S85	0.80...1.60 x U _n	1.20 x U _n	
Operate time of stage U>>	S86	0.05...600 s	0.05 s	
Time multiplier k>>	S87	0.05...2.00	0.05	
Set start value of stage U<	S88	0.30...1.20 x U _n	0.30 x U _n	
Operate time of stage U<	S89	0.10...600 s	0.10 s	

Table 8-2 Setting group 2

Variable	Group 2 (R, W, P)	Setting range	Default setting	Customer's setting
Time multiplier k<	S90	0.10...2.00	0.10	
Drop-off/pick-up ratio D/P< of stages U< and U<<	S91	1.01...1.05	1.03	
Set start value of stage U<<	S92	0.30...1.20 x U _n	0.30 x U _n	
Operate time of stage U<<	S93	0.10...600 s	0.10 s	
Time multiplier k<<	S94	0.10...2.00	0.10	
Checksum, SGF1	S95	0...31	0	
Checksum, SGF2	S96	0...255	0	
Checksum, SGF3	S97	0...255	170	
Checksum, SGF4	S98	0...63	0	
Checksum, SGB1	S99	0...255	0	
Checksum, SGR1	S100	0...15	12	
Checksum, SGR2	S101	0...15	3	
Checksum, SGR3	S102	0...15	12	
Checksum, SGR4	S103	0...15	3	
Checksum, SGR5	S104	0...15	12	
Checksum, SGR6	S105	0...15	3	
Checksum, SGR7	S106	0...15	12	
Checksum, SGR8	S107	0...15	3	

Table 8-3 Control parameters

Variable	Parameter	Setting range	Default setting	Customer's setting
Rated frequency	V133	50/60 Hz	50	
Rated Voltage	V134	100, 110, 115, 120 V	100	
Remote control of settings	V150	0/1	0	
Non-volatile memory settings	V152	0...31	31	
Event mask for U> and U>>	V155	0...255	85	
Event mask for U< and U<<	V156	0...255	85	
Event mask for output contacts' events	V157	0...255	3	
Event mask for the disturbance recorder and the HMI password	V158	0...7	1	
Unit address of the relay	V200	1...254	1	
Data transfer rate	V201	4.8 or 9.6 kbps	9.6	
Operate time of the CBFP	S121	0.10...1.00 s	0.10	
Time setting for disabling new trip indications on the LCD	S122	0...999 min	60	

Table 8.-4 Parameters for the disturbance recorder

Information	Parameter	Setting range	Default setting	Customer's setting
Post-triggering recording length in percent	V240	0...100%	50%	
Internal trigger signals' checksum	V241	0...127	82	
Internal trigger signal's edge	V242	0...127	0	
External trigger signal (BI)	V243	0/1	1	
External trigger signal's edge	V244	0/1	0	
Sampling rate	M15	800/960 Hz 400/480 Hz 50/60 Hz	800/960 Hz	
Station identification/unit number	M18	0...9999	0000	
Station name	M20	Max 15 characters	- ABB -	
Analogue channel(s): rated voltage and unit of primary voltage transformer(s)	M80	Rated voltage 0.00...600, unit V or kV	0.00, kV	

9. Service

When the protection relay is used under the conditions specified in Section 5.2.3. "Technical data", it is practically maintenance-free. The protection relay electronics include no parts or components subject to abnormal physical or electrical wear under normal operating conditions.

If the relay fails in operation or if the operating values considerably differ from those mentioned in the protection relay specifications, the relay should be overhauled. All repairs are to be taken by the manufacturer. Please contact the manufacturer or its nearest representative for further information about checking, overhaul and recalibration of the relay.



To achieve the best possible operation accuracy, all parts of the protection relay have been calibrated together. In the event of malfunction, please consult your relay supplier.

If the protection relay is sent to the manufacturer, it has to be carefully packed to prevent further damage to the device.

10.
Index

A	
Application	11
Auxiliary voltage	52, 54, 57
B	
Binary input	52, 54
Binary input test	33
Block diagram	17
C	
CBFP	14
Characteristic of the undervoltage stages	21
Characteristics of the overvoltage stages	20
Check lists	63
Checksum calculation	25
Communication ports	36
Communication protocol	37
Comtrade	35
Configuration	11, 16
Connection diagram	12
Control parameters	47, 64
Counter	37
D	
Data communication	57
Demand values	33
Design description	50
Dimensions	54
Disturbance recorder	14, 33, 46
Disturbance recorder data	33
E	
Electromagnetic compatibility tests	55
Energizing inputs	54
Environmental conditions	11
Environmental tests	55
Event code	35, 40, 41, 42
External parameterization	50
F	
Fault code	15, 50
Features	9
Function test	33
H	
HMI	14, 23

I	
IEC 60870-5-103	37
Indication messages	32, 49
Input/output connections	50
Input/output signals	48
Inputs	14, 48
Internal relay fault	15, 49, 52
L	
Latching feature	26
LCD	14, 49
LED	15, 32, 49
LED test	33
Local parameterization	50
LON bus	37
M	
Master reset	35
Measurements	16
Measuring range	54
N	
New trip indication	30
Non-volatile memory	15, 31
O	
Ordering information	59
Output signals	49
Overvoltage unit	17
P	
Parameterization	50
Parameters for the disturbance recorder	46, 65
Password	14, 42
Positive-phase-sequence	19
Power outputs (PO1, PO2)	14, 49, 52, 55
Power supply	54
Product functions	13
R	
Recorded data	35, 44
Requirements	11

S

Self-supervision	15, 49
Serial communication	36, 52
Setting groups	23, 63
Settings	23, 43
SGB1	29
SGF1...SGF4	26
SGR1...SGR8	29, 50
Signal diagram	16
Signal outputs (SO1, SO2)	14, 49, 52, 55
SPA bus communication protocol	36
Switchgroups	24

T

Technical data	54
Technical data on protection functions	31
Time/voltage characteristics	20

U

Undervoltage unit	18
-------------------------	----

W

Weighting factor	25
------------------------	----



ABB Oy

Distribution Automation

P.O. Box 699

FI-65101 Vaasa

FINLAND

Tel. +358 10 22 11

Fax. +358 10 224 1094

www.abb.com/substationautomation