



Temperature Transmitter TEU421, TEU421-Ex

intelligent, four-wire

Operating Instructions

Document No. 42/11-38 EN
Date of issue: 11.2005
Revision: 03

Manufacturer

ABB Automation Products GmbH
Borsigstr. 2
63755 Alzenau
Germany

Tel: +49 551 905-534

Fax: +49 551 905-555

CCC-Support.deapr@de.abb.com

© Copyright 2005 by ABB Automation Products GmbH
We reserve the right to technical amendments.

This document is protected by copyright. Information in this document is intended only to assist the user in the safe and efficient operation of the equipment. Its contents are not to be reproduced in full or part without prior approval of the legal owner.

The software described in this document is licensed and may only be used, copied or disclosed in accordance with the licensing terms.






Contents	Page
Important informationen	4
Necessary documentation	4
1 General safety instructions	5
2 Application and short description	6
3 Installation and commissioning	6
Accessories supplied with the unit	6
Rating plate labelling	7
3.1 Mounting location	7
3.2 Mounting the unit	8
Codes on the plug connectors design D and F	9
Internal reference junctions IP 00 and IP 20	10
3.3 Connecting the unit	10
3.4 Commissioning	12
3.5 Line compensation	12
3.6 Adjustment	13
4 Operation	14
4.1 Write protection	14
4.2 LKS interface	14
4.3 FSK interface	14
4.4 FSK bus	15
4.5 PC and Notebook requirements	15
4.6 Device data	16
4.7 Conversion	16
4.8 Changing the measuring circuit combination	17
4.9 Changing the power supply	17
4.10 Changing the output signal	17
4.11 Changing binary signals	17
5 Maintenance	20
5.1 Safety instructions for working on transmitter TEU 421 and TEU 421-Ex	20
5.2 Additional safety instructions for working on transmitter TEU421-Ex	20
6 Appendix	21
6.1 Description	21
6.1.1 Function modules	22
6.1.2 Measured value processing	22
6.1.3 Input weighting values	22
6.1.4 Reference junction compensation	22
6.1.5 Linearization/average value/difference	22
6.1.6 Damping	22
6.1.7 Scaling	22
6.1.8 Analog output	22
6.1.9 Binary signals	22
6.2 Technical data	23
6.3 Packaging	28
6.4 Accessories	28

Important informationen

Symbols

In order that you can make the best use of this document and to ensure safety during commissioning, operation and maintenance of the equipment, please note the following explanation of the symbols used.

Explanation of the symbols used.

Symbol	Signal Word	Definitions
	DANGER	DANGER indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury. (High level of risk.)
	WARNING	WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury. (Medium level of risk.)
	CAUTION	CAUTION indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury. (Low level of risk.)
	NOTICE	NOTICE indicates a potentially harmful situation which, if not avoided, may result in damage of the product itself or of adjacent objects. (Damage to property)
	IMPORTANT	IMPORTANT indicates useful hints or other special information which, if not observed, could lead to a decline in operating convenience or affect the functionality. (Does not indicate a dangerous or harmful situation.)

As well as the instructions in this document, you must also follow the generally applicable accident prevention and safety regulations.

If the information in this document is insufficient in any situation, please contact our service department, who will be happy to help you.

Please read this document carefully before installation and commissioning.

Necessary documentation

Data Sheet 10/11-3.20 EN

1 General safety instructions

Important Instructions for Your Safety. Please read and observe.

Correct and safe operation of the transmitters TEU421 and TEU421-Ex, calls for appropriate transportation and storage, expert installation and commissioning as well as correct operation and meticulous maintenance.

Only those persons conversant with the installation, commissioning, operation and maintenance of similar apparatuses and who possess the necessary qualifications are allowed to work on the transmitters TEU471 and TEU471-Ex.

Please take note of

- the contents of these Operating Instructions,
- the safety regulations affixed to the transmitters TEU421 and TEU421-Ex,
- the safety regulations pertaining to the installation and operation of electrical systems as well as
- the directives and guidelines on explosion protection.

The user must ensure that units connected to the transmitter TEU421 and TEU421-Ex fulfil the appropriate requirements of the accident prevention regulations VBG4.

The directives, norms and guidelines mentioned in these Operating Instructions are applicable in the Federal Republic of Germany. When using the transmitters TEU421 and TEU421-Ex in other countries, please observe the national regulations prevailing in the respective country.

The transmitters TEU471 and TEU471-Ex have been designed and tested in accordance with IEC 1010-1 (correspond to DIN EN 61010-1 and DIN VDE 0411 part 1) "Safety requirements for electrical measurement, control and laboratory equipment", and have been supplied in a safe condition. In order to retain this condition and to ensure safe operation, the safety instructions in these Operating Instructions bearing the headline "DANGER", „WARNING“, „CAUTION“ or „NOTICE“ must be observed. Otherwise, persons can be endangered and the transmitters themselves as well as other equipment and facilities can be damaged.

If the information in these Operating Instructions should prove to be insufficient in any point, the ABB Service Department will be delighted to give you more information.

Declaration of conformity

The requirements of the European directive 72/23/EEC (PLV) are met.

The requirements of the European directive 94/9/EC (ATEX) are met.

The product conforms with the European Directive 89/336/EEC (EMC) and its amendments as it meets the requirements of the following standards:

- Interference emission: EN 50 081-1:1992
- Interference immunity: EN 50 082-2:1995
- Test: EN 61 000-4 Parts 2, 3, 4, 5 and 6.

2 Application and short description

The transmitter TEU 421 (Ex) serves to measure temperature and other process parameters. It converts the input parameters into a load independent DC (0/4 ... 20 mA) or a direct voltage (0 ... 10 V).

The transmitter is supplied either

- with standard parameters or
- with customer specific parameters.

3 Installation and commissioning

When installing the TEU421-Ex, the requirements for setting up of electrical apparatus in hazardous areas (DIN EN 60079-14) and the provisions of the EC type examination certificate (PTB 04 ATEX 2063) must be observed.




Fig. 3-1 Front view of TEU421 (-Ex)

Accessories supplied with the unit

A test jack for line compensation is supplied with TEU421 (-Ex).

Rating plate labelling

Explanation of symbols	
	Additional insulation (DIN 30 600)
	Input (DIN 30 600)
	Output(DIN 30 600)
	Internal reference junction (DIN 30 600)
	Electrical power (DIN 30 600)
	Observe Operating Instructions!(DIN 30 600)
	Electrical apparatus tested for type examination certificate (DIN 40 012)
	Measured value constant (DIN 30 600) – last valid value held
	Measured value ascending (DIN 30 600) – overranging
	Measured value descending (DIN 30 600) – underranging
	Default value
	LKS interface
	FSK interface
2L/w/f	2-wire circuit
3L/w/f	3-wire circuit
4L/w/f	4-wire circuit

3.1 Mounting location

Position of use	+Front panel vertical
Ambient temperature	-10...+20...+70 °C
Condensation	none
Degree of protection	IP 00 (19" plug-in card) IP 20 (surface mounting case IP 20)

The input circuit of the transmitter TEU421- Ex is approved for the intrinsic safety EEx ia IIC/IIB or EEx ib IIC/IIB types of protection. The input circuit may be set up within areas subject to explosion hazard under observance of the EC type examination certificate (PTB 04 ATEX 2064 and 2062). Since only the input circuit is intrinsically safe, the transmitter TEU421- Ex must be installed outside the hazardous area.

3.2 Mounting the unit

(Dimensional drawings see Fig. 3-2)



DANGER

When installing the TEU421-Ex, the requirements for the setting up of electrical apparatus in hazardous areas DIN EN 60079-14 (VDE0165 part 1) and the provisions of the EC type examination certificates (PTB 04 ATEX 2064 and PTB 04 ATEX 2062) must be observed.




Fig. 3-2 Dimensional drawing

Codes on the plug connectors design D and F

(see Fig. 3-3 and Fig. 3-4)

No other card may be fitted into the slot intended for a 19" plug-in card in the explosion protection version. To ensure this, codes are marked on the plug connectors. The slot in the 19" subrack must be adapted to this coding.

The 19" plug-in card has a width of 4T, hence up to 21 transmitters can be installed in a single 19" subrack. Observe the permissible ambient temperature.




Fig. 3-3 Plug connector design D
Coding with protrusion and circuit board comp




Fig. 3-4 Plug connector design F
Coding with coding pin

- Fit the 19" plug-in card into the slot on the 19" subrack and secure it with two screws.

Internal reference junctions IP 00 and IP 20

- The reference junction IP 00 is mounted at the rear (wiring section) of the 19" subrack, e.g. beside the spring contact strip of the transmitter (1 slot occupied).
- The reference junction IP 20 is mounted on the cover flap of a spring contact strip. Take account of the installation depth!

**IMPORTANT**

If other reference junction constructions are used make sure that the Pt 100 is connected to a 2-wire circuit. Balancing can be carried out with the TEU421.

3.3 Connecting the unit

(see Fig. 3-5)

**DANGER**

Before all other connections are made the protective-conductor terminal must be connected to a protective conductor.

The apparatus can be dangerous if the protective conductor is interrupted inside or outside the apparatus or if the protective-conductor terminal is disconnected

All pole disconnection must be provided in the mains supply line. This device may also disconnect a group of units if it has the requisite current and voltage carrying capacity.

Where a unit with a certified intrinsically safe output circuit is connected to the intrinsically safe input circuit of the transmitter TEU471-Ex, then evidence of the intrinsic safety of the connection must be provided DIN EN 60079-14 (VDE0165 part 1).

If, for functional reasons, the intrinsically safe current circuit has to be earthed through connection to the equipotential bonding, it may only be earthed at one point.

Before switching on the apparatus make sure it is set to the voltage of the power supply.

The requirements of DIN VDE 0100 must be fulfilled when selecting the line material and laying the measuring and output signal lines. DIN EN 60079-14 (VDE0165 part 1) must further be adhered to for the explosion-protected version.

- Wire the spring contact strip mounted in the 19" subrack according to the connection diagram.




Fig. 3-5 Connection diagram
 1) At line break monitoring for 4-wire circuit the bridge BR30 must be open (see Fig. 4-4)

3.4 Commissioning



WARNING

When the apparatus is connected to its supply, terminals may be live, and the opening of covers or removal of parts except those to which access can be gained by hand is likely to expose live parts.

Electrostatic energy first has to be discharged by operating personnel before opening the ESD ¹⁾ cap.

- Turn on the power supply. The green LED lights up to indicate the unit is ready for operation after approx. 4 s.

Signal	Green LED	Red LED
oN	Unit ready for operation	Overranging Underranging Sensor fault Unit fault
Flashes slowly	Line compensation Unit fault	–
Flashes rapidly	External fault: sensor break Senso short-circuit	Line compensation with test jack
Out	Unit not ready for operation	Overranging Underranging Sensor fault Unit fault

Table 3-1 Signals of the green and red LEDs

1) ESD = Electrostatical discharge

3.5 Line compensation

Line compensation is necessary if

- a resistance thermometer or ohmmeter is used in a 2-wire circuit
- carrying out measurements using a resistance remote signalling unit (2-wire circuit)

Line compensation is not necessary if

- a resistance thermometer or ohmmeter is used in a 3-wire circuit

WICHTIG

If the line resistances are not the same for each wire than symmetry can be restored using the Device Management Tool DSV4xx (SMART VISION).

- a resistance thermometer or ohmmeter is used in a 4-wire circuit.

LINE COMPENSATION

The connected sensors must be short circuited before carrying out line compensation:



- **USING Device Management Tool DSV4xx (SMART VISION)**

Select menu option: unit data / specialist / unit / compensation / line compensation/ balancing

The Device Management Tool DSV4xx (SMART VISION) provides additional information through help texts.

- **using the test jack**

(see Table 3-2)

Sequence	Signal		Waiting time	Description
	LED1 and LED2	Green LED		
Short circuit sensor	Dependent on parameterization	on or flashing (with active sensor short circuit monitoring)	–	Operational
Insert test jack	Flashes rapidly	Flashes slowly	< 1 s < 5 min	Analog output fixed Alarm value frozen
Remove test jack	Flashes rapidly	Flashes slowly	> 1 s < 10 s	Analog output fixed Alarm value frozen
Insert test jack	Flashes rapidly	on or flashing (with active sensor short circuit monitoring)	< 1 s < 5 min	Compensation starts
Remove jack	Flashes rapidly	on or flashing (with active sensor short circuit monitoring)	> 1 s < 10 s	–
Insert kack	Dependent on parameterization	on or flashing (with active sensor short circuit monitoring)	> 1 s < 10 s	Compensation data stored
Remove jack	Dependent on parameterization	on or flashing (with active sensor short circuit monitoring)	> 1 s < 10 s	Compensation completed
Remove sensor short circuit	Dependent on parameterization	on	–	Operational

Table 3-2 Line compensation with test plug

3.6 Adjustment

The transmitter TEU421 (Ex) is supplied in an adjusted condition. Readjustment is only necessary:

- if resistances other than those specified are incorporated when modifying the measuring circuit combination
- if greater accuracy is required than that specified in the technical data (precision balancing of lower range value and upper range value)
- when switching the output from mA to V or vice versa.

The Device Management Tool DSV4xx (SMART VISION) provides information on adjustment.

Additional aids

- Precision (for the input),
- Measuring instrument (for output).

4 Operation

The transmitter is controlled via the Device Management Tool DSV4xx (SMART VISION).

4.1 Write protection

In order to avoid unwanted parameter changes, the parameters are write-protected. The jumpers BR111 (write protection active) and BR110 (write protection inactive - standard setting) must be set as seen in Fig. 4-4.

The following interfaces are available, depending on the communication between the PC and the transmitter:

4.2 LKS interface

(LKS = local communication interface)

(see Fig. 4-1)



DANGER

Potential separation is necessary with the LKS interface if the output is electrically connected to earth.

Operating apparatus:

- With Device Management Tool DSV4xx (SMART VISION)
- LKS adapter




Fig. 4-1 PC communication with the LKS interface and LKS adapter

Both off-line and on-line communication are possible with transmitters with the LKS interface.

On-line communication

- Transmitter operational

Off-line communication

- Transmitter not operational

Important

The transmitter can be parameterized without power supply.



4.3 FSK interface

(FSK = Frequency Shift Keying)

(see Fig. 4-2)

Operating apparatus:

- PC with Device Management Tool DSV4xx (SMART VISION)
- FSK modem with terminal leads

Only on-line communication is possible with transmitters with the FSK interface. The FSK interface may be operated within a bus.

4.4 FSK bus

(see Fig. 4-3)

The FSK plug-in sockets on the transmitter front panel enable stand-alone operation, i.e., the FSK connection to the terminal level is interrupted.

The transmitter is factory-set to the bus address 00000:00. This address does not permit bus operation. Bus operation is only possible if set to \neq 00000:00. Setting of the bus address is described in the Device Management Tool DSV4xx (SMART VISION).

Further technical information is provided in Data Sheet 10/63-6.71 EN.




Fig. 4-2 PC communication with the FSK interface and FSK modem




Fig. 4-3 PC communication with the FSK bus (example)

4.5 PC and Notebook requirements

See Data Sheet 10/63-1.20 EN

4.6 Device data

The device data of the transmitter are set according to the customer requirements (customized parameter definition) or according to the manufacturer's specifications (standard parameter definition, see Table 4-1).

Measuring circuit combination	MK 41/42	MK 44	MK 45
No. of measuring points	-/-	-/-	-/-
Description of measuring points	-/-	-/-	-/-
Bus address	00000:00	00000:00	00000:00
Type of measurement	Simple	Simple	Simple
Sensor	Pt 100, 3-wire circuit	V-linear	mA-linear
Measuring range	0...100 °C	0...10 V	0...20 mA
Output	4...20 mA	4...20 mA	4...20 mA
Underranging value	3.6 mA	3.6 mA	3.6 mA
Overranging value	22 mA	22 mA	22 mA
Output behaviour in the event of sensor fault	overranging	–	–
Damping	0.90 s	0.90 s	0.90 s
LED1/Binary output 1 Assignment Behaviour Circuit Switching point	Sensor fault – Load current –	Alarm value min. Load current 0 V	Alarm value min. Load current 0 mA
LED2/Binary output 2 Assignment Behaviour Circuit Switching point	Alarm value max. Load current 100 °C	Alarm value max. Load current 10 V	Alarm value max. Load current 20 mA

Table 4-1 Standard parameters

4.7 Conversion

(see Fig. 4-4 and Fig. 4-5)

The transmitter can be modified to perform another measurement task. The following can be changed:

- the measuring circuit combination
- the power supply
- the output signal
- the binary signal



It is not possible to change the interface.



NOTICE

The catalog number (P ...) on the rating plate describes the hardware configuration. This number is also stored in the transmitter. When changing the hardware, which also necessitates a change in the catalog number, this must be stored in the transmitter using the Device Management Tool DSV4xx (SMART VISION). No plausibility check is carried out for the modification. This change must be indicated on the rating plate.

4.8 Changing the measuring circuit combination

Changing from MK 41 to MK 42 or vice versa is carried out with the parameter setting program Device Management Tool DSV4xx (SMART VISION) (no hardware access). See the connection diagram.

The following resistors or bridges have to be changed to yield further variations (see Table 4-2).

MK	Jumper Br 3	Resistor R 50	Resistor R 51
MK 41/42	closed	–	–
MK 44	open	99 kΩ	1 kΩ
MK 45	closed	–	5 Ω

Table 4-2 Jumper assignment

All resistors are metal film resistors of DIN size 0207, tolerance $\leq \pm 0.1\%$ and $TK \leq 15$ ppm.

4.9 Changing the power supply

NOTICE

When changing the power supply the rating plate must be changed correspondingly.



The 230 V AC version may be changed to a 24 V UC version.

The 115 V AC and 24 V UC versions cannot be changed.

Power supply	Plug-in jumper BR 201	Jumper BR 202	Jumper Br 203
24 V UC	in position	closed	closed
230 V AC	open (parked)	open	open

Table 4-3 Jumper assignment

4.10 Changing the output signal

Output signal	Jumper BR 101	Jumper BR 104	Jumper BR 105	Jumper BR 106	Jumper BR 107	Jumper BR 108
0/4...20 mA (Load 700 Ω; test jack active)	closed	open	open	closed	open	open
0/4...20 mA (Load 750 Ω; test jack inactive)	closed	closed	open	closed	open	open
0...10 V	open	closed	closed	open	closed	closed

Table 4-4 Jumper assignment

IMPORTANT

Re-adjustment is necessary if switching from V to mA or vice versa.



4.11 Changing binary signals

The relays for the digital signals (1 or 2) are accommodated on a separate PCB. This module is to be plugged in the dedicated slot.




Fig. 4-4 Motherboard (component side)




Fig. 4-5 Motherboard (solder side)

5 Maintenance

Check the housing, the cables, the cable glands, the potential equalization line, etc. at sufficiently short intervals for possible damage, depending on the load to which they are exposed during operation.

If any of the parts that are relevant for the device protection (e.g. any of the housing panels, the cable glands, the cover thread, etc.) should be defective, put the device out of operation immediately and disconnect it from power. Do not return it to operation unless it is fully operational again.

5.1 Safety instructions for working on transmitter TEU 421 and TEU 421-Ex



WARNING

When the apparatus is connected to its supply, terminals may be live, and the opening of covers or removal of parts except those to which access can be gained by hand is likely to expose live parts.

Before starting any commissioning or repair work requiring the device to be opened, always make sure that the device is fully disconnected from power.

Capacitors inside the unit may still be charged even if the unit has been disconnected from all voltage sources.

Whenever it is likely that protection has been impaired, the unit shall be made inoperative and be secured against any unintended operation.

It must be assumed that the protection has been impaired when

- it shows visible signs of damage
- it no longer functions
- it has been stored for long periods under unfavourable conditions
- it has been subjected to adverse transport conditions.

Only fuses of the specified type and rated current may be used as a replacement. Makeshift fuses must not be used.

The fuse-holder may not be short-circuited.

The power supply fuse is on the motherboard. Only M 0.1 C fuses may be used (for all forms of power supply).

5.2 Additional safety instructions for working on transmitter TEU421-Ex



DANGER

Before beginning work on the instrument, the safety measures pertaining to the explosion protection must absolutely be borne in mind.

Components determining the explosion protection must only be replaced by components of similar quality, which are certified if necessary.

If a part of the device which determines the explosion protection has been repaired it may only be placed in operation again after an expert has checked it and certified that it complies with the explosion protection requirements. This check is not necessary if the work has been performed by authorized ABB personnel.

The transmitter TEU471 (-Ex) does not require any maintenance. In the event of errors, the power source should first be inspected, then the source, connection leads and output circuit.

Diagnostic functions can be effected with Device Management Tool DSV4xx (SMART VISION). See menu branches: "Measured value display", "Device status", "Self test".

6 Appendix

6.1 Description

(see Fig. 6-1)




Fig. 6-1 Functional diagram

The input signals are fed to the measuring point selector (MPS) via the input protection circuit. The standard input parameters (mV, Ω, V, mA) can be matched to the input voltage range of the amplifier through a filter network. The amplifier converts the low input voltage to the working range of the A/D converter.

The pulse-amplitude modulator (PAM) converts the voltage from the amplifier into a mark-space ratio. Correction values for the zero point and slope are determined from the test measurements (zero point and reference) and stored. The (sensor) break monitoring checks the sensor impedance to a maximum value. The input signal is fed with electrical isolation to the CPU. The CPU is the central component of the transmitter and fulfils a number of functions.

The following routines

- Monitoring (dead man, watchdog)
- A/D converter (read-in, plausibility checks, ...)
- Communication (reading, writing)
- Measured value processing (linearization, damping, ...)
- Self-test

are called up in succession.

The EEPROM contains data which describe the transmitter at its installation site. This type of data includes all user-specific parameterization data (e.g. measuring range, linearization, measuring point number). The EEPROM also contains data which only relates to the particular transmitter, e.g. deviations from reference values or the F-number.

The ROM contains the firmware of the transmitter. Either the LKS interface (3 V CMOS) or the FSK interface (electrically isolated) is used for communication with the PC.

Power is supplied via a transformer with an electrically isolated output voltage.

6.1.1 Function modules

(see Fig. 6-2)

The function modules shown below are configured through the Device Management Tool DSV4xx (SMART VISION) according to the measurement task.

The "readable variables" are displayed in the menu option "Diagnosis".




Fig. 6-2 Function modules

6.1.2 Measured value processing

Measuring range setting (measuring circuit selection and sensor selection); sensor monitoring (break and short-circuit); reference junction measurement for the internal reference junction temperature.

6.1.3 Input weighting values

Average value derivation by linking several sensors to one input; simulation of sensor characteristics from the same basic data (e.g. Pt 1000 from the Pt 100 characteristics - $10 \times Pt 100$)

6.1.4 Reference junction compensation

Correction of the measured value for the internal/external reference junction in thermocouple measurement

6.1.5 Linearization/average value/difference

According to standardized or customer-specific characteristics (max. 32 coincidence points); average value/difference from input and auxiliary input. The characteristics of the standardized sensors are saved in the transmitter.

6.1.6 Damping

Filter with 1st order delay

6.1.7 Scaling

Lower-range value and upper-range value

6.1.8 Analog output

Output signal adjustment for current/voltage, over- and underranging, behaviour in the event of sensor or unit fault

6.1.9 Binary signals

(not shown in the Figure)

Assignment of LED 1 + 2, binary outputs 1 + 2 for signalling of sensor, apparatus and alarm value errors.

6.2 Technical data

Input

Max. potential

230 V AC ¹⁾

Resistance thermometers in

2-, 3- and 4-wire circuits

Thermocouples

Without/with internal or external reference junction

Resistance remote signalling unit

Ω , mV, mA, V sources

Measurement options

Simple: 1 Sensor at input
 Average value: 1 Sensor at input and
 1 Sensor at auxiliary input
 or
 2...10 Sensors in series at input
 Difference: 1 Sensor at input and
 1 Sensor at auxiliary input

(Average value and difference only for mV and Ω sources MK 41 in 2-wire circuit)

Measuring circuit combinations MK

Measuring circuit combination	Complete span	Minimum span
MK 41	0...391 Ω -8...+120 mV	6.7 Ω 2 mV
MK 42	0...3250 Ω -8...+120 mV	58 Ω 2 mV
MK 44	-0.8...+12 V	0.5 V
MK 45	-1.6...+24 mA	1 mA

Measuring range

may be parameterized

Measuring current

MK 41: approx. 0.29 mA

MK 42: approx. 35 μ A

Input resistance

MK 44: 100 k Ω

MK 45: 5 Ω

Overload limit ¹⁾

Thermocouple measurement/mV measurement (MK 41/MK 42)

-0.5...+3.5 V

Resistance thermometer and resistance measurement (MK 41/MK 42)

Open or short-circuited input permitted

Voltage measurement (MK 44) -50...+100 V

Current measurement (MK 45) -100...+100 mA

Sensor monitoring

mV measurement

Break: response threshold > 1.5 M Ω
 or gradient < -3 mV/s / gradient > + 3 mV/s
 or < -8mV / > +120 mV

Ω measurement

Response threshold for sensor breaks: MK 41 > 391 Ω ;
 MK 42 > 3250 Ω

Response threshold for short-circuits: < 5 Ω

¹⁾ For TEU471-Ex observe the EC type examination certificate!

Line resistance

(R_m = measuring resistance; R_L = line resistance of a conductor)

2-wire circuit

Max. 10 Ω for both conductors

with MK 41 (average / difference): $R_{m1} + (2R_{L1}) + R_{m2} + (2R_{L2}) < 415 \Omega$

3-wire circuit

Max. 10 Ω per conductor

4-wire circuit

Max. 50 Ω per conductor

with MK 41: $(R_m + R_L) < 415 \Omega$

Internal reference junction

In-built Pt 100 in 2-wire circuit

Linearization

As per DIN IEC standardized characteristics

Resistance thermometers: Pt 100, Ni 100

(Extended to e.g. Pt 1000, Ni 50, by means of weighting Pt 100, Ni 100)

Thermocouple types: B, E, J, K, L, N, R, S, T, U or customerspecific (max. 32 coincidence points)

Input weighting values

$n = 1, 2, 3, 4, 5, 6, 7, 8, 9, 10$

(for resistance measurement additionally $n = 0.5$)

Damping

Filter with first order delay ($\tau = 0 \text{ s}, 0.9 \dots 100 \text{ s}$)

Output**Max. potential**

50 V AC

Output signal (rising/falling)

0/4...20 mA (open output permitted)

Load $\leq 700 \Omega$ test jack active

$\leq 750 \Omega$ test jack not active

0...10 V (short-circuit proof)

Load $> 10 \text{ k}\Omega$

Residual ripple $\leq 0.5 \%$ **Control range (parameterizable)**

Underranging: -0.2...0/4 mA (test jack not active) ²⁾

-0.1...0/4 mA (Prüfbuchse active)

-0.1...0 V

Overranging: 20...23.6 mA

20...22 mA (with load $\geq 600 \Omega$ or 2 binary outputs)

10...11.8 V

10...11 V (with 2 binary outputs)

Output action in the event of a fault**Type of fault**

Sensor fault or sensor/device fault

Underranging

(= user underranging)

Overranging

(= user overranging)

Default value

Parameterizable (-0.2...23.6 mA, -0.1...11.8 V) ³⁾

Hold last valid value

²⁾ Test jack bridged

³⁾ Can also be parameterized via the control range set (e.g. for overranging/underranging signal)

Relay output

1 or 2 relays with NO contact

 Switching capacity $P_{\max.} = 10 \text{ W}, 10 \text{ VA}; \cos \varphi \geq 0.7; L/R \leq 7 \text{ ms}$

 Switching current $I \cong_{\max.} = 0.5 \text{ A}$

 Switching voltage $U \cong_{\max.} = 50 \text{ V}$
Damping

Filter with delay

 1st order delay ($\tau = 0 \text{ s}; 0.9 \dots 100 \text{ s}$)

Time constant τ set to	Response time T
0 s	typ. 0.8 s max. 1 s
0.9 s	ca. 2.7 s
1 s	ca. 3.3 s
1.5 s	ca. 5.8 s
2 s	ca. 8.2 s
> 5 s	$1 + 4.6 \times \tau$

Interfaces
Lokal Communication Interface (LKS)

for workshop parameterization (power supplied from PC)

Frequency Shift Keying (FSK)

for remote parameterization and bus operation

Data format

HART protocol

Power supply
Supply voltage

24 V UC ,

115 V AC

 230 V AC (switchable to 24 V UC) ⁴⁾
Alternating voltage
 $-15 \dots +10 \%$; 48...62 Hz

Direct voltage

18...33 V

Residual ripple
 $\leq 20 \%$ within the tolerance range

Power consumption

24 V UC: ca. 1.2 W, 1.5 VA

115 V AC: ca. 2 W, 5 VA

230 V AC: ca. 2 W, 8 VA

Characteristics under rated conditions (accord. to IEC 770)

(MV = measured value; K1, K2, K3 see table)

(Examples of calculations, see Data Sheet 10/11-1.02 EN)

Measuring deviation (with respect to the span set,)
 $0.1 \% \times MV + 0.1 \% + K1$

Additional error for internal reference junction: 0.25 K

 Additional error with MK 44, MK 45: $0.1 \% \times MV$
Conformity error (contained within the measuring deviation)
 $0.1 \% + K2$

⁴⁾ Conforms to NAMUR under mains interruption only for 230 V AC

	K1	K2	K3
Ω (MK 41)	80 m Ω	20 m Ω	10 m Ω
Ω (MK 42)	0.75 Ω	0.2 Ω	0.09 Ω
mV (MK 41/42)	10 μ V	5 μ V	2 μ V
V (MK 44)	1 mV	0.5 mV	0.2 mV
mA (MK 45)	2 μ A	1 μ A	0.4 μ A
Resistance thermometer (MK 41)	0.25 K	0.05 K	0.063 K
Resistance thermometer (MK 42)	0.25 K	0.05 K	0.1 K
Thermocouple > -150 °C except type B (MK 41/MK 42)	10 μ V ⁵⁾ + 0.2 K	10 μ V ⁵⁾ or 0.2 K (greater value holds)	2 μ V ⁵⁾
Thermocouple Typ E, K, N, T -250...-150 °C Typ B > 300 °C (MK 41/MK 42)	10 μ V ⁵⁾ + 0.6 K	10 μ V ⁵⁾ or 0.6 K (greater value holds)	2 μ V ⁵⁾

⁵⁾ Insert temperature value which corresponds to the slope of 10 μ V or 2 μ V at the measurement point.

Effects

Ambient temperature (with respect to the span set)

$(0.05 \% \times MW + 0.05 \% + K3) / 10 \text{ K}$
with an internal reference junction additionally h 0.1 K / 10 K

Power supply (with respect to the span set)

< 0.05 % for 10 % voltage variation
< 0.05 % for 48...62 Hz frequency change

Influence on the output (with respect to the output span)

Effect on current $\leq 0.1 \%$ in load range 0...700 Ω
Effect on voltage $\leq 0.1 \%$ from 10 k Ω ... ∞

Parasitic voltage in input (with respect to the span set)

50 Hz symmetrical
< 0.5 % for $U_{\text{para. (ss)}} = 0.3 \times \text{span}$ ($\tau = 0 \text{ s}$)
(elevated residual ripple)
< 0.5 % for $U_{\text{para. (ss)}} = 4 \times \text{span}$ ($\tau \geq 0.9 \text{ s}$)

50 Hz unsymmetrical (to $U_{\text{eff}} = 250 \text{ V}$) (for TEU421)
< 0.006 % \times full scale / span ($\tau \geq 0.9 \text{ s}$)
< 0.05 % \times full scale / span ($\tau = 0 \text{ s}$)

DC component of fault voltage (to U- = 250 V DC)

< 0.006 % \times full scale / span ($\tau \geq 0.9 \text{ s}$)
< 0.05 % \times full scale / span ($\tau = 0 \text{ s}$)

Time behavior

Response time (damping not active)

Typically 0.8 s (1 s max.)

Electromagnetic compatibility (EMC) according to DIN EN 61326

General immunity to interference meets NAMUR recommendations for:

- mains supply tolerances
- mains interruption (max. 1 relay active)

General and safety data
Environment conditions
Climatic category

JSF to DIN 40 040

Ambient temperature

-10...+20 °C...+70 °C

Permissible ambient temperature of an equipped 19" subrack

≤ 60 °C

Transportation and storage temperature

-25...+85 °C

Relative humidity

≤ 75 %

Condensation

None

Mechanical stress
Tested

to DIN IEC 68 Part 2-27 and DIN IEC 68 Part 2-6

During transportation

Shock 30g/18 ms

During operation

Vibration 2g / ± 0.15 mm / 5...150 Hz 3 × 5 cycles

Vibration 2g / ± 10 mm / 1...35 Hz 3 × 1 cycle

Connection, housing and mounting

Electrical connections	32-pole blade connector strip accord. to DIN 41 612 design D or F
Degree of protection (DIN 40 050)	IP 00 (19" version) IP 20 (IP 20 version)
Class of protection accord. to IEC 1010-1 (correspond to DIN EN 61010-1 and DIN VDE 0411 part 1)	I
Degree of contermination	II
Overvoltage category	II Input/output III Mains
Test voltage accord. to IEC 1010-1 (correspond to DIN EN 61010-1 and DIN VDE 0411 part 1)	Mains against input/output 3.71 kV ⁶⁾ Input against output 3.71 kV Outputs against each other 0.75 kV Input/output/mains against protective conductor 1.5 kV
Material	Polycarbonat GV
Color	RAL 7032
Position of use	Front panel vertical
Weight	approx. 0.6 kg

⁶⁾ Disconnect Y capacitors

Explosion protection

EC type examination certificate

single-channel: PTB 04 ATEX 2062
 two-channel: PTB 04 ATEX 2064

Input circuit, Ex identification

Type of protection intrinsic safety
 TEU421-Ex.A ⚡ II (1) GD [EEx ia] IIC / IIB or
 TEU421-Ex.B ⚡ II (2) GD [EEx ib] IIC / IIB

Ambient temperature

19" plug-in card maximum +70 °C
 Surface-mounting case IP 20 maximum +55 °C (only single-channel)

Mounting

Outside the hazardous area

Maximum transmitter values and permitted connection data see table and EC type examination certificate

Maximum values of the transmitter	Resistance measurement		Thermocouple measurement	
	Ex. A	Ex. B	Ex. A	Ex. B
R	1506 Ω	1506 Ω	1506 Ω	1506 Ω
U _O	8.9 V	8.9 V	8.9 V	8.9 V
I _k	23.9 mA	23.9 mA	23.9 mA	23.9 mA
P	160 mW	160 mW	160mW	160 mW
L _i	330 μH	500 μH	330 μH	500 μH
C _i	397 nF	500 nF	397 nF	500 nF
Perm. L ₀ } II B	4.6 mH	4.5 mH	see EC type examination certificate	
Perm. C ₀	3.7 μF	3.6 μF		
Perm. L ₀ } II C	1.6 mH	1.5 mH		
Perm. C ₀	480 nF	380 nF		

6.3 Packaging

Packaging for transport or return to the manufacturer

If the original packaging material is no longer available, wrap the device in a padded plastic film or corrugated paper board and place it in a box of sufficient size lined with a shock-absorbing material (e.g. foam rubber). The thickness of the shock-absorber should be in accordance with the device weight and the type of shipment.

The box must be handled with care and has to be labeled accordingly.

For overseas shipment always add a desiccant (e.g. silica gel) and wrap the device and the desiccant bag in apolyethylene foil of 0.2 mm. Adapt the amount of desiccant to the packing volume and the expected transport time (at least sufficient for 3 months). Additionally line the box with a layer of union paper.

6.4 Accessories

Accessories	Catalog number
Set of resistors for changing the measuring circuit combinations	345838
Module with 1 relay output	345825
Module with 2 relay outputs	345826

ABB has Sales & Customer Support
expertise in over 100 countries worldwide.

www.abb.com/instrumentation

The Company's policy is one of continuous product
improvement and the right is reserved to modify the
information contained herein without notice.

Printed in the Fed. Rep. of Germany (11.2005)

© ABB 2005



ABB Ltd.

Salterbeck Trading Estate
Workington, Cumbria, CA14 5DS
UK
Tel: +44(0)1946-830-611
Fax: +44(0)1946-832-661

ABB Inc.

125 E. County Line Road
Warminster, PA 18974
USA
Tel: +1 215-674-6000
Fax: +1 215-674-7183

ABB Automation Products GmbH

Borsigstr. 2
63755 Alzenau
Germany
Tel: +49 551 905-534
Fax: +49 551 905-555
CCC-support.deapr@de.abb.com