

Vmax

Medium voltage vacuum circuit-breaker

ANSI: ... 15 kV; ... 1200 A; ... 31.5 kA

For your safety!

1. Foreword	2
1.1. Introduction	2
1.2. Environmental protection programme	2
1.3. Vacuum interrupter quenching principle	2
1.4. Information on this booklet	3
1.5. Drawout	3
1.6. Standard fixed	3
1.7. Application of the X-ray emission Standards	3
2. Introduction and safe practices	4
2.1. Introduction	4
2.2. Safe practices	4
2.3. Standard and regulations	5
3. Receiving, handling, and storage	6
3.1. Receiving	6
3.2. Handling	7
3.3. Storage	8
4. Description	9
4.1. General	9
4.2. Reference Standards	9
4.3. Fixed circuit-breaker	9
4.4. Characteristics of the electrical accessories	13
4.5. Preliminary operations	14
4.6. Putting into service	18
4.7. Standard fittings for circuit-breaker	27
5. Operation, installation and maintenance	28
5.1. Interlocks	28
5.2. Maintenance	30
5.3. Truck	35
6. Servicing	38
6.1. Interruption devices in general	38
6.2. Actuator and transmission system	38
6.3. Servicing details	38
6.4. Vacuum interrupters	38
7. Spare parts and accessories	39
7.1. List of spare parts	39
8. Overall dimensions	40
9. Electric circuit diagram	42
10. Product quality and environmental protection	48



For your safety!

- Make sure that the installation room (spaces, divisions and ambient) is suitable for the electrical apparatus.
- Check that all the installation, putting into service and maintenance operations are carried out by qualified personnel with suitable knowledge of the apparatus.
- Make sure that the standard and legal prescriptions are complied with during installation, putting into service and maintenance, so that installations according to the rules of good working practice and safety in the work place are constructed.
- Strictly follow the information given in this instruction manual.
- Check that the rated performance of the apparatus is not exceeded during service.
- Check that the personnel operating the apparatus have this instruction manual to hand as well as the necessary information for correct intervention.
- Pay special attention to the notes indicated in the manual by the following symbol:



**RESPONSIBLE BEHAVIOUR SAFEGUARDS
YOUR OWN AND OTHERS' SAFETY!
FOR ANY REQUESTS, PLEASE CONTACT
THE ABB ASSISTANCE SERVICE.**

1. Foreword

1.1. Introduction

This publication contains the information needed to install medium voltage Vmax/W and Vmax circuit-breakers and put them into service.

For correct use of the product, please read it carefully.

Like all the apparatus we manufacture, the Vmax/W and Vmax circuit-breakers are designed for different installation configurations.

However, they do allow further technical and construction modifications (at the customer's request) to adapt to special installation requirements.

For this reason, the information given below may sometimes not contain instructions concerning special configurations.

Apart from this manual, it is therefore always necessary to consult the latest technical documentation (circuit and wiring diagrams, assembly and installation drawings, any protection coordination studies, etc.), especially regarding any variants requested in relation to the standardised configurations.

For example, the racking and interlock sections do not apply to the fixed mount breaker styles. All information in this booklet was current at the time of printing. Unless otherwise noted, all references in this booklet are determined by viewing the circuit-breaker from the front.

Only use original spare parts for maintenance operations.

For further information, please also see the technical catalogue of the circuit-breaker.

1.2. Environmental protection programme

The Vmax/W and Vmax circuit-breakers are manufactured in accordance with the ISO 14000 Standards (Guidelines for environmental management).

The production processes are carried out in compliance with the Standards for environmental protection in terms of reduction in energy consumption as well as in raw materials and production of waste materials. All this is thanks to the medium voltage apparatus manufacturing facility environmental management system.

1.3. Vacuum interrupter quenching principle

Due to the extremely low static interrupter chamber pressure of 10⁻⁴ to 10⁻⁸ mbar, only a relatively small contact gap is required to achieve a high dielectric strength. The vacuum arc is extinguished on one of the first natural current zeros. Due to the small contact gap, high conductivity of the metal vapour plasma, and short arcing time, the associated arc energy is extremely low, which has advantageous effects on the life of the contacts and thus on that of the vacuum interrupters.



1.4. Information on this booklet

This booklet provides information for the Vmax/W and Vmax circuit-breakers as described below. Not all sections of the bulletin apply to all types of Vmax/W and Vmax circuit-breakers. All information in this booklet was current at the time of printing. Unless otherwise noted, all references in this booklet are determined by viewing the circuit-breaker from the front.

Style	Frame width	Voltage rating	Continuous current rating	Interruption ratings (symmetrical RMS)	Configurations available
Vmax/w	492 mm / 19.3 inches	15 kV	1200 A	25 - 31.5 kA	Drawout
Vmax	416 mm / 16.3 inches	15 kV	1200 A	25 - 31.5 kA	Standard fixed

1.5. Drawout

A Drawout circuit-breaker is a breaker that may be removed from a cell without unbolting connections or mounting supports. It is intended for use in ABB PowerCube modules. It contains primary and secondary disconnects and provides two operating positions: Disconnect and Connect.

1.6. Standard fixed

A fixed circuit-breaker is a breaker that is bolted in its enclosure and wired to the load frame. A fixed circuit-breaker can be mounted directly on supporting frames or on a supporting truck to be provided by the customer. The circuit-breaker, with supporting truck, must be suitably fixed to the floor of its own compartment by the customer. The floor surface in correspondence with the truck wheels must be carefully levelled. A minimum degree of protection (IP2X) must be guaranteed from the front towards live parts. The standard fixed version of Vmax must be installed by the customer in a minimal enclosure so as to guarantee a minimum degree of protection as for C37.20.2 and C37.55 test requirements.

1.7. Application of the X-ray emission Standards

One of the physical properties of vacuum insulation is the possibility of X-ray emission when the interrupter contacts are open.

The specific tests carried out at the PTB laboratories (Physikalisch-Technische Bundesanstalt, in Brunswick - Germany) show that local emission at a distance of 10 cm from the interrupter or pole surface, does not exceed 1 mSv/h.

It follows that:

- at the rated service voltage the use of vacuum interrupters is absolutely safe;
- application of the withstand voltage at industrial frequency, according to the IEC 62271-100, VDE 0670 and IEEE C37.04 Standards, is safe;
- application of a voltage higher than the withstand voltage at industrial frequency or of a direct current test voltage in direct current, specified in the IEC, VDE and ANSI/IEEE Standards, cannot be used;
- limitation of the above-mentioned local phenomena, with interrupters with open contacts, depends on keeping the specified distance between the contacts.


This condition is intrinsically guaranteed by correct operation of the operating mechanism and by adjustments of the transmission system.

2.Introduction and safe practices

2.1. Introduction

The purpose of this manual is to provide instructions for unpacking, storage, installation, operation, and maintenance for Vmax/W and Vmax vacuum circuit-breakers. This manual should be carefully read and used as a guide during installation, initial operation, and maintenance.

The specific ratings of each model circuit-breaker are listed on the individual nameplates. The Vmax/W and Vmax circuit-breakers are protective devices. As such, they are maximum rated devices. In no event should they be applied outside of their nameplate ratings.

WARNING

THE CIRCUIT-BREAKERS DESCRIBED IN THIS BOOK ARE DESIGNED AND TESTED TO OPERATE WITHIN THEIR NAMEPLATE RATING. OPERATION OUTSIDE OF THESE RATINGS MAY CAUSE EQUIPMENT TO FAIL, RESULTING IN PROPERTY DAMAGE, BODILY INJURY AND/OR DEATH.

ALL SAFETY CODES, SAFETY STANDARDS AND/OR REGULATIONS AS THEY MAY BE APPLIED TO THIS TYPE OF EQUIPMENT MUST BE ADHERED TO STRICTLY.

2.2. Safe practices

Vmax/W and Vmax circuit-breakers are equipped with high energy / high speed mechanisms. The design includes several interlocks and safety features which help ensure safe and proper operating sequences. To ensure safety of personnel associated with installation, operation, and maintenance of these circuit-breakers, the following recommendations must be followed.

Only qualified persons, as defined in the National Electric Safety Code, who are familiar with the installation and maintenance of medium voltage circuits and equipment should be permitted to work on these circuit-breakers

Read these instructions carefully before attempting any installation, operation, or maintenance of these power circuit-breakers.

Do not work on an energized circuit-breaker.

Do not work on a circuit-breaker unless all components are disconnected by means of a visible break and securely grounded.

Do not work on a circuit-breaker with power supplied to the secondary control circuit.


Do not defeat safety interlocks. This may result in bodily injury, death and/or equipment damage.

Do not work on a closed circuit-breaker.

Do not work on a circuit-breaker with charged energy (springs charged).

Do not use a circuit-breaker by itself as the sole means of isolating a high voltage circuit.

Do not leave a circuit-breaker in an intermediate position in a cell. Always place the circuit-breaker in the disconnect or connect position.

NOTICE

FAILURE TO OBSERVE THE REQUIREMENTS OF OSHA STANDARD 1910.269 CAN CAUSE DEATH OR SEVERE BURNS AND DISFIGUREMENT. THAT STANDARD SPECIFICALLY PROHIBITS THE WEARING OF POLYESTER, ACETATE, NYLON, OR RAYON CLOTHING BY EMPLOYEES WORKING WITH EXPOSURE TO ELECTRIC ARCS OR FLAMES.

2.3. Standard and regulations

2.3.1. Fabrication

The Vmax, Vmax/W circuit-breakers conform to the following Standards:

- DIN VDE 0670, part 104, and IEC 62271-100
- DIN VDE 0847, part 4, and IEC 61000-4
- IEEE C37.04

2.3.2. Installation and operation

For assembly and operation, please refer to the relative regulations, and in particular to:

- ANSI / NFPA70
- NEC

2.3.3. Service conditions

Normal service conditions

Follow the recommendations in the IEC 62271-1 and 62271-100 Standards. In more detail:

IEEE C37.09

IEEE C37.54 – C37.20.2.

Ambient temperature

Maximum + 40 °C

Average maximum over 24 hours + 35 °C

Minimum for indoor installation - 30 °C

Humidity

The average value of the relative humidity, measured for a period longer than 24 hours, must not exceed 95%

The average value of the pressure of the water vapour without condensation, measured for a period longer than 24 hours, must not exceed 2.2 kPa.

The average value of the relative humidity, measured for a period longer than 1 month, must not exceed 90%.

The average value of the pressure of the water vapour, measured for a period longer than 1 month, must not exceed 1.8 kPa.

Altitude

≤ 1000 (3300 ft.) m above sea level.

For application above 1000m (3300 ft.) C37.20.2 is applicable

Climate

To avoid the risk of corrosion or other damage in areas:


- with a high level of humidity, and/or
 - with rapid and large temperature variations, take appropriate steps (for example, by using suitable electric heaters) to prevent condensation phenomena.
-

For special installation requirements or other operating conditions, please contact ABB.

3. Receiving, handling, and storage

Vmax/W and Vmax circuit-breakers are subject to complete factory production tests and inspection prior to packaging and shipment. The shipping package is designed to provide reasonable protection during shipment and to provide convenient handling. Accessories such as opening handles and racking handles are shipped separately from the circuit-breaker. The circuit-breaker is shipped in special packing, in the open position.

Each piece of apparatus is protected by a plastic cover to prevent any infiltration of water during the loading and unloading stages and to keep the dust off during storage.



3.1. Receiving

On receipt, check the state of the apparatus, integrity of the packing and correspondence with the nameplate data (see fig. 1) with what is specified in the order confirmation and in the accompanying shipping notes.

Also make sure that all the materials described in the shipping notes are included in the supply.


Should any damage or irregularity be noted in the supply on unpacking, notify ABB (directly or through the agent or supplier) as soon as possible and in any case within five days of receipt. The apparatus is only supplied with the accessories specified at the time of ordering and validated in the order confirmation sent by ABB.

The accompanying documents inserted in the shipping packing are:

- instruction manual (this document)
- test certification
- identification label
- copy of the shipping documents
- electric wiring diagram.

Other documents which are sent prior to shipment of the apparatus are:

- order confirmation
- original shipping advice notes
- any drawings or documents referring to special configurations/conditions.



Caption

- A Circuit-breaker rating plate.
- B Operating mechanism rating plate.
- 1 Type of apparatus.
- 2 Symbols of compliance with Standards.
- 3 Serial number.
- 4 Circuit-breaker characteristics.
- 5 Characteristics of the operating mechanism auxiliaries.

Fig. 1

Immediately upon receipt of the circuit-breaker(s), examine the carton(s) to determine if any damage or loss was sustained during transit. If damage or indication of rough handling is evident, file a damage claim at once with the carrier and promptly notify the nearest district office. ABB is not responsible for damage to goods which occur after delivery. However, ABB will lend assistance if notified of claims. Use care in unpacking the circuit-breaker to avoid damaging any circuit-breaker parts.

Unpack circuit-breakers as soon as possible after receipt. If unpacking is delayed, difficulty may be experienced in making a claim for damages not evident upon receipt. Check the contents of each carton against the packing list before discarding any packing material. If any discrepancy is discovered, promptly notify the nearest district office. Information specifying the purchase order number, carton number, and part numbers of damaged or missing parts should accompany the claim.

3.2.Handling

Vmax/W and Vmax circuit-breaker shipping containers are designed to be handled by fork lift (not supplied) Fig. 2. To lift and handle the circuit-breaker, proceed as follows (fig. 2):

- use a special lifting tool (1) (not supplied) fitted with ropes with safety hooks (2);
- insert the hooks (2) in the special holes in the circuit-breaker frame and lift;
- on completion of the operation (and in any case before putting into service) unhook the lifting tool.

During handling, take great care not to stress the insulating parts and the terminals of the circuit-breaker.




Fig. 2

Once removed from the shipping container, the circuit-breaker wheels are designed to move the circuit-breaker across a smooth, paved surface.

Care must be taken not to damage the secondary plug (item 3, Figure 2a) when transporting, rolling, or handling the Vmax/W circuit-breakers.



Fig. 2a

DO NOT pull the circuit-breaker by the front handles with the circuit-breaker in any position other than full Disconnect to avoid injuries at the hands.

DO NOT move the circuit-breaker by pushing on the pole box or primary leads of the embedded poles. Damage and misalignment of the poles and contact arms assemblies will occur if force is applied to them.

3.3. Storage

When a period of storage is foreseen, our workshops can (on request) provide suitable packing for the specified storage conditions.

On receipt the apparatus must be carefully unpacked and checked as described in Checking on receipt.

If immediate installation is not possible, the packing must be replaced, using the original material supplied.

Insert special hygroscopic substances inside the packing, using at least one standard packet per piece of apparatus.

Should the original packing not be available and immediate installation is not possible, store in a covered, well-ventilated, dry, dust-free, non-corrosive ambient, away from any flammable materials and at a temperature between $-30\text{ }^{\circ}\text{C}$ and $+45\text{ }^{\circ}\text{C}$.

Circuit breakers should be installed in their permanent location as soon as possible. If the circuit-breakers are not placed in service for some time, it is advisable to provide adequate means of environmental protection. This may be done by keeping the circuit-breaker in its original shipping container and storing it in a warm, dry, and uncontaminated atmosphere. The circuit-breakers should be stored to minimize condensation. Moisture can cause deterioration of metal parts and high voltage insulation.

Prior to storage of the circuit-breaker, verification should be made that it is free from shipping damage and is in satisfactory operating condition.



4. Description

4.1. General

The Vmax series of circuit-breakers are pieces of apparatus under vacuum for indoor installation; for the electrical performances, please refer to the corresponding technical catalogue code 1VCP000408. For special installation requirements, please contact ABB.

The following versions are available:

- fixed
- withdrawable for ABB PowerCube modules.




Fig. 3




Fig. 4




Fig. 5

4.2. Reference Standards


The Vmax circuit-breakers conform to the IEC 62271-100, ANSI C37.04 – C37.54 – C37.09 – C37.55 Standards and those of major industrialized countries.

4.3. Fixed circuit-breaker

The fixed circuit-breaker (fig. 3-4) is the basic version complete with structure and front protection screen. The fixing holes are made in the lower part of the structure.

For the electrical connections of the circuit-breaker auxiliary circuits, the proper terminal box is available.

The earthing hole is placed in the rear part of the circuit-breaker.



- 1 Lever for manual closing spring charging
- 2 Signalling device for circuit-breaker open/closed
- 3 Rating plate
- 4 Opening pushbutton
- 5 Closing pushbutton
- 6 Undervoltage release mechanical override (on request)
- 7 Signalling device for closing springs charged/discharged
- 8 Operation counter
- 9 Terminals
- 10 Earthing hole
- 11 Passage for the auxiliary circuit cord
- 12 Auxiliary contacts

Fig. 6

4.3.1. General characteristics of fixed circuit-breakers Vmax




Standard fittings for fixed circuit-breakers

The basic versions of the fixed circuit-breakers are three-pole and fitted with:

- EL type manual operating mechanism
 - mechanical signalling device for closing springs charged/ discharged
 - mechanical signalling device for circuit-breaker open/closed
 - closing pushbutton
 - opening pushbutton
 - operation counter
 - set of ten circuit-breaker open/closed auxiliary contacts
- Note:** application of the shunt opening release and/or additional shunt opening release foresees the use of one or two auxiliary make contacts (normally open), thereby reducing the number of auxiliary contacts available.
- lever for manual closing spring charging
 - auxiliary circuit support terminal board

Circuit-breaker		Vmax 15
Fixed version		•
Standards	IEC 62271-100	•
	CEI EN62271-100 (file 7642)	•
	C37.54 - C37.09 - C37.04 - C37.55	•
	UL Recognized Component Mark	•
Rated voltage	Ur [kV]	15
Rated insulation voltage	Us [kV]	15
Withstand voltage at 50 Hz	Ud (1 min) [kV]	36 (at 60 Hz)
Impulse withstand voltage	Up [kV]	95
Rated frequency	fr [Hz]	60
Rated normal current (40 °C)	Ir [A]	1200
Rated breaking capacity (rated symmetrical short-circuit current)	Isc [kA]	25 (3 cycles)
		31.5 (3 cycles)
Rated-short time withstand current (2s)	Ik [kA]	25
		31.5
Making capacity	Ip [kA]	65
		82
Operation sequence	[O - 0.3" - CO - 15" - CO]	-
	[O - 0.3" - CO - 3' - CO]	•
Opening time	[ms]	27 ... 32.5
Arc duration	[ms]	10 ... 17.5
Total interruption time	[ms]	<50
Closing time	[ms]	45 ... 80
Maximum overall dimensions	H [mm/in]	534/21.02
	W [mm/in]	416/16.38
	D [mm/in]	456/17.95
	Pole centre I [mm/in]	133/5.24
	Weight	[kg/lb]
Standardized table of dimensions		1VCD003279
Operating temperature	[°C]	-30 ... +40
Tropicalization	IEC: 60068-2-30, 60721-2-1	-
Electromagnetic compatibility	IEC 62271-1	-



4.3.2. Withdrawable circuit-breaker

The withdrawable circuit-breakers (see fig. 7) are available for ABB PowerCube modules.

They consist of a truck on which the supporting structure of the circuit-breaker is fixed.

The cord with the connector (14) (plug) for connection of the operating mechanism electrical accessories comes out of the connection (15).

The strikers for operating the contacts (racked-in/isolated) placed in the switchgear are fixed in the top part of the circuit-breaker.

The slides (9) for operating the segregation shutters of the medium voltage contacts of the enclosure or of the switchgear are fixed on the sides of the circuit-breaker.

On the front part of the circuit-breaker truck, the crosspiece is mounted with the handles (17) for hooking up the circuit-breaker for the racking-in/out operations by means of the special operating lever (16). The circuit-breaker is completed with the isolating contacts (8).

The withdrawable circuit-breaker is fitted with special locks on the front crosspiece, which allow hooking up into the corresponding couplings of the switchgear.


The locks can only be activated by the handles with the truck fully resting against the crosspiece.

The operating lever (16) must be fully inserted (also see par. 4.6.6. - 4.6.7.). A lock prevents the truck from advancing into the enclosure or fixed part when the earthing switch is closed.

Another lock prevents racking-in and racking-out with the circuit-breaker closed. With the truck in an intermediate position between isolated and racked-in, a further lock prevents circuit-breaker closing (either mechanical or electrical).

A locking magnet is also mounted, on request, on the truck which, when de-energised, prevents the truck racking-in operation.

On request, an interlock is also available which prevents circuit-breaker racking-in with the door open, and door opening with the circuit-breaker closed.



- 1 Lever for manually charging the closing springs
- 2 Signalling device for circuit-breaker open/closed
- 3 Rating plate
- 4 Opening pushbutton
- 5 Closing pushbutton
- 6 Signalling device for closing springs charged/discharged
- 7 Operation counter
- 8 Isolating contacts
- 9 Slide for operating the switchgear shutters

- 10 Truck
- 11 Tab for hooking into the fixed part
- 12 Undervoltage release mechanical override (on request)
- 13 Strikers for activating the contacts placed in the enclosure
- 14 Connector (plug)
- 15 Cabling connection
- 16 Operating lever of circuit-breaker racking-in/out.
- 17 Handles for activating the locks (11)
- 18 Truck locator channel

Fig. 7

4.3.3. General characteristics of withdrawable circuit-breakers (15 kV) for PowerCube PB1 modules 600 mm wide




Standard fittings for withdrawable circuit-breakers for PowerCube PB1 modules 600 mm wide

The basic versions of the withdrawable circuit-breakers are three-pole and fitted with:

- EL type manual operating mechanism
- Mechanical signaling device for closing springs charged/discharged
- Mechanical signaling device for circuit-breaker open/closed
- Closing and opening pushbutton
- Operation counter
- Set of ten auxiliary circuit-breaker open/closed contacts
- Lever for manually charging the closing springs
- Isolating contacts

Circuit-breaker		Vmax/W 15
Use in switchgear/enclosure		PowerCube
Standards	IEC 62271-100	•
	CEI EN62271-100 (file 7642)	•
	C37.54 - C37.09 - C37.04 - C37.55	•
	UL Listed	(on request)
Rated voltage	Ur [kV]	15
Rated insulation voltage	Us [kV]	15
Withstand voltage at 50 Hz	Ud (1 min) [kV]	36 (at 60 Hz)
Impulse withstand voltage	Up [kV]	95
Rated frequency	fr [Hz]	60
Rated normal current (40°C)	Ir [A]	1200
Rated breaking capacity (rated symmetrical short-circuit current)	Isc [kA]	25 (3 cycles)
		31.5 (3 cycles)
Rated-short time withstand current (2s)	Ik [kA]	25
		31.5
Making capacity	Ip [kA]	65
		82
Operation sequence	[O - 0.3" - CO - 15" - CO]	-
	[O - 0.3" - CO - 3' - CO]	•
Opening time	[ms]	27 ... 32.5
Arc duration	[ms]	10 ... 17.5
Total interruption time	[ms]	<50
Closing time	[ms]	45 ... 80
Maximum overall dimensions	H [mm/in]	665/26.18
	W [mm/in]	503/19.80
	D [mm/in]	662/26.06
	Pole centre I [mm/in]	150/5.91
Weight	[kg/lb]	98/215.60
Standardized table of dimensions		1VCD003280
Operating temperature	[°C]	-30 ... +40
Tropicalization	IEC: 60068-2-30, 60721-2-1	-
Electromagnetic compatibility	IEC 62271-1	-



- Cord with connector (plug only) for auxiliary circuits, with striker pin on request, which does not allow connection of the plug in the socket if the rated current of the circuit-breaker is different from the rated current of the panel
- Racking-in/out lever (the quantity must be defined according to the number of pieces of apparatus ordered)
- Locking electromagnet in the truck. On request. This prevents racking-in of the circuit-breaker in the panel with auxiliary circuits not connected (plug not inserted in the socket).

4.4. Characteristics of the electrical accessories

Shunt opening release (-MO1)

Additional shunt opening release (-MO2)

Shunt closing release (-MC)

Undervoltage release (-MU)

Locking magnet on the operating mechanism (-RL1)

Un		24 - 30 - 48 - 60 V DC-AC (50-60 Hz)	110 - 132 - 220 - 250 V DC-AC (50-60 Hz)
Operating limits	-MO1-MO2-MC	65 ... 120 % Un	
	-MU	35 ... 85 % Un	
	-RL1	85 ... 110 % Un	
Opening time	-MO1-MO2	27...32.5 ms	
	-MC	45...80 ms	
	-MU	60...60 ms	
Power on inrush (Ps)	< 150 W		
Inrush duration	150 ms		
Continuous power (Pc)	3 W		
Insulation voltage	2000 V 50/60 Hz (for 1 min)		

Electronic time delay device for undervoltage release (mounted outside the circuit-breaker)

Un: 24 ... 30 - 48 - 60 - 110 ... 127 - 220 ... 250 V-
Un: 48 - 60 - 110 ... 127 - 220 ... 240 V~ 50/60 Hz
Adjustable opening time (release + time delay device): 0.5-1-1.5-2-3 s

Auxiliary contacts of the circuit-breaker (-BB1; -BB2; -BB3)

General characteristics	
Insulation voltage according to VDE 0110 standard. Group C	660 V AC 800 V DC
Rated voltage	24 V ... 660 V
Test voltage	2.2 kV
Rated overcurrent	10 A
Number of contacts	5
Contact run	6 mm ... 7 mm
Activation force	26 N
Resistance	3 mΩ
Storage temperature	-20 °C ... +120 °C
Operating temperature	-20 °C ... +70 °C
Contact overtemperature	20 K
Number of cycles	30,000
Unlimited breaking capacity if used with 10 A fuse in series	

Note: Application of the shunt opening release and/or additional shunt opening release foresees the use of one or two auxiliary make contacts (normally open), thereby reducing the number of auxiliary contacts available.

Electrical characteristics

Un		Rated current	Breaking capacity
220 V AC	Cosφ = 0,7	2.5 A	25 A
380 V AC	Cosφ = 0,7	1.5 A	15 A
500 V AC	Cosφ = 0,7	1.5 A	15 A
660 V AC	Cosφ = 0,7	1.2 A	12 A
Time constant			
24 V DC	1 ms	10 A	12 A
	15 ms	10 A	12 A
	50 ms	8 A	10 A
	200 ms	6 A	7.7 A
60 V DC	1 ms	8 A	10 A
	15 ms	6 A	8 A
	50 ms	5 A	6 A
	200 ms	4 A	5.4 A
110 V DC	1 ms	6 A	8 A
	15 ms	4 A	5 A
	50 ms	2 A	4.6 A
	200 ms	1 A	2.2 A
220 V DC	1 ms	1.5 A	2 A
	15 ms	1 A	1.4 A
	50 ms	0.75 A	1.2 A
	200 ms	0.5 A	1 A

Motor operator (-MS)

Un:	24 ... 30 - 48 ... 60 - 110 ... 130 - 220 ... 250 V-
Un:	100 ... 130 - 220 ... 250 V~ 50/60 Hz
Operating limits:	85 ... 110 % Un
Inrush power (Ps):	DC 600 W; AC = 600 VA
Rated power (Pn):	DC = 200 W; AC = 200 VA
Inrush time	0,2 s
Charging time:	6-7 s
Insulation voltage:	2000 V 50 Hz (for 1 min)

Locking magnet on the truck (-RL2)

Un:	24 - 30 - 48 - 60 - 110 - 125 - 127 - 132 - 220 - 240 V-
Un:	24 - 30 - 48 - 60 - 110 - 125 - 127 - 220 - 230 ... 240 V~ 50/60 Hz
Operating limits:	85 ... 110% Un
Inrush power (Ps):	DC 250 W; AC = 250 VA
Continuous power (Pc):	DC = 5 W; AC = 5 VA
Inrush time:	150 ms

4.5. Preliminary operations

Clean the insulating parts with clean dry cloths.

Check that the top and bottom terminals are clean and free of any deformation caused by shocks received during transport or storage.

4.5.1. Installation of fixed circuit-breakers

Vmax circuit-breaker can be fixed directly on the supporting plate or on a truck provided by the customer. The customer must guarantee a minimum degree of protection (IP2X) from the front towards live parts. The fixed version of Vmax circuit-breaker must be installed by the customer so as to guarantee a minimum degree of protection as for C37.20.2 and C37.55 test requirements.

4.5.2. Insertion and removal withdrawable circuit-breaker

This section describes the process for inserting the breaker into the disconnect position of the switchgear and the removal of the circuit-breaker from the disconnect position. Racking of the circuit-breaker to and from the test and disconnect position is covered in the following section.

Insertion (Refer to Fig. 7 and 13)

(From Withdrawn Position to Disconnect Position)

1. Align breaker and ramp, dolly or lift truck with circuit-breaker compartment
2. Pull handles (17) to center (this withdraws Cell Interlock Tabs (11) allowing breaker to be inserted)
3. Push breaker into breaker compartment with handles.
4. Align Cell Interlock Tabs with Circuit Breaker Compartment Slots (A)
5. Push Handles out to fully engage Cell Interlock Tabs into Circuit Breaker Compartment Slots
6. Visually check that Cell Interlock Tabs are engaged in Circuit-Breaker Compartment Slots (if Cell Interlock Tabs are not fully extended, racking is prevented) Breaker is now in the Disconnect Position

Removal (Refer to Fig. 7 and 14)

(From Disconnect Position to Withdrawn Position)

1. Visually check to see the Truck (11) is against the Locator Channel
2. Pull Handles to center (this withdraws Cell Interlock Tabs; allowing breaker to be removed .
4. Pull the breaker from Circuit-Breaker Compartment with the Handles onto the required transportation device.

4.5.3. Withdrawable circuit-breakers with truck made by third parties

The Vmax circuit-breakers installed on trucks made by the customer must be fitted with one or two additional auxiliary contacts (operated by the mechanical lock and by the circuit-breaker release device) which are entrusted with the function of interrupting the shunt closing release circuit (-MC).

In this way it is certain that no electrical impulse can activate the shunt closing release with the circuit-breaker in an intermediate position.

The customer must also provide a lock to prevent circuit-breaker traverse when it is in the closed position.

4.5.4. Installation of withdrawable circuit-breakers in ABB PowerCube modules

The withdrawable circuit-breakers are use in PowerCube modules see Fig. 13 - 14.

For racking-in/racking-out of the switchgear: connect the secondary plug (14) (fig. 7) with secondary disconnecter (B) (fig.14) , fully insert the crank handle (1) (fig. 11 in the appropriate seat) (2) (fig.11) and work it clockwise for racking-in, and anti-clockwise for racking-out, until the end-of-run positions are reached.

Circuit-breaker racking- in/-out must be carried out gradually to avoid shocks which may deform the mechanical interlocks and the end-of-runs.

The torque normally required to carry out racking- in and racking-out is <25 Nm.

This value must not be exceeded. If operations are prevented or difficult, do not force them and check that the operating sequence is correct.

Note

To complete the racking-in/out operation, 20 turns of the crank handle are required.

When the circuit-breaker has reached the connect/ disconnect position it can be considered as racked into the switchgear and, at the same time, earthed by means of the truck wheels.



4.5.5. Connection of the auxiliary circuits

Note: the minimum cross-section of the wires used for the auxiliary circuits must not be less than the one used for the internal cabling AWG16. Furthermore, they must be insulated for 3 kV test.

Please note that auxiliary circuits must be energized with 2 kV (maximum test voltage) as per standards indications.

Connection of the auxiliary circuit for Vmax Fixed circuit-breaker

Connection of the circuit-breaker auxiliary circuits must be made by means of the proper terminal box mounted inside the circuit-breaker and the wires must pass through the connector (1) (Fig. 8). Outside the connector, the cables must pass through a suitable metal protective covering (pipe, wiring duct, etc.) and be earthed.

To prevent the cabling wires outside the circuit-breaker (provided by the customer) from accidentally coming into contact with moving parts and therefore damaging the insulation, the wires should be positioned and fixed as shown in the figure 8.

Before removing the operating mechanism cover (1) (Fig. 9) to access the terminal box, check that the circuit-breaker is open and the closing springs discharged.




Fig. 8

4.5.6. Withdrawable circuit-breakers

The auxiliary circuits of withdrawable circuit-breakers are fully cabled in the factory as far as the connector (2 - fig. 9). For the external connections, refer to the electric wiring diagram of the switchgear.



Fig. 9

4.5.7. Power circuit connections of fixed circuit-breakers Vmax

- General recommendations
- Select the cross-section of the conductors according to the service current and the short circuit current of the installation.
- Prepare special supporting insulators, near the terminals of the fixed circuit-breaker or of the enclosure, sized according to the electro-dynamics forces deriving from the short-circuit current of the installation.

Assembly of the connections

- Check that the contact surfaces of the connections are flat, and are free of any burrs, traces of oxidation or deformation caused by drilling or impacts received.
- According to the conductor material and the surface treatment used, carry out the operations indicated in table T1 on the contact surface of the conductor.
- Assembly procedure
- Put the connections in contact with the circuit-breaker terminals taking care to avoid mechanical stresses (traction / compression) on, for example, the conducting busbars on the terminals.
- Interpose a spring washer and a flat washer between the head of the bolt and the connection.
- It is advisable to use bolts according to DIN class 8.8 Standards, also referring to what is indicated in table T2.
- In the case of cable connections, strictly follow the manufacturer's instructions to make the terminals.

Earthing

For the fixed version circuit-breaker, carry out earthing by means of the special screws marked with the relative symbol (see fig. 10).
Clean and degrease the area around the screw to a diameter of about 30 mm and, on completion of assembly, cover the joint again with Vaseline grease.
Use a conductor (busbar or cord) with a cross section conforming to the Standards in force.

Assembly procedure

- Put the connections in contact with the circuit-breaker terminals taking care to avoid mechanical stresses (traction / compression) on, for example, the conducting busbars on the terminals.

T1

Bare copper

- Clean with a fine file or emery cloth.
- Tighten fully and cover the contact surfaces with 5RX Moly type grease.

Copper or silver-plated aluminium

- Clean with a rough dry cloth.
- Only in the case of obstinate traces of oxidation, clean with a very fine grain emery cloth taking care not to remove the surface layer.
- If necessary, restore the surface treatment.

Bare aluminium

- Clean with a metal brush or emery cloth.
- Cover the contact surfaces again immediately with neutral grease.
- Insert the copper-aluminium bimetal with surfaces shined (copper side in contact with the terminal; aluminium side in contact with the connection) between the aluminium connection and the copper terminal.

T2

Bolt	Recommended tightening torque (1)	
	Without lubricant	With lubricant (2)
M6	10.5 Nm	4.5 Nm
M8	26 Nm	10 Nm

(1) The nominal tightening torque is based on a friction coefficient of the thread of 0.14 (distributed value the thread is subjected to which, in some cases, is not negligible).


The nominal tightening torque with lubricant is according to the DIN 43673 Standards.

(2) Oil or grease. The thread and contact surfaces of the lubricated heads.

Take into account the deviations from the general Standards table (for example, for contact systems or terminals) as foreseen in the specific technical documentation.

The thread and contact surfaces of the heads of bolts must be slightly oiled or greased, so as to obtain correct nominal tightening torque.

4.5.8. Operating and signalling parts



- 1 Key lock (if provided) (*)
- 2 Lever for manually charging the closing springs
- 3 Coupling lever for racking-out operation (only for withdrawable circuit-breakers)
- 4 Opening pushbutton
- 5 Closing pushbutton
- 6 Signalling device for circuit-breaker open/closed
- 7 Signalling device for closing springs charged/discharged
- 8 Operation counter
- 9 Handles for operating the truck locks (only for withdrawable circuit-breakers)
- 10 Operating lever for circuit-breaker racking-in/out
- 11 Undervoltage release mechanical override (on request).

(*) Warning! To activate the key lock: open the circuit-breaker, keep the opening pushbutton depressed, then turn the key and remove it from the housing.

Fig. 10

4.6. Putting into service

4.6.1. General procedures

CAUTION


ALL THE OPERATIONS REGARDING PUTTING INTO SERVICE MUST BE CARRIED OUT BY ABB PERSONNEL OR BY SUITABLY QUALIFIED CUSTOMER PERSONNEL WITH IN DEPTH KNOWLEDGE OF THE APPARATUS AND OF THE INSTALLATION. SHOULD THE OPERATIONS BE PREVENTED, DO NOT FORCE THE MECHANICAL INTERLOCKS AND CHECK THAT THE OPERATING SEQUENCE IS CORRECT. THE OPERATING FORCES WHICH CAN BE APPLIED FOR RACKING-IN WITHDRAWABLE CIRCUIT-BREAKERS ARE INDICATED IN PARAGRAPH "INSTALLATION OF WITHDRAWABLE CIRCUIT-BREAKERS".

- check tightness of the power connections at the circuit-breaker terminals;
- check that the value of the power supply voltage of the auxiliary circuits is within limits stated by IEEE C37.06;
- remount any covers removed during the testing operations;
- check that no foreign bodies, such as bits of packing, have got into the moving parts;
- check that there is a sufficient exchange of air in the installation place to avoid over temperatures;
- supply the auxiliary circuits with power;
- check the functionality and efficiency of the mechanical and electrical locks;
- carry out a few circuit-breaker opening and closing operations by means of the pushbuttons on the front of the circuit-breaker;
- also carry out the checks indicated in table T3;
- do not attempt to insert the circuit-breaker into any compartment prior to inspection;
- compare the circuit-breaker name plate rating with the switchgear rating;
- do not attempt to insert a closed circuit-breaker;
- always inspect the circuit-breaker compartment to insure that it is free of obstructions, tools, or other equipment.

T3

Item inspected	Procedure	Positive check
1 Insulation resistance.	Medium voltage circuit With a 2500 V megger, measure the insulation resistance between the phases and the exposed conductive part of the circuit.	The insulation resistance should be at least 50 Mohm and in any case constant over time.
	Auxiliary circuits With a 500 V megger (if the apparatus installed allows this), measure the insulation resistance between the auxiliary circuits and the exposed conductive part.	The insulation resistance should be a few Mohm and in any case constant over time.
2 Auxiliary circuits.	Check that the connections to the control circuit are correct: proceed at the relative power supply.	Operations and signals are normal.
3 Manual operating mechanism.	Carry out a few closing and opening operations (see cap. 6). N.B. Supply the undervoltage release and the locking magnet on the operating mechanism at the relative rated voltage (if provided).	The operations and the relative signals take place normally.
4 Motor operator (if provided).	Supply the spring charging geared motor at the relative rated voltage.	The springs are charged normally. The signals are normal. With the springs charged, the geared motor stops.
	Carry out a few closing and opening operations. N.B. Supply the undervoltage release and the locking magnet on the operating mechanism at the relative rated voltage (if provided).	The geared motor recharges the springs after each closing operation.
5 Undervoltage release (if provided).	Supply the undervoltage release at the relative rated voltage and carry out the circuit-breaker closing operation.	The circuit-breaker closes normally. The signals are normal.
	Cut off power to the release.	The circuit-breaker opens. The signalling changes over.
6 Shunt opening release and additional shunt opening release (if provided).	Close the circuit-breaker and supply the shunt opening release at the relative rated voltage.	The circuit-breaker opens normally. The signals are normal.

Item inspected	Procedure	Positive check
7 Shunt closing release (if provided).	Open the circuit-breaker and supply the shunt closing release at the relative rated voltage.	The circuit-breaker closes normally. The signals are normal.
8 Key lock (if provided).	Open the circuit-breaker, keep the opening pushbutton depressed, then turn the key and remove it from the housing. Attempt the circuit-breaker closing operation.	Neither manual nor electrical closing takes place.
	Put the key back in and turn it 90°. Carry out the closing operation.	Both electrical and manual closing take place normally; in this position the key cannot be removed.
9 Auxiliary contacts in the operating mechanism.	Insert the auxiliary contacts in suitable signalling circuits. Carry out a few closing and opening operations.	Signals take place normally.
10 Undervoltage override (if provided).	With the circuit-breaker open, springs charged, override not connected and undervoltage release not supplied with power, attempt circuit-breaker closing.	Closing is not possible.
11 Locking electromagnet (-RL1) (if provided).	With the circuit-breaker open, springs charged and locking electromagnet not supplied, attempt circuit-breaker closing both manually and electrically.	Closing is not possible.
	Carry out a few closing and opening operations. N.B. Supply the undervoltage release and the locking magnet on the operating mechanism at the relative rated voltage (if provided).	The geared motor recharges the springs after each closing operation.
12 Locking electromagnet on the truck circuit-breaker (-RL2) (if provided).	With the circuit-breaker open, in the isolated for test position and the locking electromagnet not supplied, attempt circuit-breaker racking-in.	Racking-in is not possible.
	Supply the locking electromagnet and carry out the racking-in operation.	Racking-in takes place correctly.
13 Auxiliary transmitted contacts for signalling circuit-breaker racked-in, isolated (UniGear or UniSafe switchgear).	With the circuit-breaker racked into the enclosure, carry out a few traverse operations from the isolated for test position to the connected position. Take the circuit-breaker to the racked-out position.	The signals due to the relative operations take place normally.


DANGER

DO NOT ATTEMPT TO REMOVE THE CIRCUIT-BREAKER FROM THE COMPARTMENT WITHOUT THE REQUIRED RAMP DOLLY ON LINK TRUK. THE CIRCUIT-BREAKER COULD FALL DOWN AND DO INJURIES TO THE BODY. REFER TO THE SPECIFIC SWITCHGEAR INSTALLATION AND MAINTENANCE MANUAL FOR DETAILS.

4.6.2. Safety indications

Vmax circuit-breakers guarantee a minimum IP2X degree of protection when installed in the following conditions:

- fixed circuit-breaker, installed behind a protective metallic net
- withdrawable circuit-breaker, installed in switchgear.

Under these conditions the operator is totally guaranteed against accidental contact with moving parts.

Should mechanical operations be carried out on the circuit-breaker outside the switchgear, be very careful of the moving parts.

If the operations are prevented, do not force the mechanical interlocks and check that the operating sequence is correct. Racking the circuit-breaker in and out of the switchgear must be done gradually to avoid shocks which may deform the mechanical interlocks.

4.6.3. Preliminary operations

- Clean the insulating parts with clean dry cloths.
- Check that the top and bottom terminals are clean and free of any deformation caused by shocks received during transport or storage.

Insertion: (Refer to Fig. 7 and Fig. 13)
(from withdrawn position)

1. Align the circuit-breaker and ramp, dolly or lift truck with the compartment.
2. Pull the handles (17) to center (this withdraws Cell Interlock Tabs (11) allowing the circuit-breaker to be inserted).
3. Push the circuit-breaker into the compartment with the handles.
4. Align the circuit-breaker interlock tabs with the compartment slots (A).
5. Push the handles out to fully engage the cell interlock tabs into the compartment slots.
6. Visually check that cell interlock tabs are engaged in the compartment slots (if cell interlock tabs are not fully extended, racking is prevented).
7. The circuit-breaker is now in the Disconnect position.

Removal: to Withdrawn Position
(Refer to Fig. 7)

1. Visually verify that the truck (10) is against the truck locator channel (18).
2. Pull the handles (17) to the centre.
3. Pull the circuit-breaker from the compartment with the handles onto the required transportation device.
4. The circuit-breaker is now in the withdrawn position.

4.6.4. Racking Vmax/W: (Figure 7)

Vmax/W circuit-breakers are designed with two positive racking positions: Disconnect, Connect. In the Disconnect position the shutters are closed. Manual opening is allowed. Electrical operation of the circuit-breaker is allowed with control power supplied through the secondary contacts with the shutters closed. As the circuit-breaker approaches the Connect position, an increase in racking force is required to lift the shutters and to engage the primary contacts. In the Connect position, the primary disconnects are fully engaged and the shutters are open. Electrical operation of the circuit-breaker through the secondary contacts remains enabled. Close door racking is mandatory between all positions

1. Engage the racking handle (item 1 Figure 11) with the racking screw collar (item c Figure 14).
 - a. CLOCKWISE (cw) rotation inserts the circuit-breaker towards the primary contacts.
 - b. COUNTER-CLOCKWISE (ccw) rotation withdraws the circuit-breaker away from the primary contacts.

Circuit-breaker rack-ing-in/-out must be carried out gradually to avoid shocks which may deform the mechanical interlocks and the end-of-runs. The torque normally required to carry out rack-ing-in and racking-out is <25 Nm. This value must not be exceeded. If operations are prevented or difficult, do not force them and check that the operating sequence is correct.

4.6.5. Disconnect through connect

1. Perform a visual inspection of the circuit-breaker:
 - a. Verify Close/Open Indicator shows OPEN.
IF NOT, OPEN THE CIRCUIT-BREAKER (CONNECT OPERATION IS PREVENTED WHILE CIRCUIT-BREAKER IS CLOSED)
2. Racking-in operation:
 - a. Verify switchgear door is CLOSED
 - b. Begin racking by rotating the racking handle to the CLOCKWISE direction.
 - c. Twenty (20) revolutions (200mm) will move the circuit-breaker between the Test and Connect positions.
 - The Connect position is indicated by a positive lock, preventing further racking shaft rotation.
 - Electric and mechanical closing operation of the circuit-breaker are prevented between Test and Connect positions.

4.6.6. Connect through disconnect

1. Perform a visual inspection of the circuit-breaker:
 - a. Verify Close/Open Indicator shows OPEN.
 - b. Verify switchgear door is CLOSED.
2. Racking-out operations:
 - a. Begin racking by rotating the racking handle in the COUNTER-CLOCKWISE direction.
 - b. Twenty (20) revolutions (200mm) will move the circuit-breaker between the Connect and Disconnect positions.
 - Electric and mechanical closing operation of the circuit-breaker are prevented between Test and Connect positions.




Fig. 11

4.6.7. Connect through disconnect

Emergency rack Out: (Figure 12)

1. In the case of a locking magnet –RL2 fault, in an emergency the truck can be racked out manually following the instructions below:
2. Open the door as emergency operation see IB Powercube # 647652/001 sec.6.3
 - a. Open the circuit-breaker
 - b. Verify Close/Open Indicator shows OPEN
 - c. cut off the power supply to the auxiliary circuit
 - d. open the enclosure door following Powercube Installation and maintenance instructions 647652/001 sec.6.3
 - e. remove the circuit-breaker metallic front protection shield.
 - f. using the manual lever, carry out an emergency racking-out operation, keeping the moving anchor (A – Fig.12) of the locking magnet –RL2 pressed left by means of a screwdriver during the initial stage of racking-out (B - Fig. 12).




Fig. 12

Table 2. Summary Racking Data

	DISCONNECT	CONNECT
Distance from Disconnected	0 mm / 0 revolutions / 0 inches	200 mm / 20 revolutions / 7.89 inches
Manual opening	Yes	Not recommended unless necessary
Electrical Operation	Yes, while power cord is connect	Yes, while power cord is connect
Control Power Available	Yes, while power cord is connect	Yes
Shutter	CLOSED	OPEN
Primary Contacts Engaged	No	Yes
Requirements to rack breaker from position	Breaker Open / Power cord connect	Breaker Open / Power cord connect
Notes	A	A

Notes A: Closed door is mandatory between all positions




Fig. 13




Fig. 14

4.6.8. Circuit-breaker closing and opening operations

Circuit-breaker operation can be either manual or electrical (fig. 15).

a) Manual spring charging operation

To manually charge the closing springs, it is necessary to repeatedly activate the charging lever (2) (maximum rotation angle of the lever: about 90°) until the yellow signalling device (7) appears which indicates completion of charging. The maximum forces which can normally be applied to the lever are < 200 N for the EL2 operating mechanism and < 250 N for the EL2S operating mechanism. For the type of operating mechanism, please refer to the rating plate (Fig. 1).

b) Electrical spring charging operation

On request, the circuit-breaker can be fitted with the following accessories for electrical operation:

- geared motor for automatic closing spring charging
- shunt closing release
- shunt opening release

The geared motor automatically recharges the springs after each closing operation until the yellow signaling device (7) appears.

If the power is cut off during charging, the geared motor stops. Automatically the motor spring charging starts recharging the springs when the power returns.

In any case, it is always possible to complete the recharging operation manually.

c) Circuit-breaker closing

The operation can only be carried out with the closing springs completely charged. For manual closing, press the pushbutton (5). When there is a shunt closing release, the operation can also be carried out remotely by means of a special control circuit. Closing having taken place is indicated by the signaling device (6).

d) Circuit-breaker opening

For manual opening, press the pushbutton (4).

When there is a shunt opening release, the operation can also be carried out remotely by means of a special control circuit. Opening having taken place is indicated by the signaling device (6).



Fig. 15

4.6.9. Operating mechanism description

When the motor is activated or manual charging lever is moved:

- 1 The operating mechanism shaft turns (1 - fig. 16)
- 2 The cams on the shaft move the closing lever assembly action 2 – fig. 16
- 3 The closing lever assembly charges the closing springs.




Fig. 16

Once the closing spring is charged completely:

- 4 A part of the closing springs force works on the closing hook through the closing lever assembly and the pin 1 - fig.17 of the cams/toggle assembly
- 5 The closing hook, remains locked by the closing shaft 2 - fig. 17
- 6 The opening hook 3 - fig. 17 reaches its position and receives the central hook of the cams/toggle assembly
- 7 The signalling device for the status of the closing springs charged/discharged goes in charge position




Fig. 17

When you push the closing pushbutton:

- 8 The closing shaft 1 - fig.18 turns and releases the closing hook
- 9 The closing springs unloads their energy on the closing lever assembly
- 10 The closing lever assembly push the long levers of the cams/ toggle assembly, by a pin 3 - fig.18
- 11 The long levers move by pin 4 - fig.18 the main shaft counter clockwise 5 - fig.18
- 12 The signalling indicator device for open/closed CB status goes in close position; the CB is closed




Fig. 18

- 13 The long levers reach the settled position
- 14 The contact springs inside the poles and the opening spring inside the frame are charged
- 15 A part of the contact springs and opening spring load works on the long levers but the long levers remain in their position by the central hook of the cams/toggle assembly
- 16 The central hook works on the opening hook 5 - fig. 19
- 17 The opening hook remains locked by the opening shaft




Fig. 19

Once the CB is closed:

The motor gear (if present) turns automatically the operating mechanism shaft (20) and the conditions of the points 1. 2. and 3. are satisfied.

When you push the opening pushbutton:

- 18 The opening shaft 1 - fig. 21 turns and releases the opening hook
- 19 The opening hook releases the central hook of the cams/toggle assembly
- 20 The long levers of the cams/toggle assembly are free now and by the force of the contact springs and the opening spring they can move
- 21 The main shaft turns clockwise
- 22 The signalling device for open/closed CB goes in open position
- 23 The CB is in open position




Fig. 20




Fig. 21

4.7. Standard fittings for circuit-breaker

4.7.1. Standard fittings for withdrawable circuit-breaker series

The basic versions of the withdrawable circuit-breakers are three-pole and fitted with:

- 1 EL type manual operating mechanism
- 2 mechanical signalling device for closing springs charged/ discharged
- 3 mechanical signalling device for circuit-breaker open/closed
- 4 closing pushbutton
- 5 opening pushbutton
- 6 operation counter
- 7 set of ten circuit-breaker open/closed auxiliary contacts
- 8 lever for manually charging the closing springs
- 9 isolating contacts
- 10 cord with connector (plug only) for auxiliary circuits, with striker pin which does not allow the plug to be inserted into the socket if the rated current of the circuit-breaker is different from the rated current of the panel
- 11 racking-in/out lever 16-fig.7(the quantity must be defined according to the number of pieces of apparatus ordered)
- 12 locking electromagnet in the truck 7 - fig. 27 (-RL2). This prevents the circuit-breaker being racked into the panel with the auxiliary circuits disconnected (plug not inserted in the socket).



Fig. 22

4.7.2. Standard fittings for fixed circuit-breaker series

The basic versions of the fixed circuit-breakers are three-pole and fitted with:

- 1 EL type manual operating mechanism
- 2 mechanical signalling device for closing springs charged/ discharged
- 3 mechanical signalling device for circuit-breaker open/closed
- 4 closing pushbutton
- 5 opening pushbutton
- 6 operation counter
- 7 set of ten circuit-breaker open/closed auxiliary contacts
- 8 lever for manually charging the closing springs



Fig. 23



Fig. 24

5. Operation, installation and maintenance


5.1. Interlocks

5.1.1. Interference blocking

A mechanical plug interference blocking in the circuit-breaker compartment prevents under rated circuit-breakers from being inserted into higher rated compartments. The code plate rating includes continuous current, interrupting current, close and latch capability, and maximum voltage.

Interlocks / protection against malfunction (for withdrawable circuit-breakers for ABB switchgear)

The Vmax/W circuit-breaker contains a number of interlocks.



These interlocks are provided to prevent incorrect operations and/or malfunctions. The interlocks are the following:

- the withdrawable truck can only be moved from the test/ isolated position to the service position (and vice versa) if the circuit-breaker is open (this means that first of all the circuit-breaker must be opened).
- the circuit-breaker can be closed if the withdrawable truck is exactly in the defined disconnected position or in the connected position (electric interlock).
- the circuit-breaker can be opened manually in the service or test position when it is not powered.
- the switchgear is provided with devices which only allow connection and disconnection of the plug connector (3) (fig.2A) in the test/ isolation position.

5.1.2. Interlocks in the case where ABB withdrawable trucks are used

- 1) The Vmax/W circuit-breaker can only be closed when the withdrawable truck is in the test or service position.
- 2) A mechanical interlock positioned on the withdrawable truck prevents a closed circuit-breaker from being moved from the test position to the service position.
- 3) Vmax/W circuit-breaker can only be racked-in/ isolated if the locking electromagnet in the truck is supplied (as well as being open) if available in the truck.

Positive position for removal

The handle release pin prevents withdrawing the circuit-breaker from the compartment by blocking withdrawal of the locking tabs. The handle release pin blocks the handles unless the circuit-breaker is in the Disconnect position.

5.1.3. Interlock in the case where non-ABB withdrawable trucks are used

Vmax circuit-breaker is implemented with mechanical connection for interlocks purpose.

- 1) to prevent movement of a closed circuit-breaker

The rotating locking device (1) (fig. 25) on the circuit-breaker can be used for this purpose: if the Vmax circuit-breaker is closed, the rotating locking device is down close to the base plate (2) (fig. 25). This prevents movement of the withdrawable truck and therefore movement of the circuit-breaker.

- 2) to prevent closing of an intermediate circuit-breaker position.

The slide locking device (3) (fig. 25a) on the circuit-breaker can be used for this purpose: if the Vmax circuit-breaker, fitted on non-ABB truck, is in intermediate position, the slide locking device must be pulled down as shown (4) (fig. 25a). This prevents movement closing circuit-breaker in intermediate position.

Note: any additional interlocks must not exert any force on the circuit-breaker drive.




Fig. 25




Fig. 25a

5.2. Maintenance

Vmax circuit-breakers are designed for a minimum amount of maintenance. Circuit-breakers in a clean, non-corrosive environment require only annual inspection. Dusty or corrosive environments require inspection more often at the discretion of the user. Following each interrupted fault inspection is required.

DO NOT work on an energized circuit-breaker.

DO NOT work on a circuit-breaker unless all of the components are disconnected by means of a visible break and securely grounded.

DO NOT work on a circuit-breaker with power supplied to the secondary control circuit.

DO NOT defeat safety interlocks. This may result in bodily injury, death and/or equipment damage.

DO NOT work on a closed circuit-breaker.

DO NOT work on a circuit-breaker with charged energy. (springs)

DO NOT use a circuit-breaker by itself as the sole means of isolating a high voltage circuit.

DO NOT leave a circuit-breaker in an intermediate position in a cell. Always have the circuit-breaker in the Disconnect or Connect position.

5.2.1. General

Vacuum circuit-breakers are characterised by simple, sturdy construction and long life.

The drive is maintenance-free for its whole operating life and only requires functional inspections.

The vacuum interrupters are maintenance-free for their whole operating life.

Vacuum interruption does not produce harmful effects even when there are frequent trips at the rated and short-circuit current.

The servicing interventions and their aim depend on the environmental conditions, on the sequence of operations and on the trips under short-circuit.


Note

For maintenance work, respect the following Standards:

- the relative specifications indicated in the “Standards and Specifications” chapter;
- regulations for safety in the workplace indicated in the “Putting into service and operations” chapter;
- regulations and specifications of the country where the apparatus is installed.

The maintenance operations can only be carried out by trained personnel who respect all the safety regulations. Furthermore, it is recommended that ABB service personnel should be called in, at least to check the service performances, and for any repair work.

During maintenance work, turn the power supply off and put the apparatus under safe conditions.



5.2.2. Mechanism

The mechanism requires visual inspection of hardware, lubrication and operation during routine inspection.

Remove the front cover by unfastening its screws and correct any loose or missing hardware .

Always lubricate the working surface of the moving parts. Verify lubrication on the connections of the actuator and lever arm. Remove any grease on the circuit-breaker frame. Use only grease Isoflex Topas NB52 (ABB No GCE0007249P100 1Pt. can). If the grease becomes caked and dirty, remove with a clean cloth and reapply lubrication.

Maintenance operations are aimed at ensuring trouble-free operation of the apparatus for the longest possible time. In accordance with what is specified in the C37.04 - C37.54 - C37.09 - C37.55 Standards and NETA Standards, the following operations must be carried out.

Inspection: Determination of the actual conditions

Servicing: Measures to be taken to maintain the specification conditions

Repairs: Measures to be taken to restore the specification conditions.

5.2.3. Operating life


All vacuum circuit-breakers are characterised by simple, sturdy construction and long useful life. Frequent operation of the service and shortcircuit currents does not negatively affect the degree of vacuum of the interrupters.


Typical useful life expectancy of a Vmax vacuum circuit-breaker is determined by the following factors:

- vacuum interrupter, maintenancefree up to 10,000 mechanical operating cycles.
- drive with magnetic actuator, maintenance free under normal service conditions
 - up to 10,000 operating cycles for all the circuit-breakers with breaking capacity up to 31.5 kA and rated current up to 1200 A
- indication of ON/OFF position up to 10,000 operating cycles
- withdrawable truck: up to 500 handling operations can be carried out in the case of normal activation and with regular inspections.

The data on the useful life are in principle applied to all the components which are not directly affected by the operator. The useful life of the manually activated components (movement of the withdrawable truck, etc.) can vary according to the type of handling.

The time intervals and amount of maintenance are determined by environmental agents, by the frequency of operation and by the number of trip operations under short-circuit.

DANGER



HIGH SPEED MECHANICAL PARTS, SERIOUS INJURY MAY OCCUR.

KEEP HANDS AND TOOLS CLEAR OF THE MECHANISM DURING OPENING AND CLOSING OPERATIONS AND ANYTIME THE OPENING SPRINGS.

OPENING SPRINGS ARE ALWAYS CHARGED WHEN THE CIRCUIT-BREAKER IS CLOSED.

5.2.4. Inspections and functional tests

Interruption devices in general

- Carry out regular inspections to check that the interruption devices are in good condition.
- Inspection at fixed intervals can be waived when the apparatus is permanently monitored by qualified personnel.
- Above all, the checks must include a visual inspection to check for any contamination, traces of corrosion and electrical discharge phenomena.
- Carry out more frequent inspections when there are unusual operating conditions (including adverse climatic conditions) and in the case of environmental pollution (e.g. heavy contamination or an atmosphere with aggressive agents).
- Visual examination of the isolating contacts.
Turning the system of contacts alternately is recommended, in order to keep the internal surface of the contact areas clean. The contact areas must be cleaned if there are signs of overheating (discoloured surface) (also see the paragraph on “Repairs”).
- If any anomalous conditions are found, appropriate servicing measures must be taken (see the paragraph on “Servicing”).

Functional test

- Make the circuit-breaker safe by discharging the closing springs (close and open the circuitbreaker by means of the closing and opening pushbuttons).
- With the circuit-breaker in the test position, carry out a few opening and closing operations by means of the shunt opening and closing releases.
- The nuts and screws are tightened in the factory and correct tightening is marked with a coloured sign. Further tightening operations during the operating life of the circuit-breaker are not foreseen. However, if it should be necessary to tighten the nuts or screws again following any trips, the values indicated in fig. 26 must be respected.

Stored energy operating mechanism Carry out the functional test of the operating mechanism every 5,000 operations or every 4 years. Before doing the test, open the circuit-breaker and carry out the following operations:

- for withdrawable circuit-breakers, take the circuit-breaker to the test position
- for fixed circuit-breakers: cut off the voltage to the medium voltage circuit.

Note

Insulate the working area and make it safe, following the safety regulations specified in the ANSI C37.04 – C37.54 – C37.09 – C37.55 VDE Standards.

Checking screw tightening




Fig. 26

5.2.5. Vacuum interrupter housing

No check is required apart from what has already been specified in par. "Operations before putting into service".

5.2.6. Servicing

Interruption devices in general

If cleaning is found to be necessary during the inspections, as specified in par. "Operations before putting into service", use the following procedure:

- insulate the working area and make it safe by following the safety regulations specified in the ANSI/NFPA70/NEC Standards.
- general cleaning of the surfaces:
 - dry and eliminate any light deposits of dirt using a soft dry cloth;
 - more resistant deposits of dirt can be removed using a slightly alkaline household cleanser or Rivolta BWR 210 type detergent.
- cleaning the insulating surfaces and conductive components:
 - light dirt: with Rivolta BWR 210 detergent;
 - resistant dirt: with cold 716 type detergent.

After cleaning, rinse thoroughly with clean water and dry carefully

Note

Only use halogen-free detergents and never trichloroethane, trichloroethylene or carbon tetrachloride!

5.2.7. Actuator and transmission system

A functional test of the drive must be carried out:

- when the number the number of operating cycles indicated has been exceeded, (after 10,000 operation) or
- during maintenance operations.

Before carrying out the functional test, open the circuit-breaker and

- take it to the test position (withdrawable circuit- breaker) or
- insulate the working area and make it safe in conformity with the safety rules and according to the regulations in force (fixed circuit-breakers)
- discharge the closing or opening springs
- Visually inspect the lubrication conditions of the tulip isolating contacts, of the sliding surfaces, ect.
- Check correct electrical and mechanical operation of the various devices, with particular attention to the interlocks.
- The screws and nuts are tightened in the factory and correct tightening is marked with a collared sign. No further tightening operations are foreseen during the operating life of the circuit-breaker.

Functional test:

- Connect the power supply voltage.
- Carry out several no-load operations. This test particularly applies to circuit-breakers which are rarely activated under normal conditions.

Note

These operations can only be carried out by ABB personnel or suitably qualified and specially trained personnel.

5.2.8. Servicing details

- If provided, turn off the spring charging motor power supply and manually discharge the operating mechanism springs by closing and opening the circuit-breaker.
- Replace parts subject to high climatic or mechanical stresses (contact an ABB service centre).

Note

These operations can only be carried out by ABB personnel or suitably qualified and specially trained personnel.

5.2.9. Vacuum interrupters

The vacuum interrupters are maintenance-free up to the maximum number of electrical operations.

The operating life of the vacuum interrupter is defined by the sum of the ultimate currents corresponding to the specific type of interrupter: when the sum of the ultimate currents is reached, the complete VI must be replaced, for electrical life ask to ABB.

Note

Dismantling and replacement of the interrupter assembly can only be carried out by ABB personnel or by qualified and specially trained personnel, especially for the necessary adjustments.

To carry out the interrupter test use the VIDAR vacuum tester, of the Electric GmbH, Bad Homburg v.d.H. company Programme. To check vacuum tightness of the interrupter, the following test values must be set on the VIDAR tester:

Rated voltage of the circuit- breaker	DC test voltage
15 kV	40 kV

The test must always be carried out with the circuit-breaker open with the contacts at the nominal distance.

Procedure for testing the degree of vacuum of the interrupter:

- cut off the voltage in the working area and make it safe in accordance with the safety regulations specified in the ANSI/ NFPA 70/NEC Standards;
- open the circuit-breaker;
- earth a terminal of each circuit-breaker phase;
- connect the earth terminal of the VIDAR tester to the circuit-breaker structure;
- connect the high voltage terminal of the VIDAR tester to the terminal not connected to earth of the interrupter (L1 phase) and carry out the test. Repeat the test for phases L2 and L3.

Note

The tester connection cables can produce an indication due to the capacitive effect. In this case the cables must not be removed.

5.2.10. Repairs

Replacement of spare parts and accessories must only be carried out by ABB personnel or suitably qualified and specially trained personnel.

Always work with the circuit-breaker open and locked so that it cannot be closed again, with the work area insulated and made safe.

The drive springs must be discharged.

All power supply sources must be disconnected and made safe against any reclosing during removal and installation work.

CAUTION

SHOULD MAINTENANCE BE CARRIED OUT BY THE CUSTOMER'S PERSONNEL, RESPONSIBILITY FOR THE INTERVENTIONS REMAINS WITH THE CUSTOMER. THE REPLACEMENT OF PARTS NOT INCLUDED IN THE "LIST OF SPARE PARTS/ ACCESSORIES" MUST ONLY BE CARRIED OUT BY ABB PERSONNEL. IN PARTICULAR:

- COMPLETE POLE WITH BUSHINGS/ CONNECTIONS
- ACTUATOR
- TRANSMISSION SYSTEM.


5.3. Truck (Refer to Fig. 27)

The truck requires visual inspection of hardware, lubrication, and operation during routine maintenance.

With the circuit-breaker outside the cell, verify all visible hardware tightness, including handles (1) and wheels (2). Wheels should rotate freely by hand movement. Replace or tighten any missing or loose hardware.

With the circuit-breaker outside the cell, rotate the racking screw as though racking the circuit-breaker to the Connect position. This process will expose surfaces inside the truck that need to be inspected and lubricated. Lubricate the exposed parts; specifically the entire Racking Screw (4). Inspect the circuit-breaker locking tabs (3) for any damage. Return truck to the Disconnect position. As a precaution, do not operate the circuit-breaker outside the cell unless the truck is in the full Disconnect position.

Truck (shown with circuit-breaker removed)



- 1 Handles
- 2 Weels
- 3 Locking tab
- 4 Racking screw
- 5 Secondary plug
- 6 Racking screw collar
- 7 -RL2
- 8 Truck locator channel

Fig. 27

5.3.1. Control wiring

During routine maintenance for control wiring, a visual inspection of the hardware should be performed and a low-frequency withstand voltage testing performed, and 3 manual operations should be conducted. Disconnect control power before verifying secondary hardware and before low-frequency withstand voltage testing.

Remove the front cover with a screwdriver. Correct any loose or missing mounting hardware. Verify the ground wire connection to the frame and all connectors' alignment and snugness on the electrical components. Visually inspect the secondary plug and correct any pins that may have become displaced.

To verify the integrity of the secondary insulation, perform the following low-frequency withstand voltage test:

1. Disconnect control power.
2. Connect all pins from the secondary to a test wire.
3. Connect test wire to the high potential lead of the test machine.
4. Ground the circuit-breaker frame.
5. Start machine with output potential at 0 (zero) VAC RMS.
6. Increase the potential to the required insulation test voltage (1125 VAC RMS).
7. Hold for one minute.
8. Reduce potential to 0 (zero) VAC and turn off machine.

A successful withstand testing indicates satisfactory insulation strength of the secondary circuit. Failing insulation will not sustain the voltage across the secondary. Replace the circuit-breaker control wiring if the insulation fails during low-frequency withstand voltage testing.

Replace the front cover before operation. Verify the operation with 2-5 electrical operations in the Test position or with a remote power supply.


5.3.2. Primary circuit assembly (Pole)

During routine maintenance for the primary circuit, a visual inspection of the hardware and a low-frequency withstand voltage testing, and lubrication of the primary contacts should occur as outlined hereinafter.


All insulation material should be clean and free of cracks and replace damaged parts.

Dirt or dust may create a dielectric path to ground on the insulation. Remove dust and dirt with a clean, lint-free cloth. Apply distilled water to the cloth to remove any difficult dirt. DO NOT return the circuit-breaker into service until the insulation surfaces are completely dry to prevent external flash-over from the live part to live part or to ground.

Lubrication on the primary contacts should be inspected during routine maintenance. Use only grease Isoflex Topas NB52 (ABB No. GCE0007249 P100, 1 Pt. can).



CAUTION



APPLYING ABNORMALLY HIGH VOLTAGE ACROSS A PAIR OF OPEN CONTACTS IN A VACUUM MAY PRODUCE X-RADIATION. THE RADIATION MAY INCREASE WITH THE INCREASE IN VOLTAGE AND/OR DECREASE IN CONTACT SPACING. IT IS RECOMMENDED THAT ALL OPERATING PERSONNEL STAND AT LEAST ONE METER AWAY AND IN FRONT OF THE CIRCUIT BEAKER DURING TESTING.

To verify the integrity of the primary insulation, perform the following low-frequency withstand voltage test:

1. Close the circuit-breaker (no control power supplied)
 - Connect the high potential lead to one pole.
 - Ground the remaining poles and the circuit-breaker frame.
2. Start machine with output potential at 0 (zero) VAC.
3. Increase the potential to the required voltage (see Table 3; note that new condition test is a factory test only and is not valid for field condition tests.)
4. Hold for one minute.
5. Decrease potential to 0 (zero) VAC and turn off machine.
6. Repeat for the remaining poles.

A successful withstand indicates satisfactory insulation strength of the primary circuit.

Rated max voltage	Dielectric Test Value, 1 Minute Dry AC rms New condition reference c37.06	Dielectric Test Value, 1 Minute Dry AC rms Field condition reference c37.20.2
15kV	36 kV	27 kV

Table 3: Primary low-frequency withstand test voltage

To verify the integrity of the vacuum interrupters perform the following low-frequency withstand voltage test:

1. Open the circuit-breaker (no control power supplied to the circuit-breaker).
 - a. Connect the high potential lead to one terminal.
 - b. Ground the remaining 5 terminals and circuit-breaker frame.

Workers must stand back at least 1.5 metres.

2. Start machine with output potential at 0 (zero) VAC.
3. Increase the potential to the required voltage (see Table 3).
4. Hold for one minute.
5. Decrease potential to 0 (zero) and turn off machine.
6. Repeat for the remaining 5 terminals.

A successful withstand indicates satisfactory vacuum integrity. Replace interrupters that fail to sustain the voltage across the open contacts.

Testing MUST be done with an AC source only.

DC testing is not considered a valid test for vacuum integrity.

Testing with meggers or other similar devices is not considered valid under any circumstances.

5.3.3. Application of the X-ray

Emission standards


One of the physical properties of vacuum insulation is the possibility of X-ray emission when the interrupter contacts are open.


The specific tests carried out at the PTB laboratories (Physikalisch-Technische Bundesanstalt, in Brunswick - Germany) show that local emission at a distance of 10 cm from the interrupter or pole surface, does not exceed 1 mSv/h.

It follows that:

- at the rated service voltage the use of vacuum interrupters is absolutely safe;
- application of the withstand voltage at power frequency, according to the IEEE C37.4 Standards, is safe;
- application of a voltage higher than the withstand voltage at power frequency or of a direct current test voltage, specified in the IEEE C37.4 Standards, cannot be used;
- limitation of the above-mentioned local phenomena, with interrupters with open contacts, depends on keeping the specific distance between the contacts.

This condition is intrinsically guaranteed by correct operation of the drive and by adjustments of the transmission system.

**DANGER**



THE INTERNAL SHIELD OF A VACUUM INTERRUPTER CAN ACQUIRE AN ELECTRIC CHARGE WHICH CAN BE RETAINED EVEN AFTER THE VOLTAGE IS REMOVED. DISCHARGE THE MID-BAND RING WITH A GROUNDING STICK BEFORE WORKING ON ANY PART OF THE CIRCUIT-BREAKER.

6. Servicing

6.1. Interruption devices in general

If the devices had to be cleaned during the inspections, according to what is specified in par. 9.2.1., use the following procedure:

- insulate the working area and make it safe, respecting the safety regulations specified in the IEC/DIN VDE Standards;
- general cleaning of surface:
 - dry and eliminate any light deposits of dirt using a soft dry cloth;
 - more resistant deposits of dirt can be removed using a slightly alkaline domestic cleanser;
- cleaning insulating surface and conductive parts:
 - light dirt: with Rivolta BWR 210 detergent;
 - resistant dirt: with cold 716 type detergent.

After cleaning, rinse thoroughly with clean water and dry carefully.

Note

Only use halogen-free detergents and never trichloroethane, trichloroethylene or carbon tetrachloride!

6.2. Actuator and transmission system

Servicing must be carried out after 10,000 operations both for the actuator (snap-on box) and for the shock absorber.

Note

Dismantling and replacement of the operating mechanism (snap-on box) can only be carried out by ABB personnel or by qualified and specially trained personnel, especially for the necessary adjustments.

6.3. Servicing details

- If provided, turn off the spring charging motor power supply and manually discharge the operating mechanism springs by closing and opening the circuit-breaker.
- Replace parts subject to high climatic or mechanical stresses (contact an ABB service centre).

Note

These operations can only be carried out by ABB personnel or suitably qualified and specially trained personnel.

6.4. Vacuum interrupters

The vacuum interrupters are maintenance-free up to the maximum number of electrical operations.

The operating life of the vacuum interrupter is defined by the sum of the ultimate currents corresponding to the specific type of interrupter: when the sum of the ultimate currents is reached, the complete VI must be replaced, for electrical life ask to ABB.

Note

Dismantling and replacement of the interrupter assembly can only be carried out by ABB personnel or by qualified and specially trained personnel, especially for the necessary adjustments.

To carry out the interrupter test use the VIDAR vacuum tester, of the Electric GmbH, Bad Homburg v.d.H. company Programme.

To check vacuum tightness of the interrupter, the following test values must be set on the VIDAR tester:

Rated circuit-breaker voltage DC test voltage of the circuit-breaker 15-40 kV

The test must always be carried out with the circuit-breaker open with the contacts at the nominal distance.


Procedure for testing the degree of vacuum of the interrupter:

- cut off the voltage in the working area and make it safe in accordance with the safety regulations specified in the IEC/DIN VDE Standards;
- open the circuit-breaker;
- earth a terminal of each circuit-breaker phase;
- connect the earth terminal of the VIDAR tester to the circuit-breaker structure;
- connect the high voltage terminal of the VIDAR tester to the terminal not connected to earth of the interrupter (L1 phase) and carry out the test. Repeat the test for phases L2 and L3.

Note

The tester connection cables can produce an indication due to the capacitive effect. In this case the cables must not be removed.

7. Spare parts and accessories

**WARNING**

ALL ASSEMBLY OPERATIONS OF SPARE PARTS/ ACCESSORIES MUST BE CARRIED OUT FOLLOWING THE INSTRUCTIONS ENCLOSED WITH THE SPARE PARTS, BY ABB PERSONNEL OR BY SUITABLY QUALIFIED CUSTOMER PERSONNEL WITH IN-DEPTH KNOWLEDGE OF THE APPARATUS (ANSI/IEEE C37.04 - C37.54 - C37.09 - C37.55 STANDARDS, NETA STANDARDS, NEC NPFA70 STANDARDS) AND ALL THE STANDARDS AIMED AT CARRYING OUT THESE INTERVENTIONS IN SAFE CONDITIONS.

SHOULD THE MAINTENANCE BE CARRIED OUT BY THE CUSTOMER'S PERSONNEL, RESPONSIBILITY FOR THE INTERVENTIONS REMAINS WITH THE CUSTOMER.

BEFORE CARRYING OUT ANY OPERATION, ALWAYS MAKE SURE THAT THE CIRCUIT-BREAKER IS OPEN, THE SPRINGS DISCHARGED AND NOT SUPPLIED (MEDIUM VOLTAGE CIRCUIT AND AUXILIARY CIRCUITS).

7.1. List of spare parts

- Shunt opening release
- Additional shunt opening release
- Undervoltage release
- Time delay device for undervoltage release
- Mechanical override for undervoltage release
- Shunt closing release
- Spring charging geared motor with electrical signalling of springs charged
- Contact signalling geared motor protection circuit-breaker open/closed
- Contact signalling closing springs charged/discharged
- Circuit-breaker auxiliary contacts
- Locking electromagnet on the operating mechanism
- Position contact of the withdrawable truck
- Contacts signalling racked-in/isolated
- Key lock in open position
- Isolation interlock with the door
- Protection for opening pushbutton
- Protection for closing pushbutton
- Locking electromagnet on the withdrawable truck
- Set of six tulip contacts

To order circuit-breaker spare parts/accessories, refer to the ordering sales codes indicated in the technical catalogue and always state the following:

- type of circuit-breaker
- rated voltage of the circuit-breaker
- rated normal current of the circuit-breaker
- breaking capacity of the circuit-breaker
- serial number of the circuit-breaker
- rated voltage of any electrical spare parts.


For availability and to order spare parts, please contact our Service office.

8. Overall dimensions

Vmax - Fixed circuit-breaker




ANSI: 15 kV - 1200 A - 25...31.5 kA

1VCD003279_V3198



Dimensions are in "mm" and in "inches".

Vmax/W - Withdrawable circuit-breakers for PowerCube
 ANSI: 15 kV - 1200 A - 25...31.5 kA
 1VCD003280_V2856



Dimensions are in "mm" and in "inches".

























9. Electric circuit diagram



Circuit-diagram of Vmax circuit-breaker in withdrawable version for PowerCube with EL operating mechanism.
For other circuit-breakers, please consult us.

The diagram indicates the following conditions:

- circuit-breaker off and connected
- circuits de-energized
- closing springs discharged


Graphical symbols for electrical diagrams (617 IEC Standards)

	Thermal effect		Frame		Capacitor (general symbol)		Passing make contact closing momentarily when its operating device is released
	Electromagnetic effect		Conductors in screened cable (two conductors shown)		Motor (general symbol)		Position switch (limit switch) make contact
	Delay		Connection of conductors		Rectifier in full wave connection (bridge)		Position switch (limit switch) brake contact
	Pushbutton control		Terminal or clamp		Make contact		Circuit-breaker with automatic release
	Key control		Socket and plug (female and male)		Break contact		Operating device (general symbol)
	Earth (general symbol)		Resistor (general symbol)		Change-over break before make contact		Lamp (general symbol)




*H)

26




*C)

31




*C)

32




* c)


33



* c)

34





Caption

- | | | | |
|-----------|---|---------|---|
| □ | = Reference number of diagram figure. | -XB | = Connector for the circuit-breaker circuits. |
| * | = See note indicated by the letter. | -XB2..9 | = Connectors of accessories. |
| -QB | = Circuit-breaker accessories. | -XB1 | = Switchboard terminal board (mounted externally to the circuit-breaker). |
| -BM | = Device for the supervision of shunt opening release and shunt closing release coil continuity (see note D). | -RL1 | = Locking magnet. If de-energized it prevents the circuit-breaker closing mechanically (it is possible to limit its consumption by connecting in series a delaying pushbutton enabling the operation). |
| -MS | = Motor for the closing springs charging (see note C). | -RL2 | = Locking magnet. If de-energized it prevents the circuit-breaker racking-in and racking-out mechanically (it is possible to limit its consumption by connecting in series a delaying pushbutton enabling the operation). |
| -BB1..2-3 | = Circuit-breaker auxiliary contacts. | -MC | = Shunt closing release (see note D). |
| -BS1 | = Limit switches of the spring-charging motor. | -MO1 | = First shunt opening release (see note D). |
| -BS2 | = Limit switches signalling closing spring charged or discharged. | -MO2 | = Second shunt opening release (see note D) |
| -BD | = Position contact of the enclosure door. | -MO3 | = Opening solenoid for release external to the circuit-breaker. |
| -BT1 | = Contacts signalling circuit-breaker in the connected position (see note E). | -MU | = Undervoltage release (see note B). |
| -BT2 | = Contacts signalling circuit-breaker in the removed position (see note E). | | |
| -BT3 | = Circuit-breaker position contact. It is open during the travel of the breaker (see note H). | | |
| -SC | = Pushbutton or contact for the circuit-breaker closing. | | |
| -SO | = Pushbutton or contact for the circuit-breaker opening. | | |

Description of figures

- Fig. 1 = Spring charging-motor circuit (see note C).
 Fig. 2 = Shunt closing release (antipumping is achieved mechanically).
 Fig. 3 = Locking magnet. If de-energized it prevents the circuit-breaker closing mechanically (this fig. must be given when is request -RL1 and fig. 31 or 32 is selected). (It is possible to limit its consumption by connecting in series a delaying pushbutton enabling the operation).
 Fig. 4 = Locking magnet. If de-energized it prevents the circuit-breaker closing mechanically (this fig. must be given when is request -RL1 and fig. 33 or 34 is selected). (It is possible to limit its consumption by connecting in series a delaying pushbutton enabling the operation).
 Fig. 5 = Instantaneous undervoltage release (see note B).
 Fig. 7 = First shunt opening release circuit with possibility of permanent supervision of coil continuity (see note D).
 Fig. 8 = Locking magnet. If de-energized it prevents the circuit-breaker racking-in and racking-out mechanically (it is possible to limit its consumption by connecting in series a delaying pushbutton enabling the operation).
 Fig. 9 = Second shunt opening release circuit with possibility of permanent supervision of coil continuity (see note D).
 Fig. 10 = Opening solenoid for release external to the circuit-breaker.
 Fig. 26 = Contact signalling closing spring charged and discharged (see note H).
 Fig. 31-32-33-34 =Circuit-breaker available auxiliary contacts.
 Fig. 51 = Contacts signalling circuit-breaker in the connected and isolated positions located on the circuit-breaker (when is request fig. 31 or 32 is obbligator).
 Fig. 52 = Contacts signalling circuit-breaker in the connected and isolated positions located on the circuit-breaker (when is request fig. 33 or 34 is on request).
 Fig. 60 = Contact signalling undervoltage release deactivate.

Incompatibility

The combinations of circuits given in the figures below are not possible on the same circuit-breaker:

3-4	31-31-33-34	4-31-32
3-33-34	-	31-32-52
33-34-51	51-52	

Notes

- A) The circuit-breaker is delivered complete with the accessories listed in the ABB order acknowledgement only. To draw up the order examine the catalogue.
 B) The undervoltage release is available in the version suitable for circuit-breaker supply side feeding or for feeding from an independent source. Circuit-breaker may be closed only if the undervoltage release is energized (lock on closing is achieved mechanically). In case of the same voltage supply for closing and undervoltage releases and if it is required the circuit-breaker automatic closing when the auxiliary voltage supply restores, it is necessary to delay the energization of the closing release by 50 ms after the undervoltage release acceptance.
 C) Check the power supply available on the auxiliary circuit to verify if it is adequate to start several closing spring-charging motors simultaneously. To prevent excessive consumption the closing springs must be charged manually before energizing the auxiliary circuit.
 D) The circuit for the supervision of shunt opening release coil continuity shall be used for this function only.
 E) Contacts signalling circuit-breaker in the connected and isolated positions (-BT1 and -BT2) given in fig. 51 or 52 are located on the circuit-breaker (moving part) and are available at request.
 F) Fig. 3 is given when are requested fig. 31 or 32 , fig. 4 when are requested fig. 33 or 34 (in this case -BT3 is obligatory).
 G) When fig. 10 is requested contact -BB3 31-32 given in fig. 32-34 is not available. When fig. 30 is requested contact -BB3 53-54 given in fig. 32-34 is not available. When fig. 9 is requested, contact -BB1 43-44 given in fig. 31-32-34-34 is not available.
 H) Both limit switches signalling must be working at the same supply voltage.

10. Product quality and environmental protection

The apparatus are produced in compliance with the requirements of international standards for the quality management system and environmental management system. In these fields, the excellent level is proved by quality certificates according to ISO 9001 and by the EMS according to ISO 14 001.

End of life of product


The ABB company is committed to complying with the relevant legal and other requirements for environment protection according to the ISO 14 001 standard.

The duty of company is to facilitate subsequent recycling or disposal at the end of product life. During disposal of the product, it is always necessary to act in accordance with local legal requirements in force.

Methods of disposal

Disposal can either be carried out thermally in an incineration plant or by storing on a waste site.

RAW MATERIAL	RECOMMENDED METHOD OF DISPOSAL
Metal material (Fe, Cu, Al, Ag, Zn, W, others)	Separation and recycling
Thermoplasts	Recycling or disposal
Epoxy resin	Separation of metal material and the disposal of rest
Rubber	Disposal
Oil as dielectric (transformer oil)	Draining from equipment and further recycling or disposal
SF6 gas Discharging from equipment and further recycling or disposal	Discharging from equipment and further recycling or disposal
Packing material	Recycling or disposal
Packing material	Recycling or disposal



Your sales contact: www.abb.com/contacts
More product information: www.abb.com/productguide

The data and illustrations are not binding.
We reserve the right to make changes without
notice in the course of technical development
of the product.

© Copyright 2011 ABB.
All rights reserved.