

FLEXIDYNE® PH Couplings

Sizes: 987, 1196, 15116, 18172, 22172, 27192, D15116, D15131, D18172

These instructions must be read thoroughly before installing or operating this product.



DESCRIPTION:

Flexidyne dry fluid couplings are a unique concept to provide soft start and momentary overload protection for all types of driven equipment. Standard NEMA-B motors with RPM base speeds of 1750, 1160 or 860 are commonly used with a Flexidyne coupling, yet other available power sources may be used with the Flexidyne coupling.




Figure 1

The dry “fluid” in the Flexidyne housing is heat treated steel shot. A measured amount, referred to as flow charge, is added into a housing which has been keyed to the motor shaft. When the motor is started, centrifugal force throws the flow charge to the perimeter of the housing, packs it between the housing and the rotor, which in turn transmits power to the load.

After the starting period of slippage between housing and rotor the two become locked together and achieve full load speed, operating without slip and with 100% efficiency.

Consequently, the motor accelerates instantly to base speed, while the load starts gradually and smoothly.

WARNING: Because of the possible danger to person(s) or property from accidents which may result from the improper use of products, it is important that correct procedures be followed. Products must be used in accordance with the engineering information specified in the catalog. Proper installation, maintenance and operation procedures must be observed. The instructions in the instruction manuals must be followed. Inspections should be made as necessary to assure safe operation under prevailing conditions. Proper guards and other suitable safety devices or procedures as may be desirable or as may be specified in safety codes should be provided, and are neither provided by Baldor Electric Company nor are the responsibility of Baldor Electric Company. This unit and its associated equipment must be installed, adjusted and maintained by qualified personnel who are familiar with the construction and operation of all equipment in the system and the potential hazards involved. When risk to persons or property may be involved, a holding device must be an integral part of the driven equipment beyond the speed reducer output shaft.

INSTALLATION

1. On all single cavity sizes, except the 18172 and 22172, install coupling flange on motor shaft. On sizes 18172 and 22172 first, place flange spacer ring on flange assembly, located between flange and clamp ring, then install coupling flange on motor shaft.
2. Mount flange assembly on motor shaft.
Straight bored assemblies - press or shrink flange assembly on the shaft.
Taperlock assemblies - install per instruction sheet supplied with Taper-lock bushing. Taperlock flanges are reversible to allow the locating of bushing screws on either the inside or the outside as desired. Motor shaft end is normally flush with flange, but may extend through as much as dimension ‘A’ in Table 1.
3. Position shafts so that dimension “B” (See Table 1) is maintained. If shaft end float is to occur, locate shafts at mid-position of end float.
4. Slip bolt ring over coupling flange and rest it on motor shaft.
5. Disassemble clamp rings and place flexible element and clamp rings in position, making certain element bead is properly seated. Install and tighten clamp ring screws alternately and evenly (approximately ½ turn per screw) until metal to metal contact is felt upon bottoming of clamp ring to flange. Tighten each screw with a torque wrench to torque value shown in Table 1.
6. Install bolt ring and screws. Tighten screws alternately and evenly (approximately ½ turn per screw) until all screws are tightened to torque value shown in Table 1.
7. For longest Flexidyne coupling life, it is always desirable to align coupling as accurately as possible at initial installation. Check both angular and parallel alignments by mounting indicators near the O.D. of the flange, as shown in Figure 2, and rotating the shafts thru 360°. For a good installation neither reading should exceed value “E” given in Table 1. Alignment should be re-checked after any repositioning.




Figure 2

BALDOR • DODGE®

The cutout which is included with the coupling must be installed to protect against excessive heat which may be generated in the Flexidyne coupling by prolonged or frequent slipping caused by overloads. It can be hooked up to automatically interrupt the current and, if desired, activate a bell, light or other warning device. For hazardous atmospheres, special explosion-proof cutouts are available.

Table 1 - Recommended Torque

Flexidyne Coupling Size	Dimension			Torque (in.-lbs.)			
	A*	B*	C*	Clamp Ring	Bolt Ring	Filler Plug	Rotor
987	2-1/8	1-5/8		300	150	200	100
1196	3-1/8	1-15/16		300	250	200	100
15116	2-5/8	2		400	300	700	200
18172	4-1/4	2-15/14		700	500	700	350
22172	3-3/4	2-15/16		700	500	700	1700
27192	4-1/4	3-5/16		1000	650	700	1700
D15116	2-3/4	2	.030	400	300		200
D15131	3-1/2	2-1/2	.035	400	350		200
D18172	3-3/4	2-15/16	.045	900	500		350

*For A, B, and C dimension refer to drawing.

INSTALLATION FOR DUPLEX COUPLINGS

NOTE: Duplex (double cavity) Flexidyne couplings are for use on horizontal shafts only.

1. Install driven hub on driven shaft, making sure that the shaft does not project beyond the end of the TAPER-LOCK® bushing. Install Taper-Lock bushing per instruction manual for bushing.
2. Mount flange assembly on motor shaft. For straight bored assemblies: press or shrink flange assembly on the shaft. For Taper-Lock assemblies: install per instruction manual for Taper-Lock bushing. Taper-Lock flanges are reversible to allow the locating of bushing screws on either the inside or the outside as desired. Motor shaft end is normally flush with flange, but may extend through as much as dimension 'A' in Table 1.

NOTE: The D18172 requires a spacer ring which must be installed between flange and clamp ring before mounting flange assembly on shaft.

Flexible Element Installation

3. Slip bolt ring over flange and rest on shaft.
4. **Size D15116 & D15131:** Remove clamp ring screws and internal clamp ring. Place internal clamp ring inside the element and reassemble to flange seating the bead of the element on the flange. Tighten clamp ring screws alternately and evenly to torque values shown in Table 1.

Size D18172: Remove external clamp ring and rest it on shaft. Turn element sideways to shaft and push over flange. Seat element on flange and reassemble clamp ring and screws tightening to recommended torque value in Table 1.
5. Place shafts in position so that dimension "B" in Table 1 will be maintained. If shaft end float is to occur, locate shafts at mid-position of end float.
6. Place bolt ring and screws in position. Using a torque wrench, tighten screws alternately and evenly until all screws are tightened to recommended torque in Table 1.

7. Check shaft alignment. Although the shafts may be perfectly aligned in installation, some parallel and angular misalignment may develop in usage due to shifting of the driving and driven units. It is desirable to align the coupling as accurately as possible at installation to minimize flexing of the flexible element caused by the shaft misalignment which usually develops in usage.

Check both parallel and angular alignments by mounting indicators near the OD of the flange (See Figure 2) and rotating the shafts through 360°. For a good installation neither indicator reading should exceed value "C" in Table 1. Both alignments should be rechecked after any repositioning.

The cutout, which is included with the coupling, must be installed to protect against excessive heat which may be generated in the Flexidyne mechanism by prolonged or frequent slipping. It can be hooked up to automatically interrupt the current and, if desired, activate a bell, light or other warning device. For hazardous atmospheres special explosion-proof cutouts are available.

START UP

1. Remove one of the filler plugs and install one-half the proper amount of flow charge specified in Table 2. Replace and tighten filler plug, making sure that no flow charge is trapped in the threads. Remove other filler plug and install the remaining one-half of the specified amount of flow charge repeating the same procedure. Tighten filler plugs to recommended torque in Table 1.
2. Attach AC ammeter (conventional clamp-on or equivalent) to one line of the AC motor. Set range to cover 200% of motor nameplate current.
3. Note the maximum allowable acceleration time for Flexidyne coupling as stated in Tables 2 and 3.

Note: Table 2 lists starting time capacity for starting cycles occurring more than once every 2 hours.

4. Push start button. Observe motor current during load acceleration and number of seconds required to reach full speed (Figure 3).

Increase amount of flow charge if:

- a. Acceleration time reaches maximum allowable before load is up to speed. Turn off power immediately if this time is reached.
- b. Acceleration amperage is below the motor nameplate value.

Decrease amount of flow charge if:

- a. Acceleration time is less than 1-1/2 seconds.
- b. Acceleration amperage is above 200% of motor nameplate value.

5. Once satisfactory operation has been obtained record the following for future reference:

- The amount of flow charge.
- Starting current.
- Acceleration Time.

The amount of flow charge in the Flexidyne coupling determines the acceleration time for a given load. Slower acceleration times will occur when less flow charge is used and faster acceleration, from stop to full speed, will be observed with greater amounts of flow charge.

CAUTION: The rotor of the Flexidyne coupling must slip during acceleration to allow flow charge to become evenly distributed in the Flexidyne housing. Therefore, DO NOT ALLOW FLEXIDYNE MECHANISM TO RUN "FREE" (that is, without a load on the driven end), otherwise an out of balance condition may result, damaging equipment.

START UP FOR DUPLEX COUPLINGS

1. The flow charge recommended in Table 2 is the amount per cavity required. To assure a more even initial distribution of flow charge, remove filter plugs and pour 1/2 of recommended amount in both cavities. Replace filler plugs, being careful to clear threads of any flow charge. Manually rotate the Flexidyne housing several turns. Remove filler plugs and pour in remaining amount of flow charge. Clear threads as before, replace filler plugs and torque to 700 in-lbs.
2. Attach AC ammeter (conventional clamp-on or equivalent) to one line of the AC motor. Set range to cover 200% of motor nameplate current.
3. Note the maximum allowable acceleration time for Flexidyne as stated in Table 3.

NOTE: Table 3 lists starting time capacity for starting cycles occurring more than once every 2 hours.

4. Push start button. Observe motor current during load acceleration and number of seconds required to reach full speed (Figure 3).




Figure 3

Increase amount of flow charge by equal quantity in each cavity if:

- a. Acceleration time reaches maximum allowable before load is up to speed. Turn off power immediately if this time is reached.
- b. Acceleration amperage is below the motor nameplate value.

Decrease amount of flow charge by equal quantity in each cavity if:

- a. Acceleration time is less than 1-1/2 seconds.
 - b. Acceleration amperage is above 200% of the motor nameplate value.
5. Once satisfactory operation has been obtained record the following for future reference:
 - The amount of flow charge.
 - Starting current.
 - Acceleration Time.

The amount of flow charge in the Flexidyne coupling determines the acceleration time for a given load. Slower acceleration times will occur when less flow charge is used and faster acceleration, from stop to full speed, will be observed with greater amounts of flow charge.

CAUTION: The rotor of the Flexidyne coupling must slip during acceleration to allow flow charge to become evenly distributed in the Flexidyne housing. Therefore, DO NOT ALLOW FLEXIDYNE MECHANISM TO RUN "FREE" (that is, without a load on the driven end), otherwise an out of balance condition may result, damaging equipment.

OPERATION

The Flexidyne coupling should start the load smoothly and without delay, provided the proper amount of flow charge has been used. Should the acceleration time exceed the maximum allowable in Table 2, shut off power to the Flexidyne coupling immediately. Allow the Flexidyne coupling to cool, then add small amounts of flow charge until proper acceleration is observed.

Vibration is an indication of accelerating too rapidly and not allowing flow charge to become evenly distributed in the Flexidyne housing. This can be corrected by removing small amounts of flow charge until vibration subsides. Other causes of vibration are, undersize shafting, unit not installed far enough on shaft or worn bore in the unit.

Slippage — The Flexidyne coupling can, without slipping, transmit overloads up to 130% of its pre-set starting torque. Should this breakaway torque be exceeded, the Flexidyne mechanism will slip and generate heat (see Overload Protection). Although slippage usually indicates increased loads, it can also be caused by worn flow charge or a worn rotor especially if the Flexidyne mechanism has been in operation for some time. The necessity to replace either a rotor or flow charge will be made evident by a loss in power transmitting capacity of the Flexidyne coupling.

To Replace Flexible Element

1. Remove screws from bolt ring and place bolt ring on shaft.
2. Remove screws, back off clamp ring and remove flexible element. (It may be necessary to back off one shaft to allow room.)
3. Install new flexible element per INSTALLATION.

OVERLOAD PROTECTION

A Thermal Cutout is available from DODGE® and is recommended for Flexidyne coupling Size 987 where slippage (due to overloads, starting or reversing) is frequent or prolonged. Its function is to protect against excessive heat which may be generated by the Flexidyne coupling. A Speed Drop Cutout is available from Dodge for Flexidyne coupling Size 1196 for installation where overloads or jamming may occur. For Size 15716, 18172, 22172 & 27192, single or double cavity, a speed drop cutout is included with the Flexidyne coupling and must be installed regardless of the application.

Either unit can be installed to send a signal to interrupt the motor current and, if desired, activate a bell, light or other warning device. Cutout switches are intended for use in control circuits only and are not recommended for DC current nor should they be used directly in the line to the motor. Both units are available in special explosion proof models for hazardous atmospheres.

MAINTENANCE

For average industrial applications involving 3 or 4 starts per day of not more than 6 seconds acceleration time each, the flow charge should be changed every 10,000 hours of operation. For more severe conditions, visually inspect flow charge at more frequent intervals; it should be changed when it has deteriorated to a half powder, half granular condition. Visual inspections should continue until enough flow charge changes have been made to adequately establish a schedule for changing Flexidyne flow charge. See Chart of Flexidyne Mechanism Flow Charge Analysis.

NOTE: The Flexidyne mechanism has been lubricated at the factory and no further lubrication is required. Never apply grease, oil or any other foreign material to the flow charge.

THERMAL CAPACITY

Since there is slippage within the flow charge during acceleration, heat is generated from friction. The thermal capacity of the Flexidyne mechanism is based on balancing this heat generated during acceleration against the cooling time between accelerations. The amount of heat generated is determined by the amount of horsepower dissipated by slipping and the duration of each acceleration. If the flow charge weight is light, the heat generated will not be as great as that which would be generated with a heavier flow charge, when compared at the same acceleration time. A longer time between starts will dissipate more heat; therefore, higher starting horsepower may be transmitted, or longer acceleration times may be allowable. (See Starting Cycle) Acceleration times shown in Table 2 are for starting frequencies of one start per hour or less. If starting frequency is more than once per hour, use acceleration time for actual starting cycle shown in Table 3.

Acceleration times listed in Tables 2 and 3 are the MAXIMUM permissible for the various starting frequencies listed. The MINIMUM acceleration time required for proper Flexidyne coupling operation is 1 to 1-1/2 seconds. This is the time required for the flow charge to be uniformly distributed around the housing cavity before the unit "locks in". Any acceleration time between the minimum and maximum listed is acceptable, although a shorter acceleration time will generally provide longer wear life. For applications requiring a specific acceleration time (within these limits) flow charge may be added or removed to produce the required results.

Stalled — If a jam-up stalls the drive, the motor continues to run and the Flexidyne coupling slips. This causes heat to be generated at twice the rate of normal acceleration. Therefore, the allowable slipping time, when stalled, is half the allowable acceleration time given in Table 2.

Starting Cycle — The time from the beginning of one acceleration to the beginning of the next. Allowable acceleration times in Table 3 are based on the assumption that the Flexidyne coupling will be running continuously, except for a momentary stop before the next start. If the stop is more than momentary, decrease the actual starting cycle by one-half the stopped time before using Table 3. For example, with a 50 minute actual starting cycle of which 20 minutes is stopped time, decrease 50 by half of 20 to give 40 minutes as the starting cycle time to use for Table 3.

Grouped Starts — For several starts grouped together followed by uninterrupted running, add the acceleration times of all starts and consider it as the time for one start. The starting cycle would be the time from the beginning of one group of starts to the beginning of the next group.

Table 2 - Flow Chart Recommendations

Based on % Starting Torque for 1760 RPM NEMA Design B Motors																						
Rated Motor HP	Flexidyne Coupling Size	100% @ 1760 RPM				125% @ 1750 RPM				150% @ 1740 RPM				175% @ 1700 RPM				200% @ 1650 RPM				
		Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	
			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.		
15	987	15	2	9	76	18.8	3	0	58	22.3	3	7	58	25.5	3	13	39	28.3	4	2	28	
20	987	20	3	2	52	25	3	10	40	30	4	0	26	34	4	8	22	38	5	3	16	
25	1196	25	3	13	98	31	4	5	76	37	4	13	55	42	5	8	42	47	6	2	37	
30	1196	30	4	2	80	37	4	13	55	45	5	8	39	51	6	3	33	57	6	12	27	
40	1196	40	5	0	44	50	5	14	34	60	6	8	24	68	7	3	22	75	8	0	19	
50	1196	50	5	13	34	62	6	10	24	74	7	6	20	85	8	2	17	94	8	11	15	
60	15116	60	7	3	31	75	8	3	25	89	9	1	20	102	10	1	16	113	10	14	15	
75	15116	75	8	3	25	94	9	3	18	111	10	3	15	127	11	0	13	141	12	0	12	
100	15116	100	9	7	16	125	10	10	13	149	11	9	11	170	12	8	9	188	13	5	8	
125	D15131	125	7	3	30	156	8	6	24	186	9	4	19	212	10	4	15	236	11	1	14	
150	D15131	150	8	3	25	187	9	3	19	224	10	3	15	255	11	1	13	283	12	1	12	
200	D15131	200	9	7	16	250	10	10	13	298	11	10	11	341	12	9	9	
200	200	D181172	15	12	60	249	18	10	47	285	20	5	35	340	22	13	30	377	24	13	26	
250	250	D181172	18	9	47	312	21	0	35	370	23	2	28	424	25	3	23	470	27	0	20	

Based on % Starting Torque for 1175 RPM NEMA Design B Motors																					
Rated Motor HP	Flexidyne Coupling Size	100% @ 1175 RPM				125% @ 1160 RPM				150% @ 1150 RPM				175% @ 1130 RPM				200% @ 1100 RPM			
		Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.
			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.	
5 7-1/2 10 15	987	5.0	2	4	230	6.2	2	11	212	7.4	3	1	176	8.5	3	8	176	9.4	3	12	161
	987	7.5	3	0	191	9.3	3	9	163	11.1	3	14	134	12.7	4	4	134	14.1	4	12	126
	1196	10.0	4	3	480	12.4	4	13	439	14.8	5	10	360	17	6	3	360	19	7	0	325
	1196	15	5	14	394	18	6	5	343	22	7	0	222	25	7	14	222	28	9	0	171
20 25 30 40	1196	20	6	8	308	25	7	14	222	30	8	4	125	34	8	13	125	38	9	10	113
	15116	25	8	8	198	31	9	13	161	37	10	12	100	42	11	13	100	47	12	10	88
	15116	30	9	7	167	37	10	10	124	44	11	11	79	51	12	9	79	57	13	8	64
	15116	40	10	14	105	50	12	14	81	59	13	0	49	68	14	0	49	75	15	3	43
100 125 150	18172	100	15	12	60	124	18	7	47	148	20	9	30	170	22	13	30	189	24	13	26
	18172	125	18	7	47	155	21	1	35	185	23	3	23	212	25	3	23	236	27	3	20
	18172	150	20	5	35	186	22	15	26	222	25	0	19	254	27	0	19	29	29	4	16
300 350	22172	300	34	0	18	374	38	9	14	442	509	565
	22172	350	36	13	16	435	517	594	660
50 60 75	50	D15116	8	8	198	62	9	13	161	74	10	12	124	85	11	8	100	94	14	12	88
	60	D15116	9	7	167	75	10	10	124	89	11	11	96	102	12	9	79	113	13	8	64
	75	D15116	10	9	124	93	11	13	91	111	12	11	68	127	13	10	54	141	14	12	47
200 250	200	D181172	15	12	60	249	18	10	47	285	20	5	35	340	22	13	30	377	24	13	26
	250	D181172	18	9	47	312	21	0	35	370	23	2	28	424	25	3	23	470	27	0	20

Based on % Starting Torque for 875 RPM NEMA Design B Motors																					
Rated Motor HP	Flexidyne Coupling Size	100% @ 875 RPM				125% @ 870 RPM				150% @ 850 RPM				175% @ 840 RPM				200% @ 820 RPM			
		Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.	Starting HP	Flow Charge		Max Time in Sec.
			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.			Lbs.	Oz.	
2	987	2.0	2	0	1000	2.5	2	2	1000	2.9	2	10	890	3.4	2	14	750	3.7	3	3	669
3	987	3.0	2	9	862	3.7	3	2	669	4.4	3	7	475	5.0	3	11	310	5.6	4	0	297
5	1196	5.0	4	9	1000	6.2	5	6	904	7.3	6	3	816	8.4	6	13	728	9.4	7	6	648
7-1/2	1196	7.5	6	0	800	9.3	6	13	656	10.9	7	10	572	12.6	8	5	527	14.0	9	0	488
10	15116	10	8	6	560	12.4	9	8	498	14.6	10	9	440	16.8	11	7	383	18.7	12	5	334
15	15116	15	10	5	430	19	11	7	326	22	12	8	280	25	13	5	250	28	14	6	220
20	15116	20	11	12	300	25	12	13	250	29	13	14	210	34	15	1	178	38	15	8	156
40	18172	40	15	3	200	50	18	0	180	58	20	6	164	67	22	8	146	75	24	7	130
50	18172	50	17	14	180	62	20	4	156	73	22	14	134	84	24	14	115	94	26	14	103
60	18172	60	19	13	160	75	22	6	130	87	24	15	112	101	26	1	95	112	28	12	82
150	22172	150	37	5	57	186	41	6	49	219	45	8	39	252	48	6	30	281	50	0	25
300	22172	300	58	11	30	373	65	5	26	437	71	0	22	504	76	0	18	562	80	0	17
25	D15116	9	9	7	498	31	10	9	430	36	11	11	334	42	12	8	290	47	13	5	270
30	D15116	10	10	5	430	37	11	7	326	44	12	8	280	50	13	5	250	56	14	6	220
75	D18172	14	14	8	200	93	17	2	188	109	19	11	172	126	21	13	154	141	23	12	140
100	D18172	17	17	14	180	124	20	4	156	146	22	14	134	168	24	14	115	187	26	14	103
125	D18172	20	20	2	160	155	22	13	126	182	25	7	107	210	27	4	90	234	29	4	76

Notes:
 Flow Charge for one cavity listed.
 Maximum Allowable Acceleration Time for one start per hour or less (For several starts grouped together followed by uninterrupted running, add the acceleration times of all starts and consider it as the time for one start. The corresponding cycle time is the time between the beginning of one group of starts to the beginning of the next group.) Proper application of the Flexidyne coupling requires that the load be connected. Without connected load acceleration time may be too fast to allow charge to be distributed for proper balance.

Table 3 - Flexidyne Coupling Thermal Capacity

Single Cavity Flexidyne Coupling Size	Starting HP	Maximum Allowable Acceleration Time in Seconds for Standard Motor Speeds at Various Starting Cycles											
		2 Hours			1 Hour			30 Min.			15 Min.		
		870	1160	1750	870	1160	1750	870	1160	1750	870	1160	1750
987	2.5	1000	1000	1000	600
	5.0	310	230	310	230	310	230	180	190
	9.1	220	166	220	166	220	166	130	135
	10.0	150	135	150	135	150	135	120	118
	15.0	120	76	120	76	120	76	100	66
	17.5	110	64	110	64	110	64	92	55
	20	52	52	52	45
				40			40			40			35
	25	26	26	26	22
	30	21	21	21	18
987	35	16	16	16	15
	38
987	2.5	425	225	90	45
	5.0	140	160	70	100	27	42	13	22
	9.1	100	110	50	72	20	29	10	15
	10.0	100	100	65	70	26	28	13	14
	15.0	85	58	50	38	21	15	11	7
	17.5	78	48	47	31	19	12	9	6
	20	38	25	10	5
				30			20			8			4
	25	18	12	5
	30	15	10	4
1196	35	13	9	3
	38
1196	5	1000	950	700	450
	10	600	480	560	480	440	400	280	270
	20	320	308	116	300	308	116	230	257	116	150	175	96
	30	136	80	136	80	115	80	80	67
	40	107	44	107	44	89	44	63	37
	50	78	34	78	34	64	34	46	28
	60	24	24	24	20
	70	21	21	21	17
	80	18	18	18	15
	90	16	16	16	13
1196	100	14	14	14	12
1196	5	290	130	46	21
	10	180	200	80	100	30	40	13	20
	20	90	130	80	42	65	50	15	26	21	6	13	11
	30	60	56	30	35	12	14	6	7
	40	47	32	23	20	9	8	4	4
	50	35	24	17	15	6	6	3	3
	60	17	10	4
	70	14	9	3
	80	12	8
	90	11	7
1196	100	10	6

Table 3 - Flexidyne Coupling Thermal Capacity

Single Cavity Flexidyne Coupling Size	Starting HP	Maximum Allowable Acceleration Time in Seconds for Standard Motor Speeds at Various Starting Cycles											
		2 Hours			1 Hour			30 Min.			15 Min.		
		870	1160	1750	870	1160	1750	870	1160	1750	870	1160	1750
15116	10	560	560	460	350
	20	300	230	300	230	240	230	170	190
	30	200	167	200	167	160	167	125	140
	40	145	105	145	105	120	105	90	90
	50	81	35	81	35	81	34	68	30
	60	56	31	56	31	56	30	47	27
	70	47	27	47	27	47	26	40	23
	80	39	23	39	23	39	22	33	20
	90	33	20	33	20	33	18	28	16
	100	28	16	28	16	28	15	24	13
	110	15	15	14	12
	120	14	14	13	11
	130	13	13	12	10
	140	12	12	11	10
	150	11	11	10	9
	160	10	10	10	8
	170	9	9	9	8
	180	9	9	9	7
	190	8	8	8	7
	200	8	8	7	6
		10 Min.			5 Min.			2 Min.			1 Min.		
		870	1160	1750	870	1160	1750	870	1160	1750	870	1160	1750
15116	10	260	160	85	53
	20	130	160	80	100	42	44	25	23
	30	95	117	60	73	32	32	19	17
	40	68	74	42	46	22	20	14	10
	50	57	28	35	19	15	12	7	8
	60	40	25	25	16	11	10	5	7
	70	34	21	21	14	9	9	5	6
	80	28	17	17	12	7	7	4	5
	90	24	15	14	10	6	6	3	4
	100	20	13	12	9	5	5	3	3
	110	12	8	5	3
	120	11	7	4
	130	10	7	4
	140	9	6	3
	150	8	6	3
	160	8	6
170	7	5	
180	7	5	
190	6	4	
200	6	4	

Table 3 - Flexidyne Coupling Thermal Capacity

Single Cavity Flexidyne Coupling Size	Starting HP	Maximum Allowable Acceleration Time in Seconds for Standard Motor Speeds at Various Starting Cycles											
		2 Hours			1 Hour			30 Min.			15 Min.		
		720	870	1160	720	870	1160	720	870	1160	720	870	1160
18172	20	600	560	450	300
	40	370	200	350	200	280	160	180	115
	60	220	160	200	160	160	130	100	94
	80	160	120	150	120	120	100	74	72
	100	96	60	96	60	80	56	58	44
	120	72	49	72	49	60	45	45	35
	140	62	38	62	38	52	35	38	26
	160	52	33	52	33	44	30	32	23
	180	28	28	26	20
	200	25	25	23	18
	220	22	22	20	16
	240	20	20	18	14
	260	18	18	17	13
	280	16	16	15	11
	300	14	14	13	10
		10 Min.			5 Min.			2 Min.			1 Min.		
		720	870	1160	720	870	1160	720	870	1160	720	870	1160
18172	20	200	90	35	16
	40	120	90	54	44	21	17	10	8
	60	66	72	32	35	12	13	5	6
	80	48	54	23	27	8	10	4	5
	100	43	32	21	17	8	7	4
	120	32	26	16	13	6	5	3
	140	27	20	13	10	5	4
	160	22	17	11	9	4	4
	180	15	8	3
	200	13	7
	220	12	6
	240	10	5
	260	9	5
	280	8	4
	300	7	4
		2 Hours			1 Hour			30 Min.			15 Min.		
		720	870	1160	720	870	1160	720	870	1160	720	870	1160
22172	60	290	270	224	150
	80	175	170	140	92
	100	110	96	110	90	90	76	62	55
	120	94	78	93	74	77	62	53	40
	140	78	60	76	58	64	48	44	35
	160	55	53	44	24	31
	180	50	48	40	28
	200	44	43	36	25
	250	30	22	30	22	25	21	18	17
	300	24	18	24	18	20	18	14	14
	350	19	16	18	16	15	15	11	12
	400	13	13	12	10
	450	11	11	10	8

Table 3 - Flexidyne Coupling Thermal Capacity

Single Cavity Flexidyne Coupling Size	Starting HP	Maximum Allowable Acceleration Time in Seconds for Standard Motor Speeds at Various Starting Cycles											
		2 Hours			1 Hour			30 Min.			15 Min.		
		720	870	1160	720	870	1160	720	870	1160	720	870	1160
27192	80	240	240	170	130
	100	196	196	143	108
	150	94	94	74	55
	200	60	42	60	42	50	39	35	30
	250	49	36	49	36	40	33	28	26
	300	38	30	38	30	30	27	22	22
	350	32	27	32	27	25	24	19	19
	400	26	24	26	24	21	22	16	17
	450	23	21	23	21	19	19	14	15
	500	20	18	20	18	17	17	12	13
	550	19	17	19	17	16	15	11	12
	600	15	15	14	11
	650	14	14	13	10
		10 Min.			5 Min.			2 Min.					
		720	870	1160	720	870	1160	720	870	1160	720	870	1160
27192	80	90	45	18	9
	100	74	37	15	8
	150	37	18	7	4
	200	24	24	12	12	5	5
	250	19	20	9	10	4
	300	15	17	7	9	3
	350	12	15	6	8
	400	10	14	5	7
	450	9	12	4	6
	500	8	11	4	5
	550	7	10	5
	600	9	4
	650	8	4
		2 Hours			1 Hour			30 Min.			15 Min.		
		870	1160	1750	870	1160	1750	870	1160	1750	870	1160	1750

Table 3 - Flexidyne Coupling Thermal Capacity

Single Cavity Flexidyne Coupling Size	Starting HP	Maximum Allowable Acceleration Time in Seconds for Standard Motor Speeds at Various Starting Cycles											
		560	230	560	230	460	230	350	190
015	20	560	230	560	230	460	230	350	190
	40	300	167	300	167	240	167	170	140
	60	200	105	200	105	160	105	125	90
	80	145	81	35	145	81	35	120	81	34	90	68	30
	100
	120	56	31	56	31	56	30	47	27
	140	47	27	47	27	47	26	40	23
	160	39	23	39	23	39	22	33	20
	180	33	20	33	20	33	18	28	16
	200	28	16	28	16	28	15	24	13
	220	15	15	14	12
	240	14	14	13	11
	260	13	13	12	10
	280	12	12	11	10
	300	11	11	10	9
	320	10	10	10	8
	340	9	9	9	8
	360	9	9	9	7
	380	8	8	8	7
	400	8	8	7	6
		10 Min.			5 Min.			2 Min.			1 Min.		
		870	1160	1750	870	1160	1750	870	1160	1750	870	1160	1750
015	20	260	160	100	85	53
	40	130	160	80	73	42	44	25	23
	60	95	117	60	46	32	32	19	17
	80	68	74	42	35	22	20	14	10
	100	57	28	19	15	12	7	8
	120	40	25	25	16	11	10	5	7
	140	34	21	21	14	9	9	5	6
	160	28	17	17	12	7	7	4	5
	180	24	15	14	10	6	6	3	4
	200	20	13	12	9	5	5	3	3
	220	12	8	5	3
	240	11	7	4
	260	7	4
	280	6	3
	300	6	3
	320	6
	340	5
	360	5
	380	4
	400	4

Table 3 - Flexidyne Coupling Thermal Capacity

Single Cavity Flexidyne Coupling Size	Starting HP	Maximum Allowable Acceleration Time in Seconds for Standard Motor Speeds at Various Starting Cycles											
		2 Hours			1 Hour			30 Min.			15 Min.		
		720	870	1160	720	870	1160	720	870	1160	720	870	1160
018	40	600	560	450	300
	80	370	200	350	200	280	160	180	115
	120	220	160	200	160	160	130	100	94
	160	160	120	150	120	120	100	74	72
	200	96	60	96	60	80	56	58	44
	240	72	49	72	49	60	45	45	35
	280	62	38	62	38	52	35	38	26
	320	52	33	52	33	44	30	32	23
	360	28	28	26	20
	400	25	25	23	18
	440	22	22	20	16
	480	20	20	18	14
	520	18	18	17	13
	560	16	16	15	11
	600	14	14	13	10
		10 Min.			5 Min.			2 Min.			1 Min.		
		720	870	1160	720	870	1160	720	870	1160	720	870	1160
		720	870	1160	720	870	1160	720	870	1160	720	870	1160
018	40	200	90	35	16
	80	120	90	54	44	21	17	10	8
	120	66	72	32	35	12	13	5	6
	160	48	54	23	27	8	10	4	5
	200	43	32	21	17	8	7	4
	240	32	26	16	13	6	5	3
	280	27	20	13	10	5	4
	320	22	17	11	9	4	4
	360	15	8	3
	400	13	7
	440	12	6
	480	10	5
	520	9	5
	560	8	4
	600	7	4

Parts Replacement Sizes 987, 1196 & 15116:

DISASSEMBLY:

1. Remove bolt ring and back off one of the shafts.
2. Remove driven hub from driven shaft. Remove filler plug and drain flow charge from Flexidyne housing.
3. Remove housing screws and housing cover. Remove cover seal retainer by inserting a small pin in the holes for the drive screws and tapping on pin to remove drive screws. Remove cover seal.
4. Remove the six rotor screws and slide driven hub off drive housing. Remove the rotor.
5. Remove ball bearing snap ring and ball bearing. To remove ball bearing place three equal length 11/64" to 3/16" diameter pins in the three holes in the end of the drive housing and press against the pins.
6. Remove rotor retainer and bearing seal shield. (Note shield is not used on 15116 coupling). Remove seal felt and housing seal.
7. Remove snap ring and bronze bushing from drive housing.

REASSEMBLY:

1. Install housing seal (red in color) on rotor retainer. Place seal felt and seal shield in position in drive housing. Install rotor retainer making sure housing seal is properly seated in drive housing.
2. Press ball bearing on drive housing. Press against inner (not outer) race. Rotor retainer must not be cocked when bearing enters it. Check after pressing to make sure rotor retainer rotates freely in seal. Install bearing snap ring.
3. Slide bronze bushing on drive housing and install snap ring.
4. Place rotor and driven hub in position. Install and tighten the 6 rotor screws.
5. Install cover seal (gray in color) in housing cover. Line up holes in seal retainer with holes in housing cover and install drive screws.
6. Place housing cover in position on drive housing so that filler plugs are diametrically opposed. Install and tighten housing screws.
7. Install flow charge and filter plug per Step 1, STARTUP.

Parts Replacement Sizes 18172, 22172 & 27192:

DISASSEMBLY:

1. Remove bolt ring and back off one of the shafts.
2. Remove Flexidyne mechanism from driven shaft. Remove one of the filler plugs and drain flow charge from Flexidyne housing.
3. Remove housing screws and housing cover. Remove cover seal retainer by inserting a small pin in the holes for the drive screws and tapping on pin to remove drive screws. Remove cover seal.
4. Remove rotor screws and remove rotor.
5. Remove ball bearing inner race retaining ring and slide driven hub off drive housing. Remove housing seal and seal felt from drive housing.
6. Remove ball bearing outer race retaining ring and remove driven end bearing from driven hub. To remove bearing, insert a plug in the bore and press on right hand end (as viewed in the drawing) of bearing. Press against outer (not inner) race of bearing.
7. Remove coupling end bearing from drive housing by placing three equal length 11/64" to 3/16" diameter pins in the three holes in end of the drive housing and pressing against the pins.

Note: On 27192 PH Flexidyne couplings remove bearing spacer before removing coupling end bearing.

REASSEMBLY:

1. Press coupling end bearing onto drive housing until it bottoms out. Press against inner (not outer) race of bearing. Slide bearing spacer onto drive housing (bearing spacer used only on 27192 PH Flexidyne couplings).
2. Press driven end bearing into driven hub until it bottoms out. Press against outer (not inner) race. Install bearing outer race retaining ring.
3. Stand driven hub on right hand (as viewed in the drawing) and place housing seal (red in color) and seal felt in position on end of driven hub.
4. Slide drive housing into driven hub and tap gently until drive housing starts to pass over housing seal. The seal may tend to twist. A wire or other blunt probe may be used to push the outer corner of the seal into position in the drive housing. Rotating the drive housing may also help to position the seal properly. When seal is properly positioned tap drive housing into place. Carefully turn the Flexidyne mechanism over and stand on adapter plate end. Install bearing outer race retaining ring.
5. Place rotor in position. Install and tighten rotor screws.
6. Install cover seal (gray in color) in housing cover. Line up holes in seal retainer with holes in housing cover and install drive screws.
7. Place housing cover in position on drive housing so that filler plugs are diametrically opposed. Install and tighten housing screws.
8. Install flow charge and filler plug per Step 1, STARTUP.

TO REPLACE FLEXIBLE ELEMENT:

1. Remove screws from bolt ring and place bolt ring on shaft.
2. Remove screws, back off clamp ring and remove flexible element. It may be necessary to back off one shaft to allow room.
3. Install new flexible element per Step 2 INSTALLATION.

PARTS REPLACEMENT D15116, D15131, D18172

Replacement of seals - (refer to parts drawing).

1. Remove bolt ring screws and back off bolt ring. Back off one shaft.
2. Remove driven hub from shaft per instruction manual for Taper-Lock bushing. Remove Flexidyne coupling from driven shaft.
3. Remove filler plug and pour out flow charge, being careful not to spill any.
4. Remove housing screws and housing cover.
5. Remove rotor screws, outside rotor and housing spacer.
6. **Size D15:** Remove rotor screws, driven hub, inside rotor, retaining ring, ball bearing and rotor retainer in that order.

NOTE: To remove ball bearing, replace every other drive hub screw with pins of equal length and 13/32" to 27/64" diameter. Press pins equally against bearing.

Size D18: Remove retaining ring and driven hub with inside rotor attached.

7. Remove and replace housing seal and bearing felt seal as follows: Set seals in place on rotor retainer (Size D15) only or driven hub (Sizes D18, D22 & D27). Install housing in place on rotor retainer (Size D15) or driven hub (Sizes D18, D22 or D27) and tap gently until housing starts to pass over housing seal, making sure that seal is not cocked. After seal is in position, tap housing into place.
8. **Sizes D18:** Replace retaining ring.
Size D15 only: Press ball bearing onto housing.

NOTE: Press against inner (not outer) bearing race. Rotor retainer must not be cocked when outer bearing race enters it. Check this, after pressing bearing, by running rotor retainer to see that it rotates freely in housing seal.

Install retaining ring, inside rotor and driven nub. Install rotor screws and tighten per recommended torque in Table 1.

9. Install housing spacer, outside rotor, and rotor screws and tighten per recommended torque in Table 1.
10. To replace cover seal in housing cover, first remove seal retainer by inserting a small rod in drive screw holes and tap on rod to remove drive screws. Remove and replace cover seal; reinstall retainer and drive screws. Place housing cover in position.
11. Install housing screws and tighten to recommended torque in Table 1.
12. Replace flow charge and filler plug per Step 1, STARTUP.
13. Reinstall Flexidyne assembly per INSTALLATION.

Replacement of bearings and seals

Steps 1 through 13 cover the replacement of seals on all sizes and the replacement of large bearing on D15 only. To replace small bearing on D15 and both bearings on D18, use following steps.

Size D15 - After performing Steps 1 through 6 Replacement of Seals:

1. Insert a plug in the bore of the hub and press on end (right end as viewed in drawing) of bearing. Press against outside (not inner) race.
2. Replace bearing in driven hub by pressing on outer (not inner) race.
3. Bearing is removed and replaced in Steps 6 and 8 above.

Sizes D18 - After performing Steps 1 through 7, Replacement of Seals:

1. Removal of bearing is similar to removal of bearing on D15 in Step 6 above, except for diameter of pins, 1/2" to 17/32" diameter on D18.
2. Replace bearing in housing by pressing on the inner (not outer) race until it bottoms out.
3. Remove bearing by removing retaining ring from driven hub. Insert a plug in bore of hub and press on end (right end as viewed in drawing) of bearing. Press against inner race.
4. Replace bearing in driven hub by pressing on outer (not inner) race until it bottoms. Replace retaining ring.

Replacement of rotors only


Size D15:

Perform Steps 1 through 6 above for removal of inside rotor only. Replace per Steps 8 through 13, Replacement of Seals.

Sizes D18:

Perform steps 1 through 7 above to remove outer rotor. Remove rotor screws and inside rotor. Replace inside rotor and rotor screws and tighten per recommended torque in Table 1. Perform Steps 8 through 13, Replacement of Seals.

Replacement Parts for 987, 1196, 15116, 18172, 22172 & 27192 PH Flexidyne Couplings



Reference	Name of Part	No. Required	Part Numbers					
			987	1196	15116	18172	22172	27192
2	Taper-Lock Bushing ①	1	1610	2012	2517	3535	3535	4040
4	Taper-Lock Bushing ①	1	2517	2517	3030	3535	4040	5050
6	FLANGE ASSEMBLY ②	1	010603	010604	010606
8	③ Flange	1	010613	010614	010616
9	③ External Clamp Ring	1	010623	010624	010626
10	③ Internal Clamp Ring	1	011047	011048	011050
11	③ Clamp Ring Screw	⑤	411253	411253	411257
	③ Hardened Flat Washer	⑤	419085	419085	419086
12	TYPE 'H' FLANGE ASSEMBLY ②	1	011134	011134	011137
14	③ Type 'H' Flange	1	011014	011014	011017
15	③ Clamp Ring	1	011054	011054	011057
16	③ Clamp Ring Screw	8	411584	411584	411586
	③ Plain Washer	8	419079	419079	419081
17	TYPE 'F' FLANGE ASSEMBLY ②	1	011154	011154	011157
18	③ Type 'F' Flange	1	011034	011034	011037
19	③ Clamp Ring	1	011054	011054	011057
20	③ Clamp Ring Screw	8	411584	411584	411586
21	③ Plain Washer	8	419079	419079	419081
22	Flange Spacer Ring	1	011274	011274
23	Flexible Element	1	011227	011228	011230	011234	011234	011236
24	Bolt Ring	1	011685	011686	011687	011689	011689	011690
25	Bolt Ring Screw	⑥	417371	417376	417376	417382	417382	417382
26	Lockwasher	⑥	419046	419047	419047	419050	419050	419050
27	④ Bolt Ring Pin	2	420150	420150	420150	420152	420152	420152
28	Adapter Plate	1	309449	311449	315449	318449	322449	327449
29	Adapter Screw	⑦	417171	415122	415042	411203	411162	411192
30	Lockwasher	⑦	419050	419014	419020	419020	419016	419018
31	Drive Housing	1	309079	311079	315077	318202	322202	327202
32	HOUSING COVER AND SEAL ASSEMBLY ②	1	391457	391464	491494	391250	391248	391249
33	③ Housing Cover	1	309080	311081	315079	318203	322203	327203
34	③ Cover Seal w/Ret. & D12 SCR's	1	391254	391255	391256	391260	391258	391259
35	Housing Screw	⑧	411039	411057	411072	411108	411102	411126
36	Lockwasher	⑧	419009	419010	419011	419013	419016	419014
37	Filler Plug	2	308021	308021	315021	315021	315021	315021
38	Lockwasher	2	419121	419121	419123	419123	419123	419123
		6	407083	407085	407087	407091
40	Rotor	1	309006	311006	315006	318006	322006	327006
41	Rotor Retainer	1	309207	311207	315207
42	Rotor Screw	⑨	415056	415058	415064	415114	415120	415122
43	Lockwasher	⑨	419011	419014	419014
44	Housing Seal	1	309036	311038	315017	318038	322238	327238
45	Driven Hub	1	309205	311205	315205	318205	322205	327205
50	Ball Bearing	1	391210	391219	391227
51	Bearing Retainer Ring	1	421013	421019	421027
52	Ball Bearing (Driven End)	1	391227	391271	391272
53	Ball Bearing (Motor End)	1	391235	391238	391272
54	Bearing Spacer	1	327213
55	Inner Race Retaining Ring	1	421088	421100	421101
56	Outer Race Retaining Ring	1	421039	421041	421044
60	Seal Felt	1	309024	311024	315024	318224	322224	327224
62	Seal Shield	1	309027	311027
64	Bronze Bushing	1	309212	311212	315212
66	Bushing Retaining Ring	1	421009	421014	421022

① When ordering Taper-Lock bushings specify the size number and the bore.

② Includes part listed immediately below.

③ Parts marked make up the assemblies under which they are listed.

④ Not shown on drawing.

⑤ 5 required on size 987; 6 required for sizes 1196 and 15116.

⑥ 6 required for size 1196; 8 required for sizes 987, 1196, 18172, 22172 and 27192.



⑦ 6 required for sizes 987, 1196, 15116, 18172 and 22172; 7 required for size 27192.

⑧ 6 required for sizes 987, 1196, 15116 and 18172; 9 required for sizes 22172 and 27192.

⑨ 6 required for sizes 987, 1196, 15116 and 18172; 8 required for sizes 22172 and 27192.

⑩ Cover seal includes retainer and drive screws.

Parts for D15116, D15131, D18172 Duplex Flexidyne Couplings



Ref	Name of Part	No. Required	Part Numbers		
			D15116	D15131	D18172
2	Taper-Lock Bushing with screws (Drive End) ①	1	2517	2517	3535
4	Taper-Lock Bushing with screws (Driven End) ①	1	3030	3030	3535
5	TAPER-LOCK FLANGE ASSEMBLY ②	1	010606	010607
6	③ Flange	1	010616	010617
7	③ External Clamp Ring	1	010626	010627
12	③ Internal Clamp Ring	1	011050	010632
13	③ Clamp Ring Screw	6	411257	411261
13	③ Washer	6	419086	419086
9	TYPE H FLANGE ASSEMBLY ②	1	011134
11	③ Type H Flange	1	011014
12	③ Clamp Ring	1	011054
13	③ Clamp Ring Screw	④	411584
13	③ Washer	④	419079
10	TYPE F FLANGE ASSEMBLY ②	1	011154
11	③ Type F Flange	1	011034
12	③ Clamp Ring	1	011054
13	③ Clamp Ring Screw	④	411584
13	③ Washer	④	419079
14	Flange Spacer Ring	1	011274
16	Flexible Element	1	011230	011231	011234
18	Bolt Ring	1	011687	011688	011689
20	Bolt Ring Screw	8	417376	417374	417382
21	Lockwasher	8	419047	419047	419050
⑨	Bolt Ring Pin	2	420150	420151	420152
22	Adapter Plate	1	315449	315450	318449
24	Adapter Screw	6	415042	411203	411203
25	Lockwasher	6	419020	419020	419020

Ref	Name of Part	No. Required	Part Numbers		
			D15116	D15131	D18172
28	DRIVE HUB AND HOUSING ASSEMBLY ②	1	391263	391263	391264
29	③ Drive Hub Screw ⑧	6	415042	411203	417220
30	③ Lockwasher ⑧	6	419020	419020	419052
32	HOUSING COVER AND SEAL ASSEMBLY ②	1	391246	391246	391250
33	③ Housing Cover	1	315079	315079	318203
33	③ Cover Seal (Gray)	1	315023	315023	318223
34	Housing Spacer	1	315080	315080	318241
36	Housing Screw	⑤	411420	411420	411242
37	Lockwasher	⑤	419011	419011	419013
81	Hex Nut	⑤	407087	407087	407091
38	Filler Plug	2	315021	315021	315021
39	Lockwasher	2	419123	419123	419123
56	Rotor	2	315006	315006	318006
58	Rotor Retainer	1	315207	315207
60	Rotor Screw (Inside)	⑥	415109	415709	415114
62	Rotor Screw (Outside)	⑥	415112	415112	415114
63	Lockwasher	⑦	419010	419010	419011
64	Housing Seal (Red)	1	315017	315017	318038
70	Driven Hub	1	315405	315405	318243
72	Small Bearing	1	391230	391230	391227
74	Large Bearing	1	391227	391227	391235
75	Bearing Spacer	1
76	Inner Race Retaining Ring	1	421088
77	Outer Race Retaining Ring	1	421047
78	Retaining Ring	1	421028	421028
80	Seal Felt	1	315024	315024	318224

① Specify bore and bushing size number which is shown as Part Number

② Includes parts listed immediately below

③ Parts make up the assemblies under which they are listed

④ 8 required for D18172

⑤ 5 required for D15116 & D15131; 6 required for D18172; 9 required

⑥ 6 required for D15116. D15131, D18172

⑦ 12 required for D15116, D15131, and D18172

⑧ Not shown on D18172 drawing

⑨ Not shown on drawings

Flexidyne Mechanism Trouble Analysis		
Symptom	Cause	Cure
Vibration	<ol style="list-style-type: none"> 1. Misalignment 2. Bent shaft 3. Excess flow charge 4. Fused flow charge 5. Improper installation – Output shaft jammed against housing 	<ol style="list-style-type: none"> 1. Realign drive or coupling. 2. Replace or straighten. 3. Remove small amount of flow charge. 4. Correct the overload. 5. Readjust spacing between shafts and Flexidyne housing.
Erratic Acceleration	<ol style="list-style-type: none"> 1. Breakdown of flow charge 2. Caked flow charge 3. Below minimum amount of flow charge 	<ol style="list-style-type: none"> 1. Replace flow charge. 2. Moist environment – use stainless flow charge. 3. Add flow charge.
Flexidyne Mechanism Doesn't Slip	<ol style="list-style-type: none"> 1. Improper installation – Output shaft jammed against housing 2. Flow charge in bearings – causing bearing seizure 	<ol style="list-style-type: none"> 1. Readjust spacing between shafts and Flexidyne housing. 2. Replace seals, bearings and flow charge or replace Flexidyne mechanism.
Excessive Slippage	<ol style="list-style-type: none"> 1. Not enough flow charge 2. Overload 3. Worn flow charge 4. Worn rotor 	<ol style="list-style-type: none"> 1. Add flow charge. 2. Relieve overload 3. Replace flow charge. 4. Replace rotor.
Poor or short flow charge life	<ol style="list-style-type: none"> 1. Excessive slip at start up 2. Excessive inching or jogging of machine 	<ol style="list-style-type: none"> 1. Add flow charge to reduce starting time. 2. Install time delay in motor control circuit.

Flexidyne Mechanism Flow Charge Analysis	
Condition	Cause
<ol style="list-style-type: none"> 1. Red oxide color, granular consistency 2. Red oxide color, powdery consistency, possibly with powdery flakes 3. Black, powdery 4. Red oxide, powdery and chunky 5. Clumping of flow charge 	<ol style="list-style-type: none"> 1. Normal after some usage. 2. Worn-out, can cause Flexidyne mechanism damage. 3. Rotor worn, excessive slip and heat. 4. Worn-out and moisture present. 5. Moisture present, use stainless flow charge.



P.O. Box 2400, Fort Smith, AR 72902-2400 U.S.A., Ph: (1) 479.646.4711, Fax (1) 479.648.5792, International Fax (1) 479.648.5895

Dodge Product Support

6040 Ponders Court, Greenville, SC 29615-4617 U.S.A., Ph: (1) 864.297.4800, Fax: (1) 864.281.2433

www.baldor.com

© Baldor Electric Company
MN4031 (Replaces 499864
& 499865)



All Rights Reserved. Printed in USA.
11/11 Printshop 500