

OPTIONS FOR ABB DRIVES

FSO-12 safety functions module

User's manual



List of related manuals

Drive hardware manuals and guides

ACS880-01 hardware manual	3AUA0000078093
ACS880-04 hardware manual	3AUA0000128301
ACS880-04 single drive module packages hardware manual	3AUA0000138495
ACS880-14 and -34 single drive module packages hardware manual	3AXD50000022021
ACS880-04F drive modules hardware manual	3AXD50000034664
ACS880-04XT drive modules (500 to 1200 kW) hardware manual	3AXD50000025169
ACS880-04FXT drive module packages hardware manual	3AXD50000274444
ACS880-07 (45 to 710 kW) hardware manual	3AUA0000105718
ACS880-07 (560 to 2800 kW) hardware manual	3AUA0000143261
ACS880-07LC drives hardware manual	3AXD50000569786
ACS880-11 drives hardware manual	3AXD50000045932
ACS880-31 drives hardware manual	3AXD50000045933
ACS880-14 drive modules hardware manual	3AXD50000035160
ACS880-34 drive modules hardware manual	3AXD50000035191
ACS880-17 (160 to 3200 kW) hardware manual	3AXD50000020436
ACS880-37 (160 to 3200 kW) hardware manual	3AXD50000020437
ACS880-17 (45 ... 400 kW) hardware manual	3AXD50000035158
ACS880-37 (45 ... 400 kW) hardware manual	3AXD50000035159
ACS880-17LC drives hardware manual	3AXD50000250295
ACS880-37LC drives hardware manual	3AXD50000251407
ACS880-104 inverter modules hardware manual	3AUA0000104271
ACS880-107 inverter units hardware manual	3AUA0000102519
ACS880-104LC inverter modules hardware manual	3AXD50000045610
ACS880-107LC inverter units hardware manual	3AXD50000196111

Drive firmware manuals and guides

ACS880 primary control program (AINLX) firmware manual	3AUA0000085967
ACS880 primary control program (YINLX) firmware manual	3AXD50001000998

Option manuals and guides

ACS-AP-I, -S, -W and ACH-AP-H, -W Assistant control panels user's manual	3AUA0000085685
FSO-12 safety functions module user's manual	3AXD50000015612
FENA-01/-11/-21 Ethernet adapter module user's manual	3AUA0000093568
FPNO-21 PROFINET adapter module user's manual	3AXD50000158614

Drive PC tool manuals

Drive Composer start-up and maintenance PC tool user's manual	3AUA0000094606
Functional safety design tool user's manual	3AXD10000102417

General safety guides

Functional safety, Technical guide No. 10	3AUA0000048753
ABB Safety information and solutions	www.abb.com/safety

Safety system manuals

ACS500-S Safety User Manual	3ADR025091M0207
ACS500 Control Builder PS501 Complete English documentation	3ADR025078M0204

User's manual

FSO-12 safety functions module

Table of contents



1. Safety instructions



8. Installation



12. Start-up



Table of contents

1. Safety instructions

Contents of this chapter	13
Use of warnings	13
Electrical safety precautions	14

2. Introduction to the manual

Contents of this chapter	17
Exclusion of liability	17
Applicability	17
Compatible products	18
ACS880 drives and option modules	18
Controller stations	20
Tools	20
Supported safety functions	21
Target audience	21
Purpose of the manual	21
Contents	21
Recommended reading	23
Terms and abbreviations	23
Certificates	30

3. Safety information and considerations

Contents of this chapter	33
Use of safety functions	33
Meeting the requirements of the Machinery Directive	34
Responsibilities	34
Intentional misuse	34
Safety-related parts	34
Limitations of Safe torque off (STO) function	34
Proof testing	35
Safety separation	35
ACS880 drives with separate inverter and supply units	35

4. Overview

Contents of this chapter	37
Intended use of the FSO module	37
System description	38
FSO module and safety system components	38
FSO module version handling	39
Layout	40
Connections	41
Type designation label	41



Operational characteristics	42
Response times	42
FSO diagnostics	43
I/O	43
Acknowledgement	44
Motor speed feedback	45
Overview of safety functions	50
Safe torque off (STO)	50
Safe stop 1 (SS1)	50
Safe stop emergency (SSE)	50
Safe brake control (SBC)	51
Safely-limited speed (SLS)	52
Variable Safely-limited speed (SLS)	52
Safe maximum speed (SMS)	52
Prevention of unexpected start-up (POUS)	52
Safe acceleration range (SAR)	52

5. Safety functions

Contents of this chapter	53
General	54
Safety function request	54
Acknowledgement methods	54
DC magnetization and drive start modes	57
Ramp monitoring	58
Safety function indications	59
FSO modes	61
FSO states	61
Transitions between FSO modes and states	62
Cascade	63
Mute time feature	65
Safe torque off (STO)	67
STO function	67
SBC after STO	69
SBC before STO	71
Safe stop 1 (SS1)	72
SS1 with time monitoring (SS1-t)	73
SS1 with ramp monitoring (SS1-r)	75
SS1 with speed limit activated SBC	77
SS1 with speed limit activated SBC, SBC before STO	80
SS1 ramp functions when drive modulation is lost	84
Safe stop emergency (SSE)	86
SSE with immediate STO	86
SSE with immediate STO, SBC after STO	87
SSE with immediate STO, SBC before STO	89
SSE with time monitoring	91
SSE with ramp monitoring	93
SSE with speed limit activated SBC	94
SSE with speed limit activated SBC, SBC before STO	98
SSE when drive modulation is lost during deceleration ramp	102
Safely-limited speed (SLS)	102

SLS with speed below monitored speed	104
SLS with time monitoring and speed above monitored speed	105
SLS with ramp monitoring and speed above monitored speed	106
SLS reaction when modulation is lost during deceleration ramp, with ramp monitoring	107
SLS reaction when modulation is lost during deceleration ramp, with time monitoring	114
FSO boot behavior with SLS active	121
SLS trip limit hits	121
Variable Safely-limited speed (SLS)	124
Variable SLS with time monitoring	125
Variable SLS with ramp monitoring	127
Safe maximum speed (SMS)	128
SMS function, version 1	129
SMS function, version 2	130
Prevention of unexpected start-up (POUS)	131
Priorities between safety functions	132
Dependencies between safety functions	133

6. PROFIsafe

Contents of this chapter	135
Introduction	135
System description	136
Required components	136
Tools	136
System overview	137
Remote I/O control	138
FSO module passivation	138
PROFIsafe description	138
PROFIsafe message format	138
FSO PROFIsafe profiles	140
FSO module modes and states	146
PROFIsafe response time	158
PROFIsafe watchdog time	160
Installation	161
Configuration	161
Configuring the FB module	161
Configuring the FSO module	163
Configuring the safety PLC	163
Downloading the GSD file	164
Configuring the ABB AC500-S Safety PLC	164
Configuring the Siemens SIMATIC Fail-safe S7 PLC	181
Configuring Siemens S7-1200 PLC with TIA14	196
Fault tracing	213
Reading diagnostic messages	213
Diagnostic messages related to F-Parameters	216
Typical communication errors	217



7. Planning for installation

Contents of this chapter	219
Requirements for designers and installers	219
Mechanical installation	219
Installation site	219
Electrical installation	220
General requirements	220
Connections	220
STO cable and data cable between FSO module and drive	221
Power supply connection	221
Ensuring the EMC compatibility	222
Selecting control cables	222
Routing the cables	222
Standard function and wiring examples	223

8. Installation

Contents of this chapter	227
Unpacking	228
Examining the delivery	229
Mechanical installation	229
Installing the module onto a BCU control unit	229
Installing the module onto a UCU control unit	229
Installing the module onto a ZCU control unit	230
Electrical installation	231
Terminals	231
Connection procedure	232

9. Installation checklists

Contents of this chapter	237
Checklists	237

10. Configuration

Contents of this chapter	239
Competence	239
Password	239
Configuring the FSO module	240
Overview - safety system configuring process	240
FSO configuring procedure	242
Configuring general settings	244
Configuring the safety fieldbus communication	245
How to configure the safety communication with PROFIsafe	245
Configuring I/O	246
How to configure I/O	246
How to configure a cascaded system	248
How to configure safety relays	252
Configuring SBC	253
How to configure the SBC in the STO function	254
How to configure the SBC in the SS1 function	254

Configuring STO	255
How to configure STO	256
How to configure SBC after STO	257
How to configure SBC before STO	258
Configuring SS1	259
How to configure SS1 with time monitoring (SS1-t)	259
How to configure SS1 with ramp monitoring (SS1-r)	261
How to configure SS1 with speed limit activated SBC	262
How to configure SS1 with speed limit activated SBC, SBC before STO	265
Related safety functions	268
Configuring SSE	269
How to configure SSE with immediate STO	270
How to configure SSE with immediate STO, SBC after or before STO	270
How to configure SSE with time monitoring	271
How to configure SSE with ramp monitoring	272
How to configure SSE with speed limit activated SBC	273
How to configure SSE with speed limit activated SBC, SBC before STO	277
Related safety functions	278
Configuring SAR	278
How to configure SARn	278
Configuring SLS	279
How to configure SLSn with time monitoring	280
How to configure SLSn with ramp monitoring	282
Related safety functions	283
Configuring Variable SLS	283
How to configure Variable SLS with time monitoring	284
How to configure Variable SLS with ramp monitoring	285
Defining the scaled SLS4 limit and SLS4 trip limits	286
Related safety functions	288
Configuring SMS	289
How to configure SMS, version 1	289
How to configure SMS, version 2	290
Related safety functions	290
Configuring POUS	290
How to configure POUS	290
How to configure SLS function behavior when drive modulation is lost	291
How to configure SLSn with time monitoring if drive modulation is lost during SLS deceleration ramp	292
How to configure SLSn with ramp monitoring if drive modulation is lost during SLS deceleration ramp	298
Configuring mute times	301
How to determine values for mute time parameters	302
How to configure limit hit situations	302
How to configure mute time for zero speed detection	305
How to configure mute time for SBC speed limit detection	306
How to configure mute time for monitoring start	306

11. Parameters

Contents of this chapter	309
FSO-12 parameters	309



Status and control words	347
--------------------------------	-----

12. Start-up

Contents of this chapter	353
Safety considerations	353
Checks	354

13. Verification and validation

Contents of this chapter	355
Verifying the achieved SIL/PL level	355
Purpose of the validation testing	355
Preconditions for validation testing	356
Validation procedure	356
General	356
Validation test reports	357
Competence	357
Tools	357
Validation of ACS880 drive firmware	358
Validation of the PROFIsafe connection	358
Validation of safety functions	359
Validation of redundant inputs	359
Validation of safety I/O's	360
Validation of the general settings	360
Validation of the STO function	361
Validation of the SBC function	362
Validation of the SSE function	364
Validation of the SS1 function	367
Validation of the SLS functions	369
Validation of the variable SLS function	371
Validation of the SMS functions	373
Validation of the POUS function	375
Validation of the cascaded safety function	376
Proof test intervals during operation	377
Residual risks	377

14. Fault tracing

Contents of this chapter	379
Status LEDs	379
Event types	380
Event code decoding with Drive Composer pro PC tool	381
Faults, warnings and events	382
User-selectable events for function requests	391
User-selectable events for limit hits and special events	392
User-selectable events for safety fieldbus failures	394
Auxiliary codes	394
FSO recovery	394
External fault	394
Internal fault	395



Reporting problems and failures	395
---------------------------------------	-----

15. Maintenance

Contents of this chapter	397
Planning	397
Tools	397
Component replacement in the safety circuit	398
Before component replacement	398
Replacing the FSO module	399
Installing the FSO module to another drive	399
Replacing the control unit of the drive	400
Replacing the control unit of the drive with a different type of control unit	400
Replacing the memory unit or updating the firmware of the drive	401
Replacing a power unit, or its circuit boards or wirings	401
Replacing the motor or motor cable	402
Replacing the FB module in PROFIsafe network	402
Start-up and validation test	402
Factory reset	402
Drive control board boot	403
Updates	404
Proof tests	404
Decommissioning	404

16. Technical data

Contents of this chapter	405
Electrical data	405
PROFIsafe and related network devices	406
Control connection data	406
Terminal and cable entry data for the control cables	407
STO cable and data cable between FSO module and drive	408
Tightening torques	408
Size and weight	408
Cooling	408
Compatible motor types	409
Speed estimation	409
Ambient conditions	409
Safety functions	411
Safety data	411
General	411
Basic safety data	413
FSO safety calculations guide (without PROFIsafe)	414
FSO safety calculations guide (with PROFIsafe)	418
Relevant failure modes	418
Response times	420
Ordering information	421
Related standards and directives	422



17. Dimension drawings

Further information



1

Safety instructions

Contents of this chapter

The chapter contains the warning symbols used in this manual and the safety instructions which you must obey when you install or connect an option module to a drive or inverter. If you ignore the safety instructions, injury, death or damage can occur. Read this chapter before you start the installation.



Use of warnings

Warnings tell you about conditions which can cause injury or death, or damage to the equipment. They also tell you how to prevent the danger. The manual uses these warning symbols:



Electricity warning tells you about hazards from electricity which can cause injury or death, or damage to the equipment.



General warning tells you about conditions, other than those caused by electricity, which can cause injury or death, or damage to the equipment.

Electrical safety precautions

This manual does not give detailed information for disconnecting and isolating all drive types. Refer also to the drive or inverter unit hardware manual.

These electrical safety precautions are for all personnel who do work on the drive, motor cable or motor.



WARNING! Obey these instructions and the safety instructions of the drive. If you ignore them, injury or death, or damage to the equipment can occur.

If you are not a qualified electrical professional, do not do installation or maintenance work. Do these steps before you start installation or maintenance work.

1. Prepare for the work.

- Make sure that you have a work order.
- Do an on-site risk assessment or job hazard analysis.
- Make sure that you have the correct tools available.
- Make sure that the workers are qualified.
- Select the correct personal protective equipment (PPE).
- Stop the drive and motor(s).

2. Clearly identify the work location and equipment.

3. Disconnect all possible voltage sources. Make sure that connection is not possible. Lock out and tag out.

- ACS880 drives with a DC/DC-converter unit or DC feeder unit: Open the disconnecting device of the energy storage connected to the unit. Then open the DC switch-disconnector of the unit.
- Open the main disconnecting device of the drive.
- If you have a permanent magnet motor connected to the drive, disconnect the motor from the drive with a safety switch or by other means.
- Open the main isolating device of the drive.
- Disconnect all dangerous external voltages from the control circuits.
- After you disconnect power from the drive, wait 5 minutes to let the intermediate circuit capacitors discharge before you continue.

4. Protect other energized parts in the work location against contact and take special precautions when close to bare conductors.

5. Measure that the installation is de-energized. Use a high-quality voltage tester. If the measurement requires that you remove shrouding or other cabinet structures, obey the local laws and regulations applicable to live



electrical work. This includes, but is not limited to, electric shock and arc protection.

- Before and after you measure the installation, verify the operation of the voltage tester on a known voltage source.
 - Make sure that the voltage between the input power terminals of the drive (L1, L2, L3) and the grounding (PE) busbar is zero.
 - Make sure that the voltage between the output power terminals of the drive (T1/U, T2/V, T3/W) and the grounding (PE) busbar is zero.
Important! Repeat the measurement with the DC voltage setting of the voltage tester. Measure between each phase and ground. There is a risk of dangerous DC voltage charging due to leakage capacitances of the motor circuit. This voltage can remain charged for a long time after the drive power-off. The measurement discharges the voltage.
 - Make sure that the voltage between the drive DC terminals and the grounding (PE) busbar is zero.
6. Install temporary grounding as required by the local regulations.
 7. Ask for a permit to work from the person that is responsible for the electrical installation work.





2

Introduction to the manual

Contents of this chapter

This chapter states exclusion of liability and describes the applicability, compatible products, supported safety functions, target audience and purpose of the manual.

The chapter also lists contents of this manual, recommended reading as well as related standards and directives, and explains used definitions, terms and abbreviations. The safety certificate is included at the end of the chapter.

Exclusion of liability

This manual is an informative aid only. It contains information that is necessary for using the FSO-12 safety functions module and implementing safety systems. The information and examples given are for general use only. They do not describe all the necessary details for implementing a safety system. The manufacturer of the machinery always remains ultimately responsible for the product safety and compliance with applicable laws. ABB does not accept any liability for direct or indirect injury or damage caused by the information contained in this document. ABB hereby disclaims all liabilities that may result from this document.

Do not open the FSO module. If you open the FSO module, the safety classification becomes invalid and the warranty ceases to be in effect.

Applicability

This manual is applicable to the FSO-12 safety functions module, revision J.

Compatible products

Check the compatibility of the earlier versions with your local ABB representative. Refer also to section [FSO module version handling](#) on page 39.

■ ACS880 drives and option modules

- ACS880 series without “No FSO support” sticker
- ACS880 primary control program (AINLX) version 2.12 or later,
or
ACS880 primary control program (YINLX) version 1.30 or later.
- FENA-21 Ethernet adapter module: version 3.05 or later
- FPNO-21 PROFINET fieldbus adapter module: version 1.00 or later

Note: The FSO-12 module is compatible with UCU-22, -23, and -24 control units that have a UCON-22 control board, revision K or later. The control board revision is shown on a sticker on the control unit.

Application control programs (for drives with BCU or ZCU control unit only)

FSO-12 behavior is independent from application control program, thus all application control programs are supported by FSO-12. Example applications:

- Machinery control program v2.40 or later
- Crane control program v2.1 or later
- Tower crane control program v1.0 or later
- Winch control program v1.0 or later
- Winder control program v1.10 or later
- PCP/ESP control program (+N5200) v1.1 or later
- PCP/ESP control program SynRM v1.1.1.0 or later
- Spinning control program v1.0 or later
- Rod pump control program v1.0 or later

ACS880 drives manufactured before December 2024

This section is a safety notice applicable to drives with ACS880 primary control program (AINLX), version 3.46 or earlier. It is not applicable to drives with ACS880 primary control program (YINLX).

There is a potential safety problem in drives with an FSO-12 module and ACS880 primary control program (AINLX), version 3.46 or earlier. With this combination, drive parameter 99.16 Motor phase order has a possible effect on the safety behavior of the motor.

If parameter 99.16 is changed after the safety validation, the motor direction of rotation **and** the monitoring limits are changed.

Example:

The initial settings are:

- SLS limit positive = 5000 rpm
- SLS limit negative = -100 rpm

Then, one year later, parameter 99.16 is changed from UVW to UWV. In this case, request for 4000 rpm forward will cause a speed of 4000 rpm backward without SLS limit violation. The effect of parameter 99.16 is useful during the commissioning phase, but changing this parameter after the safety validation can cause a potential risk.

This safety notice is applicable when these conditions are met:

1. Safe speed estimate is in use.
2. One of these safety functions is in use:
 - SLS (Safely-limited speed)
 - SMS (Safe maximum speed)
 - SSM (Safe speed monitoring)
 - Variable SLS over PROFIsafe
 - Safe speed information over PROFIsafe.
3. Speed limits are monitored with asymmetrical limits, for example:
 - SLS limit positive = 5000 rpm
 - SLS limit negative = -100 rpm.

Note: Potential risk can also occur when safety encoder feedback is used and switching to open loop control is permitted.

To minimize the potential risk caused by drive parameter 99.16, use option A or option B given below.

Option A: Update the drive firmware to version 3.47 or later. After the firmware update, the start-up and safety validation procedures must be done according to the instructions in this manual.

Option B: Lock parameter 99.16 with a dedicated delta loading package as follows:

1. Download the delta loading package into the drive. The delta package is specific to the application firmware (for example, the Crane control program has a dedicated delta package).
2. Make sure that parameter 99.16 is locked.
3. Make sure that the motor turns in the correct direction. For example, request 100 rpm to make sure that the direction is correct.
4. Make sure that the rotation direction agrees with the limits that the FSO module is monitoring.

To remove the effects of the delta package, the drive firmware must be reloaded.

Contact your local ABB representative for the software packages or for more information.

■ Controller stations

For example the following controller stations are supported. Check the compatibility of the controller station in its manual.

- ABB AC500-S Safety PLC. For more information, refer to [AC500-S Safety User Manual \(3ADR025091M0212 \[English\]\)](#)
- Siemens SIMATIC Fail-safe S7 PLC

■ Tools

- Drive Composer pro PC tool: version 1.7 or later

Note: This manual is applicable to Drive Composer pro versions until 1.12. If you use a later version, the menus and button names can be different from the ones used in this manual. For more information, refer to the documentation of the tool.



WARNING! ACS880 drives and control units that have the label “No FSO support” are not compatible with FSO-12 module. Do not use this combination.

Supported safety functions

This manual provides instructions for creating the following safety functions (according to EN/IEC 61800-5-2) for the ACS880 drives:

- Safe torque off (STO) – standard feature in the ACS880 drives, see page [67](#)
- Safe brake control (SBC), see page [51](#)
- Safe stop 1 (SS1), see page [72](#)
- Safely-limited speed (SLS), see page [102](#)
- Variable Safely-limited speed (SLS), with PROFIsafe only, see page [124](#).

Additional safety functions (not specified in EN/IEC 61800-5-2):

- Safe stop emergency (SSE), see page [86](#)
- Safe maximum speed (SMS), see page [128](#)
- Prevention of unexpected start-up (POUS), see page [131](#).

Note: The FSO-12 module does not support an encoder in safety applications.

Target audience

The manual is intended for qualified persons who design the safety application, plan the installation as well as install and commission the safety application. Read the manual before starting work on the safety application. You must know the fundamentals of safety technology, electricity, wiring, electrical components and electrical schematic symbols.

Purpose of the manual

The manual gives information on how to install the FSO safety functions module and configure and commission the supported safety functions. It also gives information on how to meet and maintain safety life cycle requirements of the FSO module to ensure required safety performance and specified safety integrity.

Drive-specific technical, configuration and installation details are in the drive hardware manual (see [List of related manuals](#) on page [2](#)).

Contents

Chapter [Safety instructions](#) (page [13](#)) explains the usage of warning symbols in this manual and the safety instructions which you must obey when you install or connect an option module to a drive or inverter.

Chapter [Introduction to the manual](#) (this chapter, page [17](#)) states exclusion of liability and describes the applicability, compatible products, supported safety functions, target audience and purpose of the manual. It also lists the contents

of this manual and recommended reading and explains used definitions, terms and abbreviations. The safety certificate is included at the end of the chapter.

Chapter [Safety information and considerations](#) (page 33) contains general safety considerations and information to be taken into account when applying the FSO safety functions.

Chapter [Overview](#) (page 37) briefly describes the FSO module with safety system components as well as the FSO layout, connections, type designation label and operational characteristics.

Chapter [Safety functions](#) (page 53) describes how the safety functions of the FSO module operate.

Chapter [PROFIsafe](#) (page 135) describes the safety system when the FSO module is connected to a safety PLC through a fieldbus (FB) module using the PROFIsafe profile of PROFINET. It describes the FSO module states and transitions and the contents of the PROFIsafe messages. The chapter also includes installation instructions, configuration instructions for the ABB AC500-S Safety PLC and Siemens SIMATIC Fail-safe S7 PLC as well as fault tracing tips.

Chapter [Planning for installation](#) (page 219) gives instructions and references to instructions in other manuals for planning the safety system installation, as well as the requirements for installation in the applicable safety standards.

Chapter [Installation](#) (page 227) gives examples of how to connect the FSO module to the ACS880.

Chapter [Installation checklists](#) (page 237) contains a checklist for checking the mechanical and electrical installation of the FSO module and refers to common cause failure checklists in standards.

Chapter [Configuration](#) (page 239) describes the password usage, outlines the configuration process and gives examples of how to configure the FSO module to implement the safety functions described in chapter [Safety functions](#).

Chapter [Parameters](#) (page 309) lists the FSO parameters.

Chapter [Start-up](#) (page 353) describes the general precautions to be taken before starting up the safety system for the first time.

Chapter [Verification and validation](#) (page 355) describes verification and validation procedures of the implemented safety functions.

Chapter [Fault tracing](#) (page 379) describes the status LEDs and provides generic diagnostics, troubleshooting and fault recovery tips for FSO-related faults.

Chapter [Maintenance](#) (page 397) explains the replacement of the FSO module in case of a module failure, gives instructions for reinstalling the FSO module to another drive and updating the firmware of the drive where the FSO is installed.

It also gives instructions for the replacement of the FB module, FSO factory reset, safety system update and decommissioning as well as proof tests.

Chapter [Technical data](#) (page 405) contains the technical specifications of the FSO module, for example, electrical data, sizes and safety data. It also lists related standards and directives.

Chapter [Dimension drawings](#) (page 423) shows the dimension drawings of the FSO module.

Recommended reading

This manual is based on the following standards. It is recommended that you are familiar with these standards before implementing safety-related systems.

- EN/IEC 61800-5-2: Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional. (Includes safety function definitions.)
- EN ISO 13849-1: Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design
- EN/IEC 62061: Safety of machinery – Functional safety of safety-related electrical, electronic and programmable electronic control systems
- EN 60204-1: Safety of machinery – Electrical equipment of machines – Part 1: General requirements.
- PROFIsafe System Description – Technology and Application. Version April 2016. Order Number 4.342.

Before starting the implementation of safety-related systems, it is highly recommended to read and understand these manuals, which will also be referred to in the later chapters of this manual:

- [Functional safety; Technical guide No. 10 \(3AUA0000048753 \[English\]\)](#)
- firmware and hardware manuals of the drive.

For a complete list of related standards and directives, refer to section [Related standards and directives](#) on page 422.

Terms and abbreviations

The terms and abbreviations used in this manual are defined in the table below.

Term / Abbreviation	Description
Acknowledgement	Deactivates the active safety functions which have been completed and are without active function request. Refer to section Acknowledgement methods on page 54. See also term Reset on page 27.
AWG	American wire gauge

Term / Abbreviation	Description
B _{10d}	Number of cycles until 10% of the components fail dangerously (for pneumatic and electromechanical components). (EN ISO 13849-1)
BCU	Type of control unit
Black channel	Communication channel that is not safe as it has not been designed and/or validated according to IEC 61508. The reliability of the connection can be secured with an additional security protocol, for example PROFIsafe, on top of the black channel.
Cat.	Classification of the safety-related parts of a control system. The categories are: B, 1, 2, 3 and 4. (EN ISO 13849-1)
CCF	Common cause failure (EN ISO 13849-1)
Common cause failure (CCF)	Failure that is the result of one or more events, causing concurrent failures of two or more separate channels in a multiple channel subsystem, leading to failure of a safety function.
Communication module	Communication module is a name for a device (eg, a fieldbus adapter) through which the drive is connected to an external communication network (eg, a fieldbus). The communication with the module is activated with a drive parameter.
Controller	Control system with bus initiative (master). In PROFINET IO terminology, controller stations are also called active stations.
Control word	16-bit word from controller to device with bit-coded control signals (sometimes called the Command word).
CRC	Cyclic redundancy check
Cyclic communication	Communication in which parameter/process data objects are sent cyclically at predefined intervals
DAT	Device acknowledgement time
DC	Diagnostic coverage (%) (EN ISO 13849-1), Direct current
Device	Passive bus participant. In PROFINET IO terminology, device stations (or slaves) are also called passive stations. Also referred to as nodes.
DI	Digital input
DO	Digital output
E-stop	Emergency stop
ELV	Extra-low voltage
EMC	Electromagnetic compatibility
External active load	Load that has the capability to accelerate the speed of the motor, for example, gravity or spring based load.
Factory reset	See Reset
Fail-safe mode	The FSO module has activated the drive STO function as a result of an error (in some cases, after a delay). To exit this mode and continue normal operation, reboot the FSO module.

Term / Abbreviation	Description
FbEq16	16-bit fieldbus equivalent: The scaling between the value shown on the panel and the integer used in communication when a 16-bit value is selected for transmission to an external system.
FbEq32	32-bit fieldbus equivalent: The scaling between the value shown on the panel and the integer used in communication when a 32-bit value is selected for transmission to an external system.
F-Device	Device that is able to communicate using PROFIsafe, eg, the FSO module.
F-Host	Programmable logic controller (PLC) that is able to communicate using PROFIsafe.
F-Input	PROFIsafe frame user data from that is sent from the F-Device (FSO) to the F-Host (PLC).
F-Output	PROFIsafe frame user data from that is sent from the F-Host (PLC) to the F-Device (FSO).
F-Parameters	Set of PROFIsafe parameters that all PROFIsafe devices support. F-Parameters are sent from the F-Host (PLC) to the F-Device (FSO) when the PROFIsafe connection is created.
FBA	Fieldbus adapter parameter (drive parameter group 50)
FB module	Fieldbus adapter module (FPNO-21 or FENA-21)
FENA-21	Optional Ethernet adapter module for EtherNet/IP™, Modbus TCP and PROFINET IO protocols
FIT	Failure in time: 1E-9 hours. Expected failure rate of semiconductors and other electronic devices. (IEC 61508)
FPNO-21	PROFINET fieldbus adapter module
FSE-31	Pulse encoder interface module which can be used in safety applications
FSO-12	Safety functions module which does not support the use of encoders
FSO-21	Safety functions module which supports the FSE-31 module and the use of safety encoders
Functional safety	Functional safety is part of the overall safety that depends on a system or equipment operating correctly in response to its inputs.
Generator mode	Drive is taking energy from the controlled application
GND	Ground
GSD file	General Station Description file that describes the basic capabilities of a device in a specified form. PROFINET uses GSDML files which are GSD files written in XML format.
HAT	Host acknowledgement time
Hazard	Potential source of harm (physical injury, or damage to health or equipment)
HFT	Hardware fault tolerance (IEC 61508)

Term / Abbreviation	Description
hi-Z state	In digital outputs, the signal is neither driven to a logical high nor low level. It is “floating”.
IGBT	Insulated gate bipolar transistor
Internal fault	A fault which is detected by FSO module's internal diagnostics. When an internal fault is detected, the FSO goes into fail-safe mode, activates drive STO, and creates a fault to the drive.
I/O	Input/output
LSB	Least significant byte
MAC address	Media access control address. A unique identifier of a network node in an communication network.
Mission time	T_M . The period of time covering the intended use of a safety function/device. After the mission time the safety device(s) must be replaced. Note that any T_M values given cannot be regarded as a guarantee or warranty. (EN ISO 13849-1).
MSB	Most significant byte
modoff	No modulation (the control of inverter IGBTs is off) WARNING! 'No modulation' is not a safe state. To achieve a safe state, the STO function must be activated.
$MTTF_D$	Mean time to dangerous failure: (The total number of life units) / (the number of dangerous, undetected failures) during a particular measurement interval under stated conditions (EN ISO 13849-1)
N/A	Not applicable
NC	Normally closed. Break contact. Normally closed contacts disconnect the circuit when the relay is energized; the circuit is connected when the relay is de-energized.
NO	Normally open. Make contact. Normally open contacts connect the circuit when the relay is energized; the circuit is disconnected when the relay is de-energized.
OEM	Original equipment manufacturer
PCB	Printed circuit board
PELV	Protected extra-low voltage (IEC 60364-4-41)
PFD_{avg}	Average probability of dangerous failure on demand (IEC 61508)
PFH	Average frequency of dangerous failures per hour (IEC 61508)
PL	Performance level (a-e) (EN ISO 13849-1)
PLC	Programmable logic controller
POUS	Prevention of unexpected start-up
Power drive systems (Safety related), PDS(SR)	Adjustable speed electrical power drive system suitable for use in safety-related applications

Term / Abbreviation	Description
Profile	Adaptation of the protocol for certain application field, for example, drives.
PROFINET	An open standard for industrial communication systems that uses the Ethernet standard. Registered trademark of PROFIBUS and PROFINET International (PI) community.
PROFIsafe	An additional layer on top of the PROFINET protocol for safety-related communication. Registered trademark of PROFIBUS and PROFINET International (PI) community.
Proof test	Periodic test performed to detect dangerous hidden failures in a safety-related system so that, if necessary, a repair can restore the system to an “as new” condition or as close as practical to this condition. (IEC 61508, IEC 62061)
Protective measure	Measure intended to achieve risk reduction
PZD	Process data (Prozessdaten)
Reasonably foreseeable misuse	Use of a machine in a way not intended by the designer, but which may result from readily predictable human behavior
Reset	Factory reset. Clears the configuration and sets the parameters to their factory default values.
Residual risk	Risk remaining after protective measures have been taken
Response time of FSO	The internal response time of the FSO, that is, the time in which the STO control output of the FSO reacts after receiving a request. (Usually this is not the same as the time from the request to the safe state of the machine application.) See also term Safety function response time (SFRT) on page 28.
Risk	Combination of the probability of occurrence of harm and the severity of that harm
Safe state	STO activated. The STO circuit in the drive is open. Note: When the drive STO is activated in the POUS function, the FSO is in the Operational state. See also section FSO states on page 61.
Safety fieldbus	Communication system used in safety-related applications. In the safety system described in this manual, safe communication is secured with the PROFIsafe application layer. See also term PROFIsafe on page 27.
Safety function	Function, with a specified safety performance, which is intended to maintain the safe condition of the installation or prevent hazardous conditions arising at the installation. Example: Safe torque off (STO)

Term / Abbreviation	Description
Safety function response time (SFRT)	<p>Worst-case elapsed time following an actuation of a safety sensor connected to a fieldbus before the corresponding safe state of its safety actuator(s) is achieved in the presence of errors or failures in the safety function channel.</p> <p>Response time of the combination of the drive and the FSO. See also term Response time of FSO on page 27.</p>
Safety module	Part of a safety system, physical entity. Example: FSO safety functions module.
Safety system	Whole safety system including for example human interface, FSO safety functions module, drive, sensors and machine.
SAR	Safe acceleration range. In the FSO module, there are two sets of SAR parameters (SAR0 and SAR1) that are used to define and/or monitor the deceleration ramp in safety functions. SAR0 parameters are used in the SSE function. SAR1 parameters are used in SS1, SLS, varSLS and SDI functions.
SBC	Safe brake control
SC	Systematic capability (IEC 61508)
SCS	Safety-related control system. Part of the control system of a machine which implements a safety function by one or more subsystems.
Scaling speed	A user-defined value that the FSO module uses as a speed reference point in ramp time calculations. See parameter 200.202 SAR speed scaling on page 312.
SELV	Safety extra-low voltage
SFF	Safe failure fraction (%) (IEC 61508)
SFRT	Safety function response time (see page 28)
SIL	Safety integrity level (1...3) (IEC 61508, IEC 62061, IEC 61800-5-2)
SLS	Safely-limited speed
SMS	Safe maximum speed
SS1	Safe stop 1
SS1-r	Safe stop 1 ramp monitored
SS1-t	Safe stop 1 time controlled
SSE	<p>Safe stop emergency</p> <p>For example, safety fieldbus failure, speed monitoring trip limit hit (SLS and SMS) will activate the SSE safety function.</p>
Status word	16-bit word from device to controller with bit-coded status messages.

Term / Abbreviation	Description
STO	<p>Safe torque off (EN/IEC 61800-5-2). In this manual, this term is used in two different contexts:</p> <ul style="list-style-type: none"> the STO circuit in the drive (the drive STO function) the STO safety function in the FSO module. <p>Safety functions in the FSO module (eg, STO, SSE, SS1 and POUS) activate the drive STO function, that is, open the drive STO circuit. In addition, some safety functions can activate the STO safety function in the FSO module, which in turn opens the drive STO circuit. See section Dependencies between safety functions on page 133.</p>
Stop category	<p>There are three categories of stop functions:</p> <ul style="list-style-type: none"> stop category 0: an uncontrolled stop where power to the machine actuators is removed immediately stop category 1: a controlled stop where the machine actuators have power for stopping, after which the power is removed stop category 2: a controlled stop where the machine actuators continue to have power. <p>Stop category 0 and 1 definitions also apply to Emergency stop categories.</p>
T_1	<p>Proof test interval. Defines the probabilistic failure rate (PFH or PFD_{avg}) for the safety function or subsystem. Performing a proof test at a maximum interval of T_1 is required to keep the SIL capability valid. The same interval must be followed to keep the PL capability (EN ISO 13849) valid. Note that any T_1 values given cannot be regarded as a guarantee or warranty. See also section Proof tests on page 404.</p>
T_M	See Mission time.
TP	Test pulse. Term diagnostic pulse is used in this manual.
TWCDT	Total worst-case delay time
UCU	Type of control unit
Validation	Confirmation by, for example, analysis that the safety system meets the functional safety requirements of the specific application.
Verification	Confirmation by, for example, testing that the safety system meets the requirements set by the specification.
WCDT	Worst-case delay time
WD	Watchdog
ZCU	Type of control unit
Zero speed	<p>Speed limit where a ramp stop safety function is considered to be completed and drive STO is activated. The acknowledgement of the safety function becomes possible when this speed is reached.</p> <p>Zero speed limit is specified with parameter FSOGEN.51 Zero speed without encoder</p>

Term / Abbreviation	Description
λ_d	Dangerous failure rate
λ_{du}	Dangerous failure rate, undetected failures
λ_s	Safe failure rate

Certificates

TÜV Nord certificate for the FSO-12 and ACS880 drive series can be found in the ABB Library, where you can also check the validity of the certificate with a specific drive variant.

The PROFIsafe certificate for the FSO-12 module is shown below.



Certificate

PROFIBUS Nutzerorganisation e.V. grants to

ABB Oy
Hiomotie 13, 00380 Helsinki, Finland

the Certificate No: **Z20141** for the PROFIsafe device:

Model Name: FSO-12
 Order Number: 3AXD50000012090
 Revision: SW: V4.3.0; HW: 1
 Application CRC: Channel A: 0x63F41365
 Channel B: 0xB630A569

This certificate confirms that the product has successfully passed the certification tests with the following PROFIsafe scope:

☒ PROFIsafe_V2 functionality on PROFINET IO

Test Report Number: PS083-2
 Authorized Test Laboratory: SIEMENS AG, Fürth, Germany

The tests were executed in accordance with the following documents:
 "PROFIsafe - Test Specification for F-Slaves, F-Devices, and F-Hosts, Version 2.1, March 2007".
 This certificate is granted according to the document:
 "Framework for testing and certification of PROFIBUS and PROFINET products".
 For all products that are placed in circulation by **June 22, 2023** the certificate is valid for life.

Karlsruhe, August 06, 2020



 (Official in Charge)


 PROFIsafe

Board of PROFIBUS Nutzerorganisation e. V.



 (Karsten Schneider)



 (Dr. Jörg Hähnliche)

3

Safety information and considerations

Contents of this chapter

This chapter contains general safety considerations and information to be taken into account when applying the FSO safety functions.



WARNING! The FSO safety functions module is delivered with the safety functions bypassed by jumper wires in connectors X:113 and X:114 to allow initial drive commissioning without the need to configure safety functions first. The safety system must always be properly commissioned and verified/validated before it can be considered safe.



WARNING! Make sure that the functional safety of the machine is maintained in situations where the safety option does not provide protection, for example, during commissioning, system maintenance, fault tracing, or decommissioning.

Use of safety functions

To make sure that the application, where FSO and its safety functions are used, is safe to use and fulfills all relevant safety requirements, it is necessary to take into account the requirements of the local (machinery) safety legislation (eg, Machinery Directive) and/or the applicable functional safety standards (eg, ISO 13849-1).

Implementing safety functions to make safe applications requires a systematic approach/process, where risk assessment is the basis of all safety

requirements. These processes are described in global ISO and IEC machinery safety and functional safety standards (eg, ISO 12100, 13849-1, IEC 62061). These are also introduced in [Functional safety; Technical guide No. 10 \(3AUA0000048753 \[English\]\)](#).

Before you take into use a system where the FSO and its safety functions are used, you must verify and validate the correct operation of the safety application according to the system safety verification plan. Refer to chapter [Verification and validation](#).

Meeting the requirements of the Machinery Directive

If the machine, where FSO is part of the safety system, will be sold or taken into use in Europe, it is the responsibility of the machine builder / OEM / system integrator to make sure that the machine is safe to use and the essential health and safety requirements (EHSR) of the Machinery Directive are fulfilled. The requirements in the applicable standards must also be met and the FSO module must be used according to the instructions provided in this manual.

Responsibilities

As a component manufacturer, ABB is only responsible for the safety and conformity of their manufactured products, not of the systems where these products are used. If you detect a failure in the safety functions, contact your local ABB representative.

Intentional misuse

Use the FSO module according to the instructions given in the applicable user's manual. ABB is not responsible for any damage caused by the misuse of the module.

The FSO module is not designed to protect a machine against intentional misuse or sabotage.

Safety-related parts

The FSO module and the drive Safe torque off (STO) channel/function are safety relevant, and the rest of the drive is considered as not safety relevant. For example, the drive regular I/O cannot be used for requesting safety functions on the FSO.

Limitations of Safe torque off (STO) function

The Safe torque off function can be used for stopping the drive in the operational mode. If a running drive is stopped by using the STO function, the drive stops by coasting. STO function can also be used for prevention of

unexpected start-up according to the limitations of IEC 60204-1, 5.4 and ISO 14118.

The Safe torque off function does not disconnect or isolate the voltage of the main and auxiliary circuits of the drive. Therefore maintenance work on any electrical parts of the system (including drive and the motor) can only be carried out after a proper isolating procedure, which must be obeyed to make sure that the maintained part of the system is properly isolated.

■ Proof testing

Periodic proof testing of, for example, electromechanical parts of the safety system may be required in order to maintain the claimed SIL / PL level of the system. In this case proof testing must be taken into consideration in the safety calculations and it must be properly documented in the user documentation. Proof testing has to be verified in the acceptance testing during the commissioning phase.

The FSO module itself does not require periodic proof testing.

External contactors, relays and mechanical actuators must be sized correctly for safety use as the automatic diagnostics only monitors the electrical connections; the mechanical final elements like brakes are not diagnosed.

Failure of a mechanical actuator, for example a brake, could lead up to an undetected fault, and a possible loss of the load control.

■ Safety separation

The FSO module and safety functions including the drive Safe torque off (STO) are safety relevant and separated from drive non-safety logic. For example, the drive regular I/O cannot be used for requesting safety functions on the FSO.



WARNING! The Safe torque off function does not disconnect the voltage of the main and auxiliary circuits from the drive. Do not do maintenance work on the electrical parts of the drive or the motor before you isolate the drive system from the main supply, from rotating permanent magnet motors, from rotating motors equipped with sine filters and from all dangerous external voltages.

Note: The Safe torque off function can be used for stopping the drive in the operational mode. If a running drive is stopped by using the STO function, the drive stops by coasting.

■ ACS880 drives with separate inverter and supply units

In ACS880 drives with separate supply and inverter units, the FSO module is connected to the inverter unit(s). The FSO module cannot be connected to supply units, brake units, or DC/DC-converter units.

4

Overview

Contents of this chapter

This chapter briefly describes the FSO module with safety system components as well as the FSO module layout, connections, type designation label and operational characteristics.

Intended use of the FSO module

FSO-12 is a safety option module for ABB ACS880 drives, which adds safety functionality, including support for PROFIsafe communication with a safety PLC through an FB module.

The intended use of the FSO module is to safely monitor and stop the drive (PDS(SR), VSD) if necessary, in case a dangerous or unexpected event occurs that requires a safe reaction of the safety related control system.

The main purpose of the FSO module is to make the systems/applications safe to use. It can be the main safety logic for the safety system, or it can be part of a larger safety related control system as a subsystem.

The FSO module can be used in applications where EN ISO 13850 is used. This standard gives the requirements for the emergency stop function of the machine (that can be implemented with FSO functions STO, SS1 and SSE). It is necessary to know the [Priorities between safety functions](#), see page 133.

The FSO module can be used with applications that comply with standard ISO 14118. This standard defines the requirements for the prevention of the unexpected start-up (POUS) of the machine (that can be implemented with FSO functions POUS, STO and SS1).


System description

The FSO module includes various safety functions that can be used for implementing safety functions in various applications, such as emergency stop, and safe speed limiting, etc. as shown in the figure below. The FSO module is one part of the functional chain of the safety functions where external components together with FSO are connected to create complete safety systems. This user's manual gives overall information on how to implement safety functions with FSO module, regarding the SIL/PL requirements, functionality, and restrictions of use. The safety requirements for the application are defined in the system-specific risk assessment. The system integrator must obey those requirements when they implement safety functions with the FSO module.

■ FSO module and safety system components

The figure below shows a safety system example that has these components:

- FSO-12 safety functions module
- ACS880-01 drive
- safety PLC
- FB module
- switches and buttons.



The FSO safety functions module is an option for the ACS880 drives. The Safe torque off (STO) function is a standard feature on the ACS880 drives.

The FSO module does not operate the drive. It only monitors the actions of the drive and commands safety functions to be executed. The request for safety functions can come from an external safety system, for example, a push button, a safety PLC, or from an FSO internal fault. Some safety functions can be permanently active. If the drive does not fulfill the commands of the FSO, the FSO stops the drive modulation using the Safe torque off (STO) function.

If the drive is connected to a safety PLC, the safety of the fieldbus communication can be secured with PROFIsafe over PROFINET technology. The safety PLC is connected to the FB module, which communicates with the FSO module. For more information, see chapter [PROFIsafe](#).

Safety functions supported by the FSO module are presented in chapter [Safety functions](#).

■ FSO module version handling

To ensure backward and forward compatibility with the ACS880 drives, the FSO-12 module has a version handling system. Both the FSO module and the ACS880 drive firmware must support the used safety functions.


You can always replace the FSO-12 module with a newer revision and use the same configuration file with the new revision. Each time you make any changes in the safety system, you must do the validation test for each safety function using the checklists given in chapter [Verification and validation](#).

Note: Due to an update in functionality related to a situation where drive modulation is lost when SLS function is active, it is recommended to update all FSO modules to revision H (or later).

Each new revision of the FSO-12 module supports all or most functions of previous FSO-12 module revisions and it can be used together with previous ACS880 drive firmware versions. In addition, previous FSO-12 module revisions can be used together with new ACS880 drive firmware versions. In this case, the drive supports only the functions of the previous FSO-12 module revision. For more information on product compatibility, refer to section [Compatible products](#) on page 18.

In the Drive Composer pro PC tool, each safety function and parameter group has a version parameter. With these parameters, the user selects the desired versions. Only the versions that are supported by both the drive firmware and the FSO module are shown in Drive Composer pro.

■ Layout



No	Description
1	24 V DC input connection
2	Safe torque off (STO) connection
3	Data connection
4, 4b	Mounting for drives with ZCU-12 control unit shown. Two mounting points on each side. The screw attached at 4b also grounds the enclosure of the FSO. Mounting points vary by installation and/or control unit type.
5	FSO grounding screw. Grounds the electronics.
6	FSO status LEDs. Refer to section Status LEDs on page 379.
7	Input / output status LEDs, one for each I/O connector (see No 8). The LEDs are in two rows above the corresponding two rows of I/O connectors. The LED is on if the state of the corresponding I/O is ON (24 V in the input or output). The data shown by LEDs is <u>only indicative and cannot be considered safe.</u>

No	Description
8	Input / output connections <ul style="list-style-type: none"> • 4 redundant or 8 single digital inputs, or combinations of redundant and single inputs. Possible redundant pairs: X113:1 & X114:1, X113:2 & X114:2, X113:3 & X114:3 and X113:4 & X114:4. • 3 redundant or 6 single digital outputs, or combinations of redundant and single outputs. Possible redundant pairs: X113:7 & X114:7, X113:8 & X114:8 and X113:9 & X114:9. • two 24 V DC reference outputs with configurable diagnostic pulses.
9	Factory reset button (under the label)

■ Connections

The FSO module has several safety I/Os for external safety devices, for example buttons, gates and indicators. The FSO-12 module does not have an encoder interface.


When you use the Safe brake control (SBC) function, the FSO module controls the mechanical brake. For more information on the SBC function, refer to chapter [Safety functions](#).

One FSO module is necessary for each drive/inverter to be monitored.

Connection details are given in section [Terminals](#) on page [231](#).

■ Type designation label

The type designation label is attached onto the top of the FSO module. An example label and description of the label contents are shown below.



No	Description
1	Type
2	Serial number of format RYWWSSSS, where R: Component revision: A, B, C, ... Y: Last digit of the manufacturing year: 4, 5, ... for 2014, 2015, ... WW: Manufacturing week: 01, 02, ... for week 1, week 2, ... SSSS: Integer starting every week from 0001
3	ABB MRP code of the FSO module
4	Combined ABB MRP code, serial number and manufacturing location
5	RoHS mark

■ Operational characteristics

The FSO module monitors that the drive operates within the configured safety limits when safety functions are active. If the limits are exceeded, FSO activates a safe stopping in the drive within the response time. The safe stopping function activates the drive STO function immediately or after an emergency ramp. Activation of the drive STO function removes the torque and, if configured, applies the brake.



WARNING! The Safe torque off function does not disconnect the voltage of the main and auxiliary circuits from the drive. See the warning on page 35.

The supported functions are preprogrammed in the FSO firmware. They cannot be programmed in any way.

Authorized personnel can configure the FSO module with the Drive Composer pro PC tool. The FSO module checks the authorization with a password before it is possible to edit the FSO parameters. The user sends the parameters from the tool to the drive, after which the FSO module and the PC tool validate the configuration, and the tool asks the user to confirm the validation.

If the FSO module detects an internal fault during its diagnostics tests, it goes into the Fail-safe mode and must be rebooted. For the FSO modes, refer to section [FSO modes](#) on page 61. For instructions on how to reboot the FSO module, refer to section [FSO recovery](#) on page 394.

The FSO module checks on every boot that the drive has the same configuration as the FSO module. If the configurations do not match, the FSO module keeps the STO active.

When the FSO module is configured with the Drive Composer pro, the tool will do a sanity check for the FSO configuration to make sure that it is plausible. Despite of this, the user must do the validation for the parametrization and for the functionality of the safety functions. The Drive Composer pro or FSO module cannot determine the validity of the configuration.

You must reboot the FSO module after the drive has recovered from a power failure or after the control unit is rebooted. For instructions on how to reboot the FSO module, refer to section [FSO recovery](#) on page 394.

■ Response times

Safety function response time and FSO response times are specified in section [Response times](#) on page 420.

The acceptable speed limits must be configured so that the speed cannot accelerate/decelerate from an acceptable speed to a dangerous speed faster than the response time of the FSO module.

■ FSO diagnostics

The FSO module performs extensive auto diagnostics tests during the runtime operation on FSO internal parts as well as the communication and STO connection between the FSO and the drive. The FSO goes into the Fail-safe mode if it detects a fault.

- The communication between the FSO and the drive is diagnosed continuously.
- The STO connection between the FSO and the drive STO connector is diagnosed during the power-up and periodically during the runtime.


If an FSO redundant I/O failure occurs, FSO module activates (or keeps active) the safety function that has been configured to the I/O. For all other I/O or safety fieldbus failures, the FSO module activates the SSE function. Also, the overtemperature fault of the FSO module activates the SSE function (for more information, see section [Configuring SSE](#) on page 269). In other internal failure situations, the FSO module activates the STO function.

■ I/O

The FSO module supports input and output redundancy.

The FSO module provides an option for applying diagnostic pulsing for its inputs and outputs. When applied, the pulsing enables the FSO diagnostics to detect cable failures as follows:

- **Inputs:** Open-circuiting and short-circuiting failures are detected with diagnostic pulsing. The failures that short-circuit the sensor are detected upon input activation when redundant connection is used.



Note: If only one of the redundant inputs is activated upon a safety function request, the FSO module activates the safety function in which the input is configured but it cannot be acknowledged before the failure is repaired. To acknowledge the safety function, you must set both input channels down and up at the same time or, switch the power off and on.

Note: ABB recommends that you use external devices which have a positive mechanical action or force-guided contacts.

Note: With external test pulses, the length of the pulses must be 0.5 ... 2 ms. Test pulses must be in totally different phasing, and must not overlap.

- **Outputs:** If diagnostic pulsing is used, failures that short-circuit the signal to the voltage supply or the ground potential are detected. Failures that open-circuit the actuator are not detected.

You can select the logical signal level for each digital output by a parameter. The selections are Active low (0 V) and Active high (24 V). Select the level depending on the application requirements. For example, Active high is suitable for the SLS indication and Active low for the SBC output. The FSO module operates according to a “de-energize to 0 V” principle, which means that in case of power loss or Fail-safe situation, the outputs will go to the low state (0 V).



WARNING! Only use the Active high selection of a digital output for indicating a status. Do not use the selection for the control of a safety device.

■ Acknowledgement

Safety functions have four acknowledgement methods for entering the Operational state (at power-up or after a safety function request is removed):

- **Manual** (recommended): The user must first acknowledge the FSO locally from the FSO I/O to allow the drive to restart.
- **Automatic:** The FSO grants the drive permission to restart after a safety function request is removed or the power-up process is completed. If the drive is in the automatic start mode, it starts automatically, which may cause danger.
- **From a safety PLC:** The FSO module expects an external acknowledgement signal from a safety PLC via the PROFIsafe communication bus.
- **Manual or from a safety PLC:** The FSO module expects an external acknowledgement signal either from the FSO I/O or from a safety PLC.

The acknowledgement method can be selected separately for the power-up, the STO (SSE and SS1 always end in drive STO), SLS and POUS safety functions.

For more information, see section [Acknowledgement methods](#) on page 54. For fault recovery, see chapter [FSO recovery](#) on page 394.



WARNING! If the FSO module has the automatic acknowledgement in use, make sure that it does not cause an unacceptable risk, for example, due to an automatic start of the drive.

■ Motor speed feedback

The FSO module must have motor speed feedback to perform safety functions. The motor speed feedback can be a measured speed from a safety encoder, or a safe speed estimate. With FSO-12 module only safe speed estimate is available. Depending on the motor speed feedback method, safety functions operate slightly differently (for example, when the indications turn on and off) due to inaccuracy in safe speed estimate. The feedback type also has an effect on how the safety functions are configured. Refer to chapter [Safety functions](#) for more information on the difference between the measured speed feedback (encoder) and safe speed estimate.

Note: With safe speed estimate, the FSO module and the drive motor control have an independent motor model of their own. The accuracy of these two speed estimates can differ from each other, especially in the low speed region.

Safe speed estimate

With safe speed estimate, the FSO module uses the drive electrical output frequency measurement to estimate the motor speed. For safe speed estimate to operate correctly, parameter [FSOGEN.21](#) must be set to the motor synchronous speed, and [FSOGEN.22](#) must be set to the motor nominal frequency.

Using safe speed estimate with an induction (asynchronous) motor: The FSO module does not estimate or compensate for motor slip. If parameter [FSOGEN.21](#) is set to the motor nominal speed, this assumes that there is always a nominal slip/load at the motor. Depending on the application, a nominal slip/load is not always present. With [FSOGEN.21](#) set to the nominal speed, a lower than nominal slip/load can cause the motor speed to be higher than the safe speed estimate. Thus, it is recommended that you set parameter [FSOGEN.21](#) to the motor synchronous speed, not nominal speed. This will generate a safe speed estimate which is more accurate with lighter loads, but the accuracy decreases when more load/slip is present. The motor synchronous speed depends on the frequency and number of poles (or pole pair number). Refer to the table that follows.

Nominal frequency	Number of poles in the motor						
	2	4	6	8	10	12	16
50 Hz	3000 rpm	1500 rpm	1000 rpm	750 rpm	600 rpm	500 rpm	375 rpm
60 Hz	3600 rpm	1800 rpm	1200 rpm	900 rpm	720 rpm	600 rpm	450 rpm

ABB

CE

UK

CA

ABB Sp. z o.o.
ul. Placydowska 27
95-070 Aleksandrów Łódzki Poland

IEC60034-1

3~ MotorM2BAX 160MLA 4 IMB3/IM10012022

No.

Ins. cl. F IP 55

V	Hz	kW	r/min	A	cos φ	Duty
690 Y	50	11	1478	12.8	0.77	S1
400 D	50	11	1478	22	0.77	S1
660 Y	50	11	1475	13	0.80	S1
380 D	50	11	1475	22.5	0.80	S1

IE4-93.3%(100%)-93.6%(75%)-93%(50%)

Product code3GBA162410-ADN

6309-2Z/C3

6209-2Z/C3

181 kg

With the example 4-pole induction motor shown above, it is recommended to use these values:

- [FSOGEN.21](#) = 1500 rpm
- [FSOGEN.22](#) = 50 Hz.

The FSO module has two safe speed estimation data channels. Speed in channel one is received from the drive ([200.01 FSO speed ch1](#)), and speed in channel two is calculated by FSO module ([200.02 FSO speed ch2](#)). FSO compares these two speed data sources. If the difference between the values is too large, the FSO module goes into the Fail-safe mode.

The motor information for the FSO module must be set according to the motor type designation label. Refer to section [Configuring general settings](#) on page [244](#).

It must be considered in the risk assessment of the application whether the safe speed estimate can be used.

Restrictions for the use of safe speed estimate

As the safe speed estimation is based on the drive electrical output frequency, there are characteristics which must be taken into account:

1. Safe speed estimate is available when the drive is modulating. If the motor shaft speed information must be safely available when the drive is not modulating, use a safety encoder together with the FSO-21 and FSE-31 modules for measuring the motor shaft speed.
2. Safe speed estimate can only be used in applications that do not have external active loads. Thus, it is not permitted to use safe speed estimate in applications that have, for example, hanging loads.
3. If the motor has slip (for example, an induction motor), the safe speed estimate differs from the drive actual motor shaft speed roughly the amount of the slip. See the graph below which illustrates the effect of the slip.
4. When the motor operates near zero speed (below 2 Hz / 3% of the nominal speed), there is ripple in the safe speed estimate signal. If the speed close to this region needs to be monitored by the FSO module using the safe speed estimate, the applicability of the estimate must be checked and considered case-by-case. For example, the motor type and number of pole pairs.
5. The drive and motor shall be dimensioned considering the application (for example, inertia, operating environment, etc). The dimensioning shall be such that all functions can be performed without exceeding the specified operating limits of the drive and motor.
6. The drive shall be dimensioned considering the motor and vice versa (for example, nominal current, nominal power, etc).
7. In the event of motor control loss, the motor shaft mechanical speed and the drive electrical output frequency can have a significant difference. The event can occur due to:
 - incorrect dimensioning of motor or AC-drive compared to the load (for example, inertia)
 - AC-drive motor control firmware failure
 - external active load
 - generator mode.

If deceleration is safety-related in the application, use a safety encoder together with the FSO-21 and FSE-31 modules for measuring the motor shaft speed, or use safety functions with ramp monitoring.

Note: When the motor shaft speed is below the monitored speed limit, then the motor shaft cannot accelerate over the speed limit, even in the event of motor shaft control loss.

The safe speed estimate calculated by the FSO module does not include slip compensation for induction motors. You must take this into account when you define monitoring limits for the safety functions. Otherwise it is possible that unnecessary monitoring limit hits occur. Using encoder for only control purposes decreases the ripple in the safe speed estimate signal. For example, defining a safe speed limit when using safe speed estimate with an induction motor:

SLS speed limit = Motor maximum permitted speed + expected motor slip + margin.

It is highly recommended to perform the best possible identification run that can be performed in the typical motor operating conditions (for example, shafts connected to motors, nominal temperature). This makes it possible to create the most accurate motor model for the speed estimation. If the Normal ID run is not possible, do the Reduced or Standstill identification run. For more information, refer to [ACS880 primary control program \(AINLX\) firmware manual \(3AUA0000085967 \[English\]\)](#), or [ACS880 primary control program \(YINLX\) firmware manual \(3AXD50001000998 \[English\]\)](#).

The safe speed estimation can only be calculated when the drive is modulating. When the drive stops the modulation, the safe speed estimation shows 0 rpm. Because of this main principle, it is a must that the motor speed starts to slow down by coasting when the power is switched off. If the motor is not decelerating fast enough by coasting, the rotation must be stopped with an external device, for example with a safe brake.


It is not allowed to use the safe speed estimation with an external active load that can accelerate the motor shaft. For example, in a hoist drive, the hanging load would potentially cause an accelerating motion because of the gravity, thus the safe speed estimate cannot be used for these types of applications.



WARNING! Applications with external active load must use a safety encoder and FSO-21 and FSE-31 modules.

The diagram below shows an example of the SLS function, and the behavior of the safe speed estimation with an induction motor and its slip. It also illustrates

the possible effect (unnecessary limit hit) if you do not take the slip into account when defining the trip limits in the FSO module.



- Actual speed
- Safe speed estimate
- SLS trip limits

In the example, the motor torque is 100% during the acceleration and the motor slip is at its maximum value. The FSO module speed estimates (ch1 & ch2) reach the SLS trip limit even though the compensated value of the actual speed of the motor stays below the SLS trip limit.

When acceleration is completed, the motor torque decreases. The FSO module speed estimates show the actual motor speed and the slip is not any more visible in the signal, assuming that the load is minimal on constant speed. The more load there is, the more slip there will be, and thus inaccuracy increases also, but in the safe direction (motor speed is lower than safe speed estimate).

During the deceleration, when the motor torque is -100%, the motor slip is again in its maximum value. Because of the torque direction, FSO speed estimates are below the actual motor speed (amount of the slip). After the FSO safe speed estimates reach 0 rpm, they begin to show reverse (negative) motor speed due to the negative motor slip. The FSO module starts to compare the safe speed estimation to the negative SLS trip limit value. Because the trip limit is much lower than the estimated speed, there will be no fault trip.

Mute time feature



WARNING! The mute time increases the response time of the safety system. This must be considered in the design of the safety system.

The FSO module has a mute time feature that can be used to suspend the monitoring limits for a short period so that spurious trips can be eliminated. The feature is available for both safe speed estimate and safety encoder feedback. The mute time feature can be especially useful with the safe speed estimate because the estimate is more prone to spurious trips caused by for example rapid changes in motor torque. The mute time should be set as short as possible.

With safe speed estimate, there are two options to implement the mute time feature in the FSO. By default, general mute time parameter [FSOGEN.31](#) is used for all speed functions. Starting from FSO rev. J, it is also possible to enable function-specific mute times for limit hit situations with parameters [FSOGEN.38](#) and [FSOGEN.39](#). For more information, refer to section [Mute time feature](#) on page 65.

Overview of safety functions

This section gives a short overview of the safety functions and gives references to the detailed descriptions. For a description of the dependencies between the safety functions, refer to section [Dependencies between safety functions](#) on page 133.

■ Safe torque off (STO)

This safety function activates the STO function in the drive, this is, opens the STO circuit in the drive. The motor coasts to a stop (stop category 0). Refer to section [STO function](#) on page 67.

The FSO module activates the STO function and the motor stops, if:

- the motor speed reaches the SAR0, SAR1, or time monitoring (ie, SS1-t) limits, or
- the FSO detects an internal failure.

■ Safe stop 1 (SS1)

This safety function stops the motor safely by ramping down the motor speed to zero speed (stop category 1). The FSO monitors the stop ramp either with the time or ramp monitoring method (SS1 function types SS1-t and SS1-r, respectively). Refer to sections

- [SS1 with time monitoring \(SS1-t\)](#) on page 73
- [SS1 with ramp monitoring \(SS1-r\)](#) on page 75.

■ Safe stop emergency (SSE)

This safety function stops the motor safely by coasting (stop category 0) or ramping down (stop category 1) the motor speed to zero speed.

You can configure this safety function to be similar to the STO (SSE with immediate STO, stop category 0) or SS1 function (SSE with emergency ramp, stop category 1). Refer to sections

- [SSE with immediate STO](#) on page 86,
- [SSE with time monitoring](#) on page 91
- [SSE with ramp monitoring](#) on page 93.

SSE is also activated in certain FSO fault reaction situations, refer to [Safe stop emergency \(SSE\)](#) on page 86.

■ Safe brake control (SBC)

This safety function provides a safe output for controlling external safety brakes. When you use the SBC function with other safety functions of the FSO module, it is always combined with the drive STO function. That is, the SBC function is activated before, at the same time with, or after the drive STO function, and also when an internal fault occurs as it activates STO.

STO function and SSE with immediate STO

In these safety functions, you can configure the SBC function to be activated before, at the same time with, or after the drive STO function. Refer to sections

- [SBC after STO](#) on page 69,
- [SBC before STO](#) on page 71,
- [SSE with immediate STO, SBC after STO](#) on page 87
- [SSE with immediate STO, SBC before STO](#) on page 89.

Note: The SBC is activated also when the drive STO is activated at zero speed in the SSE and SS1 functions.

Note: The FSO module activates the SSE function after trip limit hits in the SLS and SMS functions. As a result, this activates the drive STO and SBC functions (for more information, refer to section [Safe stop emergency \(SSE\)](#) on page 86). Make sure that you dimension the brake correctly for these situations.

SS1 function and SSE with emergency ramp

In these safety functions, you can configure the SBC and STO combination to be activated at a user-defined speed limit while ramping down to zero speed. Refer to sections

- [SS1 with speed limit activated SBC](#) on page 77
- [SSE with speed limit activated SBC](#) on page 94.

You can also define a delay so that the SBC is activated first at the user-defined speed limit and the drive STO after the delay. Refer to sections

- [SS1 with speed limit activated SBC, SBC before STO](#) on page 77
 - [SSE with speed limit activated SBC, SBC before STO](#) on page 98.
-

■ Safely-limited speed (SLS)

This safety function prevents the motor from exceeding user-defined speed limits. If the motor speed reaches the positive or negative SLS trip limit, the FSO module activates the SSE function and the motor stops. Refer to section [Safely-limited speed \(SLS\)](#) on page 102.

■ Variable Safely-limited speed (SLS)

This safety function prevents the motor from exceeding user-defined speed limits. With the variable SLS function, it is possible to scale down the SLS limits with a safety PLC via PROFIsafe communication. Refer to section [Variable Safely-limited speed \(SLS\)](#) on page 124 and chapter [PROFIsafe](#).

■ Safe maximum speed (SMS)

This safety function is used to protect the machine from too high speeds/frequencies. You can configure it to be permanently on or off. If the motor speed reaches the SMS trip limit, the FSO module activates the SSE function and the motor stops. There are two different versions of the SMS function. Refer to sections

- [SMS function, version 1](#) on page 129
- [SMS function, version 2](#) on page 130.

■ Prevention of unexpected start-up (POUS)

This safety function prevents the machine from starting accidentally. The POUS function activates the drive STO function. Refer to section [Prevention of unexpected start-up \(POUS\)](#) on page 131.

■ Safe acceleration range (SAR)

This safety function provides safe deceleration ramp monitoring for other safety functions. FSO module has two different SAR functions, SAR0 and SAR1.

SAR0 and SAR1 functions behave in the same way but they can be configured to work differently, based on the application needs. SAR0 parameters are used with the SSE function. SAR1 parameters are used with the SS1, SLS, varSLS, and SDI functions. For more information, refer to section [Configuring SAR](#) on page 278.



Safety functions

Contents of this chapter

This chapter describes how the safety functions of the FSO module operate.

The FSO-12 module supports these safety functions:


Safety function	Stop category	Information	Page
Safe torque off (STO)	Stop category 0	STO: standard drive feature	67
Safe stop 1 (SS1)	Stop category 1	With time (SS1-t) or ramp monitoring (SS1-r)	72
Safe stop emergency (SSE)	Stop category 0 or 1	With immediate STO or emergency ramp with time or ramp monitoring	86
Safe brake control (SBC)		With STO, SSE and SS1 functions	51
Safely-limited speed (SLS)		With time or ramp monitoring	102
Variable Safely-limited speed (SLS)		Only with PROFIsafe	124
Safe maximum speed (SMS)		Function permanently on/off Two different versions	128
		Version 1	129
		Version 2	130
Prevention of unexpected start-up (POUS)			131

General

■ Safety function request

A safety function can be activated locally from FSO digital inputs, from a safety PLC, in FSO internal fault situations or by another safety function (see section [Dependencies between safety functions](#) on page 133).

If you want to control a safety function with a push button, connect an activation button to an FSO digital input. 24 V in the input is the non-request for a safety function and 0 V is the request.



ID	Description
A	Normal request: The request is recognized when the button is pressed. The pressing time of the button must be at least 20 ms. Note: The safety function request must be removed before the acknowledgement is accepted.
B	Short low signals (less than 20 ms) are ignored.
C	The safety function is activated when the request signal lasts at least 20 ms.

Note: The FSO module executes the requested safety function even if the request is removed before the function has reached the acknowledgement criteria.

Note: With one input it is possible to activate up to two separate safety functions. A request activates both functions simultaneously. For the execution order, see section [Priorities between safety functions](#) (page 132).

Note: The FSO module does not react to activation requests of the safety functions during the boot.


■ Acknowledgement methods

You can configure the acknowledgement method separately for the power-up, STO (SSE and SS1 always end in drive STO), SLS and POUS safety functions.

The acknowledgement method can be manual or automatic, from a safety PLC via the PROFIsafe communication bus, or either manual or from a safety PLC.

- **Automatic:** The FSO module acknowledges the power-up process and/or safety functions automatically when these have completed successfully and the safety function request has been removed.
- **From a safety PLC:** The FSO module expects an external acknowledgement signal from a safety PLC via the PROFIsafe communication bus. The PROFIsafe profiles include the acknowledgement bits (see section [FSO PROFIsafe profiles](#) on page 140).
- **Manual:** The FSO module requires a manual acknowledgement at the end of the power-up process and/or after successful completion of a safety function when the safety function request has been removed. The user must do this manually by pressing the acknowledgement button.

You can connect only one acknowledgement button to the FSO module. The acknowledgement button must be of type “normally closed” (NC). The acknowledgement button is connected like a normal safety input. 24 V in the input is the standby (negative) state and 0 V is the positive (acknowledge) state.



ID	Description
A	Normal acknowledgement: The acknowledgement is recognized when the button is released after pressing it; the system must detect both falling and rising edge changes for successful acknowledgement triggering. The pressing time of the button must be between 0.3 ... 3.0 s.
B	Short low signals (less than 0.3 s) are ignored.
C	Too long interruptions (signal low longer than 3.0 s) on the signal are ignored and a warning message (A7D0) is generated to the drive. If there is something to acknowledge, it is ignored and the user must press the acknowledgement button again.

Acknowledgement is possible, if:

- A safety function request is not active.
- STO: Delay defined by parameter [STO.13 Restart delay after STO](#) or [STO.14 Time to zero speed with STO and modoff](#) has passed.

Note: If an SSE or SS1 request is received while the STO function is active, the STO function must be completed before acknowledgement is permitted. For more information, refer to section [Safe torque off \(STO\)](#) on page 67.

- SSE, SS1: Safety function is completed.
- SLS, Variable SLS: The monitoring has started.

When automatic acknowledgement is used, the FSO module acknowledges the safety function immediately after the safety function request has been removed and the above requirements are met.

When manual or acknowledgement from a safety PLC is used, the FSO module waits for an external acknowledgement signal (from the FSO I/O or from a safety PLC) before it can acknowledge the safety function(s). After the FSO module has received the signal, it acknowledges all active safety functions that can be acknowledged with the same acknowledgement.

When several safety functions are active at the same time, the priorities described in section [Priorities between safety functions](#) (page 132) apply.

Note: If the FSO module is rebooted after a safety function request has been removed but before it has been acknowledged, the FSO reboot acknowledges the safety function.

■ DC magnetization and drive start modes

The correct operation of safety functions that limit or monitor motor speed (for example, SLS, SMS) requires that the ID run is done prior to operation.


Note: Motor speed estimation is disabled on drive side when certain start modes with magnetization or DC current control modes are active. SLS cannot provide reliable protection during motor start, when:

1. Motor start with magnetization is requested: parameter 21.01 Start mode = Fast (0) OR Constant time (1) OR Automatic (2), OR
2. DC current control is enabled with parameter 21.08 DC current control. This parameter is associated with DC hold and Post magnetization features, OR
3. Motor pre-heating is enabled with parameter 21.14 Pre-heating input source, OR
4. Continuous magnetization is enabled with parameter 21.12 Continuous Magnetization command = Magnetization active (1), OR
5. Auto-phasing is enabled, OR
6. Fly-start is on.

For more information, refer to the firmware manual of the drive.

Ramp monitoring

The ramp monitoring is configured with five parameters as described below.



ID	Description
A	Minimum deceleration time from the Scaling speed to zero. Configured for each SARn ramp, n = 0...1 separately. For example for SAR0: parameter SARx.11 SAR0 min ramp time to zero .
B	Target time for deceleration from the Scaling speed to zero. Configured for each SARn ramp, n = 0...1 separately. For example for SAR0: parameter 200.102 SAR0 ramp time to zero .
C	Maximum deceleration time from the Scaling speed to zero. Configured for each SARn ramp, n = 0...1 separately. For example for SAR0: parameter SARx.12 SAR0 max ramp time to zero .
D	Initial allowed range for the SARn ramp: value of parameter SARx.02 SAR initial allowed range . This parameter moves the location of the maximum ramp forward on the time axis, when monitoring is started, that is, at time of D, the maximum limit is the value of the motor speed, that was in use when the monitoring started. Common for all ramps SARn, n = 0...1.
E	Scaling speed: value of parameter 200.202 SAR speed scaling . Speed value that the FSO module uses as a reference point in ramp time calculations. This value and the minimum (A), target (B) and maximum (C) ramp times define fixed slopes for the deceleration ramps that are used in ramp monitoring. Common for all ramps SARn, n = 0...1.

Limit hit: If the motor speed hits a ramp monitoring limit, the FSO module activates the STO function and generates an event. The user can select the

event type (warning, fault or event) with parameter [FSOGEN.62 STO indication safety limit](#).

■ Safety function indications

Safety functions have the following indications:

- Request indication, which is shown in the control panel or in the event log (stopping functions (STO, SS1, SSE) and POUS)
- Digital output indication, see [Parameters](#) on page 309
- Status bit indication, see [FSO PROFIsafe profiles](#) on page 140 and [Status and control words](#) on page 347.

Request indication

The safety function request indication for stopping functions (STO, SS1, SSE) and POUS is activated immediately when a safety function is requested. The type of the indication (event type) is selected with parameter [FSOGEN.61 STO indication ext request](#).

Note: For the POUS function, the request indication is always a warning if activated when the drive is not modulating, and the indication is a fault, when the drive is modulating, see [FSO premature POUS](#) on page 382.

FSO digital output indication

FSO digital outputs can be configured for indication or for controlling, eg, safety door locking/unlocking. Digital output indications for the safety functions are explained in connection with the safety function descriptions in chapter [Safety functions](#), in [Configuring I/O](#) on page 246, and in [Parameters for FSO inputs and outputs](#) on page 339.

If configured to a function output parameter, the digital output is controlled to change state immediately when a safety function is requested. If configured to a function completed output parameter, the digital output is controlled to change state when a safety function is completed.

Note: A logic state of output indication signals can be configured to be active low or active high.

See also chapter PROFIsafe for [Remote I/O control](#) on page 138.

Status bit indication

PROFIsafe status bit indication of the safety function is relevant when the FSO module is part of a PROFIsafe control system. These are safety-related indications.

Note: Status and control words (see [Status and control words](#) on page 347) are not safety-related indications, and they can be used for monitoring purposes

only. They are not allowed to be used as safe status and control indications in PROFIsafe/safety systems.

STO, SS1, SSE, POUS functions

States of the configured and connected functions are indicated with FSO digital outputs and fieldbus status signals when the function is started:

- Stopping functions (SSE and SS1) are always started and their active state indicated immediately (the monitoring method depends on the configuration) (parameters [SSE.21 SSE output](#) and [SS1.21 SS1 output](#)).
- The drive STO state is indicated when the drive STO circuit is open (parameter [STO.21 STO output](#) and octet 0 bit 7 STO_active).

Note: When the SBC is activated before the drive STO, the drive STO active state is indicated after a delay (parameter [SBC.12 STO SBC delay](#)).

Note: SBC active state is indicated only with status bit (octet 0 bit 6 SBC_active).

- POUS active state is indicated immediately when requested from an input ([POUS.21 POUS output](#)).
- Ramp monitoring (SAR0 and SAR1, see section [Configuring SAR](#) on page 278) is not indicated.

The FSO module switches off the digital output indications (SSE, SS1 and POUS functions) when the function is acknowledged.

Stop completed indications are activated when the stopping function has completed, but is not yet acknowledged. There are separate indications for each stopping function STO, SSE and SS1 (parameters [STO.22 STO completed output](#), [SSE.22 SSE completed output](#), [SS1.22 SS1 completed output](#)) and one common for all of them (parameter [FSOGEN.11 Stop completed output](#)). The FSO module switches off the indications when the function is acknowledged.

The completed indication of the POUS function (parameter [POUS.22 POUS completed output](#)) is activated after the time defined by parameter [POUS.13 POUS delay for completion](#) has passed. The FSO module switches off the completed indication when the POUS request is removed.

SLS, Variable SLS

- SLS active state is indicated when the motor speed is in the user-defined range. The FSO module switches off the indication when the function is acknowledged or the monitored speed exceeds the user-defined limit (this also causes the SLS to trip, that is, the FSO module activates the SSE function).

For further information on indication and output parameters, see chapter [Parameters](#) on page 309, and [FSO PROFIsafe profiles](#) on page 140.

■ FSO modes

The FSO can be in one of the following modes:

- **Power down:** The power to the FSO is off. The drive STO circuit is open. The POWER LED is off.
- **Start-up:** The FSO is starting up after power-up. Indicated with a blinking green RUN LED.
- **Running:** The FSO is up and running. It can be in different states (see section [FSO states](#) on page 61) depending on the status of safety functions and the safety fieldbus communication. Indicated with a green RUN LED.
- **Fail-safe:** There is a failure in the FSO. The drive STO is active. Indicated with a red STATUS/FAULT LED. You have to reboot the FSO to exit the Fail-safe mode. See section [Transitions between FSO modes and states](#) on page 62.
- **Configuration:** Parameters are uploaded from the FSO module. The drive STO is active. Indicated with blinking RUN and STATUS/FAULT LEDs. You can exit the Configuration mode by downloading the new configuration to the FSO or by rebooting the FSO.

For more information on the FSO LEDs, see section [Status LEDs](#) on page 379.

■ FSO states

When the FSO is up and running, it can be in one of the following states depending on the drive STO status:

- **Safe:** STO active, that is, the drive STO circuit is open and the motor is stopped. The SBC is active (if used).
- **Operational:** STO inactive.


In the Operational and Safe states, the FSO can execute the safety functions.

Note: When the POUS function is active, the FSO module is in the Operational state and the drive STO is active.

■ Transitions between FSO modes and states

The following diagram shows the possible transitions during normal operation of the FSO module.

- Power down:STO active, power off (below 19 V)
- Start-up:STO active, power on (above 19 V), start-up checks performed
- Configuration:STO active, setting of parameters
- Operational:STO inactive, FSO running
- Operational:STO active, POUS active, FSO running
- Safe:STO active, FSO running
- Fail-safe:STO active, I/O, FSO or communication fault detected.



At power-up, the FSO goes into the Start-up mode. During the power-up process, FSO is in Safe state (STO active). It performs start-up checks and, according to the configuration, enters the Operational state either automatically or after an acknowledgement request from the FSO I/O or from a safety PLC.

The Drive Composer pro PC tool can request the Configuration mode, when the FSO is in the Start-up, Operational, Safe or Fail-safe mode and the drive is in the Torque off mode (not modulating). The FSO exits the Configuration mode into the Start-up mode when the user either:

- downloads the new configuration to the FSO, or
- reboots the module (for rebooting instructions, see chapter [FSO recovery](#) on page 394).

If there is an internal fault, the FSO enters the Fail-safe mode. To identify and recover from the cause of the fault, see section [FSO recovery](#) on page 394.

The FSO exits the Fail-safe mode into the Start-up mode when the user reboots the module (for rebooting instructions, see chapter [FSO recovery](#) on page 394).

When the FSO is in the Power down, Start-up, Configuration, Safe or Fail-safe mode, the drive STO function is always active. When the FSO is in the Operational state, the drive STO function is inactive (except when the POUS function is active, the drive STO function is also active).

Note: When the drive is connected to a safety PLC via the PROFIsafe over PROFINET communication bus, see the states diagrams in section [FSO module modes and states](#) on page 146 in chapter [PROFIsafe](#).

■ Cascade

It is possible to cascade up to six FSO modules into a daisy-chain type network (resembles somewhat an I/O master/follower system): If an FSO triggers a cascaded safety function, it passes the triggering information to the next FSO, which triggers the next one, and so on, until the last FSO again triggers the first one.


Without a PROFIsafe communication bus, you can cascade only safety functions which have a primary and a secondary digital input: STO, SS1, SSE and SLS1.

If you want to a cascade safety function which has only one digital input (SLS2, SLS3, SLS4), you must have a PROFIsafe communication bus and configure the safety function request from a safety PLC.

For detailed configuration instructions, see section [How to configure a cascaded system](#) on page 248.

This figure shows an example cascade configuration. Two different safety functions are cascaded in the same cascaded system. Safety function 1 is

cascaded in one cascade loop (Cascade A) and safety function 2 in another (Cascade B).



The inputs and outputs of the FSO module are defined as pairs. In this example, single input X113:2 is cascaded with single output X113:8 in Cascade A. When Emergency stop (Safety function 1 = SSE) is activated in the master FSO module (from a redundant digital input X113:1 & X114:1), it is also activated in the follower FSO modules via digital master FSO outputs. Safety function 2 is cascaded with single input X113:3 and single output X113:9 (Cascade B). When POUS (Safety function 2 = POUS) is activated in the master FSO module (from a single digital input X113:4), it is also activated in the follower FSO modules. Feedback from the last FSO in cascaded chain is wired back to master FSO.

You must configure one of the cascaded FSO modules as the master and the others as followers.

You can configure a separate safety function indication both in the master and the follower FSO modules. Use the completed output of the cascaded safety function for the indication - in this example, output X113:7 is used to indicate SSE completed.

You must configure all follower FSO modules to use the automatic acknowledgement method. The master FSO module can use any

acknowledgement method. The acknowledgement always starts from the master FSO module.

You can configure one or two safety functions in the same cascaded system (Cascade A and Cascade B). If the whole cascaded system must trip after reaching a trip limit of any safety function, or with a safety fieldbus failure, you must cascade the SSE function.

If an FSO module activates the STO function (after a limit hit, an STO request from the I/O or the safety fieldbus, or after an internal fault), also the cascaded SSE output is triggered.

Note: When several drives are linked together in a master/follower system and the follower drive is in the torque control mode, stopping functions with a deceleration ramp (SSE with emergency ramp and SS1) will turn the follower drive to the speed control mode. For more information on the master/follower functionality in the drive, see the firmware manual.

■ Mute time feature



WARNING! The mute time increases the response time of the safety system. This must be considered in the design of the safety system.

Mute time feature with the safe speed estimation

When there are spurious transients in safe speed estimate, you can suspend speed monitoring with mute time to prevent unnecessary trips in the safety system. The transient mute time can be set to cover the transient situation with the parameter [FSOGEN.31 Transient mute time](#). This transient mute time covers limit hits, monitoring start, and zero speed limits.

It is also possible to use function-specific mute times for limit hit situations in SLSx, SMS, and variable SLS functions with the safe speed estimate (starting from FSO rev. J). Mute times for each of these functions can be set independently. In addition, they can be set longer than the transient mute time [FSOGEN.31](#).

By default, these function-specific mute times are disabled, and the value set to parameter [FSOGEN.31 Transient mute time](#) is used in limit hit situations instead. Function-specific mute times for limit hit situations of the SLSx and variable SLS functions can be enabled with the parameter [FSOGEN.38 Enable SLSx mute times](#).

After the SLSx specific mute times have been enabled, the following mute time parameters are used in limit hit situations.


- [SLSx.17 Mute time for SLS1](#)
- [SLSx.27 Mute time for SLS2](#)
- [SLSx.37 Mute time for SLS3](#)
- [SLSx.47 Mute time for SLS4](#)
- [SLSx.57 Mute time for variable SLS](#)

The function-specific mute time for SMS is activated with a separate parameter [FSOGEN.39 Enable SMS mute time](#). After the parameter [FSOGEN.39](#) has been activated, the mute time parameter [SMS.17 Mute time for SMS](#) is used in limit hit situations for the SMS function.

In monitoring start and zero speed limit situations, [FSOGEN.31 Transient mute time](#) parameter is always used even if the SLSx and SMS specific mute times are enabled.

Mute times in monitoring start, limit hit and zero speed situations

The parameters used for monitoring start, limit hit and zero speed situations are described in the time diagram and table below.



- | | |
|---|---|
| A | SLS trip limit |
| B | SLS limit |
| C | FSOGEN.51 Zero speed without encoder |
| 1 | SLS function is requested from higher speed than the SLS limit. |
| 2 | Monitoring start situation |
| 3 | Limit hit situation |
| 4 | Zero speed situation |

	Monitoring start delay (D)	Limit hit (E)	Zero speed delay time (F)
Function-specific mute times disabled	FSOGEN.31	FSOGEN.31	FSOGEN.31
Function-specific mute times enabled	FSOGEN.31	Function-specific mute times	FSOGEN.31

Note: SS1 and SSE functions always use [FSOGEN.31](#) for limit hit situations.

Safe torque off (STO)

The STO function brings the machine safely into a no-torque state and/or prevents it from starting accidentally. The STO function in the FSO module activates the drive STO function, that is, opens the STO circuit in the drive. This prevents the drive from generating the torque required to rotate the motor. If the motor is running when the STO function is activated, it coasts to a stop.

You can configure the SBC function to be activated before, at the same time with, or after the drive STO function. For more information on the STO function in the ACS880 drives, refer to the applicable drive hardware manual.



WARNING! For the encoderless mode, you have to set parameters [STO.14](#) and [SBC.13](#) so that the motor has enough time to stop from full speed when modulation is stopped.


Note: If the SSE is cascaded, STO activation also activates the SSE cascade indication signal (output). See sections [Safe stop emergency \(SSE\)](#) on page 86 and [Cascade](#) on page 63.

Note: Always set the parameters related to the STO function to have the correct monitoring limit hit and fault reaction behavior. An internal monitoring of the FSO module can trigger the STO function even if you have not defined an external request signal. These internal monitorings trigger STO:

- SAR0, SAR1 or SSE/SS1 limit hit
- FSO module fail safe state.

■ STO function

The operation of the STO function when the SBC is not used is described in the time diagram and table below. For configuration, see section [How to configure STO](#) on page 256.




- A Time to zero speed (parameter [STO.14](#)): Time from the STO activation to the moment when the safety function is completed and the STO completed indication (parameter [STO.22](#)) goes on. You must set this to the estimated time in which the motor coasts to a stop from the maximum speed.
- B Restart delay after STO (parameter [STO.13](#)): Time from the STO activation to the moment when the acknowledgement becomes allowed. With this parameter, you can allow a restart of the drive before the motor has stopped (fly-start). You can use this feature only in certain applications. This parameter is relevant only when an external request activates the STO function.

Step	Description
1	The STO request is received (for example, from the I/O). The FSO activates the drive STO function and starts counters for times A and B. STO active indication parameter STO output (STO.21) goes on.
2	After time B has elapsed, the acknowledgement becomes allowed as soon as the STO request has been removed (step 4). Note: If an SSE or SS1 request is received while the STO function is active, the STO function must be completed before the acknowledgement is allowed.
3	After time A has elapsed, the FSO module defines the motor as stopped and the STO completed indication goes on.
4	The STO request is removed.
5	After the acknowledgement, the STO function is deactivated. The indications STO output (STO.21) and STO completed output (STO.22) go off.

■ SBC after STO

The operation of the SBC after the STO function (positive SBC delay) is described in the time diagram and table below. For configuration, see section [How to configure SBC after STO](#) on page 257.



- A SBC delay (parameter [SBC.12](#)): Time from the activation of the drive STO function to the moment when the FSO activates the SBC function (brake). In this case the value is positive and the FSO activates the SBC after the drive STO. If the value is zero, the FSO activates the SBC and drive STO functions at the same time. **Note:** It is possible to set the SBC delay so that the SBC is activated while the motor is still rotating.
- B SBC time to zero speed (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the STO completed indication (parameter [STO.22](#)) goes on. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
- C Restart delay after STO (parameter [STO.13](#)): Time from the STO activation to the moment when the acknowledgement becomes allowed. With this parameter, you can allow a restart of the drive before the motor has stopped (fly-start). You can use this feature only in certain applications. This parameter is relevant only when an external request activates the STO function.

Step	Description
1	The STO request is received (for example, from the I/O). The FSO activates the drive STO and starts counters for times A and C. STO active indication parameter STO output (STO.21) goes on.


70 Safety functions

Step	Description
2	After time C has elapsed, the acknowledgement becomes allowed as soon as the STO request has been removed (step 5).
3	After time A has elapsed, the FSO activates the SBC (brake) and starts a counter for time B.
4	After time B has elapsed, the FSO module defines the motor as stopped and the STO completed indication goes on.
5	The STO request is removed.
6	After the acknowledgement, the STO and SBC functions are deactivated, and the control is given back to the drive, which controls the brake from now on. The indications STO output (STO.21) and STO completed output (STO.22) go off.

■ SBC before STO

The operation of the SBC before the STO function (negative SBC delay) is described in the time diagram and table below. For configuration, see section [How to configure SBC before STO](#) on page 258.

The reason to use a negative SBC delay is to have the mechanical brake closed just before the drive STO circuit is opened.



- A SBC delay (parameter [SBC.12](#)): Time from the activation of the drive STO to the moment when the FSO activates the SBC function (brake). In this case the value is negative and the FSO activates the SBC before the drive STO. If the value is zero, the FSO activates the SBC and drive STO functions at the same time.
- B SBC time to zero speed (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the STO completed indication (parameter [STO.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
- C Response time (depends on system configuration, see page 420)

Step	Description
1	The STO request is received (for example, from the I/O). The FSO activates the SBC function (brake) and starts counters for times A and B. STO active indication parameter STO output (STO.21) goes on.

Step	Description
2	After time C has elapsed, the SBC starts to brake the motor.
3	After time A has elapsed, the FSO activates the drive STO.
4	After time B has elapsed, the FSO module defines the motor as stopped and the STO completed indication goes on. The acknowledgement becomes allowed as soon as the STO request has been removed (step 5).
5	The STO request is removed.
6	After the acknowledgement, the STO and SBC functions are deactivated, and the control is given back to the drive, which controls the brake from now on. The indications STO output (STO.21) and STO completed output (STO.22) go off.

Safe stop 1 (SS1)

The SS1 function stops the motor safely by ramping down the motor speed. The FSO activates the drive STO function below a user-defined zero speed limit.


The FSO monitors the stop ramp either with the time or ramp monitoring method (SS1 function types SS1-t and SS1-r, respectively). If the motor speed does not follow the monitoring limit(s), the FSO activates the STO function and the motor coasts to a stop.

The SS1 function uses SAR1 parameters to define and/or monitor the stop ramp.

When you use the SBC function with the SS1 function, you can configure the SBC and drive STO combination to be activated at a user-defined speed limit while ramping down to zero speed. You can also define a delay so that the SBC is activated first at the user-defined speed limit and the drive STO after the delay.

■ SS1 with time monitoring (SS1-t)

The operation of the SS1 with time monitoring (SS1-t) is described in the time diagram and table below. For configuration, see section [How to configure SS1 with time monitoring \(SS1-t\)](#) on page 259.



- A SS1-t delay for STO (parameter [SS1.14](#)): Time after which the FSO activates the STO function regardless of the motor speed.
- B Zero speed (parameter [FSOGEN.51](#)): Speed limit for activating the drive STO function. The safety function is completed and the SS1 completed indication (parameter [SS1.22](#)) goes on.
- C Response time (depends on system configuration, see page [420](#))


Step	Description
1	The SS1 request is received (for example, from the I/O). The FSO starts a counter for time A. SS1 active indication parameter SS1 output (SS1.21) goes on.
2	After time C has elapsed, the drive starts to ramp down the motor speed. SAR1 parameter 200.112 defines the deceleration ramp. Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.

74 Safety functions

Step	Description
3	<p>The motor speed reaches the zero speed limit (B), FSO activates the drive STO function and STO active indication parameter STO output (STO.21) goes on. The SS1 completed output indication (parameter SS1.22) goes on and the acknowledgement becomes allowed as soon as the SS1 request has been removed (step 4).</p> <p>Note: If the SBC is configured in the STO function (see section Safe torque off (STO) on page 67), also the SBC is activated (not shown in the figure).</p> <ul style="list-style-type: none">• If the STO SBC delay (parameter SBC.12) is negative, the SBC is activated here and the drive STO after this delay.• If the STO SBC delay is positive or zero, the SBC and drive STO functions are activated at the same time.• The SS1 completed indication goes on after the delay defined with parameter SBC.13 has elapsed from the SBC activation. <p>Note: You can define an extra delay (parameter SS1.15) before the FSO activates the drive STO (not shown in the figure).</p>
3b	<p>If the drive has not decelerated fast enough when time A has elapsed, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p>
4	<p>The SS1 request is removed.</p>
5	<p>After the acknowledgement, the STO and SS1 functions are deactivated. The indications SS1 output (SS1.21), SS1 completed output (SS1.22), and STO output (STO.21) go off.</p>

■ SS1 with ramp monitoring (SS1-r)

The operation of the SS1 with ramp monitoring (SS1-r) is described in the time diagram and table below. For configuration, see section [How to configure SS1 with ramp monitoring \(SS1-r\)](#) on page 261.



- A Zero speed (parameter [FSOGEN.51](#)): Speed limit for activating the drive STO function. The safety function is completed and the SS1 completed indication (parameter [SS1.22](#)) goes on. The acknowledgement becomes allowed.
- B Response time (depends on system configuration, see page [420](#))
- Ramp monitoring limits

Step	Description
1	The SS1 request is received (for example, from the I/O).
2	After time B has elapsed, the drive starts to ramp down the motor speed. SAR1 parameter 200.112 defines the deceleration ramp. The FSO starts the SAR1 ramp monitoring (parameters SARx.21 and SARx.22). Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.
2b	If the motor speed hits a ramp monitoring limit, the FSO activates the STO function. Refer to section Safe torque off (STO) on page 67 for more information on how to configure the STO function.


Step	Description
3	<p>The motor speed reaches the zero speed limit (B), FSO stops the SAR1 monitoring and activates the drive STO function, and STO active indication parameter STO output (STO.21) goes on. The SS1 completed output indication (parameter SS1.22) goes on and the acknowledgement becomes allowed as soon as the SS1 request has been removed (step 4).</p> <p>Note: If the SBC is configured in the STO function (see section Safe torque off (STO) on page 67), also the SBC is activated (not shown in the figure).</p> <ul style="list-style-type: none"> • If the STO SBC delay (parameter SBC.12) is negative, the SBC is activated here and the drive STO after this delay. • If the STO SBC delay is positive or zero, the SBC and drive STO functions are activated at the same time. • The SS1 completed indication goes on after the delay defined with parameter SBC.13 has elapsed from the SBC activation. <p>Note: You can define an extra delay (parameter SS1.15) before the FSO activates the drive STO (not shown in the figure).</p>
4	The SS1 request is removed.
5	<p>After the acknowledgement, the STO and SS1 functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SS1 output (SS1.21), SS1 completed output (SS1.22), and STO output (STO.21) go off.</p>

■ SS1 with speed limit activated SBC

In these examples, the SBC and drive STO functions are activated at a user-defined speed limit.

With time monitoring (SS1-t)

The operation of the SS1-t function with speed limit activated SBC is described in the time diagram and table below. For configuration, see section [How to configure SS1 with speed limit activated SBC](#) on page 262.




- A SBC speed (parameter [SBC.15](#)): Speed limit below which the FSO activates the SBC (brake) and drive STO functions while ramping.
- B SS1-t delay for STO (parameter [SS1.14](#)): Time after which the FSO activates the STO function regardless of the motor speed.
- C SBC time to zero (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SS1 completed indication (parameter [SS1.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
- D Response time (depends on system configuration, see page [420](#))

Step	Description
1	The SS1 request is received (for example, from the I/O). The FSO starts a counter for time B. SS1 state indication parameter SS1 output (SS1.21) goes on.
2	After time D has elapsed, the drive starts to ramp down the motor speed. SAR1 parameter 200.112 defines the deceleration ramp. Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.
3	The motor speed goes below the SBC speed limit (A), the FSO checks the value of STO SBC delay (parameter SBC.12) and activates the SBC and drive STO functions: <ul style="list-style-type: none"> • If the STO SBC delay is positive or zero, the SBC and drive STO functions are activated at the same time (this case is shown in the figure). • If the STO SBC delay is negative, the SBC is activated here and the drive STO after this delay (see section SS1 with speed limit activated SBC, SBC before STO on page 80). • STO active indication parameter STO output (STO.21) goes on when STO is activated. <p>The FSO starts a counter for time C.</p> <p>Note: You can define an extra delay (parameter SS1.15) before the FSO activates the SBC and drive STO functions (not shown in the figure).</p>
3b	If the drive has not ramped down fast enough when time B has elapsed, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.
4	After time C has elapsed, the FSO defines the motor as stopped, the SS1 completed output indication (parameter SS1.22) goes on and the acknowledgement becomes allowed as soon as the SS1 request has been removed (step 5).
5	The SS1 request is removed.
6	After the acknowledgement, the SS1, STO and SBC functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SS1 output (SS1.21) , SS1 completed output (SS1.22) , and STO output (STO.21) go off.

With ramp monitoring (SS1-r)

The operation of the SS1-r function with speed limit activated SBC is described in the time diagram and table below. For configuration, see section [How to configure SS1 with speed limit activated SBC](#) on page 262.



- A SBC speed (parameter [SBC.15](#)): Speed limit below which the FSO activates the SBC (brake) and drive STO functions while ramping.
 - B SBC time to zero (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SS1 completed indication (parameter [SS1.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
 - C Response time (depends on system configuration, see page [420](#))
- Ramp monitoring limits

Step	Description
1	The SS1 request is received (for example, from the I/O).


Step	Description
2	<p>After time C has elapsed, the drive starts to ramp down the motor speed. SAR1 parameter 200.112 defines the deceleration ramp. The FSO starts the SAR1 ramp monitoring (parameters SARx.21 and SARx.22).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p>
3	<p>The motor speed goes below the SBC speed limit (A), the FSO stops the SAR1 monitoring. The FSO checks the value of STO SBC delay (parameter SBC.12) and activates the SBC and drive STO functions:</p> <ul style="list-style-type: none">• If the STO SBC delay is positive or zero, the SBC and drive STO functions are activated at the same time (this case is shown in the figure).• If the STO SBC delay is negative, the SBC is activated here and the drive STO after this delay (see section SS1 with speed limit activated SBC, SBC before STO on page 80.)• STO active indication parameter STO output (STO.21) goes on when STO is activated. <p>The FSO starts a counter for time B.</p> <p>Note: You can define an extra delay (parameter SS1.15) before the FSO activates the SBC and drive STO functions (not shown in the figure).</p>
3b	<p>If the motor speed hits a ramp monitoring limit, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p>
4	<p>After time B has elapsed, the FSO defines the motor as stopped, the SS1 completed output indication (parameter SS1.22) goes on and the acknowledgement becomes allowed as soon as the SS1 request has been removed (step 5).</p>
5	<p>The SS1 request is removed.</p>
6	<p>After the acknowledgement, the SS1, STO and SBC functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SS1 output (SS1.21), SS1 completed output (SS1.22), and STO output (STO.21) go off.</p>

■ SS1 with speed limit activated SBC, SBC before STO

In these examples, the SBC function is activated at a user-defined speed limit and drive STO function after a user-defined delay (negative SBC delay). The reason to use a negative SBC delay (parameter SBC.12) is to have the mechanical brake closed just before the drive STO circuit is opened.

With time monitoring (SS1-t)

The operation of the SS1-t function with speed limit activated SBC, SBC before STO is described in the time diagram and table below. For configuration, see section How to configure SS1 with speed limit activated SBC, SBC before STO on page 265.




- A SBC speed (parameter [SBC.15](#)): Speed limit below which the FSO activates the SBC (brake).
- B SS1-t delay for STO (parameter [SS1.14](#)): Time after which the FSO activates the STO function regardless of the motor speed.
- C SBC delay (parameter [SBC.12](#)): Time from the activation of the SBC function to the moment when the FSO activates the drive STO function.
- D SBC time to zero (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SS1 completed indication (parameter [SS1.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
- E Response time (depends on system configuration, see page [420](#))

Step	Description
1	The SS1 request is received (for example, from the I/O). The FSO starts a counter for time B. SS1 state indication parameter SS1 output (SS1.21) goes on.
2	After time E has elapsed, the drive starts to ramp down the motor speed. SARI parameter 200.112 defines the deceleration ramp. Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.

Step	Description
3	The motor speed goes below the SBC speed limit (A), the FSO activates SBC function. The FSO starts counters for times C and D. Note: You can define an extra delay (parameter SS1.15 , not shown in the figure) before the FSO activates the SBC function. This affects also the STO activation (step 4).
3b	If the drive has not ramped down fast enough when time B has elapsed, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.
4	After time C has elapsed, the FSO activates the drive STO function. STO active indication parameter STO output (STO.21) goes on when STO is activated.
5	The SS1 request is removed.
6	After time D has elapsed, the FSO defines the motor as stopped, the SS1 completed output indication (parameter SS1.22) goes on and the acknowledgement becomes allowed as soon as the SS1 request has been removed (step 5).
7	After the acknowledgement, the SS1, STO and SBC functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SS1 output (SS1.21) , SS1 completed output (SS1.22) , and STO output (STO.21) go off.

With ramp monitoring (SS1-r)

The operation of the SS1-r function with speed limit activated SBC, SBC before STO is described in the time diagram and table below. For configuration, see section [How to configure SS1 with speed limit activated SBC, SBC before STO](#) on page 265.



- A SBC speed (parameter [SBC.15](#)): Speed limit below which the FSO activates the SBC function (brake) while ramping. The SAR1 ramp monitoring is stopped.
 - B SBC delay (parameter [SBC.12](#)): Time from the activation of the SBC function to the moment when the FSO activates the drive STO function.
 - C SBC time to zero (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SS1 completed indication (parameter [SS1.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
 - D Response time (depends on system configuration, see page [420](#))
- Ramp monitoring limits

Step	Description
1	The SS1 request is received (for example, from the I/O).
2	<p>After time D has elapsed, the drive starts to ramp down the motor speed. SAR1 parameter 200.112 defines the deceleration ramp. The FSO starts the SAR1 ramp monitoring (parameters SARx.21 and SARx.22).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p>

Step	Description
3	<p>The motor speed goes below the SBC speed limit (A), the FSO stops the SAR1 monitoring and activates the SBC function.</p> <p>The FSO starts counters for times B and C.</p> <p>Note: You can define an extra delay (parameter SS1.15, not shown in the figure) before the FSO activates the SBC function. This affects also the STO activation (step 4).</p>
3b	<p>If the motor speed hits a ramp monitoring limit, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p>
4	<p>After time B has elapsed, the FSO activates the drive STO function. STO active indication parameter STO output (STO.21) goes on when STO is activated.</p>
5	<p>The SS1 request is removed.</p>
6	<p>After time C has elapsed, the FSO defines the motor as stopped, the SS1 completed output indication (parameter SS1.22) goes on and the acknowledgement becomes allowed as soon as the SS1 request has been removed (step 5).</p>
7	<p>After the acknowledgement, the SS1, STO and SBC functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SS1 output (SS1.21), SS1 completed output (SS1.22), and STO output (STO.21) go off.</p>


■ **SS1 ramp functions when drive modulation is lost**

The operation of SS1-r and -t functions in a situation where drive modulation is lost during the deceleration ramp is described below.

The operation of SSE function in this situation is otherwise similar, but SSE indications are shown instead of SS1 indications.

With safe speed estimation

With both SS1-r and SS1-t, STO function is activated right away when the modulation is lost but the SS1 indications are operational. STO cascading is not activated in this case. The completed indication of the STO function is not indicated ([STO.22](#)), instead the SS1 completed indication ([SS1.22](#)) is activated. Otherwise STO function (and SBC, if in use) behaves as configured.



A Zero speed (parameter [FSOGEN.51](#))

Step	Description
1	<p>The SS1 request is received (for example, from the I/O). The drive starts to ramp down the motor speed. SAR1 parameter 200.112 defines the deceleration ramp. The FSO starts the SAR1 ramp monitoring (parameters SARx.21 and SARx.22).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p>
2	<p>The drive trips on a fault or user stops the drive, modulation of the drive stops. FSO module activates the STO function and STO indication (parameter STO.21 STO output).</p> <p>SAR1 ramp monitoring goes off.</p> <p>See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p> <p>Note: If STO is used in cascaded system (see Cascade on page 63), it will not be activated in the whole system in this case.</p> <p>Note: SS1 completed indication (SS1.22) is used instead of STO completed indication (STO.22) in this case</p> <p>Note: If the SBC is configured in the STO function, also the SBC is activated according to the configuration (not shown in the figure).</p>
3	<p>The SS1 completed output indication (parameter SS1.22) goes on and the acknowledgement becomes allowed as soon as the SS1 request has been removed.</p> <p>SS1 function can be acknowledged when STO.14 delay has elapsed after the drive modulation is lost.</p>

Safe stop emergency (SSE)

The SSE function can be configured either with immediate STO or with emergency ramp.

With immediate STO

The behavior of the SSE with immediate STO is identical to the STO function (see section [Safe torque off \(STO\)](#) on page 67) except that parameter [Restart delay after STO](#) is not used.

You can configure the SBC function to be activated before, at the same time with, or after the drive STO function.

With emergency ramp

The behavior of the SSE with emergency ramp is identical to the SS1 function (see section [Safe stop 1 \(SS1\)](#) on page 72) except that different time and ramp monitoring parameters are used. The SSE function uses SAR0 parameters to monitor and/or define the emergency ramp. Drive ramp parameters cannot be used.


When you use the SBC function with the SSE function, you can configure the SBC and drive STO combination to be activated at a user-defined speed limit while ramping down to zero speed. You can also define a delay so that the SBC is activated first at the user-defined speed limit and the drive STO after the delay.

Note: Always set the parameters related to the SSE function to have the correct trip limit hit and fault reaction behavior. An internal monitoring of the FSO module can trigger the SSE function even if you have not defined an external request signal. These internal monitorings trigger SSE:

- SMS or SLS function speed limit hits
- PROFIsafe fault
- FSO module I/O fault, FSO module overtemperature, FSO module power supply fault.

■ SSE with immediate STO

The operation of the SSE with immediate STO function is described in the time diagram and table below. For configuration, see section [How to configure SSE with immediate STO](#) on page 270.




- A Time to zero speed (parameter [STO.14](#)): Time from the STO activation to the moment when the safety function is completed, the SSE completed indication (parameter [SSE.22](#)) goes on and the acknowledgement becomes allowed. You must set this to the estimated time in which the motor coasts to a stop from the maximum speed.

Step	Description
1	The SSE request is received (for example, from the I/O). The FSO activates the drive STO function and starts a counter for time A. SSE active indication SSE output (SSE.21) and STO output (STO.21) go on.
2	After time A has elapsed, the FSO module defines the motor as stopped and the SSE completed indication goes on. The acknowledgement becomes allowed as soon as the SSE request has been removed (step 3).
3	The SSE request is removed.
4	After the acknowledgement, the SSE and STO functions are deactivated, and the control is given back to the drive. The indications SSE output (SSE.21) , SSE completed output (SSE.22) , and STO output (STO.21) go off.

■ SSE with immediate STO, SBC after STO

The operation of the SSE with immediate STO, SBC after STO (positive SBC delay) is described in the time diagram and table below. For configuration, see section [How to configure SSE with immediate STO, SBC after or before STO](#) on page 270.



- A SBC delay (parameter [SBC.12](#)): Time from the activation of the drive STO function to the moment when the FSO activates the SBC function (brake). In this case, the value is positive and the FSO activates the SBC after the drive STO. If the value is zero, the FSO activates the SBC and drive STO functions at the same time. **Note:** It is possible to set the SBC delay so that the SBC is activated while the motor is still rotating.
- B SBC time to zero speed (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.


Step	Description
1	The SSE request is received (for example, from the I/O). The FSO activates the drive STO function and starts a counter for time A. SSE active indication SSE output (SSE.21) and STO output (STO.21) go on.
2	After time A has elapsed, the FSO activates the SBC and starts a counter for time B.
3	After time B has elapsed, the FSO module defines the motor as stopped and the SSE completed indication goes on. The acknowledgement becomes allowed as soon as the SSE request has been removed (step 4).
4	The SSE request is removed.

Step	Description
5	After the acknowledgement, the SSE, STO and SBC functions are deactivated and the control is given back to the drive, which controls the brake from now on. The indications SSE output (SSE.21) , SSE completed output (SSE.22) , and STO output (STO.21) go off.

■ SSE with immediate STO, SBC before STO

The operation of the SSE with immediate STO, SBC before the STO (negative SBC delay) is described in the time diagram and table below. For configuration, see section [How to configure SSE with immediate STO, SBC after or before STO](#) on page 270.

The reason to use a negative SBC delay is to have the mechanical brake closed just before the drive STO circuit is opened.




- A SBC delay (parameter [SBC.12](#)): Time from the activation of the drive STO function to the moment when the FSO activates the SBC function (brake). In this case, the value is negative and the FSO activates the SBC before the drive STO. If the value is zero, the FSO activates the SBC and drive STO functions at the same time.
- B SBC time to zero speed (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
- C Response time (depends on system configuration, see page [420](#))

Step	Description
1	The SSE request is received (for example, from the I/O). The FSO activates the SBC function (brake) and starts counters for times A and B. SSE active indication SSE output (SSE.21) and STO output (STO.21) go on.
2	After time C has elapsed, the SBC starts to brake the motor.
3	After time A has elapsed, the FSO activates the drive STO function.
4	After time B has elapsed, the FSO module defines the motor as stopped and the SSE completed indication goes on. The acknowledgement becomes allowed as soon as the SSE request has been removed (step 5).
5	The SSE request is removed.

Step	Description
6	After the acknowledgement, the SSE, STO and SBC functions are deactivated and the control is given back to the drive, which controls the brake from now on. The indications SSE output (SSE.21) , SSE completed output (SSE.22) , and STO output (STO.21) go off.

■ SSE with time monitoring

The operation of the SSE with time monitoring is described in the time diagram and table below. For configuration, see section [How to configure SSE with time monitoring](#) on page 271.




- A SSE delay for STO (parameter **SSE.15**): Time after which the FSO activates the STO function regardless of the motor speed.
- B Zero speed (parameter **FSOGEN.51**): Speed limit for activating the drive STO function. The safety function is completed and the SSE completed indication (parameter **SSE.22**) goes on. The acknowledgement becomes allowed.
- C Response time (depends on system configuration, see page 420)

Step	Description
1	The SSE request is received (for example, from the I/O). The FSO starts a counter for time A. SSE active indication SSE output (SSE.21) goes on.

Step	Description
2	After time C has elapsed, the drive starts to ramp down the motor speed. SAR0 parameter 200.102 defines the deceleration ramp.
3	<p>The motor speed reaches the zero speed limit (B), FSO activates the drive STO function and STO active indication parameter STO output (STO.21) goes on. The SSE completed indication goes on and the acknowledgement becomes allowed as soon as the SSE request has been removed (step 4).</p> <p>Note: If the SBC is configured in the STO function (see section Safe torque off (STO) on page 67), also the SBC is activated (not shown in the figure).</p> <ul style="list-style-type: none"> • If the STO SBC delay (parameter SBC.12) is negative, the SBC is activated here and the drive STO after this delay. • If the STO SBC delay is positive or zero, the SBC and drive STO functions are activated at the same time. • The SSE completed indication goes on after the delay defined with parameter SBC.13 has elapsed from the SBC activation. <p>Note: You can define an extra delay (parameter SSE.16) before the FSO activates the drive STO (not shown in the figure).</p>
3b	If the drive has not ramped down fast enough when time A has elapsed, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.
4	The SSE request is removed.
5	After the acknowledgement, the STO and SSE functions are deactivated. The indications SSE output (SSE.21) , SSE completed output (SSE.22) , and STO output (STO.21) go off.

■ SSE with ramp monitoring

The operation of the SSE with ramp monitoring is described in the time diagram and table below. For configuration, see section [How to configure SSE with ramp monitoring](#) on page 272.



- A Zero speed (parameter [FSOGEN.51](#)): Speed limit for activating the drive STO function. The safety function is completed, ramp monitoring is stopped and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed.
- B Response time (depends on system configuration, see page 420)
- Ramp monitoring limits

Step	Description
1	The SSE request is received (for example, from the I/O). SSE active indication SSE output (SSE.21) goes on.
2	After time C has elapsed, the drive starts to ramp down the motor speed. SAR0 parameter 200.102 defines the deceleration ramp. The FSO starts the SAR0 ramp monitoring (parameters SARx.11 and SARx.12).
2b	If the motor speed hits a ramp monitoring limit, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.


Step	Description
3	<p>The motor speed reaches the zero speed limit (B), the FSO stops the SAR0 monitoring and activates the drive STO function, and STO active indication parameter STO output (STO.21) goes on. The SSE completed indication goes on the acknowledgement becomes allowed as soon as the SSE request has been removed (step 4).</p> <p>Note: If the SBC is configured in the STO function (see section Safe torque off (STO) on page 67), also the SBC is activated (not shown in the figure).</p> <ul style="list-style-type: none">• If the STO SBC delay (parameter SBC.12) is negative, the SBC is activated here and the drive STO after this delay.• If the STO SBC delay is positive or zero, the SBC and drive STO functions are activated at the same time. <p>The SSE completed indication goes on after the delay defined with parameter SBC.13 has elapsed from the SBC activation.</p> <p>Note: You can define an extra delay (parameter SSE.16) before the FSO activates the drive STO (not shown in the figure).</p>
4	<p>The SSE request is removed.</p>
5	<p>After the acknowledgement, the STO and SSE functions are deactivated and the control is given back to the drive, which can modulate again. The indications SSE output (SSE.21), SSE completed output (SSE.22), and STO output (STO.21) go off.</p>

■ **SSE with speed limit activated SBC**

In these examples, the SBC and drive STO functions are activated at a user-defined speed limit.

With time monitoring

The operation of the SSE with speed limit activated SBC and time monitoring is described in the time diagram and table below. For configuration, see section [How to configure SSE with speed limit activated SBC](#) on page 273.




- A SBC speed (parameter [SBC.15](#)): Speed limit below which the FSO activates SBC (brake) and drive STO functions while ramping.
- B SSE delay for STO (parameter [SSE.15](#)): Time after which the FSO activates the drive STO function regardless of the motor speed.
- C SBC time to zero (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
- D Response time (depends on system configuration, see page [420](#))

Step	Description
1	The SSE request is received (for example, from the I/O). The FSO starts a counter for time B. SSE active indication SSE output (SSE.21) goes on.
2	After time D has elapsed, the drive starts to ramp down the motor speed. SARO parameter 200.102 defines the deceleration ramp.

Step	Description
3	<p>The motor speed goes below the SBC speed limit (A), the FSO checks the value of STO SBC delay (parameter SBC.12) and activates the SBC and drive STO functions:</p> <ul style="list-style-type: none">• If the STO SBC delay is positive or zero, the SBC and drive STO functions are activated at the same time (this case is shown in the figure).• If the STO SBC delay is negative, the SBC is activated here and the drive STO after this delay (see section SSE with speed limit activated SBC, SBC before STO on page 98).• STO active indication parameter STO output (STO.21) goes on when STO is activated. <p>The FSO starts a counter for time C.</p> <p>Note: You can define an extra delay (parameter SSE.16) before the FSO activates the SBC and drive STO functions (not shown in the figure).</p>
3b	<p>If the drive has not ramped down fast enough when time B has elapsed, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p>
4	<p>After time C has elapsed, the FSO defines the motor as stopped, the SSE completed indication goes on and the acknowledgement becomes allowed as soon as the SSE request has been removed (step 5).</p>
5	<p>The SSE request is removed.</p>
6	<p>After the acknowledgement, the SSE, STO and SBC functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SSE output (SSE.21), SSE completed output (SSE.22), and STO output (STO.21) go off.</p>

With ramp monitoring

The operation of the SSE with speed limit activated SBC and ramp monitoring is described in the time diagram and table below. For configuration, see section [How to configure SSE with speed limit activated SBC](#) on page 273.



- A SBC speed (parameter [SBC.15](#)): Speed limit below which the FSO activates the SBC (brake) and drive STO functions while ramping. The safety function is completed, the ramp monitoring is stopped and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed.
 - B SBC time to zero (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
 - C Response time (depends on system configuration, see page [420](#))
- Ramp monitoring limits

Step	Description
1	The SSE request is received (for example, from the I/O). SSE active indication SSE output (SSE.21) goes on.
2	After time C has elapsed, the drive starts to ramp down the motor speed. SAR0 parameter 200.102 defines the deceleration ramp. The FSO starts the SAR0 ramp monitoring (parameters SARx.11 and SARx.12).


Step	Description
3	<p>The motor speed goes below the SBC speed limit (A), the FSO stops the SAR1 monitoring. The FSO checks the value of STO SBC delay (parameter SBC.12) and activates the SBC and drive STO functions:</p> <ul style="list-style-type: none">• If the STO SBC delay is positive or zero, the SBC and drive STO functions are activated at the same time (this case is shown in the figure).• If the STO SBC delay is negative, the SBC is activated here and the drive STO after this delay (see section SSE with speed limit activated SBC, SBC before STO on page 98.)• STO active indication parameter STO output (STO.21) goes on when STO is activated. <p>The FSO starts a counter for time B.</p> <p>Note: You can define an extra delay (parameter SSE.16) before the FSO activates the SBC and drive STO functions (not shown in the figure).</p>
3b	<p>If the motor speed hits a ramp monitoring limit, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p>
4	<p>After time B has elapsed, the FSO defines the motor as stopped, the SSE completed indication goes on and the acknowledgement becomes allowed as soon as the SSE request has been removed (step 5).</p>
5	<p>The SSE request is removed.</p>
6	<p>After the acknowledgement, the SSE, STO and SBC functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SSE output (SSE.21), SSE completed output (SSE.22), and STO output (STO.21) go off.</p>

■ **SSE with speed limit activated SBC, SBC before STO**

In these examples, the SBC function is activated at a user-defined speed limit and drive STO function after a user-defined delay (negative SBC delay). The reason to use a negative SBC delay (parameter [SBC.12](#)) is to have the mechanical brake closed just before the drive STO circuit is opened.

With time monitoring

The operation of the SSE with speed limit activated SBC, SBC before STO and time monitoring is described in the time diagram and table below. For configuration, see section [How to configure SSE with speed limit activated SBC, SBC before STO](#) on page 277.




- A SBC speed (parameter [SBC.15](#)): Speed limit below which the FSO activates the SBC function (brake).
- B SSE delay for STO (parameter [SSE.15](#)): Time after which the FSO activates the STO function regardless of the motor speed.
- C SBC delay (parameter [SBC.12](#)): Time from the activation of the SBC function to the moment when the FSO activates the drive STO function.
- D SBC time to zero (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
- E Response time (depends on system configuration, see page [420](#))

Step	Description
1	The SSE request is received (for example, from the I/O). The FSO starts a counter for time B. SSE active indication SSE output (SSE.21) goes on.
2	After time E has elapsed, the drive starts to ramp down the motor speed. SARO parameter 200.102 defines the deceleration ramp.

Step	Description
3	The motor speed goes below the SBC speed limit (A), the FSO activates SBC function. The FSO starts counters for times C and D. Note: You can define an extra delay (parameter SSE.16 , not shown in the figure) before the FSO activates the SBC function. This affects also the STO activation (step 4).
3b	If the drive has not ramped down fast enough when time B has elapsed, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.
4	After time C has elapsed, the FSO activates the drive STO function. STO active indication parameter STO output (STO.21) goes on when STO is activated.
5	The SSE request is removed.
6	After time D has elapsed, the safety function is completed, the SSE completed indication goes on and the acknowledgement becomes allowed as soon as the SSE request has been removed (step 5).
7	After the acknowledgement, the SSE, STO and SBC functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SSE output (SSE.21) , SSE completed output (SSE.22) , and STO output (STO.21) go off.

With ramp monitoring

The operation of the SSE with speed limit activated SBC, SBC before STO and ramp monitoring is described in the time diagram and table below. For configuration, see section [How to configure SSE with speed limit activated SBC, SBC before STO](#) on page 277.



- A SBC speed (parameter [SBC.15](#)): Speed limit below which the FSO activates the SBC (brake) while ramping. The SAR0 ramp monitoring is stopped.
 - B SBC delay (parameter [SBC.12](#)): Time from the activation of the SBC function to the moment when the FSO activates the drive STO function.
 - C SBC time to zero (parameter [SBC.13](#)): Time from the SBC activation to the moment when the safety function is completed and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed. You must set this to the estimated time in which the motor brakes to a stop from the maximum speed.
 - D Response time (depends on system configuration, see page [420](#))
- Ramp monitoring limits

Step	Description
1	The SSE request is received (for example, from the I/O). SSE active indication SSE output (SSE.21) goes on.
2	After time D has elapsed, the drive starts to ramp down the motor speed. SAR0 parameter 200.102 defines the deceleration ramp. The FSO starts the SAR0 ramp monitoring (parameters SARx.11 and SARx.12).

Step	Description
3	The motor speed goes below the SBC speed limit (A), the FSO stops the SAR0 monitoring and activates the SBC function. The FSO starts counters for times B and C. Note: You can define an extra delay (parameter SSE.16 , not shown in the figure) before the FSO activates the SBC function. This affects also the STO activation (step 4).
3b	If the motor speed hits a ramp monitoring limit, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.
4	After time B has elapsed, the FSO activates the drive STO function. STO active indication parameter STO output (STO.21) goes on when STO is activated.
5	The SSE request is removed.
6	After time C has elapsed, the FSO defines the motor as stopped, the SSE completed indication goes on and the acknowledgement becomes allowed as soon as the SSE request has been removed (step 5).
7	After the acknowledgement, the SSE, STO and SBC functions are deactivated and the control is given back to the drive, which is allowed to modulate again. The indications SSE output (SSE.21) , SSE completed output (SSE.22) , and STO output (STO.21) go off.

■ SSE when drive modulation is lost during deceleration ramp

The behavior of SSE function in a situation where modulation is lost during deceleration ramp is similar to SS1 function with ramp monitoring, see section [SS1 ramp functions when drive modulation is lost](#) on page 84.

Safely-limited speed (SLS)

The SLS prevents the motor from exceeding user-defined speed limits. The drive limits the motor speed so that it stays between the SLS speed limits.

If the motor speed is above the user-defined SLS limit when SLS function is activated, the motor speed is first decelerated to the required speed. You can configure the SLS function to use either the time monitoring or ramp monitoring method when the motor speed is decelerated. You can also configure the reaction of the SLS function in case that the drive modulation is lost during the deceleration ramp.

Note: All SLS functions can be active at the same time. Motor speed is limited to the lowest SLS limit. The lowest trip limit will trip the drive.

Time monitoring

When SLS function is activated at a speed higher than SLS limit, motor starts to decelerate according to deceleration ramp time defined by drive parameters. The motor speed must reach SLS monitoring limit within monitoring time limit,

otherwise SSE function is activated (see section [SLS with time monitoring and speed above monitored speed](#) on page 105).

Ramp monitoring

When SLS function is activated at a speed higher than SLS limit, motor starts to decelerate according to deceleration ramp slope defined by SLS SAR1 function. The motor speed must decelerate within SAR1 minimum and maximum limits, otherwise STO function is activated (see section [SLS with ramp monitoring and speed above monitored speed](#) on page 106).

If the SLS monitoring must be activated immediately after the SLS request, regardless of the current speed, time monitoring with a zero time delay (parameter [SLSx.04](#)) must be used instead of ramp monitoring.

When the SLS monitoring is active, the FSO monitors and limits the motor speed, but if the motor speed still reaches the SLS trip limit, the FSO module activates the SSE function (see section [SLS trip limit hits](#) on page 121).


SLS reaction when modulation is lost during deceleration ramp

If the user requests the SLS function while the motor speed is above SLS limit, SLS function will trigger a deceleration ramp to bring motor to SLS speed. If the drive modulation is lost during deceleration due to drive error or power failure and FSO is using safe speed estimate for safety function purposes, then FSO does not have the motor speed information anymore and the motor coasts to a stop. When it is critical to receive a safe indication of this situation, FSO parameters can be set accordingly (starting from FSO rev. H). User can select, whether, in the case of modulation loss, STO indication is activated. This lets the user activate, for example, a safe break. The user can also set the reaction type and the delay for activating the STO indication after the modulation loss.

For this procedure to work, at least the auxiliary power (24 V DC) to the control unit and the FSO module must be on. For more information, see section [SLS reaction when modulation is lost during deceleration ramp, with ramp monitoring](#) on page 107.

■ SLS with speed below monitored speed

This applies to both time and ramp monitoring.



A SLS trip limit positive (parameter [SLSx.14](#), [SLSx.23](#), [SLSx.33](#) or [SLSx.43](#))

B SLS limit positive (parameter [200.23](#), [200.33](#), [200.43](#) or [200.53](#))


--- SSE coast stop due to SLS trip limit hit

Step	Description
1	The SLS request is received. The motor speed is below the SLS limit positive (B) and the FSO starts the SLS monitoring. The SLS active indication (parameter SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes on. The drive limits the motor speed so that it does not go above the SLS limit positive.
2	If the motor speed reaches the SLS trip limit positive (A), the FSO activates the SSE function and the motor coasts to a stop (in this case, the SSE function has been configured as “Immediate STO” (parameter SSE.13), see section SLS trip limit hits on page 121).
3	The SLS request is removed. The SLS monitoring is still on (acknowledgement method is manual or from a safety PLC) (parameter SLSx.02 , configured as Manual_Safebus). Note: If automatic acknowledgement is used, the SLS monitoring is also ended.
4	The SLS function is acknowledged and the FSO stops the SLS monitoring. The SLS active indication (parameter SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes off.

Note: If drive modulation is lost when SLS function is activated and the motor speed is below SLS limit, SLS indication is on and STO is not activated due to loss of drive modulation.

■ **SLS with time monitoring and speed above monitored speed**

The operation of the SLS function with time monitoring is described in the time diagram and table below. For configuration, see section [How to configure SLSn with time monitoring](#) on page 280.




- A SLS trip limit positive (parameter [SLSx.14](#), [SLSx.23](#), [SLSx.33](#) or [SLSx.43](#))
- B SLS limit positive (parameter [200.23](#), [200.33](#), [200.43](#) or [200.53](#))
- C SLS time delay (parameter [SLSx.04](#)): Delay for forcing to start SLS monitoring.

Step	Description
1	The SLS request is received. The motor speed is above the SLS trip limit positive (A). The FSO starts the counter for the SLS time delay (C) (parameter SLSx.04).
2	The drive starts to ramp down the motor speed. The drive (parameter 23.13 or 23.15) defines the deceleration ramp until the speed reaches the SLS limit positive (B). The FSO starts the SLS monitoring when the motor speed is in the middle of the SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306). The SLS active indication (parameter SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes on.
3	The motor speed reaches the SLS limit positive (B).
3-6	The drive limits the motor speed, but if the motor speed still reaches the SLS trip limit positive, the FSO activates the SSE function. See section SLS trip limit hits on page 121.

Step	Description
4	The FSO starts the SLS monitoring at the latest here, that is, after the SLS time delay (C) has elapsed. Note: If the motor speed is above the SLS trip limit after the SLS time delay (C) has elapsed, the FSO module activates the SSE function. For more information, see section SLS trip limit hits on page 121.
5	The SLS request is removed, but the SLS monitoring is still on (acknowledgement method is manual or from a safety PLC). Note: If automatic acknowledgement is used, the SLS monitoring is also ended.
6	The SLS function is acknowledged and FSO stops the SLS monitoring. The SLS active indication (parameter SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes off.

■ **SLS with ramp monitoring and speed above monitored speed**

The operation of the SLS function with ramp monitoring is described in the time diagram and table below. For configuration, see section [How to configure SLSn with ramp monitoring](#) on page 282.



- A SLS trip limit positive (parameter [SLSx.14](#), [SLSx.23](#), [SLSx.33](#) or [SLSx.43](#))
- B SLS limit positive (parameter [200.23](#), [200.33](#), [200.43](#) or [200.53](#))
- C Response time (depends on system configuration, see page 420)
- Ramp monitoring limits (SAR1) or SLS trip limit (A)

Step	Description
1	The SLS request is received. The motor speed is above the SLS trip limit positive (A).

Step	Description
2	<p>After time C has elapsed, the drive starts to ramp down the motor speed. The SAR1 parameter 200.112 defines the deceleration ramp until the speed reaches the SLS limit positive (B). The FSO starts the SAR1 ramp monitoring (parameters SARx.21, SARx.22).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p> <p>The FSO starts the SLS monitoring when the motor speed is in the middle of the SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306), and stops the SAR1 monitoring. The SLS active indication (parameter SLSx.15, SLSx.24, SLSx.34 or SLSx.44) goes on.</p>
2b	If the motor speed does not follow the ramp monitoring limits, the FSO activates the STO function. See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.
3	The motor speed reaches the SLS limit positive (B).
3-5	The drive limits the motor speed, but if the motor speed still reaches the SLS trip limit positive, the FSO activates the SSE function. For more information, see section SLS trip limit hits on page 121 .
4	<p>The SLS request is removed, but the SLS monitoring is still on (acknowledgement method is manual or from a safety PLC).</p> <p>Note: If automatic acknowledgement is used, the SLS monitoring is also ended.</p>
5	The SLS function is acknowledged and the FSO stops the SLS monitoring. The SLS active indication (parameter SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes off.


■ SLS reaction when modulation is lost during deceleration ramp, with ramp monitoring

If SLS function is activated when motor speed is above the SLS trip limit, FSO will force the drive to decelerate to SLS limit. If the drive stops modulation during this deceleration ramp, user can pre-select the reaction of the SLS function (parameter [SLSx.05](#)) from the following:

- Modoff delay time
- Monitoring active
- Monitoring active and modoff delay time
- Monitoring and modoff delay time disabled.

SLS reaction if modulation is lost with Modoff delay time

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp with Modoff delay time selected (parameter [SLSx.05](#) is set to Modoff delay time) is described in the time diagram and table below. For configuration, see section [How to configure SLS function behavior when drive modulation is lost](#) on page [291](#).




- A SAR1 ramp monitoring
- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A). The drive starts to ramp down the motor speed. The SAR1 parameter 200.112 defines the deceleration ramp slope until the speed reaches the SLS limit. The FSO starts the SAR1 ramp monitoring (parameters SARx.21, SARx.22). SAR1 configuration defines the target and monitoring limits for the deceleration ramp (SARx.22, 200.112, SARx.02).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop. SAR1 monitoring of the FSO is switched off. SLS Modoff delay time starts (parameters SLSx.05 & SLSx.06). STO.14 delay starts.</p> <p>Note: This reaction is the default for FSO and the delay time is set to 0 ms.</p>
3	<p>Modulation of the drive has not returned and the SLSx.06 Modoff delay time has run out, and FSO activates STO function and STO indication (parameter STO.21 STO output). See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p>
4	<p>If modulation does not return, and STO.14 delay has elapsed, SLS indication goes on.</p>

SLS reaction if modulation is lost with Modoff delay time - modulation returns before modoff delay

The operation of the SLS function in case of the modulation of the drive is lost during the deceleration ramp and the modulation returns before the Modoff delay time has run out with Modoff delay time selected (parameter [SLSx.05](#) is set to Modoff delay time) is described in the time diagram and table below.




- A SAR1 ramp monitoring
- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A). The drive starts to ramp down the motor speed. The SAR1 parameter 200.112 defines the deceleration ramp slope until the speed reaches the SLS limit. The FSO starts the SAR1 ramp monitoring (parameters SARx.21, SARx.22). SAR1 configuration defines the target and monitoring limits for the deceleration ramp (SARx.22, 200.112, SARx.02).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop. SAR1 monitoring of the FSO is switched off. SLS Modoff delay time starts (parameters SLSx.05 & SLSx.06). STO.14 delay starts.</p>

Step	Description
3	Modulation of the drive returns. FSO activates SAR1 monitoring again with same ramps as when the SLS request was set.
4	The Modoff delay time limit. If the modulation would not return before this time, see previous case.
5	The FSO starts the SLS monitoring when the motor speed is in the middle of the SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306), and stops the SAR1 monitoring. The SLS indication (parameter SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes on.

SLS reaction if modulation is lost with Monitoring active

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp with Monitoring active selected (parameter [SLSx.05](#) is set to Monitoring active) is described in the time diagram and table below. For configuration, see section [How to configure SLS function behavior when drive modulation is lost](#) on page 291.




- A SAR1 ramp monitoring
- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit
- E Last valid speed estimate of FSO

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A). The drive starts to ramp down the motor speed. The SAR1 parameter 200.112 defines the deceleration ramp slope until the speed reaches the SLS limit. The FSO starts the SAR1 ramp monitoring (parameters SARx.21, SARx.22). SAR1 configuration defines the target and monitoring limits for the deceleration ramp (SARx.22, 200.112, SARx.02).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop. SAR1 monitoring of the FSO is on (parameter SLSx.05 configured as Monitoring active). As the modulation is lost, FSO's safe speed estimation is stopped and it starts to use the last speed information that it had before the modulation was lost. With SLSx.06 Monitor active, SAR1 monitoring stays active also when the modulation is lost from the drive.</p> <p>STO.14 delay starts.</p>
3	<p>Modulation of the drive has not returned and the safe speed estimation with the last valid speed information hits the SAR1 monitoring and FSO activates STO function and STO indication (parameter STO.21 STO output). See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p> <p>If the modulation returns before the last valid speed estimation of FSO hits the SAR1 monitoring limit, the drive will continue the deceleration for as long as the speed stays within the SAR1 ramp monitoring limits.</p>
4	<p>SLS indication goes on after STO.14 delay has elapsed.</p>

SLS reaction if modulation is lost with Monitoring active and modoff delay time - modulation returns

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp with Monitoring active and modoff delay time selected (parameter [SLSx.05](#) is set to Monitoring active and modoff delay time) is described in the time diagram and table below. For configuration, see section

How to configure SLS function behavior when drive modulation is lost on page 291.




- A SAR1 ramp monitoring
- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit
- E Last valid speed estimate of FSO

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A). The drive starts to ramp down the motor speed. The SAR1 parameter 200.112 defines the deceleration ramp slope until the speed reaches the SLS limit. The FSO starts the SAR1 ramp monitoring (parameters SARx.21, SARx.22). SAR1 configuration defines the target and monitoring limits for the deceleration ramp (SARx.22, 200.112, SARx.02).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the deceleration time.</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop.</p> <p>SAR1 monitoring of the FSO is on (parameter SLSx.05 configured as Monitoring active and modoff delay time).</p> <p>SLS Modoff delay time starts (parameters SLSx.05 & SLSx.06).</p> <p>As the modulation is lost, FSO's safe speed estimation is stopped and it starts to use the last speed information that it had before the modulation was lost.</p>

Step	Description
3	Modulation of the drive returns before the last valid speed information hits the SAR1 limit and before the modoff delay time has run out. Deceleration continues as parametrized as long as the speed does not hit the SAR1 limits.
4	If modulation of the drive has not returned and the SLSx.06 Modoff delay time has run out or the last valid speed reaches the SAR limit, FSO activates STO function and STO indication (parameter STO.21 STO output). See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.
5	The FSO starts the SLS monitoring when the motor speed is in the middle of the SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306), and stops the SAR1 monitoring. The SLS indication (parameters SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes on.

SLS reaction if modulation is lost with Monitoring and modoff delay time disabled

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp with Monitoring and modoff delay time disabled selected (parameter [SLSx.05](#) is set to Monitoring and modoff delay time disabled) is described in the time diagram and table below. For configuration, see section [How to configure SLS function behavior when drive modulation is lost](#) on page 291.



- A SAR1 ramp monitoring
- B Actual motor speed (coasting after modoff)
- C SLS trip limit

D SLS limit

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A). The drive starts to ramp down the motor speed. The SAR1 parameter 200.112 defines the deceleration ramp slope until the speed reaches the SLS limit. The FSO starts the SAR1 ramp monitoring (parameters SARx.21, SARx.22). SAR1 configuration defines the target and monitoring limits for the deceleration ramp (SARx.22, 200.112, SARx.02).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop.</p> <p>SAR1 monitoring of the FSO is switched off (parameter SLSx.05 configured as Monitoring and modoff delay time are disabled).</p> <p>SLS Modoff delay time monitoring is not in use.</p> <p>STO.14 delay starts.</p>
3	<p>The SLS indication (parameter SLSx.15, SLSx.24, SLSx.34 or SLSx.44) goes on after STO.14 has elapsed.</p>


If the drive modulation returns before the [STO.14](#) delay has run out, the deceleration continues as parametrized and the SAR1 monitoring is set on again.

■ **SLS reaction when modulation is lost during deceleration ramp, with time monitoring**

SLS reaction if modulation is lost with Modoff delay time

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp with Modoff delay time selected (parameter [SLSx.05](#) is set to Modoff delay time) is described in the time diagram and table

below. For configuration, see section [How to configure SLS function behavior when drive modulation is lost](#) on page 291.




- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A).</p> <p>The drive starts to ramp down the motor speed.</p> <p>The FSO starts the SLS time delay (parameter SLSx.04).</p> <p>The drive (parameter 23.13 or 23.15) defines the deceleration ramp until the speed reaches the SLS limit.</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop.</p> <p>SLS Modoff delay time starts (parameters SLSx.05 & SLSx.06).</p> <p>STO.14 delay starts.</p>
3	<p>Modulation of the drive has not returned, the SLSx.06 Modoff delay time has run out, and FSO activates STO function and STO indication (parameter STO.21 STO output). See section Safe torque off (STO) on page 67 for more information on how to configure the STO function.</p>
4	<p>SLSx.04 time delay for SLS time monitoring</p>
5	<p>SLS indication goes on after STO.14 delay has elapsed.</p>

SLS reaction if modulation is lost with Modoff delay time - modulation returns before modoff delay

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp and the modulation returns before the Modoff delay time has run out with Modoff delay time selected (parameter [SLSx.05](#) is set to Modoff delay time) is described in the time diagram and table below.




- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit

Step	Description
1	The SLS request is received. The motor speed is above the SLS trip limit positive (A). The drive starts to ramp down the motor speed. The FSO starts the counter for the SLS time delay (C) (parameter SLSx.04) The drive (parameter 23.13 or 23.15) defines the deceleration ramp until the speed reaches the SLS limit.
2	The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop. SLS Modoff delay time starts (parameters SLSx.05 & SLSx.06).
3	Modulation of the drive returns before the SLSx.06 Modoff delay time has run out.
4	Modoff delay time limit. If the modulation would not return before this time, see previous case.
5	Speed is below the monitoring limit and SLS monitoring is started.

Step	Description
6	The FSO starts the SLS monitoring at the latest here, that is, after the SLS time delay has elapsed. The FSO starts the SLS monitoring when the motor speed is in the middle of the SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306). The SLS indication (parameters SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes on.

SLS reaction if modulation is lost with Monitoring active

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp with Monitoring active selected (parameter [SLSx.05](#) is set to Monitoring active) is described in the time diagram and table below. For configuration, see section [How to configure SLS function behavior when drive modulation is lost](#) on page 291.




- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit
- E Last valid speed estimate of FSO

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A).</p> <p>The drive starts to ramp down the motor speed.</p> <p>The FSO starts the counter for the SLS time delay (C) (parameter SLSx.04).</p> <p>The drive (parameter 23.13 or 23.15) defines the deceleration ramp until the speed reaches the SLS limit.</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop.</p> <p>STO.14 delay starts.</p> <p>As the modulation is lost, FSO's safe speed estimation is stopped and it starts to use the last speed information that it had before the modulation was lost.</p>
3	<p>Modulation of the drive has not returned and the safe speed estimation with the last valid speed information of the motor speed is above the SLS trip limit after the SLS time delay has elapsed. FSO module activates the SSE function. SSE function triggers STO function because the modulation is lost and it cannot activate any deceleration ramp in this case. For more information, see section SLS trip limit hits on page 121.</p> <p>If the modulation returns before the last valid speed estimation of FSO has hit the SLS time delay limit, the drive will continue the deceleration until SLS monitoring or time monitoring limit is reached. If the motor speed is above the SLS trip limit after the SLS time delay has elapsed, the FSO module activates the SSE function.</p>
4	<p>If modulation does not return, SLS indication goes on after STO.14 delay has elapsed.</p>

SLS reaction if modulation is lost with Monitoring and modoff delay time disabled

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp with Monitoring and modoff delay time disabled selected (parameter [SLSx.05](#) is set to Monitoring and modoff delay time disabled) is described in the time diagram and table below. For configuration, see section [How to configure SLS function behavior when drive modulation is lost](#) on page 291.




- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A).</p> <p>The drive starts to ramp down the motor speed.</p> <p>The drive (parameter 23.13 or 23.15) defines the deceleration ramp until the speed reaches the SLS limit.</p> <p>The FSO starts the counter for the SLS time delay (C) (parameter SLSx.04)</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop. Here, STO is not activated due to loss of modulation.</p> <p>STO.14 delay starts.</p>
3	<p>If modulation does not return, SLS indication goes on after STO.14 delay has elapsed.</p>

SLS reaction if modulation is lost with Monitoring and modoff delay time disabled - modulation returns

The operation of the SLS function in case the modulation of the drive is lost during the deceleration ramp with Monitoring and modoff delay time disabled selected (parameter [SLSx.05](#) is set to Monitoring and modoff delay time disabled) is described in the time diagram and table below. For configuration,

see section [How to configure SLS function behavior when drive modulation is lost](#) on page 291.



- B Actual motor speed (coasting after modoff)
- C SLS trip limit
- D SLS limit

Step	Description
1	<p>The SLS request is received. The motor speed is above the SLS trip limit positive (A).</p> <p>The drive starts to ramp down the motor speed.</p> <p>The drive (parameter 23.13 or 23.15) defines the deceleration ramp until the speed reaches the SLS limit.</p> <p>The FSO starts the counter for the SLS time delay (C) (parameter SLSx.04).</p>
2	<p>The drive trips on a fault, there is a drive power loss, or user stops the drive by coast stop.</p> <p>SLS delay time monitoring is switched off (parameter SLSx.04) as Monitoring and modoff delay time are disabled.</p> <p>FSO starts to wait until the STO.14 delay has run out or modulation returns.</p>
3	<p>The drive modulation returns.</p> <p>Deceleration continues toward SLS limit speed.</p>
4	<p>FSO starts the SLS monitoring when the motor speed is in the middle of the SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306).</p> <p>The SLS indication goes on.</p>


Step	Description
5	FSO starts the SLS monitoring at the latest here, that is, after the SLS time delay has elapsed.

Note: With time-monitored SLS: If modulation is lost during deceleration ramp but it returns after [SLSx.04](#) delay time has elapsed, with motor speed higher than SLS trip limit, then SLS limit hit is generated.

■ **FSO boot behavior with SLS active**

When the safe speed estimate is in use, the following boot behavior exists.

During FSO module boot, the FSO module has no valid speed data and thus a very high initialization value for motor speed is assumed for internal FSO usage. If an SLS function or variable SLS function is active during FSO reboot and parameter [SLSx.05](#) is configured so that Modoff delay time or Monitoring active is selected, the FSO will prevent the drive from restarting until the [STO.14](#) delay time has elapsed.




Step	Description
1	SLS request is active during FSO boot.
2	FSO module is rebooted. STO.14 delay time counter is started.
3	STO.14 has elapsed, STO acknowledgement is possible, and SLS indication is activated. Note: STO acknowledgement is not possible until STO.14 delay has elapsed. If you try to acknowledge STO before STO.14 delay has elapsed, STO.14 delay time counter will be restarted.

■ **SLS trip limit hits**

If the motor speed exceeds an SLS trip limit, the FSO activates the SSE function. The operation of SLS and SSE indications in SLS trip limit hit situations are described in the diagrams and tables below. For more information on the SSE function, see section [Safe stop emergency \(SSE\)](#) on page 86.

SSE with immediate STO

This applies when the SSE function has been configured as “Immediate STO”.




- A SLS trip limit positive (parameter [SLSx.14](#), [SLSx.23](#), [SLSx.33](#) or [SLSx.43](#))
- B SLS limit positive (parameter [200.23](#), [200.33](#), [200.43](#) or [200.53](#))
- C Response time (depends on system configuration, see page [420](#))
- D Time to zero speed (parameter [STO.14](#))
- SLS trip limit (A)

Step	Description
1	The SLS request is received, the motor speed is below the SLS limit positive (B) and the FSO starts the SLS monitoring. The SLS indication (parameter SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes on.
2	The motor speed goes above the SLS limit positive (B).
3	The motor speed reaches the SLS trip limit positive (A). The SLS indication goes off.
4	After time C has elapsed, the FSO activates the SSE function, opens the drive STO circuit and the motor coasts to a stop.
5	After time D has elapsed, the motor has stopped and the SLS active indication goes on (speed is below the SLS limit positive). The SSE completed indication goes on. Note: If the SBC is configured in the SSE function, parameter SBC.13 is used here instead of STO.14 .
6	The SLS request is removed. The SLS monitoring is still on (acknowledgement method is manual or from a safety PLC).

Step	Description
7	The SLS function is acknowledged and the FSO stops the SLS monitoring. The SSE function is acknowledged with the same acknowledgement. The indications go off.

SSE with emergency ramp

This applies when the SSE function has been configured as “Emergency ramp” (with ramp monitoring or time monitoring).



- A SLS trip limit positive (parameter [SLSx.14](#), [SLSx.23](#), [SLSx.33](#) or [SLSx.43](#))
 - B SLS limit positive (parameter [200.23](#), [200.33](#), [200.43](#) or [200.53](#))
 - C Response time (depends on system configuration, see page [420](#))
 - D Zero speed limit (parameter [FSOGEN.51](#)): Speed limit to define the motor as stopped. The safety function is completed and the SSE completed indication (parameter [SSE.22](#)) goes on. The acknowledgement becomes allowed.
- SLS trip limit (A)

Step	Description
1	The SLS request is received, the motor speed is below the SLS limit positive (B) and the FSO starts the SLS monitoring. The SLS indication (parameter SLSx.15 , SLSx.24 , SLSx.34 or SLSx.44) goes on.
2	The motor speed goes above the SLS limit positive (B).
3	The motor speed reaches the SLS trip limit positive (A). The SLS active indication goes off.

Step	Description
4	After time C has elapsed, the FSO activates the SSE function and the drive starts the ramp down the motor speed. SAR0 parameter 200.102 defines the ramp.
5	The motor speed goes below the SLS limit positive (B) and the SLS active indication goes on.
6	The motor speed reaches the zero speed limit (D). The motor has stopped and the FSO opens the drive STO circuit. The SSE completed indication goes on.
7	The SLS request is removed. The SLS monitoring is still on (acknowledgement method is manual or from a safety PLC).
8	The SLS function is acknowledged and the FSO stops the SLS monitoring. The SSE function is acknowledged with the same acknowledgement. The indications go off.

Variable Safely-limited speed (SLS)

This safety function requires that FSO communicates with a safety-capable PLC via PROFIsafe over PROFINET. For more information, see chapter [PROFIsafe](#).

The SLS function prevents the motor from exceeding user-defined speed limits. With the Variable SLS function, the speed limits are scaled with a safety PLC via PROFIsafe bus and can be changed on the fly.

If the motor speed reaches the SLS trip limit, the FSO module activates the SSE function (see section [SLS trip limit hits](#) on page 121). If the motor speed reaches a ramp monitoring limit during deceleration, the FSO module activates the STO function. With time monitoring, the FSO module starts to monitor motor speed after SLS time delay has elapsed, and if the speed is above the SLS trip limit, the FSO activates the SSE function.

The SLS function with fixed limits and the SMS function can be active at the same time with the Variable SLS function. In this case, the FSO module limits the motor speed according to the lowest speed limit.

The safety PLC sends the Variable SLS request to the FSO module in a PROFIsafe message. The message includes a scaling value as a percentage (%). The scaling value is used to scale the original SLS and trip limits (SLS4 parameters) to new, scaled values. The FSO module uses these scaled values until a new scaling value is received from the safety PLC.

The Variable SLS limits cannot be scaled above the SLS4 limits.

In the PROFIsafe message, the bits that are used to configure the Variable SLS function are:

- **Positive_Scaling**: defines whether the positive SLS limits are scaled or not.
- **Negative_Scaling**: defines whether the negative SLS limits are scaled or not.
- **Variable_SLS_limit (MSB and LSB)**: defines the scaling value. For example, if the value set in Variable_SLS_limit = 5000, the scaling value is 50%.

Note: Do not add a plus or a minus sign (+ / -) in front of the scaling value for the Variable_SLS_limit. Use a scaling value smaller than 100.

The same scaling value is applied to both the positive and the negative limits. For more information, see section [ABB_PS1 profile F-Output user data](#) on page 141.


For more information on how the FSO module defines the scaled limits, see section [Defining the scaled SLS4 limit and SLS4 trip limits](#) on page 286.

For more information on drive modulation loss during SLS deceleration ramp, see [SLS reaction when modulation is lost during deceleration ramp, with ramp monitoring](#) on page 107 and [SLS reaction when modulation is lost during deceleration ramp, with time monitoring](#) on page 114.

■ Variable SLS with time monitoring

In Variable SLS with time monitoring, the ramp according to which the drive decelerates the motor to different speeds is monitored using the time monitoring method. Drive parameters define the deceleration ramp. If the motor speed is accelerated, drive parameters define the acceleration ramp and it is not monitored.

For configuration, see section [How to configure Variable SLS with time monitoring](#) on page 284.



- A Variable SLS trip limits (parameter [SLSx.43](#) and the scaling values set in the safety PLC)
- B SLS time delay (parameter [SLSx.04](#)): Delay for forcing to start SLS monitoring.
- C Response time (depends on system configuration, see page 420)
- Variable SLS trip limit (A)


Step	Description
1	The Variable SLS request is received from the safety PLC (for example, 70%). The FSO sends a request to the drive to ramp down the motor speed to the new SLS speed limit. The FSO start a counter for the SLS time delay (B).
2	After time C has elapsed, the drive starts to ramp down the motor speed. The drive (parameter 23.13 or 23.15) defines the deceleration ramp. The FSO starts the SLS monitoring when the motor speed is in the middle of the new SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306).
3	The new motor speed has been reached. The Variable SLS active indication (parameter SLSx.51) goes on.
4	The FSO starts the SLS monitoring at the latest here, that is, after the SLS time delay (B) has elapsed. Note: If the motor speed is above the SLS trip limit after the SLS time delay (B) has elapsed, the FSO module activates the SSE function. For more information, see section SLS with time monitoring and speed above monitored speed on page 105.
5	The Variable SLS request is received again from the safety PLC (for example, 50%). The FSO sends a request to the drive to ramp down the motor speed to the new speed limit. The FSO starts a counter for the SLS time delay (B). Note: The FSO continues to monitor the existing Variable SLS limits until the new speed limit has been reached. Note: If variable SLS limits are rescaled before previous limits have been reached, time monitoring delay SLSx.04 starts from the beginning.
6	After time C has elapsed, the drive starts to ramp down the motor speed. Drive parameters define the deceleration ramp. The Variable SLS active indication goes off (see also section How to configure limit hit situations on page 302). The FSO starts the SLS monitoring when the motor speed is in the middle of the new SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306).
7	The new motor speed has been reached. The SLS active indication goes on.
8	The FSO starts the SLS monitoring with the new SLS limits at the latest here, that is, after the SLS time delay (B) has elapsed.
9	The Variable SLS request is received again from the safety PLC (100%). The FSO sends a request to the drive to accelerate the motor speed to the new speed limit. The FSO starts to monitor the motor speed according to the new SLS limits.
10	After time C has elapsed and if the motor speed is lower than the new speed limit, the drive accelerates the motor speed to the requested speed.
11	The Variable SLS request is removed from the safety PLC (acknowledgement method is manual or from a safety PLC). Note: If automatic acknowledgement is used, the Variable SLS monitoring is also ended.
12	The Variable SLS is acknowledged, the FSO stops the SLS monitoring and the drive continues with the speed reference set by the user. The Variable SLS indication (parameter SLSx.51) goes off.

Note: For more information on the modoff functionality in a situation where drive modulation is lost during SLS deceleration ramp, see chapter [SLS reaction when modulation is lost during deceleration ramp, with ramp monitoring](#) on page 107, and [SLS reaction when modulation is lost during deceleration ramp, with time monitoring](#) on page 114).

■ Variable SLS with ramp monitoring

In Variable SLS with ramp monitoring, the ramp according to which the drive decelerates the motor to different speeds is monitored using the ramp monitoring method (SAR1 parameters of the FSO module). Drive or SAR1 parameters define the deceleration ramp. If the motor speed is accelerated, drive parameters define the acceleration ramp and it is not monitored.

For configuration, see section [How to configure Variable SLS with ramp monitoring](#) on page 283.



- A Variable SLS trip limits (parameter [SLSx.43](#) and the scaling values set in the safety PLC)
- B Response time (depends on system configuration, see page [420](#))
- Ramp monitoring limits or Variable SLS trip limit (A)

Step	Description
1	The Variable SLS request is received from the safety PLC (for example, 70%). The FSO sends a request to the drive to ramp down the motor speed to the new speed limit.

Step	Description
2-3	<p>After time B has elapsed, the drive starts to ramp down the motor speed. SAR1 parameter 200.112 defines the deceleration ramp. The FSO starts to monitor the ramp according to SAR1 parameters (SARx.21, SARx.22).</p> <p>Note: If parameter 200.112 has value 0, the drive (parameter 23.23) defines the ramp.</p> <p>Note: If the motor speed does not follow the ramp, the FSO activates the STO function.</p> <p>The FSO starts the SLS monitoring when the motor speed is in the middle of the new SLS limit and the SLS trip limit (see also section How to configure mute time for monitoring start on page 306).</p>
3	The new motor speed has been reached. The Variable SLS active indication (parameter SLSx.51) goes on.
4	The Variable SLS request is received again from the safety PLC (for example, 50%). The FSO sends a request to the drive to ramp down the motor speed to the new speed limit.
5	<p>After time B has elapsed, the drive starts to ramp down the motor speed. SAR1 parameter 200.112 defines the deceleration ramp. The FSO starts to monitor the ramp with SAR1 parameters (SARx.21, SARx.22). The Variable SLS indication goes off (see also section How to configure limit hit situations on page 302).</p> <p>Note: The FSO continues to monitor the existing Variable SLS limits until the new speed limit has been reached.</p>
6	The new motor speed has been reached and the FSO starts to monitor the motor speed according to the new SLS limits. The Variable SLS active indication goes on.
7	The Variable SLS request is received again from the safety PLC (100%). The FSO sends a request to the drive. The FSO starts to monitor the motor speed according to the new SLS limits.
8	After time B has elapsed and if the motor speed is lower than the new speed limit, the drive accelerates the motor speed to the requested speed.
9	<p>The Variable SLS request is removed from the safety PLC (acknowledgement method is manual or from a safety PLC).</p> <p>Note: If automatic acknowledgement is used, the Variable SLS monitoring is also ended.</p>
10	The Variable SLS is acknowledged and the FSO stops the SLS monitoring. The drive continues with the speed reference set by the user. The Variable SLS indication (parameter SLSx.51) goes off.

Safe maximum speed (SMS)

The SMS function is used to protect the machine from too high speeds/frequencies. You can configure it to be permanently on or off. There are two different versions of the SMS function:


- 1. **Version 1:** If the motor speed reaches the minimum or the maximum SMS trip limit, the FSO module activates the SSE function.
- 2. **Version 2:** The minimum and maximum SMS limits limit the motor speed. This version of the SMS function is similar to the SLS function except that it can only be permanently on or off.

The required version of the SMS function is selected with FSO parameters.

You can configure the minimum and maximum SMS limits and SMS trip limits separately.

■ **SMS function, version 1**

The operation of the SMS function, version 1 is described in the time diagram and table below. For configuration, see section [How to configure SMS, version 1](#) on page 289.




- A SMS trip limit positive (parameter [SMS.14](#))
- B SMS trip limit negative (parameter [SMS.13](#))
- C Response time (depends on system configuration, see page 420)
- SMS trip limits (A and B)

Step	Description
1	The motor speed reaches the SMS trip limit positive (A).

Step	Description
2	<p>After time C has elapsed, the FSO activates the SSE function. In this case, the SSE function has been configured as “Immediate STO” (parameter SSE.13). This opens the drive STO circuit immediately and the motor coasts to a stop. The STO and SSE indications go on.</p> <p>Note: If SBC is used, it is activated according to SBC configuration settings (see the note on page 51). See section Safe stop emergency (SSE) on page 86 for more information on how to configure the SSE function.</p>
3	<p>After the SSE function has been completed, the FSO acknowledges the SSE function (in this case, automatic acknowledgement is used) and deactivates the SSE and drive STO functions. The indications go off.</p>

■ SMS function, version 2

The operation of the SMS function, version 2 is described in the time diagram and table below. For configuration, see section [How to configure SMS, version 2](#) on page [290](#).



- A SMS trip limit positive (parameter [SMS.14](#))
- B SMS trip limit negative (parameter [SMS.13](#))
- C SMS limit positive (parameter [200.73](#))
- D SMS limit negative (parameter [200.72](#))
- SMS trip limits (A and B)

The drive limits the motor speed so that it stays between the SMS limit positive and negative. If the motor speed still hits the SMS trip limit positive or negative, the FSO module activates the SSE function (see section [Safe stop emergency \(SSE\)](#) on page [86](#) for more information on how to configure the SSE function).

If you use the SMS function, version 2 and you need to remove the FSO module from the drive, do these steps:

1. Reconfigure the FSO module so that the SMS function, version 2 is deactivated (set parameter [200.71 SMS activity and version](#) to Disabled). For more information, see chapter [Configuration](#).
2. Remove the FSO module from the drive.

This removes the SMS limits from the drive. Unnecessary limits can affect the normal operation of the drive.

Prevention of unexpected start-up (POUS)


The POUS function prevents the machine from starting unexpectedly. The POUS function activates the Safe torque off (STO) function in the drive.



WARNING! The situations in which you can use the POUS function must always be based on a risk assessment (see IEC 60204-1:2016).

For more information on the STO function in the ACS880 drives, see the drive hardware manual.

The operation of the POUS function is described in the time diagram and table below. For configuration, see section [Configuring POUS](#) on page [290](#).



- A POUS delay for completion (parameter [POUS.13](#)): Sets a delay for POUS completed indication. The POUS completed indication (parameter [POUS.22](#)) goes on after this delay.

Note: POUS function does not activate SBC function, even if SBC is configured into use together with the STO function.

Step	Description
1	The user stops the motor.
2	<p>The user activates the POUS function. The FSO activates the drive STO function and starts a counter for time A. The POUS active indication (parameter POUS.21) and the STO active indication (parameter STO.21) become active.</p> <p>Note: If the user activates the POUS function when the motor is running, the FSO activates the drive STO function, generates a fault (7A97) and the motor coasts to a stop.</p>
3	<p>After time A has elapsed, the POUS completed indication becomes active (parameter POUS.22).</p> <p>Note: Connect the POUS indication lamp to this indication signal.</p>
4	<p>The user removes the POUS request. The POUS completed indication is deactivated. The acknowledgement becomes allowed.</p> <p>Note: If the user activates the POUS request again before the POUS function has been acknowledged, the counter for time A is restarted and the POUS completed indication is activated after this delay.</p>
5	<p>The user acknowledges the POUS function. The POUS active indication goes off. The FSO deactivates the drive STO function and the user can restart the motor.</p> <p>Note: If automatic acknowledgement is used, this happens already when the POUS request is removed (step 4).</p>
6	The user starts the motor.

Priorities between safety functions

When several safety functions are active at the same time, these priorities apply:

1. the STO function overrides the SSE and SS1 functions
2. the SSE function overrides the SS1 function.

The overriding function will also override the indications of the low priority functions, eg, by switching off the outputs of the safety functions with lower priority.

The POUS function is independent of other safety functions. If you activate the POUS function when another safety function is active (for example, during a deceleration ramp), it can disturb the performance of the other safety function. ABB recommends that you do not activate the POUS function when the motor is running.

Example: The SS1 function uses SAR1 parameters to define the stop ramp. In some situations (for example, with PROFIsafe-related faults or trip limit hits), the FSO module activates the Safe stop emergency (SSE) function. When the SSE function has been configured as “Emergency ramp”, it uses SAR0 parameters to define the stop ramp. If the FSO module activates the SSE

function while the SS1 function is active, the SSE function overrides the SS1 function. Therefore, SAR0 parameters are used instead of SAR1 parameters to define the stop ramp.

When a safety function overrides another safety function, this does not remove the request of the overridden safety function. Therefore, the overridden safety function restarts after the other safety function has been completed and acknowledged.


Dependencies between safety functions

The figure below shows how different safety functions of the FSO module are related to each other and the drive STO function.

1. Zero speed limit reached: The SS1 and SSE (with emergency ramp) functions activate the drive STO function (that is, open the drive STO circuit) when the motor speed reaches the user-defined zero speed limit.
2. Trip limit hit: The SMS and SLS functions activate the SSE function when the motor speed reaches a user-defined trip limit.
3. Monitoring limit hit: The SS1, SSE (with emergency ramp) and SLS functions (with ramp monitoring) activate the STO function of the FSO module when the motor speed reaches a monitoring limit.

The STO, SSE with immediate STO and POUS functions activate the drive STO function, that is, open the drive STO circuit.

The POUS function activates the drive STO independently of the stopping functions of the FSO module.



6

PROFIsafe

Contents of this chapter

This chapter describes the safety system when the FSO module is connected to a safety PLC through a fieldbus adapter module using the PROFIsafe profile of PROFINET. It describes the FSO module states and transitions and the contents of the PROFIsafe messages. The chapter also includes installation instructions, configuration instructions for the ABB AC500-S Safety PLC and Siemens SIMATIC Fail-safe S7 PLC and fault tracing tips.

Introduction

When the drive is controlled from a safety PLC, the reliability of the fieldbus communication must be secured. This can be done with the PROFIsafe technology. The PROFIsafe technology includes several safety measures to minimize the effect of various transmission errors that can occur when messages are transferred in a complex network.

PROFIsafe is an application layer (protocol) that describes the safety communication between fail-safe devices. It is an additional layer on top of the standard PROFIBUS and PROFINET protocols.

There are two versions of the PROFIsafe protocol:

- V1 can only be used with PROFIBUS
- V2 can be used with PROFIBUS and PROFINET.

The FSO module supports PROFIsafe protocol version V2.4 with PROFINET.

The PROFIsafe protocol can be used for safety applications up to SIL 3 according to IEC 61508 / IEC 62061, or up to PL e, cat. 4 according to EN ISO 13849-1.

It is possible to use the shared device feature together with an FPNO-21 module. For more information, refer to [FPNO-21 PROFINET adapter module user's manual \(3AXD50000158614 \[English\]\)](#).

For more information on PROFIsafe and PROFINET, see www.profibus.com.

System description

■ Required components


- FSO-12 safety functions module, revision C or later
- ACS880 primary control program (AINLX) version 2.12 or later, or
ACS880 primary control program (YINLX) version 1.30 or later
- FB module: FPNO-21 PROFINET fieldbus adapter module (version 1.00 or later) or FENA-21 Ethernet adapter module (version 3.05 or later)
- compatible safety PLC system, for example, ABB AC500-S Safety PLC or Siemens SIMATIC Fail-safe S7 PLC

■ Tools

- Drive Composer pro PC tool: version 1.7 or later
 - For ABB PLCs: Automation builder: 1.0 or later (includes PS501 Control Builder Plus version 2.3.0), safety license PS501-S
 - For Siemens PLCs: SIMATIC Step 7 V5.5 + S7 Distributed Safety V5.4 and SIMATIC Step 7 V 11 (TIA Portal) + Step 7 Safety Advanced V 13
-

■ System overview

This figure shows an overview of a safety PLC that is connected to the ACS880 drive via the PROFIsafe communication bus.



The FSO safety functions module and the FB module are installed on the ACS880 drive. The safety PLC is connected to the FB module, which communicates with the FSO module. The safety PLC activates safety functions via the PROFIsafe communication bus. The user can also activate safety functions from an I/O device (for example, an emergency stop button) which is connected to the FSO module.

The PROFIsafe protocol secures the whole path from the location where a safety signal originates to the location where it is processed and vice versa.

The safety PLC sends PROFIsafe messages (frames) to the FSO module through the FB module which extracts the frame from the PROFINET communication. The FSO module reads and interprets the PROFIsafe messages and performs the required actions. The FSO module sends PROFIsafe messages back to the FB module which transmits them to the safety PLC.

The term PROFIsafe F-Output data refers to the application-specific user data in the frames that are transmitted to the FSO module (F-Device) from the safety PLC (F-Host). The term PROFIsafe F-Input data refers to the application-specific user data in the frames that are transmitted from the FSO module to the safety PLC.

PLC. For a detailed description of the PROFIsafe message format, see section [PROFIsafe message format](#) on page 138.

F-Parameters are PROFIsafe parameters that all PROFIsafe devices support. F-Parameters are sent from the F-Host (safety PLC) to the F-Device (FSO module) when the PROFIsafe connection is created. They contain the PROFIsafe addresses and the watchdog time for the PROFIsafe connection.

Note: ABB recommends that you use only PROFINET compatible Ethernet switches and cables in the PROFIsafe communication bus.

Remote I/O control

You can control the FSO module outputs and read input information also from the safety PLC. A request to activate or deactivate an output is sent from the safety PLC (PROFIsafe controller) to the FSO module in a PROFIsafe message. See section [FSO PROFIsafe profiles](#) on page 140.

Only FSO outputs that are not configured for control use (for example, to control an indication lamp or a brake) can be activated from the safety PLC. If the safety PLC tries to activate an FSO output that is configured for control use, the FSO module rejects the request, activates the SSE function and goes into the Fail-safe mode (see section [FSO module modes and states](#) on page 146). To exit the Fail-safe mode, reboot the FSO as described in section [FSO recovery](#) on page 394.

FSO module passivation

If the FSO module or the safety PLC detects an error in the fieldbus communication, the FSO module is passivated. The status of the FSO outputs that are not configured for any control use (for example, to control an indication lamp or a brake) are set to “low”. The FSO module activates the SSE function, goes into the Safe state and generates an event. The user can select the event type (warning, fault or event) with parameter [SBUSGEN.10 STO indication passivation](#).

After the cause of the passivation is found, the SSE function must be acknowledged before the communication continues. The status of the safety functions and FSO outputs are set according to the PROFIsafe message that was received before the passivation.

PROFIsafe description

■ PROFIsafe message format

The FSO module supports only the PROFIsafe short frame format. The short frame supports a maximum of 12 octets of user data. The frame also includes a

CRC (3 octets) and one Status/Control Byte octet. Therefore, the maximum frame size of the message is 16 octets.

Data	F-Input / F-Output user data	Status / Control Byte	CRC2
Size (octets)	Max. 12	1	3

Control Byte and CRC2 bit order

PROFIsafe messages sent from the safety PLC to the FSO module include the F-Output user data, the Control Byte and CRC2.

This table shows the bit order of the Control Byte and CRC2.

N_o is the length of F-Output user data.

Octet	Bit	Name	Description
Control Byte			
N_o	7	Reserved	The value is ignored.
	6	Reserved	The value is ignored.
	5	Toggle_h	Toggle bit
	4	Activate_FV	Fail-safe values (FV) to be activated
	3	Use_TO2	Use F_WD_Time_2 (secondary watchdog). Not in use. The value is ignored.
	2	R_cons_nr	Reset Vconsnr_d
	1	OA_Req	Operator acknowledgement requested
	0	iPar_EN	Parameter assignment deblocked. Not in use. The value is ignored.
CRC2			
N_o+1	7	CRC bit 23	Octet 3 (MSB) of 24 bit CRC
	...		
	0	CRC bit 16	
N_o+2	7	CRC bit 15	Octet 2 of 24 bit CRC
	...		
	0	CRC bit 8	
N_o+3	7	CRC bit 7	Octet 1 (LSB) of 24 bit CRC
	...		
	0	CRC Bit 0	

Status Byte and CRC2 bit order

PROFIsafe messages sent from the FSO module to the safety PLC include the F-Input user data, the Status Byte and CRC2.

This table shows the bit order of the Status Byte and CRC2.
N_i is the length of F-Input user data.

Octet	Bit	Name	Description
Status Byte			
N _i	7	Reserved	The value is always 0. Must be ignored by the F-Host.
	6	cons_nr_R	Vconsnr_d has been reset.
	5	Toggle_d	Toggle bit
	4	FV_activated	Fail-safe values (FV) activated.
	3	WD_timeout	Communication fault: Watchdog timeout
	2	CE_CRC	Communication fault: CRC error
	1	Device_Fault	Failure exists in the F-Device.
	0	iPar_OK	F-Device has new iParameter values assigned. Not in use. The value is always 0.
CRC2			
N _i +1	7	CRC bit 23	Octet 3 (MSB) of 24 bit CRC
	...		
	0	CRC bit 16	
N _i +2	7	CRC bit 15	Octet 2 of 24 bit CRC
	...		
	0	CRC bit 8	
N _i +3	7	CRC bit 7	Octet 1 (LSB) of 24 bit CRC
	...		
	0	CRC bit 0	

■ **FSO PROFIsafe profiles**

The content of the F-Input and F-Output user data is configured with FSO specific PROFIsafe profiles. The FSO-12 module supports the ABB_PS1 profile.

The ABB_PS1 profile provides the functionality to control and monitor the safety functions, the SLS limits, the safe speed value and the states of the FSO I/O.

ABB_PS1 profile F-Output user data

This table shows the bit order of the F-Output data, which is included in the PROFIsafe message sent to the FSO module from the safety PLC. For all the bits in the F-Output data, one (1) means active and zero (0) non-active.

Type	Octet	Bit	Name	Description
Unsigned 16 (used as bits)	0	0	SLS2_request	SLS2 (Safely-limited speed) activation requested by the controller.
		1	SLS1_request	SLS1 (Safely-limited speed) activation requested by the controller.
		2	Reserved ^{*)}	Must not be used (must be 0).
		3	Reserved ^{*)}	Must not be used (must be 0).
		4	SS1_request	SS1 (Safe stop 1) activation requested by the controller.
		5	SSE_request	SSE (Safe stop emergency) activation requested by the controller.
		6	POUS_request	POUS (Prevention of unexpected start-up) activation request by the controller.
		7	STO_request	STO (Safe torque off) activation requested by the controller.
Unsigned 16 (used as bits)	1	0	Reserved ^{*)}	Must not be used (must be 0).
		1	Reserved ^{*)}	Must not be used (must be 0).
		2	Reserved ^{*)}	Must not be used (must be 0).
		3	Reserved ^{*)}	Must not be used (must be 0).
		4	Reserved ^{*)}	Must not be used (must be 0).
		5	Reserved ^{*)}	Must not be used (must be 0).
		6	SLS4_request	SLS4 (Safely-limited speed) activation requested by the controller.
		7	SLS3_request	SLS3 (Safely-limited speed) activation requested by the controller.
Unsigned 16 (used as bits)	2	0	Variable_SLS_request	Variable SLS (Safely-limited speed) activation requested by the controller and the Variable SLS limit is valid.
		1	Reserved ^{*)}	Must not be used (must be 0).
		2	SF_end_ack	Safety function ending acknowledgement = 1, no acknowledgement = 0.
		3	Reserved ^{*)}	Must not be used (must be 0).
		4	Reserved ^{*)}	Must not be used (must be 0).
		5	Reserved ^{*)}	Must not be used (must be 0).
		6	Reserved ^{*)}	Must not be used (must be 0).
		7	Reserved ^{*)}	Must not be used (must be 0).

Type	Octet	Bit	Name	Description
Unsigned16 (used as bits)	3	0	Safe_output_X114_9_ctrl	State of the safe output X114:9 (see section Remote I/O control on page 138). 1 = 24 V, 0 = 0 V.
		1	Safe_output_X114_8_ctrl	State of the safe output X114:8 (see section Remote I/O control on page 138). 1 = 24 V, 0 = 0 V.
		2	Safe_output_X114_7_ctrl	State of the safe output X114:7 (see section Remote I/O control on page 138). 1 = 24 V, 0 = 0 V.
		3	Safe_output_X113_9_ctrl	State of the safe output X113:9 (see section Remote I/O control on page 138). 1 = 24 V, 0 = 0 V.
		4	Safe_output_X113_8_ctrl	State of the safe output X113:8 (see section Remote I/O control on page 138). 1 = 24 V, 0 = 0 V.
		5	Safe_output_x113_7_ctrl	State of the safe output X113:7 (see section Remote I/O control on page 138). 1 = 24 V, 0 = 0 V.
		6	Negative_Scaling	Selects whether Variable SLS limit is scaled for negative direction. 0 = Limit scaled, 1 = Limit not scaled (100%).
		7	Positive_Scaling	Selects whether Variable SLS limit is scaled for positive direction. 0 = Limit scaled, 1 = Limit not scaled (100%).
Integer16	4		Variable_SLS_limit_MSB	Safely-limited speed relative limit (MSB) [0.01%]
Integer16	5		Variable_SLS_limit_LSB	Safely-limited speed relative limit (LSB) [0.01%]

^{*)} If the PROFIsafe message includes a safety function request which is not supported or if the safety function has not been configured, the FSO module activates the SSE function and generates an FSO configuration fault (see chapter [Fault tracing](#)).

ABB_PS1 profile F-Input user data

This table shows the bit order of the F-Input user data, which is included in the PROFIsafe message sent from the FSO module to the safety PLC. For all the bits in the F-Input data, one (1) means active and zero (0) non-active.

Note: In the Fail-safe and Configuration states, all the bits in the PROFIsafe message are set to “0”. In these cases, you can read the FSO state from:


- Siemens PLC: bits QBAD and PASS_OUT in the PROFIsafe data block
- ABB PLC: bit Device_Fault in the PROFIsafe data structure.

See also section [FSO module modes and states](#) on page 146.

Type	Octet	Bit	Name	Description
Unsigned 16 (used as bits)	0	0	SLS2_active	SLS2 (Safely-limited speed) is active. Active when the SLS2 function is active and the motor speed is below the SLS2 limit (that is, when the SLS2 monitoring is on).
		1	SLS1_active	SLS1 (Safely-limited speed) is active. Active when the SLS1 function is active and the motor speed is below the SLS1 limit (that is, when the SLS1 monitoring is on).
		2	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		3	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		4	SS1_active	SS1 (Safe stop 1) is function active.
		5	SSE_active	SSE (Safe stop emergency) function is active.
		6	SBC_active	SBC (Safe brake control) function is active.
		7	STO_active	STO (Safe torque off) function is active.
Unsigned 16 (used as bits)	1	0	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		1	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		2	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		3	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		4	SAR1_active	SAR1 (Safe acceleration range) is active.
		5	SAR0_active	SAR0 (Safe acceleration range) is active.
		6	SLS4_active	SLS4 (Safely-limited speed) is active. Active when the SLS4 function is active and the motor speed is below the SLS4 limit (that is, when the SLS4 monitoring is on).
		7	SLS3_active	SLS3 (Safely-limited speed) is active. Active when the SLS3 function is active and the motor speed is below the SLS3 limit (that is, when the SLS3 monitoring is on).
Unsigned 16 (used as bits)	2	0	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		1	SMS_active	SMS (Safe maximum speed) function is active.
		2	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		3	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		4	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		5	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		6	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.
		7	Reserved ^{*)}	The value is 0. Must be ignored by the F-Host.

Type	Octet	Bit	Name	Description
Unsigned 16 (used as bits)	3	0	Safe_input_X114_4	State of the safe input X114:4.
		1	Safe_input_X114_3	State of the safe input X114:3.
		2	Safe_input_X114_2	State of the safe input X114:2.
		3	Safe_input_X114_1	State of the safe input X114:1.
		4	Safe_input_X113_4	State of the safe input X113:4.
		5	Safe_input_X113_3	State of the safe input X113:3.
		6	Safe_input_X113_2	State of the safe input X113:2.
		7	Safe_input_X113_1	State of the safe input X113:1.
Unsigned 16 (used as bits)	4	0	Variable_SLS_active	Variable SLS (Safely-limited speed) is active. Active when the Variable SLS function is active and the motor speed is below the Variable SLS limit (that is, when the Variable SLS monitoring is on).
		1	POUS_active	POUS (Prevention of unexpected start-up) function is active.
		2	Safe_output_X114_9	State of the safe output X114:9.
		3	Safe_output_X114_8	State of the safe output X114:8.
		4	Safe_output_X114_7	State of the safe output X114:7.
		5	Safe_output_X113_9	State of the safe output X113:9.
		6	Safe_output_X113_8	State of the safe output X113:8.
		7	Safe_output_X113_7	State of the safe output X113:7.

Type	Octet	Bit	Name	Description													
Unsigned 16 (used as bits)	5	0	SF_end_ack_req	Safety function ending acknowledgement requested = 1, no acknowledgement requested = 0. Acknowledgement can be done via PROFIsafe. Note: These values are indicative only and shall not be used for safety-related decisions about safety function states (there are other ways to safely determine the state of a function, for example, using SS1 to check octet 0 bit 4 and then octet 5 bit 4: if safe state, then SS1 is completed).													
		1	SF_end_ack_req_local	Local safety function ending acknowledgement requested = 1, no acknowledgement requested = 0. Acknowledgement can only be done locally via the FSO I/O if SF_end_ack_req is 0. Note: These values are indicative only and shall not be used for safety-related decisions about safety function states (there are other ways to safely determine the state of a function, for example, using SS1 to check octet 0 bit 4 and then octet 5 bit 4: if safe state, then SS1 is completed).													
		2	STO_control_active	The drive STO circuit is open. Note: The motor may still be rotating.													
		3	Speed_value_valid	Is the speed value valid (= 1) or not (= 0). The speed value is defined in octets 6 and 7. Note: Octet 2 bit 0 indicates the speed source and octet 5 bit 3 indicates the validity of the indicated speed source.													
		4	FSO_state	Safe state = 1 Operational state = 0													
		5	FSO_mode.0														
		6	FSO_mode.1	<table><tr><td>FSO operating mode</td><td>FSO_mode.1</td><td>FSO_mode.0</td></tr><tr><td>Start-up</td><td>0</td><td>0</td></tr><tr><td>Running</td><td>0</td><td>1</td></tr><tr><td>Fail-safe</td><td>1</td><td>0</td></tr><tr><td>Configuration</td><td>1</td><td>1</td></tr></table>	FSO operating mode	FSO_mode.1	FSO_mode.0	Start-up	0	0	Running	0	1	Fail-safe	1	0	Configuration
FSO operating mode	FSO_mode.1	FSO_mode.0															
Start-up	0	0															
Running	0	1															
Fail-safe	1	0															
Configuration	1	1															

Type	Octet	Bit	Name	Description
		7	Modulating	The drive is modulating = 1 It is not known if the drive is modulating or not = 0  WARNING! The only safe way to make sure that a drive is not modulating is to activate drive STO. Drive STO can be activated, eg, with FSO STO or POUS function.
Integer16	6		Safe_speed_MSB	The current motor speed value from FSO (MSB).
Integer16	7		Safe_speed_LSB	The current motor speed value from FSO (LSB).

^{*)} The safety PLC must ignore the value of the reserved bits. This ensures the compatibility with future versions of the PROFIsafe profile where the reserved bits may be used.

Note: The states of all FSO inputs and outputs are shown in the PROFIsafe message. These states also show the states of SBC outputs and feedback inputs.

■ **FSO module modes and states**

When the FSO module is connected to a safety PLC via the PROFIsafe communications bus, the FSO module can be in the following modes and states:

- Start-up mode
- Configuration mode
- Fail-safe mode
- RUN states:
 - Operational
 - Safe (User acknowledgement request)
 - Safe (Module passivation)
 - Safe (Module passivation & reintegration)
 - Safe (Module passivation with a command).

The FSO module modes and states are described in the following two figures and tables.


The first figure shows the modes, states and transitions during normal operation. The second figure shows the modes, states and transitions when fatal errors in the FSO module occur or when cycling power of the FSO module.

Note: If PROFIsafe is not configured, see the FSO states described in section [FSO states](#) on page 61 in chapter [Safety functions](#).

Note: If PROFIsafe is configured, the FSO module stays in the Start-up mode until it has received valid F-Parameters from the safety PLC.


State diagrams

Overview of states and transitions in the FSO module during normal operation.



Note: It is possible to go to the Configuration mode from any other state when the drive is not modulating. From the Configuration mode, it is possible to go only to the Start-up mode.

Overview of states and transitions in the FSO module when fatal errors in the FSO module occur or when cycling power of the FSO module.



Description of states

This table describes the FSO module states and how the states are shown in the PROFIsafe messages. The Status Byte and the profiles are described in detail in sections [Status Byte and CRC2 bit order](#) on page 139 and [FSO PROFIsafe profiles](#) on page 140.

The table refers to several variables that are available to the programmer of an F-Host program (for example, an AC500-S program in CoDeSys):

OA_Req_S	This variable indicates that the FSO is in the “Safe (User acknowledgement request)” state ready for acknowledgement.
FV_Activated_S	This variable indicates that the FSO is in the Safe state. Fail-safe values (“0”) are set to the I/O channels.
OA_C	This variable indicates that PROFIsafe is running successfully after PROFIsafe communication error(s) have been solved. The FSO is in the “Safe (User acknowledgement request)” state and variable OA_Req_S is set to “1”. Setting OA_C variable to “1” acknowledges that the PROFIsafe communication errors have been solved and it is possible to go to the Operational state.
Device_Fault	This variable is the Device_Fault bit of the PROFIsafe Status Byte. When the value is 1, the FSO is in the Fail-safe mode.

State	Description
Start-up	<p>The FSO module hardware is initialized and internal start-up tests are executed. After a successful parameterization, the PROFIsafe communication is expected to be initiated by the PROFIsafe F-Host. The FSO module remains in this state:</p> <ul style="list-style-type: none"> • if the parameterization failed or is pending • if the PROFIsafe communication is pending. <p>PROFIsafe Status Byte bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • OA_Req_S = 0 • FV_activated_S = 1 • Device_Fault = 0 <p>ABB_PS1 profile bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • FSO_mode.1 = 0 • FSO_mode.0 = 0 • SF_end_ack_req_local = 0 • SF_end_ack_req = 0 • FSO_state = 1

State	Description
Operational	<p>PROFIsafe communication is up and running. The safety application is running without any detected errors.</p> <p>PROFIsafe Status Byte bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none">• OA_Req_S = 0• FV_activated_S = 0• Device_Fault = 0 <p>ABB_PS1 profile bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none">• FSO_mode.1 = 0• FSO_mode.0 = 1• SF_end_ack_req_local = 0• SF_end_ack_req = 0• FSO_state = 0

State	Description
Safe (Module passivation & reintegration)	<p>PROFIsafe communication is up and running. The FSO application is running with detected errors.</p> <p>At least one of the active safety functions has encountered an error. For example, the SLS1 function is active and its speed limits are violated. The drive is stopped using the configured method. In the end, the drive STO is activated.</p> <p>As soon as the STO function has been completed and no errors are detected, reintegration of the FSO module is possible. It depends on the FSO configuration from where the reintegration can be done. All tripped safety functions must be acknowledged to complete the reintegration.</p> <p>SF_end_ack_req_local is set if any of the safety functions can be acknowledged locally via FSO inputs.</p> <p>SF_end_ack_req is set if any of the safety functions can be acknowledged via PROFIsafe frame bit SF_end_ack. A positive edge from "0" to "1" is required to acknowledge the module reintegration.</p> <p>If automatic acknowledgement is configured for the error condition, neither of the status bits is set. The acknowledgement is done automatically.</p> <p>As soon as all errors have been solved and they have been acknowledged, the Operational state is reached.</p> <p>PROFIsafe Status Byte bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • OA_Req_S = 0 • FV_activated_S = 0 • Device_Fault = 0 <p>ABB_PS1 profile bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • FSO_mode.1 = 0 • FSO_mode.0 = 1 • SF_end_ack_req_local = 1, if it is possible to acknowledge any of the tripped safety functions locally via the FSO inputs. SF_end_ack_req_local = 0, otherwise. • SF_end_ack_req = 1, if it is possible to acknowledge any of the tripped safety functions via PROFIsafe. SF_end_ack_req = 0, otherwise. • FSO_state = 1

State	Description
Safe (Module passivation)	<p>The FSO application is running and there has been an error in the PROFIsafe communication.</p> <p>The FSO module and, as a result, all its I/O channels are passivated. Possible reasons for module passivation are:</p> <ol style="list-style-type: none"> 1. PROFIsafe communication failure (CRC error) 2. PROFIsafe watchdog timeout exceeded. <p>The drive is stopped using the configured method. In the end, the drive STO is activated. The fail-safe value "0" is set to all I/O channels. If the connection to the PROFIsafe F-Host is possible, the fail-safe value "0" is transferred to the safety PLC for all I/O channels.</p> <p>If the PROFIsafe communication is broken, the safety application continuously attempts to establish a communication to the safety PLC.</p> <p>A state transition to another RUN state is possible only if the detected error has been solved.</p> <p>PROFIsafe Status Byte bits in the F-Host for the FSO module (if communication is possible):</p> <ul style="list-style-type: none"> • OA_Req_S = 0 • FV_activated_S = 1 • Device_Fault = 0 • CE_CRC = 1, in case of a communication error, CE_CRC = 0, otherwise • WD_timeout = 1, in case of a watchdog timeout, WD_timeout = 0, otherwise <p>ABB_PS1 profile bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • FSO_mode.1 = 0 • FSO_mode.0 = 1 • SF_end_ack_req_local = 0 • SF_end_ack_req = 0 • FSO_state = 1

State	Description
Safe (Module passivation with a command)	<p>PROFIsafe communication is up and running. The FSO application is running without any detected errors.</p> <p>The FSO module and all its I/O channels are passivated because the safety application on the safety PLC requested a module passivation (activate_FV_C = 1 was set).</p> <p>The drive is stopped using the configured method. In the end, the drive STO is activated and the FSO module is in the Safe state. The fail-safe value "0" is set to all I/O channels. The fail-safe value "0" is transferred to the safety PLC for all I/O channels.</p> <p>PROFIsafe Status Byte bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • OA_Req_S = 0 • FV_activated_S = 1 • Device_Fault = 0 <p>ABB_PS1 profile bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • FSO_mode.1 = 0 • FSO_mode.0 = 1 • SF_end_ack_req_local = 0 • SF_end_ack_req = 0 • FSO_state = 1
Safe (User acknowledgement request)	<p>PROFIsafe communication is up and running. The FSO application is running without any errors but waits for the acknowledgement of a module reintegration (module error has been solved).</p> <p>The FSO module is in the Safe state. The fail-safe value "0" is still transferred to the safety PLC for all input channels. All output channels have a state of "0". The OA_Req_S bit is reported as "1".</p> <p>As soon as the safety application in the safety PLC sets OA_C (positive edge), the FSO module goes to the Operational state if no further errors are detected. The OA_C must be "1" until OA_Req_S starts to deliver "0".</p> <p>PROFIsafe Status Byte bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • OA_Req_S = 1 • FV_activated_S = 1 • Device_Fault = 0 <p>ABB_PS1 profile bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • FSO_mode.1 = 0 • FSO_mode.0 = 1 • SF_end_ack_req_local = 0 • SF_end_ack_req = 0 • FSO_state = 1

State	Description
Fail-safe	<p>The FSO application keeps the system in the Fail-safe mode. PROFIsafe communication is up and running.</p> <p>This state is reached if a fatal error (for example, CPU test, RAM test, I/O channel test etc. failed) takes place.</p> <p>The drive is stopped using the configured method. In the end, the drive STO is activated. The fail-safe value “0” is set to all I/O channels. The fail-safe value “0” is transferred to the safety PLC for all I/O channels.</p> <p>This state can be left only to the Start-up mode by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, see the drive firmware manual).</p> <p>PROFIsafe Status Byte bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • OA_Req_S = 0 • FV_activated_S = 1 • Device_Fault = 1 <p>ABB_PS1 profile bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • FSO_mode.1 = 1 • FSO_mode.0 = 0 • SF_end_ack_req_local = 0 • SF_end_ack_req = 0 • FSO_state = 1 <p>See also the Note on page 142.</p>
Configuration	<p>The FSO module is in the Safe state. Upon transferring to the Configuration mode, the FSO answers to one PROFIsafe frame. The fail-safe value “0” is transferred to the safety PLC for all I/O channels. After that PROFIsafe communication is not possible. The fail-safe value “0” is set to all I/O channels.</p> <p>This state can only be entered from the Fail-safe mode or from any other state when the drive is not modulating.</p> <p>This state can be left only to the Start-up mode by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, see the drive firmware manual).</p> <p>PROFIsafe Status Byte bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • OA_Req_S = 0 • FV_activated_S = 1 • Device_Fault = 0 <p>ABB_PS1 profile bits in the F-Host for the FSO module:</p> <ul style="list-style-type: none"> • FSO_mode.1 = 1 • FSO_mode.0 = 1 • SF_end_ack_req_local = 0 • SF_end_ack_req = 0 • FSO_state = 1 <p>See also the Note on page 142.</p>

Transitions between states

This table describes the transitions between the FSO module states. The numbering of the transitions refer to the transitions shown in the state diagrams on page 147.

ID	From	To	Description
1	Start-up	Safe (Module passivation with a command)	The FSO module goes to this state directly after Start-up during a normal start-up.
2	Operational	Start-up	The FSO module goes to this state by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, refer to the drive firmware manual).
3	Start-up	Safe (Module passivation)	PROFIsafe watchdog time or PROFIsafe communication error was detected directly after Start-up.
4	Safe (Module passivation)	Start-up	The FSO module goes to this state by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, see the drive firmware manual).
5	Start-up	Fail-safe	Fatal error(s) (CPU test, RAM test, etc. failed) detected.
6	Fail-safe	Start-up	The FSO module goes to the Start-up mode by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, refer to the drive firmware manual).
7	Operational	Safe (Module passivation & reintegration)	Execution of at least one safety function encountered a problem. The system reaches the Safe state. As soon as at least one of the errors can be acknowledged, it can be done locally, via PROFIsafe, or automatically depending on the FSO configuration.
8	Safe (Module passivation & reintegration)	Operational	All the related errors have been solved and acknowledged.
9	Operational	Fail-safe	Fatal error(s) (CPU test, RAM test, etc. failed) detected.
10	Operational	Safe (Module passivation)	PROFIsafe watchdog time or PROFIsafe communication error was detected.

ID	From	To	Description
11	Operational	Safe (Module passivation with a command)	Command "activate_FV_C = 1" was sent from the safety PLC.
12	Safe (Module passivation & reintegration)	Fail-safe	Fatal error(s) (CPU test, RAM test, etc. failed) detected.
13	Safe (Module passivation)	Fail-safe	Fatal error(s) (CPU test, RAM test, etc. failed) detected.
14	Safe (Module passivation & reintegration)	Start-up	The FSO module goes to this state by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, refer to the drive firmware manual).
15	Start-up	Start-up	The FSO module goes to this state by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, refer to the drive firmware manual).
16	Safe (User acknowledgement request)	Fail-safe	Fatal error(s) (CPU test, RAM test, etc. failed) detected.
17	Safe (User acknowledgement request)	Start-up	The FSO module goes to this state by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, refer to the drive firmware manual).
18	Safe (Module passivation with a command)	Safe (Module passivation)	PROFIsafe watchdog time or PROFIsafe communication error was detected.
19	Safe (Module passivation)	Safe (Module passivation with a command)	Module error (watchdog time or communication error (CRC)) has been solved and command "activate_FV_C = 1" is received.
20	Safe (User acknowledgement request)	Safe (Module passivation)	PROFIsafe watchdog time or PROFIsafe communication error was detected.
21	Safe (Module passivation)	Safe (User acknowledgement request)	Module error (watchdog time or communication error (CRC)) has been solved and <ul style="list-style-type: none"> command "activate_FV_C = 0" then <ul style="list-style-type: none"> the FSO module sets OA_Req_S = 1.

ID	From	To	Description
22	Safe (User acknowledgment request)	Operational	OA_C (positive edge) was set by the PROFIsafe F-Host for the FSO module.
23	Safe (User acknowledgment request)	Safe (Module passivation with a command)	Command “activate_FV_C = 1” was sent from the PROFIsafe F-Host.
24	Safe (Module passivation with a command)	Safe (User acknowledgment request)	Command “activate_FV_C = 0” has been received and “OA_Req_S = 1”.
25	Safe (Module passivation with a command)	Fail-safe	Fatal error(s) (CPU test, RAM test, etc. failed) detected.
26	Safe (Module passivation with a command)	Start-up	The FSO module goes to this state by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, refer to the drive firmware manual).
27	Safe (Module passivation with a command)	Operational	No module error and “activate_FV_C = 0”.
28	Safe (Module passivation & reintegration)	Safe (Module passivation)	PROFIsafe watchdog or PROFIsafe communication error was detected.
29	Safe (Module passivation & reintegration)	Safe (Module passivation with a command)	Command “activate_FV_C = 1” was sent from the safety PLC.
30	Safe (User acknowledgment request)	Safe (Module passivation & reintegration)	OA_C (positive edge) was set by the PROFIsafe F-Host, but there are existing errors in the active safety functions or there are errors that need to be acknowledged.
31	Safe (Module passivation with a command)	Safe (Module passivation & reintegration)	Command “activate_FV_C = 0” was set by the PROFIsafe F-Host but there are existing errors in the active safety functions or there are errors that need to be acknowledged.
32	Any state when the motor is not running	Configuration	Drive Composer pro connects to the FSO module and as a result the FSO goes to the Configuration state.
33	Configuration	Start-up	From the Configuration mode, it is possible to go only to the Start-up mode by cycling power of the FSO module or by giving the reset command via the drive (parameter 96.09 FSO reboot, see the drive firmware manual).

■ **PROFIsafe response time**

The safety function response time (SFRT) is the time within which the safety system must react after an error has occurred in the system.

SFRT is also the maximum time within which the safety system must respond to a change in the input signals.

According to PROFIsafe System Description, Version April 2016, SFRT for PROFIsafe devices can be defined as:

$$\text{SFRT} = \text{TWCDT} + \text{Longest } \Delta T_{\text{WD}}$$

where

- TWCDT (total worst-case delay time) is the maximum time for input signal transfer in the safety system until the output reaction under worst-case conditions (all components require the maximum time)
- Longest ΔT_{WD} is the longest time difference between the watchdog time for a given entity and the worst-case delay time.

In safety systems, to define SFRT you must take into account a potential single fault in one of the components during the signal transfer. It is enough to consider a single fault only (see PROFIsafe System Description, Version April 2016).

The worst-case delay time (WCDT) and watchdog (WD) values for the FSO and FENA modules are listed in the table below.

Device	WCDT	Device WD
FSO	50 ms	50 ms
FPNO-21	3 ms	-
FENA-21	3 ms	-

The documentation of the safety PLC defines how you can calculate the processing time and transmission time of the PROFIsafe connection.

For example, [AC500-S Safety User Manual \(3ADR025091M0212 \[English\]\)](#) proposes that SFRT is calculated using the following formula:

$$\text{SFRT} = \text{Device_WD1} + 0.5 \times \text{F_WD_Time1} + \text{F_Host_WD} + 0.5 \times \text{F_WD_Time2} + \text{Device_WD2} + \text{Longest } \Delta T_{\text{WD}}$$

where

- Device_WD1 is an internal input device watchdog time
- F_WD_Time1 is the watchdog time for receipt of the new valid telegram (from the input device to the safety PLC)
- F_Host_WD is the watchdog time of the safety PLC
- F_WD_Time2 is the watchdog time for receipt of the new valid telegram (from the safety PLC to the output)
- Device_WD2 is an internal output device watchdog time.

Instead of WCDT values, the calculation uses watchdog times. Refer to [AC500-S Safety User Manual \(3ADR025091M0212 \[English\]\)](#) for details.

For example, when using the ABB AI581-S as the input device, the SM560-S safety PLC and the FSO module as the output device, SFRT can be calculated as follows:


$$\begin{aligned} \text{SFRT} &= \text{Device_WD1} + 0.5 \times \text{F_WD_Time1} + \text{F_Host_WD} + 0.5 \times \text{F_WD_Time2} + \\ &\quad \text{Device_WD2} + \text{Longest } \Delta\text{T_WD} \\ &= 76.5 + 15 + 6 + 45.5 + 50 + 45.5 = 238.5 \text{ ms} \end{aligned}$$

where

- Device_WD1 = 76.5 ms
 - F_WD_Time1 = 30 ms
 - F_Host_WD = 6 ms
 - F_WD_Time2 = 91 ms
 - Device_WD2 = 50 ms
 - Longest $\Delta\text{T_WD}$ = Max (0.5 x F_WD_Time1; 0.5 x F_WD_Time2) = 45.5 ms (all other used WCDT values are equal to their corresponding watchdog times).
-

■ PROFIsafe watchdog time

F-Parameter `F_WD_Time` determines the watchdog time for the PROFIsafe connection. The minimum watchdog time is composed of four timing sections as shown in this figure.



1. Device acknowledgement time (DAT) is the time it takes for the F-Device (such as the FSO module) to process an incoming PROFIsafe frame. DAT starts when the F-Device receives the PROFIsafe frame and ends when the F-Device has prepared a new PROFIsafe frame using the currently available process values.
2. Bus time is the time it takes when the PROFIsafe frame is transmitted from the F-Device (FSO module) to the F-Host (such as the ABB SM560-S safety controller station) through the "black channel".
3. Host acknowledgement time (HAT) is the time it takes for the F-Host to process an incoming PROFIsafe frame.
4. Another Bus time elapses when the new PROFIsafe frame is transmitted from the F-Host back to the F-Device.

`F_WD_Time` assigned to the FSO module must be higher than the minimum watchdog time. The worst-case delay time of the FSO module also depends on the safety functions that are used simultaneously and on the PROFIsafe cycle time. The longest worst-case delay time of the FSO module is 50 ms which is based on its internal watchdog.

Calculating the watchdog time

It is not always easy to calculate the worst-case delay time of "black channel" components. Refer to [AC500-S Safety User Manual \(3ADR025091M0212 \[English\]\)](#) for a proposed method of tracing the actual PROFIsafe cycle times in a real system.

You must then set F_WD_Time about 30% higher than the worst-case value in variable tResponseTimeMS (in the AC500-S safety program) for the given safety device.

If you use this approach for the FSO module, you can set the PROFIsafe cycle time and the corresponding watchdog time F_WD_Time as short as possible for the given system.

If the longest recorded PROFIsafe cycle time (minimum F_WD_Time) is, for example, 40 ms, a suitable value for F_WD_Time is:

$$F_WD_Time = 40 \text{ ms} \times 1.3 = 52 \text{ ms.}$$

If you can calculate F_WD_Time instead, use the values given in the table on page 158. DAT time for the FSO module is 50 ms and the FENA-21 module adds 3 ms to both Bus times.

For example, if HAT is 6 ms and Bus times are 4 ms until FENA, F_WD_Time is:

$$F_WD_Time = (50 \text{ ms} + (3 \text{ ms} + 4 \text{ ms}) + 6 \text{ ms} + (4 \text{ ms} + 3 \text{ ms})) \times 1.3 = 91 \text{ ms.}$$

Installation

Installation procedure:

1. Install the FSO safety functions module to the drive. Refer to chapters [Planning for installation](#) and [Installation](#), and the drive hardware manual.
2. Install the FB module to the drive. Refer to the applicable manual:
 - [FENA-01/-11/-21 Ethernet adapter module user's manual \(3AUA0000093568 \[English\]\)](#), or
 - [FPNO-21 PROFINET adapter module user's manual \(3AXD50000158614 \[English\]\)](#).
3. Connect the FB module to the safety PLC through a PROFINET network. Refer to the manual of the FB module, and the manual of the safety PLC.

Configuration

■ Configuring the FB module

You can use the drive control panel or the Drive Composer pro PC tool to change the settings of the FB module.

Note: This section describes only the most important configuration steps. For more detailed information, see [FPNO-21 PROFINET adapter module user's manual \(3AXD50000158614 \[English\]\)](#), [FENA-01/-11/-21 Ethernet adapter module user's manual \(3AUA0000093568 \[English\]\)](#) and the drive firmware manual.

Note: Example values in the table below are chosen based on the upcoming example project.

Parameters for the PROFINET communication

- 1. Depending on the drive, you can configure the FB module as fieldbus channel A or B. Enable the communication between the drive and the FB module for the option slot where the FB module is installed in (parameter 50.01 FBA A enable or 50.31 FBA B enable).
- 2. Set the FB module parameters that correspond to the selected fieldbus channel. Parameter groups 51, 52 and 53 include the settings for FBA A and groups 54, 55 and 56 for FBA B.

Groups 52, 53, 55 and 56 configure the contents of the normal PROFINET cyclic communication by mapping the words in the PROFINET frame to the desired drive parameters.

Groups 51 and 54 configure the PROFINET connection.

Index	Name/Value	Description	Example value
50.01	FBA A enable	Enables/disables communication between the drive and fieldbus adapter A and specifies the slot the adapter is installed into.	1
	Option slot 1	Communication between drive and fieldbus adapter A enabled. The adapter is in slot 1.	
50.31	FBA B enable	Enables/disables communication between the drive and fieldbus adapter B, and specifies the slot the adapter is installed into.	0
	Disable	Communication between drive and fieldbus adapter B disabled.	
51/54.01	FBA A/B type	Shows the type of the connected fieldbus adapter module A/B. This parameter is read-only.	Ethernet
51/54.02	FBA A/B PAR2 (PROTOCOL/PROFILE)	Selects one of the PNIO profiles.	11
	PNIO ABB Pro	Profile PNIO ABB Pro is selected	
51/54.03	FBA A/B PAR2 (COMMRATE)	Sets the Ethernet communication rate.	0
	Auto	Ethernet communication rate is negotiated automatically by the device.	
51/54.04...13	IP CONFIGURATION	The user can set the IP configuration for the network in these parameters or in the PLC project.	Static IP 0

Index	Name/Value	Description	Example value
51/54.20	Telegram type	Shows the telegram type for the selected I/O communication. This parameter is read-only.	4
	PPO4	PPO Type 4	
51/54.21	Alarm disable	Enables/disables the sending of diagnostic messages to the PROFINET network.	0
	Enabled	Diagnostic messages are sent.	
51/54.27	FBA A/B PAR REFRESH	Validates any changed FB module configuration settings and reboots the FB module taking all the changes to the drive parameters in use. After refreshing, the value reverts automatically to Done (0). Note: This parameter cannot be changed while the drive is running.	1
	REFRESH	Refreshing.	

Note: When the FB module is installed to the drive for the first time, you must set the value of parameter 51/54.02 to one of the PROFINET profiles (value 11 if a drop-down list is unavailable) and reboot the FB module with parameter 51/54.27. Only after this, the rest of the parameters in group 51/54 get the correct texts and options. If required, you must reconnect Drive Composer pro to the drive to get the parameters show up correctly (select **Refresh** from the **New** menu).

See the FB module user's manual and the drive firmware manual for all necessary parameter settings and detailed instructions on how to control the drive and motor using the normal PROFINET cyclic communication.

■ Configuring the FSO module

Set the FSO module parameters as described in section [Configuring the safety fieldbus communication](#) on page 245.

■ Configuring the safety PLC

After the drive has initialized the FB module, you must prepare the safety PLC for communication with the adapter module. Examples of ABB AC500-S Safety PLC and Siemens SIMATIC Fail-safe S7 PLC are given below. The examples include the minimum required steps for starting the PROFINET and PROFIsafe communication with the FB and FSO modules. For detailed information, see the documentation of your safety PLC.

The examples apply to all drive types that are compatible with the FB and FSO modules.

■ Downloading the GSD file

To configure the controller station, you need a type definition (GSD) file. In PROFINET IO, the GSD file is written in an XML-based language called GSDML.

Download the FB module GSD file from the ABB Document library (www.abb.com/drives/documents). The file name format is: **GSDML-Vx.x-ABB-FENA-yyyyymmdd.xml** or **GSDML-Vx.x-ABB-FPNO-yyyyymmdd.xml**.

- FPNO GSDML file
- FENA GSDML file

The GSD file describes the vendor-specific, PROFIdrive-specific and PROFIsafe-specific features of the adapter module. You can use the vendor-specific features, for example, in the ABB Drives communication profile. The PROFIdrive profile supports a set of services described in the PROFIdrive specification.

The actual PROFIsafe messages are processed in the FSO module. The GSD file and the instructions in this chapter refer to the FB module which is the device that is connected to PROFINET.

■ Configuring the ABB AC500-S Safety PLC

This example shows how to configure the communication between the ABB AC500-S Safety PLC and the FENA-21 adapter module using Automation Builder 2.0.


Before you use the safety configuration and programming tools in Automation Builder, you must study the AC500-S Safety PLC user manual. Refer to [AC500-S Safety User Manual \(3ADR025091M0212 \[English\]\)](#). Only qualified persons are permitted to work with the AC500-S Safety PLC.

You need a password to configure the safety parts of an Automation Builder project. In all new projects, there is a default user “Owner” with an empty password. This is a project administrator who can, for example, access the safety controller station. For detailed information on the passwords and access permissions in Automation Builder, refer to the AC500-S Safety PLC user manual.


You can find the complete documentation of ABB PLCs and Automation Builder 2.0 application in www.abb.com/PLC.

Before you start, make sure that you have downloaded the FENA GSD file from the ABB Document library. Refer to section [Downloading the GSD file](#) on page 164.


1. Start the ABB Automation Builder application.
2. On the **Tools** menu, select **Device Repository**.
3. In the window that opens, click **Install...** and browse for the GSD file.




4. Open or create the PLC project that is used to control the drive.



5. After creating the project, the following view is shown. Add the necessary controller devices to the PLC project.




Next, add the necessary controller devices to the PLC project. First add the safety controller to slot 1 (make sure that the physical controller is in the same slot). Right-click on the slot, select Add object, and pick the SM560-S safety controller from the list.




Note: When adding the safety controller, a login screen will appear. The default login information is:

User name: Owner


Password: (empty)




Next, in the same way, add the CM579-PNIO PROFINET master to slot 2.



Note: Make sure that the “Enable debug” setting is On for the safety controller station, if you want to view or debug the PLC program after the download.




6. Right-click on the PROFINET controller **CM579-PNIO-Master** and add the FENA module to the PROFINET IO network.




7. Add the desired I/O module, for example, “PPO Type 4” to the first slot of the FENA module to define cyclic communication between the module and the PLC.
8. Add the PROFIsafe module “PROFIsafe ABB_PS1” to the second slot of the FENA module to define cyclic communication between the module and the

PLC.




9. Define the PROFINET controller (CM579-PNIO) properties, such as the IP address and IP address settings for devices:
- Select **PNIO_Controller**.
 - On the **PROFINET I/O Controller** tab, define the necessary IP addresses.




10. Define the FENA properties:
- Select **FENA_21**.
 - On the **PNIO identification** tab, define the IP address and Subnet mask, and type the Station name (in this example, drive1).


Note: Use only lower case letters for the Station name.



11. Set the communication parameters (if you have already done this, you can move on to the next step Create configuration data for safety and non-safety.).
 - Right-click on the PLC_AC500_V2 controller and open the communication settings. Tick Use advanced settings and open the Advanced settings window.




- In the advanced settings, create a new local profile with the following parameters:




- Next open the CoDeSys safety program and choose Communication

parameters from the Online drop down menu.



- Now create a new profile and fill in the following parameters:



- Next check that your network adapter is in the same subnet. Open the


Windows network and sharing center and click on the network adapter.




Unidentified network
Public network

Access type: No network access
Connections: **Local Area Connection 4**


- Navigate to the IPv4 properties.



- Finally, set your subnet to the same range as the PLC. Check that the IP address is not in use on the network.



12. Create configuration data for safety and non-safety.



Note: The PROFIsafe source and destination addresses have to be different in order for the configuration process to work. Also, when creating safety data, some libraries will have to be created.

13. Return to the PROFINET controller (CM579-PNIO) properties. On the **Assign I/O Device Name** tab:

- Click **Connect to PLC (Login)** and select the communication link used between Automation Builder and the PLC.
- Click **Scan** to find all PROFINET devices connected to the network.
- In the **Configure station name** box, select the station name defined for the module in step 10 (in this example, drive1), and click **Assign I/O Device name**.
- In the **IP address** and **Network mask** boxes, type the IP address and subnet mask defined in step 11, and click **Assign IP configuration**.

14. Define the I/O module properties:


- Select the I/O module **PPO_Type_4**.
- On the **General** tab, configure the Stop Mode Action and Control-zero mode functions, and define Fail safe values for the PLC output process data (PZDs).

The screenshot shows the HW Config interface. On the left, a project tree for 'Safety_test' is visible, containing a PLC_AC500_V2 and various modules. The 'PPO_Type_4' module is selected. The main window displays the 'General' tab for this module. On the right, 'Module Information' shows 'Ident Number' as 16#00000104 and 'Slot Number' as 1. Below this, 'User-Defined Parameters' includes a 'Set All Default Values' button and a table of parameters.

Parameters	Value	Allowed values
General parameters		
Stop Mode Action selection	Freeze data	0..2
Control-zero mode selection	Use data	0..1
Fail safe Control Word	0	0..65535
Fail safe Reference	0	0..65535
Fail safe value of Ref PZD3	0	0..65535
Fail safe value of Ref PZD4	0	0..65535
Fail safe value of Ref PZD5	0	0..65535
Fail safe value of Ref PZD6	0	0..65535

- Rename the I/O modules, for example, drive1_PPO4 and drive1_ABB_PS1.
- On the **PNIO Module I/O Mapping** tab, type names for the variables that refer to the drive's signals in the PLC program. (See section [ABB_PS1](#))


profile F-Output user data on page 141.)



15. Define the PROFIsafe module properties:

- Select the PROFIsafe module **PROFIsafe_ABB_PS1**.

On the **F-Parameter** tab, modify the PROFIsafe safety parameters. Three of the listed parameters can be modified for FENA:



- F_Source_Add is the address of the safety controller station (in this example, AC500 SM560-S).
- F_Dest_Add is the address of the FENA module. This is defined by FSO parameter **PROFIsafe.11**, see section [Configuring the safety fieldbus communication](#) on page 245.

These two define the codename for the PROFIsafe relationship of this particular FENA module and the safety controller station.

- F_WD_Time is the PROFIsafe watchdog time. See section [Calculating the watchdog time](#) on page 160 for instructions on how to calculate the correct watchdog time.
- On the **PNIO Module Safety I/O Mapping** tab, type names for the variables that refer to the PROFIsafe message data in the safety PLC program. (See section [ABB_PS1 profile F-Output user data](#) on page 141.)

Devices

Safety_test

PLC_AC500_V2 (PM583-ETH - TB521-ETH)

Application

IO_Bus

Interfaces

COM1_Online_Access (COM1 - Online Access)

COM2_Online_Access (COM2 - Online Access)

FBP_Online_Access (FBP - Online Access)

Ethernet

ETH1 (ETH1)

Protocols (Protocols)

Extension_Bus

AC500_SM560_S (AC500 SM560-S)

AC500_S

CM579_PNIO (CM579-PNIO)

PNIO_Controller (PROFINET-IO-Controller)

FENA_21 (FENA-21)

drive1_PP04 (PPO Type 4)

drive1_ABB_PS1 (PROFIsafe ABB_PS1)

drive1_PP04

drive1_ABB_PS1

General

I/O mapping list

F-Parameter

PNIO Module Safety I/O Mapping

PNIO Module I/O Mapping

Information

Variable	Mapping	Channel	Type	Unit	Descr
ABB_PS1_In0		ABB_PS1 In0	UINT		
ABB_PS1_In1		ABB_PS1 In1	UINT		
ABB_PS1_In2		ABB_PS1 In2	UINT		
drive1_VarSLs_act		Variable SLs state	BOOL		
drive1_POUS_act		POUS active	BOOL		
drive1_out_x114_9		Safe output x114 9	BOOL		
drive1_out_x114_8		Safe output x114 8	BOOL		
drive1_out_x114_7		Safe output x114 7	BOOL		
drive1_out_x113_9		Safe output x113 9	BOOL		
drive1_out_x113_8		Safe output x113 8	BOOL		
drive1_out_x113_7		Safe output x113 7	BOOL		
drive1_SF_EndAc...		SF end ack req	BOOL		
drive1_SF_EndAc...		SF end ack req local	BOOL		
drive1_STO_act		STO control active	BOOL		
drive1_Speedvalu...		Speed value valid	BOOL		
drive1_FSO_state		FSO state	BOOL		
drive1_FSO_mode0		FSO mode0	BOOL		
drive1_FSO_mode1		FSO mode1	BOOL		
drive1_Modulating		Modulating	BOOL		
drive1_PS_Safe_Speed		ABB_PS1 In Safe Speed	INT		
ABB_PS1_Out0		ABB_PS1 Out0	UINT		
ABB_PS1_Out1		ABB_PS1 Out1	UINT		
drive1_PS_VarSLsLim		ABB_PS1 Out VarSLsLimit	INT		

16. Create the configuration data for the controller station:
- Right-click on the **Application** and select **Create Configuration Data**.
17. Create the safety configuration data for the controller station:
- Right-click on the **AC500_S** and select **Create Safety Configuration Data**.
18. Download the safety and “non-safety” PLC programs. This is done through Codesys, by double clicking on "Application". Then in Codesys, open Online drop down menu and choose Login. Same is done to the safety program by double clicking on "AC500_S".
- Note:** The non-safety program may be empty, but the safety program must contain a watchdog in order for PROFIsafe to run.
19. Create a program that controls the drive:
- Double-click the **Application**. This opens the PLC program in the CoDeSys programming tool.
20. Create a safety program that controls the FSO via PROFIsafe:
- Double-click the **AC500_S**. This opens the safety PLC program in the CoDeSys programming tool.

Note: If you do not have an existing safety program, you must at least implement watchdog toggling.

CoDeSys - AC500_SAC500PRO [SAFETY MODE] - [PLC_PRG (PRG)]

File Edit Project Insert Extras Online Window Help

POUs
PROFIsafe
PLC_PRG (PRG)

```

0002 VAR
0003   SF_WDOG: SF_WDOG_TIME_SET;
0004 END_VAR
0005
0006
0007 (* Toggle Watchdog *)
0008 SF_WDOG
0009   EN := TRUE;
0010   WDOG:=5;
0011   RESET:=FALSE;
0012   DONE=>;
0013   ACT_TIME=>;
0014   MAX_TIME=>;
0015
0016 (* Automatic operator acknowledgment for PROFIsafe *)
0017 IF drive1_ABB_PS1_OA_Req_S := TRUE THEN
0018   drive1_ABB_PS1_OA_C := TRUE;
0019 ELSE
0020   drive1_ABB_PS1_OA_C := FALSE;
0021 END_IF
0022
0023 (* Automatic acknowledgment for FSO *)
0024 IF drive1_SF_end_ack_req := TRUE THEN
0025   drive1_SF_end_ack := TRUE;
0026 ELSE
0027   drive1_SF_end_ack := FALSE;
0028 END_IF
0029
0030 (* Keep SLS3 active all the time *)
0031 drive1_SLS3_request := TRUE;
0032
0033
0034
0035
0036
0037
0038
0039
0040

```

Loading library C:\Program Files (x86)\Common Files\ICA-Targets\ABB_AC500AC500_V12\Library\SafetyBase_PROFIsafe_...
Loading library C:\Program Files (x86)\Common Files\ICA-Targets\ABB_AC500AC500_V12\Library\SafetyBlocks_PL_Copen_...
Loading library C:\Program Files (x86)\Common Files\ICA-Targets\ABB_AC500AC500_V12\Library\SafetyExt_AC500_V22.lib
Loading library C:\Program Files (x86)\Common Files\ICA-Targets\ABB_AC500AC500_V12\Library\SafetyUtil_CoDeSys_AC5...
Loading library C:\Program Files (x86)\Common Files\ICA-Targets\ABB_AC500AC500_V12\Library\Target_AC500_V22.lib
Loading library C:\Program Files (x86)\Common Files\ICA-Targets\ABB_AC500AC500_V12\Library\SysLibs\SYSLIBCALLBAC...

Ln: 14, Col: 31 ONLINE [OV READ]

Note: If there are communication problems at this point, select **Communication parameters...** from the **Online** menu.

Note: To make sure that the program is downloaded to the PLC (even when no changes have been made), select **Clean all** from the **Project** menu.

- In the window that opens, click **Yes**. This downloads the program to the PLC.
- In the **Online** menu, select **Create boot project**. This saves the program permanently to the PLC.
- In the **Online** menu, select **Logout**.


22. Repeat step 21 for the safety program.

23. Switch the power of both PLCs off and on.

24. For the “non-safety” program:

- In the **Online** menu, select **Login**.

25. In the **Online** menu of the “non-safety program”, select **Run**. This starts both programs.



Monitoring the PROFIsafe message

It is possible to monitor the contents of the PROFIsafe message. For example:

1. Check the variable values in the **Current Value** column on the **PNIO Module I/O Mapping** tab.

Variable	Mapping	Channel	Address	Type	Current Value
drive1_PS1_In1		ABB_PS1 In0	%IW2.6	UINT	0
drive1_PS1_In2		ABB_PS1 In1	%IW2.7	UINT	136
drive1_PS1_In3		ABB_PS1 In2	%IW2.8	UINT	40
drive1_VarSLS_ac...		Variable SLS active	%DX2.16.0	BOOL	FALSE
drive1_POUS_acti...		POUS active	%DX2.16.1	BOOL	FALSE
drive1_Out_x114_9		Safe output x114 9	%DX2.16.2	BOOL	FALSE
drive1_Out_x114_8		Safe output x114 8	%DX2.16.3	BOOL	FALSE
drive1_Out_x114_7		Safe output x114 7	%DX2.16.4	BOOL	FALSE
drive1_Out_x113_9		Safe output x113 9	%DX2.16.5	BOOL	FALSE
drive1_Out_x113_8		Safe output x113 8	%DX2.16.6	BOOL	FALSE
drive1_Out_x113_7		Safe output x113 7	%DX2.16.7	BOOL	FALSE
drive1_SF_end_a...		SF end ack req	%DX2.17.0	BOOL	FALSE
drive1_SF_end_a...		SF end ack req logical	%DX2.17.1	BOOL	FALSE
drive1_STO_contr...		STO control active	%DX2.17.2	BOOL	FALSE
drive1_Speed_vali...		Speed value valid	%DX2.17.3	BOOL	TRUE
drive1_FSO_state		FSO state	%DX2.17.4	BOOL	FALSE
drive1_FSO_model0		FSO model0	%DX2.17.5	BOOL	TRUE
drive1_FSO_model1		FSO model1	%DX2.17.6	BOOL	FALSE
drive1_Modulating		Modulating	%DX2.17.7	BOOL	FALSE
drive1_PS_Safe_Speed		ABB_PS1 In Safe Speed	%IW2.9	INT	0
		PROFIsafe F Message trailer	%IB2.20		
drive1_PS1_Out1		ABB_PS1 Out0	%QW2.6	UINT	0
drive1_PS1_Out2		ABB_PS1 Out1	%QW2.7	UINT	0
drive1_PS_var_SLS...		ABB_PS1 Out VarSLSLimit	%QW2.8	INT	0
		PROFIsafe F Message trailer	%QB2.18		


■ Configuring the Siemens SIMATIC Fail-safe S7 PLC

This example shows how to configure the communication between the Siemens SIMATIC Fail-safe S7 PLC and the FENA-21 adapter module using SIMATIC Manager Step 7 (version V5.5+SP2) and S7 Distributed Safety Programming (version V5.4+SP5).

For detailed configuration instructions, refer to the documentation of the safety PLC (S7 Distributed Safety - configuring and programming, Programming and Operating Manual, 07/2013, A5E00109537-05).


Before you start, make sure that you have downloaded the FENA GSD file from the ABB Document library. Refer to section [Downloading the GSD file](#) on page 164.

1. Start SIMATIC Manager and open/create a SIMATIC project.
2. Add the necessary objects to the project.
In this example, a SIMATIC 300 Station and an Industrial Ethernet object have been added.




3. Open the hardware configuration of the project.
4. Select the controller station and rail from the catalog and drag them to the project.

This example project uses a CPU 319F-3 controller station (V2.8) that is installed in a RACK-300 Rail.




- When you install the controller station to the rail, select Industrial Ethernet as the subnet for the controller station.




- Install the FENA GSD file:
 - In the **Options** menu, select **Install GSD Files**.
 - Browse for the GSD file that you downloaded from the ABB Document library.
 - Click **Install**.

Note: In some versions of the SIMATIC environment, you have to close the whole SIMATIC program and open it again to make the new GSD file visible in the object catalogue.



7. Click and drag the FENA object from the device catalog to the Ethernet (1): PROFINET-IO-System.
8. Click and drag the desired I/O object, for example PPO Type 4, to the first slot of the FENA module to define cyclic standard communication between the module and the PLC.
9. Click and drag the PROFIsafe object PROFIsafe ABB_PS1 to the second slot of the FENA module to define cyclic safety communication between the


module and the PLC.



10. Double-click **FENA** to open the **Properties** window.

11. On the **General** tab, type the Device name for the adapter module (in this

example, drive1).




Note: Do not change the IP address assigned here. Use the same IP address for the FENA adapter module also in other tools (eg, the Drive Composer pro PC tool) which you use to connect to the drive.


12. Click **OK**.

13. In the hardware configuration, double-click the I/O object (PPO Type 4) in Slot 1 to open the **Properties** window.

14. Type a name for the I/O object (in this example, PROFIsafe ABB_PS1).




15. On the **Parameters** tab, configure the Stop mode and Control-zero mode functions, and define Fail safe values for the PLC output process data (PZDs).



16. Assign the device name (defined in step 11) to the adapter module:

- In the hardware configuration, click **FENA**.
- In the **PLC** menu, select **Ethernet**, and select **Assign Device Name**.
- Click the **Update** button.


- Click the available device with the correct MAC address to which the device name will be assigned.
- Click **Assign name**. This assigns the name to the FENA module.
- Click **Close**.



17. Check F-Parameters for the controller:

- In the hardware configuration, double-click the controller station (for example, CPU 319F-3).
- Select the **F Parameters** tab.
- When prompted, give the password for the Safety Program. See the documentation of the SIMATIC system for details.

- Make the necessary changes and click **OK**.




18. Set F-Parameters of the FENA module:

- In the hardware configuration, double-click **PROFIsafe ABB_PS1** to open the **Properties** window.
- On the **PROFIsafe** tab, modify the F_Dest_Add and F_WD_Time values as needed.
- F_Source_Add is the address of the safety controller station. You can modify this in the **host F Parameters** tab.
- F_Dest_Add is the address of the FENA module. This is defined by FSO parameter **PROFIsafe.11**, see section [Configuring the safety fieldbus communication](#) on page 245.


These two define the codename for the PROFIsafe relationship of this particular FENA module and the safety controller station.

- F_WD_Time is the PROFIsafe watchdog time. See section [Calculating the watchdog time](#) on page 160 for instructions on how to calculate the correct watchdog time.



19. If necessary, you can give proper symbol names to the cyclic data:

- Right-click the I/O object (PPO Type 4) in Slot 1 and select **Edit Symbols...**
- Add names for the symbols.
- Repeat the same for the PROFIsafe object (PROFIsafe ABB_PS1) in Slot 2.




Note: In PROFINET communication, the bits of each octet are sent the most significant bit first. Therefore, the bits of every octet in the PROFINET message are in reversed order compared to the bits shown in the figure. For

example, the first bit that is sent in the PROFINET message is the 7th bit of the first octet (I 0.7).

20. Check the protection of the controller station:

- In the hardware configuration, double-click the controller station (for example, CPU 319F-3).
- Select **Protection** tab.
- Select **1: Access protect. for F CPU**.
- Check **Can be bypassed with password**.
- Enter the password twice to the edit boxes.
- Check **CPU contains safety program**.



21. Save, compile and download the hardware configuration to the PLC.

The PLC is now ready for communication with the FENA adapter module.


Configuring the communication when there is no safety program

If there is no safety program in the project, these instructions can help you to get the communication working.




WARNING! Do not use this safety program in real safety applications. This safety program is only an example which you can use only for trial purposes to get the system up and running.

1. In SIMATIC Manager, right-click on the **Blocks** folder of the S7 Program of the project.
2. Select **Insert New Object**, and add the following blocks to the program:
 - Organization Block OB35 to call the safety program cyclically.
 - Function Block FB1 using F-FBD language.
 - Function FC1 using F-CALL language.




3. Double-click on the **FC1** block.
4. Set DB1 as the I-DB for the F-program block and FB1 as the F-program block.

5. Click **OK** and close the dialog windows.




- 6. In SIMATIC manager, double-click on **OB35**.
- 7. Add call to FC1 by dragging the FC1 block from the FC blocks folder.
- 8. Save the block and close the editor.



- 9. In SIMATIC manager, double-click on **FB1**.
- 10. Add acknowledgement for reintegration by assigning the value of ACK_REQ to ACK_REI in DB2185.

11. Save the block and close the editor.




Note: This example program also keeps the SLS3 function active all the time.

12. In SIMATIC Manager, select **Edit safety program** from the **Options** menu.
13. Select **Compile**.
14. Select **Download**. If prompted, accept the inclusion of standard blocks.
15. Switch the controller station to run mode.

Monitoring the PROFIsafe message

It is possible to monitor the contents of the PROFIsafe message. For example:


1. In HW Configuration, select **Monitor/Modify** for the PROFIsafe telegram in Slot 2 of the FENA module.




■ Configuring Siemens S7-1200 PLC with TIA14

This example can be done with FENA-21 or FPNO-21 adapter modules.


1. Open TIA14 and create a new project.




2. Select your CPU from the list.




3. Install the FENA-21 GSDML file.




4. Add FENA-21 to the device configuration by dragging it from the hardware catalog.





5. Open the FENA-21 device view and add (by dragging and dropping) the desired PPO and PS telegrams to slot 1 and 2. In this example, we use PPO7 and PS2 (Additional info in manuals).




6. **Network view** shows E-stop icon on the FENA device to indicate that device has safety I/O.



7. Assign FENA-21 to PROFINET controller.




- Network configuration is updated.




- I/O addressing is assigned automatically to FENA. This can be seen in


Device view (highlighted with a red box in the image below).




8. Select PLC from network view and Properties will show on the bottom of the screen. In PLC properties, enable F-capability (safety and PROFIsafe) under the **Fail-safe** submenu.




9. In the **F-parameters** submenu, define the maximum allowed safety program execution interval. If this value is exceeded, PROFIsafe goes to safe state (watchdog).




10. In **Ethernet addresses** submenu, set the PLC IP address.



11. In **Advanced options**, set PLC minimum cycle time for I/O and PROFINET communication (PROFINET cycle time).




12. For testing purposes, you can disable the PLC password. Remember to enable the PLC password after you have done the validation.




13. In FENA properties, set the FENA-21 IP address and PROFINET device name. The device name will be used as identification. After successful identification, PLC will assign IP address to FENA.

Note: FB module parameters (51.04 onwards) should be static 0.0.0.0 in the drive.




14. Configure FENA ABB PS PROFIsafe settings:


- F_Source_Add = PLC PROFIsafe address
- F_Dest_Add = FSO PROFIsafe address
- F_WD_Time = Maximum allowed PROFIsafe message cycle time. In this example, we use 200 ms.



15. Add OB86 (Rack or station failure) program block to prevent PLC from stopping on I/O error.



16. Add new Function block “ABB_Drive”.




17. Add variables to ABB_Drive FB.

ACS880 FENA-21 PROFIsafe ▶ PLC_1 [CPU 1212FC DC/DC/RLY] ▶ Program blocks ▶ ABB_Drive [FB2]

ABB_Drive								
	Name	Data type	Default value	Retain	Accessible f...	Writa...	Visible in ...	Setpoint
1	▼ Input							
2	Drive PPO HWADDR FB	HW_SUBMODULE	0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
3	▼ Output							
4	◀Add new>							
5	▼ InOut							
6	◀Add new>							
7	▼ Static							
8	PZD read error	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
9	PZD write error	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
10	▼ PPO OUT	Struct		Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
11	PZD OUT_1	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
12	PZD OUT_2	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
13	PZD OUT_3	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
14	PZD OUT_4	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
15	PZD OUT_5	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
16	PZD OUT_6	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
17	PZD OUT_7	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
18	PZD OUT_8	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
19	PZD OUT_9	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
20	PZD OUT_10	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
21	PZD OUT_11	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
22	PZD OUT_12	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
23	◀Add new>							
24	▼ PPO IN	Struct		Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
25	PZD IN_1	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
26	PZD IN_2	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
27	PZD IN_3	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
28	PZD IN_4	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
29	PZD IN_5	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
30	PZD IN_6	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
31	PZD IN_7	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
32	PZD IN_8	Word	16#0	Non-ret...	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
33	PZD IN_9	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
34	PZD IN_10	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
35	PZD IN_11	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>
36	PZD IN_12	Word	16#0	Non-retain	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>

18. Add ABB_Drive FB to OB1. Assign new instance Data Block for ABB_Drive FB.
When using multiple drives, create one DB for each drive.

Call options



DB
Single instance

Data block

Name

ABB_Drive1_DB

Number

2

☐ Manual

☒ Automatic

If you call the function block as a single instance, the function block saves its data in its own instance data block.

more...

OK

Cancel

19. Select the corresponding FENA PPO address for the drive HW input.

Network 1:

Comment

%DB2

ABB_Drive1_DB

%FB2

ABB_Drive

... EN

Drive PPO

FENA

HW ADDR FB

ENO

FENA-Head	Hw_SubModule				
FENA-Interface	Hw_Interface				
FENA-Interface-Port_1	Hw_Interface				
FENA-Interface-Port_2	Hw_Interface				
FENA-PPO_Type_7_1	Hw_SubModule				
FENA-PROFIsafe_ABB_PS2_1	Hw_SubModule				
FENA-Proxy	Hw_SubModule				

Network 1:

Comment

%DB2

ABB_Drive1_DB

%FB2

ABB_Drive

... EN

Drive PPO

277

FENA-PPO_Type_7_1

HW ADDR FB

ENO


The value can be verified from the HW configuration, in the FENA PPO type properties, under the **Hardware Identifier** tab.

The screenshot displays the configuration interface for an ACS880 FENA-21 PROFIsafe device. The main window shows a graphical representation of the device with a label 'FENA' and an ABB logo. The right-hand pane, titled 'Device overview', contains a table listing the modules and their rack and slot positions.


Module	Rack	Slot	I ad...
FENA	0	0	
Interface	0	0 X1	
PPO Type 7_1	0	1	68...
PROFIsafe ABB_PS2_1	0	2	1.....

The bottom pane shows the 'Properties' window for 'PPO Type 7_1 [PPO Type 7]'. The 'Hardware identifier' tab is selected, displaying the 'Hardware identifier' field with the value '277'.

20. In ABB_Drive FB, add blocks DPRD_DAT and DPWR_DAT.



21. Insert values to blocks.



Later the PPO message data can be found in ABB_Drive1_DB.

The screenshot shows the SIMATIC Manager interface with the project tree on the left and the 'ABB_Drive1_DB' data table on the right. The project tree is expanded to 'Safety Administration' > 'Program blocks' > 'ABB_Drive1_DB [DB2]'. The data table has the following columns: Name, Data type, Start value, Retain, Accessible f..., Writ..., Visible in..., and Setpoint.

Name	Data type	Start value	Retain	Accessible f...	Writ...	Visible in...	Setpoint
1 Input							
2 Drive PPO HW ADDR FB	HW_SUBMODULE	0					
3 Output							
4 InOut							
5 Static							
6 PZD read error	Word	16#0					
7 PZD write error	Word	16#0					
8 PPO OUT	Struct						
9 PZD OUT_1	Word	16#0					
10 PZD OUT_2	Word	16#0					
11 PZD OUT_3	Word	16#0					
12 PZD OUT_4	Word	16#0					
13 PZD OUT_5	Word	16#0					
14 PZD OUT_6	Word	16#0					
15 PZD OUT_7	Word	16#0					
16 PZD OUT_8	Word	16#0					
17 PZD OUT_9	Word	16#0					
18 PZD OUT_10	Word	16#0					
19 PZD OUT_11	Word	16#0					
20 PZD OUT_12	Word	16#0					
21 PPO IN	Struct						
22 PZD IN_1	Word	16#0					
23 PZD IN_2	Word	16#0					
24 PZD IN_3	Word	16#0					
25 PZD IN_4	Word	16#0					
26 PZD IN_5	Word	16#0					
27 PZD IN_6	Word	16#0					
28 PZD IN_7	Word	16#0					
29 PZD IN_8	Word	16#0					
30 PZD IN_9	Word	16#0					
31 PZD IN_10	Word	16#0					
32 PZD IN_11	Word	16#0					
33 PZD IN_12	Word	16#0					

22. In PLC **Safety Administration**, configure F-runtime group cycle time, warn and maximum cycle time limits. If maximum limit is exceeded, PLC will go to safe state.

The screenshot shows the SIMATIC Manager interface with the project tree on the left and the 'Safety Administration' > 'F-runtime group 1 [RTG1]' configuration window on the right. The configuration window has the following sections:

- General:** F-runtime group 1 [RTG1], F-blocks, F-compilant PLC data types, Access protection, Web server F-Admins, Settings.
- Add F-runtime group:** An F-runtime group consists of an F-OB (cycle OB or cyclic interrupt OB) that calls a main safety block (FB or FC). Additional user-specific safety functions must then be called from this main safety block. [More...](#)
- F-runtime group 1 [RTG1]:**
 - Fail-safe organization block:** Name: FOB_RTG1, Event class: Cyclic interrupt, Number: 123, Cycle time: 100 ms, Phase shift: 0 ms, Priority: 9. A 'calls' arrow points to the 'Main safety block'.
 - Main safety block:** Main_Safety_RTG1 [FB1].
 - F-runtime group parameters:**
 - Warn cycle time of the F-runtime group: 110 ms
 - Maximum cycle time of the F-runtime group: 120 ms
 - DB for F-runtime group communication: (None)
 - F-runtime group information DB: RTG15pInfo

23. Create tag table for ABB_PS2 safety functions. See bit descriptions from FSO PROFIsafe profiles (Chapter 6). See correct I/O addresses from HW configuration.

Device overview

Module	Rack	Slot	I address	Q address	Type
FENA	0	0			FENA-21
Interface	0	0 X1			FENA
PPO Type 7_1	0	1	68...91	64...87	PPO Type 7
PROFIsafe ABB_PS2_1	0	2	1...14	1...10	PROFIsafe ABB_PS2

Project tree

ACS880 FENA-21 PROFIsafe ▶ PLC_1 [CPU 1212FC DC/DC/RLY] ▶ PLC

Devices

PLC tags

Show all tags

Add new tag table

Default tag table [40]

Drive1 ABB PS2 [105]

PLC data types

Watch and force tables

Online backups

Traces

Device proxy data

Program info

PLC alarm text lists

Local modules

Distributed I/O

Drive1 ABB PS2

	Name	Data type	Address
1	Drive1_SLS2_active	Bool	%I1.0
2	Drive1_SLS1_active	Bool	%I1.1
3	Drive1_Tag_3	Bool	%I1.2
4	Drive1_Tag_4	Bool	%I1.3
5	Drive1_SS1_active	Bool	%I1.4
6	Drive1_SSE_active	Bool	%I1.5
7	Drive1_SBC_active	Bool	%I1.6
8	Drive1_STO_active	Bool	%I1.7
9	Drive1_Tag_9	Bool	%I2.0
10	Drive1_Tag_10	Bool	%I2.1
11	Drive1_Tag_11	Bool	%I2.2
12	Drive1_Tag_12	Bool	%I2.3
13	Drive1_SAR1_active	Bool	%I2.4

24. Save and download project to PLC.

Siemens - C:\User\OnSite\2017\2017 Expertdays fieldbus training\ACS880_Profinet_TIA_P

Project Edit View Insert Online Options Tools Window Help

Save project

Download

Project tree

ACS880 FENA-21 PROFIsafe ▶ PLC_1

Devices

ACS880 FENA-21 PROFIsafe

Add new device

Devices & networks

PLC_1 [CPU 1212FC DC/DC/RLY]

Main_Safety_RTG1

Name


Data ty

& >= 1 ? ? - -o| -> [-=]


Block title:

25. Scan for accessible devices (start search). Note that a firewall can block

traffic.




26. In device configuration, right-click FENA icon and select **Assign device name**.



27. Select update list and identify the correct FENA-based on MAC ID label. Click **Assign name**.

Note: The MAC ID can be found on the cover of the FB module.



The PLC will assign a name and IP address to the selected FENA and drive parameter group 51 values will update accordingly.

51. FBA A settings			
1	FBA A type	Ethernet	NoUnit
2	Protocol/Profile	PNIO ABB Pro	NoUnit
3	Commrate	Auto	NoUnit
4	IP configuration	Temp IP	NoUnit
5	IP address 1	192	NoUnit
6	IP address 2	168	NoUnit
7	IP address 3	11	NoUnit
8	IP address 4	2	NoUnit
9	Subnet CIDR	24	NoUnit
10	GW address 1	192	NoUnit
11	GW address 2	168	NoUnit
12	GW address 3	11	NoUnit
13	GW address 4	2	NoUnit

Fault tracing

■ Reading diagnostic messages

You can read the PROFIsafe diagnostics messages from:

1. the Event logger of the Drive Composer pro PC tool,
2. the Event log of the ACS-AP-x assistant control panel and
3. the error buffers of the PLC system. In this case, make sure that drive parameter 51.21 is set to Enabled.

ABB AC500-S

In the ABB AC500-S system, you can read PROFINET diagnostics messages from Control Builder Plus or with a separate PNIO_DEV_DIAG function block in the “non-safety” PLC program.


To read the alarm data of the last active alarm from Control Builder Plus:

1. Select **FENA_21**.
 2. On the **Diagnostics for Profinet slave** tab, select **Refresh** to read diagnostics messages.
-


SIMATIC Manager

To read diagnostics messages:


- 1. In the **PLC** menu, select **Diagnostic/Setting**.
- 2. Select **Hardware diagnostics**.
- 3. In the window that opens, select the FENA module of your system.
- 4. Click the **Module Information** button.



5. To read the diagnostic messages, select the **I/O Device Diagnostics** tab.



6. To check the Device number of the FENA module, select the **General** tab.



■ **Diagnostic messages related to F-Parameters**

The diagnostics messages in this table are caused by problems in the F-Parameter processing that takes place only when the controller station sends the F-Parameters to FB module. This happens normally only when the controller station starts up the PROFINET communication with the FB module.

Value (hex)	Description	Notes
64 (0x0040)	Mismatch of safety destination address (F_Dest_Add).	F_Dest_Add did not match the value configured in the safety parameters (PROFIsafe.11 PROFIsafe F_Dest_Add).
65 (0x0041)	Safety destination address is not valid (F_Dest_Add).	F_Dest_Add of 0 or FFFFh is not allowed. A valid F_Dest_Add is within range 1...65534.
66 (0x0042)	Safety source address is not valid (F_Source_Add).	F_Source_Add of 0 or FFFFh is not allowed. A valid F_Source_Add is within range 1...65534.

Value (hex)	Description	Notes
67 (0x0043)	Safety watchdog time value is 0 ms (F_WD_Time).	Watchdog time 0 ms is not allowed. A valid F_WD_Time is within range 1...65535.
68 (0x0044)	Parameter "F_SIL" exceeds SIL from specific device application.	F_SIL defined for this device at F-Host is not correct. This device supports only F_SIL = 3.
69 (0x0045)	Parameter "F_CRC_Length" does not match the generated values.	F-Parameter checksum length different from 3 octets. This device supports only three (3) octet CRC2.
70 (0x0046)	Parameter "F_Par_Version" set incorrectly.	Version of F-Parameter defined for this device at F-Host is not correct. This device supports only V2.
71 (0x0047)	CRC1 Fault	Checksum CRC1 calculated over the F-Parameters does not match the checksum value in the F-Parameters.
72 (0x0048)	Device-specific diagnosis information	Unsupported PROFINET submodule identification number received from the controller station upon PROFINET connection, or general error in the F-Parameters.

■ Typical communication errors

This table lists some typical error situations in the PROFINET and PROFIsafe communication.

Fault	Cause	What to do
You cannot start the PROFINET communication.	The FB module station name saved in the FB module does not match the station name of the FB module in the PLC configuration.	Check the station names in both places.
	The FB module IP address saved in the FB module does not match the IP address of the FB module in the PLC configuration.	Check the IP settings in both places.
	The FB module is not configured for the PROFINET communication.	Check drive parameter 51.01 or 54.01. See the FB module user's manual for details.

Fault	Cause	What to do
You cannot start the PROFIsafe communication.	The drive safety parameters are not set correctly.	In the ACS880 drives, check the values of parameters 200.222 Safety bus type and 200.223 Safety fieldbus adapter slot . See section How to configure the safety communication with PROFIsafe on page 245 for details.
	The PROFIsafe destination address of the FB module does not match the station name of the FB module in the PLC configuration.	In the ACS880 drives, check the value of parameter PROFIsafe.11 PROFIsafe F_Dest_Add . See section How to configure the safety communication with PROFIsafe on page 245 for details.
PROFIsafe communication watchdog time exceeds often.	The watchdog time is too short.	Calculate a new watchdog time. See section Calculating the watchdog time on page 160.
All errors solved but you still cannot start the PROFIsafe communication.	After you have modified the configuration of the safety devices, you may have to reboot the whole system before the changes take effect.	<p>Reboot the safety PLC.</p> <p>If this does not help, reboot also the FSO module, the FB module and the drive.</p> <p>To reboot the FSO module:</p> <ul style="list-style-type: none"> • switch the power off and on, or • use drive parameter 96.09 FSO reboot. <p>To reboot the FB module:</p> <ul style="list-style-type: none"> • switch the power off and on, or • use drive parameter FBA A/B PAR REFRESH (parameter 51.27/54.27, refer to the drive firmware manual). <p>To reboot the drive:</p> <ul style="list-style-type: none"> • switch the power off and on, or • use drive parameter Control board boot (parameter 96.08, refer to the drive firmware manual).

7

Planning for installation

Contents of this chapter

This chapter gives instructions and references to instructions in other manuals for planning the safety system installation, as well as the requirements for installation in the applicable safety standards.

Requirements for designers and installers

- Designers and installers must be trained to understand the requirements and principles of designing and installing safety-related systems.
- Designers and maintainers must be trained to understand the causes and consequences of Common Cause Failures (CCF). See the checklist for the appropriate standard in section [Checklists](#) on page 237.

Mechanical installation

■ Installation site

The subsystem elements must always be likely to operate in the range of temperature, humidity, corrosion, dust, vibration, etc. for which they are specified, without the use of external environmental control. For the environmental requirements for the FSO module, refer to section [Ambient conditions](#) on page 409.

Use the FSO module only in an environment where there are no conductive dust or contaminants. To make sure that there is sufficient protection against contamination, you can install the FSO module into an enclosure that has a rating of IP54 or higher. For more information on environmental limits, refer to chapter **Planning the mechanical installation** in the drive hardware manual.



WARNING! Do not operate a safety module in environmental conditions that are outside of the limits given in the technical data of the safety module. Environmental conditions that are outside of the specified limits can cause a malfunction in the module and a subsequent loss of a safety function.

Electrical installation

■ General requirements

Electrical installation of the safety system must be done according to the practices outlined in chapter **Planning the electrical installation** in the drive hardware manual.

Chapter [Installation checklists](#) provides additional advice for the planning.

All wiring must be sufficiently protected, and routed and clamped where necessary.

When installing cabling, it must be made sure that there is no pulling or pinching on the cables.

■ Connections


Inputs and outputs

To design the safety system architecture and select components to be used, it is essential to read and understand the different architecture options (for example single channel / redundancy).

Single inputs can be connected to any terminal X113:1...4 or X114:1...4.

Redundant inputs must be connected so that one input is connected to X113:n, and the other is connected to X114:n (n= 1...4; the same for both inputs).

Use diagnostic pulse TP1 (X113:10) for the X113 inputs and TP2 (X114:10) for the X114 inputs.



Note: You can use calculation software to help in selecting the architecture that will meet the safety integrity requirements for a particular application. Use, for example, ABB's Functional safety design tool. For more information, refer to [Functional safety design tool user's manual \(3AXD10000102417 \[English\]\)](#).

■ STO cable and data cable between FSO module and drive

For the specifications, refer to section [STO cable and data cable between FSO module and drive](#) on page 408.

■ Power supply connection

For the power supply specifications, refer to chapter [Technical data](#).

Obey these requirements for the power supply connection of the FSO module:

- the system must be protected against overvoltage and overcurrent.
- the length of the cabling between the FSO and its power supply must be 3 m (9.8 ft) or less, or a sufficiently low interference level must be otherwise guaranteed.

To make it easy to energize and de-energize the FSO module, ABB recommends that you install a supply disconnecting device for the FSO power supply.

To prevent unnecessary fault indications, ABB recommends that you:

- energize the drive control unit and FSO module simultaneously during power-up
- de-energize the FSO module after the drive control unit during power-down.

Note: The FSO module power input (X112) is protected against overvoltage, undervoltage and overcurrent, and it has a reverse polarity protection. The FSO module goes into Fail-safe mode if one or more of these protections trip. The module goes into Fail-safe mode also if output voltages of the internal power

supply are outside the specified limits (caused by, for example, overvoltage in the supply input).

Note: If you de-energize the FSO module, you cannot operate the drive.

■ Ensuring the EMC compatibility

The system must only be used in the EMC environment it is designed for, or necessary mitigations must be applied.

■ Selecting control cables

All control cables must be shielded. Use double-shielded twisted pair cable for low voltage digital signals (control cables to on-field devices). An alternative solution is to use single-shielded twisted multi-pair cable.

Refer to section [Control connection data](#) on page 406 and chapter **Planning the electrical installation** in the drive hardware manual.

■ Routing the cables

Refer to chapter **Planning the electrical installation** in the drive hardware manual. Obey especially these rules:


- When using redundant signaling, take care to avoid common cause failures in the cables. This can be done by routing the two channels through two well-apart routes, or by protecting the cabling appropriately, for example by using double-shielded cables.
 - Do not mix 24V-level signals with non-ELV-signals or power feeds in the same cable.
 - Safety-related control system (SCS) signal cables for the individual channels must be routed separately from the other channels at all positions or sufficiently shielded.
 - Safety-related control system (SCS) signal and electrical energy power cables must be separated at all positions or sufficiently shielded.
 - Cross-connection between the channels of the subsystem must be prevented.
 - Signal paths must be physically separated (for example, separation in wiring).
-

■ Standard function and wiring examples

Passive switch

Examples:


- Limit switch
- Emergency stop button



Relay / contactor output with feedback

Examples:

- Brake control
- Door/gate unlock




Safe brake control (SBC)

In the figure below normal and safe brake controls are connected in series. Both are independent and redundant 2-channel solutions.

The safe brake control must have a feedback from the brake system. The SBC feedback can be from a relay/contactor or from the mechanical brake itself.

If an inductive load is connected to the digital outputs on the FSO module, it is recommended to use a flyback diode in the circuit.


Note: If the drive can control the brake also, the feedback must not be from the mechanical brake.



Active sensors / input signals from solid state devices

Examples:


- PLC 24 V DC PNP
- Light curtain OSSD



Outputs to solid state devices


Example:

- PLC 24 V DC NPN



Cascade

Example:



8

Installation

Contents of this chapter

This chapter gives examples of how to connect the FSO module to the ACS880 drive.




WARNING! Connect the FSO module to a 24 V DC power supply. If you connect it to a power supply with a higher voltage (for example, 115 V or 230 V), it will cause damage to the module. If this occurs, the module must be replaced.



Unpacking

If you have ordered the FSO module option separately, it is delivered in its own package. The package contains these items:

- FSO-12 module. The default mounting plate for ZCU-12 control unit is attached to the module. (1)
- connector plugs and attachment screws (2)
- FSO data cable, 85 mm (3)
- FSO data cable, 220 mm (4)
- FSO data cable for UCU-22, -23, and -24 control units, 223 mm (5)
- STO cable, 220 mm (6)
- STO cable, 400 mm (7)
- connector for the power supply wires (8)
- mounting plate for ZCU-14 control unit (9)
- mounting plate for UCU-22, -23, and -24 control units (10)
- user's manual (11).



Examining the delivery

Make sure that all parts are in the package and that there are no signs of damage. Notify the shipper immediately if you find damaged parts. Do not use damaged parts, they must be replaced.

Make sure that the FSO module is of the correct type. Refer to section [Type designation label](#) on page 41.

Mechanical installation

If you have ordered the FSO module option with the drive, it is delivered with the FSO already installed and the FSO data cable connected. In this case, continue with section [Electrical installation](#) on page 231.

If you have ordered the FSO module option separately, it is delivered in its own package and you must install it to the drive control unit.

Do not install the FSO module on a FEA-03 F-series extension adapter, or onto an USCA-02 slot adapter.

If necessary, remove the default mounting plate from the FSO module and replace it with the other mounting plate in the package.

You can install the FSO module:

- onto the control unit, or
- adjacent to the control unit.

If you do not install the module directly onto the control unit, make sure that the module is correctly grounded. For the requirements of the STO cable and data cable, refer to section [STO cable and data cable between FSO module and drive](#) on page 408.



■ Installing the module onto a BCU control unit

Install the FSO mechanically onto the control unit as described in the drive or inverter unit hardware manual, or [BCU-02, BCU-12 and BCU-22 control units hardware manual \(3AUA0000113605 \[English\]\)](#). For the tightening torques, refer to section [Tightening torques](#) on page 408.


■ Installing the module onto a UCU control unit

Install the FSO mechanically onto the control unit as described in the drive or inverter unit hardware manual, or [UCU-22, UCU-23 and UCU-24 control units hardware manual \(3AXD50000817726 \[English\]\)](#). Use the adapter included in the FSO module package. For the tightening torques, refer to section [Tightening torques](#) on page 408. Do not install the FSO module onto an USCA-02 slot adapter.

■ **Installing the module onto a ZCU control unit**

Install the FSO mechanically onto the control unit as described in the drive hardware manual. For the tightening torques, refer to [Tightening torques](#) on page 408.


Examples are shown below:



Electrical installation

■ Terminals

The connections are shown in the figure below.



A	Electronics grounding screw
B	Enclosure grounding screw, at any of the mounting points, depending on the installation type

X110:		
	DATA	Data connection to the drive control unit

X111:		
1	STO	STO 24 V
2	STO	STO ground
3	STO	STO1LO drive internal signal
4	STO	STO2LO drive internal signal

X112:		
1	POWER	24 V
2	POWER	0 V

X113:		
1	DI	Channel 1 digital input 1
2	DI	Channel 1 digital input 2
3	DI	Channel 1 digital input 3
4	DI	Channel 1 digital input 4
5	GND	Signal ground
6	GND	Signal ground
7	DO	Channel 1 digital output 1
8	DO	Channel 1 digital output 2
9	DO	Channel 1 digital output 3
10	TP	Channel 1 test pulse out

X114:		
1	DI	Channel 2 digital input 1
2	DI	Channel 2 digital input 2
3	DI	Channel 2 digital input 3
4	DI	Channel 2 digital input 4
5	GND	Signal ground
6	GND	Signal ground
7	DO	Channel 2 digital output 1
8	DO	Channel 2 digital output 2
9	DO	Channel 2 digital output 3
10	TP	Channel 2 test pulse out



Note: The signal grounds (X113:5, X113:6, X114:5, X114:6) cannot be used for grounding the cable shields.

■ Connection procedure



WARNING! Obey the safety instructions. See chapter [Safety instructions](#) on page 13. If you ignore them, injury or death can occur.

1. Stop the drive and do the steps in section [Electrical safety precautions](#) on page 14 before you start the work.
2. Make sure that the FSO electronics grounding screw is correctly tightened. Refer to section [Tightening torques](#) on page 408.
3. Make sure that the enclosure grounding screw is correctly tightened. Refer to section [Tightening torques](#) on page 408.





4. Make sure that the FSO data cable (terminal X110) is connected to the drive. Use only the cable delivered with the module.





5. Connect the supplied four-wire cable to FSO terminal X111. Connect the other end of the cable to the drive STO connection (XSTO connector). ABB recommends that you use the cable delivered with the FSO module. For the specifications for a customer-defined cable, refer to section [STO cable and data cable between FSO module and drive](#) on page 408.



6. Connect the digital inputs, digital outputs, diagnostic pulses and signal ground at the FSO terminals X113 and X114 according to the application requirements.
 - Use a tightening torque of 0.24 Nm (2.1 lbf-in).
 - Use proper cable strain relief.
 - Use only the I/O terminal blocks attached to the FSO module.
 - Make sure that the ground terminal maximum current is not exceeded. For the maximum current, refer to section [Control connection data](#) on page 406.



7. Connect the power supply wires to the FSO terminal X112. Use a tightening torque of 0.24 Nm (2.1 lbf·in) for the FSO terminals. Use proper cable strain relief. See also section [Power supply connection](#) on page 221.





9

Installation checklists

Contents of this chapter

This chapter contains a checklist for checking the mechanical and electrical installation of the FSO module and refers to common cause failure checklists in standards.

Checklists



WARNING! Obey the safety instructions given in chapter [Safety instructions](#). If you ignore them, injury or death, or damage to the equipment can occur.

Before you start up the FSO module, make sure that the mechanical and electrical installation is completed. Use the checklists given in this chapter. Examine the installation together with another person.

Stop the drive and do the steps in section [Electrical safety precautions](#) on page [14](#) before you start the work.

For more information on how to do the tasks given in the checklist, refer to chapters [Planning for installation](#) and [Installation](#).

Make sure that ...	
Mechanical installation	
<input type="checkbox"/>	The ambient operating conditions are within the permitted range.
<input type="checkbox"/>	<u>Drives with separate inverter and supply units</u> : The FSO module is installed in the inverter unit.
<input type="checkbox"/>	The FSO module is correctly attached and the grounding screw is correctly tightened.
<input type="checkbox"/>	The FSO data cable and STO cable are correctly installed and connected.
<input type="checkbox"/>	Packing materials and tools are removed from the installation area.
Electrical installation	
<input type="checkbox"/>	If a PELV power supply is used, its ground is in the same potential as the drive ground.
<input type="checkbox"/>	Correct supply (input power) fuses are installed.
<input type="checkbox"/>	The data cable between the drive and the FSO module is routed separately from high power cables (for example, drive input power and motor cabling).
<input type="checkbox"/>	I/O wiring is correctly clamped, marked, tightened and protected.
<input type="checkbox"/>	24 V DC power supply is correctly connected and secured with strain relief, and the polarity of the supply voltage connection is correct.
<input type="checkbox"/>	The FSO electronics grounding screw is correctly tightened.

10

Configuration

Contents of this chapter

This chapter describes the password usage, outlines the configuration process and gives examples of how to configure the FSO module to implement each safety function as described in chapter [Safety functions](#).

Competence

The person who configures the safety functions in the FSO module must be a competent person as required by IEC 61508-1 clause 6. In this context, the person must have adequate expertise and knowledge of functional safety, the safety functions as well as the configuration of the FSO module. ABB has training courses available on the FSO module.

Password


You need a password to be able to upload the parameters from the FSO and download the modified parameters from your PC to the FSO and the drive.

The password is set to “12345678” at the factory. The password must contain 4...8 digits. When you change it, make sure that you do not forget the new password. If you forget the password, you must do a factory reset to the FSO module, which clears the configuration and resets the parameters to the factory defaults. The password is reset to the default “12345678”.

Configuring the FSO module

■ Overview - safety system configuring process

The diagram and table below explain the main phases of the safety system configuring process.



No.	Phase
1. & 2.	Risk assessment & Safety requirements <ul style="list-style-type: none"> • analysis and evaluating of the risks • need for risk reduction • required PL or SIL level • speed limits and distances for safety functions.
3.	Planning of the configuration of the FSO How to do the safety configuration in a safe way, including configuration, commissioning, validation and verification.
4.	Design of the safety functions Selected safety functions and related parameter settings must be based on the risk assessment and the safety requirements of the application. For example: <ul style="list-style-type: none"> • safely limited speed (SLS) trip limits • settings of I/O's • selection of the stopping function • diagnostics and fault reaction, etc.
5.	Commissioning of the FSO <ul style="list-style-type: none"> • configuring and fine tuning of the safety parameters of the FSO module • commissioning of the PROFIsafe connection to the safety PLC • electrical installation, etc.
6.	Validation of the functional safety system Validation of the safety functions which are used in the safety system: They operate as required in the application, and the safety requirements (SRS) arising from the risk assessment are fulfilled. If any of the safety functions does not pass the validation tests, it is necessary to return to the design phase, and modify the safety function so that it fulfills the safety requirements from the risk assessment. After the modification, the validation test(s) must be repeated and passed. Refer to chapter Verification and validation .
7.	Validation test report Validation must be properly documented and stored. Refer to section Validation test reports on page 357.
8.	Modification After the modifications, the validation tests must be repeated and passed.
9.	Decommissioning

■ FSO configuring procedure

The FSO parameters are set with the Drive Composer pro PC tool. The names of the FSO parameters and parameter settings are shown in the manual as they appear on the screen when using the tool. See [Drive Composer PC tool user's manual \(3AUA0000094606 \[English\]\)](#) for instructions on using the tool.

You must always check all parameter values to make sure that they are suitable for your application. The preset values in a delivered FSO module or factory default values are not valid for a safety application as such.

Note: Configuration is only possible when the drive is not modulating or the FSO is in the Safe state.

Note: FSO-12 and FSO-21 have different firmware versions, and thus their safety configuration files are not compatible.

After you initially start up the FSO and also after you later modify any application parameters or the configuration, you must check the safety of the entire system by doing a verification according to the system safety verification plan and by doing a validation of the correct operation of the safety application. Refer to chapter [Verification and validation](#).

Plan the configuration (parameter values) according to the safety requirements of the system, installation, wiring, etc. These requirements should be based on the risk assessment of the application. The configuration should take into account also the electrical design documents of the system.

Set the parameter values for the FSO module with the Drive Composer pro PC tool as follows:

1. Power up the drive and make sure that the motor is not running.
2. Connect your PC to the drive, start the Drive Composer pro PC tool and select **Safety settings**.
3. Open the parameters for setting:
 - First configuration: Upload the parameters from the FSO to the PC tool (button **Read settings from drive**). A password is required.
 - Make a backup copy of the preset safety file (button **Save to file**).
 - Existing configuration: Open the configuration file (button **Load from file**).

Note: When you upload parameters from the FSO module to the PC tool, the FSO goes into the Configuration mode and indicates a fault ([7A8B](#)). You can

exit the Configuration mode by rebooting the FSO module or by downloading the parameters to the FSO (refer to steps 5...6 below).

4. Set the parameter values.

- General parameters: Make sure that at least that the motor parameters are correct
- Safety fieldbus communication (if used): Set up the communication between the safety PLC and FSO module.
- Safety functions: You must at least check and set the parameters related to the STO and SSE functions, regardless of what you use the FSO for or which safety functions you use. The FSO module can activate the STO and SSE functions in internal fault situations. The STO and SSE functions are essential for the FSO to be able to make the system safe.
- I/O: Make sure that the I/O parameters are set according to the installation (wiring) plan. Set diagnostic pulsing for I/Os when necessary. Examine possible safety relays and cascade connections.

Note: Make sure that the diagnostic pulsing settings are compatible with all devices in the system (for example, switches, light curtains and PLCs).

5. After configuring all necessary functions, do these two steps:

- Download the configuration to the FSO (button **Download to FSO and validate**). A password is required.
- Save the configuration to your PC (button **Save safety file**).

6. After downloading, the FSO and the tool validate the configuration, and the tool asks you to confirm the validation.

7. Change the password to protect the settings (button **Change password**). A password is required.

Note: The motor must be stopped when you change the password.

8. Validate safety functions, print the report from the configuration, including all the values of the parameters and CRC. Sign and store the report according to your safety management plan.

Note: You can use the safety configuration report in the Drive Composer pro PC tool for this purpose.

Make sure that you saved the safety file and parameter backup file after validation for later use. The safety file is not included in the drive backup process.


Note: If you want to clear the configuration and start again from the factory setup, do a factory reset. Refer to section [Factory reset](#) on page [402](#).

Configuring general settings

To configure the general settings, use the Drive Composer pro PC tool to set the FSO parameters listed below. See parameter group [FSOGEN](#) on page 180.

Example: The figure below shows an example I/O set-up:

- After power-up, the acknowledgement can only be performed manually ([FSOGEN.41 Power-up acknowledgement](#) = Manual).
- [Acknowledgement button](#) is connected to input X114:4 ([FSOGEN.42 Acknowledgement button input](#) = DI X114:4).
- [FSOGEN.22 Motor nominal frequency](#) = 50.00 Hz. Use the same value with the drive parameter 99.08 Motor nominal frequency, and the value on the motor type designation label.
- [FSOGEN.21 Motor nominal speed](#) = 1500.0 rpm. Set this parameter to the motor synchronous speed, not the nominal speed. The nominal speed is shown on the motor type designation label. For the synchronous speed, refer to the table in section [Safe speed estimate](#) on page 45.
- [FSOGEN.51 Zero speed without encoder](#) = 90.0 rpm. Stopping functions are considered to be completed at this speed. Use suitable (low enough) value according to application.
- External requests ending in the drive STO are reported to the drive as events ([FSOGEN.61 STO indication ext request](#) = Event).
- Safety function limit hits are reported as faults ([FSOGEN.62 STO indication safety limit](#) = Fault).
- No output connected for the completion of stop functions (STO, SSE, SS1) ([FSOGEN.11 Stop completed output](#) = None).



Configuring the safety fieldbus communication


■ How to configure the safety communication with PROFIsafe

To configure the safety fieldbus communication between the FSO module and a safety PLC, set the FSO parameters shown in the figure below to appropriate values using the Drive Composer pro PC tool. See parameter groups [Safety](#) on page 309, [SBUSGEN](#) on page 345 and [PROFIsafe](#) on page 346.

In addition, you must install the FB module to the drive and set up the safety communication network between the modules as described in chapter [PROFIsafe](#).

Example:

- PROFIsafe communication activated
([SBUSGEN. 01 SBUS activity and version](#) = Version 1 and [200.222 Safety bus type](#) = PROFIsafe)
- Speed scaling: 1500 rpm
([SBUSGEN. 06 Safety fieldbus speed scaling](#) = 1500 rpm)
- the FSO module generates a fault message if the module is passivated due to safety fieldbus problems
([SBUSGEN.10 STO indication passivation](#) = Fault)
- the FB module is connected to option slot 1
([200.223 Safety fieldbus adapter slot](#) = FBA A and [50.01 FBA A enable](#) = 1)
- PROFIsafe profile ABB_PS1 in use
([PROFIsafe. 12 PROFIsafe telegram type](#) = 0x221)
- IP address of the FB module: 1
([PROFIsafe.11 PROFIsafe F_Dest_Add](#) = 1)



Configuring I/O

■ How to configure I/O

To configure the I/O, set the FSO parameters shown in the figure below to appropriate values using the Drive Composer pro PC tool. See parameter group [SAFEIO](#) on page 339.

The location of the input and output terminals on the FSO module is shown in section [Layout](#) on page 40.

Inputs

Inputs can be configured into use with different safety functions. It is possible to select either single or redundant inputs in use. For example, if a single input X113:1 is supposed to activate the STO function, user must configure this input in use in the STO configuration view.

There are input A and input B for the safety functions. User can use them either for cascading, or for connecting two different and independent activation switches for the same function.

It is possible to set diagnostic pulses for the inputs. User must set the pulse length and period, and also define the inputs which use the pulses.

Outputs

Outputs can be configured into use for different safety functions ([Safety function indications](#) on page 59), a safety relay, the SBC function, and a cascade loop. User can select the output type (single or redundant output), and set the logic state for each digital output. The logic state of output can be configured to be active low or active high.

For some of the safety functions, output A and output B are available. This enables the use of cascaded functions, and the function specific indications.

It is possible to set diagnostic pulses for the outputs. User must set the pulse length and period, and also define the outputs which use the pulses.

Note: Make sure that the I/O configuration for safety functions is set up according to the circuit diagrams.

Safety relay output


The safety relay output is used to the control of the safety relay. This output is redundant and has a feedback input.

I/O redundancy

Redundant input or output is configured by selecting I/O pair to safety function I/O parameter. For example, redundant input for STO function: DI X113:1 & X114:1 must be configured either to STO input A or input B.

Example: The figure below shows an example I/O set-up:

- All inputs use diagnostic pulses with 1 ms width and 30 s period.
- One redundant cascaded connection from input 1 to output 7
- One safety relay (always redundant) connected to output 8 with feedback connected to input 3
- All outputs, except X114:9, have active low logic state and diagnostic pulsing on. Pulse width 1 ms and period 59 s.
- Output X114:9 has active high logic state and diagnostics pulses are not used.



Note: The safety relay inputs and outputs must be configured so that in the Safe state the circuit is disconnected (0 V).

■ How to configure a cascaded system

This example shows how to configure the cascaded system (Cascade A) as shown in section [Cascade](#) on page 63. The SSE function is used as an example (Safety function 1 in the figure on page 63). In this configuration example, Cascade B is not configured (parameter [SAFEIO.13 Cascade B](#) = None).

1. Define one of the FSO modules as the master and the other FSO modules are followers in Cascade A:
 - In the master FSO: [SAFEIO.11 M/F mode for cascade](#) = A = master, B = master (only Cascade A is configured in this example).
 - In the follower FSOs: [SAFEIO.11 M/F mode for cascade](#) = A = follower, B = follower (only Cascade A is configured in this example).
 2. Connect a digital input to the corresponding digital output in the cascaded system (single cascade X113:2 -> X113:8):
 - [SAFEIO.12 Cascade A](#) = X113:2 -> X113:8.
 3. Set the digital inputs and outputs of the SSE function as defined for the cascaded system:
 - The SSE function is activated from a redundant digital input in the master FSO ([SSE.11 SSE input A](#) = DI X113:1&X114:1)
 - The SSE function is cascaded back to the master FSO with a single digital input and output ([SSE.12 SSE input B](#) = DI X113:2, [SSE.21 SSE output](#) = DO X113:8)
 - The SSE function is cascaded with a single digital input and output in the follower FSOs ([SSE.12 SSE input B](#) = DI X113:2, [SSE.21 SSE output](#) = DO X113:8).

Note: Do not use the completed output of the safety function as the cascaded output (parameter ([SSE.22 SSE completed output](#) = None, or you can use this output for the safety function indication).
 4. Set the acknowledgement method in the master FSO modules (in this example, Manual is used):
 - [STO.02 STO acknowledgement](#) = Manual
 5. Set the digital input for the acknowledgement button in the master FSO module:
 - [FSOGEN.42 Acknowledgement button input](#) = DI X114:2.
 6. Set the acknowledgement method in the follower FSO modules (must be Automatic in the follower FSOs).
 - [STO.02 STO acknowledgement](#) = Automatic
 7. Set the other parameters related to the SSE function as defined in section [Configuring SSE](#) on page 269.
-

Parameter settings in the master FSO

Index	Name/Value	Description
SAFEIO.11	M/F mode for cascade	Sets the master/follower mode of the FSO module for both cascade connections A and B separately. In this example, only cascade connection A is used.
	A = master, B = master	This module is the master on cascade connection A.
SAFEIO.12	Cascade A	Sets the cascade connection A for the FSO module. For each FSO module in cascade A, the digital input connected to the safety function is also internally connected to the corresponding digital output of the module (digital input -> digital output).
	X113:2 -> X113:8	Single cascade X113:2 -> X113:8
SAFEIO.13	Cascade B	Sets the cascade connection B for the FSO module.
	None	Not cascaded
STO.02	STO acknowledgement	Sets the acknowledgement method used in the STO, SSE and SS1 functions. See section Acknowledgement methods on page 54 for more information on different acknowledgement methods.
	Manual	The FSO module reads the external STO acknowledgement signal through the digital input defined by parameter FSOGEN.42 Acknowledgement button input .
SSE.11	SSE input A	Sets the digital input that is connected to the primary input of the SSE function. In this example, this parameter sets the digital input that is used for the activation of the SSE function in the master FSO.
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1
SSE.12	SSE input B	Sets the digital input that is connected to the secondary input of the SSE function. In this example, this parameter sets the digital input that is used in the cascade loop (Cascade A) to cascade the SSE function back to the master FSO.
	DI113:2	Single input X113:2
SSE.21	SSE output	Sets the digital output that indicates the activity of the SSE function. Active from the SSE request until the function has been acknowledged. In this example, this parameter sets the digital output that is used in the cascade loop (Cascade A) to cascade the SSE function to the follower FSOs.
	DO X113:8	Single output X113:8

Index	Name/Value	Description
SSE.22	SSE completed output	Sets the digital output that indicates the completion of the SSE function. In this example, output X113:7 is connected to the indication lamp.
	DO X113:7	Single output X113:7
FSOGEN.42	Acknowledgement button input	Sets the digital input that is connected to the button for acknowledgement operations.
	DI X114:2	Single input X114:2

Parameter settings in the follower FSOs

Index	Name/Value	Description
SAFEIO.11	M/F mode for cascade	Sets the master/follower mode of the FSO module for both cascade connection A and B separately. In this example, only cascade connection A is used.
	A = follower, B = follower	This module is a follower on cascade connection A.
SAFEIO.12	Cascade A	Sets the cascade connection A for the FSO module. For each FSO module in cascade A, the digital input connected to the safety function is also internally connected to the corresponding digital output of the module (digital input -> digital output).
	X113:2 -> X113:8	Single cascade X113:2 -> X113:8
STO.02	STO acknowledgement	Sets the acknowledgement method used in the STO, SSE and SS1 functions.
	Automatic	The FSO module generates the STO acknowledgement signal automatically after the STO, SSE or SS1 request has been removed and the stop function is completed (output defined by parameter FSOGEN.11 Stop completed output is active).
SSE.11	SSE input A	Sets the digital input that is connected to the primary input of the SSE function. In this example, the activation of the SSE function in the follower FSOs comes from the master FSO through the cascade loop (Cascade A), and this parameter must be set to None.
	None	No input connected
SSE.12	SSE input B	Sets the digital input that is connected to the secondary input of the SSE function. In this example, this parameter sets the digital input that is used in the cascade loop (Cascade A) to cascade the SSE function to the follower FSOs.
	DI X113:2	Single input X113:2
SSE.21	SSE output	Sets the digital output that indicates the activity of the SSE function. Active from the SSE request until the function has been acknowledged. In this example, this parameter sets the digital output that is used in the cascade loop (Cascade A) to cascade the SSE function to the follower FSOs.
	DO X113:8	Single output X113:8

Index	Name/Value	Description
SSE.22	SSE completed output	Sets the digital output that indicates the completion of the SSE function.
	None	No output connected

■ **How to configure safety relays**

If you want to control a safety relay or contactor with the FSO module, define the use of the related I/O with these parameters. See also section [Relay / contactor output with feedback](#) on page 223.

Index	Name/Value	Description
SAFEIO.21	Safety relay 1 output	Sets the digital output connected to the safety relay 1.
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8
SAFEIO.22	Safety relay 1 feedback	Sets the digital feedback input of safety relay 1.
	DI X113:4	Single input X113:4
SAFEIO.23	Safety relay 1 feedback type	Sets the type of the feedback signal for safety relay 1.
	Mechanically linked NC contacts	Feedback of the safety relay is NC (inverted state compared with the relay).
SAFEIO.24	Safety relay 2 output	Sets the digital output for safety relay 2.
	None	No output connected
SAFEIO.25	Safety relay 2 feedback	Sets the digital feedback input of safety relay 2.
	None	No input connected
SAFEIO.26	Safety relay 2 feedback type	Sets the type of the feedback signal for safety relay 2.
	Mechanically linked NC contacts	Feedback of the safety relay is NC (inverted state compared with the relay).

Do not configure a safety function activation to a safety relay feedback. In addition, you have to connect the safety relay to the desired safety function. Set the same digital output as you set for the safety relay as the output of the

desired safety function. In this example, safety relay 1 is connected to the SBC function.


Index	Name/Value	Description
SBC.21	SBC output	Sets the digital output that is connected to the SBC output (brake relays).
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8

Configuring SBC

When you use the SBC function (brake) with other safety functions of the FSO module, it is always combined with the drive STO function. That is, the SBC function is activated before, at the same time with or after the drive STO function.

You can configure the SBC in the STO, SSE and SS1 functions:

- If you configure the SBC in the STO function, this also takes it into use in the SSE with immediate STO function.
- If you configure the SBC in the SS1 function, this also takes it into use in the SSE with emergency ramp function.



WARNING! If the SBC function is in use, automatic acknowledgement will automatically release the safe brake immediately when the STO request is removed. Prevent unexpected start-up in the case of using SBC together with automatic acknowledgement.

SBC at zero speed limits

When you configure the SBC function in the STO function, the SBC is activated also when the drive STO is activated at the zero speed in the SSE and SS1 functions. Depending on how the SBC is configured, the SBC is activated before or at the same time with the drive STO function. See section [Safe torque off \(STO\)](#) on page 67.

SBC at trip limit hits

The FSO module activates the SSE function after trip limit hits in the SLS and SMS functions. You can configure the SSE function either with immediate STO (stop category 0) or with emergency ramp (stop category 1), see section [Safe stop emergency \(SSE\)](#) on page 86. If you want that the SBC is activated at trip limit hits, you have to configure the SBC function in the correct SSE function.

Note: Make sure that you dimension the brake correctly for these situations.

SBC at monitoring limit hits

The FSO module activates the STO function after time or ramp monitoring limit hits in the SS1, SSE with emergency ramp and SLS functions. If you want that the SBC is activated at monitoring limit hits, you have to configure the SBC function in the STO function.

Brake failure situations

To make sure that the system is set to safe state also if the brake fails to operate, set parameter [STO.14](#) to a suitable value. If the safety function is not completed before this time has elapsed, the system is set to the safe state.

Define also the FSO module reaction to a missing brake feedback signal (parameter [SBC.22 SBC feedback action](#)).

FSO internal fault situations

The FSO module activates STO and SBC if configured into use in internal fault situations.

■ How to configure the SBC in the STO function

Use these parameters to configure the SBC:

1. Set the how the brake is used with parameter [SBC.11 STO SBC usage](#):
 - None: the SBC is not used
 - Delayed brake (the value can be positive, zero or negative)
2. Set the correct delay with parameter [SBC.12 STO SBC delay](#):
 - If the value is zero (0 ms), the FSO activates the SBC and drive STO functions at the same time.
 - If the value is positive, the FSO activates the SBC after the drive STO. See section [How to configure SBC after STO](#) on page 257.
 - If the value is negative, the FSO activates the SBC before the drive STO. See section [How to configure SBC before STO](#) on page 258.

See also section [How to configure mute time for SBC speed limit detection](#) on page 306.

■ How to configure the SBC in the SS1 function

Use these parameters to configure the SBC:

1. Set the correct SBC speed limit with parameter [SBC.15 SSE/SS1 SBC speed](#):
 - If the value is zero (0 rpm) the SBC is not used in the SS1 and SSE with emergency ramp functions.
 - If the value is positive (the corresponding negative value is used in the opposite direction), the FSO activates the SBC and drive STO functions
-

at the same time when the speed limit is reached. See section [How to configure SS1 with speed limit activated SBC](#) on page 262.

2. You can also set a negative delay with parameter [SBC.12 STO SBC delay](#):
 - If the value is negative, the FSO activates the SBC at the speed limit (set with parameter [SBC.15 SSE/SS1 SBC speed](#)) and the drive STO after this delay. See section [How to configure SS1 with speed limit activated SBC, SBC before STO](#) on page 265.
 - If the value is zero (0 ms) or positive, the FSO activates the SBC and drive STO functions at the same time when the speed limit is reached.

Note: If parameter [SBC.11 STO SBC usage](#) is Delayed brake, the same parameter [SBC.12 STO SBC delay](#) is used also in the STO and SSE with immediate STO functions (see section [How to configure the SBC in the STO function](#) on page 254). In the SS1 (and SSE with emergency ramp) function, this parameter is relevant always when parameter [SBC.15 SSE/SS1 SBC speed](#) is not zero.

Monitoring limit hits in the SS1 function

When you configure the SBC in the SS1 (and SSE with emergency ramp) function, this does not take the SBC into use in the STO function. Therefore, the SBC is not activated in limit hit situations if parameter [SBC.11 STO SBC usage](#) is None. For limit hit situations, you have to configure the SBC also in the STO function. See section [How to configure the SBC in the STO function](#) on page 254.

See also section [How to configure mute time for SBC speed limit detection](#) on page 306.

Configuring STO

To configure the STO function, set the FSO parameters listed below to appropriate values using the Drive Composer pro PC tool. See parameter groups [STO](#) on page 316 and [SBC](#) on page 320.


For more information on the STO and SBC functions, see page 67.

Note: Always set the parameters related to the STO function to have the correct monitoring limit hit and fault reaction behavior.

■ How to configure STO

Example: The figure below shows an example of a simple STO function set-up:

- redundant emergency stop button connected to input (STO.11 STO input A = DI X113:1 & X114:1)
- automatic acknowledgement (STO.02 STO acknowledgement = Automatic)
- estimated time in which the motor coasts to a stop from the maximum speed is 1500 ms (STO.14 Time to zero speed with STO and modoff = 1500 ms)
- the fly-start feature is in use, that is, you can restart the drive before the motor has stopped (STO.13 Restart delay after STO = 1000 ms)
- no output connected
- no brake (SBC.11 STO SBC usage = None).




■ How to configure SBC after STO

For more information on the SBC after STO function, see page 69.

Example: The figure below shows an example of the SBC after the STO function set-up:

- STO delayed brake with positive delay 900 ms
(SBC.11 STO SBC usage = Delayed brake, SBC.12 STO SBC delay = 900 ms)
- redundant emergency stop button connected to input
(STO.11 STO input A = DI X113:1 & X114:1)
- automatic acknowledgement (STO.02 STO acknowledgement = Automatic)
- estimated time in which the motor brakes to a stop from the maximum speed: 400 ms (SBC.13 SBC time to zero speed = 400 ms)
- the fly-start feature is not in use, that is, you cannot start the motor before it has stopped (STO.13 Restart delay after STO = 1300 ms)
- brake connected to redundant output, diagnostic pulses activated
(SBC.21 SBC output = DO X113:7 & X114:7, SAFEIO.53 and SAFEIO.56 = On),
SAFEIO.21 Safety relay 1 output = DO X113:7 & X114:7)
- STO is activated if brake feedback fails (SBC.22 SBC feedback action = STO)
- feedback from the brake is connected to digital input X113:2
(SAFEIO.22 Safety relay 1 feedback = DI X113:2)
- feedback input type NC (inverted state compared with the brake relay)
(Safety relay 1 feedback type = Mechanically linked NC contacts).




■ **How to configure SBC before STO**

For more information on the SBC before STO function, see page 71.

Example: The figure below shows an example of the SBC before the STO set-up:

- STO delayed brake with negative delay -500 ms
([SBC.11 STO SBC usage](#) = Delayed brake, [SBC.12 STO SBC delay](#) = -500 ms)
- redundant emergency stop button connected to input
([STO.11 STO input A](#) = DI X113:1 & X114:1)
- automatic acknowledgement ([STO.02 STO acknowledgement](#) = Automatic)
- estimated time in which the motor brakes to a stop from the maximum speed: 1200 ms ([SBC.13 SBC time to zero speed](#) = 1200 ms)
- brake connected to redundant output, diagnostic pulses activated
([SBC.21 SBC output](#) = DO X113:7 & X114:7, [SAFEIO.53](#) and [SAFEIO.56](#) = On),
[SAFEIO.21 Safety relay 1 output](#) = DO X113:7 & X114:7)
- STO is activated if brake feedback fails ([SBC.22 SBC feedback action](#) = STO)
- brake feedback input connected to input
([SAFEIO.22 Safety relay 1 feedback](#) = DI X113:2)
- feedback input type NC (inverted state compared with the brake relay)
([SAFEIO.23 Safety relay 1 feedback type](#) = Mechanically linked NC contacts).



Configuring SS1


To configure the SS1 function, set the FSO parameters listed below to appropriate values using the Drive Composer pro PC tool. See parameter group [SS1](#) on page 327.

For more information on the SS1 function, see page 72.

■ How to configure SS1 with time monitoring (SS1-t)

Example: The figure below shows an example of an SS1-t set-up:


- SS1 function activated ([SS1.01 SS1 activity and version](#) = Version 1)
 - SAR1 emergency ramp ([200.112 SAR1 ramp time to zero](#), always with the SS1 function - see section [Configuring SAR](#) on page 278)
 - SS1 with time monitored ramp ([SS1.13 SS1 type](#) = SS1-t)
 - delay for STO activation after SS1 request: 2000 ms ([SS1.14 SS1-t delay for STO](#) = 2000 ms)
 - automatic acknowledgement ([STO.02 STO acknowledgement](#) = Automatic)
 - redundant emergency stop button connected to input ([SS1.11 SS1 input A](#) = DI X113:1 & X114:1)
 - single output connected ([SS1.21 SS1 output](#) = DO X114:9)
 - zero speed limit where SS1 function is completed and drive STO activated is 90 rpm ([FSOGEN.51 Zero speed without encoder](#) = 90 rpm)
 - delay for activating STO after the zero speed limit has been reached: 0 ms ([SS1.15 SS1-r ramp zero speed delay for STO](#) = 0 ms)
 - speed limit activated brake not in use ([SBC.15 SSE/SS1 SBC speed](#) = 0 rpm).
 - See also section [Configuring mute times](#) on page 301.
-



■ How to configure SS1 with ramp monitoring (SS1-r)

Example: The figure below shows an example of the SS1-r function set-up:

- SS1 function activated ([SS1.01 SS1 activity and version = Version 1](#))
- SAR1 emergency ramp ([200.112 SAR1 ramp time to zero](#), always with the SS1 function - see section [Configuring SAR](#) on page 278)
- SS1 with monitored ramp ([SS1.13 SS1 type = SS1-r](#)). See also section [How to configure SARn](#) on page 278.
- automatic acknowledgement ([STO.02 STO acknowledgement = Automatic](#))
- redundant emergency stop button connected to input ([SS1.11 SS1 input A = DI X113:1 & X114:1](#))
- single output connected ([SS1.21 SS1 output = DO X114:9](#))
- zero speed limit where SS1 function is completed and drive STO activated is 90 rpm ([FSOGEN.51 Zero speed without encoder = 90 rpm](#))
- delay for activating STO after the zero speed limit has been reached: 0 ms ([SS1.15 SS1-r ramp zero speed delay for STO = 0 ms](#))
- speed limit activated brake not in use ([SBC.15 SSE/SS1 SBC speed = 0 rpm](#)).
- See also section [Configuring mute times](#) on page 301.




■ How to configure SS1 with speed limit activated SBC

Note: If you configure the SS1 with speed limit activated SBC function, this activates the same function in the SSE function (see section [How to configure SSE with speed limit activated SBC](#) on page 273). This does not activate the SBC in the STO function. If necessary, configure the SBC also in the STO function (see section [Configuring STO](#) on page 255). See also the note on page 51.


Example 1: The figure below shows an example of the SS1-t function with speed limit activated SBC set-up:

- SS1 function activated ([SS1.01 SS1 activity and version](#) = Version 1)
 - SS1 with time monitored ramp ([SS1.13 SS1 type](#) = SS1-t)
 - SAR1 emergency ramp ([200.112 SAR1 ramp time to zero](#), always with the SS1 function - see section [Configuring SAR](#) on page 278)
 - delay for STO activation after SS1 request: 2000 ms ([SS1.14 SS1-t delay for STO](#) = 2000 ms)
 - automatic acknowledgement ([STO.02 STO acknowledgement](#) = Automatic)
 - redundant emergency stop button connected to input ([SS1.11 SS1 input A](#) = DI X113:1 & X114:1)
 - single output connected ([SS1.21 SS1 output](#) = DO X114:9)
 - brake connected to redundant output, diagnostic pulses activated ([SBC.21 SBC output](#) = DO X113:7 & X114:7, [SAFEIO.53](#) and [SAFEIO.56](#) = On), [SAFEIO.21 Safety relay 1 output](#) = DO X113:7 & X114:7)
 - speed limit activated brake in use, speed below which the brake and STO are activated: 180.0 rpm ([SBC.15 SSE/SS1 SBC speed](#) = 180 rpm)
 - delay for activating STO after brake is zero (STO and SBC are activated at the same time) ([SBC.12 STO SBC delay](#) = 0 ms)
 - delay for activating the brake and STO after the SBC speed limit has been reached: 0 ms ([SS1.15 SS1-r ramp zero speed delay for STO](#) = 0 ms)
 - delay for defining the safety function as completed, that is, an estimated time in which the motor brakes to a stop from the maximum speed: 1200 ms ([SBC.13 SBC time to zero speed](#) = 1200 ms)
 - STO is activated if brake feedback fails ([SBC.22 SBC feedback action](#) = STO)
 - brake feedback input connected to input ([SAFEIO.22 Safety relay 1 feedback](#) = DI X113:2)
 - feedback input type NC (inverted state compared with the brake relay) ([SAFEIO.23 Safety relay 1 feedback type](#) = Mechanically linked NC contacts).
 - See also section [Configuring mute times](#) on page 301.
-



Example 2: The figure below shows an example of the SS1-r function with speed limit activated SBC set-up:

- SS1 function activated ([SS1.01 SS1 activity and version = Version 1](#))
 - SAR1 emergency ramp ([200.112 SAR1 ramp time to zero](#), always with the SS1 function - see section [Configuring SAR](#) on page 278)
 - SS1 with monitored ramp ([SS1.13 SS1 type = SS1-r](#)). See also section [How to configure SARn](#) on page 278.
 - automatic acknowledgement ([STO.02 STO acknowledgement = Automatic](#))
 - redundant emergency stop button connected to input ([SS1.11 SS1 input A = DI X113:1 & X114:1](#))
 - single output connected ([SS1.21 SS1 output = DO X114:9](#))
 - brake connected to redundant output, diagnostic pulses activated ([SBC.21 SBC output = DO X113:7 & X114:7](#), [SAFEIO.53](#) and [SAFEIO.56 = On](#)), [SAFEIO.21 Safety relay 1 output = DO X113:7 & X114:7](#))
 - speed limit activated brake in use, speed limit below which the brake and STO are activated: 180.0 rpm ([SBC.15 SSE/SS1 SBC speed = 180 rpm](#))
 - delay for activating STO after brake is zero (STO and SBC are activated at the same time) ([SBC.12 STO SBC delay = 0 ms](#))
 - delay for activating the brake and STO after the SBC speed limit has been reached: 0 ms ([SS1.15 SS1-r ramp zero speed delay for STO = 0 ms](#))
 - delay for defining the safety function as completed, that is, an estimated time in which the motor brakes to a stop from the maximum speed: 1200 ms ([SBC.13 SBC time to zero speed = 1200 ms](#))
 - STO is activated if brake feedback fails ([SBC.22 SBC feedback action = STO](#))
 - brake feedback input connected to input ([SAFEIO.22 Safety relay 1 feedback = DI X113:2](#))
 - feedback input type NC (inverted state compared with the brake relay) ([SAFEIO.23 Safety relay 1 feedback type = Mechanically linked NC contacts](#)).
 - See also section [Configuring mute times](#) on page 301.
-



■ How to configure SS1 with speed limit activated SBC, SBC before STO


Note: If you configure the SS1 with speed limit activated SBC, SBC before STO function, this activates the same function in the SSE function (see section [How to configure SSE with speed limit activated SBC](#) on page 273). This does not activate the SBC in the STO function. If necessary, configure the SBC also in the STO function (see section [Configuring STO](#) on page 255). See also the note on page 51.

Example 1: The figure below shows an example of the SS1-t function with speed limit activated SBC, SBC before STO set-up:

- SS1 function activated ([SS1.01 SS1 activity and version = Version 1](#))
- SS1 with time monitored ramp ([SS1.13 SS1 type = SS1-t](#))
- SAR1 emergency ramp ([200.112 SAR1 ramp time to zero](#), always with the SS1 function - see section [Configuring SAR](#) on page 278)
- delay for STO activation after SS1 request: 2000 ms ([SS1.14 SS1-t delay for STO = 2000 ms](#))
- automatic acknowledgement ([STO.02 STO acknowledgement = Automatic](#))
- redundant emergency stop button connected to input ([SS1.11 SS1 input A = DI X113:1 & X114:1](#))
- single output connected ([SS1.21 SS1 output = DO X114:9](#))
- brake connected to redundant output, diagnostic pulses activated ([SBC.21 SBC output = DO X113:7 & X114:7](#), [SAFEIO.53](#) and [SAFEIO.56 = On](#)), [SAFEIO.21 Safety relay 1 output = DO X113:7 & X114:7](#))
- speed limit activated brake in use, speed below which the brake and STO are activated: 180.0 rpm ([SBC.15 SSE/SS1 SBC speed = 180 rpm](#))
- delay for activating STO after brake: -300 ms (only a negative delay is possible, the SBC is activated before STO) ([SBC.12 STO SBC delay = -300 ms](#))

Note: The same SBC delay is used in the STO and SS1/SSE functions.

- delay for activating the brake after the SBC speed limit has been reached: 0 ms ([SS1.15 SS1-r ramp zero speed delay for STO = 0 ms](#), not shown in the figure)
 - delay to define the safety function as completed, that is, estimated time in which the motor brakes to a stop from the maximum speed: 1200 ms ([SBC.13 SBC time to zero speed = 1200 ms](#))
 - STO is activated if brake feedback fails ([SBC.22 SBC feedback action = STO](#))
 - brake feedback input connected to input ([SAFEIO.22 Safety relay 1 feedback = DI X113:2](#))
 - feedback input type NC (inverted state compared with the brake relay) ([SAFEIO.23 Safety relay 1 feedback type = Mechanically linked NC contacts](#)).
 - See also section [Configuring mute times](#) on page 301.
-




Example 2: The figure below shows an example of the SS1-r function with speed limit activated SBC, SBC before STO set-up:

- SS1 function activated (SS1.01 SS1 activity and version = Version 1)
- SAR1 emergency ramp (200.112 SAR1 ramp time to zero, always with the SS1 function - see section [Configuring SAR](#) on page 278)
- SS1 with monitored ramp (SS1.13 SS1 type = SS1-r). See also section [How to configure SARn](#) on page 278.
- automatic acknowledgement (STO.02 STO acknowledgement = Automatic)
- redundant emergency stop button connected to input (SS1.11 SS1 input A = DI X113:1 & X114:1)
- single output connected (SS1.21 SS1 output = DO X114:9)
- brake connected to redundant output, diagnostic pulses activated (SBC.21 SBC output = DO X113:7 & X114:7, SAFEIO.53 and SAFEIO.56 = On, SAFEIO.21 Safety relay 1 output = DO X113:7 & X114:7)
- speed limit activated brake in use, speed limit below which the brake is activated: 180.0 rpm (SBC.15 SSE/SS1 SBC speed = 180 rpm)
- delay for activating STO after brake: -300 ms (only a negative delay is possible, the SBC is activated before STO) (SBC.12 STO SBC delay = -300 ms)

Note: The same SBC delay is used in the STO and SS1/SSE functions.

- delay for activating the brake after the SBC speed limit has been reached:
0 ms ([SS1.15 SS1-r ramp zero speed delay for STO](#) = 0 ms, not shown in the figure)
- delay to define the safety function as completed, that is, estimated time in which the motor brakes to a stop from the maximum speed: 1200 ms ([SBC.13 SBC time to zero speed](#) = 1200 ms)
- STO is activated if brake feedback fails ([SBC.22 SBC feedback action](#) = STO)
- brake feedback input connected to input ([SAFEIO.22 Safety relay 1 feedback](#) = DI X113:2)
- feedback input type NC (inverted state compared with the brake relay) ([SAFEIO.23 Safety relay 1 feedback type](#) = Mechanically linked NC contacts).
- See also section [Configuring mute times](#) on page 301.



■ Related safety functions

The SS1 function uses SAR1 ramp parameters. See section [Configuring SAR](#) on page 278.

The FSO module activates the STO function if the motor speed hits a monitoring limit (time or ramp monitoring). See section [Configuring STO](#) on page [255](#).

Configuring SSE

To configure the SSE function, set the FSO parameters listed below to appropriate values using the Drive Composer pro PC tool. See parameter groups [SSE](#) on page [324](#) and [SBC](#) on page [320](#).


For more information on the SSE function, see page [86](#).

Note: Always set the parameters related to the SSE function to have the correct trip limit hit and fault reaction behavior. For example, the FSO module activates the SSE function if an I/O failure occurs.

■ How to configure SSE with immediate STO

Example: The figure below shows an example of the SSE function with immediate STO set-up:

- drive STO is activated immediately after the SSE request (**SSE.13 SSE function** = Immediate STO)
- automatic acknowledgement (**STO.02 STO acknowledgement** = Automatic)
- redundant emergency stop button connected to input (**SSE.11 SSE input A** = DI X113:1 & X114:1)
- no outputs connected
- delay for restarting the drive: 1500 ms. This is the estimated time in which the motor coasts to a stop from the maximum speed. (**STO.14 Time to zero speed with STO and modoff** = 1500 ms)
- no brake (**SBC.11 STO SBC usage** = None).



■ How to configure SSE with immediate STO, SBC after or before STO

The configuration is identical to the SBC after or before STO functions with these differences:

- parameter **STO.13 Restart delay after STO** is not used
- SSE input parameters (**SSE.11 SSE input A** and **SSE.12 SSE input B**) are used instead of STO input parameters
- SSE output parameters (**SSE.21 SSE output** and **SSE.22 SSE completed output**) are used instead of STO output parameters.

See sections [How to configure SBC after STO](#) on page 257 and [How to configure SBC before STO](#) on page 258.

For more information on the SSE with immediate STO and SBC after STO function, see page 87.


For more information on the SSE with immediate STO and SBC before STO function, see page 89.

■ **How to configure SSE with time monitoring**

For more information on the SSE function with time monitoring, see page 91.

Example: The figure below shows an example of the SSE function with time monitoring set-up:

- SAR0 emergency ramp (200.102 SAR0 ramp time to zero, always with the SSE function - see section [Configuring SAR](#) on page 278)
- SSE with time monitored ramp ([SSE.13 SSE function](#) = Emergency ramp, [SSE.14 SSE monitoring method](#) = Time)
- delay for STO activation after SSE request: 2000 ms ([SSE.15 SSE delay for STO](#) = 2000 ms)
- automatic acknowledgement ([STO.02 STO acknowledgement](#) = Automatic)
- redundant emergency stop button connected to input ([SSE.11 SSE input A](#) = DI X113:1 & X114:1)
- single output connected ([SSE.21 SSE output](#) = DO X113:9)
- zero speed limit where SSE function is completed and drive STO activated is 90 rpm ([FSOGEN.51 Zero speed without encoder](#) = 90 rpm)
- delay for activating the drive STO after the speed limit has been reached: 0 ms ([SSE.16 SSE ramp zero speed delay for STO](#) = 0 ms)
- speed limit activated brake not in use ([SBC.15 SSE/SS1 SBC speed](#) = 0 rpm)
- See also section [Configuring mute times](#) on page 301.




■ How to configure SSE with ramp monitoring

For more information on the SSE function with ramp monitoring, see page [93](#).

Example: The figure below shows an example of the SSE function with ramp monitoring set-up:

- SAR0 emergency ramp (200.102 SAR0 ramp time to zero, always with the SSE function - see section [Configuring SAR](#) on page 278)
- SSE with emergency ramp ([SSE.13 SSE function](#) = Emergency ramp)
- SSE with monitored ramp ([SSE.14 SSE monitoring method](#) = Ramp). See also section [Configuring SAR](#) on page 278.
- redundant emergency stop button connected to input ([SSE.11 SSE input A](#) = DI X113:1 & X114:1)
- single output connected ([SSE.21 SSE output](#) = DO X113:9)
- zero speed limit where SSE function is completed and drive STO activated is 90 rpm ([FSOGEN.51 Zero speed without encoder](#) = 90 rpm)
- delay for activating the drive STO after the zero speed limit has been reached: 0 ms ([SSE.16 SSE ramp zero speed delay for STO](#) = 0 ms)
- speed limit activated brake not in use ([SBC.15 SSE/SS1 SBC speed](#) = 0 rpm).
- See also section [Configuring mute times](#) on page 301.




■ How to configure SSE with speed limit activated SBC

Note: If you configure the SSE with speed limit activated SBC function, this activates the same function in the SS1 function (see section [How to configure SS1 with speed limit activated SBC](#) on page 262). This does not activate the SBC

in the STO function. If necessary, configure the SBC also in the STO function (see section [Configuring STO](#) on page 255). See also the note on page 51.


Example 1: The figure below shows an example of the SSE with emergency ramp function with speed limit activated SBC set-up with time monitoring:

- SSE with emergency ramp ([SSE.13 SSE function](#) = [Emergency ramp](#))
 - SAR0 emergency ramp ([200.102 SAR0 ramp time to zero](#), always with the SSE function, see also section [Configuring SAR](#) on page 278)
 - time monitored ramp ([SSE.14 SSE monitoring method](#) = Time)
 - delay for STO activation after SSE request: 2000 ms ([SSE.15 SSE delay for STO](#) = 2000 ms)
 - redundant emergency stop button connected to input ([SSE.11 SSE input A](#) = DI X113:1 & X114:1)
 - single output connected ([SSE.21 SSE output](#) = DO X113:9)
 - brake connected to redundant output, diagnostic pulses activated ([SBC.21 SBC output](#) = DO X113:7 & X114:7, [SAFEIO.53](#) and [SAFEIO.56](#) = On, [SAFEIO.21 Safety relay 1 output](#) = DO X113:7 & X114:7)
 - speed limit activated brake in use, speed below which the brake and STO are activated 240.0 rpm ([SBC.15 SSE/SS1 SBC speed](#) = 240 rpm)
 - delay for activating STO after brake is zero (STO and SBC are activated at the same time) ([SBC.12 STO SBC delay](#) = 0 ms)
 - delay for activating the brake and drive STO after the speed limit has been reached 0 ms ([SSE.16 SSE ramp zero speed delay for STO](#) = 0 ms)
 - STO is activated if brake feedback fails ([SBC.22 SBC feedback action](#) = STO)
 - brake feedback input connected to input ([SAFEIO.22 Safety relay 1 feedback](#) = DI X113:2)
 - feedback input type NC (inverted state compared with the brake relay) ([SAFEIO.23 Safety relay 1 feedback type](#) = Mechanically linked NC contacts).
 - See also section [Configuring mute times](#) on page 301.
-



Example 2: The figure below shows an example of the SSE with emergency ramp function with speed limit activated SBC set-up with ramp monitoring:

- SSE with emergency ramp ([SSE.13 SSE function = Emergency ramp](#))
 - SAR0 emergency ramp ([200.102 SAR0 ramp time to zero](#), always with the SSE function - see section [Configuring SAR](#) on page 278)
 - SAR0 monitored ramp ([SSE.14 SSE monitoring method = Ramp](#), see also section [Configuring SAR](#) on page 278)
 - redundant emergency stop button connected to input ([SSE.11 SSE input A = DI X113:1 & X114:1](#))
 - single output connected ([SSE.21 SSE output = DO X113:9](#))
 - brake connected to redundant output, diagnostic pulses activated ([SBC.21 SBC output = DO X113:7 & X114:7](#), [SAFEIO.53](#) and [SAFEIO.56 = On](#), [SAFEIO.21 Safety relay 1 output = DO X113:7 & X114:7](#))
 - speed limit activated brake in use, speed below which the brake and STO are activated 240.0 rpm ([SBC.15 SSE/SS1 SBC speed = 240 rpm](#))
 - delay for activating STO after brake is zero (STO and SBC are activated at the same time) ([SBC.12 STO SBC delay = 0 ms](#))
 - delay for activating the brake and drive STO after the speed limit has been reached 0 ms ([SSE.16 SSE ramp zero speed delay for STO = 0 ms](#))
 - STO is activated if brake feedback fails ([SBC.22 SBC feedback action = STO](#))
 - brake feedback input connected to input ([SAFEIO.22 Safety relay 1 feedback = DI X113:2](#))
 - feedback input type NC (inverted state compared with the brake relay) ([SAFEIO.23 Safety relay 1 feedback type = Mechanically linked NC contacts](#)).
 - See also section [Configuring mute times](#) on page 301.
-



■ How to configure SSE with speed limit activated SBC, SBC before STO

The configuration of the SSE with speed limit activated SBC, SBC before STO is identical to the configuration of the same SS1 function with these differences:

- SSE input parameters (SSE.11 SSE input A and SSE.12 SSE input B) are used instead of SS1 input parameters
- SSE output parameters (SSE.21 SSE output and SSE.22 SSE completed output) are used instead of SS1 output parameters.
- type of the SSE function must be set: SSE with emergency ramp (SSE.13 SSE function = Emergency ramp)
- SAR0 emergency ramp and monitoring limits are used instead of SAR1 parameters (see section [Configuring SAR](#) on page 278).
- monitoring method is set with parameter (SSE.14 SSE monitoring method = Time or Ramp)
- delay for STO activation after SSE request is set with parameter SSE.15 SSE delay for STO
- delay for activating the brake after the speed limit has been reached is set with parameter SSE.16 SSE ramp zero speed delay for STO.

Note: If you configure the SSE with speed limit activated SBC function, this activates the same function in the SS1 function (see section [How to configure SS1 with speed limit activated SBC, SBC before STO](#) on page 265). This does not activate the SBC in the STO function. If necessary, configure the SBC also in the STO function (see section [Configuring STO](#) on page 255). See also the note on page 51.

For more information on the SSE with speed limit activated SBC, SBC before STO SBC function, see page 98.

■ Related safety functions

The SSE function uses SAR0 ramp parameters. See section [Configuring SAR](#) on page 278.

The FSO module activates the STO function if the motor speed hits a monitoring limit (SSE with time or ramp monitoring). See section [Configuring STO](#) on page 255.


Configuring SAR

■ How to configure SARn

To configure the SARn ($n = 0 \dots 1$), set the FSO parameters listed below to appropriate values using the Drive Composer pro PC tool. See parameter groups [Safety](#) on page 309 and [SARx](#) on page 338. See also section [Ramp monitoring](#) on page 58.

Example: The figure below shows an example of a SAR1 monitoring set-up:

- SAR1
- ramp time from Scaling speed to zero: 1000 ms
(200.112 SAR1 ramp time to zero = 1000 ms)
- Scaling speed: 1500 rpm (200.202 SAR speed scaling = 1500 rpm)
- initial range for monitoring: 100 ms (SARx.02 SAR initial allowed range = 100 ms)
- minimum allowed ramp time: 500 ms
(SARx.21 SAR1 min ramp time to zero = 500 ms)
- maximum allowed ramp time: 1000 ms
(SARx.12 SAR1 max ramp time to zero = 1500 ms).



Note: If you use SAR1 in several safety functions at the same time, tune it according to the function which requires the tightest monitoring range.

Configuring SLS

To configure the SLSn (n = 1...4), set the FSO parameters listed below to appropriate values using the Drive Composer pro PC tool. See parameter groups [Safety](#) on page 309 and [SLSx](#) on page 330.

For more information on the SLS function, see page 102.

Depending on the application, set the negative and positive SLS and SLS trip limits separately.

■ How to configure SLSn with time monitoring


Example: The figure below shows an example of the SLS1 function with time monitoring set-up:

- SLS1 function activated ([200.21 SLS1 activity and version = Version 1](#))
- time monitored deceleration ramp ([SLSx.03 SLS activation monitoring method = Time](#))
- deceleration ramp according to drive parameters (always with time monitoring)
- SLS activation delay: 2000 ms ([SLSx.04 SLS time delay = 2000 ms](#))
- automatic acknowledgement ([SLSx.02 SLS acknowledgement = Automatic](#))
- redundant SLS activation button connected to input ([SLSx.11 SLS1 input A = DI X113:2 & X114:2](#))
- single output connected ([SLSx.15 SLS1 output A = DO X114:7](#))
- positive limits: SLS 1200.0 rpm, trip limit 1320.0 rpm ([200.23 SLS1 limit positive = 1200 rpm](#), [SLSx.14 SLS1 trip limit positive = 1320 rpm](#)).
- negative limits: SLS -900.0 rpm, trip limit -1020.0 rpm ([200.22 SLS1 limit negative = -900 rpm](#), [SLSx.13 SLS1 trip limit negative = -1020 rpm](#)).
- See also section [Configuring mute times](#) on page 301.

Note: The difference between the SLS limit and the corresponding SLS trip limit must be at least 0.1 rpm.

Note: If you also use the SMS function, the SLS trip limits positive and negative must be below the speed defined by parameter [SMS trip limit positive](#) and above the speed defined by parameter [SMS trip limit negative](#), respectively.

SLS1



200.21 = Version 1
SLSx.02 = Automatic
SLSx.03 = Time

Inputs
SLSx.11
= DI X113:2 &
X114:2
SLSx.12
= None

Outputs
SLSx.15
= DO X114:7
SLSx.16
= None


■ How to configure SLSn with ramp monitoring

Example: The figure below shows an example of the SLS2 function with ramp monitoring set-up:

- SLS2 function activated ([200.31 SLS2 activity and version = Version 1](#))
- monitored deceleration ramp ([SLSx.03 SLS activation monitoring method = Ramp](#))
- deceleration ramp and monitoring limits according SAR1 parameters (see section [Configuring SAR](#) on page 278)
- automatic acknowledgement ([SLSx.02 SLS acknowledgement = Automatic](#))
- redundant SLS activation button connected to input ([SLSx.21 SLS2 input = DI X113:2 & X114:2](#))
- single output connected ([SLSx.24 SLS2 output = DO X114:7](#))
- positive limits: SLS 1200.0 rpm, trip limit 1320.0 rpm ([200.33 SLS2 limit positive = 1200 rpm](#), [SLSx.23 SLS2 trip limit positive = 1320 rpm](#)).
- negative limits: SLS -900.0 rpm, trip limit -1020.0 rpm ([200.32 SLS2 limit negative = -900 rpm](#), [SLSx.22 SLS2 trip limit negative = -1020 rpm](#)).
- See also section [Configuring mute times](#) on page 301.

Note: The difference between the SLS limit and the corresponding SLS trip limit must be at least 0.1 rpm.

Note: If you also use the SMS function, the SLS trip limits positive and negative must be below the speed defined by parameter [SMS trip limit positive](#) and above the speed defined by parameter [SMS trip limit negative](#), respectively.



■ Related safety functions

The SLS1...4 functions use SAR1 parameters to monitor and/or define the deceleration ramp (SLS with ramp monitoring). See section [Configuring SAR](#) on page 278.

The FSO module activates the STO function if the motor speed hits a ramp monitoring limit during the deceleration ramp (SLS with ramp monitoring). See section [Configuring STO](#) on page 255.

The FSO module activates the SSE function if the motor speed hits a trip limit. See section [Configuring SSE](#) on page 269.

Configuring Variable SLS

This safety function requires that a safety PLC is connected to the FSO module via the PROFIsafe communication bus. For more information, see chapter [PROFIsafe](#) and section [Configuring the safety fieldbus communication](#) on page 245.

To configure the Variable SLS function, set the FSO parameters listed below to appropriate values using the Drive Composer pro PC tool. See parameter groups [Safety](#) on page 309 and [SLSx](#) on page 330.

The Variable SLS function uses the SLS4 limits of the FSO module. Depending on the application, set the negative and positive SLS and trip limits separately.

Note: If possible, reserve SLS4 function only for variable SLS use.

The FSO module scales the SLS4 trip limit so that the difference between the new limits does not become too small. For more information, see section [Defining the scaled SLS4 limit and SLS4 trip limits](#) on page 286.

Note: If SLS4 limits or trip limits are changed, it affects the Variable SLS limits and trip limits.

For more information on the Variable SLS function, see page 124.

■ How to configure Variable SLS with time monitoring


Example: The figure below shows an example of the Variable SLS function with time monitoring set-up:

- Variable SLS function activated
([200.61 SLS variable activity and version](#) = Version 1)
- automatic acknowledgement ([SLSx.02 SLS acknowledgement](#) = Automatic)
- time monitored deceleration ramp
([SLSx.03 SLS activation monitoring method](#) = Time)
- deceleration and acceleration ramps according to drive parameters
- SLS activation delay: 2000 ms ([SLSx.04 SLS time delay](#) = 2000 ms)
- single output connected ([SLSx.51 Variable SLS output](#) = DO X114:7)
- positive limits: SLS 1200.0 rpm, trip limit 1320.0 rpm
([200.53 SLS4 limit positive](#) = 1200 rpm,
[SLSx.43 SLS4 trip limit positive](#) = 1320 rpm).
- negative limits: SLS -100.0 rpm, trip limit: -150.0 rpm
([FSOGEN.51 Zero speed without encoder](#), not shown in the figure)
([200.52 SLS4 limit negative](#) = -100 rpm,
[SLSx.42 SLS4 trip limit negative](#) = -150 rpm).
- See also section [Configuring mute times](#) on page 301.

Note: The difference between the SLS limit and the corresponding SLS trip limit must be at least 0.1 rpm.

These values are defined in the safety program:

- only positive limits are scaled: Positive_Scaling = 0, Negative_Scaling = 1
- scaling values from the safety PLC: 70%, 50%, 100%
(value set in Variable_SLS_limit = 7000, 5000, 10000).



■ How to configure Variable SLS with ramp monitoring

Example: The figure below shows an example of the Variable SLS function with ramp monitoring set-up:

- Variable SLS function activated
(200.61 SLS variable activity and version = Version 1)
- automatic acknowledgement (SLSx.02 SLS acknowledgement = Automatic)
- monitored deceleration ramp
(SLSx.03 SLS activation monitoring method = Ramp)
- deceleration ramp and ramp monitoring limits according to SAR1 parameters, acceleration ramp according to drive parameters
- single output connected (SLSx.51 Variable SLS output = DO X114:7)
- positive limits: SLS 1200.0 rpm, trip limit 1320.0 rpm
(200.53 SLS4 limit positive = 1200 rpm,
SLSx.43 SLS4 trip limit positive = 1320 rpm).
- negative limits: SLS -100.0 rpm, trip limit: -150.0 rpm
(FSOGEN.51 Zero speed without encoder, not shown in the figure)


(200.52 SLS4 limit negative = -100 rpm,
SLSx.42 SLS4 trip limit negative = -150 rpm).

- See also section [Configuring mute times](#) on page 301.

Note: The difference between the SLS limit and the corresponding SLS trip limit must be at least 0.1 rpm.

These values are defined in the safety program:

- only positive limits are scaled: Positive_Scaling = 0, Negative_Scaling = 1
- scaling values from the safety PLC: 70%, 50%, 100%
(value set in Variable_SLS_limit = 7000, 5000, 10000).



See also section [SLS reaction when modulation is lost during deceleration ramp, with ramp monitoring](#) on page 107.

■ Defining the scaled SLS4 limit and SLS4 trip limits

Because the same scaling percentage is used to scale both the original SLS4 limit and SLS4 trip limit, this affects the difference between new, scaled SLS4 limit and SLS4 trip limits. The FSO scales the SLS4 trip limit so that the difference between the new limits does not become too small.


The FSO module first scales the original SLS4 and SLS4 trip limits with the given percentage. If necessary, the new, scaled SLS4 trip limit is then adjusted according to these rules when safe speed estimate is used:

- If the difference between original SLS4 and SLS4 trip limits is less than 25 rpm: the difference between the scaled limits is the same as the original difference. See Example 1 below.
- If the difference between original SLS4 and SLS4 trip limits is more than 25 rpm: the difference between the limits is at least 25 rpm. See Example 2 below.
- Regardless of the original difference between the limits, the scaled SLS4 trip limit must always be at least the zero speed value (parameter [FSOGEN.51](#)).

Example 1:

- Original SLS4 limit 100 rpm
- Original SLS4 trip limit 102 rpm
- Zero speed value 12 rpm

In this case, the difference between original SLS4 and SLS4 trip limits is smaller than 25 rpm. Trip limit is scaled to at least 2 rpm higher than the SLS4 limit. When the scaling value is 10% or less, trip limit is determined by the zero speed value.




- A Scaled SLS4 trip limit
- B Scaled SLS4 limit
- C Zero speed value [FSOGEN.51](#)
- D The difference between scaled SLS4 limit and trip limit (2 rpm)

E Minimum value for scaled SLS4 trip limit determined by the zero speed value (12 rpm)

Example 2:

- Original SLS4 limit 100 rpm
- Original SLS4 trip limit 150 rpm
- Zero speed value 12 rpm

In this case, the difference between original SLS4 and SLS4 trip limits is greater than 25 rpm. SLS4 limit and trip limit are scaled down normally from 100% to 50%. When the scaling value is 50%, the difference between the limits is 25 rpm and it stays constant even if the scaling value is decreased further. Zero speed value is less than the 25 rpm and has no effect to the trip limit scaling.



- A Scaled SLS4 trip limit
- B Scaled SLS4 limit
- C Zero speed value [FSOGEN.51](#)
- D The difference between SLS4 limits is 50 rpm when the scaling value is 100%
- E The difference between the scaled SLS4 limits is 25 rpm if the scaling value is 50% or less

■ **Related safety functions**

The Variable SLS function uses SAR1 parameters to monitor and/or define the deceleration ramp (Variable SLS with ramp monitoring). See section [Configuring SAR](#) on page 278.

The FSO module activates the STO function if the motor speed hits a ramp monitoring limit during the deceleration ramp (Variable SLS with ramp monitoring). See section [Configuring STO](#) on page 255.

The FSO module activates the SSE function if the motor speed hits a trip limit. See section [Configuring SSE](#) on page 269.

Configuring SMS

To configure the SMS, set the FSO parameters listed below to appropriate values using the Drive Composer pro PC tool. See parameter groups [SMS](#) on page 338 and [Safety](#) on page 309.


There are two different versions of the SMS function. Select the required version with parameter [200.71 SMS activity and version](#).

For more information on the SMS function, see page 128.

■ How to configure SMS, version 1

Example: The figure below shows an example of the SMS, version 1 set-up:

- SMS function version 1 activated ([200.71 SMS activity and version](#) = Version 1)
- positive limit 1800.0 rpm ([SMS.14 SMS trip limit positive](#) = 1800 rpm)
- negative limit -1200.0 rpm ([SMS.13 SMS trip limit negative](#) = -1200 rpm)
- SSE function configured as immediate STO ([SSE.13 SSE function](#) = Immediate STO).
- See also section [Configuring mute times](#) on page 301.




■ How to configure SMS, version 2

Example: The figure below shows an example of the SMS, version 2 set-up:

- SMS function version 2 activated ([200.71 SMS activity and version](#) = Version 2)
- SMS limit positive ([200.73 SMS limit positive](#) = 1750)
- SMS limit negative ([200.72 SMS limit negative](#) = -1150)
- SMS trip limit positive 1800.0 rpm ([SMS.14 SMS trip limit positive](#) = 1800 rpm)
- SMS trip limit negative -1200.0 rpm ([SMS.13 SMS trip limit negative](#) = -1200 rpm)
- SSE function configured as immediate STO ([SSE.13 SSE function](#) = Immediate STO).
- See also section [Configuring mute times](#) on page 301.

Note: If you also use an SLS function, the SMS positive and negative trip limits must be more than the speed defined by the corresponding SLS positive trip limit and less than the speed defined by the corresponding SLS negative trip limit, respectively.



■ Related safety functions

The FSO module activates the SSE function if the motor speed hits an SMS trip limit. See section [Configuring SSE](#) on page 269.

Configuring POUS


■ How to configure POUS

To configure the POUS function, set the FSO parameters listed below to appropriate values using the Drive Composer pro PC tool. See parameter group [POUS](#) on page 322.

For more information on the POUS function, see page 131.

Example: The figure below shows an example of the POUS function set-up:

- POUS function activated (POUS.01 POUS activity and version = Version 1)
- automatic acknowledgement (POUS.02 POUS acknowledgement = Automatic)
- redundant POUS switch connected to inputs X113:1 and DIX114:1 (POUS.11 POUS input = DI X113:1 & X114:1)
- delay for POUS complete indication: 0 (POUS.13 POUS delay for completion = 0 ms)
- POUS completed output (for example, an indication lamp) connected to single output: X114:9 (POUS.22 POUS completed output = DO X114:9).



How to configure SLS function behavior when drive modulation is lost

When it is critical for the process that the drive must be able to indicate safely if the drive modulation is lost during SLS deceleration, user must configure this behavior separately for the SLS function. Once the configuration for the modoff behavior is made, it is the same for SLS 1...SLS 4 functions and for variable SLS function.

To configure SLS functions into use (SLS1...SLS4 or variable SLS), see chapters [Configuring SLS](#) on page 279 and [Configuring Variable SLS](#) on page 283. The following parametrization is relevant for a situation where drive modulation is lost during SLS deceleration ramp and SLS function is activated when motor speed is higher than SLS limit speed.

For more information on the modoff reaction related to SLS function, see [SLS reaction when modulation is lost during deceleration ramp, with ramp monitoring](#) on page 107 and [SLS reaction when modulation is lost during deceleration ramp, with time monitoring](#) on page 114.


■ **How to configure SLSn with time monitoring if drive modulation is lost during SLS deceleration ramp**

Example 1: The figure below shows an example of the modoff situation with SLS function with time monitoring when "Modoff delay time" (parameter [SLSx.05](#)) is selected:

- Basic parametrization of the SLS function made according to chapter [Configuring SLS](#) on page 279.
- Modoff delay time monitoring is active when drive modulation is lost ([SLSx.05 SLS ramp modoff reaction](#) = Modoff delay time)
- Modoff delay time ([SLSx.06 SLS ramp modoff delay time](#) = 200 ms)

Relevant parameters for this configuration:

- Deceleration time (drive parameter 23.13 Deceleration time 1)
- SLS activation delay: 2000 ms ([SLSx.04 SLS time delay](#) = 2000 ms)
- [STO.14 Time to zero speed with STO and modoff](#): 2500 ms.




1. SLS request is activated ([SLSx.11 SLS1 input A](#) = DI X113:2 & X114:2). SLS time delay monitoring is started ([SLSx.04 SLS time delay](#) = 2000 ms). Deceleration to SLS limit speed is started (23.13 Deceleration time 1).
2. Modulation is lost. Motor starts to coast to a stop. SLS time monitoring limit is kept active also when modulation is lost ([SLSx.04 SLS time delay](#) = 2000 ms). Modoff delay time starts to run ([SLSx.06 SLS ramp modoff delay time](#) = 200 ms).
3. Modulation of the drive has not returned before the SLS ramp modoff delay time has elapsed ([SLSx.06 SLS ramp modoff delay time](#) = 200 ms). FSO activates SSE function ([SSE.13 SSE function](#)) as the modulation is lost. SSE function triggers STO function regardless of the configuration of the SSE function. STO indication goes on ([STO.21 STO output](#) = DO X113:7).
4. SLS time monitoring limit ([SLSx.04 SLS time delay](#) = 2000 ms).
5. [STO.14](#) delay starts when drive modulation is lost. If modulation does not return, SLS indication goes on after [STO.14](#) delay has elapsed.

Example 2: The figure below shows an example of the modoff situation with SLS function with time monitoring when "Monitoring active" (parameter [SLSx.05](#)) is selected:

- Basic parametrization of the SLS function made according to chapter [Configuring SLS](#) on page 279.
- Monitoring active when drive modulation is lost ([SLSx.05 SLS ramp modoff reaction](#) = Monitoring active)

Relevant parameters for this configuration:

- Deceleration time (drive parameter 23.13 Deceleration time 1)
 - SLS activation delay: 2000 ms ([SLSx.04 SLS time delay](#) = 2000 ms)
 - [STO.14 Time to zero speed with STO and modoff](#): 2500 ms.
-



1. SLS request is activated ([SLSx.11 SLS1 input A](#) = DI X113:2 & X114:2). SLS time delay monitoring is started ([SLSx.04 SLS time delay](#) = 2000 ms). Deceleration to SLS limit speed is started (drive parameter 23.13 Deceleration time 1).
2. Modulation is lost. Motor starts to coast to a stop. FSO stores last valid safe speed estimation value. SLS time monitoring limit is kept active also when modulation is lost ([SLSx.04 SLS time delay](#) = 2000 ms).
3. Last valid speed estimation value is higher than SLS trip limit speed when SLS time monitoring limit has elapsed ([SLSx.04 SLS time delay](#) = 2000 ms). STO indication goes on ([STO.21 STO output](#) = DO X113:7); see chapter [How to configure STO](#) on page 256.
4. [STO.14](#) delay starts when drive modulation is lost. If modulation does not return, SLS indication goes on after [STO.14](#) delay has elapsed.


When drive modulation is lost, last valid speed estimate is stored to FSO module until modulation comes back or monitoring limit is reached. Time monitoring is kept active also when modulation is lost during SLS deceleration ramp. The time monitoring begins when SLS is requested. A time monitoring hit due to lost modulation is generated when SLS time delay has elapsed. SLS hit is indicated and STO is activated. Drive restart is not possible until [STO.14](#) delay has elapsed.

Example 3: The figure below shows an example of the SLS function with time monitoring when "Monitoring active and modoff delay time" (parameter [SLSx.05](#)) is selected:

- Basic parametrization of the SLS function made according to chapter [Configuring SLS](#) on page 279.
- Monitoring and modoff delay time are active when drive modulation is lost ([SLSx.05 SLS ramp modoff reaction](#) = Monitoring active and modoff delay time)
- Modoff delay time ([SLSx.06 SLS ramp modoff delay time](#) = 300 ms)

Relevant parameters for this configuration:

- Deceleration time (drive parameter 23.13 Deceleration time 1)
- SLS activation delay: 2000 ms ([SLSx.04 SLS time delay](#) = 2000 ms)
- [STO.14 Time to zero speed with STO and modoff](#): 2500 ms.



1. SLS request is activated ([SLSx.11 SLS1 input A](#) = DI X113:2 & X114:2). SLS time delay monitoring is started ([SLSx.04 SLS time delay](#) = 2000 ms). Deceleration to SLS limit speed is started (23.13 Deceleration time 1).
2. Modulation is lost. Motor starts to coast to a stop. SLS time monitoring limit is kept active also when modulation is lost ([SLSx.04 SLS time delay](#) = 2000

ms). Modoff delay time starts to run ([SLSx.06 SLS ramp modoff delay time](#) = 300 ms).

3. Modulation of the drive returns before the SLS ramp modoff delay time has elapsed ([SLSx.06 SLS ramp modoff delay time](#) = 300 ms). Drive continues to decelerate according to drive parameter in step 2.
4. SLS ramp modoff delay time limit ([SLSx.06 SLS ramp modoff delay time](#) = 300 ms).
5. The speed of the drive reaches the SLS speed limit ([200.23 SLS1 limit positive](#) = 1200 rpm). SLS monitoring is activated and SLS indication goes on ([SLSx.15 SLS1 output A](#) = DO X114:7).
6. The [SLSx.04](#) time monitoring limit. SLS indication is activated at the latest.


Time monitoring is kept active also when modulation is lost during SLS deceleration ramp and [SLSx.06 SLS ramp modoff delay time](#) is set shorter than [SLSx.04 SLS time delay](#). FSO indicates SLS hit and STO is activated when [SLSx.06](#) has elapsed. Drive restart is possible until [SLSx.06](#) has elapsed.

Example 4: The figure below shows an example of the SLS function with time monitoring when "Monitoring and modoff delay time disabled" (parameter [SLSx.05](#)) is selected:

- Basic parametrization of the SLS function made according to chapter [Configuring SLS](#) on page 279.
- Monitoring and modoff delay time are disabled when drive modulation is lost ([SLSx.05 SLS ramp modoff reaction](#) = Monitoring and modoff delay time disabled)

Relevant parameters for this configuration:

- Deceleration time (drive parameter 23.13 Deceleration time 1)
 - SLS activation delay: 2000 ms ([SLSx.04 SLS time delay](#) = 2000 ms)
 - [STO.14 Time to zero speed with STO and modoff](#): 2500 ms.
-



1. SLS request is activated ([SLSx.11 SLS1 input A](#) = DI X113:2 & X114:2). SLS time delay monitoring is started ([SLSx.04 SLS time delay](#) = 2000 ms). Deceleration to SLS limit speed is started (23.13 Deceleration time 1).
2. Modulation is lost. Motor starts to coast to a stop. SLS time monitoring limit is disabled when modulation is lost ([SLSx.04 SLS time delay](#) = 2000 ms). Time to zero speed with STO and modoff starts to run ([STO.14 Time to zero speed with STO and modoff](#) = 2500 ms).
3. Modulation of the drive does not return. After [STO.14](#) has elapsed, SLS indication goes on ([SLSx.15 SLS1 output A](#) = DO X114:7).

The time monitoring of the SLS function is disabled when modulation of the drive is lost during SLS deceleration ramp. When the drive stops modulation, FSO disables the time monitoring of the SLS function and starts to wait that the motor will coast to zero speed ([STO.14 Time to zero speed with STO and modoff](#)). When [STO.14](#) has elapsed, SLS indication goes on. [STO.14](#) delay should be parametrized so that when this time has elapsed, the motor speed is 0.


■ **How to configure SLSn with ramp monitoring if drive modulation is lost during SLS deceleration ramp**

Example 1: The figure below shows an example of the modoff situation with SLS function with ramp monitoring when "Modoff delay time" (parameter [SLSx.05](#)) is selected:

- Basic parametrization of the SLS function made according to chapter [Configuring SLS](#) on page 279.
- Modoff delay time monitoring is active when drive modulation is lost ([SLSx.05 SLS ramp modoff reaction](#) = Modoff delay time)
- Modoff delay time ([SLSx.06 SLS ramp modoff delay time](#) = 200 ms)

Relevant parameters for this configuration:

- Scaling speed: 1500 rpm ([200.202 SAR speed scaling](#) = 1500 rpm)
- Deceleration time and ramp monitoring according to SAR1 parameters
 - ramp time from Scaling speed to zero: 1000 ms ([200.112 SAR1 ramp time to zero](#) = 1000 ms)
 - initial range for monitoring: 100 ms ([SARx.02 SAR initial allowed range](#) = 100 ms)
 - minimum allowed ramp time: 500 ms ([SARx.21 SAR1 min ramp time to zero](#) = 500 ms)
 - maximum allowed ramp time: 1000 ms ([SARx.22 SAR1 max ramp time to zero](#) = 1500 ms).
- [STO.14 Time to zero speed with STO and modoff](#): 2500 ms.



1. SLS request is activated ([SLSx.11 SLS1 input A](#) = DI X113:2 & X114:2). SLS ramp monitoring is activated (SAR1). Parameter [200.202 SAR speed scaling](#) (= 1500 rpm) is used as a reference point in ramp time calculations. Deceleration towards the SLS limit speed is started according to SAR1 parameters:
 - ramp time from Scaling speed to zero: 1000 ms ([200.112 SAR1 ramp time to zero](#) = 1000 ms)
 - initial range for monitoring: 100 ms ([SARx.02 SAR initial allowed range](#) = 100 ms)
 - minimum allowed ramp time: 500 ms ([SARx.21 SAR1 min ramp time to zero](#) = 500 ms)
 - maximum allowed ramp time: 1000 ms ([SARx.22 SAR1 max ramp time to zero](#) = 1500 ms).
2. Modulation is lost. Motor starts to coast to a stop. SLS ramp monitoring is disabled. Modoff delay time starts to run ([SLSx.06 SLS ramp modoff delay time](#) = 200 ms).
3. Modulation of the drive has not returned before the SLS ramp modoff delay time has elapsed ([SLSx.06 SLS ramp modoff delay time](#) = 200 ms). FSO activates STO function. STO indication goes on ([STO.21 STO output](#) = DO X113:7).
4. [STO.14](#) delay starts when drive modulation is lost. If modulation does not return, SLS indication goes on after [STO.14](#) delay has elapsed.

When drive modulation is lost, last valid speed estimate is shown to FSO module until modulation comes back or monitoring limit is reached. SAR1 monitoring is disabled when modulation is lost during SLS deceleration ramp.


Example 2: The figure below shows an example of the modoff situation with SLS function with ramp monitoring when "Monitoring active" (parameter [SLSx.05](#)) is selected:

- Basic parametrization of the SLS function made according to chapter [Configuring SLS](#) on page 279.
- Monitoring active when drive modulation is lost ([SLSx.05 SLS ramp modoff reaction](#) = Monitoring active)

300 Configuration

Relevant parameters for this configuration:

- Scaling speed: 1500 rpm ([200.202 SAR speed scaling](#) = 1500 rpm)
- Deceleration time and ramp monitoring according to SAR1 parameters
 - ramp time from Scaling speed to zero: 1000 ms ([200.112 SAR1 ramp time to zero](#) = 1000 ms)
 - initial range for monitoring: 100 ms ([SARx.02 SAR initial allowed range](#) = 100 ms)
 - minimum allowed ramp time: 500 ms ([SARx.21 SAR1 min ramp time to zero](#) = 500 ms)
 - maximum allowed ramp time: 1000 ms ([SARx.22 SAR1 max ramp time to zero](#) = 1500 ms).
- [STO.14 Time to zero speed with STO and modoff](#): 2500 ms.



1. SLS request is activated ([SLSx.11 SLS1 input A](#) = DI X113:2 & X114:2). SLS ramp monitoring is activated (SAR1). Parameter [200.202 SAR speed scaling](#) (= 1500 rpm) is used as a reference point in ramp time calculations.

Deceleration towards the SLS limit speed is started according to SAR1 parameters.

- ramp time from Scaling speed to zero: 1000 ms ([200.112 SAR1 ramp time to zero](#) = 1000 ms)
 - initial range for monitoring: 100 ms ([SARx.02 SAR initial allowed range](#) = 100 ms)
 - minimum allowed ramp time: 500 ms ([SARx.21 SAR1 min ramp time to zero](#) = 500 ms)
 - maximum allowed ramp time: 1000 ms ([SARx.22 SAR1 max ramp time to zero](#) = 1500 ms).
2. Modulation is lost. Motor starts to coast to a stop. FSO stores last valid safe speed estimation value. SLS ramp monitoring limit (SAR1) is kept active also when modulation is lost.
 3. Modulation of the drive has not returned. If [SLSx.05](#) is set to Monitoring active, SAR1 monitoring limit hit is generated based on the last valid speed estimate of FSO.
 4. [STO.14](#) delay starts when drive modulation is lost. If modulation does not return, SLS indication goes on after [STO.14](#) delay has elapsed.

When drive modulation is lost, last valid speed estimate is stored to FSO module until modulation comes back or monitoring limit is reached. Ramp monitoring is kept active also when modulation is lost during SLS deceleration ramp. The ramp monitoring is activated when SLS is requested.

Note: It is also possible to use fixed delay time until tripping fault without time/ramp monitoring by setting [SLSx.05](#) to Modoff delay time and by setting a suitable delay until tripping fault with [SLSx.06](#). With value 0, the tripping fault is generated immediately.

Note: [SLSx.05](#) and [SLSx.06](#) are used only with speed estimate and only with SLS1...SLS4 and Variable SLS functions in a situation where drive modulation is lost during deceleration to SLS speed.

Configuring mute times




WARNING! The mute time increases the response time of the safety system. This must be considered in the design of the safety system.

To minimize the effects of small transient variations in the speed measurement data, you can fine-tune the operation of the safety functions with mute time parameters. For the description of this feature, see [Mute time feature](#) on page 65.

■ How to determine values for mute time parameters

The suitable values for mute times can be determined by monitoring FSO speed signals (200.01 FSO speed ch1, 200.02 FSO speed ch2) with the Drive Composer pro tool. If possible, all transient situations within the whole speed range of the application should be monitored. Based on the results, the mute times should be set as short as possible. After the mute time parameters have been correctly set, safety functions can be validated. You can check the motor speed for motor control from the following parameters: 1.1, 1.2, and 90.1. See drive firmware manual for more information.



- A Motor torque
- B FSO speed signals
- C Motor speed estimate of the drive


■ How to configure limit hit situations

Example 1: SMS trip limit hit

This example covers trip limit situations of SMS function with synchronous machines. This example is valid when SMS-specific mute time is disabled (parameter [FSOGEN.39](#)).

- parameter [FSOGEN.39 Enable SMS mute time](#) = Disabled
- parameter [FSOGEN.31 Transient mute time](#) = 100 ms.

Note: When a synchronous machine is started, there is a possibility of short (< 100 ms) error spikes in safe speed estimate which can cause an unnecessary trip if the mute time is set too short. If the motor is rotated only in positive direction and negative SMS trip limit is set close to zero speed, there is an increased possibility that the error spike could cause an unnecessary trip.



--- Actual speed

— Safe speed estimate

— SMS trip limits

- 1 Error spike caused by the starting of the synchronous motor, spike duration 50 ms. [FSOGEN.31](#) is set longer than the error spike and the SSE is not activated.
- 2 Safe speed estimate exceeds the SMS trip limit
- 3 [FSOGEN.31 Transient mute time](#) has elapsed. SSE is activated.

This example also applies to:


- trip limit hits in the SLS1...4 and Variable SLS functions when the SLSx mute times are disabled with parameter [FSOGEN.38](#).

Example 2: SLS safe speed estimate trip limit hit situation

Note: This example is for more complex systems which cannot be properly configured with general transient mute time.

This example covers safe speed estimate trip limit situations with acceleration of an induction motor. It is possible that safe speed estimate goes above the SLS trip limit for limited time when an induction machine is accelerated with high load inertia. In this example, SLS1 function is used. Function-specific mute time is set long enough to prevent the limit hit during acceleration.

- parameter [FSOGEN.38 Enable SLSx mute times](#) = Enabled
- parameter [SLSx.17 Mute time for SLS1](#) = 1200 ms (function-specific)



--- Actual speed

— Safe speed estimate

— SLS1 trip limit positive SLSx.14

- 1 Amount of slip in safe speed estimate during acceleration
- 2 Safe speed estimate exceeds the SLS trip limit
- 3 Safe speed estimate returns below SLS trip limit before the mute time for SLS1 has elapsed. SSE is not activated and drive continues normal operation.


This example also applies to:

- Trip limit hits in the SLS2...4 and Variable SLS functions when the SLSx mute times are enabled with parameter [FSOGEN.38 Enable SLSx mute times](#)
- Trip limit hit in the SMS function when the SMS mute time ([SMS.17](#)) is enabled with parameter [FSOGEN.39 Enable SMS mute time](#).

■ How to configure mute time for zero speed detection


Example 1: Zero speed limit is reached with the SS1 function (or SSE with emergency ramp), the SBC is not used.

- parameter **FSOGEN.31 Transient mute time** = 20 ms.



Example 2: Zero speed limit is reached with the SS1 function (or SSE with emergency ramp), a negative SBC delay (parameter **SBC.12 STO SBC delay**) is configured in the STO function:

- parameter **FSOGEN.31 Transient mute time** = 20 ms.




Note: If the SBC delay (parameter **SBC.12 STO SBC delay**) is positive or zero (0 ms), the SBC and STO functions are activated at the same time.

■ **How to configure mute time for SBC speed limit detection**

Example: SBC speed limit (parameter [SBC.15](#)) is reached with the SS1 function (or SSE with emergency ramp), a negative SBC delay (parameter [SBC.12](#) [STO SBC delay](#)) is configured with the SS1 function:

- parameter [FSOGEN.31](#) [Transient mute time](#) = 20 ms.




Note: If the SBC delay (parameter [SBC.12](#) [STO SBC delay](#)) is positive or zero (0 ms), the SBC and STO functions are activated at the same time.

■ **How to configure mute time for monitoring start**

Example: The start of SLS monitoring in the SLS1 function

In this example, SLS1 function is requested from a higher speed than the SLS trip limit.

- parameter **FSOGEN.31 Transient mute time** = 20 ms.



- 1 SLS request activated
- 2 Safe speed in the middle of SLS and SLS trip limits
- 3 SLS monitoring started. SLS indication activates ([SLSx.15](#), [SLSx.16](#)).



Parameters

Contents of this chapter

This chapter describes the parameters and the status and control words of the FSO module.

FSO-12 parameters

The following table lists the FSO-12 parameters: The parameter row shows the parameter index, name, description and factory default value. The subsequent rows show the parameter value range or names, descriptions and numerical values of the selectable named alternatives. You can view and modify these parameters in the Safety settings window of the Drive Composer pro PC tool.

Note: The factory default values shown in the table can be different from the pre-set parameter values in a delivered FSO (ordered with a plus code, for example, +Q973). For more information, see section [Factory reset](#) on page 402.

Note: ABB recommends that you set drive parameter 31.22 STO indication run/stop to Warning/Warning, Event/Event or No indication/No indication. This prevents the drive from tripping on a fault each time the FSO opens the drive STO circuit. You can configure the FSO module so that it generates the necessary faults to the drive event system.

For additional information on drive parameters and their settings, see the drive firmware manual.

Index	Name/Value	Description	Factory default
Safety		General drive safety parameters	
200.11	FS module type	Module type indicator of the FSO module	FSO-12

Index	Name/Value	Description	Factory default
200.12	FS hardware version	FSO module hardware version indicator	Shows the current HW version
200.13	FS firmware version	FSO module firmware version indicator	Shows the current FW version
200.21	SLS1 activity and version	Activates or deactivates the SLS1 function and shows the version of the SLS1 function.	Disabled
	Disabled	Deactivates the SLS1 function.	
	Version 1	Activates version 1 of the SLS1 function.	
200.22	SLS1 limit negative	Sets the SLS1 negative speed limit for the drive	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
200.23	SLS1 limit positive	Sets the SLS1 positive speed limit for the drive	0.0 rpm
	0.0...35880.0 rpm	Speed	
200.31	SLS2 activity and version	Activates or deactivates the SLS2 function and shows the version of the SLS2 function.	Disabled
	Disabled	Deactivates the SLS2 function.	
	Version 1	Activates version 1 of the SLS2 function.	
200.32	SLS2 limit negative	Sets the SLS2 negative speed limit for the drive.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
200.33	SLS2 limit positive	Sets the SLS2 positive speed limit for the drive.	0.0 rpm
	0.0...35880.0 rpm	Speed	
200.41	SLS3 activity and version	Activates or deactivates the SLS3 function and shows the version of the SLS3 function.	Disabled
	Disabled	Deactivates the SLS3 function.	
	Version 1	Activates version 1 of the SLS3 function.	
200.42	SLS3 limit negative	Sets the SLS3 negative speed limit for the drive.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
200.43	SLS3 limit positive	Sets the SLS3 positive speed limit for the drive	0.0 rpm

Index	Name/Value	Description	Factory default
	0.0...35880.0 rpm	Speed	
200.51	SLS4 activity and version	Activates or deactivates the SLS4 function and shows the version of the SLS4 function.	Disabled
	Disabled	Deactivates the SLS4 function.	
	Version 1	Activates version 1 of the SLS4 function.	
200.52	SLS4 limit negative	Sets the SLS4 negative speed limit for the drive. Note: Variable SLS uses this limit as scaled. See Defining the scaled SLS4 limit and SLS4 trip limits on page 286.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
200.53	SLS4 limit positive	Sets the SLS4 positive speed limit for the drive. Note: Variable SLS uses this limit as scaled. See Defining the scaled SLS4 limit and SLS4 trip limits on page 286.	0.0 rpm
	0.0...35880.0 rpm	Speed	
200.61	SLS variable activity and version	Activates or deactivates the Variable SLS function and shows the version of the Variable SLS function. Note: This function can be activated only when the safety fieldbus is installed.	Disabled
	Disabled	Deactivates the Variable SLS function.	
	Version 1	Activates version 1 of the Variable SLS function.	
200.71	SMS activity and version	Activates or deactivates the SMS function and shows the version of the SMS function.	Disabled
	Disabled	Deactivates the SMS function.	
	Version 1	Activates version 1 of the SMS function. See section SMS function, version 1 on page 129.	
	Version 2	Activates version 2 of the SMS function. See section SMS function, version 2 on page 130.	
200.72	SMS limit negative	Sets the negative speed limit for the SMS function. Note: This parameter is used only in version 2 of the SMS function.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	

312 Parameters

Index	Name/Value	Description	Factory default
200.73	SMS limit positive	Sets the positive speed limit for the SMS function. Note: This parameter is used only in version 2 of the SMS function.	0.0 rpm
	0.0...35880.0 rpm	Speed	
200.101	SAR0 version	Shows the version of the SAR0 function.	Version 1
	Version 1	Version 1.	
200.102	SAR0 ramp time to zero	Sets the target time for the SAR0 ramp (used in the SSE function). Target time = Time in which the drive decelerates the motor from speed 200.202 SAR speed scaling to zero.	1 ms
	1...1,800,000 ms	Time	
200.111	SAR1 version	Shows the version of the SAR1 function.	Version 1
	Version 1	Version 1.	
200.112	SAR1 ramp time to zero	Sets the target time for the SAR1 ramp (used in the SS1 and SLS functions). Target time = Time in which the drive decelerates the motor from speed 200.202 SAR speed scaling to zero. Note: With value 0 ms, the drive (parameter 23.23 Emergency stop time) defines the safe stop ramp. The FSO module monitors the actual ramp using SAR1 parameters (ramp monitoring) or parameter SS1.14 SS1-t delay for STO (time monitoring).	1 ms
	0...1,800,000 ms	Time.	
200.201	Drive general settings version	Shows the version of the drive general safety settings (includes parameters 200.202 , 200.222 , 200.223 and 200.254).	Version 1
	Version 1	Version 1.	
200.202	SAR speed scaling	Sets a speed value that the FSO module uses as a reference point in ramp time calculations. See section Ramp monitoring on page 58 .	1500 rpm
	0...35880 rpm	Speed	

Index	Name/Value	Description	Factory default
200.222	Safety bus type	Sets the type of the safety fieldbus (if used). Note: To activate the safety fieldbus, you must also set parameter SBUSGEN. 01 SBUS activity and version to value Version 1 .	Not used
	Not used	The safety fieldbus is not used.	
	PROFIsafe	PROFIsafe	
200.223	Safety fieldbus adapter slot	Sets the slot in which the safety fieldbus adapter is installed. Note: The slots on the drive control board are defined by drive parameters 50.01 (FBA A) and 50.31 (FBA B). Refer to the drive firmware manual.	FBA A
	FBA A	The safety fieldbus adapter is in slot FBA A.	
	FBA B	The safety fieldbus adapter is in slot FBA B.	
200.254	CRC of the configuration	Shows the FSO configuration checksum.	0
	0...65535	Checksum	

FSOGEN		General FSO parameters	
FSOGEN.01	FSO general settings version	Shows the version of the FSO general parameter group (includes parameter groups FSOGEN and SAFEIO and parameters SLSx.02 , SLSx.03 , SLSx.04 , SARx.02).	Version 1
	Version 1	Version 1.	
FSOGEN.11	Stop completed output	Sets the digital output that indicates the completion of any stop function. Active when the FSO module has completed the STO, SSE or SS1 function.	None
	None	No input connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	

Index	Name/Value	Description	Factory default
	DO X114:9	Single output X114:9	
FSOGEN.21	Motor nominal speed	Sets the synchronous motor speed.	100.0 rpm
	1.0 ...35880.0 rpm	Speed	
FSOGEN.22	Motor nominal frequency	Sets the nominal motor frequency.	1.00 Hz
	1.00...598.00 Hz	Frequency	
FSOGEN.31	Transient mute time	Sets the mute time for the safe speed functions. The FSO module waits for the transient mute time before it acts after a ramp monitoring or trip limit hit, or after the zero speed limit is reached.	0 ms
	0...1000 ms	Time	
FSOGEN.38	Enable SLSx mute times	Enables SLS-specific mute times which are used in SLS limit hit situations. These mute times can be set with parameters SLSx.17 , SLSx.27 , SLSx.37 , SLSx.47 and SLSx.57 . When this parameter is disabled, FSOGEN.31 is used in limit hit situations.	Disabled
	Disabled	Deactivates SLSx mute times	
	Enabled	Activates SLSx mute times	
FSOGEN.39	Enable SMS mute time	Enables SMS-specific mute time, which is used in limit hit situations and can be set with parameter SMS.17 . When this parameter is disabled, FSOGEN.31 is used in limit hit situations.	Disabled
	Disabled	Deactivates SMS mute time	
	Enabled	Activates SMS mute time	
FSOGEN.41	Power-up acknowledgement	Sets the power-up acknowledgement method. Note: If a safety function request is active when the FSO module is rebooted, the request must be removed before the power-up acknowledgement is accepted.	Manual
	Manual	The FSO module reads an external acknowledgement signal through the digital input defined by parameter FSOGEN.42 Acknowledgement button input .	

Index	Name/Value	Description	Factory default
	Automatic	The FSO module generates the acknowledgement signal automatically after the power-up.	
	Safebus	The FSO module expects an external acknowledgement signal from the safety fieldbus after the power-up.	
	Manual_Safebus	The FSO module expects an external acknowledgement signal either from a digital input or from the safety fieldbus after the power-up.	
FSOGEN.42	Acknowledgement button input	Sets the digital input that is connected to the button for acknowledgement operations.	None
	None	No input connected	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
FSOGEN.51	Zero speed without encoder	Sets the zero speed limit for ramp stop safety functions. Used to define when the safety function is completed and can be acknowledged. Note: This is the absolute value. The same value is used in both positive and negative directions. Note: You cannot set trip limits below this value.	0.0 rpm
	0.0...600.0 rpm	Speed	
FSOGEN.61	STO indication ext request	Sets the type of the event that the FSO module generates and sends to the drive after external requests that end to a successful activation of the drive STO function (STO, SSE or SS1). Note: When the FSO module triggers the STO function in fault situations, it always generates a fault.	Fault
	None	No event generated	
	Fault	Fault generated	

Index	Name/Value	Description	Factory default
	Warning	Warning generated	
	Event	Pure event generated	
FSOGEN.62	STO indication safety limit	Sets the type of the event that the FSO module generates for limit hits in the SLS1, ..., SLS4 and SMS functions and for limit hits during ramp and time monitoring of safety ramps SAR0 and SAR1. Note: When the FSO module triggers the STO function in fault situations, it always generates a fault.	Fault
	None	No event generated	
	Fault	Fault generated	
	Warning	Warning generated	
	Event	Pure event generated	
FSOGEN.254	CRC of the whole configuration	Shows the FSO configuration checksum.	0
	0...65535	Checksum	

STO		Parameters for the STO function	
STO.01	STO version	Shows the version of the STO function.	Version 1
	Version 1	Version 1.	
STO.02	STO acknowledgement	Sets the acknowledgement method used in the STO, SSE and SS1 functions. See section Acknowledgement methods on page 54 for more information on different acknowledgement methods.	Manual
	Manual	The FSO module reads the external STO acknowledgement signal through the digital input defined by parameter FSOGEN.42 Acknowledgement button input . The FSO module accepts the acknowledgement after the STO, SSE or SS1 request has been removed and the stop function is completed (output defined by parameter FSOGEN.11 STO completed output is active).	
	Automatic	The FSO module generates the STO acknowledgement signal automatically after the STO, SSE or SS1 request has been removed and the stop function is completed (output defined by parameter FSOGEN.11 STO completed output is active).	

Index	Name/Value	Description	Factory default
	Safebus	The FSO module expects an external STO acknowledgement signal from the safety fieldbus after the STO, SSE or SS1 request has been removed and the stop function is completed (output defined by parameter FSOGEN.11 STO completed output is active).	
	Manual_Safebus	The FSO module expects an external STO acknowledgement signal either from a digital input or from the safety fieldbus after the STO, SSE or SS1 request has been removed and the stop function is completed (output defined by parameter FSOGEN.11 STO completed output is active).	
STO.11	STO input A	Sets the digital input that is connected to the primary input of the STO function.	DI X113:1 & X114:1
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
STO.12	STO input B	Sets the digital input that is connected to the secondary input of the STO function. The secondary input is mostly used for the cascade connection. See parameters SAFEIO.12 Cascade A and SAFEIO.13 Cascade B .	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	

Index	Name/Value	Description	Factory default
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
STO.13	Restart delay after STO	<p>Sets the time after which the acknowledgement of the FSO module and restart of the drive are allowed after the FSO has activated the STO function and opened the drive STO circuit. With this parameter, you can allow a restart of the drive before the motor has stopped (fly-start).</p> <p>This parameter is relevant only when an external request activates the STO function.</p> <p>If you do not want to use the fly-start feature, set this parameter to the same value as parameter STO.14 Time to zero speed with STO and modoff.</p>	3,600,000 ms
	0...3,600,000 ms	Time	

Index	Name/Value	Description	Factory default
STO.14	Time to zero speed with STO and modoff	<p>Sets the time that is needed to coast the motor to a standstill from maximum process speed. If this time is not known, it can be measured with Drive Composer pro PC tool when an encoder is used for motor control (otherwise you have to make sure that the motor shaft has stopped rotating by other means, eg, visually.).</p> <p>Acknowledgement is allowed after coast stop in the STO, SSE and SS1 functions (when SBC is not used).</p> <p>If SBC is used, see parameter SBC.13 SBC time to zero speed.</p> <p>If an external request activates the STO function, this parameter sets the time after which the function is completed and the STO completed indication goes on. In this case, parameter STO.13 Restart delay after STO defines the time after which the acknowledgement is allowed.</p> <p>If the drive STO is activated or modulation stopped while a monitoring safety function is indicating “unsafe”, after this time acknowledgement is allowed. For example, if the drive modulation is lost during SLS deceleration ramp, SLS OK will be indicated after this time has elapsed. See section SLS trip limit hits on page 121.</p>	3,600,000 ms
	0...3,600,000 ms	Time	
STO.21	STO output	<p>Sets the digital output that indicates the status of the STO function in the drive. Active when the STO circuit in the drive is open.</p> <p>Note: In a cascade connection, this indicates the activity of the STO function of the FSO module.</p>	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	

Index	Name/Value	Description	Factory default
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
STO.22	STO completed output	Sets the digital output that indicates the completion of the STO function. See the diagrams in section Safe torque off (STO) on page 67.	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	

SBC		Parameters for the SBC function	
SBC.01	SBC version	Shows the version of the SBC function.	Version 1
	Version 1	Version 1.	
SBC.11	STO SBC usage	Sets how the mechanical brake (SBC) is used together with the STO function. Note: This parameter is used also in the SSE function when it is configured as Immediate STO (parameter SSE.13 SSE function = Immediate STO).	Delayed brake
	None	No brake	
	Delayed brake	Time controlled brake. Parameter SBC.12 STO SBC delay defines the delay.	

Index	Name/Value	Description	Factory default
	SBC.12 STO SBC delay	<p>Sets the time when the SBC function will be activated in relation to the activation of the STO function. A negative value means that the FSO module activates the SBC before the drive STO function.</p> <p>If the value is 0 ms, the FSO activates the drive STO and SBC functions at the same time.</p> <p><u>STO function and SSE with immediate STO:</u> This parameter is valid if parameter SBC.11 STO SBC usage has value Delayed brake.</p> <p><u>SSE with emergency ramp and SS1 function:</u> This parameter is valid if parameter SBC.15 SSE/SS1 SBC speed is not zero. Only a negative value and zero are used. If the value is positive, it is regarded as zero.</p> <p>Note: You must include the mechanical brake delays in this value.</p>	3,600,000 ms
	-5000... 3,600,000 ms	Time	
	SBC.13 SBC time to zero speed	<p>Sets the estimated time from the SBC activation to the moment when the safety function is completed and the STO completed indication (parameter STO.22) goes on (ie, motor has stopped and the system can be set to a safe state).</p> <p>Must be configured to the estimated time in which the external brake decelerates the motor to a stop from the maximum speed.</p> <p>The total delay from the moment the FSO module has activated the drive STO function until the system is in safe state becomes: STO SBC delay (SBC.12) + SBC time to zero speed (SBC.13).</p> <p>Note: If the value of SBC time to zero speed (SBC.13) is less than 800 ms (the feedback delay), the total delay becomes: STO SBC delay (SBC.12) + 800 ms.</p>	3,600,000 ms
	0...3,600,000 ms	Time	

Index	Name/Value	Description	Factory default
SBC.15	SSE/SS1 SBC speed	Sets the speed below which the FSO module activates the brake (SBC) while ramping in the SSE and SS1 functions. If the value is 0.0 rpm, this feature is not in use. Note: This is the absolute value. The same value is used in both positive and negative directions.	0.0 rpm
	0.0...1000.0 rpm	Speed	
SBC.21	SBC output	Sets the digital output that is connected to the SBC output (brake relays).	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
SBC.22	SBC feedback action	Sets the action that the FSO module takes when there is a problem with the SBC feedback.	No STO
	STO	The FSO module goes into the Fail-safe mode and activates the drive STO function.	
	No STO	The FSO module sends a warning to the drive.	

POUS		Parameters for the POUS function	
POUS.01	POUS activity and version	Activates or deactivates the POUS function and shows the version of the POUS function.	Disabled
	Disabled	Deactivates the POUS function.	
	Version 1	Activates version 1 of the POUS function.	
POUS.02	POUS acknowledgement	Sets the POUS acknowledgement method.	Manual
	Manual	The FSO module reads the POUS acknowledgement signal through the digital input defined by parameter FSOGEN.42 Acknowledgement button input . The FSO module accepts the acknowledgement after the POUS request has been removed.	
	Automatic	The FSO module generates the POUS acknowledgement signal automatically after the POUS request has been removed.	

Index	Name/Value	Description	Factory default
	Safebus	The FSO module expects an external POUS acknowledgement signal from the safety fieldbus after the POUS request has been removed.	
	Manual_Safebus	The FSO module expects an external POUS acknowledgement signal either from a digital input or from the safety fieldbus after the POUS request have been removed.	
POUS.11	POUS input	Sets the digital input that is connected to the POUS input.	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
POUS.13	POUS delay for completion	Sets the delay for the activation of the POUS complete indication after the POUS request.	0 ms
	0...3,600,000 ms	Time	
POUS.21	POUS output	Sets the digital output that indicates the activity of the POUS function. Active from the POUS request until the function has been acknowledged.	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	

Index	Name/Value	Description	Factory default
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
POUS.22	POUS completed output	Set the digital output that indicates the completion of the POUS function. Active after the time defined by parameter POUS.13 POUS delay for completion has elapsed from the POUS request until the POUS request has been removed. Note: Connect the POUS indication lamp to this output.	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	

SSE		Parameters for the SSE function	
SSE.01	SSE version	Shows the version of the SSE function.	Version 1
	Version 1	Version 1.	
SSE.11	SSE input A	Sets the digital input that is connected to the primary input of the SSE function.	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	

Index	Name/Value	Description	Factory default
SSE.12	SSE input B	Sets the digital input that is connected to the secondary input of the SSE function. The secondary input is mostly used for the cascade connection. See parameters SAFEIO.12 Cascade A and SAFEIO.13 Cascade B .	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
SSE.13	SSE function	Sets the type of the SSE function.	Emergency ramp
	Immediate STO	The FSO module activates the drive STO immediately after the SSE request.	
	Emergency ramp	The FSO module activates the drive STO after an emergency ramp.	
SSE.14	SSE monitoring method	Sets the method used for the SSE emergency ramp monitoring. This parameter is relevant only if parameter SSE.13 SSE function is set to Emergency ramp .	Ramp
	Ramp	Ramp monitoring. SAR0 parameters define the emergency ramp and monitoring limits. See parameters 200.102 , SARx.11 , SARx.12 and SARx.02 .	
	Time	Time monitoring. Parameter 200.102 SAR0 ramp time to zero defines the emergency ramp and it is monitored with parameter SSE.15 SSE delay for STO .	

Index	Name/Value	Description	Factory default
SSE.15	SSE delay for STO	Sets the delay for STO activation after the SSE request. This parameter is relevant only if parameter SSE.13 SSE function is set to Emergency ramp , time monitoring is used (SSE.14 SSE monitoring method = Time) and the motor speed does not follow the ramp.	3,600,000 ms
	0...3,600,000 ms	Time	
SSE.16	SSE ramp zero speed delay for STO	Sets an extra delay time for the drive STO (and SBC, if used) activation at the zero speed limit in the SSE with emergency ramp function. With this parameter, the FSO module delays the STO activation so that the drive is able to reach the shaft zero speed before the FSO module activates the drive STO function. The delay counter starts when the motor speed reaches the zero speed limit (parameter FSOGEN.51). After this delay has elapsed, the FSO module activates the drive STO function. You can use this parameter when the motor rotates a heavy load (high inertia). Note: The FSO module activates the drive STO immediately if the drive stops modulating before this delay has passed (that is, the motor actual speed reaches 0 rpm).	30,000 ms
	0...30,000 ms	Time	
SSE.21	SSE output	Sets the digital output that indicates the activity of the SSE function. Active from the SSE request until the function has been acknowledged.	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	

Index	Name/Value	Description	Factory default
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
SSE.22	SSE completed output	Sets the digital output that indicates the completion of the SSE function. See the diagrams in section Safe stop emergency (SSE) on page 86.	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	

SS1		Parameters for the SS1 function	
SS1.01	SS1 activity and version	Activates or deactivates the SS1 function and shows the version of the SS1 function.	Disabled
	Disabled	Deactivates the SS1 function.	
	Version 1	Activates version 1 of the SS1 function.	
SS1.11	SS1 input A	Sets the digital input that is connected to the primary input of the SS1 function.	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	

Index	Name/Value	Description	Factory default
SS1.12	SS1 input B	Sets the digital input that is connected to the secondary input of the SS1 function. The secondary input is mostly used for the cascade connection. See parameters SAFEIO.12 Cascade A and SAFEIO.13 Cascade B .	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
SS1.13	SS1 type	Sets the SS1 type, that is, the method used for the SS1 monitoring.	SS1-r
	SS1-r	Ramp monitoring. SAR1 parameters define the stop ramp and the monitoring limits. See parameters 200.112 , SARx.21 , SARx.22 and SARx.02 .	
	SS1-t	Time monitoring. SAR1 parameter 200.112 define the stop ramp and it is monitored with parameter SS1.14 SS1-t delay for STO .	
SS1.14	SS1-t delay for STO	Sets the time monitoring limit for SS1-t function. See parameter SS1.13 SS1 type . FSO will activate STO function if the zero speed limit is not reached within this target time. Note: This parameter is relevant only if time monitoring is used.	3,600,000 ms
	0...3,600,000 ms	Time	

Index	Name/Value	Description	Factory default
SS1.15	SS1-r ramp zero speed delay for STO	<p>Sets an extra delay time for the drive STO (and SBC, if used) activation at the zero speed limit in the SS1 function.</p> <p>The FSO module uses a speed estimation, which may differ, due to motor slip, from the actual shaft speed of the motor). With this parameter, the FSO module delays the STO activation so that the drive is able to reach the shaft zero speed before the FSO module activates the STO function.</p> <p>The delay counter starts when the motor speed reaches the zero speed limit (parameter FSOGEN.51). After this delay has elapsed, the FSO module activates the drive STO function. You can use this parameter when the motor rotates a heavy load (high inertia).</p> <p>Note: The FSO module activates the drive STO immediately if the drive stops modulating before the delay has passed (that is, the motor actual speed reaches 0 rpm).</p>	0 ms
	0...120,000 ms	Time	
SS1.21	SS1 output	Sets the digital output that indicates the activity of the SS1 function. Active from the SS1 request until the function has been acknowledged.	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
SS1.22	SS1 completed output	Sets the digital output that indicates the completion of the SS1 function. See the diagrams in section Safe stop 1 (SS1) on page 72 .	None
	None	No output connected	

Index	Name/Value	Description	Factory default
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	

SLSx		Parameters for the SLS1...4 functions	
SLSx.02	SLS acknowledgement	Sets the acknowledgement method used in the SLS1...4 functions.	Manual
	Manual	The FSO module reads the external SLS acknowledgement signal through the digital input defined by parameter FSOGEN.42 Acknowledgement button input . The FSO module accepts the acknowledgement after the SLS request has been removed and the SLS limit has been achieved (that is, SLS monitoring is on).	
	Automatic	The FSO module generates the SLS acknowledgement signal automatically after the SLS request has been removed and the SLS limit has been achieved (that is, SLS monitoring is on).	
	Safebus	The FSO module expects an external SLS acknowledgement signal from the safety fieldbus. The FSO module accepts the acknowledgement after the SLS request has been removed and the SLS limit has been achieved (that is, SLS monitoring is on).	
	Manual_Safebus	The FSO module expects an external SLS acknowledgement signal either from a digital input or from the safety fieldbus. The FSO module accepts the acknowledgement after the SLS request has been removed and the SLS limit has been achieved (that is, SLS monitoring is on).	

Index	Name/Value	Description	Factory default
SLSx.03	SLS activation monitoring method	Sets the monitoring method that is used in SLS activation.	Ramp
	Ramp	Ramp monitoring. SAR1 parameters define the deceleration ramp and monitoring limits. See parameters 200.112 , SARx.21 , SARx.22 and SARx.02 .	
	Time	Time monitoring. The drive (parameter 23.13 or 23.15) defines the deceleration ramp and it is monitored with parameter SLSx.04 SLS time delay .	
SLSx.04	SLS time delay	Sets the latest activation time for SLS monitoring after an SLS request. This parameter is relevant only if time monitoring is used. See parameter SLSx.03 SLS activation monitoring method . Note: With time monitoring, when Monitoring active and Modoff delay time are selected, SLSx.04 and SLSx.06 time must be set shorter than STO.14 , otherwise STO is not activated due to limit hit when drive modulation is lost with SLS function. Note: If the value of this parameter is set to 0 ms, SLS monitoring will be started immediately regardless of the motor speed.	0 ms
	0...4,000,000 ms	Time	
SLSx.05	SLS ramp modoff reaction	Selects the fault reaction in case the drive modulation is lost during the SLS deceleration ramp, when SLS is activated from speed which is higher than SLS limit speed.	Modoff delay time
	Modoff delay time	If drive modulation is lost during the SLS deceleration ramp and the modulation does not return within SLSx.06 time, FSO activates STO. Note: If speed is below SLS limit (eg, 200.22), modoff is ignored.	

Index	Name/Value	Description	Factory default
	Monitoring active	If drive modulation is lost during the SLS deceleration ramp, SLS ramp or time monitoring (SLSx.03) is kept on. Limit hit is generated based on the last valid speed estimate information of FSO.	
	Monitoring active and Modoff delay time	Both Modoff delay time and Monitoring active values are in use: FSO generates the hit based on whichever condition is met first and activates the STO.	
	Monitoring and modoff delay time are disabled	If drive modulation is lost during the SLS deceleration ramp, FSO does not activate STO. SLS indication (eg, SLSx.15) goes on after STO.14 time has elapsed.	
SLSx.06	SLS ramp modoff delay time	Time to trip when modulation is lost. Note: This time must be set shorter than STO.14 , otherwise STO is not activated due to limit hit when drive modulation is lost with SLS function.	0 ms
	0...3,600,000 ms	Time	
SLSx.11	SLS1 input A	Sets the primary digital input for the SLS1 function.	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
SLSx.12	SLS1 input B	Sets the secondary digital input for the SLS1 function. The secondary input is mostly used for cascade connection (only SLS1 can be cascaded). See parameters SAFEIO.12 Cascade A and SAFEIO.13 Cascade B .	None

Index	Name/Value	Description	Factory default
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
SLSx.13	SLS1 trip limit negative	Sets the SLS1 negative speed limit that trips the drive.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
SLSx.14	SLS1 trip limit positive	Sets the SLS1 positive speed limit that trips the drive.	0.0 rpm
	0.0...35880.0 rpm	Speed	
SLSx.15	SLS1 output A	Sets the primary digital output for the SLS1 function. Active when SLS1 function is active and the motor speed is below the SLS1 limit (that is, when the SLS1 monitoring is on).	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	

Index	Name/Value	Description	Factory default
SLSx.16	SLS1 output B	Sets the secondary digital output for the SLS1 function. Active when SLS1 function is active and the motor speed is below the SLS1 limit (that is, when the SLS1 monitoring is on). The secondary output is mostly used for cascade connection. See parameters SAFEIO.12 Cascade A and SAFEIO.13 Cascade B .	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
SLSx.17	Mute time for SLS1	Sets the SLS1 specific mute time for limit hit situations.	0 ms
	0...10000 ms		
SLSx.21	SLS2 input	Sets the digital input for the SLS2 function.	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	

Index	Name/Value	Description	Factory default
SLSx.22	SLS2 trip limit negative	Sets the SLS2 negative speed limit that trips the drive.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
SLSx.23	SLS2 trip limit positive	Sets the SLS2 positive speed limit that trips the drive.	0.0 rpm
	0.0...35880.0 rpm	Speed	
SLSx.24	SLS2 output	Sets the digital output for SLS2 function. Active when SLS2 function is active and the motor speed is below the SLS2 limit (that is, when the SLS2 monitoring is on).	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
SLSx.27	Mute time for SLS2	Sets the SLS2 specific mute time for limit hit situations.	0 ms
	0...10000 ms		
SLSx.31	SLS3 input	Sets the digital input for the SLS3 function.	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	

Index	Name/Value	Description	Factory default
	DI X114:4	Single input X114:4	
SLSx.32	SLS3 trip limit negative	SLS3 negative speed limit that trips the drive.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
SLSx.33	SLS3 trip limit positive	Sets the SLS3 positive speed limit that trips the drive.	0.0 rpm
	0.0...35880.0 rpm	Speed	
SLSx.34	SLS3 output	Sets the digital output for the SLS3 function. Active when SLS3 function is active and the motor speed is below the SLS3 limit (that is, when the SLS3 monitoring is on).	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
SLSx.37	Mute time for SLS3	Sets the SLS3 specific mute time for limit hit situations.	0 ms
	0...10000 ms		
SLSx.41	SLS4 input	Sets the digital input for the SLS4 function.	None
	None	No input connected	
	DI X113:1 & X114:1	Redundant input X113:1 & X114:1	
	DI X113:2 & X114:2	Redundant input X113:2 & X114:2	
	DI X113:3 & X114:3	Redundant input X113:3 & X114:3	
	DI X113:4 & X114:4	Redundant input X113:4 & X114:4	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	

Index	Name/Value	Description	Factory default
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
SLSx.42	SLS4 trip limit negative	Sets the SLS4 negative speed limit that trips the drive. Note: Variable SLS uses this limit as scaled. See Defining the scaled SLS4 limit and SLS4 trip limits on page 286.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
SLSx.43	SLS4 trip limit positive	Sets the SLS4 positive speed limit that trips the drive. Note: Variable SLS uses this limit as scaled. See Defining the scaled SLS4 limit and SLS4 trip limits on page 286.	0.0 rpm
	0.0...35880.0 rpm	Speed	
SLSx.44	SLS4 output	Sets the digital output for the SLS4 function. Active when SLS4 function is active and the motor speed is below the SLS4 limit (that is, when the SLS4 monitoring is on).	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
SLSx.47	Mute time for SLS4	Sets the SLS4 specific mute time for limit hit situations.	0 ms
	0...10000 ms		
SLSx.51	Variable SLS output	Sets the digital output for the Variable SLS function. Active when Variable SLS function is active and the motor speed is below the Variable SLS limit (that is, when the Variable SLS monitoring is on).	None
	None	No output connected	

Index	Name/Value	Description	Factory default
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
	DO X113:7	Single output X113:7	
	DO X113:8	Single output X113:8	
	DO X113:9	Single output X113:9	
	DO X114:7	Single output X114:7	
	DO X114:8	Single output X114:8	
	DO X114:9	Single output X114:9	
SLSx.57	Mute time for variable SLS	Sets the variable SLS specific mute time for limit hit situations.	0 ms
	0...10000 ms		

SMS		Parameters for the SMS function	
SMS.13	SMS trip limit negative	Sets the negative speed limit that trips the drive for the SMS function.	0.0 rpm
	-35880.0 ...0.0 rpm	Speed	
SMS.14	SMS trip limit positive	Sets the positive speed limit that trips the drive for the SMS function.	0.0 rpm
	0.0 ...35880.0 rpm	Speed	
SMS.17	Mute time for SMS	Sets the SMS specific mute time for limit hit situations.	0 ms
	0...5000 ms		

SARx		Parameters for SARx ramps	
SARx.02	SAR initial allowed range	Sets the initial allowed range for the SARx ramp. This parameter moves the location of the maximum monitoring ramp forward on the time axis, when monitoring is started. The slope of the ramp stays the same as defined with parameters 200.202 and SARx.12 (SAR0) or SARx.22 (SAR1). For more information, refer to section Ramp monitoring on page 58.	0 ms
	0...60,000 ms	Time	
SARx.11	SAR0 min ramp time to zero	Sets the minimum ramp time for the SAR0 ramp monitoring.	0 ms

Index	Name/Value	Description	Factory default
	0...1,799,999 ms	Time. Note: With value 0 ms, the ramp is not monitored	
SARx.12	SAR0 max ramp time to zero	Sets the maximum ramp time for the SAR0 ramp monitoring.	1 ms
	1...3,600,000 ms	Time	
SARx.21	SAR1 min ramp time to zero	Sets the minimum ramp time for the SAR1 ramp monitoring.	0 ms
	0...1,799,999 ms	Time Note: With value 0 ms, the ramp is not monitored	
SARx.22	SAR1 max ramp time to zero	Sets the maximum ramp time for the SAR1 ramp monitoring.	1 ms
	1...3,600,000 ms	Time	

SAFEIO		Parameters for FSO inputs and outputs	
SAFEIO.11	M/F mode for cascade	Sets the master/follower mode of the FSO module for both cascade connections A and B separately.	A = follower, B = follower
	A = follower, B = follower	The module is a follower on cascade connection A and a follower on cascade connection B.	
	A = master, B = follower	The module is the master on cascade connection A and a follower on cascade connection B.	
	A = follower, B = master	The module is a follower on cascade connection A and the master on cascade connection B.	
	A = master, B = master	The module is the master on cascade connection A and the master on cascade connection B.	
SAFEIO.12	Cascade A	Sets the cascade connection A for the FSO module. For each FSO module in cascade A, the digital input connected to the safety function is also internally connected to the corresponding digital output of the FSO module (digital input -> digital output). This resembles a master/follower connection. Refer to section Cascade on page 63.	None
	None	Not cascaded	
	X113:1 & X114:1 -> X113:7 & X114:7	Redundant cascade X113:1 & X114:1 -> X113:7 & X114:7	

Index	Name/Value	Description	Factory default
	X113:2 & X114:2 -> X113:8 & X114:8	Redundant cascade X113:2 & X114:2 -> X113:8 & X114:8	
	X113:3 & X114:3 -> X113:9 & X114:9	Redundant cascade X113:3 & X114:3 -> X113:9 & X114:9	
	X113:1 -> X113:7	Single cascade X113:1 -> X113:7	
	X113:2 -> X113:8	Single cascade X113:2 -> X113:8	
	X113:3 -> X113:9	Single cascade X113:3 -> X113:9	
	X114:1 -> X114:7	Single cascade X114:1 -> X114:7	
	X114:2 -> X114:8	Single cascade X114:2 -> X114:8	
	X114:3 -> X114:9	Single cascade X114:3 -> X114:9	
SAFEIO.13	Cascade B	Sets the cascade connection B for the FSO module. For each FSO module in cascade B, the digital input connected to the safety function is also internally connected to the corresponding digital output of the FSO module (digital input -> digital output). Refer to section Cascade on page 63.	None
	None	Not cascaded	
	X113:1 & X114:1 -> X113:7 & X114:7	Redundant cascade X113:1 & X114:1 -> X113:7 & X114:7	
	X113:2 & X114:2 -> X113:8 & X114:8	Redundant cascade X113:2 & X114:2 -> X113:8 & X114:8	
	X113:3 & X114:3 -> X113:9 & X114:9	Redundant cascade X113:3 & X114:3 -> X113:9 & X114:9	
	X113:1 -> X113:7	Single cascade X113:1 -> X113:7	
	X113:2 -> X113:8	Single cascade X113:2 -> X113:8	
	X113:3 -> X113:9	Single cascade X113:3 -> X113:9	
	X114:1 -> X114:7	Single cascade X114:1 -> X114:7	
	X114:2 -> X114:8	Single cascade X114:2 -> X114:8	
	X114:3 -> X114:9	Single cascade X114:3 -> X114:9	

Index	Name/Value	Description	Factory default
SAFEIO.21	Safety relay 1 output	<p>Sets the digital output connected to the safety relay 1.</p> <p>To connect the safety relay to a certain safety function, you must set the same digital outputs in the output parameter for that safety function. For example, if you set parameter SBC.21 SBC output to the same value as you set for the safety relay output, the safety relay is active when the SBC function is active.</p> <p>Note: The output must always be redundant. Otherwise the feedback signal of the safety relay is not used (see parameter SAFEIO.22 Safety relay 1 feedback).</p>	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
SAFEIO.22	Safety relay 1 feedback	<p>Sets the digital feedback input of safety relay 1.</p> <p>Parameter SAFEIO.23 Safety relay 1 feedback type sets the type of the feedback input.</p>	None
	None	No input connected	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
SAFEIO.23	Safety relay 1 feedback type	<p>Sets the type of the feedback signal for safety relay 1.</p> <p>Note: FSO reads the feedback signal in every state change situation, ie, when STO is activated. The feedback delay is 800 ms for both feedback types, that is, a feedback signal from the safety relay must be received within 800 ms.</p>	Mechanically linked NC contacts

Index	Name/Value	Description	Factory default
	Mechanically linked NC contacts	Feedback of the safety relay is NC (inverted state compared with the relay).	
	Mechanically linked NO contacts	Feedback of the safety relay is NO (same state compared with the relay).	
SAFEIO.24	Safety relay 2 output	Sets the digital output for safety relay 2. See also parameter SAFEIO.21 Safety relay 1 output . Note: The output must always be redundant. Otherwise the feedback signal of the safety relay is not used (see SAFEIO.25 Safety relay 2 feedback).	None
	None	No output connected	
	DO X113:7 & X114:7	Redundant output X113:7 & X114:7	
	DO X113:8 & X114:8	Redundant output X113:8 & X114:8	
	DO X113:9 & X114:9	Redundant output X113:9 & X114:9	
SAFEIO.25	Safety relay 2 feedback	Sets the digital feedback input of safety relay 2. Parameter SAFEIO.26 Safety relay 2 feedback type sets the type of the feedback input.	None
	None	No input connected	
	DI X113:1	Single input X113:1	
	DI X113:2	Single input X113:2	
	DI X113:3	Single input X113:3	
	DI X113:4	Single input X113:4	
	DI X114:1	Single input X114:1	
	DI X114:2	Single input X114:2	
	DI X114:3	Single input X114:3	
	DI X114:4	Single input X114:4	
SAFEIO.26	Safety relay 2 feedback type	Sets the type of the feedback signal for safety relay 2. Note: The feedback delay is 800 ms for both feedback types, that is, a feedback signal from the safety relay must be received within 800 ms.	Mechanically linked NC contacts
	Mechanically linked NC contacts	Feedback of the safety relay is NC (inverted state compared with the relay).	
	Mechanically linked NO contacts	Feedback of the safety relay is NO (same state compared with the relay).	

Index	Name/Value	Description	Factory default
SAFEIO.31	DI diagnostic pulse length	Sets the length of the diagnostic pulse for digital inputs.	1 ms
	0.5 ms	Length of the diagnostic pulse is 0.5 ms.	
	1 ms	Length of the diagnostic pulse is 1 ms.	
	2 ms	Length of the diagnostic pulse is 2 ms.	
SAFEIO.32	DI diagnostic pulse period	Sets the time during which the FSO module must receive at least one whole diagnostic pulse.	10,000 ms
	50...59,000 ms	Time	
SAFEIO.33	DI X113:1 diag pulse on/off	Sets the diagnostic pulse of digital input X113:1 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.34	DI X113:2 diag pulse on/off	Sets the diagnostic pulse of digital input X113:2 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.35	DI X113:3 diag pulse on/off	Sets the diagnostic pulse of digital input X113:3 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.36	DI X113:4 diag pulse on/off	Sets the diagnostic pulse of digital input X113:4 on or off	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.37	DI X114:1 diag pulse on/off	Sets the diagnostic pulse of digital input X114:1 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.38	DI X114:2 diag pulse on/off	Sets the diagnostic pulse of digital input X114:2 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.39	DI X114:3 diag pulse on/off	Sets the diagnostic pulse of digital input X114:3 on or off	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.40	DI X114:4 diag pulse on/off	Sets the diagnostic pulse of digital input X114:4 on or off	On
	Off	Diagnostic pulse off	


Index	Name/Value	Description	Factory default
	On	Diagnostic pulse on	
SAFEIO.51	DO diagnostic pulse length	Sets the length of the diagnostic pulse for digital outputs.	1 ms
	0.5 ms	Length of the diagnostic pulse is 0.5 ms.	
	1 ms	Length of the diagnostic pulse is 1 ms.	
	2 ms	Length of the diagnostic pulse is 2 ms.	
SAFEIO.52	DO diagnostic pulse period	Sets the time during which the FSO module must receive at least one whole diagnostic pulse.	10,000 ms
	50...59,000 ms	Time	
SAFEIO.53	DO X113:7 diag pulse on/off	Sets the diagnostic pulse of digital output X113:7 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.54	DO X113:8 diag pulse on/off	Sets the diagnostic pulse of digital output X113:8 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.55	DO X113:9 diag pulse on/off	Sets the diagnostic pulse of digital output X113:9 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.56	DO X114:7 diag pulse on/off	Sets the diagnostic pulse of digital output X114:7 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.57	DO X114:8 diag pulse on/off	Sets the diagnostic pulse of digital output X114:8 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.58	DO X114:9 diag pulse on/off	Sets the diagnostic pulse of digital output X114:9 on or off.	On
	Off	Diagnostic pulse off	
	On	Diagnostic pulse on	
SAFEIO.71	DO X113:7 logic state	Sets the logic state of digital output X113:7.	Active low
	Active low	Active state of the output is low voltage.	
	Active high	Active state of the output is high voltage.	
SAFEIO.72	DO X113:8 logic state	Sets the logic state of digital output X113:8.	Active low

Index	Name/Value	Description	Factory default
	Active low	Active state of the output is low voltage.	
	Active high	Active state of the output is high voltage.	
SAFEIO.73	DO X113:9 logic state	Sets the logic state of digital output X113:9.	Active low
	Active low	Active state of the output is low voltage.	
	Active high	Active state of the output is high voltage.	
SAFEIO.74	DO X114:7 logic state	Sets the logic state of digital output X114:7.	Active low
	Active low	Active state of the output is low voltage.	
	Active high	Active state of the output is high voltage.	
SAFEIO.75	DO X114:8 logic state	Sets the logic state of digital output X114:8.	Active low
	Active low	Active state of the output is low voltage.	
	Active high	Active state of the output is high voltage.	
SAFEIO.76	DO X114:9 logic state	Sets the logic state of digital output X114:9.	Active low
	Active low	Active state of the output is low voltage.	
	Active high	Active state of the output is high voltage.	
SBUSGEN		General parameters for safety fieldbuses	
SBUSGEN.01	SBUS activity and version	Activates or deactivates the safety fieldbus.	Disabled
	Disabled	Deactivates the safety fieldbus.	
	Version 1	Activates version 1 of the safety fieldbus.	
SBUSGEN.06	Safety fieldbus speed scaling	Sets the rpm value that corresponds to 20000 for safety fieldbus communication.	1500.0 rpm
	0.10...30000.0		
SBUSGEN.10	STO indication passivation	Sets the type of the event that the FSO module generates when the FSO module is passivated due to safety fieldbus problems.	Fault
	None	No event generated	
	Fault	Fault generated	
	Warning	Warning generated	
	Event	Pure event generated	

Index	Name/Value	Description	Factory default
PROFIsafe		Parameters for PROFIsafe	
PROFIsafe.1 1	PROFIsafe F_Dest_Add	Sets the PROFIsafe destination address for FSO which is used in the safety communication network. Note: This address must be the same as is set in the F-Parameters for the PROFIsafe module properties (F_Dest_Add). For more information, see section Configuring the safety PLC on page 163.	1
1...65534			
PROFIsafe.12	PROFIsafe telegram type	Shows the PROFIsafe telegram type.	0x221
0x221		PROFIsafe telegram 0x221 (545). Corresponds to profile ABB_PS1 in the GSD file. See section Downloading the GSD file on page 164.	

Status and control words

This table lists the FSO module and drive status and control words. You can view these in the ACS880 parameter tab of Drive Composer pro.

 **WARNING!** This data is purely informative. Do not use it for functional safety purposes.

Index	Name/Value	Description		
Safety				
200.01	FSO speed ch1	Shows the motor speed estimate 1 of the FSO module. The FSO module reads the value from the drive via communication channel 1.		
0.00 ... rpm		Speed FbEq16: 1 = 1 rpm; FbEq32: 100 = 1 rpm		
200.02	FSO speed ch2	Shows the motor speed estimate 2 of the FSO module. The FSO module reads the source data from the drive via communication channel 2 and calculates the speed estimate 2 using the data.		
0.00 ... rpm		Speed FbEq16: 1 = 1 rpm; FbEq32: 100 = 1 rpm		
200.03	FSO DI status	Shows the states of the FSO digital inputs.		
		Bit	Name	Values
		0	Input X113:1	0 = Off, 1 = On
		1	Input X113:2	0 = Off, 1 = On
		2	Input X113:3	0 = Off, 1 = On
		3	Input X113:4	0 = Off, 1 = On
		4	Input X114:1	0 = Off, 1 = On
		5	Input X114:2	0 = Off, 1 = On
		6	Input X114:3	0 = Off, 1 = On
		7	Input X114:4	0 = Off, 1 = On
8-15	Reserved			

Index	Name/Value	Description		
200.04	FSO DO status	Shows the states of the FSO digital outputs.		
		Bit	Name	Values
		0	Output X113:7	0 = Off, 1 = On
		1	Output X113:8	0 = Off, 1 = On
		2	Output X113:9	0 = Off, 1 = On
		4	Output X114:7	0 = Off, 1 = On
		5	Output X114:8	0 = Off, 1 = On
		6	Output X114:9	0 = Off, 1 = On
		7-15	Reserved	
200.05	FSO control word 1	Shows the states of the FSO commands.		
		Bit	Name	Values
		0	STO request	0 = Off, 1 = On
		1	SSE request	0 = Off, 1 = On
		2	SS1 request	0 = Off, 1 = On
		3	Reserved	
		4	SAR0 request	0 = Off, 1 = On
		5	SAR1 request	0 = Off, 1 = On
		6	Reserved	
		7	Reserved	
		8	Reserved	
		9	Reserved	
		10	SLS1 request	0 = Off, 1 = On
		11	SLS2 request	0 = Off, 1 = On
		12	SLS3 request	0 = Off, 1 = On
		13	SLS4 request	0 = Off, 1 = On
		14	Reserved	
		15	Reserved	
200.06	FSO control word 2	Shows the states of the FSO commands.		
		Bit	Name	Values
		0	Reserved	
		1	CRC request	0 = Off, 1 = On
		2	FSO brake	0 = Off, 1 = On
		3	Variable SLS request	0 = Off, 1 = On
		4	SS1 modoff allowed	0 = Off, 1 = On
		5	SSE modoff allowed	0 = Off, 1 = On
		6-15	Reserved	

Index	Name/Value	Description		
200.07	FSO status word 1	Shows the FSO status word 1.		
		Bit	Name	Values
		0	FSO mode bit 1	0 = Undefined
		1	FSO mode bit 2	1 = Start-up mode
		2	FSO mode bit 3	2 = Running mode
				3 = Fail-safe mode
				4 = Configuration mode
		3	FSO state bit 1	0 = Safe state
		4	FSO state bit 2	1 = Operational state
		5	FSO STO active	0 = Off, 1 = On
		6	Brake state	0 = Off, 1 = On
		7	POUS monitoring	0 = Off, 1 = On
		8	SSE monitoring	0 = Off, 1 = On
		9	SS1 monitoring	0 = Off, 1 = On
		10	Reserved	
		11	SAR0 monitoring	0 = Off, 1 = On
		12	SAR1 monitoring	0 = Off, 1 = On
		13	Reserved	
		14	Reserved	
		15	Reserved	

Index	Name/Value	Description		
200.08	FSO status word 2	Shows the FSO status word 2.		
		Bit	Name	Values
		0	Reserved	
		1	SLS1 monitoring	0 = Off, 1 = On
		2	SLS2 monitoring	0 = Off, 1 = On
		3	SLS3 monitoring	0 = Off, 1 = On
		4	SLS4 monitoring	0 = Off, 1 = On
		5	Reserved	
		6	Reserved	
		7	Reserved	
		8	Reserved	
		9	Reserved	
		10	Reserved	
		11	Reserved	
		12	SMS monitoring	0 = Off, 1 = On
		13	Reserved	
		14	var SLS monitoring	0 = Off, 1 = On
		15	Reserved	

Index	Name/Value	Description			
200.09	Drive status word 1	Shows the drive status word 1.			
		Bit	Name	Description	Values
		0	Drive status bit 1		0 = Disabled
		1	Drive status bit 2		1 = Readyon
		2	Drive status bit 3		2 = Readyrun
		3	Drive status bit 4		3 = Starting
					4 = Readyref
					5 = Stopping
					6 = Faulted
		4	Reserved		
		5	Reserved		
		6	Modulation	Drive modulation on or off.	0 = Off, 1 = On
		7	STO circuit 1	State of drive STO circuit 1.	0 = Off, 1 = On
		8	STO circuit 2	State of drive STO circuit 2.	0 = Off, 1 = On
		9	SS1 active	State on the drive side	0 = Off, 1 = On
		10	Reserved		
		11	SAR0 active		0 = Off, 1 = On
		12	SAR1 active		0 = Off, 1 = On
		13	Reserved		
		14	Reserved		
		15	Reserved		

Index	Name/Value	Description			
200.10	Drive status word 2	Shows the drive status word 2.			
		Bit	Name	Description	Values
		0	Reserved		
		1	SLS1 active	State on the drive side	0 = Off, 1 = On
		2	SLS2 active		0 = Off, 1 = On
		3	SLS3 active		0 = Off, 1 = On
		4	SLS4 active		0 = Off, 1 = On
		5	Reserved		
		6	Reserved		
		7	Reserved		
		8	Drive brake state	State of the drive operational brake.	0 = Off, 1 = On
		9	STO 1 diag	The drive has noticed an STO diagnostic pulse on circuit 1 or 2.	0, 1
		10	STO 2 diag		0, 1
		11-15	Reserved		

12

Start-up

Contents of this chapter

This chapter describes the general precautions to be taken before starting up the safety system for the first time.

Safety considerations

The start-up must be done by a qualified electrical professional who has sufficient knowledge of functional, machine and process safety. The safety instructions must be obeyed during the start-up. Refer to the drive and the safety component specific safety instructions in the individual product manuals.



WARNING! Until all the safety functionality is validated, the system must not be considered safe.



Note: The safety of the machine users must be ensured in each phase of the application life cycle (for example, commissioning, start-up, maintenance, etc.).

Checks

Before starting the system for the first time, make sure that

- the installation has been checked, according to the individual product checklists (drive, safety component) and the checklists provided in this document (see chapter [Installation checklists](#)).
- all necessary configuration steps have been completed
- all tools are cleared from the installation area to prevent short circuits and projectiles
- starting the system does not cause any danger
- all safety functions which are configured into use, are validated according to chapter [Verification and validation](#) on page 355.



13

Verification and validation

Contents of this chapter

This chapter describes verification and validation of the implemented safety functionality.

Verification and validation produce documented proof of the compliance of the implementation with specified safety requirements.

More information can be found in [Technical guide No. 10 - Functional safety \(3AUA0000048753 \[English\]\)](#).

Verifying the achieved SIL/PL level

Verification of the functional safety system demonstrates and ensures that the implemented safety system meets the requirements specified for the system in the safety requirements specification phase.

The most convenient way to verify the required SIL/PL level reached with the implemented system is to use a specific safety calculator software.

Purpose of the validation testing

The purpose of the validation testing is to verify that the safety functions which are used in the safety system, operate as required in the application, and that the safety requirements specification (SRS) arising from the risk assessment is fulfilled. By testing, the plausibility of the safety functions is ensured against the SRS requirements. All situations relevant to the application according to the risk assessment must be tested. For example, possible configuration errors of the safety functions should be found by the validation testing.

Preconditions for validation testing

Validation testing is done for the entire and complete safety system. It is recommended to do all the verification and validation tests so that the real load of the application is connected to the motor. The whole safety system (for example, emergency stop buttons, light curtains, etc.) must be installed, set-up, and the drives commissioned and ready to use before the safety system can be tested. All safety functions in use must be tested with each of the drive, and/or as a whole section of drives (span of control of safety function).

Validation procedure

■ General

It is always the responsibility of the machine builder/designer/integrator to make sure that the operation of all the required safety functions are correctly verified and validated.

It is necessary to validate first the general settings of the FSO module before the validation of the safety functions.

Always configure and validate the STO and SSE functions. An internal monitoring of the FSO module can trigger the STO or SSE function even if you have not defined an external request signal for them.



WARNING! The system must not be considered safe until the safety functionality, which is necessary for safe use of the application based on the risk assessment, is validated. Validation of each safety function must be performed before the application is taken into the use.

The validation tests using the start-up checklists later in this section must be done:

- at the initial configuration of the safety function
 - after changes related to the safety function (wiring, components, settings, etc.)
 - after maintenance work related to the safety function.
-

The validation test must include at least these steps:

- preparing a validation test plan
- testing all commissioned functions for proper operation in the final complete safety system
- testing all used inputs for proper operation, also for the input redundancy. See also [Validation of redundant inputs](#) on page 359.
- testing all used outputs for proper operation
- documenting all validation tests performed
- testing person signing and archiving the validation test report for further reference.

Always save the safety configuration file and parameter backup file after a successful validation test.

■ Validation test reports

You must store the signed validation test reports in the logbook of the machine. The report must include, as required by the referred standards:

- description of the safety application (including a figure)
- a description and revisions of safety components that are used in the safety application
- a list of all safety functions that are used in the safety application
- a list of all safety related parameters and their values (the drive STO has no safety-related parameters, but listing the non-safety related parameter 31.22 STO indication run/stop and its setting is recommended)
- documentation of start-up activities, references to failure reports and resolution of failures
- the test results for each safety function, all safety parameter values including the CRC value of the safety configuration (parameter [200.254](#)), date of the tests and confirmation by the test personnel.

You must store all validation test reports done due to changes or maintenance in the logbook of the machine.

■ Competence

The validation test of the safety function must be carried out by a competent person with expertise and knowledge of the safety function as well as functional safety, as required by IEC 61508-1 clause 6. The test procedures and report must be documented and signed by this person.

■ Tools

You must use the Drive Composer pro PC tool to do the validation procedures.

■ Validation of ACS880 drive firmware

If ACS880 primary control program (AINLX) version 3.46 or earlier is used, you must take into account the safety notice in section [ACS880 drives manufactured before December 2024](#) on page 18.

■ Validation of the PROFI-safe connection

Do these steps to validate the PROFI-safe connection:

1. Make sure that the PROFI-safe communication is enabled in FSO parameter [200.222 Safety bus type](#).
2. Make sure that the fieldbus module (FENA-21 or FPNO-21) is configured into use in the drive. Refer to the applicable drive firmware manual and fieldbus module user's manual.
3. Make sure that correct option slot is configured for PROFI-safe. The value of FSO module parameter [200.223 Safety fieldbus adapter slot](#) must correspond to the FBA channel of the fieldbus interface (FBA A or FBA B).
4. Make sure that the fieldbus module is correctly configured in drive parameter group 51 or 54. Most importantly:
 - parameter 51.02/54.02 Protocol/Profile must be set to configure one of the PROFINET profiles,
 - parameter 51.21 or 54.21 must be set to Enabled (0) to enable sending of the PROFI-safe diagnosis messages.

Note: The parameter group depends on the FBA channel that is used. For more information, refer to the drive firmware manual and fieldbus module user's manual.

5. Make sure that the PROFI-safe watchdog time for the fieldbus module that is configured in the controller station is calculated as specified in section [Calculating the watchdog time](#) on page 160.
 6. Make sure that the PROFI-safe address (F_Dest_Add) of the FSO module is unique in the network and the same value is set in FSO parameter [PROFI-safe.11 PROFI-safe F_Dest_Add](#) and in the safety controller station.
 7. Make sure that the PROFI-safe address (F_Source_Add) of the safety PLC is unique in the network.
 8. Make sure that the PROFI-safe speed scaling value in FSO parameter [SBUSGEN. 06 Safety fieldbus speed scaling](#) is calculated as specified in section [Configuring the safety fieldbus communication](#) on page 245.
 9. Make sure that the safety controller station is commissioned according to its instructions. Make sure that the correct GSD-file is in use, for example, a correct PS profile is in use.
-

10. Make sure that the communication between controller and PROFINET/PROFIsafe devices is established properly.
11. Verify by activating some suitable safety function in each of the FSOs modules in PROFIsafe network, that the safety function is activated in correct drive.
12. Verify by disconnecting the PROFINET cable from the fieldbus adapter that correct FSO module is passivated and SSE function is activated.
13. Make sure that the drive event log does not contain any unexpected entries. See chapter [Fault tracing](#) for details.
14. Make sure that the diagnostic messages at the safety controller station (PLC) do not contain any unexpected entries.

■ Validation of safety functions

Once the system is fully configured and wired for the safety functions, and the initial checks have been done, you must do the following functional test procedure for each safety function:

1. Run the system to the operational state, and make sure that the drive and FSO module are ready for the safety function validation. There are no active faults in the drive or FSO module.
2. Make sure that the acknowledgement method has been configured as required in the risk assessment of the application (manual or automatic acknowledgement).
3. Activate the safety function, for example through PROFIsafe or by an activating safety switch.
4. Verify that the desired functionality takes place, and the system behaves safely according to the requirements of the risk assessment.
5. Document the test results to the validation test report.
6. Sign and file the validation test report.

■ Validation of redundant inputs

If safety function is configured to use redundant inputs, the diagnostic function of each redundant input must be verified.

This is an validation example with the SS1 function. Inputs X113:1 and X114:1 are set for the SS1 input. Validation procedure:

1. Remove one channel from the FSO input 1 for SS1 function (for example, input X113:1).
2. Make sure that the FSO module activates the SS1 function (FSO SS1 request).
3. Make sure that the warning of redundant inputs ([A7D0](#)) appears.
4. Connect the disconnected input channel back to the FSO input 1 for SS1.
5. Verify that it is not possible to acknowledge the SS1 function.
6. Request SS1 function by activating both input channels.
7. Make sure that the warning of the redundant inputs ([A7D0](#)) disappears.
8. Deactivate SS1 function.
9. Acknowledge the function.

Repeat this procedure for all redundant input(s), and with all safety functions that use the inputs.

■ Validation of safety I/O's

The safety I/O configuration (SAFEIO.xx parameters) and functionality including the test pulsing must be verified according to the application requirements. If safety relay outputs and their feedbacks are used in the application, the related diagnostic functions must also be verified.

■ Validation of the general settings

Make sure that the general settings of the safety functions are configured correctly according to your design. For a configuration example, see section [Configuring general settings](#) on page 244. Check the values of these parameters:

- [FSOGEN.41 Power-up acknowledgement](#)
 - [FSOGEN.42 Acknowledgement button input](#)
 - [FSOGEN.22 Motor nominal frequency](#)
 - [FSOGEN.21 Motor nominal speed](#)
 - [FSOGEN.51 Zero speed without encoder](#)
 - [FSOGEN.61 STO indication ext request](#)
 - [FSOGEN.62 STO indication safety limit](#)
 - [FSOGEN.11 Stop completed output.](#)
-

■ Validation of the STO function



WARNING! Configure and validate the STO function independently and before other safety functions.

General validation principles:

- The STO function is the basic safety function. It must always be configured and validated before (and independent of) other safety functions. This is essential because the internal diagnostics of the FSO module can trigger the STO function even if no external request signal has been defined for the function.
- The STO function must always be tested with a separate request signal. The signal is connected to a suitable FSO module input, and the input is configured to be the interface for the STO request.
- If the stop by coast time from the maximum process speed to zero speed is not known, it must be measured, and parameter [STO.14 Time to zero speed with STO and modoff](#) set accordingly.
- If an encoder is not used, it must be ensured by other means (for example, by a visual check) that the motor shaft stops within the [STO.14](#) delay time and that the STO function cannot be acknowledged before the motor shaft has stopped. The only exception to this is when [STO.13 Restart delay after STO](#) has been set shorter than [STO.14](#) delay time. In that case, the fly-start of the motor is possible.

To validate the STO function:

1. Make sure that the input for the STO function is configured according to the wiring diagram.
2. Make sure that the output to indicate the drive STO state ([STO.21 STO output](#)) is configured correctly according to your design.
3. Make sure that the STO function is configured correctly according to your design. For a configuration example, see chapter [Configuring STO](#) on page [255](#). Check these settings:

Activation:

- [STO.11 STO input A](#)
- [STO.12 STO input B](#)
- **Note:** Activation can also come from the PROFIsafe.

Acknowledgement:

- [STO.02 STO acknowledgement](#)
 - [FSOGEN.42 Acknowledgement button input](#) if manual acknowledgement is used.
-

Functionality:

- [STO.13 Restart delay after STO](#) (if fly-start is used)
- [STO.14 Time to zero speed with STO and modoff](#). (This is the estimated time in which the motor coasts to a stop from the maximum process speed.)

Indication:

- [STO.21 STO output](#)
- [STO.22 STO completed output](#)
- [FSOGEN.11 Stop completed output](#)

4. If you made any changes, download and validate the configuration with the Drive Composer pro PC tool.
5. Make sure that you can run and stop the motor freely.
6. Activate the STO function. For example, by pressing an emergency stop button, which is wired to an FSO input for the STO function request.
7. Remove the STO function request.
8. Make sure that the drive STO is activated immediately after the STO request.
9. Make sure that STO output ([STO.21](#)) shows the state of the drive STO correctly.
10. a) If manual acknowledgement (or safebus acknowledgement) is in use: Verify by trying to acknowledge the function, that it is not possible before the motor speed is low enough:

With safe speed estimation:

- Acknowledgement is not possible before coast time defined by parameter [STO.14 Time to zero speed with STO and modoff](#)
- If fly start is allowed, acknowledgement is not possible before the time defined by parameter [STO.13 Restart delay after STO](#) has elapsed.
-
- If fly start is allowed, acknowledgement is not possible before the time defined by parameter [STO.13 Restart delay after STO](#) has elapsed.

b) If automatic acknowledgement is in use: Verify that STO function is not acknowledged before the motor is in safe state. See the conditions above.

■ Validation of the SBC function

SBC function always uses the drive STO.

Drive STO is always activated immediately in the following cases/situations:

- FSO STO function
- SSE, when it is configured to be immediate STO
- SSE ramp or SS1 function is completed.

Validation of the delayed brake function

1. Check the wiring between the FSO module and safe brake, and make sure that they are done correctly according to the design.
2. Make sure that the SBC function is configured correctly according to your design. For a configuration example, see section [How to configure the SBC in the STO function](#) on page 254. Check these settings:

Functionality:

- [SBC.11 STO SBC usage](#) = Delayed brake
 - [SBC.12 STO SBC delay](#)
 - [SBC.13 SBC time to zero speed](#)
 - [SBC.21 SBC output](#)
 - [SBC.22 SBC feedback action](#)
 - [SAFEIO.22 Safety relay 1 feedback](#)
 - [SAFEIO.23 Safety relay 1 feedback type](#).
3. Check that the drive STO and the SBC are activated correctly based on your application needs.
 - a) When positive STO SBC delay ([SBC.12](#)) is used: Make sure that the drive STO is activated first and the SBC after the delay has elapsed.
 - b) When [SBC.12 STO SBC delay](#) is 0 ms, Make sure that the drive STO is activated at the same time as the SBC.
 - c) When negative STO SBC delay ([SBC.12](#)) is used: Make sure that the SBC is activated first and the drive STO after the delay has elapsed.
 4. Make sure that the required failure reaction ([SBC.22](#)) takes place if there is no SBC feedback signal ([SAFEIO.22](#)). For example, disconnect the SBC feedback cable to verify.

Validation of the speed limit activated SBC

This feature is possible with:

- the safe speed estimate with the SS1 or SSE ramp

Procedure:

1. Check the wiring between the FSO module and safe brake, and make sure that they are done correctly according to the design.
2. Make sure that the SBC function is configured correctly according to your design. For a configuration example, see chapter [How to configure the SBC in the STO function](#) on page 254. Check these settings:

Functionality:

- [SBC.12 STO SBC delay](#)
 - [SBC.13 SBC time to zero speed](#)
 - [SBC.15 SSE/SS1 SBC speed](#) > 0 rpm
 - [SBC.21 SBC output](#)
 - [SBC.22 SBC feedback action](#)
 - [SAFEIO.22 Safety relay 1 feedback](#)
 - [SAFEIO.23 Safety relay 1 feedback type](#).
3. Check that the drive STO and the SBC are activated correctly based on your application needs.
 4. Check that the brake is activated at the correct speed.
 - a) When [SBC.12 STO SBC delay](#) is 0 ms or greater, check that the SBC and drive STO is activated at the same time at the speed limit.
 - b) When a negative [SBC.12 STO SBC delay](#) is used: Check that the SBC is activated at the speed limit, and the drive STO after the delay has elapsed. This parameter is only relevant for the SS1 or SSE ramp.
 5. Make sure that the required failure reaction ([SBC.22](#)) takes place if there is no SBC feedback signal ([SAFEIO.22](#)). For example, disconnect the SBC feedback cable to verify.

■ Validation of the SSE function

Always configure and validate the SSE function. Test the SSE function always with a separate function request, for example by activating it via a suitable input configured for the SSE.

Internal diagnostics of the FSO module, trip limit hit cases and PROFIsafe passivation will trigger the SSE function even if you have not defined an external request signal for the SSE. For example, the FSO module activates the SSE function if an SLS trip limit hit occurs. The SSE function must be configured as SSE with STO, SSE with ramp stop, or SSE with time monitoring, based on the risk assessment of the application. The configuration must also cover the worst-case situation in case any of the issues above triggers the SSE function, or in case any stopping function with the SSE triggers the SSE.

Validation of the SSE with immediate STO function with safe speed estimation

1. Make sure that the input for the SSE function is configured according to the wiring diagram.
2. Make sure that the SSE function is configured correctly according to your design. For a configuration example, see chapter [How to configure SSE with immediate STO](#) on page 270). Check these settings:

Activation:

- [SSE.11 SSE input A](#)
- [SSE.12 SSE input B](#).
- **Note:** Activation can also come from the PROFIsafe.

Acknowledgement:

- [STO.02 STO acknowledgement](#)
- [FSOGEN.42 Acknowledgement button input](#) if manual acknowledgement is used.

Functionality:

- [SSE.13 SSE function](#) = Immediate STO
- [STO.14 Time to zero speed with STO and modoff](#). ([STO.14](#) is the time in which the motor coasts to a stop from the maximum speed.)

Indication:

- [SSE.21 SSE output](#)
- [SSE.22 SSE completed output](#)
- [FSOGEN.11 Stop completed output](#).

3. If you made any changes, download and validate the configuration with the Drive Composer pro PC tool.
 4. Make sure that you can run and stop the motor freely. Start the drive.
 5. Activate the SSE function. For example, press the emergency stop button, which is wired to the FSO input for the SSE function.
 6. Make sure that the drive STO is activated immediately after the SSE request.
 7. Remove the SSE function user request.
 8. a) If manual acknowledgement (or safebus acknowledgement) is in use: Verify by trying to acknowledge the function, that it is not possible before the motor is in safe state.
 b) If automatic acknowledgement is in use: Make sure that the function is not acknowledged and that the delays are correctly configured by verifying that the drive cannot be restarted before the motor is in safe state.
-

Validation of the SSE with emergency ramp function

1. Make sure that the input for the SSE function is configured according to the wiring diagram.
2. Make sure that the SSE function and SAR0 setting or time monitoring limit is configured correctly according to your design. For a configuration example see section [How to configure SSE with time monitoring](#) on page 271 or [How to configure SSE with ramp monitoring](#) on page 272. Check these settings:

Activation:

- [SSE.11 SSE input A](#)
- [SSE.12 SSE input B](#).
- **Note:** activation can also come from the PROFIsafe

Acknowledgement:

- [STO.02 STO acknowledgement](#)
- [FSOGEN.42 Acknowledgement button input](#) if manual acknowledgement is used.

Functionality:

- [SSE.13 SSE function](#) = Emergency ramp
- [200.202 SAR speed scaling](#)
- [200.201 SAR0 ramp time to zero](#)
- [SSE.16 SSE ramp zero speed delay for STO](#), if used
- With safe speed estimation: [FSOGEN.51 Zero speed without encoder](#)
- a) With ramp monitoring:
 - [SSE.14 SSE monitoring method](#) = Ramp
 - [SARx.02 SAR initial allowed range](#)
 - [SARx.11 SAR0 max ramp time to zero](#)
 - [SARx.12 SAR0 max ramp time to zero](#).

OR

b) With time monitoring:

- [SSE.14 SSE monitoring method](#) = Time
 - [SSE.15 SSE delay for STO](#).
-

Indication:

- [SSE.21 SSE output](#)
 - [SSE.21 SSE completed output](#)
 - [FSOGEN.11 Stop completed output](#).
3. If you made any changes, download and validate the configuration with the Drive Composer pro PC tool.
 4. Make sure that you can run and stop the motor freely. Start the drive and accelerate the motor to the maximum speed of the application.
 5. Activate the SSE function. For example, press the emergency stop button which is wired to FSO module input for the SSE function.
 6. Remove the SSE function user request.
 7. a) If manual acknowledgement (or safebus acknowledgement) is in use: Verify by trying to acknowledge the function, that it is not possible before the motor speed is low enough:
 - With safe speed estimation: [FSOGEN.51 Zero speed without encoder](#)
 - b) If automatic acknowledgement is in use: Verify that the function is not acknowledged before the motor is in safe state, see the conditions above.
 8. Make sure that the motor speed decelerates as expected and the FSO does not trip to the monitoring limit (ramp or time).
 9. Start the drive and accelerate the motor to the maximum speed of the application.
 10. Activate the SSE function. For example, press the emergency stop button which is wired to the FSO module input for the SSE function.
 11. Remove the SSE function user request.
 12. Activate the coast stop of the drive.

You can, for example, cause an external fault trip in the drive. For more information, see the drive firmware manual (Group 31 Fault functions).
 13. Make sure that the FSO trips the drive, and activates the STO function according to the application requirements.
 14. Make sure that the acknowledgement of the STO function is not possible before the motor is in safe state

■ Validation of the SS1 function

1. Make sure that the input for the SS1 function is configured according to the wiring diagram.
 2. Make sure that the SS1 function, and SAR1 setting or time monitoring limit is configured correctly according to your design. For a configuration example,
-

see chapter [How to configure SS1 with time monitoring \(SS1-t\)](#) on page 259, or [How to configure SS1 with ramp monitoring \(SS1-r\)](#) on page 261. Check these settings:

Activation:

- [SS1.11 SS1 input A](#)
- [SS1.12 SS1 input B](#).
- **Note:** activation can also come from the PROFIsafe

Acknowledgement:

- [STO.02 STO acknowledgement](#)
- [FSOGEN.42 Acknowledgement button input](#) if manual acknowledgement is used.

Functionality:

- [SS1.01 SS1 activity and version](#) = Version 1
- [SS1.15 SS1-r ramp zero speed delay for STO](#) (if used)
- [200.202 SAR speed scaling](#)
- [200.112 SAR1 ramp time to zero](#)
- drive parameter 23.23 emergency stop time, if [200.112](#) = 0 ms
- if with safe speed estimation: [FSOGEN.51 Zero speed without encoder](#)
- a) If ramp monitoring is in use:
 - [SS1.13 SS1 type](#) = SS1-r
 - [SARx.02 SAR initial allowed range](#)
 - [SARx.21 SAR1 min ramp time to zero](#)
 - [SARx.22 SAR1 max ramp time to zero](#)

OR

b) If time monitoring is in use:

- [SS1.13 SS1 type](#) = SS1-t
- [SS1.14 SS1-t delay for STO](#).

Indication:

- [SS1.21 SS1 output](#)
- [SS1.22 SS1 completed output](#)
- [FSOGEN.11 Stop completed output](#).

3. If you made any changes, download and validate the configuration with the Drive Composer pro PC tool.

Note: SAR1 is common with the SS1, SLS functions. Any changes to the SAR1 values will have impact on these functions.

4. Make sure that you can run and stop the motor freely. Start the drive and accelerate to the maximum speed of the application.
5. Activate the SS1 function. For example, press an emergency stop button which is wired to FSO module input for the SS1 function.
6. Remove the SS1 function user request.
7. a) If manual acknowledgement (or safebus acknowledgement) is in use: Try to acknowledge the function and verify, that it is not possible before the motor is in safe state (the motor speed is not dangerously high for the application):
 - With safe speed estimation: Safety zero speed limit for **FSOGEN.51 Zero speed without encoder**
- OR
- b) If automatic acknowledgement is in use: Verify that the function is not acknowledged before the motor speed is low enough. See the conditions above.
8. Make sure that the motor speed decelerates as it is designed, and the FSO module does not trip to the monitoring limit (ramp or time).
9. After the motor is in safe state and the function is acknowledged, start the drive again and accelerate to the maximum speed of the application.
10. Activate the SS1 function. For example, by pressing the emergency stop button which is wired to FSO module input for the SS1 function.
11. Remove the SS1 function user request.
12. Activate the coast stop.

You can, for example, cause an external fault trip in the drive. For more information, see the drive firmware manual (Group 31 Fault functions).
13. Make sure that the FSO module trips the drive and activates the STO function according to the application requirements.
14. Make sure that the acknowledgement of the STO function is not possible before the motor is in safe state.

■ Validation of the SLS functions

Note: STO and SSE validation test must always be done before SLS or any other validation tests.

Follow these steps to validate all SLS functions (SLS1...4) that are used in the application. SLS1 is used as an example later in this section.

Note: If SLS4 limits are changed, this will have an impact on varSLS function also, which means that both of these functions must be validated.

1. Make sure that the input for the SLS1 function is wired and configured according to the wiring diagram.
2. Make sure that the SLS1 function is configured according to your design. For a configuration example, see section [Configuring SLS](#) on page 279. Check these settings:

Activation:

- [200.21 SLS1 activity and version](#)
- [SLSx.11 SLS1 input A](#)
- [SLSx.12 SLS1 input B](#) (only for SLS1).

Functionality for the SLS function:

- [200.22 SLS1 limit negative](#)
- [200.23 SLS1 limit positive](#)
- [SLSx.13 SLS1 trip limit negative](#)
- [SLSx.14 SLS1 trip limit positive.](#)

Acknowledgement:

- [SLSx.02 SLS acknowledgement](#)
- [FSOGEN.42 Acknowledgement button input](#) if manual acknowledgement is used.

Functionality:

a) with ramp monitoring:

- [SLSx.03 SLS activation monitoring method](#) = Ramp
- [200.202 SAR speed scaling](#)
- [200.112 SAR1 ramp time to zero](#)
- [SARx.02 SAR initial allowed range](#)
- [SARx.21 SAR1 min ramp time to zero](#)
- [SARx.22 SAR1 max ramp time to zero](#)
- drive parameter 23.23 emergency stop time, If [200.112 SAR1 ramp time to zero](#) = 0 ms.

OR

b) with time monitoring:

- [SLSx.03 SLS activation monitoring method](#) = Time
 - drive parameter 23.13 deceleration time 1 (or 23.15 deceleration time 2)
 - [SLSx.04 SLS time delay.](#)
-

Indication:

- [SLSx.15 SLS1 output A](#)
- [SLSx.16 SLS1 output B](#) (only available for SLS1).

Test the SLS function as it is used in the application. Pay attention to the testing of the relevant fault situations for the application, for example, tripping fault in the drive, etc.

3. Start the drive and accelerate it to a suitable speed. Activate the SLS function with an FSO module input, or via the safety bus.
If you activate the function at a speed higher than the SLS limit ([200.23](#) or [200.22](#)), make sure that the deceleration ramp operates as required and no tripping fault occurs during the deceleration.
4. Make sure that SLS function limits the motor speed to the required limit. Give a speed reference higher than the SLS limit. Make sure that the drive does not follow speed references that are higher than the SLS limit.
5. Make sure that the SLS indication output ([SLSx.15](#) or [SLSx.16](#)) indicates safe speed when motor speed is within SLS limits.
6. Deactivate the SLS function. Make sure that the SLS indication ([SLSx.15](#) or [SLSx.16](#)) goes off, and the drive runs the motor according to the given user reference (outside the SLS speed limits).

Note: If the SLS function can be activated at a higher motor speed than the SLS limit ([200.23](#) or [200.22](#)), validate the correct operation as follows:

7. Activate SLS function at a motor speed above the SLS limit ([200.23](#) or [200.22](#)).
8. Activate the coast stop of the drive.
9. Make sure that the FSO module reacts according to your application requirements. For example, it trips the drive with the STO.
10. Make sure that the following events occur only after the motor is in safe state:
 - the SLS indication ([SLSx.15](#)) goes on, if it is configured.
 - Acknowledgement of the stopping function (SSE or STO) is possible in case a stopping function was triggered earlier. See step 9.

■ Validation of the variable SLS function

Note: STO and SSE validation and PROFIsafe interface validation must always be done before SLS or any other validation tests.

Follow these steps to validate the variable SLS function:

1. Make sure that the input for the variable SLS function is configured in use in the safety PLC project.
2. Make sure that the variable SLS function is configured in the FSO module according to your design. For a configuration example, see section [Configuring Variable SLS](#) on page 283. Check these settings:

Activation:

- [200.61 SLS variable activity and version](#)

Functionality for the SLS function

- [200.52 SLS4 limit negative](#)
- [200.53 SLS4 limit positive](#)
- [SLSx.42 SLS4 trip limit negative](#)
- [SLSx.43 SLS4 trip limit positive](#)

Acknowledgement:

- [SLSx.02 SLS acknowledgement](#)
- [FSOGEN.42 Acknowledgement button input](#) if manual acknowledgement is used.

Functionality for the deceleration ramp:

a) with ramp monitoring:

- [SLSx.03 SLS activation monitoring method](#) = Ramp
- [200.202 SAR speed scaling](#)
- [200.112 SAR1 ramp time to zero](#)
- [SARx.02 SAR initial allowed range](#)
- [SARx.21 SAR1 min ramp time to zero](#)
- [SARx.22 SAR1 max ramp time to zero](#)
- drive parameter 23.23 emergency stop time, If [200.112](#) = 0 ms.

OR

b) with time monitoring:

- [SLSx.03 SLS activation monitoring method](#) = Time
- drive parameter 23.13 deceleration time 1 (or 23.15 deceleration time 2)
- [SLSx.04 SLS time delay](#)

Indication:

- [SLSx.51 Variable SLS output](#)

3. Check from the safety PLC project that variable SLS scaling is set correctly.

Octet 3 for enabling the scaling:

- bit 6 negative scaling
- bit 7 positive scaling

Octets 4 and 5 for the variable SLS speed scaling value.

Test the variable SLS function as used in the application. Pay attention to the testing of the relevant fault situations for the application, for example the tripping fault in the drive, etc:

4. Start the drive with suitable speed reference. Activate the variable SLS function via the safety bus.
5. Make sure that the variable SLS function limits the motor speed to the required variable SLS limit by the application. Try to give a speed reference higher than the limit. Make sure that the drive does not follow speed references higher than the scaled SLS limit.
6. Make sure that [SLSx.51 Variable SLS output](#) indicates safe speed when motor speed is within the limits.
7. Scale down the variable SLS limit by various test scaling values.
8. Make sure that the deceleration ramp operates as required and no tripping fault occurs during the deceleration and that the reference SLS4 limits (100% scaling) are set according to the application requirements.
9. Make sure that [SLSx.51 Variable SLS output](#) indicates safe speed when motor speed is within the scaled variable SLS limits.
10. Deactivate variable SLS function. Make sure that the variable SLS indication goes off, and the drive runs the motor according to the given user reference.

Note: If the variable SLS function can be activated at a higher speed than the variable SLS limit, validate the correct operation as follows:

11. Activate the variable SLS function at a motor speed above the variable SLS limit (or scale down the variable SLS limit).
12. Activate the coast stop of the drive.
13. Make sure that the FSO module reacts according to your application requirements, for example, it trips the drive with the STO.
14. Make sure that the following events occur only after the motor is in safe state:
 - SLS indication ([SLSx.51](#)) goes on, if it is configured.
 - Acknowledgement of the stopping function (SSE or STO) is possible in case a stopping function was triggered earlier. See step [13](#).

■ Validation of the SMS functions



WARNING! If the SMS validation is to be performed with the machinery coupled to the motor, make sure that the machinery is able to withstand the fast speed changes and the set maximum speed.

Validation of the SMS functions, version 1

1. Make sure that the SMS function is configured correctly according to your design. For a configuration example, see section [How to configure SMS, version 1](#) on page 289. Check these settings:

Activation:

- [200.71 SMS activity and version](#).

Functionality:

- [SMS.13 SMS trip limit negative](#)
- [SMS.13 SMS trip limit positive](#).

If possible, test the SMS trip limit in practice:

2. Make sure that you can run and stop the motor freely.
3. Start the drive and accelerate to a speed higher than [SMS.14 SMS trip limit positive](#).
4. Make sure that the FSO module detects the over speed and activates the SSE function.
5. Make sure that the SSE is configured according to the application safety requirements.
6. Make sure that the acknowledgement of the SSE function is only possible when the motor is in safe state.

Validation of the SMS function, version 2

1. Make sure that the SMS function is configured correctly according to your design. For a configuration example, see section [How to configure SMS, version 2](#) on page 290. Check these settings:

Activation:

- [200.71 SMS activity and version](#)

Functionality:

- [200.72 SMS limit negative](#)
- [200.73 SMS limit positive](#)
- [SMS.13 SMS trip limit negative](#)
- [SMS.14 SMS trip limit positive](#)

2. Make sure that you can run and stop the motor freely.
 3. Start the drive and accelerate to a speed higher than the SMS limit positive ([200.73](#)).
 4. Make sure that SMS function limits the motor speed to the required limit by the application. Try to give a speed reference higher than the limit. Make
-

sure that the drive does not follow speed reference if it is higher than the SMS limit. Repeat the test for both SMS limits (if in use in the application).

5. Make sure that also SMS trip limits ([200.72](#), [200.73](#)) are set according to the application requirements. This procedure does not test the trip limits.

■ Validation of the POUS function

1. Make sure that the input and output(s) for the POUS function are configured according to the wiring diagram.
2. Make sure that the POUS function is configured correctly according to your design. For a configuration example, see section [Configuring POUS](#) on page [290](#). Check these settings:

Activation:

- [POUS.01 POUS activity and version](#)
- [POUS.11 POUS input](#)
- **Note:** activation can also come from the PROFIsafe.

Acknowledgement:

- [POUS.02 POUS acknowledgement](#)
- [FSOGEN.42 Acknowledgement button input](#) if the manual acknowledgement is used.

Functionality:

- [POUS.13 POUS delay for completion](#).

Indication:

- [POUS.21 POUS output](#)
- [POUS.22 POUS completed output](#).

6. Make sure that the motor is stopped.
 7. Activate the POUS function.
 8. Make sure that you cannot start the drive.
 9. Make sure that POUS output ([POUS.21](#)) activates immediately when POUS function is requested according to the system design.
 10. Make sure that the POUS indication lamp goes on according to the system design. The delay is defined by parameter POUS delay for completion ([POUS.13](#)).
 11. Make sure that you cannot start the drive.
 12. Deactivate the POUS function request and give acknowledgement signal if the manual acknowledgement is used.
 13. Make sure that the POUS output ([POUS.21](#)) and indication lamp goes off.
 14. Start the drive and make sure that the motor runs normally.
-

■ Validation of the cascaded safety function

Without a PROFIsafe communication bus, you can cascade only safety functions which have a primary and a secondary digital input: STO, SS1, SSE, SLS1. Repeat the cascading validation procedure to all cascaded safety functions in your application.

This example shows how to validate the SSE function in a cascaded system (Cascade A) as shown in section [Cascade](#) on page 63.

1. Make sure that the cascaded safety function(s) are configured according to the wiring diagram.
2. Make sure that the cascaded safety functions are configured correctly according to your design. For a configuration example see chapter [How to configure a cascaded system](#) on page 248. Check these settings:

Master FSO:

- [SAFEIO.11 M/F mode for cascade](#)
- [SAFEIO.12 Cascade A](#)
- [STO.02 STO acknowledgement](#) = Automatic
- [SSE.11 SSE input A](#)
- [SSE.12 SSE input B](#)
- [SSE.21 SSE output](#)
- [FSOGEN.42 Acknowledgement button input](#)

Follower FSO modules (check the settings in each follower FSO module in the cascade chain):

- [SAFEIO.11 M/F mode for cascade](#)
- [STO.02 STO acknowledgement](#) = Automatic
- [SSE.11 SSE input A](#) or [SSE.12 SSE input B](#)
- [SSE.21 SSE output](#)

3. Activate cascaded safety function from the master FSO module.
4. Check that the correct safety function is activated in the whole cascaded chain.
5. Check that all cascaded safety functions are operating correctly according to the design in each of the cascaded FSO module.
6. Deactivate cascaded safety functions from the master FSO, and acknowledge the safety function by using manual acknowledgement if in use.
7. Check that the follower FSO modules are acknowledged.

Repeat this procedure for the Cascade B chain if in use.

Proof test intervals during operation

Proof tests are intended to ensure that the safety integrity of a safety system is maintained continuously and does not deteriorate over time. Proof tests are often required for mechanical brakes, for example. Proof tests are used mainly for parts of the system that cannot be automatically diagnosed.

The proof test interval is the interval between two proof tests. When the proof test interval has elapsed, the safety system has to be tested and restored to an "as new condition". The proof test must also be part of the regular maintenance plan.

For some of the components (electronics), the proof test interval is the same as the expected life time of the system.

A specific safety calculator software can assist in determining the requirements for the proof tests.

Residual risks

The safety functions are used to reduce the recognized hazardous conditions. In spite of this, it is not always possible to eliminate all potential hazards. Therefore the warnings for the residual risks must be given to the operators.



Fault tracing

Contents of this chapter

This chapter describes the status LEDs and provides generic diagnostics and troubleshooting tips for the FSO module related faults generated by the drive. It contains a list of the warning and fault messages with possible causes and corrective actions. The causes of most warnings and faults can be identified and corrected using the information in this chapter. If not, contact an ABB service representative.

Warnings and faults are listed in separate tables. Each table is sorted by warning/fault code.

Status LEDs

The status LEDs are situated on the front of the FSO module. The table below gives information on the status LED indications.

LED	LED off	LED on and steady		LED flashing	
POWER	No power	Green	Power to the FSO is on.	-	-
RUN	FSO is in the Fail-safe mode and Safe state (STO activated).	Green	FSO is in the Operational or Safe state.	Green	FSO is in the Configuration or Start-up mode.

LED	LED off	LED on and steady		LED flashing	
STATUS/FAULT	The drive is in normal operation, without active safety functions and no faults.	Green	A safety function is active.	Green	Request for a safety function has ended but it has not been acknowledged.
		Red	FSO is in the Fail-safe mode.	Red	FSO is in the Configuration mode (RUN LED is also blinking).
STO	The drive STO circuit is closed and the drive is in operation.	Green	The drive STO circuit is open.	-	-
FB	Safety communication to the fieldbus has stopped.	Green	FSO is ready to start safety communication to the fieldbus.	Green	Safety communication to the fieldbus is running.

Event types

The FSO module generates three types of events to the drive:

- Pure events, which are only informative data
- Warnings, which are shown to the user
- Faults, which stop the drive and are shown to the user.

It is not necessary to reset warnings. They stop showing when the cause of the warning stops or is repaired. Warnings will not trip the drive and the drive will continue to run the motor. Faults cause the drive to trip and the motor to stop. For information on how to recover from a fault, refer to section [FSO recovery](#) on page 394.

You can select the event type (warning, fault or event) for function requests, limit hits and special events:

- Parameter [FSOGEN.61 STO indication ext request](#) defines the event type for the STO, SS1 and SSE function external requests. The same parameter also defines the event type that the FSO module generates when the function is completed.

- Parameter [FSOGEN.62 STO indication safety limit](#) defines the event type for the limit hits of:
 - SLS1, ..., SLS4, Variable SLS and SMS functions
 - ramp monitoring and time monitoring of the safety ramps SAR0 and SAR1.
- Parameter [SBUSGEN.10 STO indication passivation](#) defines the event type for the FSO module passivation caused by safety fieldbus problems.

Event code decoding with Drive Composer pro PC tool

You can find the reason for the event from the event log of the Drive Composer PC tool. Hover the mouse over the AUX-code in Drive Composer. For a list of codes, see the table below.

Faults, warnings and events

Code (hex)	Name	Cause	What to do	
Faults				
7A81	TUCSO fault	FSO subsystem fault	Contact your local ABB representative.	
7A8B	FSO general fault	FSO module is in the Configuration mode. FSO module also generates this fault after certain malfunctions which the FSO module indicates by warnings. First the FSO module generates a warning indication which allows the drive to control the system to a safe state. After this the drive trips.	See the warning log for more information on the actual cause.	3)
7A90	FSO stop completed	FSO module has completed the STO, SS1 or SSE function.	-	1)
7A91	FSO safe speed limit	FSO module detected an SLS or SMS speed trip limit violation.	Check the separate code related to SLS and SMS functions. See section User-selectable events for limit hits and special events on page 392.	2) 3)
7A92	FSO out of eme ramp	Motor speed was not inside the ramp window during the SSE function.	Make sure that the drive can decelerate the load using the ramp time (200.102 SAR0 ramp time to zero).	2)
7A93	FSO ramp coasted	Drive coasted the motor to stop instead of using the ramp.	Make sure that the FSO module speed limit for stopping the ramp deceleration is not too large (FSOGEN.51 Zero speed without encoder).	2)
7A94	FSO out of safe ramp	Motor speed was not inside the ramp window during the SS1 function.	Make sure that the drive can decelerate the load using the ramp time (200.112 SAR1 ramp time to zero).	2)
7A97	FSO premature POUS	FSO received an external POUS request while the drive was still modulating.	It is recommended to activate the POUS function only when the drive is stopped.	

Code (hex)	Name	Cause	What to do	
7A98	FSO undefined fault	FSO new version, undefined fault in the dive event system.	Contact your local ABB representative.	
7A99	FSO passivated	FSO module was passivated due to safety fieldbus problems.	Examine the fieldbus connection and fieldbus controller for passivation cause.	5)
Warnings				
A7D0	FSO general warnings	Warning from the FSO module, for example: <ul style="list-style-type: none"> • acknowledgement button not operated correctly • I/O redundancy fault 	See the tips in the Drive Composer PC tool.	3)
A7D1	FSO internal fault	Internal fault in the FSO module	Reboot the FSO module. If the problem continues, replace the FSO module. Contact your local ABB representative.	5) 3)
A7D2	FSO IO fault	Problems in the I/O cabling or safety relays	Examine the FSO I/O cabling.	4) 3)
A7D3	FSO STO fault	Problems in the STO cabling or inside the drive	Examine the FSO STO cabling.	4)
A7D4	FSO STO request	FSO module received an external STO request.	-	1)
A7D5	FSO communication fault	Fault in FSO communication	Examine all connections.	4) 3)
A7D6	FSO safety fieldbus fault	Fault in FSO safety fieldbus communication	Examine all connections.	4) 3)
A7D7	FSO configuration fault	Fault in FSO configuration	Examine the FSO module parameter settings using Drive Composer pro.	4)

Code (hex)	Name	Cause	What to do	
A7D9	FSO encoderless fault	Speed estimates differ too much.	<ul style="list-style-type: none"> • Check the behavior of the driven load compared with the drive control parameter settings. • Make sure that the drive is suitable for the drive train and the motor. • Adapt control parameters if gear play or torsional rigidity causes problems. • <u>Drives with ACS880 primary control program (AINLX) version 3.47 or newer, or ACS880 primary control program (YINLX) version 1.30 or newer:</u> A7D9 indicates that drive parameter 99.16 Motor phase order was changed from its initial setting. Change parameter 99.16 back to its initial setting. If the motor turns in the incorrect direction, change the phase order of the motor cable. If the motor turns in the incorrect direction and it is impractical to change the phase order of the motor cable, contact your local ABB representative. 	4)
A7DA	FSO temperature fault	FSO module temperature is too high.	<ul style="list-style-type: none"> • Examine the ambient conditions. Reboot the FSO module. • Make sure that cooling is sufficient. Contact your local ABB representative. 	4)
A7DB	FSO undefined warning	FSO new version, undefined warning in the drive event system.	Contact your local ABB representative.	
AA90	FSO stop completed	FSO module has completed the STO, SS1 or SSE function.	-	1)
AA91	FSO safe speed limit	FSO module detected an SLS or SMS speed trip limit violation.	<p>Check the separate code related to SLS and SMS functions.</p> <p>See section User-selectable events for limit hits and special events on page 392.</p>	2) 3)

Code (hex)	Name	Cause	What to do	
AA92	FSO out of eme ramp	Motor speed was not inside the ramp window during the SSE function.	Make sure that the drive can decelerate the load using the ramp time (200.102 SAR0 ramp time to zero).	2)
AA93	FSO ramp coasted	Drive coasted the motor to stop instead of using the ramp.	Make sure that the FSO module zero speed limit for the deceleration ramp is not too large (FSOGEN.51 Zero speed without encoder).	2)
AA94	FSO out of safe ramp	Motor speed was not inside the ramp window during the SS1 function.	Make sure that the drive can decelerate the load using the ramp time (200.112 SAR1 ramp time to zero).	2)
AA97	FSO POUS request	FSO module received an external POUS request and activated POUS.	-	
AA99	FSO passivated	FSO module was passivated due to safety fieldbus problems.	Examine the fieldbus connection and fieldbus controller for passivation cause.	5)
AAA1	FSO STO request	FSO module received an external STO request.	-	1)
AAA2	FSO SSE request	FSO module received an external SSE request.	-	1)
AAA3	FSO SS1 request	FSO module received an external SS1 request.	-	1)
AAA4	FSO SLS1 hit	FSO module detected an SLS1 speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SLS is configured correctly. Make sure that SLS trip limits are defined correctly. Make sure that mute time values are defined correctly (FSOGEN.31 or SLSx.17 if enabled).	2) 6)

Code (hex)	Name	Cause	What to do	
AAA5	FSO SLS2 hit	FSO module detected an SLS2 speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SLS is configured correctly. Make sure that SLS trip limits are defined correctly. Make sure that mute time values are defined correctly (FSOGEN.31 or SLSx.27 if enabled).	2) 6)
AAA6	FSO SLS3 hit	FSO module detected an SLS3 speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SLS is configured correctly. Make sure that SLS trip limits are defined correctly. Make sure that mute time values are defined properly (FSOGEN.31 or SLSx.37 if enabled).	2) 6)
AAA7	FSO SLS4 hit	FSO module detected an SLS4 speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SLS is configured correctly. Make sure that SLS trip limits are defined correctly. Make sure that mute time values are defined properly (FSOGEN.31 or SLSx.47 if enabled).	2) 6)
AAA8	FSO SMS hit	FSO module detected an SMS speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SMS is configured correctly. Make sure that SMS trip limits are defined correctly. Make sure that mute time values are defined properly (FSOGEN.31 or SMS.17 if enabled).	2) 6)
AAA9	FSO SAR0 hit	FSO module detected an SAR0 limit violation.	Make sure that the drive can decelerate the load using the ramp time (200.102 SAR0 ramp time to zero).	2)

Code (hex)	Name	Cause	What to do	
AAAA	FSO SAR1 hit	FSO module detected an SAR1 limit violation.	Make sure that the drive can decelerate the load using the ramp time (200.112 SAR1 ramp time to zero).	2)
AAB2	FSO ramp time hit	FSO module detected a violation of a time monitored ramp.	<p>Make sure that the drive can decelerate the load within the time defined for ramp time monitoring.</p> <ul style="list-style-type: none"> Examine the drive ramp time settings. Make sure that the drive can in fact accomplish the deceleration along the ramp defined. <p>Make sure that the limit for ramp time monitoring of the FSO module exceeds the actual drive ramp time. The parameter varies depending on the safety function. For the SS1 function it is SS1.14 SS1-t delay for STO.</p>	2)
AAB3	FSO zero spd hit	Drive speed rushed during zero speed delay (SSE.16 SSE ramp zero speed delay for STO or SS1.15 SS1-r ramp zero speed delay for STO).	Examine the drive.	2)
AAB4	FSO speed sync fail	FSO module detected a difference between the two monitored motor speed values (200.01 FSO speed ch1 and 200.02 FSO speed ch2).	Restart the drive and the FSO module.	2)
AAB5	FSO varSLS hit	FSO module detected a Variable SLS speed trip limit violation.	<p>Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that Variable SLS is configured correctly.</p> <p>Make sure that Variable SLS trip limits are defined correctly.</p> <p>Make sure that mute time values are defined correctly (FSOGEN.31 or SLSx.57 if enabled).</p>	2) 6)

Code (hex)	Name	Cause	What to do	
AAB6	FSO safebus passivation	FSO module was passivated due to communication problems.	Examine the fieldbus connection and fieldbus controller for passivation cause.	5)
Events				
B790	FSO general event	FSO module generated an event other than a fault or a warning.	See the tips in the Drive Composer PC tool.	3)
B792	FSO undefined event	FSO new version, undefined event in the drive event system.	Contact your local ABB representative.	
BA90	FSO stop completed	FSO module has completed the STO, SS1 or SSE function.	-	1)
BA91	FSO safe speed limit	FSO module detected an SLS or SMS speed trip limit violation.	Check the separate code related to SLS and SMS functions. See section User-selectable events for limit hits and special events on page 392.	2) 3)
BA92	FSO out of eme ramp	Motor speed was not inside the ramp window during the SSE function.	Make sure that the drive can decelerate the load using the ramp time (200.102 SAR0 ramp time to zero).	2)
BA93	FSO ramp coasted	Drive coasted the motor to stop instead of using the ramp.	Make sure that the FSO module zero speed limit for the deceleration ramp is not too large (FSOGEN.51 Zero speed without encoder).	2)
BA94	FSO out of safe ramp	Motor speed was not inside the ramp window during the SS1 function.	Make sure that the drive can decelerate the load using the ramp time (200.112 SAR1 ramp time to zero).	2)
BA99	FSO passivated	FSO module was passivated due to safety fieldbus problems.	Examine the fieldbus connection and fieldbus controller for passivation cause.	5)
BAA1	FSO STO request	FSO module received an external STO request.	-	1)
BAA2	FSO SSE request	FSO module received an external SSE request.	-	1)
BAA3	FSO SS1 request	FSO module received an external SS1 request.	-	1)

Code (hex)	Name	Cause	What to do	
BAA4	FSO SLS1 hit	FSO module detected an SLS1 speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SLS is configured correctly. Make sure that SLS trip limits are defined correctly. Make sure that transient mute time values are defined correctly (FSOGEN.31 or SLSx.17 if enabled).	2) 6)
BAA5	FSO SLS2 hit	FSO module detected an SLS2 speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SLS is configured correctly. Make sure that SLS trip limits are defined correctly. Make sure that transient mute time values are defined correctly (FSOGEN.31 or SLSx.27 if enabled).	2) 6)
BAA6	FSO SLS3 hit	FSO module detected an SLS3 speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SLS is configured correctly. Make sure that SLS trip limits are defined correctly. Make sure that transient mute time values are defined correctly (FSOGEN.31 or SLSx.37 if enabled).	2) 6)
BAA7	FSO SLS4 hit	FSO module detected an SLS4 speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SLS is configured correctly. Make sure that SLS trip limits are defined correctly. Make sure that transient mute time values are defined correctly (FSOGEN.31 or SLSx.47 if enabled).	2) 6)

Code (hex)	Name	Cause	What to do	
BAA8	FSO SMS hit	FSO module detected an SMS speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that SMS is configured correctly. Make sure that SMS trip limits are defined correctly. Make sure that transient mute time values are defined correctly (FSOGEN.31 or SMS.17 if enabled).	2) 6)
BAA9	FSO SAR0 hit	FSO module detected an SAR0 limit violation.	Make sure that the drive can decelerate the load using the ramp time (200.102 SAR0 ramp time to zero).	2)
BAAA	FSO SAR1 hit	FSO module detected an SAR1 limit violation.	Make sure that the drive can decelerate the load using the ramp time (200.112 SAR1 ramp time to zero).	2)
BAB2	FSO ramp time hit	FSO module detected a violation of a time monitored ramp.	Make sure that the drive can decelerate the load within the time defined for ramp time monitoring. <ul style="list-style-type: none"> Examine the drive ramp time settings. Make sure that the drive can in fact accomplish the deceleration along the ramp defined. Make sure that the limit for ramp time monitoring of the FSO module exceeds the actual drive ramp time. The parameter varies depending on the safety function. For the SS1 function it is SS1.14 SS1-t delay for STO .	2)
BAB3	FSO zero spd hit	Drive speed rushed during zero speed delay (SSE.16 SSE ramp zero speed delay for STO or SS1.15 SS1-r ramp zero speed delay for STO).	Check the drive.	2)
BAB4	FSO speed sync fail	FSO module detected a difference between the two monitored motor speed values (200.01 FSO speed ch1 and 200.02 FSO speed ch2).	Restart the drive and FSO module.	2)

Code (hex)	Name	Cause	What to do
BAB5	FSO varSLS hit	FSO module detected a Variable SLS speed trip limit violation.	Do an investigation to find the cause for the trip from the application point of view. If the application is correct, make sure that Variable SLS is configured correctly. Make sure that Variable SLS trip limits are defined correctly. Make sure that transient mute time values are defined correctly (FSOGEN.31 or SLSx.57 if enabled).
BAB6	FSO safebus passivation	FSO module was passivated due to communication problems.	Examine the fieldbus connection and fieldbus controller for passivation cause.

2) 6)

5)

¹⁾ This is a user-selectable event for a function request. See parameter [FSOGEN.61 STO indication ext request](#) and section [User-selectable events for function requests](#) on page 391.

²⁾ This is a user-selectable event for a limit hit or a special event. See parameter [FSOGEN.62 STO indication safety limit](#) and section [User-selectable events for limit hits and special events](#) on page 391.

³⁾ For more information, see the tips in the Drive Composer PC tool.

⁴⁾ This warning indicates a fault actually. However, the FSO module generates a warning indication first to allow the drive to control the system to a safe state. When the system is in the safe state, the drive trips. Fault indication is [7A8B FSO general fault](#).

⁵⁾ This is a user-selectable event for a safety fieldbus failure. See parameter [SBUSGEN.10 STO indication passivation](#) and section [User-selectable events for safety fieldbus failures](#) on page 394.

⁶⁾ See section [Configuring mute times](#) on page 301.

■ **User-selectable events for function requests**

The table below gives the user-selectable events related to function requests.

Function/ Incident	Events depending on the event type selection (parameter FSOGEN.61)		
	Fault	Warning	Event
STO function			
STO request	AAA1 FSO STO request (warning) ¹⁾	AAA1 FSO STO request	BAA1 FSO STO request
STO completed	7A90 FSO stop completed	AA90 FSO stop completed	BA90 FSO stop completed
SS1 function			
SS1 request	AAA3 FSO SS1 request (warning) ¹⁾	AAA3 FSO SS1 request	BAA3 FSO SS1 request
SS1 completed	7A90 FSO stop completed	AA90 FSO stop completed	BA90 FSO stop completed

Function/ Incident	Events depending on the event type selection (parameter FSOGEN.61)		
	Fault	Warning	Event
SSE function			
SSE request	AAA2 FSO SSE request (warning) ¹⁾	AAA2 FSO SSE request	BAA2 FSO SSE request
SSE completed	7A90 FSO stop completed	AA90 FSO stop completed	BA90 FSO stop completed

¹⁾ If you select Fault for parameter [FSOGEN.61 STO indication ext request](#), the FSO module generates a warning at the function request, and a fault trip only after the function is completed. The fault trip is delayed because the drive must be able to control the system to the Safe state first.

Note: If you select None for parameter [FSOGEN.61 STO indication ext request](#), the FSO module generates no event when it receives a function request or detects that the function is completed.

■ **User-selectable events for limit hits and special events**

The table below gives user-selectable events related to limit hits and special events.

Limit/Incident	Events depending on the event type selection (parameter FSOGEN.62)		
	Fault	Warning	Event
SLS1			
SLS1 limit hit	AAA4 FSO SLS1 hit (warning) ¹⁾	AAA4 FSO SLS1 hit	BAA4 FSO SLS1 hit
System at safe state	7A91 FSO safe speed limit	AA91 FSO safe speed limit	BA91 FSO safe speed limit
SLS2			
SLS2 limit hit	AAA5 FSO SLS2 hit (warning) ¹⁾	AAA5 FSO SLS2 hit	BAA5 FSO SLS2 hit
System at safe state	7A91 FSO safe speed limit	AA91 FSO safe speed limit	BA91 FSO safe speed limit
SLS3			
SLS2 limit hit	AAA6 FSO SLS3 hit (warning) ¹⁾	AAA6 FSO SLS3 hit	BAA6 FSO SLS3 hit
System at safe state	7A91 FSO safe speed limit	AA91 FSO safe speed limit	BA91 FSO safe speed limit
SLS4			
SLS4 limit hit	AAA7 FSO SLS4 hit (warning) ¹⁾	AAA7 FSO SLS4 hit	BAA7 FSO SLS4 hit
System at safe state	7A91 FSO safe speed limit	AA91 FSO safe speed limit	BA91 FSO safe speed limit

Limit/Incident	Events depending on the event type selection (parameter FSOGEN.62)		
	Fault	Warning	Event
Variable SLS			
varSLS limit hit	AAB5 FSO varSLS hit (warning)¹⁾	AAB5 FSO varSLS hit	BAB5 FSO varSLS hit
System at safe state	7A91 FSO safe speed limit	AA91 FSO safe speed limit	BA91 FSO safe speed limit
SMS			
SMS limit hit	AAA8 FSO SMS hit (warning)¹⁾	AAA8 FSO SMS hit	BAA8 FSO SMS hit
System at safe state	7A91 FSO safe speed limit	AA91 FSO safe speed limit	BA91 FSO safe speed limit
SARO			
SARO limit hit	AAA9 FSO SARO hit (warning)¹⁾	AAA9 FSO SARO hit	BAA9 FSO SARO hit
System at safe state	7A92 FSO out of eme ramp	AA92 FSO out of eme ramp	BA92 FSO out of eme ramp
SAR1			
SAR1 limit hit	AAAA FSO SAR1 hit (warning)¹⁾	AAAA FSO SAR1 hit	BAAA FSO SAR1 hit
System at safe state	7A92 FSO out of eme ramp	AA92 FSO out of eme ramp	BA92 FSO out of eme ramp
Ramp time hit			
Ramp time hit	AAB2 FSO ramp time hit (warning)¹⁾	AAB2 FSO ramp time hit	BAB2 FSO ramp time hit
System at safe state	7A92 FSO out of eme ramp	AA92 FSO out of eme ramp	BA92 FSO out of eme ramp
Zero speed hit			
Zero speed hit	AAB3 FSO zero spd hit (warning)¹⁾	AAB3 FSO zero spd hit	BAB3 FSO zero spd hit
System at safe state	7A92 FSO out of eme ramp	AA92 FSO out of eme ramp	BA92 FSO out of eme ramp
Speed values not in synchrony			
Speeds not in sync.	AAB4 FSO speed sync fail (warning)¹⁾	AAB4 FSO speed sync fail	BAB4 FSO speed sync fail
System at safe state	7A90 FSO stop completed	AA90 FSO stop completed	BA90 FSO stop completed

¹⁾ If you select Fault for parameter [FSOGEN.62 STO indication safety limit](#), the FSO module generates a warning at the limit hit, and a fault only after the system is at the Safe state.

Note: If you select None for parameter [FSOGEN.62 STO indication safety limit](#), the FSO module

generates no event when it detects a limit hit.

■ **User-selectable events for safety fieldbus failures**

The table below gives user-selectable events related to safety fieldbus failures.

Incident	Events depending on the event type selection (parameter SBUSGEN.10)		
	Fault	Warning	Event
Problem in the safety fieldbus communication	AAB6 FSO safebus passivation (warning) ¹⁾	AAB6 FSO safebus passivation	BAB6 FSO safebus passivation
System at safe state	7A99 FSO passivated	AA99 FSO passivated	BA99 FSO passivated

¹⁾ If you select Fault for parameter [SBUSGEN.10 STO indication passivation](#), the FSO module generates a warning at the passivation, and a fault only after the system is at the Safe state.

Note: If you select None for parameter [SBUSGEN.10 STO indication passivation](#), the FSO module generates no event when it detects a failure in the safety fieldbus communication.

Auxiliary codes

Faults, warnings and events have 32-bit auxiliary codes, which help in finding the problem. See the tips in the Drive Composer PC tool for more information on the auxiliary codes.

FSO recovery

■ **External fault**

An external fault in a safety circuit can lead to safe state or fail-safe state activation in the FSO module. Safe state means STO activation with software indication according to [Faults, warnings and events](#) table on page 382. A drive reset is necessary before resuming normal operation.

In the fail-safe state, STO is activated and an applicable fault code is shown. In this case, a drive reset and FSO reboot are necessary before resuming normal operation.

If the FSO module goes into the fail-safe state because of an external fault that can be repaired, resuming normal operation can occur after a reboot of the FSO module. The steps for recovering from the fault situation are as follows:

1. Find the cause of the fault from the Drive Composer event log.
2. Repair the cause of the fault. Refer to the instructions in section [Faults, warnings and events](#) on page 382.
3. Reboot the FSO with one of the methods below:
 - Disconnect the X112 connector and reconnect it (power off and on), or
 - Use the **Reboot FSO** button in the Drive Composer pro PC tool (Safety settings), or
 - Use the drive parameter 96.09 FSO reboot (with Drive Composer or control panel).

Note: The FSO accepts a 'soft boot' if it is in Fail-safe mode and the motor is stopped.

If necessary, also reset the fault in the drive using the control panel (by pressing the Reset button) or the Drive Composer pro PC tool, or through the fieldbus.

If the FSO module does not recover from the fault, contact your local ABB representative.

■ Internal fault

If there is an internal fault in FSO module that leads to a permanent defect, the module must be replaced. The FSO module is not repairable.

Reporting problems and failures

If you detect a failure in the safety module or safety function that prevents FSO fault recovery, contact your local ABB representative. Provide the support package file of your configuration and the safety file of the FSO module. For more information, refer to the Drive Composer PC tool user's manual.

15

Maintenance

Contents of this chapter

This chapter contains maintenance information related to the FSO module:

- instructions for component replacement in the safety circuit (for example, replacement of the FSO module, control unit, memory unit, power unit, or FB module)
- how to reset the FSO module to factory settings
- how to recover the FSO module from fail-safe mode
- information about updates to the safety system
- information about proof tests.



WARNING! Obey the instructions in chapter [Safety instructions](#). If you ignore them, injury or death, or damage to the equipment can occur.

Planning

All maintenance and repair actions on a safety critical system must be planned, performed and documented accordingly.

Tools

You need the Drive Composer pro PC tool to perform the maintenance procedures.

Component replacement in the safety circuit



WARNING! During maintenance and repair, if the FSO module is removed, the functional safety of the machinery must be ensured by other means.

If the FSO module fails to operate, you must replace it with a new one. The module is not repairable.

Save the safety configuration file and parameter backup file during the first commissioning and after successful validation tests of the safety functions.

Note: When the FSO module is in the Fail-safe mode, it can be recovered by a reboot. Refer to section [FSO recovery](#) on page 394 for rebooting instructions.

■ Before component replacement



WARNING! Obey the instructions in chapter [Safety instructions](#). If you ignore them, injury or death, or damage to the equipment can occur.

1. Stop the driven machinery and prevent an unexpected start-up.
 2. Upload the FSO parameters from the FSO to the Drive Composer pro PC tool and save the safety file. If this is not possible, use a backup from a previous commissioning.
 3. Create a parameter backup file with the Drive Composer PC tool or control panel.
 4. Open the supply disconnecting device. Refer to the drive hardware manual.
 5. Make sure that it is safe to start the work.
-

■ Replacing the FSO module



WARNING: Do not bypass the FSO module, or the safety functions of the FSO module under any circumstances.

1. Disconnect IO wiring, data cable and STO cable and remove the FSO module.
2. Mark clearly on the FSO module that it is decommissioned.
3. Install the new FSO module and wiring according to the instructions in chapter [Installation](#).
4. Download the FSO parameters from the Drive Composer pro PC tool to the FSO module according to chapter [Configuration](#).
5. If you are updating the module from revision G (or earlier) to revision H (or later), there are new parameters that you must set. See [SLSx.05](#) and [SLSx.06](#) on page [331](#). If you download an old configuration, the new parameters will get the default values. It is recommended to download, upload, and check the parameters.
6. Update the revision and the serial number of the new FSO module to the logbook of the driven machine.

■ Installing the FSO module to another drive

1. Install the FSO module and wiring to the new drive according to chapter [Installation](#).
 2. Restore the drive parameter backup, if available.
 3. Download the correct safety configuration file to the spare part FSO module.
-

■ Replacing the control unit of the drive

This section gives instructions on how to replace a control unit with the same type of control unit.

1. Make a backup of the drive parameters. Use a control panel or the Drive Composer PC tool.
2. Replace the control unit. Refer to the drive hardware manual and/or control unit hardware manual.
3. Install the FSO module and connect data and STO cables to the control unit. Connect FSO IO connectors and power supply connector.
4. Restore the drive configuration:
 - install the previously used memory unit to the new control unit, or
 - install a new memory unit and restore the parameter backup with the Drive Composer PC tool or control panel.
5. Do the start-up and validation procedures. Refer to section [Start-up and validation test](#) on page [402](#).

■ Replacing the control unit of the drive with a different type of control unit

This section gives instructions on how to replace a control unit with a different type of control unit. In this example, a BCU-02 will be replaced with a UCU-22 control unit.

Note: Memory units, firmware versions, and data cables for FSO are not interchangeable between BCU and UCU control units.

1. Make a backup of the drive parameters. Use a control panel or the Drive Composer PC tool.
2. Replace the BCU-02 control unit with a UCU-22 control unit. Refer to the drive hardware manual and/or control unit hardware manual.
3. Install the FSO module.
4. Connect the UCU-22 compatible data cable between the control unit and FSO module.
5. Connect the STO cable to the control unit.
6. Connect the FSO IO connectors and power supply connector.
7. Install an UMU-01 memory unit.
8. Restore the drive parameters from the backup.
9. Read the configuration from FSO, then restore it to the control unit with the Drive Composer pro PC tool.
10. Reboot the FSO module.
11. Reset the drive.
12. Do the start-up and validation procedures. See section [Start-up and validation test](#) on page 402.

■ Replacing the memory unit or updating the firmware of the drive

1. Take a backup of the drive parameter settings, if possible.
2. Download the drive firmware to the memory unit.
3. Restore drive parameter backup, if available.
4. Reboot the FSO module.
5. Reset the drive.
6. Upload and download the FSO configuration file if the drive firmware is updated from an older version than AINLX 2.60.

■ Replacing a power unit, or its circuit boards or wirings

1. Replace the relevant part or power unit.
 2. Do the start-up and validation procedures. Refer to section [Start-up and validation test](#) on page 402.
-

■ Replacing the motor or motor cable

1. Replace the motor or motor cable.
2. If the motor was replaced with a different type of motor, do the steps in section [Start-up and validation test](#) on page 402.
3. Make sure that the motor turns in the correct direction and at the requested speed. For example, request 100 rpm and make sure that the direction and speed is correct.

■ Replacing the FB module in PROFIsafe network

1. Replace the FB module according to the instructions in [FPNO-21 PROFINET fieldbus adapter module user's manual \(3AXD50000158614 \[English\]\)](#), or [FENA-01/-11/-21 Ethernet adapter module user's manual \(3AUA0000093568 \[English\]\)](#).
2. Assign the device name for the FB module from the safety PLC (see section [Configuring the ABB AC500-S Safety PLC](#) on page 164 or section [Configuring the Siemens SIMATIC Fail-safe S7 PLC](#) on page 181.
3. Update the revision and the serial number of the new FB module to the logbook of the driven machine.

■ Start-up and validation test

1. Do the start-up procedure according to chapter [Start-up](#).
2. Do the validation procedure for each safety function according to chapter [Verification and validation](#).

Factory reset


Only do a factory reset if:

- you forget the password, or
- you want to do the configuration again from scratch.

Note: The factory reset clears the configuration and takes the factory default values back in use. These factory default values are not the same as the preset values in a delivered FSO (ordered with a plus code). The factory default values are invalid for restart. The FSO needs a full reconfiguration before it can be restarted. You can also use the safety file that was saved at the first start-up (see page 242).

1. Make sure that the motor is stopped.
 2. Lift the **Factory reset** label on the right side of the I/O terminals. Push the button underneath with, for example, a pen until the LEDs start to flash
-

(approximately 5 seconds). This returns the factory settings (parameters, including the password) to the FSO.



3. Configure the safety functions with the Drive Composer pro PC tool. To be able to restart the drive, make sure that at least these parameters are set according to application requirements:

Parameter index	Name	Factory default value	Preset value (with option +Q973)
FSOGEN.21	Motor nominal speed	100.0 rpm	1500.0 rpm
FSOGEN.22	Motor nominal frequency	1 Hz	50 Hz
FSOGEN.41	Power-up acknowledgement	Manual	Automatic
STO.02	STO acknowledgement	Manual	Automatic
STO.13	Restart delay after STO	3,600,000 ms	2000 ms
STO.14	Time to zero speed with STO and modoff	3,600,000 ms	2000 ms
SBC.11	STO SBC usage	Delayed brake	None
SLSx.02	SLS acknowledgement	Manual	Automatic

4. Set a new password with the Drive Composer PC tool.

Drive control board boot

If you reboot the drive control unit (for example, by cycling the power or with parameter 96.08 Control board boot), the FSO module goes into the Fail-safe mode.

To exit the Fail-safe mode:

- switch the FSO module power off and then switch it back on, or
- reboot the FSO module with drive parameter 96.09 FSO reboot, or
- click the **Reboot FSO** button in Drive Composer pro.

Note: The STO function must be completed before you can reboot the FSO module with parameter 96.09 FSO reboot or with the **Reboot FSO** button. Refer to section [Safe torque off \(STO\)](#) on page 67.

Updates

After changes in the safety application or the safety system configuration, you must do the validation tests to make sure that the safety functionality is maintained. Refer to chapter [Verification and validation](#).

Proof tests

Periodic proof testing of the safety system may be required in order to maintain the claimed SIL/PL level of the system, to make sure that the safety integrity of a safety system is maintained continuously and does not deteriorate over time.

If proof testing is required, it must be taken into consideration in the safety calculations, maintenance manuals, user documentation, and it must be done periodically.

In high demand mode of operation, the maximum proof test interval for the FSO module is 20 years. In low demand mode of operation, the maximum proof test interval for FSO is 20, 5 or 2 years. You must select the proof test interval according to the application where the modules are used. Refer to section [Safety data](#) on page 411.

To do a proof test of the FSO module, obey the instructions in section [Validation of safety functions](#) on page 359. A reboot of the FSO module is necessary for the proof test.

Decommissioning



WARNING! Obey the instructions in chapter [Safety instructions](#). If you ignore them, injury or death, or damage to the equipment can occur.

When you decommission the FSO module, make sure that the safety of the machine is maintained until the decommissioning is complete. Mark clearly on the module that it is decommissioned.

If you use the SMS function, version 2, obey the instructions in section [SMS function, version 2](#) on page 130.



Technical data

Contents of this chapter

This chapter contains the technical specifications of the FSO-12 module.

Electrical data

Supply voltage	+24 ± 3 V DC (PELV)
Current consumption	Maximum 1000 mA (external power supply)
Inputs	4 redundant or 8 single, or combinations of redundant and single, 24 V DC NPN Maximum time delay between redundant input channels: 300 ms Maximum test pulse tolerance: 2 ms
Outputs	3 redundant or 6 single, or combinations of redundant and single, 24 V DC PNP
EMC	Complies with EMC standards EN 61800-3:2004 and IEC 61000-6-7:2014. For the maximum STO cable length, refer to section STO cable and data cable between FSO module and drive on page 408.

PROFIsafe and related network devices

All network devices used in conjunction with this device shall meet the requirements of IEC 61010-1 or IEC 61131-2.

Control connection data

Logic levels	“0” < 5 V, “1” > 15 V
Digital input impedance	4 kohm
Digital output capability	150 mA @ 20 V each, 700 mA @ 20 V total when all outputs are in use
Max. cable length between digital input/output and external device	250 m (820 ft)
Max. current through signal ground terminals (X113:5, X113:5, X114:5, X114:6)	1000 mA

Terminal and cable entry data for the control cables

The tightening torque for the terminals is 0.24 N·m (2.1 lbf·in).

Conductor size, one conductor					
Solid or stranded		Stranded, ferrule without plastic sleeve		Stranded, ferrule with plastic sleeve	
Minimum	Maximum	Minimum	Maximum	Minimum	Maximum
mm ²	mm ²	mm ²	mm ²	mm ²	mm ²
0.14	1.5	0.25	1.5	0.25	0.5

Conductor size, one conductor					
Solid or stranded		Stranded, ferrule without plastic sleeve		Stranded, ferrule with plastic sleeve	
Minimum	Maximum	Minimum	Maximum	Minimum	Maximum
AWG	AWG	AWG	AWG	AWG	AWG
26	16	23	16	23	21


Conductor size, two conductors with the same cross section							
Solid		Stranded		Stranded, ferrules without plastic sleeve		Stranded, TWIN ferrules with plastic sleeve	
Minimum	Maximum	Minimum	Maximum	Minimum	Maximum	Minimum	Maximum
mm ²	mm ²	mm ²	mm ²	mm ²	mm ²	mm ²	mm ²
0.08	0.5	0.08	0.75	0.25	0.34	0.5	0.5

Conductor size, two conductors with the same cross section							
Solid		Stranded		Stranded, ferrules without plastic sleeve		Stranded, TWIN ferrules with plastic sleeve	
Minimum	Maximum	Minimum	Maximum	Minimum	Maximum	Minimum	Maximum
AWG	AWG	AWG	AWG	AWG	AWG	AWG	AWG
28	21	28	19	23	22	21	21

STO cable and data cable between FSO module and drive

STO cable	ABB recommends that you use the cable included in the delivery. The specifications for a customer-defined cable are as follows: <ul style="list-style-type: none">• Maximum length: 1 m (3.28 ft)• Use the connectors of the original STO cable. Tightening torque is 0.24 N·m (2.1 lbf·in).• See pin order in section Terminals on page 231.• Installation must comply with good installation practices (routing, shielding, supporting, strain relief).
Data cable	Use only the data cable included in the delivery.

Tightening torques

Image	No.	Description	Torque
	1.	Grounding screw, FSO module electronics	1.2 N·m (10.6 lbf·in)
	-	Screws that attach mounting plate to FSO module, 4 pcs. On the back.	0.96 N·m (8.5 lbf·in)
	3.	Screws that ground the mounting plate to drive (metal to metal).	1.2 N·m (10.6 lbf·in)
	OR		
		Screws that attach the mounting plate to drive (metal to plastic).	0.79 N·m (7.0 lbf·in)

Size and weight

	mm	in	kg	lb
Length	100	3.94	-	-
Width	60	2.36	-	-
Depth (with wiring)	50	1.97	-	-
Weight	-	-	0.230	0.507

Cooling

Cooling method	Dry clean air (natural convection)
----------------	------------------------------------

Compatible motor types

Motor type	Induction motor (IM), Permanent magnet motor (PM), Synchronous reluctance motor (SynRM)
Motor control mode	FSO can be used in Direct Torque Control (DTC) or scalar mode.

Speed estimation

Speed range	Permitted range depends on the motor used. Maximum range: (-35880...+35880 rpm)/(number of motor pole pairs).
Accuracy	The speed estimation error is ± motor slip. There can also be estimation ripples at the zero speed region (below 2 Hz / 3% of the nominal speed). For more information, refer to section Safe speed estimate on page 45.
Operational frequency	Drive output up to 598 Hz

Ambient conditions

	Operation installed for stationary use	Storage in the protective package	Transportation in the protective package
Altitude	0...1000 m (0...3281 ft) above sea level: no derating necessary 1000...2000 m (3281...6564 ft) above sea level: air outside the module is derated to -15...+49 °C (+5...+120 °F) 2000...4000 m (6564...13124 ft) above sea level: air outside the module is derated to -15...+40 °C (+5...+104 °F)	-	-
Air temperature	-15...+70 °C (+5...+158 °F)	-40...+70 °C (-40...+158 °F)	-40...+70 °C (-40...+158 °F)
Relative humidity	5...95%, no condensation permitted. If corrosive gases are present, the maximum permitted humidity is 60%.		

	Operation installed for stationary use	Storage in the protective package	Transportation in the protective package
Contamination	IEC 60721-3-3:2002 Chemical gases: Class 3C2 Solid particles: Class 3S2	IEC 60721-3-1:1997 Chemical gases: Class 1C2 Solid particles: Class 1S3	IEC 60721-3-2:1997 Chemical gases: Class 2C2 Solid particles: Class 2S2
	No contaminants, conductive dust or corrosive dust permitted. Use at least IP54 enclosure in an environment where there is conductive or corrosive dust.		
Vibration IEC 60068-2-6, Test Fc (2007- 12)	Frequency range: <u>2...9 Hz</u> : Constant deflection = 7 mm <u>9...200 Hz</u> : Constant acceleration = 20 m/s ²		
Shock IEC 60068-2-27 Test Ea (2008-02)	Peak acceleration 50 m/s ² . Pulse duration 30 ms, 3 pulses in each direction with STO and SS1 functions activated.		
Atmospheric pressure	70 ... 106 kPa (0.7 ... 1.05 atmospheres)		

For the environmental limits of the drive, refer to the drive hardware manual.


Safety functions

Stopping functions	
STO	Safe torque off
SBC	Safe brake control
SS1	Safe stop 1
SSE	Safe stop emergency
Speed-related functions	
SLS	Safely-limited speed
Variable SLS	Variable Safely-limited speed
SMS	Safe maximum speed
SAR	Safe acceleration range - SAR is used only for deceleration with SS1, SSE and SLS and Variable SLS functions.
Other	
POUS	Prevention of unexpected start-up

Safety data

■ General

To determine the SIL/PL capability of the whole safety function where the FSO is included, the failure rates (PFD_{avg}/PFH) of all components implementing the safety function (see the figure below) must be added.



- **FSO module with its subsystems.** The FSO acts as the logic part in the safety function. The safety data for the safety function where FSO and drive are used is composed of the safety data of the subsystems. Safety data for different subsystems is shown in section [Basic safety data](#) on page 413.
- **Digital inputs and outputs.** Subsystems for the digital inputs and outputs of the FSO. Can be used as single or dual channel and with or without diagnostic pulses.
- **Speed measurement subsystem** is a mix of two different safety data as the speed estimation is calculated independently by the FSO and the drive. In the safety data tables, these two safety data are already combined in the safety data of this subsystem. This subsystem can be used together with the following safety functions: STO (with or without SBC), SS1, SSE, SLS, varSLS, SMS.

Note: POUS does not use any speed measurement subsystem.

- **PROFIsafe** is a subsystem for the reliability of PROFIsafe connection. This subsystem is used in case the PROFIsafe connection is in use in the application through FENA-21 or FPNO-21 module. FSO module takes care of the reliability and safety of this connection.
- **Logic subsystem** is included in each safety function implemented with the FSO.
- **STO output from the FSO** to the Drive STO. STO is a critical subsystem for all safety functions. Therefore it shall be included in safety calculations of those functions.
- **Drive STO** is the actuator for the STO of the drive. For the safety data, see the drive hardware manual.

Note: All safety functions have the capability to activate STO. This means that STO subsystems (STO output and Drive STO) are always part of the safety function's calculations even though it might not be activated in normal use.

- **Sensors, input devices, encoders, PLCs, and possible additional actuators.** Refer to section [FSO safety calculations guide \(without PROFIsafe\)](#) on page 414. For the safety data, refer to the documentation of the manufacturer.
- **SLS function** uses the Speed measurement subsystem.

After calculating the total PFDavg/PFH for the safety function, it must be verified that the PFDavg/PFH of the safety function fulfills the requirement for the targeted SIL/PL.

For additional information on safety calculations, see standards EN ISO 13849-1, EN/IEC 62061, IEC 61508, IEC 61511, or [Technical guide No. 10, Functional safety \(3AUA0000048753 \[English\]\)](#).

■ Basic safety data

The FSO-12 module is a type B safety component as defined in IEC 61508-2. The FSO-12 data related to safety standards IEC 61508, EN/IEC 61800-5-2, EN ISO 13849-1, IEC 61511, and EN/IEC 62061 is listed below for the different subsystems within the FSO module.

The maximum useful mission time (T_m) for the FSO module is 20 years. After 20 years, the module must be replaced.

The given safety data is applicable with these proof test intervals:

- $T_1 = 20$ years (high demand and continuous mode of operation)
- $T_1 = 2, 5, \text{ or } 20$ years (low demand mode of operation).

Make sure that the proof test is performed within this time (see also section [Proof tests](#) on page 404).

EN/IEC 61508		EN ISO 13849-1		EN/IEC 62061	
SIL	up to 3	PL	up to e	SIL	3

3AXD10001287182 D

	1-ch. DI, pulses	2-ch. DI, pulses	1-ch. DI, no pulses	2-ch. DI, no pulses	Logic	PROFI-safe ¹⁾
SIL	3	3	2	3	3	3
PL	d	e	c	e	e	e
PFH (1/h) ($T_1 = 20$ a)	1.1E-10	5.5E-12	1.1E-08	2.9E-11	1.1E-11	1.0E-09
PFD_{avg} ($T_1 = 2$ a)	5.8E-08	5.9E-08	5.7E-06	6.7E-07	9.9E-08	8.8E-06
PFD_{avg} ($T_1 = 5$ a)	1.4E-07	1.5E-07	1.4E-05	1.7E-06	2.5E-07	2.2E-05
PFD_{avg} ($T_1 = 20$ a)	5.8E-07	5.9E-07	5.8E-05	6.7E-06	9.9E-07	8.8E-05
MTTF_D (a)	10747	10431	10628	10738	11290	114155
HFT	0	1	0	1	1	-
Cat.	2	3	1	3	3	4
SFF (%)	99.7	99.7	73.5	98.6	99.0	99.0
DC (%)	99.0	99.0	1.4	94.6	96.7	99.0

3AXD10001287182 D

1) We assume conservatively that $PFH = \lambda d = 1$, $FIT = 1e-9$ 1/h, $MTTF_D = 1/\lambda d = 1/(1e-9$ 1/h) = $1e9$ h = 114155 a. Based on the BGIA Report 2/2008e: Functional Safety of Machine Controls – Application of EN ISO 13849, ch. 6.2.17.


	1-ch. DO, pulses	2-ch. DO, pulses	1-ch. DO, no pulses	2-ch. DO, no pulses	STO output	Speed estimate, worst case values
SIL	3	3	1	3	3	3
PL	d	e	c	e	e	e
PFH (1/h) (T ₁ = 20 a)	6.3E-10	1.7E-10	4.9E-09	2.2E-10	1.8E-11	1.0E-08
PFD _{avg} (T ₁ = 2 a)	3.8E-07	1.5E-06	2.3E-06	2.4E-06	1.6E-07	1.4E-04
PFD _{avg} (T ₁ = 5 a)	9.6E-07	3.7E-06	5.7E-06	5.9E-06	3.9E-07	2.7E-04
PFD _{avg} (T ₁ = 20 a)	3.8E-06	1.5E-05	2.3E-05	2.4E-05	1.6E-06	5.0E-04
MTTF _d (a)	2412	2406	2412	2412	321699	164
HFT	0	1	0	1	1	0
Cat.	2	3	1	3	3	3
SFF (%)	99.5	97.5	96.2	96.6	99.4	99.0
DC (%)	98.7	92.9	89.6	90.7	99.0	99.0
PFH _{diag} (1/h)	-	-	-	-	-	2.61E-07
λ _{Diag_s} (1/h)	-	-	-	-	-	7.79E-08
λ _{diag_d} (1/h)	-	-	-	-	-	6.74E-07

3AXD10001287182 D, 3AXD10000024229 N

■ FSO safety calculations guide (without PROFIsafe)


STO, SS1-t, SSE-t and SSE with immediate STO

Block diagram for single channel solution:



2	FSO Logic
3	FSO STO output
4	FSO Digital output (optional)
5	Drive STO

Block diagram for dual channel solution:




STO and other stopping functions with FSO include FSO subsystems Digital input, Logic, possible Digital output and STO output, and Drive STO. In the figure above, safety function is implemented with 1-channel and non-pulsed signals. Figure 2 shows a 2-channel solution. Signals may be either pulsed or non-pulsed. However, all choices have an effect on safety values. Block diagrams are equal to SS1-t, SSE-t and SSE with immediate STO functions. Same approach for the logic subsystems applies in all safety functions below.

Note: ABB's safety data component libraries do not contain any subsystems for external (non-ABB) components.


Note: All safety functions in FSO can be activated either through safety IOs or through PROFIsafe. In case PROFIsafe is used, safety IOs are optional.

Encoderless SLS or SS1-r




Safely-limited speed (SLS) without encoder includes the following subsystems: FSO encoderless speed measurement, FSO Digital input, FSO Logic, FSO STO output, FSO digital output (optional), and Drive STO. Block diagram is equal to SS1-r function.

POUS




Prevention of unexpected start-up (POUS) includes the following subsystems: FSO Digital input, FSO Logic, FSO STO output, FSO Digital output (optional), and Drive STO.

SMS without encoder



Safe maximum speed (SMS) includes the following subsystems: FSO encoderless speed measurement, FSO Logic, FSO STO output, and Drive STO.

SBC




Safe brake control (SBC) includes the following subsystems: FSO Logic, FSO STO output, FSO Digital output, Contactor 1 and 2 (can be provided by ABB), and Drive STO.

Note: SBC is used together with other safety functions, and a triggering subsystem must be included in the calculation.

■ **FSO safety calculations guide (with PROFIsafe)**

Safety functions can also be implemented with PROFIsafe over PROFINET connectivity. FSO has own subsystem for PROFIsafe communication which is used together with other FSO internal subsystems.



PROFIsafe can replace digital inputs and/or digital outputs of the FSO. For example, it is possible to use PROFIsafe input and FSO output in the same configuration.

It is also possible to read and activate FSO I/O's through the PROFIsafe connection. In this case, the safety block diagram must contain the FSO input and/or output subsystems used in the safety calculation.

It is also possible that the customer's PLC uses safe speed information from the drive to operate a safety function. In this case, the FSO encoderless speed measurement must be added to the calculation.

■ **Relevant failure modes**

The following failure modes related to the outputs of the FSO-12 have been considered in the design:

- STO output
- PROFIsafe
- Digital outputs.

The relevant dangerous failure mode due to internal random hardware failure of FSO-12 are that these outputs are not activated on command.

The probabilities of the dangerous undetected failures of the safety functions are given in the basic safety table.


FSO-12 implements several diagnostics to detect internal random hardware failures. The diagnostics cycle time for each of the channels is 10 hours or less. The diagnostics of each channel is separate and independent of the other channel.

The relevant failure mode of the diagnostics is that, due to a random hardware fault in the diagnostic system, the fault reaction is not performed while a detectable fault in the safety function is present.


■ Response times

Safety function response time	Maximum response time of the FB module (FPNO or FENA), FSO and drive combination is 100 ms. Note: Mute time usage increases the response time.
FSO-12 response time <ul style="list-style-type: none">from an FSO input to an FSO digital output activation	Maximum 35 ms
Cascade response time <ul style="list-style-type: none">from FSO's STO activation to the cascade output activationfrom the cascade input to the cascade output activation	Maximum 35 ms Maximum 35 ms If the STO is cascaded, safety function response time for the cascaded units is $(n-1) \times 35 \text{ ms} + 100 \text{ ms}$, where n is the number of cascaded FSO modules.
PROFIsafe <ul style="list-style-type: none">Worst-case delay time (WCDT)Device acknowledgement time (DAT)	54 ms (FSO and FB module combination) 54 ms

Example 1 - Response times



Example 2 - Response times for cascading



Ordering information

Ordering codes for related kits:

FSO-12 kit	3AXD50000016771
FSO-21 kit	3AXD50000023987
FSE-31 kit	3AXD50000023272
FENA-21	3AUA0000089109
FPNO-21	3AXD50000192779

Option codes (plus codes) when ordered together with drive:

FSO-12	+Q973
FSO-21	+Q972
FSE-31 kit	+L521
FENA-21	+K475

FPNO-21	+K492
---------	-------

Related standards and directives

Referenced standards are listed in the table below.


Standard	Name
EN 60204-1:2018 IEC 60204-1:2021	Safety of machinery – Electrical equipment of machines – Part 1: General requirements
IEC 61508 Parts 1-3, Ed. 2.0:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems
IEC 61800-5-2:2016 EN 61800-5-2:2007	Adjustable speed electrical power drive systems – Part 5-2: Safety requirements – Functional
IEC 62061:2021 +AMD1:2024 EN IEC 62061:2021	Safety of machinery – Functional safety of safety-related control systems
EN ISO 12100:2010	Safety of machinery – General principles for design – Risk assessment and risk reduction
EN ISO 13849-1:2023	Safety of machinery – Safety-related parts of control systems – Part 1: General principles for design
EN ISO 13849-2:2012	Safety of machinery – Safety-related parts of control systems – Part 2: Validation
IEC 61000-6-7:2014	Electromagnetic compatibility (EMC) - Part 6-7: Generic standards - Immunity requirements for equipment intended to perform functions in a safety-related system (functional safety) in industrial locations
IEC 60533:2015	Electrical and electronic installations in ships - Electromagnetic compatibility (EMC) - Ships with a metallic hull
EN ISO 13850:2015	Safety of machinery - Emergency stop function - Principles for design
ISO 14118:2017 & EN ISO 14118:2018	Safety of machinery - Prevention of unexpected start-up
2006/42/EC	European Machinery Directive
	PROFIsafe System Description – Technology and Application. Version April 2016. Order Number 4.342.
	PROFIsafe - Profile for Safety Technology on PROFIBUS DP and PROFINET IO, V2.4
Other	Sector-specific C-type standards

17

Dimension drawings

The dimension drawings of the FSO-12 module with two different bottom plates for different drive control unit types are shown below. The dimensions are given in millimeters and [inches].







Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to abb.com/searchchannels.

Product training

For information on ABB product training, navigate to new.abb.com/service/training.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Navigate to new.abb.com/drives/manuals-feedback-form.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet at abb.com/drives/documents.



abb.com



3AXD50000015612L