


REF 542plus

Configuration Tool Manual



Contents

Copyrights	7
1. Introduction	9
1.1. This manual	9
1.2. Use of symbols	9
1.3. Intended audience	9
1.4. Product documentation	10
1.5. Document revisions	10
2. Safety information	11
3. Installation of REF 542plus Configuration Tool	13
3.1. System requirements	13
3.2. Installing the REF 542plus Configuration Tool	13
3.2.1. Installable components	13
3.2.2. Installing a new version of the REF 542plus Configuration Tool	15
3.2.3. Restart after an installation	16
3.3. Removing the REF 542plus Configuration Tool	16
3.4. Starting the REF 542plus Configuration Tool	16
3.5. Using the REF 542plus Configuration Tool	17
3.5.1. Operating Tool	18
3.5.2. First steps in creating or editing an application ..	18
3.5.3. Working with projects	18
3.5.4. Selecting the language version	20
3.5.5. Setting the PC and REF 542plus connection	20
3.5.6. Configuring REF 542plus	20
3.5.7. Creating a function chart (FUPLA)	21
3.5.7.1. Adding and moving function blocks ...	21
3.5.7.2. Adding and moving a connection	23
3.5.7.3. Starting configuration dialogs	24
3.5.7.4. Deleting objects in the function chart	26
3.5.7.5. Checking function chart	26
3.5.7.6. Setting the LCD and display language	27
3.5.8. Uploading/downloading configuration	27
3.5.9. Description of the Main menu items	29
3.5.9.1. File	29
3.5.9.2. Connect	31
3.5.9.3. View	35
3.5.9.4. Configure	35
3.5.9.5. Utilities	54

3.5.9.6.	Options.....	55
3.5.9.7.	Help	58
3.5.10.	Description of the Drawing menu items	59
3.5.10.1.	File	59
3.5.10.2.	Edit.....	60
3.5.10.3.	View.....	61
3.5.10.4.	Insert.....	62
3.5.10.5.	Utilities	63
3.5.10.6.	Options.....	65
3.5.10.7.	Help	65
3.5.11.	Description of the status bar	66
4.	Setting REF 542plus.....	67
4.1.	Connecting inputs and outputs	67
4.2.	General settings	68
4.2.1.	Serial Port	68
4.2.2.	TCP/IP port.....	71
4.2.3.	Global Settings.....	76
4.2.4.	Hardware	81
4.2.5.	Analog inputs	84
4.2.6.	Analog Input 20 mA	86
4.2.7.	Analog outputs 20 mA	88
4.2.8.	Single line diagram	91
4.2.8.1.	User controls of the LCD editor.....	91
4.2.8.2.	Working with the LCD editor.....	94
4.2.8.3.	Configuration dialog box for symbols	97
4.2.8.4.	Configuration dialog box for lines	99
4.2.9.	Display language	99
4.2.10.	Char maps (For operation with HMI V4).....	101
4.2.11.	LED Bars	103
4.3.	Function and configuration of the function blocks	104
4.3.1.	Control panel on the HMI control unit	104
4.3.1.1.	Indication LED	105
4.3.1.2.	Alarm LED	109
4.3.1.3.	Alarm Reset	110
4.3.1.4.	LR-Key	111
4.3.1.5.	Emergency Buttons	112
4.3.1.6.	HMI Command.....	113
4.3.1.7.	Enable/Disable.....	114
4.3.2.	Binary IO (switching objects).....	115
4.3.2.1.	Switching Object 0-1	121
4.3.2.2.	Switching Object 0-3	123
4.3.2.3.	Switching Object 1-0	126

4.3.2.4.	Switching Object 1-1	129
4.3.2.5.	Switching Object 1-2	132
4.3.2.6.	Switching Object 2-1	136
4.3.2.7.	Switching Object 2-2	139
4.3.2.8.	Switching Object 2-2 H-Bridge	150
4.3.2.9.	Switching Object 4-4 H-Bridge	159
4.3.2.10.	Module for truck (withdrawal unit)....	170
4.3.2.11.	IO-Supervision	172
4.3.3.	Digital logic 1	174
4.3.3.1.	Inverter	174
4.3.3.2.	Constant 1/Constant 0.....	175
4.3.3.3.	AND logic gate with inverting output..	175
4.3.3.4.	AND logic gate with an inverting input.....	176
4.3.3.5.	AND logic gate.....	177
4.3.3.6.	OR logic gate	178
4.3.3.7.	OR logic gate with inverting output ..	179
4.3.4.	Digital logic 2	179
4.3.4.1.	Exclusive OR logic gate	180
4.3.4.2.	Exclusive OR logic gates with inverting output	181
4.3.5.	Flip-Flops	181
4.3.5.1.	R-S Flip-Flop	182
4.3.5.2.	R-S Flip-Flop with timing input (clock)	183
4.3.5.3.	J-K Flip-Flop.....	184
4.3.5.4.	D Flip-Flop	185
4.3.5.5.	T Flip-Flop.....	186
4.3.5.6.	Monoflop retriggerable.....	187
4.3.5.7.	Monoflop non-retriggerable.....	188
4.3.5.8.	Drop Delay/Rise Delay (slope delay).....	189
4.3.5.9.	Counter	191
4.3.5.10.	Pulse generator.....	193
4.3.5.11.	Digital Store object	195
4.3.6.	Analog Objects.....	196
4.3.6.1.	Analog Threshold	196
4.3.6.2.	Measurement supervision NPS and PPS	199
4.3.6.3.	Analog Input 20mA object.....	204
4.3.6.4.	Energy management.....	208
4.3.6.5.	Energy Counter.....	209

4.3.6.6.	Energy Pulse Output.....	211
4.3.6.7.	Power Factor Controller.....	214
4.3.7.	Communication objects.....	223
4.3.7.1.	Binary Write.....	224
4.3.7.2.	16-Bit Write	227
4.3.7.3.	Binary Read	230
4.3.7.4.	16-Bit Read	233
4.3.7.5.	Direct Read-Write	236
4.3.7.6.	Event Generator.....	238
4.3.7.7.	Bay Reserve.....	241
4.3.7.8.	Switch Authority Allocation	245
4.3.8.	CAN Communication Objects.....	248
4.3.9.	Miscellaneous objects.....	248
4.3.9.1.	Parameter Set Selector	248
4.3.9.2.	Operating hours counter	252
5.	Terminology	255
6.	Abbreviations	257

Copyrights

The information in this document is subject to change without notice and should not be construed as a commitment by ABB Oy. ABB Oy assumes no responsibility for any errors that may appear in this document.

In no event shall ABB Oy be liable for direct, indirect, special, incidental or consequential damages of any nature or kind arising from the use of this document, nor shall ABB Oy be liable for incidental or consequential damages arising from the use of any software or hardware described in this document.

This document and parts thereof must not be reproduced or copied without written permission from ABB Oy, and the contents thereof must not be imparted to a third party nor used for any unauthorized purpose.

The software or hardware described in this document is furnished under a license and may be used, copied or disclosed only in accordance with the terms of such license.

© Copyright 2016 ABB Oy

All rights reserved.

Trademarks

ABB is a registered trademark of ABB Group. All other brand or product names mentioned in this document may be trademarks or registered trademarks of their respective holders.

Guarantee

Please inquire about the terms of guarantee from your nearest ABB representative.

1. Introduction

1.1. This manual

This manual describes how to use the REF 542plus Configuration Tool program.

1.2. Use of symbols

This publication includes the following icons that point out safety-related conditions or other important information:



The electrical warning icon indicates the presence of a hazard which could result in electrical shock.



The warning icon indicates the presence of a hazard which could result in personal injury.



The caution icon indicates important information or warning related to the concept discussed in the text. It might indicate the presence of a hazard which could result in corruption of software or damage to equipment or property.



The information icon alerts the reader to relevant facts and conditions.

It should be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process performance leading to information or property loss. Therefore, comply fully with all notices.

1.3. Intended audience

This manual is intended for engineers to support configuration and engineering of systems and/or applications.

1.4. Product documentation

Name of the Manual	Document ID
Real Time Clock Synchronization, IRIG-B Input Time Master	1MRS755870
Product Guide	1MRS756269
Configuration Manual	1MRS755871
iButton Programmer User Manual	1MRS755863
Manual Part 3, Installation and Commission	1 VTA100004
Manual Part 4, Communication	1VTA100005
Motor Protection with ATEX Certification, Manual	1MRS755862
SCL Tool Configuration Manual	1MRS756342
Protection Manual	1MRS755860
Technical Reference Manual	1MRS755859
Technical Reference Modbus RTU	1MRS755868
Web Manual, Installation	1MRS755865
Web Manual, Operation	1MRS755864
IEC 61850 PIXIT	1MRS756360
IEC 61850 Conformance Statement	1MRS756361
IEC61850 TISSUES Conformance Statement	1MRS756362
Lifecycle Service Tool	1MRS756725

1.5. Document revisions

Version	IED Revision number	Date	History
1VTA100003-Rev.2, en		22.10.2002	First release
1VTA100172-Rev 3, en		22.11.2003	Updated to version 4D02
A		28.02.2006	Document updated - language - layout
B	2.5	30.09.2006	Updated to software version V4E02e.
C	2.5	31.05.2007	Updated to software version V4E04x.
D	2.6	19.12.2008	Updated to software version V4F06x
E	3.0	10.02.2010	Updated to software version V4F08x
F	3.0	27.06.2016	Content updated

Applicability

This manual is applicable to REF 542plus Release 3.0, software version V4F08x.

2. Safety information



Dangerous voltages can occur on the connectors, even though the auxiliary voltage has been disconnected.

Non-observance can result in death, personal injury or substantial property damage.

Only a competent electrician is allowed to carry out the electrical installation.

National and local electrical safety regulations must always be followed.

The frame of the device has to be carefully earthed.



The device contains components which are sensitive to electrostatic discharge. Unnecessary touching of electronic components must therefore be avoided.

3. Installation of REF 542plus Configuration Tool

3.1. System requirements

- IBM compatible personal computer
- Intel Pentium processor
- Minimum 128 MB RAM
- CD-ROM drive or DVD-ROM drive
- Free hard drive 50 MB
- Microsoft Windows NT 4.0 Service Pack 6, Windows 2000, Windows XP, Windows Vista
- Mouse

3.2. Installing the REF 542plus Configuration Tool



There are two different versions of the REF 542plus Configuration Tool. The REF 542plus Configuration Tool can only be used by ABB switchgear companies. The use of the Operating Tool has no restrictions. The REF 542plus Configuration Tool allows inserting protection function blocks. The Protection function menu is disabled in the Operating Tool.

The installation software automatically selects the language used to guide the user through the installation process based on the User Locale Settings of the Windows system. The following languages are available:


- English (US)
- German
- Italian
- Czech
- Slovak
- In all the other cases English is the default

Follow the instructions and observe the information provided by the installation program. Every step in the installation process can be reversed or the entire program can be cancelled.

To start the installation software, start the set up.exe program on the disk for example by double-clicking the left mouse button when the cursor is over the file.

3.2.1. Installable components

In the setup wizard it is possible to choose between two setup types: complete and custom.




A051663

Fig. 3.2.1.-1 Choosing the setup type

The complete setup installs automatically the following components:

- The REF 542plus Configuration Tool (mandatory) which contains:
 - Executable and language libraries
 - Latin and Cyrillic fonts for the HMI
 - English and Russian
 - String files (STC)
 - The Analog Input Boards definition
 - The Web Server configuration file
- An example of drawing (optional) and an empty drawing into the Drawings folder
- The character map bitmaps (for Latin and Cyrillic ASCII chars). These bitmaps can be used to customize the characters downloaded to the HMI.


The Custom Setup allows the user to select/deselect the optional components.



A051664

Fig. 3.2.1.-2 Custom Setup

Select/deselect a program feature by clicking on the component in the Custom Setup window.



A051665

Fig. 3.2.1.-3 Selecting and deselecting features in the Custom Setup window



Complete Setup is recommended.

3.2.2.

Installing a new version of the REF 542plus Configuration Tool

A new installation does not overwrite older configuration tools. All older configuration tools not used anymore should be uninstalled from the system.



First uninstall old configuration tools if you intend to reuse the target directory or group names of an older installation.

3.2.3. Restart after an installation

Depending on the update status of your Windows libraries, the installation software can ask for a computer restart at the end of the process. Restarting is recommended.

3.3. Removing the REF 542plus Configuration Tool

The installed REF 542plus Configuration Tool is compliant with MSI (Microsoft Installer) technology. Thus it is always possible to repair or remove the tool from the computer.

To remove the REF 542plus Configuration Tool:

1. Go to the Start Menu and choose Settings.
2. Go to the Control Panel and select Add/Remove Programs.
3. Mark the REF 542plus Configuration Tool you would like to uninstall and click **Remove**.
4. Follow the instructions.

3.4. Starting the REF 542plus Configuration Tool

After the installation has been completed as described in Section 3.2. Installing the REF 542plus Configuration Tool, the REF 542plus Configuration Tool can be started as follows:


The program groups are accessed through the **Start** button. By default the program group with the REF 542plus configuration software is in:

`<programs folder>\ABB\REF 542plus\...`

For example:

`C:\Program Files\ABB\REF 542plus\ConfToolV4E06x\`

This folder structure is not mandatory. Usually the common “ABB” folder is followed by the product name (REF 542plus). Leave the version of the tool in the folder name so that it would be easier to handle side-by-side installation of different configuration tools on the same computer.



A080362

Fig. 3.4.-1 Main view of the IED Configuration Tool

The menu is described in Section 3.5.9. Description of the Main menu items. The status bar of the main view is described in Section 3.5.11. Description of the status bar.



Pay attention to the version in the main view of the REF 542plus Configuration Tool or in the About dialog box (available in the Help menu). Ensure it is the latest available version and compatible with the firmware version of the REF 542plus to be configured.

3.5.

Using the REF 542plus Configuration Tool

The following sections provide basic information on using the REF 542plus Configuration Tool. The most important activities in creating or editing an application are described.

Section 3.5.9. Description of the Main menu items explains the menu items in the main menu and the character menu in the sequence in which they are displayed in the REF 542plus Configuration Tool.



The limitations of the operating tool that are described in this section are not explained any further in the configuration tool manual.

3.5.1. Operating Tool

The Operating Tool has the following limitations:

Additional protection functions cannot be added to the application. If a protection function in the application is deleted, it cannot be added again later.

3.5.2. First steps in creating or editing an application

All the functions of the REF 542plus Configuration Tool are not described in the following sections. All menu items in the REF 542plus Configuration Tool are described in Section 3.5.9. Description of the Main menu items.

The sequence of the following sections corresponds to the same sequence of steps required when defining a new application. When an existing application is opened, all basic settings are of course already specified. The function chart is also complete. However, the procedure for editing an application is the same as for creating a new one.

3.5.3. Working with projects

The set of files that belongs to an application in connection with the REF 542plus Configuration Tool is referred to a project. Projects can be created, opened and saved in the REF 542plus Configuration Tool. After starting the REF 542plus Configuration Tool, a new project by the name new.ref is created.



When saving a new project for the first time, always use **Main Menu > File > Save as** F7. Otherwise the name "new.ref" is used.

Table 3.5.3.-1 describes the set of files associated with a project. Not all of them are created in every application. In addition, the table shows when the files are created or updated. If the files need to be created, the corresponding menu Generate Report File must be activated.

Table 3.5.3.-1 File descriptions

File	Contents	Created	Updated
*.ref	File comprising: - Drawing - Parameter - HMI LCD configuration - LCD texts All other files can be recreated from this file, with the exception of the fault record files and of the SCL file (WEBREF configuration)	When saving	When saving
*.bak	Application back-up file	When opening	When opening
*.doc	- Device configuration - Rated values of the analog inputs - Configured protection functions with setting values	When printing or generating reports	When printing or generating reports

File	Contents	Created	Updated
*.wir	All connections in use are counted, the connection number and the associated text is saved. The object number sorts the connections to which they are connected and by the number of the connector pin. Also the object type to which the connection is linked is written to this file.	When printing or generating reports	When printing or generating reports
*.lst	All events generated by the application are listed here.	When printing or generating reports	When printing or generating reports
*.can	CAN related information (I/O blocks, addresses, and so on)	When printing or generating reports	When printing or generating reports
*.lcu	The mimic diagram configuration of the current application.	When exporting a mimic diagram	When exporting a mimic diagram
*.svg	The mimic diagram configuration of the current application in Standard Vector Graphic format.	When generating the SVG file if the Web interface is enabled	When generating the SVG file if the Web interface is enabled
*.ri1	The setting parameter set 1 of the distance protection. The Omicron test set uses this file for automatic testing.	When saving an application with distance protection	When saving an application with distance protection
*.ri2	The setting parameter set 2 of the distance protection. The Omicron test set uses this file for automatic testing.	When saving an application with distance protection	When saving an application with distance protection
*.rca	XML file contains the SPA registers of the objects which are applied in the specific configuration and used as input by the Modbus Suite Tool and the SCL Tool for IEC 61850.	When generating the SPA address file in the main menu	When generating the same menu again
*.rce	The default events for each FUPLA object based on the 61850 data model	Provided with the application	When clicking Save default in Event page of each FUPLA object
*.rcm	The setting parameter of the communication described in the ascii-file	When saving the file generated in the communication menu	
*.cfg	Configuration file for the fault recorder module.	When exporting a fault record	
*.dat	Fault record file with the recorded data.	When exporting a fault record	

Only files with the names *.ref can be opened directly in the REF 542plus Configuration Tool.

3.5.4. Selecting the language version

Select the language of the menus, dialog boxes and messages of the configuration software in **Main Menu > Options > Language > [English, German, Italian, Czech]**. The setting takes effect immediately and it is also kept after closing the software.

3.5.5. Setting the PC and REF 542plus connection

To download the application from the PC to REF 542plus or to upload an application or other data from the REF 542plus, the connection must be established first. To properly configure the connection port, open the dialog box in **Main Menu > Connect > Port Configuration**.

Serial connection

A serial/optical cable is needed. One end is plugged in to the optical interface of the HMI and the other end is plugged in to the PC serial RS-232 interface. Ensure that the parameters of the dialog box "Serial Interface" in the configuration software are the same as the parameters for the serial interface configured in the operating system.

Ensure that the slave address of the dialog box "Serial Interface..." in the configuration software is the same as the slave address of the connected base unit. If not, the communication between the PC and REF 542plus cannot be established.

TCP/IP connection

A standard Ethernet cable is needed. One end is plugged in to the Ethernet interface of the device and the other end is plugged in to the PC Ethernet interface. Set the IP address of the REF 542plus device and ensure that the subnet mask of the PC Ethernet Adapter is the same as that of the REF 542plus device.



The TCP/IP settings of REF 542plus can be read from the Communication dialog box of the Configuration Tool under **MAINBOARD > TCP/IP properties**.

3.5.6. Configuring REF 542plus

To be able to configure the application, the hardware module installed in the REF 542plus must be entered into the configuration software. Enter the hardware module to the REF 542plus Configuration Tool in **Main Menu > Configure > Global Settings and in Main Menu > Configure > Hardware**.

The communication with the station control system can be configured by selecting **Main Menu > Communication**. In this submenu you can define the properties for the communication via the Ethernet interface on the mainboard of the REF 542plus.

The properties can be defined for the communication using TCP/IP, for example MODBUS TCP/IP, WEBSERVER or GSM/SMS, can be defined accordingly. Besides that, the communication setting using the optional communication module can also be selected. The setting is for example SPA, Modbus RTU, ABB LON or IEC 60870-5-103 can also be selected. The communication setting can then be saved to a file. Downloading the communication parameter can later be performed separately from the downloading of the FUPLA.

The analog inputs and outputs should be defined before making the application settings in **Main Menu > Configure > Terminals > Analog Inputs** and if necessary in **Main Menu > Configure > Terminals > Analog Outputs**. If an analog output board is not used, this menu item cannot be selected.

The analog inputs 0/4-20 mA can be defined if necessary in **Main Menu > Configure > Terminals > Analog Inputs 4-20 mA**. If an analog input 4-20 mA board is not used, this menu item cannot be selected.

The menu **Main Menu > Component** is prepared for future use. It has currently no functionality.

It is recommended to define the display language (**Main Menu > Configure > HMI > Display Language**) before continuing the configuration. This setting influences the translation to REF 542plus fonts of strings on the configuration software in case of non-Latin characters (for example Cyrillic, Chinese, Hebrew, and so on).

3.5.7. Creating a function chart (FUPLA)

To create the function chart, start the function chart editor in **Main Menu > Configure > Drawing**.



Before the function chart editor can be started, make the settings for a new application in **Main Menu/Configure/Global Settings** and in **Main Menu > Configure > Hardware**.

The first page of the application is displayed. To make an application more manageable, it can be distributed over several pages. One page is larger than the PC screen. All areas of the current page can be viewed by using the scroll bars to the right and at the bottom of the drawing editor window. The arrow keys (arrow keys) on the keyboard can also be used for this.

3.5.7.1. Adding and moving function blocks

Function blocks can be added and moved in the working mode.

Add a function block

Select **Drawing Menu > Insert**. A submenu with various function groups is displayed. Selecting a function group brings up another submenu listing the individual function blocks. The selected function block is placed on the top left of the page.

Example: Select **Drawing Menu > Insert > Control Panel > Indication LED** to select the indication LED function block.

Move a function block

To move, hold the left mouse button down when the cursor is on the function block and drag it with the mouse.

Restrictions

Note that not all function blocks can be combined together.

Restrictions for function blocks and connections are listed in Table 3.5.7.1.-1.

Table 3.5.7.1.-1 Restrictions in the FUPLA

Function block	Restrictions
Protection function	Max. 24 protection functions Max. 250 protection parameters 100% DSP load
Fault recorder	Max. 1 fault recorder and Min. 1 configured protection function
Digital store object	Max. 1
Energy counter	Max. 15
Switching object	Max. 62
Analog threshold objects	Max. 10
Analog Input 0-20 mA object	Max. 48
Direct read write object	Max. 99
Net number	Max. 512
Wire	Max. 1000
Signaling LED	Max. 32 on 4 sides of 8 LED's each
Number of pages	Max. 99
HMI commands	Max. 32
Control objects visible on HMI	Max. 48

Determining the cycle time



Once a new application has been created and loaded into the REF 542plus device, its cycle time must be checked. The cyclic time is displayed on the HMI menu Service/Statistics.



The application cycle time must be less than 30 ms to ensure proper functioning of REF 542plus. Longer times can result in poor and dangerous performances like missing events and binary I/O changes.

3.5.7.2.

Adding and moving a connection

The function blocks can be linked to each other in the drawing mode. By positioning the cursor over a connection point on a function block or at the beginning or at the end point of a connection, the cursor changes to a shape of a soldering iron.

A total of 512 connections can be added. There are 502 numbers available for connections (11 ... 512). Connection numbers 0 ... 10 are for internal use.

Add a connection

When the soldering iron is displayed, hold the right mouse button down and drag the mouse to make a connection. The connection ends when the mouse button is released.

The terminals of two function blocks can be connected in this way. The connection can also end in the FUPLA without connecting to a terminal. The connection number is automatically 1 or 2 in this case to indicate that it does not connect two function blocks. Use the configuration dialog box to assign a previously used connection number to the connection. Connections with the same connection number can be linked even if they do not contact each other.

Connections run at right angles or in a straight line, therefore also diagonally, depending on their setting. The relevant setting is made in **Drawing Menu > View > Wires > Right-angled** or **Drawing Menu > View > Wires > Straight**.

Move a connection

When the soldering iron is displayed, hold the left mouse button down and drag the mouse to move a connection point. When the mouse button is released, the connection point remains at this position.



When a connection point is dragged or moved from one function block terminal to another, ensure that the connection is properly positioned at the function block.

Check connections after a move

There are two options how to check the connections:

- Move the cursor over the connection wire. Double-click the left mouse button to start the configuration dialog box for the wire. The terminal information area shows the number of the wire that is properly terminated. The numbers 11 and 12 indicate that there is still no connection.

OR

- Move the function block in the FUPLA. If the connections are moved with it, the connection is correct.

3.5.7.3.


Starting configuration dialogs

A dialog box can be opened for all function blocks and connections by moving the cursor over the function block or the wire and double-clicking the left mouse button. The configuration dialog box is displayed.

Configuration dialog box function block

The configuration dialog box for a connection enables the function block to be configured and/or provides information on the terminated connections.

Configuration dialog box for a connection



A051667

Fig. 3.5.7.3.-1 Configuration dialog box for a connection

Net number

Enter the wire connection number in the Net number text box. The currently assigned connection number is displayed, a 1 or a 2. Only numbers 1 or 2 are displayed when the connection ends with a terminal point in the FUPLA. To find the currently assigned connection number, the configuration software searches the connection numbers from 11 upwards for a free connection.

The connection number is also displayed in the function chart beside the connection.

Setting range: 11 ... 512 (steps: 1)
Default: currently assigned connection, 1 or 2

Next unused net number

The next free connection is assigned in Next unused net number. The configuration software searches the connection numbers from 11 upwards for a free connection.

Maximum number of wires

The Maximum number of wires information field displays the maximum possible number of connections in the current function chart. A total of 1000 connections can be used. There are 502 connection numbers available.

Used

The Used information field displays how many connections are already set up in the function chart.

Comment

Enter a comment, a name, for the connection in the Comment text box. The name is also displayed in the function chart beside the connection. This name is assigned to all connections with the same connection number.

Setting range: 0 ... 20 characters of the standard character set
Default: [Empty]

Choose next free

Click on the **Choose next free** button to assign the next free connection number to the connection. The dialog box is then closed, and the connection has the corresponding number.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

3.5.7.4.**Deleting objects in the function chart**

Deleting a function block:

1. Move the cursor over the function block to be deleted.
2. Double-click the right mouse button.
3. A confirmation query is displayed.
4. Click the **OK** button to delete the function block or **Cancel** to keep the function block.

Deleting a connection:

1. Move the cursor over the connection which is to be deleted.
2. Double-click the right mouse button.
3. A confirmation query is displayed.
4. Click the **OK** button to delete the connection or **Cancel** to keep the connection.

Deleting the current page:

1. Select **Draw Mode > Edit > Delete Page**.
2. A confirmation query is displayed.
3. Click the **OK** button to delete the page or **Cancel** to keep the page.

Deleting all connections in the application:

1. Select **Draw Mode > Edit > Delete All > Wires**.
2. A confirmation query is displayed.
3. Click the **OK** button to delete the connections or **Cancel** to keep the connections.

Deleting all pages in the application:

1. Select **Draw Mode > Edit > Delete All > Pages**.
2. A confirmation query is displayed.
3. Click the **OK** button to delete the pages or **Cancel** to keep the pages.

3.5.7.5.**Checking function chart**

The function chart can be checked both in draw mode and in connection mode. Press the F9 key on the keyboard or select **Drawing Menu > Utilities > Check Drawing F9** or **Main Menu > Utilities > Check Drawing F9**.

The checking routine of the configuration software runs the following tests:

- Binary inputs and outputs: checks availability of the numbers of the binary inputs and outputs used in the application. The availability depends on the number and type of binary input and output boards in use.
- Device configuration: checks availability of a device configuration. Checks if the configuration dialog box in **Main Menu > Configure > Hardware** has been processed.
- Function blocks: all function blocks must be linked to at least one connection.

- DSP load: the DSP load (load on the protection and measuring unit) can be maximum 100%. Maximum 250 protection parameters and maximum 24 protection functions can be used.
- Connections: the number of connections must not exceed 512.
- Double connections: connections with the same number may only be connected to one function block output.
- Calculation of power: the configuration of the analog inputs must match the type of power calculation.
- Switching objects: a maximum of 62 switching objects may be configured. Every switching object must have its own Field bus address and binary output represented by the switching object must be physically present.
- Direct write-read command: a maximum of 100 function blocks of this type are permitted.

3.5.7.6. Setting the LCD and display language

When the application has been set up, the mimic diagram for the LCD can be configured and the language in which the messages are displayed on the LCD selected in **Main Menu > Configure > Display and in Main Menu > Configure > Display Language**.

3.5.8. Uploading/downloading configuration

Once the configuration is completed, the next action is usually to download it to the device. The REF 542plus Configuration Tool is able to perform such action if the following conditions are valid:

The communication between REF 542plus HMI unit and the REF 542plus Configuration Tool has been established and it is working. To check the connection, check the version of the REF 542plus device (refer to Section 3.5.9.2. Connect). The following problems can happen:

1. General communication error is that the REF 542plus device is not available.
The problems and the possible solutions could be:

Table 3.5.8.-1 Problems and solutions

Problem	Solution
REF 542plus base unit is not turned on.	Connect the right power cable to the power supply.
REF 542plus HMI is not turned on.	Connect the right power cable to the power port of the HMI.
REF 542plus HMI is not connected to the REF 542plus base unit.	Connect it with the serial cable the right ports.
REF 542plus HMI is not ready.	It is ready when waiting a configuration or when a configuration has been already downloaded.
Broken cable	Replace the cable.
Coupling of optical connector to the HMI is not perfect.	Re-insert the connector.
PC COM port malfunction	Change the COM port or the PC.

Problem	Solution
COM settings on the REF 542plus Configuration tool do not match the current connection.	Change the COM settings. Refer to Section 3.5.5. Setting the PC and REF 542plus connection and Section 4.2.1. Serial Port. In particular, pay attention to: baud rate, data bits and base unit slave address.
PC COM port is already used by another software.	Close the application (for example TeraTerm), which is using the COM port, and set again the COM settings in the REF 542plus Configuration Tool.

2. Not all the version information is published by the REF 542plus device. If the mandatory information is not published then the download command is not allowed. A REF 542plus V4E02x version should publish the following information:
 - REF 542plus software/firmware versions are mandatory. Whatever the version is, REF 542plus has to publish them.
 - Configuration information is optional. Available partially in version older than V4D02x. Remember that sometimes the information can be also a blank space and it can be a valid value.
 - Char map information is mandatory. Available only in V4D02x REF 542plus versions. Needed only for REF 542plus V4E02 with HMI V4, which is the HMI version until now. For the new version HMI V5 the Unicode fonts are mandatory for displaying international characters.
3. The version of the REF 542plus in general must be compliant with the REF 542plus Configuration Tool. For example, if the device is a V4E02x, then the configuration tool should also be of the same version. For more detailed information, contact your local ABB representative.
4. The Char Map for HMI V4 or the Unicode fonts for HMI V5 in the REF 542plus device must match with the String file (STC) active in the configuration to be downloaded. For example, if the device contains the Latin char map, then only configurations with String file using this char map are downloadable. The REF 542plus device with HMI V4 is provided by default with a Latin char map, thus if another one is needed, then download first the new char map (for example Cyrillic, refer to Section 4.2.10. Char maps (For operation with HMI V4)).



From the version V4E04x onwards, the application of the HMI V4 is not recommended anymore.

The configuration of REF 542plus is always uploadable from the device. The REF 542plus Configuration Tool is able to perform such action, if the following conditions are valid:

Communication between REF 542plus HMI unit and REF 542plus Configuration Tool is established and working. To check the connection, check the version of the REF 542plus device (refer to Section 3.5.9.2. Connect). Follow the troubleshooting procedure of the download above.

The version of the REF 542plus device must be at least V4B.0x. During the upload, the configuration information is translated to the V4E02x version.

3.5.9. Description of the Main menu items

The menu items of the configuration software are grouped into main and drawing menus. The following sections provide a description of main menu items.

The main menu is displayed after starting the configuration software. The drawing menu items are described in Section 3.5.10. Description of the Drawing menu items

3.5.9.1. File

New

A new project under the name new.ref is created. Save it immediately under a different name, because this name is always reserved for new projects.

Open ... F2

A dialog box for opening a file is displayed. The default file ending for the file format is ref. If necessary, browse through the disk and directory structure to open a configuration file.

The dialog box for opening the file is also displayed when the F2 key on the PC keyboard is pressed.

After the project has been opened, a drawing check is run. Any error messages must first be acknowledged before the project can be edited.

Save F6

The open application file is saved. If a new application file has been created, the file new.ref is saved in the default work directory of the configuration software. In case of a new file saved for the first time, use Save as.

An application can also be saved by pressing the F6 key on the PC keyboard.



Before saving, the configuration software runs a check of the application. Any messages that are displayed must be acknowledged before saving.

Save as F7

A dialog box for saving a file is displayed. The file can be given any wanted name and location. The default file ending for the file format is ref.

The dialog box can also be started by pressing the F6 key on the PC keyboard.



The configuration software runs a check of the application before saving. Any messages that are displayed must be acknowledged before saving.

Send E-Mail

Calls the default e-mail editor and inserts the currently open *.ref-file of the configuration software as attachment.

Print

A Print dialog box is displayed. Its appearance depends on the operating system and the installed printer. Additional inputs regarding the print process can be made in the dialog box.

Print > Drawing

The function chart is printed out, if necessary on several pages.

Print > Parameters

A file is printed with a list of all the parameters in the application sorted by their origin. For example, this includes the device settings and also the parameter sets for the protection functions.

Print > Eventlist

A file that lists all possible events that could be generated by the application is printed out. They are sorted by the function block that generated them.

Print > Connections

The connection numbers and the associated comments are printed out in a list form.

Print > CAN Settings

All the configured CAN addresses are printed. Not applicable for the time being.

Print Setup

When the configuration program is installed, the default printer is activated. If required, another printer can be directly selected and defined as the default printer.

Print Preview

Print Preview displays the preview of the drawing.

MRU (Most Recently Used files)

The four most recently used configuration files.

Exit Application

Ends the session of the configuration software.

3.5.9.2.

Connect



To be able to use this menu, the REF 542plus device must be connected to a PC.

Port configuration

Starts the configuration dialog box for the connection from the PC to REF 542plus and selects the option Serial Port or TCP/IP Port.

Serial Port

Starts the configuration dialog box for the connection from the PC to REF 542plus via the serial port. The baud rate is to be set 9600 for former release 1.0 (version V4C01x), 19200 for release 2.0 (version V4D02x) or for release 2.5 using the existing HMI V4 and 115200 for release 2.5 using the new HMI V5 or connect it directly to the base unit by zero modem cable.

TCP/IP Port

Sets the IP address of the REF 542plus device and ensures that the subnet mask of the PC Ethernet adapter is the same as the one of the REF 542plus device.



The TCP/IP settings of REF 542plus can be read from the Communication dialog box of the Configuration tool in the section **MAINBOARD > TCP/IP properties**.

Send Configuration

Sends or downloads the data from the opened application in the PC to REF 542plus.

Load Configuration

Loads or uploads the application currently in REF 542plus from the device to the PC.

Send Mainboard Software

Sends or downloads the base software of the Mainboard.

Send COM Board Software

Sends or downloads the base software of the communication board (only for IEC103 or LON).

Read Fault recorder

Loads (or uploads) the fault record data saved in REF 542plus into the PC when the New Data button is clicked in the dialog box.

Input Status

Loads (or uploads) the current status of the binary inputs of the first two input/output boards of REF 542plus when the New Data button is clicked in the dialog box. The data are marked with the current PC system date and time and can be saved and printed.

Output Status

Loads (or uploads) the current status of the binary outputs of the first two input/output boards of REF 542plus when the New Data button is clicked in the dialog box. The data is marked with the current PC system date and time and can be saved and printed.

Measurement

Loads (or uploads) the current status of the operational measured values from REF 542plus. These are certain values that can also be displayed in the LCD screen above the mimic diagram.

The continuous measured value transmission to the PC can be configured in the operational measured values dialog box. The operational measured values and, if wanted, the values from the binary inputs and outputs, are then regularly transmitted from REF 542plus to the PC.

The data is marked with the current PC system date and time and can be saved and printed.

CB Monitoring

Displays the dialog that enables the CB Monitoring data reading to:


- upload data from the connected device
- reset data in the connected device
- save uploaded data to a recording file (text format)
- upload data from a recorded file

Send Lifecycle data ...

Requests the Lifecycle composition file from the device and sends it automatically to the Lifecycle Service Tool.

Site information

Displays the dialog for customer site information stored into REF542plus unit and allows updating it.



The image shows a Windows-style dialog box titled "Site Address Data". Inside the dialog, there is a message: "Please validate the following Site Address data." Below this message is a form with several input fields. The fields are labeled on the left and have corresponding input boxes on the right. The labels and their values are: "Customer name" with "The Customer Name", "Street" with "The Street", "House number" with "12345", "Zip" with "12345", "City" with "The City", "State" with "The State", and "Country" with a dropdown menu showing "Switzerland". At the bottom of the dialog, there are two buttons: "OK" and "Cancel".


Field Label	Field Value
Customer name	The Customer Name
Street	The Street
House number	12345
Zip	12345
City	The City
State	The State
Country	Switzerland

A080210

Fig. 3.5.9.2.-1 Site address data

Connect > Version


Reads the current versions of the REF 542plus micro controllers (MC) and the configuration software. The information is displayed in a dialogue box. If a connection to REF 542plus cannot be established, an error message is displayed.



A051668

Fig. 3.5.9.2.-2 Connection warning when REF 542plus is not reachable

If the REF 542plus is available, the version dialog box is displayed.



A051669

Fig. 3.5.9.2.-3 Software, FUPLA and Char Map versions dialog box

The versions are divided into three groups:

1. Software: micro controller, DSP, HMI, field bus type, analog input 20 mA, configuration software versions. The REF 542plus version must be equal to the REF 542plus Configuration Tool version in order to download a configuration. Uploading is always possible.
2. FUPLA: configuration information like file name, project name, feeder name, FUPLA date, strings file name and license key.
3. For application with the HMI V4 the Char Map is to be used: header version, char map version, char map description and code page (and char map family code page, which is a reserved parameter). The REF 542plus stored char map must be equal to the downloaded configuration STC file. For example, if the REF 542plus Configuration Tool is on English STC file, then the char map on the device must be Latin. If not, it is necessary to download first the char map into the device (refer to Section 4.2.10. Char maps (For operation with HMI V4)) and then the configuration download. For the application with the new HMI V5 the Unicode fonts must be downloaded accordingly.

3.5.9.3.

View

Toolbar

Opens the toolbar on the top side of the REF 542plus Configuration Tool.

Status Bar

Sets the status bar at the bottom of the REF 542plus Configuration Tool.

Transfer Bar

Opens the transfer bar below the toolbar.

3.5.9.4.

Configure

Global Settings

Starts a configuration dialog box in which the basic settings are made. Functions such as fault monitoring, coil monitoring and default values such as the general filter time and the device address are defined here. In addition, the system messages (events), which can be sent from the system itself to a station control system, can be configured in two other dialog boxes.



This configuration dialog box must be edited before an application can be created.

Hardware

Starts a configuration dialog box in which settings that describe the delivery variations of the REF 542plus device can be made.



This configuration dialog box must be edited before an application can be created.

Communication

This dialog box must be filled in to set the properties for the communication ports.

A080212

Fig. 3.5.9.4.-1 Dialog box for the Communication Port Properties

The left side of the box describes the properties of the Ethernet port on the mainboard and the right side the parameter for the communication using the optional communication module. The Ethernet port can be used for MODBUS TCP, SPA TCP, the embedded WEB SERVER and the connection to GSM. In addition, for time synchronization of the mainboard, the connection to SNTP (Simple Network Time Protocol) by using the Ethernet port is also provided.

The optional communication module is foreseen for the following protocols:

- SPA
- ABB LON per LAG 1.4
- IEC 60870-5-103
- MODBUS RTU
- Ethernet module for IEC 61850 and/or MODBUS TCP

The buttons in the Menu section for generating actions on the rcm file are the following:

- **Upload from file:** is used to upload a configuration (rcm file) previously saved on disk. A file pop-up dialog opens showing the folder from where to upload the file.
- **Save to file:** is used to store a configuration (rcm file) on disk. A file pop-up dialog opens showing the folder from which to download the file.
- **Upload from device:** is used to read the communication section parameters from a device.
- **Download to device:** is used to write the configuration of the communication parameters to a device.
- **Clear all settings:** is used to remove all previously configured settings.

Click **OK** to accept all the changes and close the dialog.

Click **Cancel** to discard all the changes and close the dialog.

Click **Apply** to accept all the changes and keep the dialog open.

MAINBOARD > ETHERNET PORT


If the connection to REF 542plus has been established, the MAC address can be obtained.



The MAC address is needed for the communication is not possible.

MAINBOARD > TCP/IP properties

When the TCP/IP properties have been selected, the following dialog box opens.



A060418


Fig. 3.5.9.4.-2 TCP/IP properties dialog box

The parameters for the IP address of REF 542plus, subnet mask and default gateway are crucial for the TCP/IP communication.

MAINBOARD > MODBUS TCP

For the MODBUS TCP section there are two configuration settings to be done for the client IPs on:

- Access control module enabling/disabling
- Priority pool list



A080214


Fig. 3.5.9.4.-3 MODBUS TCP properties dialog box

Access Control Module:

If you enable the security access module you have to enter a list of authorized client IPs that are the unique clients that may establish a MODBUS TCP connection (maximum 10 IPs). Connections of clients with different IPs will be refused.

If the Access Control Module is not enabled, all the clients will be accepted to establish a connection.

Access Control Module Enabled



A080216

Fig. 3.5.9.4.-4 Access control module enabled

The authorized clients can belong to priority or non-priority connection pools with the constraint that the total number of priority and non-priority connections will be 4. When you enter client IPs in the priority pool from the authorized IP address, the number of free connections will be automatically updated. In fact, the number of non-priority client connections will be defined as the number of remaining free connections (not used by the priority pool) after the priority client connection configuration.


It is also necessary to configure the maximum number of connections allowed for each IP address belonging to the priority connection pool (in the above example the IP 10.10.10.176 of priority pool has 2 available connections, while the IPs 10.10.10.172 and 10.10.10.171 belong to two non-priority connections).

Access Control Module Disabled

If the Access Control Module is disabled, all the client's IPs are accepted. The configuration or priority pool/non-priority pools' client remains the same as described above with the freedom to add any IP (it is no longer present in the list of authorized IPs). In the below example, see figure 3.5.9.4.-4, the IP 10.10.10.175 is a priority client with 1 connection and the number of free connections for non-priority pools is then equal to 3.

MAINBOARD > SNTP

The following dialog box shows the SNTP (Simple Network Time Protocol) properties




A080218

Fig. 3.5.9.4.-5 SNTP properties

MAINBOARD > SNTP > Read Info Status

The following dialog box shows the SNTP Info Status dialog. From here it is possible to receive information only once or every two seconds about configuration values and status of the SNTP client and the 4 SNTP servers.




A080220

Fig. 3.5.9.4.-6 SNTP data

MAINBOARD > SPA TCP

The following dialog box shows the SPA TCP properties. The user has to select wether to enable or not the Access Control Module. Only when enabled is it possible to insert one or more clients as authorized IPs.

The maximum number of authorized IP addresses is 10.




A080222

Fig. 3.5.9.4.-7 SPA TCP properties

MAINBOARD > WEB SERVER


The following dialog box shows the user configuration for the embedded WEB server communication.



A060420

Fig. 3.5.9.4.-8 Dialog box for the user configuration of the WEB SERVER

The following dialog box shows the user administration of new or existing users.




A060421

Fig. 3.5.9.4.-9 Dialog box for the administration of WEB SERVER users

MAINBOARD > GSM/SMS

REF 542plus can operate on its own as an SMS gateway via a GSM modem, or it can refer to another connected device via TCP/IP. Usually only one REF 542plus in a switchgear has a GSM modem, and thus all the others refer to it.




A060422

Fig. 3.5.9.4.-10 Configuration dialog box for the SMS messaging system

The type of modem to be used can be selected from the modem configuration dialog box.



The modem does not require a PIN code for the SIM card.



A060423

Fig. 3.5.9.4.-11 Configuration dialog box for the GSM modem

COM BOARD

This part of the dialog box is dedicated for the communication setting using an optional module.

COM BOARD > MODULE TYPE

Several different module types can be selected:

- SPA
- ABB LON per LAG 1.4
- IEC 60870-5-103
- MODBUS RTU (the same module can be reprogrammed for SPA)
- Ethernet module for IEC 61850 or MODBUS TCP (both protocols can be applied simultaneously).

COM BOARD > PORTS

The slave address or unit ID for the communication can be defined in the following dialog box.



A060424

Fig. 3.5.9.4.-12 Configuration dialog box for the optional communication module type

In case of the Ethernet module, the IP addresses of the two ports are not configured yet and are fixed to temporary invalid values 0.0.0.0. The configuration of valid IP addresses is needed, otherwise it is not possible to accept the changes made in the dialog or to download REF542plus of the *.rcm file. To configure the IP addresses, perform the following steps:

- Click the **Properties** button. A dialog for configuring the Ethernet card parameters opens.
- Click the **Read info status** button. A dialog displaying information status values for the Ethernet card opens.

The following Port1 and Port2 related parameters configured in the Properties dialog are displayed in the PORTS section:

- Protocol: the type of protocol loaded in the communication card.
- IP address: the IP address for the port.
- MAC Address: the MAC address for the port.

These values are displayed after you have given input in the Properties dialog. After clicking the **Properties** button, the Properties dialog opens and it is ready for data input.

A080224

Fig. 3.5.9.4.-13 Ethernet module properties dialog

The parameters that need configuring are grouped into three main sections (round circled in the Fig. 3.5.9.4.-13):

- TOPOLOGY
- TCP/IP
- TIME SYNCHRONIZATION

If you select the Single Channel topology option button, you need to select the channel number. The default value is CHANNEL 1.


After that the input data area for parameter settings of channel 1 (port 1) or channel 2 (port 2) is enabled. If required, for example for redundancy purposes, Dual Channel topology can also be used. Note that each port has to be connected to different network.



The default IP address for a completely new Ethernet module is 192.168.2.10. The related subnet mask is 255.255.255.0

A subnet mask does not work like an IP address, nor does it exist independently from the IP address. Instead, a subnet mask accompanies an IP address and the two values work together. All valid subnet masks contain two parts: the left side with all

mask bits set to '255' (the extended network portion) and the right side with all bits set to '0' (the host portion). If an invalid address for the IP address or for the subnet mask is inserted, an error message is displayed (see Fig. 3.5.9.4.-14).



A070416

Fig. 3.5.9.4.-14 Error message for wrong IP address or the related subnet mask

If the Ethernet parameters are invalid, it is not possible to accept the changes made in the dialog or to download REF 542plus of the *.rcm file. An error message is displayed, see Fig. 3.5.9.4.-15.



A070417

Fig. 3.5.9.4.-15 Error message for wrong Ethernet module configuration



If the Ethernet parameters in an existing *.ref file are already configured with communication parameters, it is strongly recommended to cross-check them by uploading the existing communication settings from the device.



It is always possible to save the *.rcm file, but the same error message appears again if the file is reused.

Use the check box in the Time Synchronization section to enable or disable the SNTP based time synchronization of the REF 542plus.

To accept the input data and close the dialog, click **OK**.

To discard any changes, click **Cancel**.

Once the configuration is completed, it is possible to start the download phase to REF 542plus.



However, if the GPS clock with IRIG-B is connected to the REF 542plus, the time is used as the time source regardless of whether this check box is checked or not.

COM BOARD > Read Info Status

If Module type is “ETHERNET,” the button **Read Info Status** displays the following dialog to read:

- GENERAL: The working status of the Ethernet board
- PROTOCOLS: For each protocol IEC61850 or MODBUS TCP it is possible to read
 - Status information
 - The number of active clients and the indication of the maximum number of allowed connections
 - Protocol configuration with the name of the configuration file.
- TCP/IP: The following information is provided for each port:
 - MAC address
 - IP address
 - Subnet mask
 - Default gateway
 - Status
- TIME SYNCHRONIZATION: Provides the CONFIGURATION value and the STATUS information regarding:
 - SNTP Client
 - SNTP Server 1
 - SNTP Server 2
 - SNTP Server 3
 - SNTP Server 4

The button **Start polling** can be used to refresh data every two seconds.

ETHERNET Board Data			
GENERAL			
Working status	Running		
PROTOCOLS			
	Status	Connect. (Active/Max)	Protocol configuration files
IEC61850	Config. ok	0 / 5	_bay_49_ptrc.cid
MODTCP	Config. ok	0 / 4	Bay_46_26_ddef.xls
TCP/IP			
	PORT 1	PORT 2	
MAC address	00-23-45-67-89-B5	00-23-45-67-89-B6	
IP address	192.168.2.23	192.168.2.23	
Subnet mask	255.255.255.0	255.255.255.0	
Default gateway	0.0.0.0	0.0.0.0	
Status	Configured - Connected	Not Config. - Disconnected	
TIME SYNCHRONIZATION			
	CONFIGURATION	STATUS	
SNTP Client	Unicast	Disabled	
SNTP Server 1	101.111.111.111	Not config.	
SNTP Server 2	0.0.0.0	Not config.	
SNTP Server 3	0.0.0.0	Not config.	
SNTP Server 4	0.0.0.0	Not config.	
<input type="button" value="Refresh"/> <input type="button" value="Start polling"/> <input type="button" value="Exit"/>			

A080226

Fig. 3.5.9.4.-16 Ethernet board data

Terminals

The Terminals menu item enables the selection of three submenu items. With them the analog inputs, analog inputs 20 mA and analog outputs 20 mA can be configured. Correct configuration of the analog inputs in particular is very important if REF 542plus is to function properly.

Terminals > Analog Inputs

Starts a configuration dialog box in which settings can be made to adapt the analog inputs of REF 542plus to the sensors or transformers used. These informations are important for starting and tripping protection functions. Measured values are also recorded with these sensors or transformers.

This configuration dialog box allows also the arrangement of other parameters: network settings and calculated values, such as the selection of metering system and the type of power calculation.



The same sensors or transformers are used for the protection and the measurement functions.

Terminals > Analog Inputs 20 mA

Starts a configuration dialog box in which settings can be made to adapt the 20mA Analog Inputs of the REF 542plus to the used sensors. Several SF6- density-sensors but also general purpose sensors with 4..20mA-interface can be connected to these inputs.

Terminals > Analog Outputs 20 mA

Starts a configuration dialog box in which settings can be made to adapt the analog output 20 mA board of the REF 542plus used.

Component

Not applicable for the time being.

Drawing

Starts the function chart editor. Function blocks can be added, connected and configured to set the wanted functions for the bay control and protection unit.

The menu bar with the drawing menu is displayed. The menu items of the drawing menu are described later.

HMI

The HMI menu item enables the selection of further submenu items for the configuration of the single line diagram to be shown on the display, the language selection and so forth.

HMI > Single Line Diagram

Starts the editor for the LCD. The single-line diagram can be set up. Its elements are connected to the corresponding function blocks. At any time it is always possible to select IEC or ANSI bitmaps to be shown on the HMI.

HMI > Display Language

Starts the dialog box that sets the language version for the texts displayed on the LCD. At the same time the correct message texts for the application are selected. The dialog box shows also the char set code page of the selected language. The REF 542plus Configuration Tool uses this value in order to handle properly the non-Latin characters like Arabic, Cyrillic and Hebrew.

HMI > User Text

In case two languages are configured, the first language is always defined as the local one and the second language as English as default language. The display can be switched from one language to the other alternatively. This submenu item shows the text of the information to be displayed in those two languages.

HMI > Download Unicode Fonts

The Unicode fonts are already implemented on the HMI V5. If for some reason other unicode fonts need to be used, the download can be performed with this submenu item.

HMI > Char Maps

The user can manage the Char Maps bitmap fonts both on the PC and in REF 542plus. Refer to Section 4.2.10. Char maps (For operation with HMI V4)(for operation with HMI V4.

HMI > Key Code

The **HMI > Key Code** menu contains two submenus that allow online setting up of the protection and control keys. If REF 542plus is connected properly, the current key is displayed in the dialog box. Then the key can be changed. When the OK button is clicked, the key is sent to REF 542plus.

The key can be composed of maximum 16 alphanumeric chars.

HMI > Key Codes > Set protection key


Opens the dialog box to change the current protection key.

HMI > Key Codes > Set control key

Opens the dialog box to change the current control key.

HMI > LED Bars

Assigns the display of the measurement values to the LED bars according to the following configuration dialog box.



A051670

Fig. 3.5.9.4.-17 Configuration dialog box to assign the measurement values of the LED bars

CB Monitoring

With Release 2.6 the CB monitoring function is introduced. It can be used to supervise the contact wear condition by calculating of the switched current and to help fault analysis by storing all configured measurements in case of CB trip. The function can be opened in menu configure on the main page of the REF 542 configuration or operation tool. For more detailed information please refer to the same section in REF 542 Product Manual, document number 1MRS755860.

3.5.9.5.**Utilities****Check Drawing F9**

Starts the software routine that checks the drawing according to specific criteria. If necessary, relevant error messages are displayed after the check.

Generate Report Files

Creates report file of the currently opened configuration file.

Generate SPA Addresses File

Creates a file with SPA addresses of all configured blocks for the application.

Protection Functions

Lists all protection functions configured. The configuration dialog box for the setting parameter can be opened by double-clicking the wanted protection function

Events

This feature is provided for the automatic events checking. The configuration tool setup will provide a default ETHERNET_IEC61850.RCE file with default events for each configured FUPLA object based on the 61850 data model. This default file is in accordance with the 61850 data model. It is also possible to edit/modify it and create other *.rce files. The configuration tool can be used to select which *.rce file to be used through the menu option called “Options,” which will be described later.

The menu Events precedes the following submenus:

- Set All Events
- Clear All Events
- Set Default Events
- Save Default Events


With the functions “Set Default Events” and “Save Default Events” the required default events for the configured application can be defined and saved. The defined default events can be used for other similar applications. Functions for set and clear all events are also provided.

3.5.9.6.

Options


Customize

This menu provides the customization of location for a file generated by the tool (ie SPA RCA file and Com RCE file), the language to be used and the handling of Lifecycle Service remote server for test. The following two figures show the customization of the file location SPA RCA file and the COM RCE file.



A080228

Fig. 3.5.9.6.-1 Customization of the file location SPA RCA file




A080230

Fig. 3.5.9.6.-2 Customization of the file location Com RCE file


In this dialog it is possible to select the folder containing the default events RCE file. If more files are present, it is possible to select one of them that will be used in the application. Moreover, it is also possible to create a new empty RCE file that will be filled afterwards from inside the events page of each FUPLA object.

The following figures show the customization of the language used in the configuration or in the operating tool and the options for the Lifecycle Service definition. More detailed information can be obtained in the corresponding manual for the Lifecycle Tool.



A080232


Fig. 3.5.9.6.-3 Customization of the language in the configuration/operating tool



A080234

Fig. 3.5.9.6.-4 Customization of the Lifecycle Service remote servers


This dialog provides the possibility to configure a test remote server for the ABB Lifecycle Service to avoid sending “dummy” data to official production database.



A100554

Fig. 3.5.9.6.-5 Customization of the log

This dialog provides the possibility to enable the log system in order to register actions in a log file during the daily use of Configuration Tool. The location of the log file can be chosen in this customization page.



A100556

Fig. 3.5.9.6.-6 Customization of User Manager

This dialog provides the possibility to enable the user profile management that assigns one of the four levels of capability to use Configuration Tool. The login window requires user ID and the password "Super-User."

3.5.9.7.

Help

Function key F1

Opens an information window that shows the assignment of the function keys on the PC keyboard. The appropriate function keys are also shown with the corresponding menu items.

Table 3.5.9.7.-1 shows the assignment of the function keys in the main menu and in the drawing menu.

Table 3.5.9.7.-1 Assignment of the function keys

Key	Main Menu	Drawing Menu
F1	Help on function keys	Information dialog box function keys
F2	Open file...	-
F3	-	Wire mode: Connect FUPLA symbols
F4	-	Draw mode: Move FUPLA symbols
F5	-	Refresh drawing (screen refresh)
F6	Save	Save
F7	Save as...	-
F8	-	Repeat last add action (only for logic symbols)
F9	Check Drawing	Check drawing
F10	-	Sequences ON/OFF
F11	-	-
F12	-	FUPLA Monitor

About

Opens an information window with copyright and version information of the REF 542plus Configuration Tool.

3.5.10.

Description of the Drawing menu items

The menu items of the configuration software are grouped into main and drawing menus. The following sections provide a description of drawing menu items.

The main menu is displayed after starting the configuration software. The drawing menu is displayed when **Main Menu > Configure > Drawing** has been selected. The main menu items are described in Section 3.5.9. Description of the Main menu items.

3.5.10.1.

File

Save F6

The open application file is saved. If a new application file has been created, the file new.ref is saved in the default work directory of the configuration software. In case of a new file, use the menu item Save as when it is saved for the first time.

A project can also be saved by pressing the F6 function key on the PC keyboard.



Before saving, the configuration tool runs a check of the application. Any messages that are displayed must be acknowledged before saving.

Exit Edit

The editor used to create and edit the function chart is closed. The function chart display disappears and the main menu bar is displayed again.

3.5.10.2.

Edit

Copy Page

The displayed page on the editor is copied into the Windows clipboard.

Paste Page

If the Windows clipboard contains a Drawing page, then it is pasted into the displayed page. The REF 542plus Configuration Tool checks the pasted object. Thus, if an object reached the maximum number of installations, it is not pasted into the page.

Insert Page

Opens a dialog box with which a page can be added. The number of the page is entered in the text box before an empty page is added. An information window displays the last page that has been used in the application. The **Accept** and **Cancel** buttons are used to add the page or to cancel the procedure. The dialog box is closed and the user is returned to the drawing menu.

The configuration software provides a maximum of 99 pages for one application.

Delete Page

Opens a dialog box with which the current page can be deleted. The **Accept** and **Cancel** buttons are used to delete the page or to cancel the procedure. The dialog box is closed and the user is returned to the drawing menu.

Delete All

The Delete All menu item has two submenu items. They provide the option of deleting all connections or all pages.

After the selection, a confirmation window is displayed. Click **OK** to confirm the deletion or **Cancel** to cancel the deletion. The dialog box is closed and the user is returned to the drawing menu.

Domain

Not applicable for the time being.

Search Wire

Opens a dialog box where all connections with the same number can be found. The connection number is entered into the appropriate text box.

The **OK** button closes the dialog box and the connections with the number input are marked red on all pages of the function chart.

The **Cancel** button closes the dialog box and returns the user to the drawing menu.

Search Object

The Search Object menu item has two submenu items. They enable a function block (referred to as an object here) to be searched either by its Field bus address or its object number.

A dialog box is displayed after making the selection. The Field bus address or the object number can be entered into the text box.

The **OK** button closes the dialog box and the object with the Field bus address or the object number that was entered is displayed in the function chart.

The **Cancel** button closes the dialog box and returns the user to the drawing menu.

3.5.10.3.

View

Toolbar

Opens the toolbar on the top side of the REF 542plus Configuration Tool.

Status Bar

Sets the status bar at the bottom of the REF 542plus Configuration Tool.

Sequences F10

The Sequences menu item shows and hides all labels on the function blocks and connections. The F10 function key on the PC keyboard does the same thing.

Wires

The Wires menu item has two submenu items. This enables the user to select whether connections can run only at right angles (perpendicular and horizontal) or in straight lines (perpendicular, horizontal and diagonal).

This setting may be changed at any time and affects all connections.

Next page PgDn

Shows the next page in the function chart. The PgDn (Page Down) key or Screen↓ on the PC keyboard does the same thing.

Previous page PgUp

Shows the previous page in the function chart. The PgUp (Page Up) key or Screen↑ on the PC keyboard does the same thing.

Go to page

Opens a dialog box with which any page of the function chart can be displayed. The number of the page required is entered into the text box. An information window displays the last page that has been used in the application. The **OK** and **Cancel** buttons display the page or cancel the procedure. The dialog box is closed and the user is returned to the drawing menu.

The configuration software provides a maximum of 99 pages for one application.

Zoom

Opens a dialog box with which the page view can be enlarged. The percentage factor is entered into the appropriate text box. It is always based on the default size of 100%.

Redraw F5

Refreshes the display on the screen. The size and the markings of searched objects remain as before.

Reset

Removes the markings on searched objects and resets the size to the default factor of 100%. Page 1 of the application is displayed also.

3.5.10.4.**Insert**

A menu with all possible function blocks arranged by function groups is displayed. The various submenus are used to select the corresponding function blocks. The selected one is then added to the function chart.

The sequence of descriptions corresponds to the menu structure of the Insert menu described here. Therefore, a list of the function groups with their function blocks is not given here.

3.5.10.5.**Utilities****Check drawing F9**

Checks the drawing according to specific points. If necessary, relevant error messages are displayed after the check.

FUPLA Monitor F12

The FUPLA Monitor menu item can be marked by selecting it. A <✓> is then displayed beside the menu item. If also the special cable for the optical – RS 232 interface for the communication between the PC with the HMI control unit is connected, the logical level of the connection in the FUPLA can be shown on line.

Switching objects

An information dialog box is displayed. It lists the field bus addressField bus addresses available for the switching objects. Additional information is also shown adjacent:

- - - - - -: The field bus addressField bus address is not used by a switching object.

“EXAMPLE TEXT”: Text from the Comment text box in the configuration dialog box of the switching object.


“empty”: The field bus addressField bus address is used by a switching object. However, no comment text has been entered.



When the cursor is placed over a line with the data of a switching object and the left mouse button is double-clicked, the dialog box is closed and the switching object is marked in the function chart.

DSP Information

The dialog box is shown in Fig. 3.5.10.5.-1. The DSP load, number of protection parameters and the number of protection functions used are listed accordingly.




A051768

Fig. 3.5.10.5.-1 Dialog box Drawing menu > Utilities > DSP information

Protection functions

The dialog box shown in Fig. 3.5.10.5.-2 is displayed. It lists the protection functions in the application.



A051676

Fig. 3.5.10.5.-2 Dialog box Drawing menu > Utilities > Protection Functions

Double-clicking a protection function from the list, the protection function block on the editor is shown and marked. The **Close** button ends the dialog.

Wires

An information dialog box with the numbers of the connections in use opens. The number of connections with this number is shown adjacent in parentheses. At the end of the text that was entered into the Comment text box of the configuration dialog box of the connection follows.



When the cursor is placed over a line with the data of a connection and the left mouse button is double-clicked, the dialog box is closed and all relevant connections are marked in the function chart.

Drawing Set 1

Shows the configured protection trip characteristics according to parameter set 1.

Drawing Set 2

Shows the configured protection trip characteristics according to parameter set 2.

3.5.10.6.

Options

Block Moving of Objects

Objects already present in FUPLA cannot be moved anymore.

Moving Objects Transparently

Objects in FUPLA can be moved transparently.

FUPLA Monitor

Can be used to monitor online the logical condition of the signals in the FUPLA.

Unicode Fonts

The fonts are used for application with HMI V5 and checked by default if HMI V5 is selected as Hardware in menu Configuration.

3.5.10.7.

Help

Function key F1

The function key F1 opens an information window that shows the assignment of the function keys on the PC keyboard. The function keys are also shown with the corresponding menu items.

About

Opens an information window with copyright and version information of the REF 542plus Configuration Tool.

3.5.11.

Description of the status bar

The main view status bar shows the following information:

- COM port settings: the selected COM port and the base unit address
- Web server settings: it is displayed if the Web server is enabled. The IP address is shown as well between square brackets.
- String file name (STC): When the opened configuration is an old one (Release 1 – V4C or older) the file name is not shown. Then it is strongly suggested to update it with the new STC files.
- Charset and codepage: It represents the charset used by the REF 542plus Configuration Tool in order to interpret and convert the Unicode strings of the configuration to the ASCII chars handled by REF 542plus.

4. Setting REF 542plus

In this chapter the following information is available:

- Options for adding required functions to the configuration of the REF 542plus device
- Settings that can be made in the configuration software to adapt the REF 542plus to the application
- Configuring the function chart or plan (FUPLA) to the bay in which the unit is operating
- Implementing the protection functions by using the related function blocks
- All other function blocks that can be added to the FUPLA

If the unit has been delivered with a custom application, this section helps in understanding the function blocks with respect to their function and configuration.

The variety of functions offered by REF 542plus results mainly from the PLC-like programming option provided by the REF 542plus Configuration Tool. Various function blocks are linked to one another in one FUPLA.

The objects that can be added to the function chart are referred to as function blocks. They are used to address binary and analog inputs and outputs and to define switching operations, interlocking and protection functions.

Each function block has inputs and/or outputs that can be used within the FUPLA. To open the configuration dialog box of a function block, point the wanted function block and double-click the left mouse button.

Normally a configuration or an application has been created to be precisely customized for the purpose and location of the REF 542plus device. The configuration has been loaded and saved into the related REF 542plus device. The configuration specifies what protection functions are applied, when and what interlockings are activated and what initial variables are set for the analog and binary outputs of REF 542plus. The application implemented with the FUPLA provides exactly the protection, measurement, supervision and control functions that are required.

4.1. Connecting inputs and outputs

The REF 542plus device receives a great variety of information on the equipment being monitored through its analog and binary inputs. These input quantities are digitally processed in the function chart. The REF 542plus outputs are addressed from the FUPLA, for example to trip the switching objects in the bay.

To enable the REF 542plus inputs and outputs to be used in the function chart, they are represented by function blocks, the switching objects. This enables several inputs and outputs to be combined.

4.2. General settings

Before a FUPLA can be created and exported to REF 542plus, settings must be made in the PC.

4.2.1. Serial Port

To configure the serial port (RS-232) of the computer, the applicable Serial tab must be selected.

The screenshot shows the 'PC Communication Properties' dialog box with the 'Serial' tab selected. The dialog has three tabs: 'General', 'Serial', and 'TCP/IP'. The 'Serial' tab contains the following settings:

- ComPort:** A dropdown menu labeled 'Select Serial Port :' with 'COM1' selected.
- BaudRate:** Three radio button options: 9600 (HMI 'V4C'), 19200 (HMI 'V4D', 'V4E'), and 115200 (HMI 'V5' or MC Debug Port). The 115200 option is selected and highlighted with a dashed border.
- Parity:** Three radio button options: NONE, ODD, and EVEN. The NONE option is selected.
- Data BITS:** Two radio button options: 7 (HMI 'V4C') and 8 (Others). The 8 option is selected.
- Stop BITS:** Two radio button options: 1 and 2. The 1 option is selected.
- Base Unit:** A text field labeled 'Slave Address:' containing the value '99', with a range indicator '1 .. 255' to its right.

At the bottom of the dialog are three buttons: 'OK', 'Cancel', and 'Apply'.

A100558

Fig. 4.2.1.-1 Serial port properties

The tab has five option fields where the settings for the computer serial port can be made.

ComPort

Under ComPort click the active interface on the computer to enable communication from the PC to REF 542plus over a special serial optical cable.

Setting range: COM1, COM2
Default: COM 1

BaudRate

Under BaudRate click the baud rate of the COM port. Release 1.1 supports 9600 bps, release 2 supports 19200 bps and release 2.5 115200 bps.

Setting range: 9600, 19200 and 115200
Default: 115200 (for release 2.5)

Data Bits

Under Data Bits click the data bits of the COM port. REF 542plus V4D.02 operates with 8 bits. Older versions operate with 7 bits.

Setting range: 7, 8
Default: 8

Slave Address

Enter the REF 542plus base unit slave address in the Slave Address text box. This address allows the user to connect more REF 542plus base units to the same HMI. It has nothing to do with the REF 542plus communication card interface.


Setting range: 1 ... 254
Default: 99



Since it is possible to connect more REF 542plus base units to the HMI, the engineer must configure the referred base unit. In fact, the REF 542plus Configuration Tool uploads/downloads the configuration from/to the REF 542plus base unit addressed by the base unit slave address in the serial port configuration.

Fig. 4.2.1.-2 shows a PC with the REF 542plus Configuration Tool that is connected to an HMI via serial communication port (COM1 or COM2). The HMI is shared by three REF 542plus base units, which have three different addresses (on a RS-485 bus). In order to connect the REF 542plus Configuration Tool with a certain REF 542plus base unit it is necessary to configure the right slave unit address. For

example if the REF 542plus Configuration Tool wants to communicate with the first REF 542plus base unit, then the slave address base unit (in the serial port dialog box) must be set to 99.



A051678

Fig. 4.2.1.-2 PC connected via HMI to several base units



The base unit address set in the Serial Port dialog box can be different from the slave address set into the hardware configuration. This is the case when it is necessary to change a slave address of a REF 542plus base unit. For example if it is needed to change the second REF 542plus base unit address (in Fig. 4.2.1.-2) from 100 to 103, it is necessary to communicate with the current base unit which has address 100, but then configure the hardware configuration with 103. After the download of the configuration, REF 542plus restarts with the new address 103. Any further connection request with address 100 fails.



By default, in production, the REF 542plus base unit is set with address 99 (which is the default of the REF 542plus Configuration Tool as well).



The following options are set:

Parity: Default: Even

Stop BITS: Default: 1

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.


Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.2.2.

TCP/IP port

To configure the TCP/IP port of the computer to be used to transmit the configuration file of the application, the applicable TCP/IP tab must be edited. It is also possible to set the IP address of the REF 542plus unit involved in the TCP/IP communication.



A100560

Fig. 4.2.2.-1 TCP/IP port properties

The "Remote device" section allows setting the IP address of the REF 542plus unit involved in a direct communication with Configuration Tool.

The "Local Network Properties" section shows the list of the Ethernet adapters currently installed in the PC. Once an Ethernet adapter is selected, the related TCP/IP parameters are shown as read-only:

- Mac address
- Type of connection (static or DHCP)
- IP address
- Subnet mask
- Default gateway




Both the REF 542plus unit and the PC must be connected to the same network.

To adjust the IP parameters of the PC Ethernet adapter so that it is in the same subnet or in general to modify other TCP/IP parameters, a utility is provided in the TCP/IP tab.

To change the parameters of a PC Ethernet adapter:


- Select the adapter from the list.
- Select "Change network configuration settings" to make the **Change Settings** button available.



A100562

Fig. 4.2.2.-2 Enabling the PC for TCP/IP change

- Click **Change Settings** to open the TCP/IP dialog to enter new settings.



A100564


Fig. 4.2.2.-3 TCP/IP settings change for the PC

If the new parameters are correct, **Save Settings** becomes available.

- Click **Save Settings** to start the renewing of the PC Ethernet card.

The configuration can be done also from outside Configuration Tool.


- From **Control Panel > Network connections**, select the Ethernet adapter whose parameters need to be modified.
- Click **Properties** and select from the list "Internet Protocol (TCP/IP)."



A100566

Fig. 4.2.2.-4 TCP/IP settings and properties change through Control Panel

After selecting "Internet protocol (TCP/IP)," a window appears that allows the changing of the TCP/IP parameters.



A100568

Fig. 4.2.2.-5 Internet protocol properties

In the Internet protocol property window, the PC Ethernet port is configured to communicate with the address 192.168.2.234 and with the subnet 255.255.255.0. The subnet value must match the subnet value set in the REF 542plus unit, while only the first three digits of the IP address must match the ones of the REF 542plus unit. The fourth digit must be different. After the setting, it is possible to verify the remote connection with a ping command.

4.2.3.

Global Settings

The Global Settings are available in **Main Menu > Configure > Global**. The wanted general configuration inputs are made in this dialog box. With the exception of those for trip circuit supervision, the inputs are independent of the REF 542plus model supplied.



It is absolutely essential to edit the configuration dialog boxes in **Main Menu > Configure > Global Settings** and in **Main Menu > Configure > Hardware** before the drawing editor is opened.

Configuration

REF542plus Global Settings

Project:

Feeder:

Global filter time: 0 .. 1000 ms

Active protection set: 1 .. 2

Revision:

Name of configuration:

☐ Errorsupervision

☐ Doubleswitching

☒ Events

☐ No Events when function blocked

Coilsupervision

☐ Card1_1

☒ Card1_2

☐ Card2_1

☐ Card2_2

☐ Card3_1

☐ Card3_2

☐ Show events on HMI

Operate Delay Time: 0 .. 300.0 s

Reset Delay Time: 0 .. 60.0 s

Test Mode

☐ used

☒ not used

System Events 1 System Events 2 System Events 3

OK Cancel

A080236

Fig. 4.2.3.-1 Configuration box for the REF 542plus Global Settings

To assure the correct behavior of the communication using the Ethernet module and the communication protocol IEC 61850, select the No events when function blocked check box. The selection is possible after you have selected the Events check box.

The check box “No Events when function blocked” is a feature for IEC 61850 communication protocol. It is based on the related standard as it is needed to have a complete deactivation of a blocked function in the FUPLA for the generation of the related events.

If the check box “Lifecycle Service used” is not checked and downloaded with the configured application in order to allow for switching off the warning message “Compos. has Changed. Pls Connect to Tool” in the status bar of the HMI.

Node address

The Node address sets the addressing of the bay control and protection unit over the field bus. Every device installed on a field bus is assigned a unique device address.

Setting range: 1 ... 255
Default: 99

Project

Enter a name for the project in the Project text box. The name entered is only a more precise description and has nothing to do with the name under which the application can be saved. One project can include several bays.

Setting range: 0 ... 20 characters (standard character set)

Feeder

In the Feeder text box, enter a name for the feeder for which the application is created as part of the project above. The name entered is only a more precise description and has nothing to do with the name under which the application can be saved.

Setting range: 0 ... 20 characters (standard character set)

Global filter time

In the Global filter time text box, enter the time in ms that is required for an input signal to address the binary input to be detected as such. The general filter time is valid for all binary inputs and is added to a non-adjustable filter time that is set by the design of the unit (1 ms). The last is referred to as the hardware filter time.

Setting range: 0 ... 999 ms (increment: 1 ms)
Default: 20

Active protection set

In the Active protection set text box, enter a parameter set of the protection parameter that is intended to be active when REF 542plus is started. The active parameter set can be changed later with the local control on the REF 542plus operator view.

Setting range: 1 ... 2 (increment: 1)
Default: 1

Changes

A variable that shows the number of changes to the configuration for the service in encrypted form is displayed here.

Name of configuration

The Name of configuration displays the name as which the application file/ configuration file is saved.

Coil supervision

In the former version of the binary I/O module version V2 there were four check boxes in the Coil supervision area that enabled trip circuit supervision (= coil supervision) to be activated for two trip circuits each for a maximum of two or three binary input and output modules. However, since REF 542plus release 2.0, the binary I/O module version V2 is not available anymore. Note that the successor version, the binary I/O module version V3, provides only one coil supervision on each module. The maximum number of coil supervision is two or three, depending on the ordered housing.

Card1_1 (not available anymore in BIO V3)

Activates or deactivates trip circuit supervision for binary output 1 on the 1st input and output board.

Card1_2

Activates or deactivates trip circuit supervision for binary output 2 on the 1st input and output board.

Card2_1 (not available anymore in BIO V3)

Activates or deactivates trip circuit supervision for binary output 1 on the 2nd input and output board.

Card2_2

Activates or deactivates trip circuit supervision for binary output 2 on the 2nd input and output board.

Card3_1 (not available anymore in BIO V3)

Activates or deactivates trip circuit supervision for binary output 1 on the 3rd input and output board.

Card3_2

Activates or deactivates trip circuit supervision for binary output 2 on the 3rd input and output board.

Error supervision

In current version of REF 542plus is not to be used anymore.

Doubleswitching

Doubleswitching provides the option of activating double actuation. After selecting a switching object once on the LCD of the REF 542plus HMI control unit, the option of sending two switching commands to this switching object is available. In general, three seconds are available for sending a switching command after selecting a switching device. If double actuation is activated, another 10 seconds is available to send another switching command after the first switching command.

Events

Select the Events check box to allow event data to be generally sent to a station automation system. See also the system events' 1, 2 and 3 buttons.

Autoreclosure (AR)

Since release 2.0 (version V4D02x) the embedded Autoreclose is not to available anymore. Therefore an independent and separate function blocks Autoreclose can be applied.

Test mode

Click the used option button in the Test mode area to allow entry to the test mode via the HMI control unit in general. Click not used in the Test mode area to deny entry to the test mode via the HMI control unit.

System events 1

Clicking on the **System events 1** button displays a dialog box in which various device-based events can be enabled. If they occur they are then sent to the station automation system.

See also the buttons **System events 2** and **System events 3** and the check box events. Events may also be enabled in the configuration dialogs of some function blocks and they are then based on these.

System events 2

Clicking on the **System events 2** button displays another dialog box in which various device-based events can be enabled. If these events occur they are then sent to the station control system.

See also the buttons for System events and check box events. Events may also be enabled in the configuration dialogs of some function blocks and they are then based on these.

System events 3

Clicking the **System events 3** button displays another dialog box in which various device-based events can be enabled. If these events occur, they are then sent to the station control system.

See also the buttons **System events 1** and **System events 2** and check box events. Events may also be enabled in the configuration dialogs of functions blocks and the events are then based on the dialogs.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.2.4.

Hardware

The general hardware configuration is available in **Main Menu > Configure > Hardware**.



It is absolutely essential first to edit the configuration dialog boxes in **Main Menu > Configure > Global Settings** and in **Main Menu > Configure > Hardware** to get to the drawing editor.

A051053

Fig. 4.2.4.-1 REF 542plus hardware configuration

REF 542plus Housing

Choose 2 IO-Slots option button for a normal housing (2 input/output slots) or 4 IO-Slots option button for a wide housing (4 input/output slots).

Binary IO Boards

<+> button increases and <-> button reduces the number of active binary input and output boards. The wanted number is shown on the left after Number:.

Choose the type of relay that is used on the active binary input and output boards. Either mechanical (conventional) relays or solid state (transistor) relays.



Different binary I/O boards cannot be combined in one REF 542plus device (mechanical relays and solid state relays).

The related information fields binary inputs and binary outputs show how many inputs and outputs are available depending on the number and type of boards in use.

Analog input board

The dialog box provides a selection of predefined analog input boards according to the ordering code. Further description can be found later in Section 4.2.5. Analog inputs.

Analog Input 20 mA Boards

Configure the number of analog input 4-20 mA boards in use under Analog Input 4-20 mA Boards. These boards can only be used in deep housing. The <+> and <-> buttons are used for settings.

Analog Output 20 mA Boards

Configure the number of analog output boards in use under 4-20mA Analog Output Boards. These boards can only be used in deep housing. The <+> and <-> buttons are used for settings. The information field shows the number of possible analog outputs.

Field Bus

Select whether the process bus is to be used or not. CAN option is dedicated only for application designed by ABB switchgear companies.

Communication Interface

In the **Communication Interface** drop-down menu a field bus variation can be selected. Depending on the type of field bus the parameters button is then activated.

Parameters

Click the **Parameters...** button and a dialog box is displayed depending on the protocol selection. When SPA is selected, the REF 542plus slave address is required and the network topology. When Modbus is selected, the first and the second port addresses can be set. When IEC 60870-5-103 is selected, it is possible to change the unit address, the baud rate and the ASDU type. When LON is used, only the unit address can be set.

Base Unit

Configure the address of the configured REF 542plus base unit in Slave Address text box under the Base Unit. This value can be different from the current one (refer to Chapter Serial Port settings).

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.2.5.**Analog inputs**

Main Menu > Configure > Terminals > Analog Inputs displays the dialog box below. The analog measurement inputs of REF 542plus can be configured and set for the transducers in use. The settings are particularly important for the safe and proper functioning of the unit.

The screenshot shows the 'REF542plus Analog Inputs' dialog box with the 'Inputs' tab selected. The 'Analog Input Board' is set to '750170/814'. A table lists 8 inputs with their types, network numbers, directions, connections, and nominal values. Below the table, there are sections for 'Network nominal values' (Net 1) and 'Calculated values'.

Cha...	Type	Net...	Direction	Connection	RPV	RSV	IRV	Phase calib	Amp calib	Ter...
1	Current Transformer	1	Line	Phase 1	100.000 A	1.000 A	1.000 A	0.000	1.0000	X80
2	Current Transformer	1	Line	Phase 2	100.000 A	1.000 A	1.000 A	0.000	1.0000	X80
3	Current Transformer	1	Line	Phase 3	100.000 A	1.000 A	1.000 A	0.000	1.0000	X80
4	Voltage Transformer	1	Normal	Phase 1	100.000 kV	100.000 V	100.000 V	0.000	1.0000	X80
5	Voltage Transformer	1	Normal	Phase 2	100.000 kV	100.000 V	100.000 V	0.000	1.0000	X80
6	Voltage Transformer	1	Normal	Phase 3	100.000 kV	100.000 V	100.000 V	0.000	1.0000	X80
7	Voltage Transformer	1	Normal	Residual	100.000 kV	100.000 V	100.000 V	0.000	1.0000	X80
8	Current Transformer	1	Line	Earth	100.000 A	1.000 A	1.000 A	0.000	1.0000	X80

Network nominal values
 Net 1
 Nominal Network frequency : 50 Hz
 Nominal Voltage : 100.000 kV
 Nominal Current : 100.000 A

Calculated values :
 Power calculation : Three phase power
 Reference system : Load
 Maximal measured values : 0 min
 THD calculation on : Set 2, AI 7


Buttons: OK, Cancel, Apply

A051681

Fig. 4.2.5.-1 Inputs tab in the Analog Inputs configuration dialog box

The Inputs tab displays the complete overview of the analog input settings: sensors, nominal values, calculated values.

The Analog Input Board field represents the ID of the installed board in REF 542plus. The REF 542plus Configuration Tool automatically configures the sensor when the user selects the board from the dialog box below, by clicking the Get group data button.



A051682

Fig. 4.2.5.-2 Analog Boards dialog box

Selecting the board from the list, the sensor type is displayed on the right. The sensor acronyms are:

- CT – current transformer
- RC – current rogowsky coil
- VT – voltage transformer
- VS – voltage sensor
- CT 0.2 – current transformer with Input Nominal Value set to 0.2 A

The REF 542plus Analog Board definition is in Boards\REF542plusAI.xml.

It is always possible to configure manually all the sensors by double-clicking on the correspondent row in the table, or by pressing the SPACEBAR on the keyboard. The sensor dialog box is displayed below.



Every time a new analog board is selected from the analog boards dialog box, all the channel values (RPV, RSV, and so on) are overwritten with the default values.




The analog board name (for example 750170/814) is substituted by the Custom board name when the user makes changes to the analog input channels type.

For more information about the analog input configuration, refer to the REF 542plus Protection Manual.

4.2.6. Analog Input 20 mA

When selecting **Main Menu > Configure > Terminals > Analog Inputs 20mA**, Analog Inputs 20mA dialog opens. See Fig. 4.2.6.-1. The analog inputs 20mA can be configured and set for the connected sensors. Settings are particularly important for safe and proper functioning of the unit.

The analog input 20 mA module in REF 542plus is designed to work with passive sensors only. The passive sensors are supplied by the module directly. The output supply voltage is about 15 VDC. The standard interface of the sensors shall be 2-wire designed and loop-powered. The loop resistance must be set so that the power consumption of the sensors requires a loop current of 4 mA. The current range between 4 mA and 20 mA is dedicated for the intended measurement range.



A051054

Fig. 4.2.6.-1 Example of the configuration dialog for setting the analog inputs 20mA

The dialog box is initially identical for all Analog Inputs 20mA. For this reason only one input and its configuration is described. Information on the setting ranges of the filtering parameters can be found beside the input fields.

Sensor type

In the **Sensor type** drop-down menu the user can choose between four possible sensor types: Not used, Trafag, Density 4-20 mA and General purpose 4-20 mA. The Thermal Overload Environment Temperature is only available, when the sensor type Gen.-Purpose 4-20 mA is selected.

Density unit

In the **Density unit** drop-down menu the user can choose the unit identifier for the density measurement to be visualized on the HMI when sensor type is Trafag or Density 4-20mA. There are three possible density units: Kpa, Kg/m³ and Psi.

Measure unit

In case of a general purpose sensor the unit name must be edited through the Measure unit text box. The text box is disabled when sensor type is Unused, Trafag or Density 4-20mA. The string can be seven characters long at the most.

Measure name

Measure name is the string descriptor of the measurement acquired by the sensor. It is what the user sees on the HMI Measurement Table. The name can be 20 characters long at the most.

Temperature name

Temperature name is the descriptor of the temperature measurement acquired by the Trafag sensor. It is what the user sees on the HMI Measurement Table. If the **Sensor type** is not Trafag the text box is disabled. The name can be 22 characters long at the most.

Data value at 4 mA and 20 mA

Data values at 4 mA and 20 mA are the engineering values corresponding to the current levels of 4 mA and 20 mA. The text box for setting this parameter is enabled only in case of Sensor type density 4-20 mA and Gen. Pur. 4-20 mA. If Sensor type is Unused or Trafag then the parameters are not used and the corresponding text boxes are disabled. The unit is the one set through the dedicated parameter. The resolution displayed below the data values represents the resolution used by the device to scale the parameters to 16 bits values. The resolution is calculated automatically by the REF 542plus Configuration Tool and it is applied automatically to the approximation to the data values when the edit box loses the focus.

Averaging time

The Averaging time parameter sets the width of the time window used to calculate the average value. The Averaging time is expressed in minutes.


Filtering time

When a digital signal is extracted from an analog signal a debouncing operation must be performed. The Filtering time is expressed in milliseconds.

4.2.7.

Analog outputs 20 mA

The REF542plus Analog Outputs dialog box is displayed in **Main Menu > Configure > Terminals > Analog Outputs** where the analog outputs on the REF 542plus analog output board can be configured.



A051684

Fig. 4.2.7.-1 Configuration dialog box for the analog outputs

Because all analog outputs are configured in the same way, only one output is described here. All setting options for an analog output can be found on one index card.

Select a REF 542plus measured or calculated value from the drop-down list by clicking the arrow <▼>. The value is then generated at the corresponding analog output.



The selection list always shows all possible measured and calculated values. In fact only the following values can be output:

Measured values applied to the analog inputs and

Calculated values required by a configured protection function

0 mA = and 4 mA =

In the 0 mA = and 4 mA text boxes the user can specify what multiple of the rated value of a measured or calculated value is mapped to the initial value of the analog output board. The initial value of the output range of the analog output changes here depending on the mode marked. If 0 mA or 4 mA can be tapped at the analog output, the current measured or calculated value is [-4.000 ... +4.000] multiplied by its rated value.

Setting range: -0.0000 ... +4.0000
Default: +0.0000 (increment: 0.0001)

20 mA =

In the 20 mA = text box the user can specify what multiple of the rated value of a measured or calculated value is mapped to the final value of the analog output board. If 20 mA is generated at the analog output, the current measured or calculated value is [-4.000 ... +4.000] multiplied by its rated value.

Setting range: -4.0000 ... +4.0000
Default: +0.0000 (increment: 0.0001)

Mode

Select the output mode in the Mode area. This sets the output range to which the input range set above is mapped. The option with zero signal current allows a continuous current to flow through the line from the analog output board to the display device. This enables an error message to be generated by the display device if no signal is received over the line. However, this limits the output range.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.



If the powerfactor cos phi is selected for the output, the meaning of the text boxes is different:

The configuration-value of the 0 mA (4 mA) nominal value becomes the minimal capacitive cos φ


The configuration value of the 20 mA nominal value becomes the maximal inductive cos φ .



If $\cos \varphi$ is outside of the configured range, the output is 24 mA.

If $\cos \varphi$ is not available ($I, U < 1\%$ of nominal value), the output is 0 mA (4 mA).

See the following Fig. 4.2.7.-2 and Fig. 4.2.7.-3.



A051685

Fig. 4.2.7.-2 Configuration dialog box for the analog output of powerfactor $\cos \varphi$

Example 1:	0 mA =	0	$\cos \varphi$ capacitive
	20 mA =	0	$\cos \varphi$ inductive
This leads to the following analogue outputs:			
φ°	$\cos \varphi$	Analogue output/mA	
-180	-1 capacitive	24	
-90	0 capacitive	0	
-60	0.5 capacitive	5	
0	1	10	
+60	0.5 inductive	15	
+90	0 inductive	20	
+180	-1 inductive	24	
	not available	0	

Example2:	4 mA =	0	$\cos \varphi$ capacitive
	20 mA =	0	$\cos \varphi$ inductive
This leads to the following analogue outputs:			
φ°	$\cos \varphi$	Analogue output/mA	
-180	-1 capacitive	24	
-90	0 capacitive	4	
-60	0.5 capacitive	8	
0	1	12	
+60	0.5 inductive	16	
+90	0 inductive	20	
+180	-1 inductive	24	
	not available	4	


A051686

Fig. 4.2.7.-3 Examples for analog output of powerfactor $\cos \varphi$

4.2.8. Single line diagram

The REF 542plus Display dialog box in Section 4.2.8.1. User controls of the LCD editor is available in **Main Menu > Configure > HMI > Single Line Diagram**. This editor is used to configure the single-line diagram displayed on the LCD in standard operation. The editor is also used to configure the connection between the single-line diagram and the switching device.

4.2.8.1. User controls of the LCD editor



A051687

Fig. 4.2.8.1.-1 Editor for configuring the single-line diagram

The elements labeled in the figure above are described in the following paragraphs.

Drawing field

This area represents the area of the LCD of the HMI control unit REF 542plus usable for the single-line diagram. The single-line diagram configured here always fits between the measured value display and the status line on the LCD.

Coordinates of the cursor position

When cursor is in the drawing field, the location coordinates are shown in the form x, y.

Buttons

Close

The **Close** button closes the editor. The single-line diagram is automatically saved with the configuration. When the editor is closed the user is prompted to save the single-line diagram.

Import and Export

The **Import** and **Export** buttons offer the option of reusing a previously configured single-line diagram. Usually, the single-line diagram is saved in the *.ref file as the rest of the configuration. However, it could be useful to import in the current configuration a previously saved single-line diagram. To do this the single-line diagram must first be exported. After clicking on the appropriate button, a standard dialog box for saving the file to be exported is displayed. The file name has the ending *.lcu. If the user wishes to reuse or change a previously configured single-line diagram, click the **Import** button. A standard dialog box in which the file to be imported can be selected is displayed. The file name must have the ending *.lcu.



Single-line diagrams that were not prepared with the editor described above cannot be imported.

Clear All

When clicking the **Clear All** button, all elements on the drawing field are deleted. If the configuration has been previously saved, the drawing as it stands at this point is saved with it.

Tools

The four buttons set the mode in which work on the drawing field is conducted. The appearance of the cursor also depends on the mode.

Edit



Elements can be selected, moved and deleted in the editing mode. The editing mode is always activated again after using other modes.

Symbol



Any symbol can be added and configured on the drawing field in the Symbol mode.

Thin Line



Use the Thin Line mode to draw thin lines in the drawing field.

Thick Line



Use the Thick Line mode to draw thick lines in the drawing field.

Text Field



Use the Text Field mode to write text.

The exact usage of the buttons is explained in more detail after the editor controls have been explained.

Check boxes

Enable Sloping Lines

When the Enable Sloping Lines check box is selected, diagonal lines can be drawn on the drawing field as well as perpendicular and horizontal lines.

Block Moving

Selecting the Block Moving check box prevents unwanted movement of elements on the drawing field. To move an element, hold down the SHIFT key. This key must also be used for extending, shortening or changing the direction of lines.

Selected element

A selected element is shown inverted. All operations can only be conducted on the selected element. For this reason only one element can be selected at a time.

Free Resources

The Free Resources area displays information on the number of symbols and lines (the possible elements) that can still be drawn.

Marked Element

The Marked Element area displays information on the element that is to be selected.

Lines: coordinates of the start and finish points, the line thickness (thin/thick) and the line length in pixels.

Switching objects: coordinates of the lower left corner, Field bus address and comment for the function block that is represented.

Other symbols: coordinates of the left lower corner.

Cursor appearance

The cursor can appear differently depending on the specific mode in the drawing field.



Standard appearance is shown when the cursor is not on any element.



Movement cursor is shown when the cursor is on an element. Click the left mouse button to select the element.



Drag cursor is shown when the cursor is on the end of a selected line. The line can then be shortened or lengthened by dragging with the left mouse button held down.



Symbol cursor is used in the Symbol mode. Click the mouse to open the configuration dialog box for a new symbol.



Line cursor is used in the Line mode. Hold the left mouse button down and drag to draw perpendicular, horizontal or diagonal (if enabled) lines.

4.2.8.2.

Working with the LCD editor

Select an element/deselect selection

To select a symbol or a line, click the left mouse button when the cursor is on them.

The selected symbol is shown inverted: the sizing handles at the ends of the line are emphasized.

To deactivate a selection, click the left mouse button when the cursor is not on an element in the drawing field.

Select sizing handle

1. Select a line.
2. The sizing handles are shown.
3. Move the cursor to the sizing handle and hold the left mouse button down. Drag the sizing handle with the mouse.

OR:

1. Mark one or the other sizing handle by using the key combination CTRL +SPACEBAR several times.
2. The arrow keys on the keyboard can be used to make very precise movements of the sizing handle.

Open context-dependent pop-up menus

In addition to the options for conducting various operations described above, the editor for the LCD also has content-dependent pop-up menus. Open pop-up menus by clicking the right mouse button. The contents depend on where the cursor is on the drawing field at that time (pop-up menus can only be opened there). A menu beside the cursor opens in which various editing options can be selected. This offers faster access to the various functions. All functions offered there can also be accessed as described above.

To display a specific contextual menu, click the right mouse button when the cursor is on an element (line, symbol or text) in the drawing field. The menu items depend on the selected element. All the elements have the following commands: delete, to delete the element and edit, to configure the element.

Some elements, for example the switching objects, has in addition the State menu which can set the status of the selected element (for example closed, opened, in error or moving).

Click the right mouse button when the cursor is not on an element and a pop-up menu is displayed. The menu contains the following commands: Insert symbol, line and text, Import, Export, Clear All, and Copy. The last command copies the bitmap in the Windows clipboard. The other commands are the same as the dialog box buttons.

Move element

Select the element and drag the mouse with the element while holding the left mouse button down.

OR:

After selecting the element move it with the arrow keys on the keyboard.

Insert symbol

1. Click the symbol button.
2. Move the cursor to the wanted position for the symbol in the drawing field.
3. Click the left mouse button to open the symbol configuration dialog box.

Configure existing symbol

Move the cursor over the symbol and double-click the left mouse button. The configuration dialog box opens.

Insert line

1. Click the thin line or thick line button.
2. Move the cursor in the drawing field to the wanted position for the beginning of the line.
3. Click the left mouse button and hold it down to set the beginning point of the line.
4. Drag the mouse with the button held down to the end point of the line.
5. Release the mouse button.

Configure existing line

Move the cursor over the line and double-click the left mouse button. The configuration dialog box opens.

Delete element

1. Select the element that is to be deleted.
2. Click Delete on the keyboard.
3. The user is prompted to confirm or cancel the deletion.

Change line size

1. Select sizing handle.
2. Drag the mouse with the sizing handle while holding the left mouse button down.

OR:

After selecting the sizing handle move it with the arrow keys on the keyboard.

Change the appearance of a switching object

Click on the switching object symbol while holding the CTRL key down. Every switching object has four different appearances, which represent its switching status.

OR:

Select the switching object and change its appearance with the key combination CTRL+SPACEBAR.

Select elements one after the other

1. Select an element
2. Use the keys CTRL+right arrow or CTRL+up arrow to select the next or the previous element according to an internal sorting process.

Use the keys CTRL+left arrow or CTRL+down arrow to select the next or the previous element in the opposite direction to the internal sorting process.


Copy drawing field to the clipboard

Use the INSERT key on the keyboard to copy the entire drawing field to the clipboard as a two-color bitmap graphic.

4.2.8.3.

Configuration dialog box for symbols

The configuration dialog box Set Symbol is displayed when a new symbol is added or if it is opened as described in the previous Section 4.2.8.2. Working with the LCD editor. The type of shapes depends on the standard selection: IEC or ANSI.



A051698

Fig. 4.2.8.3.-1 Configuration dialog box for symbols in the editor for the LCD

Shape

Click the arrow < ▼ > to open the drop-down menu **Shape** that displays optional appearances of the symbols. A description and the dimensions of the image (height, width) are adjacent to the image. In the case of the switching objects, please note that only one of four possible images is shown.

Field Bus Address

Set the connection between the element on the LCD and the function chart in the **Field Bus Address** drop-down menu. The selected symbol represents the switching object with the corresponding Field bus address on the LCD. After clicking the arrow that opens the list < ▼ >, the selection of possible Field bus addresses that have been used in the function chart for switching objects is displayed. The comment that can be entered in the configuration dialog box of that switching object is adjacent.

The drop-down menu **Field Bus Address** is opened automatically when a symbol in the Symbol list has been selected.

Position

The x and y coordinates are displayed at the lower left corner of the symbol. Other coordinates can be entered in the Position text box to move the symbol.

Single Object/Combined Object

To select whether the wanted switching object is represented by one or two symbols, choose Single Object or Combined Object option button. The second symbol can be selected with the option buttons Earth Switch and Isolator. Only these two options are available for the second symbol.

Example:

A 3-position switch (with some exceptions) can be shown using a combination consisting of an earthing switch and an isolator.

Selectability

Select under Selectability how the switching object can be directly selected locally.

privileged	The first switching object that is selected.
selectable	This switching object can be selected. The sequence in which the switching objects are selected is set internally. Only the switching object that is selected first can be set (see above).
not selectable	This switching object cannot be selected locally on the REF 542plus. It can only be addressed from the station control system.

OK


Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.2.8.4. Configuration dialog box for lines

The configuration dialog box Edit Line for lines is opened as already described in the previous Section 4.2.8.3. Configuration dialog box for symbols.



A051699

Fig. 4.2.8.4.-1 Configuration dialog box for lines in the editor for the LCD

Start Position

Enter the x and y coordinates of the starting point of the line into the two text boxes. The current values are displayed there when the dialog box is opened.

End Position

Enter the x and y coordinates of the end point of the line into the two text boxes. The current values are displayed there when the dialog box is opened.

Line Width

Select whether the selected line should be drawn thick or thin. The current values are displayed there when the dialog box is opened.

OK


Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.2.9. Display language

Main Menu > Configure > HMI > Display Language displays the dialog box below. Select the language file from which the texts that is displayed on the LCD display screen is read.



A051700

Fig. 4.2.9.-1 Configuration dialog box for selecting the language of the texts on the LCD

The first part of the dialog box shows the current display language stored into the configuration and the charset codepage. Old configuration is refreshed by selecting the new display language and the correspondent codepage. For example when the English string file is loaded the codepage Latin is chosen. Instead, for Russian string file the Cyrillic codepage is used.

Choose New Display Language

Click the arrow < ▼ > to open a list of files. The file is selected depending on the wanted language and the configuration used. The language English and German are provided as default. Translation into other languages can be done easily by editing the related .stc file.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.




The standard language file provided is english.stc. To change to another language, this file needs to be translated correspondingly.

4.2.10.

Char maps (For operation with HMI V4)

Main Menu > Configure > HMI > Char Maps displays the dialog box below. With the dialog box it is possible to download the “font” (also called char map) used by the LCD to display the texts to the device.




A051701

Fig. 4.2.10.-1 Configuration dialog box to handle font bitmaps and character map files

The list on the left contains the char bitmaps folder installed in the PC. It is possible to add new bitmaps folder (for example for new languages). The REF 542plus does not use directly such bitmaps, but a generated binary file, called *.rfn.

As shown in Fig. 4.2.10.-2, the installation provides two *.rfn binary files. They are generated from the installed (if selected during installation) bitmap folders.

These files can be generated clicking the **Generate File On Disk** button. The generated files have the same name of the folder.



A051702

Fig. 4.2.10.-2 Installed files

The list on the right contains the *.rfn file already installed in the PC. Selecting a character map file it is possible to download this binary file to the device where it is used by the HMI to display the text.


It is always possible to retrieve the font file *.rfn from a REF 542plus device, by clicking the **Upload File From Device** button. Depending on the version and on the character set, it can overwrite an existing *.rfn file.

The folder and file names follow this convention:

<Codepage name>-<codepage>-<internal use>-<version>

For example “Hebrew-1255-1000-003” is the third version of the Hebrew char map.

The version in the file names is important in order to keep also the previous char maps on disk whenever changes are applied. Otherwise the last generated or uploaded char map file overwrites the existing one.



A051703


Fig. 4.2.10.-3 Installed bitmap files for Latin char set

A bitmaps folder contains the chars from ASCII code 32 to 255. A bitmap char is 8x8 pixels black and white. The normal background is white and the char/symbol is black. In order to display a readable char the following rule must be followed: the bitmap must be edited with a char of 5x7 pixels. The rest of the pixels can be used by the HMI for special effects (underline, and so on).

The char bitmap file name must follow this rule:

<string>_xyz.bmp


The <string> can be the charset name, and it must not contain “_”. The digits “xyz” instead represent the ASCII code of the char (always between 032 and 255).



A051704

Fig. 4.2.10.-4 Example of bitmap (Latin_057)

If the HMI V5 is applied, the provided Unicode fonts must be downloaded and used. The following screenshot shows how to find the Unicode fonts.




A060425

Fig. 4.2.10.-5 Menu for downloading Unicode fonts

4.2.11.

LED Bars

Main Menu > Configure > HMI > LED Bars displays the dialog box LED Bars. With the dialog box it is possible to configure the three LED (light emitting diode) bars on the HMI. It is possible to assign a defined signal to a LED bar and the label shown aside.



A051705

Fig. 4.2.11.-1 Configuration dialog box LED bars

4.3. Function and configuration of the function blocks

This section describes all function blocks that can be added to the FUPLA or that are already present in the FUPLA. The structure is adapted to the menu structure of the Add menu in the function chart editor. Every description has a similar structure.

Description of the function blocks

In the following descriptions of the function blocks, a diagram of a function block is followed by an explanation of its function, its connections and, if applicable, a typical application. This is followed by a screenshot of the configuration dialog box associated with the function block if it is not an information dialog box, which only has the **OK** or **Cancel** buttons.

Finally, the various elements of the configuration dialog boxes are explained. If input parameters are involved, the input range and its optional increment and the default value are also given. To ensure that every function block has a complete description, elements that occur repeatedly are always described.

Description of the switching objects


Only the sections where the switching objects are described have a different procedure. They are preceded by an additional section that describes a selected switching object in detail. This includes information on the appearance of a switching object in the function chart and its configuration dialog box. All descriptions are somewhat shorter in the sections on every single switching object.

Object number

The number on the left side, above every function block is the sequential number (object number), which is assigned by the configuration software. It may be assigned several times in the images of the function blocks. Every object number is only assigned once in a correct application.

4.3.1. Control panel on the HMI control unit

Following sections contain the descriptions of the function blocks that are available in **Drawing Menu > Insert > Control Panel**.

4.3.1.1.**Indication LED**

A051706

*Fig. 4.3.1.1.-1 Function block Indication LED***Function**

The Indication LED function block represents the configurable indication LED's adjacent to the LCD on the HMI as local control unit. This function block can be used to address the LED's from the FUPLA and appropriate indication texts can be added.

Connections

The LEDs can be in one of four states depending on the wiring of the two inputs: off, green, red and orange (amber). The indicated text depends on the color displayed by the LED. The following Table 4.3.1.1.-1 shows the corresponding combinations.

Table 4.3.1.1.-1 Connections on the function block Indication LED

Color	Green Input	Red Input
Off	0	0
Green	1	0
Red	0	1
Amber	1	1

Eight LEDs on each of the four pages (totally 32 LEDs) can be addressed.

Typical application

Use of the signaling LED to receive the status indication for temperature supervision of a motor. A green LED stands for example "OK", an amber LED stands for "critical status" (with the starting signal of a protection function) and a red LED stands for "fault: motor too hot" (with the trip signal of a protection function).

Configuration

The following section describes several tabs in the Indication configuration dialog box. In all the tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A051707

Fig. 4.3.1.1.-2 General tab, Indication LED function block

Page number

Input of the number of the LED page that is to be configured.

Setting range: 1 ... 4 (increment: 1)

Default: [number of the next LED that is not configured]

LED number

In the **LED number** drop-down menu, select the number of the LED that is to be configured. The number is also put in the function block.

Setting range: 1 ... 8 (increment: 1)
Default: Number of the next LED that is not configured

Texts for the Display

OFF

In the OFF text box, write the text that is displayed in the LCD after the scan of the LED message texts when the LED is off. In the FUPLA, the text is displayed above the function block.

Setting range: 0 ... 20 characters (standard character set)
Default: [Empty]

Green

In the Green text box, write the text that is displayed in the LCD, when the condition is fulfilled. In the FUPLA, the text is displayed above the function block.

Setting range: 0 ... 20 characters (standard character set)
Default: [Empty]

Amber

In the Amber text box, write the text that is displayed in the LCD, when the condition is fulfilled. In the FUPLA, the text is displayed above the function block.


Setting range: 0 ... 20 characters (standard character set)
Default: [Empty]

Red

In the Red text box, write the text that is displayed in the LCD, when the condition is fulfilled. In the FUPLA, the text is displayed above the function block.

Setting range: 0 ... 20 characters (standard character set)
Default: [Empty]

Parameter



A051708

Fig. 4.3.1.1.-3 Parameter tab, Indication LED function block

Latch signal

The Latch signal check box must be selected if an acknowledgement is required after the LED status (off, red, green or amber) has changed. If the reason for the change of the LED state is still in effect, the acknowledgement has no effect.


Setting range: Selected/Not selected
Default: Not selected

Send SMS on transition to RED

The Send SMS on transition to RED check box must be selected if an SMS message should be sent by the Web server (if enabled) whenever the LED turns to red.

Setting range: Selected/Not selected
Default: Not selected

Pins



A051709

Fig. 4.3.1.1.-4 Pins tab, Indication LED function block

On the Pins tab, you can see a list of connections on the function block and information about the wire number connected to the pin. There is also information whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has not made connections.

4.3.1.2.

Alarm LED



A051710

Fig. 4.3.1.2.-1 Function block Alarm LED

Function

The Alarm LED function block represents the alarm LED on the HMI control unit. This enables it to be controlled from the FUPLA.

Connections

The function block connections are not labeled on the function block. They are described as the upper and lower connection.

There are two options for switching the alarm LED on and off:

1. The LED is switched on if the upper connection is at logical 1 and the LED is switched off if the upper connection is at logical 0.

OR

2. The LED is switched on if the lower connection receives a logical 1 signal and the LED is switched off if there is no longer a logical 1 signal at the lower connection.

AND

If the alarm is acknowledged at the REF 542plus control panel.

Typical application

The alarm LED is on if a power circuit-breaker OFF command has been generated by a protection function being addressed and the power circuit-breaker has been tripped.


Configuration

Only the function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has not made connections. These inputs are then confirmed with the **OK** button.

4.3.1.3.

Alarm Reset



A051711

Fig. 4.3.1.3.-1 Function block Alarm Reset

Function

The Alarm Reset function block provides return confirmations on the alarm and where from the alarm was acknowledged in the function chart.

Connections

ALARM output: Logical 1 if the alarm is still active and the ALARM LED is on (even after an attempted acknowledgement of the alarm)

REMOTE output: Logical 1 impulse if acknowledged from the station control system.

LOCAL output: Logical 1 impulse if acknowledged "locally".

Typical application

The signals received can be used to reset flip-flops if an alarm (for example power circuit-breaker off) is acknowledged at the HMI control unit of REF 542plus.


Configuration

Only the function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.1.4.

LR-Key



A051712

Fig. 4.3.1.4.-1 Function block LR-Key

Function

The LR-Key function block provides information on the position of the "local/remote" key switch on the REF 542plus control panel at both outputs.

Connections

Table 4.3.1.4.-1 Connection at the function block Local - Remote

Connection	Local	Remote
No control (OFF)	0	0
Remote	0	1
Local	1	0
Local & Remote	1	1

Typical application

A reconfirmation of the key switch setting that can also be forwarded to a substation automation system is possible with the LR-Key function block. This enables switching authorizations to be assigned, for example no switching operations permitted at the HMI control unit.


Configuration

Only the function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.1.5.

Emergency Buttons



A051713

Fig. 4.3.1.5.-1 Function block Emergency Buttons

Function

The Emergency Buttons function block represents the two Emergency Switch Off buttons on the HMI control unit. If a switch is actuated, a logical 1 is displayed at the corresponding function block output.

Connections

LEFT output: Logical 1 is displayed if the left key on the HMI control unit is actuated.

Both outputs: Logical 1 is displayed if the both keys on the HMI control unit are actuated.

Typical application


A typical application for the emergency buttons is an actuation of the tripping of the circuit-breaker with both emergency switches.

Configuration

Only the function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the OK button.

4.3.1.6.

HMI Command



A051714

Fig. 4.3.1.6.-1 Function block HMI Command

Function


The HMI Command function block represents a command launched by the user via the HMI control unit menu. When the user selects the command from the HMI menu, then the output of the function block is set for one-FUPLA-cycle to logical 1. The name of the HMI menu (visible in the HMI menu) is set into the configuration dialog box of the function block.

Connections

Output: Logical 1 for a FUPLA cycle if the command is selected.


Configuration

The unique parameter is the command name.



A051715

Fig. 4.3.1.6.-2 Configuration dialog box of the function block HMI Command

4.3.1.7.**Enable/Disable**

A051716

Fig. 4.3.1.7.-1 Function block Enable/Disable

Function


The new constant block, also called Enable/Disable, produces a 0 or 1 depending on the user's settings. The user can change the constant value via LD HMI or via communication board. It is possible to instantiate till 40 Enable/Disable function blocks.

Connections

Output: Logical value of the constant.

Configuration

The configuration dialog box allows the user to choose the Field bus address (used for the communication board), the name of the constant (used for the HMI), the constant value, and the flag in order to enable the parameter on the HMI.



A051717

Fig. 4.3.1.7.-2 Configuration dialog box of the function block Enable/Disable

4.3.2. Binary IO (switching objects)

This section describes the function blocks that are available in **Drawing Menu > Insert > Binary IO**.


The function blocks described here are switching objects. A switching object represents one or more combined binary inputs and outputs in the function chart. Instead of function chart the abbreviation FUPLA is used in the following. A switching object enables signals at the binary inputs to be used in the FUPLA. For example, the message from a sensor that monitors the spring of a circuit-breaker or the position messages of a switching device.

A switching object also enables signals to be sent to the binary outputs from the FUPLA. For example, a switching command can be sent to a switching device in this way. Both power and signal outputs can be addressed in case of outputs.

All the switching objects described in the following sections have identically structured FUPLA displays and configuration dialog boxes. To clarify the principle, a switching object 2-1 is described below. However, all elements of the FUPLA display and of the configuration dialog box are explained with the individual switching objects. The explanation there is somewhat shorter.

The switching object labeling already shows the principal structure. An example of a switching object 2-1 can be seen in the next figure. The above mentioned switching object represents the logical combination of two binary outputs and one binary input.

EXAMPLE



A051718

Fig. 4.3.2.-1 Example of a switching object in the function chart (Fupla symbol)

Number of the switching object

The sequential number is displayed in the upper left side of the function block in the FUPLA. It is automatically assigned by the configuration software and updated when function blocks are deleted or new ones are added. It is used to localize the relevant function block in the event of error messages from the configuration software. It is also required in the internal processing of the function blocks in REF 542plus.

Connection comment/connection number

Every connection drawn in the function chart is assigned a connection number. A comment is also attached to the connection. Comment and number are displayed with every connection in the function chart and the connection number is also displayed in the configuration dialog boxes of the connected function blocks.

Number and type of the physical input

Physical binary inputs from the primary system are always placed in the right half of the FUPLA display of a switching object. Their connections are also on the right. The signal that is displayed to the physical input can be tapped at the relevant connection. The type (BI - binary input and so on) and the input number of the physical input are also shown in the function chart display.

Number and type of the physical output

Physical binary outputs to the primary system are always placed in the left half of the FUPLA display of a switching object. Their connections are also on the left. A logical signal to the appropriate connection starts, if authorized, an output relay switching operation. To enable this, a logical 1 must be at the IL input and a logical

0 at the BL input. Otherwise, the interlocking status LED turns to red or the switching operation is suppressed. The type (OP - Open or CL - close and so on) and the channel number of the physical input are also displayed in the FUPLA.

Pulse output

The connection pulse output is available only with switching objects that represent at least one physical input and output. Because most switchgears can only switch with short impulses, a closing time of 0 to 65000 ms is provided. This logical 1 is canceled in case of switching objects with a limit stop if a return confirmation regarding the successful switching operation has been transmitted over a binary input of the switching object. Switching objects have a limit stop if they represent at least one physical input and output.

Limit stop

If inputs and outputs are combined in one switching object and internally interconnected, the function block includes a limit stop. A limit stop operates when the wanted position of a switch is reached and the reconfirmation is received via a binary input. The switching impulse (generated at P) is canceled, even if the configured impulse length has not yet been reached.

The connection time monitor output Time> is available only with switching objects that represent at least one physical input and output. A logical 1 is displayed at the connection if the impulse time (at pulse output P) has expired and a reconfirmation regarding the successful switching operation is not received by the binary input.

Interlocking input


The interlocking input (interlocking) connection is available only with switching objects that represent at least one physical output. To enable a switching operation, there must be a logical 1 at the connection IL. If a switching operation is started and the interlocking input IL is at logical 0, an error message "interlocking violation" is generated and displayed at the REF 542plus control panel using the LED provided for that purpose (interlocking status LED).

Blocking input

The connection blocking input (blocking) is available only with switching objects that represent at least one physical output. If a logical 1 is applied to this connection, a switching operation can be blocked. A logical 1 at the BL connection places the function block out of service. If the interlocking input IL is set to logical 1, a switching operation would be allowed. However, this can be blocked by a logical 1 signal at the connection BL. If a signal for the switching operation is given to the connection of the physical output, no switching takes place and an "interlocking violation" error message (interlocking status LED) is also generated.

Field bus address

The combined inputs can be addressed under a Field bus address as shown in the figure below, in which a configuration dialog box is displayed after double clicking the FUPLA symbol. The Field bus address is to be selected in the configuration dialog box.



A051719

Fig. 4.3.2.-2 Example of the switching object configuration dialog box

Furthermore there are:

Number and type of the physical input

Enter a channel number for the physical binary inputs from the primary system.

Setting range: 0... [number of binary inputs] (increment: 1)
Default: 0

Filtertime [ms]

Enter a period in ms during which an input signal at the binary input must be applied to be detected as such. The function block-dependent filter time entered here is added to the general filter time, which is specified in the configuration dialog box REF 542plus Global Settings, and to the hardware filter time, which is set by the design of the binary input/output board.

hardware filter time + general filter time = total filter time

Number and type of physical output

Enter a channel number for the physical binary outputs to the primary system.

Setting range: 0... [number of binary outputs] (increment: 1)

Default: 0

Note the different relay types.

Imp.length [ms]

Because most switchgears can only switch with short impulses, a closing time of 0 to 65000 ms can be written in the configuration dialog box under impulse length, which has exactly the same effect on the current output. This "extended" switching signal is generated as logical 1 at the pulse output P connection. This logical 1 is canceled in the case of switching objects with a limit stop if a return confirmation regarding the successful switching operation has been transmitted over a binary input of the switching object. Switching objects have a limit stop if they represent at least one physical input and output.

No. of cycles

Enter the value of the mechanical switching cycle counter at the circuit-breaker in the No. of cycles text box. The value entered in the No. of cycles text box is the starting value of the switching cycle counter in REF 542plus. When the configuration is exported from REF 542plus to the PC, the current value of the switching cycles is entered to this position.



In this program version the text box is only used by the Switching Object 2-2 if a circuit-breaker is applied. It has no function with all other switching objects.

Field bus address

The Field bus address is shown at the bottom left side of the FUPLA beside the switching object: "Adr.: XX". It is automatically assigned in the configuration dialog box, so every Field bus address is only used once. Addresses that are freed (when a function block is deleted) are assigned again by the configuration software. As an alternative the Field bus address can also be assigned in the configuration dialog box with the field bus selection list. The selection list is displayed by clicking the < ▼ > button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)

Default: The next free Field bus address

Pins

Under Pins in the Switching Object dialog box is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

Setting for switching object-specific special function

Check boxes for activating or deactivating functions appear here. Further information can be found in the switching object description.

Events

The **Events** button cannot be selected if the transmission of events is generally suppressed in the REF 542plus Global Settings. Click the **Events** button to display a dialog box where the events are released that are then sent to the station automation system. The default is for all events to be released for sending.

An event that has been sent is a message to the station control system regarding a change in status. Depending on the function block type, different events can be generated and released. The input can be accepted or canceled in the dialog box with the **OK** and **Cancel** buttons.

Comment

Enter comments regarding the switching object in the Comment text box. The comment is also shown on the upper left side of the switching object in the function chart.

Setting range: 0 ... 20 characters (standard character set)


Default: [Empty]

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.3.2.1. Switching Object 0-1

A051720

*Fig. 4.3.2.1.-1 Function block Switching Object 0-1***Function**

The signal of a physical binary input is made available in the Switching object 0-1 function block.

Connections

BI output: Connection at which the binary input signal of the represented physical input can be tapped.


Table 4.3.2.1.-1 Connection labels switching object 0-1

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
BI	Input	BI

Typical application

A typical application for the switching object 0-1 is a connection of a gas pressure monitor that sends a logical 1 or 0 to the relevant binary input.

Configuration



A051721

Fig. 4.3.2.1.-2 Configuration dialog box Switching Object 0-1

Field bus address

The Field bus address is automatically assigned so that every Field bus address is used only once. As an alternative the Field bus address can also be selected from the list, which is displayed by clicking the < ▼ > button.

Setting range: 5 ... 49 and 111 ...127 (increment: 1)
Default: Next free Field bus address

Input No. [Name] (once per represented input)

In the Input No. [Name] text box enter the number of the physical input to be represented. The assigned number, underlined in white, is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary inputs] (increment: 1)
Default: 0

Filtertime [ms] (once per represented input)

In the Filtertime[ms] text box enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Comment

Enter comments (for example purpose) on the switching object in the Comment text box. The text is also displayed in the FUPLA on the left side above the switching object.

Setting range: 0 ... 21 characters (standard character set)
Default: [Empty]

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

Events

Click the **Events** button to open a dialog box. Select (activate) the events that are sent to the station control system over the field bus. The button is available only when the events function has been activated in the Global Settings.

4.3.2.2.

Switching Object 0-3




Fig. 4.3.2.2.-1 Function block Switching Object 0-3

A051722

Function

The signal of three physical binary inputs is made available in the Switching Object 0-3 function block. All connections are addressed over one Field bus address.

Connections

EARTH, OPEN and LINE outputs: Connections at which the binary input signals of the various represented physical inputs can be tapped.

Table 4.3.2.2.-1 Connection labels switching object 0-3

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
EARTH	Input No. earth	BI earth
OPEN	Input No. open	BI open
LINE	Input No. line	BI line

Typical application


Position a confirmation signal from a manually operated switching device, for example a 3-position isolator.

Configuration

A051723

Fig. 4.3.2.2.-2 Configuration dialog box Switching Object 0-3

Field bus address

The Field bus address is automatically assigned so that every Field bus address is only used once. As an alternative, the Field bus address can also be selected from the list, which is displayed by clicking the <  > button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)
Default: Next free Field bus address

Input No. [Name] (once per represented input)

In the Input No. [Name] text box enter the number of the physical input that is to be represented. The assigned number, underlined, underlined in white, is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary inputs] (increment: 1)
Default: 0

Filtertime [ms] (once per represented input)

In the Filtertime [ms] text box enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Comment

In the Comment text box enter comments (for example purpose) on the switching object. The text is also displayed in the FUPLA on the left side above the switching object.

Setting range: 0 ... 21 characters (standard character set)
Default: [Empty]

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel


When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

Events

Click the **Events** button to open a dialog box. Select (activate) the events that are sent to the station control system over the field bus. The button is available only when the events function has been activated in the Global Settings.

4.3.2.3.

Switching Object 1-0



A051724

Fig. 4.3.2.3.-1 Function block Switching Object 1-0

Function

Switching Object 1-0 actuates a physical binary output from the function chart.

Connections

IL input is an interlocking input. A switching operation can only be conducted if there is a logical 1 signal.

BL input is a blocking input. If there is a logical 1 signal here, the switching operations of the represented output are blocked.

PO input is a signaling input for a physical output. A logical 1 signal initiates, if enabled, an output relay switching operation.

P output is a pulse output. A logical 1 can be tapped for the duration of the output relay switching operation.


Table 4.3.2.3.-1 Connection labels switching object 1-0

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
PO	Output No.	PO active
IL	-	IL
P	-	Pulse
BL	-	BL

Typical application

Use as output for the contact signaling of for example general start.

Configuration



A051725

Fig. 4.3.2.3.-2 Configuration dialog box Switching Object 1-0

Field bus address

The Field bus address is automatically assigned so that every Field bus address is only used once. As an alternative the Field bus address can also be selected from the list which is displayed by clicking the < ▼ > button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)
Default: Next free Field bus address

Output No. [Name] (once per represented output)

Enter the number of the physical output that is to be represented in the Output No. text box. The assigned number, underlined, underlined in white, is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary outputs] (increment: 1)
Default: 0

Imp.length [ms] (once per represented output)

Enter the maximum duration of the output relay switching operation in the Imp. length [ms] text box. In function blocks with limit stops the switching operation ends before if necessary.

No. of cycles (once per represented output)

Not used.

Comment

Enter comments (for example purpose) on the switching object in the Comment text box. The text is also displayed in the FUPLA on the left side above the switching object.

Setting range: 0 ... 21 characters (standard character set)

Default: [Empty]

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

Use Two Step Switch Command

If two-stage switching is activate, a switching object must be selected with a command from the station control system and switched with a 2nd command. This option does not refer to local switching.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel


When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

Events

Click the **Events** button to open a dialog box. Select (activate) the events that are sent to the station control system over the field bus. The button is available only when the events function has been activated in the Global Settings.

4.3.2.4.

Switching Object 1-1



A051726

Fig. 4.3.2.4.-1 Function block Switching Object 1-1

Function

Switching Object 1-1 function block actuates a physical binary output from the function chart. The return confirmation is received via the physical binary input, which can be tapped in the function chart.

Connections

IL input is an interlocking input. A switching operation can only be conducted if there is a logical 1 signal here.

BL input is a blocking input. If there is a logical 1 signal here, the switching operations of the represented output are blocked.

PO input is a signaling input for a physical output. A logical signal to this function block input starts, if enabled, a corresponding switching operation of the represented output relay.

P output is a pulse output. A logical 1 can be tapped for the duration of the output relay switching operation.

BI output is a signal output at which the binary input signal of the represented physical input can be tapped.

Time > output is a time monitor output. If a logical 1 can be tapped here, the set impulse time is expired and a return confirmation regarding the correct switching operation is no longer received over the represented binary input.


Table 4.3.2.4.-1 Connection labels switching object 1-1

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
IL	-	IL
BL	-	BL
PO	Output No.	PO Active
TIME>	-	Time>
BI	Input No.	BI
P	-	Pulse

Typical application

A typical application for the Switching Object 1-1 is using the physical output to actuate a tension motor for the spring of a power circuit-breaker. The return confirmation over the physical input provides information on the spring status.

Configuration



A051727

Fig. 4.3.2.4.-2 Configuration dialog box Switching Object 1-1

Field bus address

The Field bus address is automatically assigned so that every Field bus is only used once. As an alternative the Field bus address can also be selected from the list, which is displayed by clicking the < ▼ > button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)
Default: Next free Field bus address

Output No. [Name] (once per represented output)

Enter the number of the physical output that is to be represented in the Output No. text box. The assigned number, underlined, underlined in white, is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary outputs] (increment: 1)
Default: 0

Imp.length [ms] (once per represented output)

Enter the maximum duration of the output relay switching operation in the Imp.length [ms] text box. In function blocks with limit stops the switching operation ends before if necessary.

No. of cycles (once per represented output)

Not used.

Input No. [Name] (once per represented input)

Enter the number of the physical input that is to be represented in the Input No. text box. The assigned number, underlined, underlined in white, is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary inputs] (increment: 1)
Default: 0

Filtertime [ms] (once per represented input)

In the Filtertime [ms] text box enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Comment

Enter comments (for example purpose) on the switching object in the Comments text box. The text is also displayed in the FUPLA on the left side above the switching object.

Setting range: 0 ... 21 characters (standard character set)
Default: [Empty]

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

Use Two Step Switch Command

If two-stage switching is activated, a switching object must be selected with a command from the station control system and switched with a 2nd command. This option does not refer to local switching.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel


When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

Events

Click the **Events** button to open a dialog box. Select (activate) the events that are sent to the station control system over the field bus. The button is available only when the events function has been activated in the Global Settings.

4.3.2.5.

Switching Object 1-2



A051728

Fig. 4.3.2.5.-1 Function block Switching Object 1-2

Function

Switching Object 1-2 function block actuates a physical binary output from the function chart. The return confirmation is received via two physical binary inputs, which can be tapped in the function chart.

Connections

IL input is an interlocking input. A switching operation can only be conducted if there is a logical 1 here.

BL input is a blocking input. If there is a logical 1 signal here, the switching operations of the represented output are blocked.

PO input is a signaling input for a physical output. A logical signal to this function block input starts, if enabled, a corresponding switching operation of the represented output relay.

Time > output is a time monitor output. If a logical 1 can be tapped here, the set impulse time is expired and a return confirmation regarding the correct switching operation is no longer received over the represented binary input.

OP, CL outputs are signal outputs at which the binary input signal of the represented physical input can be tapped.

P output is a pulse output. A logical 1 can be tapped for the duration of the output relay switching operation.

Table 4.3.2.5.-1 Connection labels switching object 1-2

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
IL	-	IL
BL	-	BL
PO	Output No.	PO Active
TIME>	-	Time>
OP	Input No. open	BI open
CL	Input No. closed	BI closed
P	-	Pulse

Configuration

Switching Object 1-2

Field bus address

013

Output No.:

0

Imp.length[ms]:

100

No.of cycles:

0

Input No. open:

0

Filtertime[ms]

100

Input No. close:

0

Filtertime[ms]

100

☒ Indicate Intermediate Position

☐ Use Two Step Switch Command

☐ Invert inputs

Comment:

Pins

PO active:

1

BI open:

2

BI close:

2

IL:

1

Pulse:

2

BL:

1

Time >:

2

OK

Cancel

Events...

A051729

Fig. 4.3.2.5.-2 Configuration dialog box Switching Object 1-2

Field bus address

The Field bus address is automatically assigned so that every Field bus address is only used once. As an alternative the Field bus address can also be selected from the list which is displayed by clicking the < ▼ > button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)
Default: Next free Field bus address

Output No. [Name] (once per represented output)

Enter the number of the physical output that is to be represented to the Output No. text box. The assigned number, underlined in white, is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary outputs] (increment: 1)
Default: 0

Imp.length [ms] (once per represented output)

Enter the maximum duration of the output relay switching operation in the Imp. length [ms] text box. In function blocks with limit stops the switching operation is ended before if necessary.

No. of cycles (once per represented output)

Not used.

Input No. [Name] (once per represented input)

Enter the number of the physical input that is to be represented in the Input No. text box. The assigned number is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary inputs] (increment: 1)
Default: 0

Filvertime [ms] (once per represented input)

In the Filvertime [ms] textbox, enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Comment

Enter comments (for example purpose) on the switching object in the Comment text box. The text is also displayed in the FUPLA on the left above the switching object.

Setting range: 0 ... 21 characters (standard character set)
Default: [Empty]

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

Indicate Intermediate Position

If this check box is selected, an intermediate setting is displayed on the LCD screen during the switching operation. This enables a visual confirmation of the switching operation on the LCD. Otherwise only the initial and final positions are displayed during a switching operation.

Use Two Step Switch Command

If two-stage switching is activated, a switching object must be selected with a command from the station control system and switched with a 2nd command. This option does not refer to local switching.

OK


Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

Events

Click the **Events** button to open a dialog box. Select (activate) the events that are sent to the station control system over the field bus. The button is available only when the events function has been activated in the Global Settings.

4.3.2.6.**Switching Object 2-1**

A051730

Fig. 4.3.2.6.-1 Function block Switching Object 2-1

Function

Switching Objects 2-1 function block actuates two physical binary outputs from the function chart. The return confirmation is received via the physical binary input, which can be tapped in the function chart.

Connections

IL input is an interlocking input. A switching operation can only be conducted if there is a logical 1 here.

BL input is a blocking input. If there is a logical 1 signal here, the switching operations of the represented output are blocked.

OP, CL inputs are signaling inputs for one physical output each. A logical signal to this function block input starts, if enabled, a corresponding switching operation of the represented output relay.

Time > output is a time monitor output. If a logical 1 can be tapped here, the set impulse time is expired and a return confirmation regarding the correct switching operation is no longer received over the represented binary input.

BI output is a signal output at which the binary input signal of the represented physical input can be tapped.

P outputs are pulse outputs, one for each represented output. A logical 1 can be tapped for the duration of the switching operation of the output relay.

Table 4.3.2.6.-1 Connection labels switching object 2-1


FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
IL	-	IL open
IL	-	IL closed
BL	-	BL
OP	Output No. open	PO open
CL	Output No. close	PO closed
TIME>	-	Time>
BI	Input No.	BI
P	-	Pulse open
P	-	Pulse close

Configuration

A051731

Fig. 4.3.2.6.-2 Configuration dialog box Switching Object 2-1

Field bus address

The Field bus address is automatically assigned so that every Field bus address is only used once. As an alternative the Field bus address can also be selected from the list which is displayed by clicking the  button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)
Default: Next free Field bus address
Setting range for physical outputs: Every text box exists once per represented output.

Output No. [Name] (once per represented output)

Enter the number of the physical output that is to be represented to the Output No. text box. The assigned number, underlined in white, is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary outputs] (increment: 1)
Default: 0

Imp.length [ms] (once per represented output)

Enter the maximum duration of the output relay switching operation in the Imp. length [ms] text box. In function blocks with limit stops the switching operation is ended before if necessary.

No. of cycles (once per represented output)

Not used.

Input No. [Name] (once per represented input)

Enter the number of the physical input that is to be represented in the Input No. text box. The assigned number is also shown in the function block adjacent to the connection.

Setting range: 0 ... [number of binary inputs] (increment: 1)
Default: 0

Filtertime [ms] (once per represented input)

In the Filtertime [ms] text box, enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Comment

Enter comments (for example purpose) on the switching object in the Comment text box. The text is also displayed in the FUPLA on the left above the switching object.

Setting range: 0 ... 21 characters (standard character set)
Default: [Empty]

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

Use Two Step Switch Command

If two-stage switching is activated, a switching object must be selected with a command from the station control system and switched with a 2nd command. This option does not refer to local switching.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

Events

Click the **Events** button to open a dialog box. Select (activate) the events that are sent to the station control system over the field bus. The button is available only when the events function has been activated in the Global Settings.

4.3.2.7.

Switching Object 2-2




Fig. 4.3.2.7.-1 Function block Switching Object 2-2

A051732

Function

Switching Objects 2-2 function block actuates two physical binary outputs from the FUPLA. The reconfirmation is received via two physical binary inputs, which can be defined in the FUPLA. This switching object can also be used to actuate a circuit-breaker.

Connections

IL inputs are interlocking inputs, one per represented output. A switching operation can be conducted if a logical 1 is here.

BL input is a locking input. If there is a logical 1 signal here, the switching operations of the represented output are blocked.

OP, CL inputs (left) are FUPLA inputs for actuating each time the related physical output. A logical signal to this function block input starts, if enabled, a corresponding switching operation of the related output relay.

SYNCH. input is not a synchronized input. A closing operation is only allowed if a logical 0 signal is present at the input.

RES. GRANT input is a reservation grant input. A switching operation is only possible, if the logical 1 signal is present at the input. This input is normally used in connection with LON communication per LAG (LON Application Guide) version 1.4 as confirmation the reservation request.

Time > output is a time monitor output. If a logical 1 can be tapped here, the set impulse time is expired and a return confirmation regarding the correct switching operation is no longer received over the represented binary input.

OP, CL outputs (right): Channel definition of the signal outputs coming from the status information of the primary switching device.

P outputs are pulse outputs, one per represented output. A logical 1 can be tapped for the duration of the switching operation of the output relay

DEF OPEN output is a defined open output, which generates a logical 1 signal if the switching device has reached the definitive open position.

DEF CLOSE output is a defined close output, which generates a logical 1 signal if the switching device has reached the definitive close position.

DEF POS output is a defined Position output, which generates a logical 1 signal if the switching device has reached the definitive open or closed position.

ERROR POS output is an error position output, which generates a logical 1 signal if both open and close output has a logical 1 signal or if the switching operation is interrupted by overreaching the time monitor.

RES. REQ output is a reservation request output, which is normally used in connection with LON communication per LAG 1.4. Before starting the switching operation, a reservation request must be done by generating a logical 1 signal at this output.

Table 4.3.2.7.-1 Connection labels switching object 2-2

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
IL	-	IL open
IL	-	IL closed
BL	-	BL
OP (left)	Output No. open	PO open
CL (left)	Output No. close	PO closed
SYNCH.	-	NOT Synchronized
RES. GRANT	-	Reservation Granted
TIME OUT	-	Time Limit Expired
OP (right)	Input No. open	-
CL (right)	Input No. close	-
BI	Input No.	BI
P	-	Pulse pin open
P	-	Pulse pin close
DEF. OPEN	-	Defined open
DEF. CLOSE	-	Defined Closed
DEF. POS	-	Def Position
ERROR POS	-	Error Position
TIMEOUT	-	Time Limit Expired
RES. REQ	-	Reservation Request

Typical application

A typical application is the use of the binary outputs to actuate a motor-driven isolator. The position status confirmation signal is received via the two binary inputs.

Configuration

The following section describes several tabs in the Switching Object 2-2 configuration dialog box. In all the tabs there are **OK** or **Cancel** buttons.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A051733

Fig. 4.3.2.7.-2 General tab, function block Switching Object 2-2

Field bus address

The Field bus address is automatically assigned so that every Field bus address is only used once. As an alternative the Field bus address can also be selected from the list, which is displayed by clicking the < ▼ > button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)

Default: Next free Field bus address

Comment

Enter comments (for example purpose) on the switching object in the Comment text box. The text is also displayed in the FUPLA on the left side above the switching object.

Setting range: 0 ... 20 characters (standard character set)

Default: [Empty]

Kind of switching device

Select the check box corresponding to the switching device used.

Options

Under Options select the option required for displaying the switching operation on the LCD:

Indicate intermediate position

If the Indicate intermediate position check box is selected, an intermediate setting is displayed on the LCD screen during the switching operation. This enables a visual return confirmation of the switching operation on the LCD. Otherwise only the initial and final positions are displayed during a switching operation.

Enable two step command

If the Enable two step command check box is selected, two-stage switching is activated. The switching object must be selected with a command from the station automation system and switched with a 2nd command. This option does not refer to local switching.


Invert inputs

If the Invert inputs check box is selected, the logical signal of the inputs are is inverted.

Open/Close activated by

Select the signal used for the switching operation.

Outputs



A051734

Fig. 4.3.2.7.-3 Outputs tab, function block Switching Object 2-2

Output Open

Output

In the Output text box enter the number of the physical output that is to be represented. The assigned number is also shown in the function block adjacent to the connection.

Setting range: 0 ... 27 [number of binary outputs] (increment: 1)
Default: 0

Pulse length [ms]

In the Pulse length [ms] text box enter the maximum duration of the output relay switching operation. In function blocks with limit interrupts the switching operation if necessary.

Setting range: 0 ... 65000 (increment: 1)
Default: 100

Output Close

Output

In the Output text box enter the number of the physical output that is to be represented. The assigned number is also shown in the function block adjacent to the connection.

Setting range: 0 ... 27 [number of binary outputs] (increment: 1)
Default: 0

Pulse length [ms]

In the Pulse length [ms] text box enter the maximum duration of the output relay switching operation. In function blocks with limit interrupts the switching operation if necessary.

Setting range: 0 ... 65000 (increment: 1)
Default: 100

Switch cycles

In the Switch cycles text box enter the number of switching cycle during the reconfiguration of the REF 542plus device.

Setting range: 0 ... 65000 (increment: 1)
Default: 0

Inputs

Switching Object 2-2

General Outputs **Inputs** Events Pins

Position Indication: Open

Input 0 .. 42

Filter time 0 .. 65000 ms

Position Indication: Close

Input 0 .. 42

Filter time 0 .. 65000 ms

Response time 0 .. 65000 ms

Synchron time 0 .. 65000 ms

OK Cancel Apply

A051735

Fig. 4.3.2.7.-4 Inputs tab, function block Switching Object 2-2

Position Indication: Open

Input [Name]

In the Input text box enter the number of the physical input that is to be represented. The assigned number is shown in the function block adjacent to the connection.

Setting range: 0 ... 42 (increment: 1)
Default: 0

Filter time [ms]

In the Filter time text box enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Setting range: 0 ... 65000 (increment: 1)
Default: 100

Position Indication: Close

Input [Name]

In the Input text box enter the number of the physical input that is to be represented. The assigned number is shown in the function block adjacent to the connection.

Setting range: 0 ... 42 (increment: 1)
Default: 0

Filter time [ms]

In the Filter time text box enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Setting range: 0 ... 65000 (increment: 1)
Default: 100

Response time

In the Response time text box enter the maximum duration of the time for the granting the reservation.


Setting range: 0 ... 65000 (increment: 1)
Default: 100

Synchron time

In the Synchron time text box enter the maximum duration of the time for the synchronization of the closing operation.

Setting range: 0 ... 65000 (increment: 1)
Default: 100

Events



A080364

Fig. 4.3.2.7.-5 Events tab, function block Switching Object 2-2

The main part in the tab is the list of events. The channel number over which the events are sent is shown in the left column near to the check box. To enable the individual events to be transmitted to the substation automation system, transmission of events must be generally enabled.

The events of the function block Power Factor Controller must also be enabled. Mark the adjacent check box so the event is generated and sent as required.

Set All

Click the **Set All** button to select, generate and send all events as required.

Clear All

Click the **Clear All** button to clear the selection.

Set Default

Click the **Set Default** button to use the default configuration for events. The default configuration for events for each function object is defined in the associated *.rce file.

Save Default

Click the **Save Default** button to save the checked events in the associated *.rce file.

Event Masks E15 ... E0 and E31 ... E16


The selecting of events is also possible under Event Masks. The input must be in hexadecimal code. Refer to the following Table 4.3.2.7.-2 for the events E0 to E15. The input for the events from E16 to E31 is in principle similar. The events E28 to E31 are not used in this function block. If you select the check boxes in the list you can read the hexadecimal code in the text boxes.

Table 4.3.2.7.-2 shows an overview of the events of the function block Unbalanced Load Protection.

Table 4.3.2.7.-2 Switching Object 2-2

10	E0	Moving	E4	Error
10	E1	Input opened	E2	Input closed
10	E5	Output opened	E6	Output closed
10	E7	End position not reached started	E8	End position not reached back
10	E9	Output 2 opened	E10	Output 2 closed
10	E15	Blocked inactive	E16	Blocked active
10	E17	Interlocked inactive	E18	Interlocked active
10	E19	Synch. Bypass inactive	E20	Synch. Bypass active
10	E21	Selected back	E22	Selected started
10	E23	Bypass inactive	E24	Bypass active
10	E26	Select confirmation positive	E27	Select confirmation negative
10	E28	Execution confirmation positive	E29	Execution confirmation negative
10	E30	Execution termination positive	E31	Execution termination negative

Pins




A051737

Fig. 4.3.2.7.-6 Pins tab, function block Switching Object 2-2

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.2.8.

Switching Object 2-2 H-Bridge



Adr.:8

A051742

Fig. 4.3.2.8.-1 Function block Switching Object 2-2 H-Bridge



This switching object can only be used with the input/output board with solid state relays. One switching object 2-2 H-Bridge or 4-4 H-Bridge can be used in the application per board.

Function

The Switching Object 2-2 H-Bridge function block is used to actuate four binary physical outputs, which are specially designed for the motor control unit. The required return confirmations are received via the three physical binary inputs. Only two of the four physical outputs in use can be actuated. The other two are used to implement the wanted functions and are actuated internally.

Connections

IL inputs are interlocking inputs, one per represented output. A switching operation can be conducted if there is a logical 1 here.

BL input is a blocking input. If there is a logical 1 signal here, the switching operations of the represented output are blocked.

LINE, EARTH inputs (left) are signaling inputs for one physical output each. A logical signal to this function block input starts, if enabled, a corresponding switching operation of the represented output relay. The unlabelled inputs cannot be influenced; their function is implemented over the relay circuitry.

RES. GRANT inputs are reservation grant inputs. A switching operation is only possible if the logical 1 signal is present at the input. This input is normally used in connection with LON communication per LAG 1.4 as confirmation of the reservation request.

Time > output is a time monitor output. If a logical 1 can be tapped here, the set impulse time is expired and a return confirmation regarding the correct switching operation is no longer received over the represented binary input.

LINE, EARTH outputs (right) are signal outputs at which the binary input signal of the represented physical input can be tapped.

PP outputs are pulse outputs, one per represented output. A logical 1 can be tapped for the duration of the switching operation of the output relay.

RES. REQ output is a reservation request output, which is normally used in connection with LON communication per LAG 1.4. Before starting the switching operation, a reservation request must be done by generating a logical 1 signal at this output.

Table 4.3.2.8.-1 Connection labels Switching Object 2-2 H-Bridge

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
IL (EARTH)	-	IL earth
IL (LINE)	-	IL line
EARTH (left)	Earth	Earth
LINE (left)	Line	Line
BL	-	BL

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
EARTH (right)	Input No. earth	BI earth
LINE (right)	Input No. line	BI line
RES. GRANT	-	Reservation granted
TIME >	-	Timeout
VALID	-	Valid Position
RES. REQ	-	Reservation Request

Typical application

This switching object can be used to control a motor-driven transfer switch without an intermediate setting. This functions with special circuitry of two relays on the binary input/output board with solid state relays.

Configuration

The following section describes several tabs in the Switching Object 2-2 H-Bridge dialog box. In all tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.


General



A051743

Fig. 4.3.2.8.-2 General tab , function block Switching Object 2-2 H-Bridge

Field bus address

The Field bus address is automatically assigned so that every Field bus address is used only once. As an alternative the Field bus address can also be selected from the list, which is displayed by clicking the  button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)
Default: Next free Field bus address

Comment

Enter comments (for example purpose) on the switching object in the Comments text box. The text is also displayed in the FUPLA on the left side above the switching object.

Setting range: 0 ... 20 characters (standard character set)
Default: [Empty]

Options

Under Options select the option required for displaying the switching operation on the LCD:

Indicate intermediate position

If the Indicate intermediate position check box is selected, an intermediate setting is displayed on the LCD screen during the switching operation.


Enable two step command

If the Enable two step command check box is selected, the two-stage switching is activated and a switching object must be selected with a command from the station automation system and switched with a 2nd command. This option does not refer to local switching.

Invert inputs

If the Invert inputs check box is selected, the logical signal of the inputs is inverted.

Parameter



A051744

Fig. 4.3.2.8.-3 Parameters tab, function block Switching Object 2-2 H-Bridge

Brake Time

In the Brake Time text box enter a time in ms for which the motor windings are short-circuited to brake the motor after reaching the end position.

Setting range: 0 ... 65 000 ms (increment: 1 ms)
Default: 100

Waiting Time


In the Waiting Time text box enter a time in ms during which no switching command can be sent to prevent overloading the transistors on the input/output board and the motor.

Setting range: 2 000 ... 65 000 ms (increment: 1 ms)
Default: 2 000

MaxTimeToGrant

In the MaxTimeToGrant text box enter a time in ms during which the reservation of the switching operation in connection with the LON Communication per LAG 1.4 is granted.

Outputs



A051745

Fig. 4.3.2.8.-4 Outputs tab, function block Switching Object 2-2 H-Bridge


No. of Cycles (available twice)

Not used.

Pulse Length

In the Pulse Length text box enter the maximum duration of the output relay switching operation. In function blocks with limit stops the switching operation ends before if necessary.

Inputs



A051746

Fig. 4.3.2.8.-5 Inputs tab, function block Switching Object 2-2 H-Bridge

Input Settings Line/Earth

The number of the represented physical output is a fixed assignment.

Setting range: 0 ... [number of binary outputs] (increment: 1)

Default: 0

Input No. [Name] (once per represented input)

In the Input No. [Name] text box enter the number of the physical input to be represented. The assigned number is also shown in the function block adjacent to the connection.


Setting range: 0 ...42 [number of binary inputs] (increment: 1)

Default: 0

Filtertime [ms] (once per represented output)

In the Filtertime [ms] enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Events



A051747

Fig. 4.3.2.8.-6 Events tab, function block Switching Object 2-2 H-Bridge

Set All

Click the **Set All** button to select, generate and send all events as required.

Clear All

Click the **All** button to clear the selection.

Set Default

Click the Set Default button to use the default configuration for events. The events 0 ... 7, 18, 19 and 24 ... 27 are selected.

Event Masks E15 ... E0 and E31 ... E16


The selecting of events is also possible under Event Masks. The input must be in hexadecimal code. Refer to the following table for the events E0 to E15. The input for the events from E16 to E31 is in principle similar. The events E28 to E31 are not used in this function block. If you select the check boxes in the list you can read the hexadecimal code in the text boxes.

The following Table 4.3.2.8.-2 shows an overview of the events of the function block Unbalanced Load Protection.

Table 4.3.2.8.-2 Switching Object 2-2

8	E0	Switch Position Intermediate	E4	Switch Position Error
8	E1	Switch Position Open	E2	Switch Position Closed
8	E9	Command timeout inactive	E10	Command timeout active
8	E13	Interlocking error left	E14	Interlocking error right
8	E15	Blocked inactive	E16	Blocked active
8	E17	Interlocked inactive	E18	Interlocked active
8	E21	Selected inactive	E22	Selected active
8	E23	Interlocking bypass inactive	E24	Interlocking bypass active
8	E26	Select confirmation positive	E27	Select confirmation negative
8	E28	Execution confirmation positive	E29	Execution confirmation negative
8	E30	Execution termination positive	E31	Execution termination negative

Pins




A051748

Fig. 4.3.2.8.-7 Pins tab, function block Switching Object 2-2 H-Bridge

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.2.9.

Switching Object 4-4 H-Bridge



A051749

Fig. 4.3.2.9.-1 Function block Switching Object 4-4 H-Bridge



This switching object can only be used with the binary input output board with solid state relays. One switching object 2-2 H-Bridge or 4-4 H-Bridge can be used in the application per board.

Function

The function block Switching Object 4-4 H-Bridge is used to actuate four binary physical outputs, which are specially designed for the motor control unit. The required return confirmations are received via the five physical binary inputs. The function block itself assumes the subsequent sequential control.

The VALID signaling output signals a valid position of the 3-position switch:

- Earth switch closed
- Intermediate setting (earth switch and line open)
- Line opened.

The valid position is reached when the pulse outputs are logical 0 and the binary inputs signal is in one of the three positions above.

The binary input SUP/earth switch supervision enables sensors that also supervise the all-pole correct earthing to be connected. If this binary input is not used, the connection pin on the function block must be set to logical 1 or connected with the earth switch OFF connection pin.

Connections

IL inputs are interlocking inputs, one per represented output. A switching operation can be conducted if there is a logical 1 here.

BL input is a blocking input. If there is a logical 1 signal here, the switching operations of the represented output are blocked.

BO: Earth switch ON/OFF, BO: Line ON/OFF inputs (left) are signaling inputs for one physical output each. A logical signal to this function block input starts, if enabled, a corresponding switching operation of the represented output relay. The unlabelled inputs cannot be influenced; their function is implemented over the relay circuitry.

TIME> output is a time monitor output. If a logical 1 can be tapped here, the set impulse time is expired and a return confirmation regarding the correct switching operation is no longer received over the represented binary input.

RES. GRANT inputs are reservation grant inputs. A switching operation is only possible if the logical 1 signal is present at the input. This input is normally used in connection with LON communication per LAG 1.4 as confirmation of the reservation request.

BI: Earth switch ON/OFF, BI: Line ON/OFF outputs (right) are signal outputs at which the binary input signal of the represented physical input can be tapped.

PP RIGHT/PP LEFT outputs are pulse outputs, one per represented output. A logical 1 can be tapped for the duration of the switching operation of the output relay PP RIGHT is the pulse output for the busbar–intermediate setting–earth movement direction and PP LEFT is the pulse output for the earth–intermediate setting–busbar movement direction.

VALID output is a signaling output. If a logical 1 can be tapped here, the 3-position switch has reached a valid position.

SUP is a signaling output for a physical input. It is used for additional supervision of the position earth switch all-pole closed.

RES. REQ outputs are reservation request outputs, which are normally used in connection with LON communication per LAG 1.4. Before starting the switching operation, a reservation request must be done by generating a logical 1 signal at this output.

Table 4.3.2.9.-1 Connection labels switching object 4-4 H-Bridge

FUPLA display	Parameter setting range of the configuration dialog box	Connection label in the configuration dialog box
BL	-	Block
IL	-	IL close Earth
IL	-	IL open earth
IL	-	IL close line
IL	-	IL open line
BO: Earthswitch ON	Earth close	Close earth
BO: Earthswitch OFF	Earth open	Open earth
BO: Line ON	Line close	Close line
BO: Line OFF	Line open	Open line
RES. GRANT	-	Reservation granted
PP right	-	PP right
PP left	-	PP left
RES. GRANT	-	Reservation granted
TIME >	-	Timeout
VALID	-	Valid Position
BI: Earth switch ON	Earth closed	BI Earth closed
BI: Earth switch OFF	Earth opened	BI Earth opened
BI: Line ON	Line closed	BI Line opened
BI Line OFF	Line opened	BI line closed
SUP	Earth switch supervision	Earth supervision
RES. REQ	-	Reservation Request

Typical application

The Switching Object 4-4 H-Bridge function block enables a 3-position switch to be actuated with a motor drive. Additional auxiliary relays for activating and deactivating the motor are not required. Information on the switch status is received via three freely configurable binary inputs. The switching object assumes the subsequent control sequences:

- Checks the interlock conditions
- Switches on pole reversal relay, depending on selection
- Switches on motor relay
- Switches off motor relay after reaching the end position
- Brakes motor by short circuiting the motor windings
- Activates timing circuit for dead time

Switching Object 4-4 H-Bridge functions with special circuitry of two relays on the binary input/output board with conventional relays.

A 3-position isolator is represented by two separate objects (isolator and earth switch) on the HMI LCD, which are then configured as a combined object.

Configuration

The following section describes several tabs in the Switching Object 4-4 H-Bridge dialog box. In all tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.


General



A051750

Fig. 4.3.2.9.-2 General tab, function block Switching Object 4-4 H-Bridge

Field bus address

The Field bus address is automatically assigned so that every Field bus address is used only once. As an alternative the Field bus address can also be selected from the list, which is displayed by clicking the  button.

Setting range: 5 ... 49 and 111 ... 127 (increment: 1)
Default: Next free Field bus address

Comment

Enter comments (for example purpose) on the switching object in the Comments text box. The text is also displayed in the FUPLA on the left side above the switching object.

Setting range: 0 ... 20 characters (standard character set)
Default: [Empty]

Options

Under Options select the option required for displaying the switching operation on the LCD:

Indicate intermediate position

If the Indicate intermediate position check box is selected, an intermediate setting is displayed on the LCD screen during the switching operation.


Enable two step command

If the Enable two step command check box is selected, the two-stage switching is activated and a switching object must be selected with a command from the station automation system and switched with a 2nd command. This option does not refer to local switching.

Invert inputs

If the Invert inputs check box is selected, the logical signal of the inputs is inverted.

Parameters



A051753

Fig. 4.3.2.9.-3 Parameters tab, function block Switching Object 4-4 H-Bridge

Brake Time

In the Brake Time text box enter a time in ms for which the motor windings are short-circuited to brake the motor after reaching the end position.

Setting range: 0 ... 65 000 ms (increment: 1 ms)

Default: 100

Waiting time

In the Waiting Time text box enter a time in ms during which no switching command can be sent to prevent overloading the transistors on the input/output board and the motor.


Setting range: 2 000 ... 65 000 ms (increment: 1 ms)

Default: 2 000

MaxTimeToGrant

In the MaxTimeToGrant text box enter a time in ms during which the reservation of the switching operation in connection with the LON Communication per LAG 1.4 is granted.

Outputs



A051754

Fig. 4.3.2.9.-4 Outputs tab, function block Switching Object 4-4 H-Bridge

Earth close/open, Line close/open

The number of the represented physical output is a fixed assignment.

Setting range: 0 ... [number of binary outputs] (increment: 1)

Default: 0


No. of Cycles (once per represented output pair)

Not used.

Pulse Length (once per represented output pair)

Enter the maximum duration of the output relay switching operation in the Pulse Length text box. In the function blocks with limit stops the switching operation ends before if necessary.

Inputs



A051755

Fig. 4.3.2.9.-5 Inputs tab, function block Switching Object 4-4 H-Bridge

Earth/Line closed/opened input (once per represented input)


Enter the number of the physical input that is to be represented. The assigned number, underlined in white, is also shown in the function block adjacent to the connection.

Setting range: 0 ... 42 [number of binary inputs] (increment: 1)
Default: 0

Filter time [ms] (once per represented output)

In the Filter time [ms] enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Inputs



A051756

Fig. 4.3.2.9.-6 Inputs tab, function block Switching Object 4-4 H-Bridge


Input

Enter a 0 (zero) as number of the represented input so that the earth switch supervision (SUP) binary input is not used.

Filter time [ms] (once per represented output)

In the Filter time [ms] enter the time during which a signal must be applied at the physical binary input to be detected as a logical signal. The input filter time is added to the hardware and to the general filter time.

Events



A080240

Fig. 4.3.2.9.-7 Events tab, function block Switching Object 4-4 H-Bridge

The main part in the Events tab is the list of events. The channel number over which the events are sent is shown in the left column near to the check box. To enable the individual events to be transmitted to the substation automation system, transmission of events must be generally enabled.

The events of the function block Power Factor Controller must also be enabled. Mark the adjacent check box so the event is generated and sent as required.

Set All

Click the **Set All** button to select, generate and send all events as required.

Clear All

Click the **Clear All** button to clear the selection.

Set Default

Click the **Set Default** button to use the default configuration for events. The default configuration for events for each function object is defined in the associated *.rce file.

Save Default

Click the **Save Default** button to save the checked events in the associated *.rce file.

Event Masks E15 ... E0 and E31 ... E16


The selecting of events is also possible under Event Masks. The input must be in hexadecimal code. Refer to the following table for the events E0 to E15. The input for the events from E16 to E31 is in principle similar. The events E28 to E31 are not used in this function block. If you select the check boxes in the list you can read the hexadecimal code in the text boxes.

The following Table 4.3.2.9.-2 shows an overview of the events of the functionblock Unbalanced Load Protection.

Table 4.3.2.9.-2 Switching Object 4-4 H Bridge

Event	Text	Event	Text
E0	Disc. Pos. Intermediate	E16	Blocked active
E1	Disc. Pos. Closed	E17	Disc. Interlocked inactive
E2	Disc. Pos. Opened	E18	Disc. Interlocked active
E3	not selectable	E19	Earth interlocked inactive
E4	Disc. Pos. Error	E20	Earth interlocked active
E5	Earth Pos. Intermediate	E21	Selected inactive
E6	Earth Pos. Closed	E22	Selected active
E7	Earth Pos. Opened	E23	Interlock bypass inactive
E8	Earth Pos. Error	E24	Interlock bypass active
E9	Command timeout inactive	E25	not selectable
E10	Command timeout active	E26	Select confirmation positive
E11	not selectable	E27	Select confirmation negative
E12	not selectable	E28	Execution confirmation positive
E13	Interlocking error left	E29	Execution confirmation negative
E14	Interlocking error right	E30	Execution termination positive
E15	Blocked inactive	E31	Execution termination negative

Pins




A051758

Fig. 4.3.2.9.-8 Pins tab, function block Switching Object 4-4 H-Bridge

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.2.10.

Module for truck (withdrawal unit)



A051759

Fig. 4.3.2.10.-1 Function block Module for truck

Function

The Module for truck function block is used to move or hide switch symbols on the LCD. Fixed symbols (transducers, motors, generators and so on) cannot be hidden or moved because they do not have a unique Field bus address.

The switch symbol interconnections on the LCD screen with the switching objects in the function chart are shown with the Field bus address. In the same way, the function block module for thrust is linked to the switching symbol that is to be moved or hidden with the Field bus address.

Connections

If the Jump (move) input is set to logical 1, a symbol on the LCD is moved 11 pixels to the left. If the input is set to logical 0 again, the symbol on the LCD resumes its initial position.


If the Disapp. input is set to logical 1 again, the symbol on the LCD is hidden. If the input is set to logical 0 again, the symbol on the LCD becomes visible again.

Typical application

If the power circuit-breaker is on a trolley (thrust), it must also be possible to show its end positions on the LCD. The power circuit breaker symbol must be correctly displayed depending on the current position of the thrust (operating or test position).

In addition, if the power circuit-breaker is no longer connected with the other secondary technology, this status must be shown on the LCD. For example, this occurs when the symbol is hidden.

Configuration



A051760

Fig. 4.3.2.10.-2 Configuration dialog box function block Module for truck

Field bus address

Click the < ▼ > button to open a list of the Field bus addresses used in the function chart. Select the Field bus address of the switching object whose symbol is to be moved on the LCD screen.

Jump/Disappear


The connections of the function block with the connection number connected to it are shown here. Inputs are not possible. If there are yet no connections on the function block, connection number 1 is displayed. It indicates an input.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.3.2.11.**IO-Supervision**

A051761

Fig. 4.3.2.11.-1 Function block IO-Supervision

Function

The IO-Supervision function block provides messages from the trip circuit supervision to the function chart. The REF 542plus Global Settings referring to trip circuit supervision and the FUPLA are linked in this way. The single messages can be blocked independently of one another. In addition, the entire function block can be blocked; a signal regarding that can be tapped at one of its outputs. The error messages from the trip circuit supervision cannot be suppressed on the LCD screen.

Up to two output channels can be monitored for the first two binary input/output boards (cards). The trip circuit supervision must be activated in the Global Settings of the configuration software for every channel.

Connections

Because the labeling of the inputs and outputs is partly abbreviated in the function block and in the configuration dialog box, the list below explains the abbreviation further if necessary.

BCS11/Bl.Ca.1 Co.1 input	Blocking Coil Supervision 11/blocking board 1 coil 1	If a logical 1 is set on this channel, the output signal is blocked and the supervision function of this coil is generated.
BCS12/Bl.Ca.1 Co.2 input	Blocking Coil Supervision 12/blocking board 1 coil 2	If a logical 1 is set on this channel, the output signal is blocked and the supervision function of this coil is generated.
BCS21/Bl.Ca.2 Co.1 input	Blocking Coil Supervision 21/blocking board 2 coil 1	If a logical 1 is set on this channel, the output signal is blocked and the supervision function of this coil is generated.
BCS22/Bl.Ca.2.Co.2 input	Blocking Coil Supervision 22/blocking board 2 coil 2	If a logical 1 is set on this channel, the output signal is blocked and the supervision function of this coil is generated.
BCS31/Bl.Ca.3 Co.1 input	Blocking Coil Supervision 31/blocking board 3 coil 1	If a logical 1 is set on this channel, the output signal is blocked and the supervision function of this coil is generated.
BCS32/Bl.Ca.3.Co.2 input	Blocking Coil Supervision 32/blocking board 3 coil 2	If a logical 1 is set on this channel, the output signal is blocked and the supervision function of this coil is generated.
B.A.S./Bl. active superv. input	Blocking Active Supervision/blocking input switch supervision	If a logical 1 is applied to this connection, switch supervision is deactivated.
Coil supervision Card1 Coil1/St. Ca.1 Co.1 output	Start board 1 coil 1	If a logical 1 can be tapped at this output, the trip circuit supervision for the corresponding coil has detected an error.
Coil supervision Card1 Coil2/St. Ca.1 Co.2 output	Start board 1 coil 2	If a logical 1 can be tapped at this output, the trip circuit supervision for the corresponding coil has detected an error.
Coil supervision Card2 Coil1/St. Ca.2 Co.1 output	Start board 2 coil 1	If a logical 1 can be tapped at this output, the trip circuit supervision for the corresponding coil has detected an error.
Coil supervision Card1 Coil2/St. Ca.2 Co.2 output	Start board 2 coil 2	If a logical 1 can be tapped at this output, the trip circuit supervision for the corresponding coil has detected an error.
Coil supervision Card3 Coil1/St. Ca.3 Co.1 output	Start board 3 coil 1	If a logical 1 can be tapped at this output, the trip circuit supervision for the corresponding coil has detected an error.
Coil supervision Card3 Coil2/St. Ca.3 Co.2 output	Start board 3 coil 2	If a logical 1 can be tapped at this output, the trip circuit supervision for the corresponding coil has detected an error.
Active Supervision/St. active superv. output	Start switch supervision	If a logical 1 can be tapped at this output, the switch supervision is operating. If a logical 0 can be tapped, the switch supervision is not active because it has been blocked via the B.A.S. input.

Typical application

The trip-circuit supervision can be used to detect defective trip solenoids on the power circuit-breaker. For example, the return confirmation over the function block trip-circuit supervision can be used to generate an event for a station control system. Interlocking of the power circuit-breaker is also possible.

Configuration

Only the function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible. The names of the connections in the configuration dialog box are German and in the FUPLA display English. Both labels can be found in the connection description.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.


4.3.3.

Digital logic 1

The following sections describe the function blocks that are available in **Drawing Menu > Insert > Digital Logic 1**.

4.3.3.1.

Inverter



A051762

Fig. 4.3.3.1.-1 Function block Inverter

Function

The Inverter function block inverts the input signal and sends it to its output.

Table 4.3.3.1.-1 Logic table

On	Off
1	0
0	1


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.3.2.

Constant 1/Constant 0



A051763

Fig. 4.3.3.2.-1 Function blocks Constant 1 and Constant 0

Function

The two function blocks continuously send a logical 0 and a logical 1 respectively to their outputs.

Table 4.3.3.2.-1 Logic table

Constant 0 Output	Constant 1 Output
0	1


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.3.3.

AND logic gate with inverting output



A051764

Fig. 4.3.3.3.-1 Function block AND logic gate with inverting output

Function

The AND logic gate inverts the output signal. Otherwise, the function is identical to the standard AND logic gate.

Table 4.3.3.3.-1 *Logic table*

On 1	On 2	Off
0	0	1
0	1	1
1	0	1
1	1	0


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.3.4.

AND logic gate with an inverting input



A051765

Fig. 4.3.3.4.-1 Function blocks AND logic gate with an inverting inputs

Function

AND logic gates have all an inverting input. Because only the inverted input is changed, only one function block is described here.


Table 4.3.3.4.-1 *Logic table*

On 1	On 2	Off
0	0	0
0	1	1
1	0	0
1	1	0

Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.3.5.**AND logic gate**

A051766

Fig. 4.3.3.5.-1 Function blocks AND logic gate with varying input number

Function

The AND logic gates execute a logical AND interconnection on their inputs (left on the function block). The result of this logical operation is available on the output (right on the function block). Therefore a logical 1 is displayed on the output when all inputs are set to logical 1.

The AND logic gates above differ only in the number of inputs.

Table 4.3.3.5.-1 Logic table

On 1	On 2	Off
0	0	0
0	1	0
1	0	0
1	1	1

The logic Table 4.3.3.5.-1 shows as an example the function of the AND logic gate with two inputs.


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.3.6.

OR logic gate



A060035

Fig. 4.3.3.6.-1 Function blocks OR logic gate with varying output numbers

Function

The OR logic gates execute a logical OR interconnection of their inputs (left on the function block). The result of this logical operation is available on the output (right on the function block).

Therefore a logical 1 is displayed on the output when one of the inputs is set to logical 1.

The OR logic gates above differ only in the number of inputs.

Logic table

The following logic Table 4.3.3.6.-1 shows as an example the function of the OR logic gate with two inputs.


Table 4.3.3.6.-1 Function of the OR logic gate

On 1	On 2	Off
0	0	0
0	1	1
1	0	1
1	1	1

Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.3.7.**OR logic gate with inverting output**

A060036

Fig. 4.3.3.7.-1 Function block OR logic gate with inverting output (NOR logic gate)

Function

This OR logic gate inverts the output signal. Otherwise, the function is identical to the standard OR logic gate.

Table 4.3.3.7.-1 OR logic gate with inverting output

On 1	On 2	Off
0	0	1
0	1	0
1	0	0
1	1	0

Configuration


The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.4.**Digital logic 2**

The following sections describe the function blocks that are available in Drawing Menu/Insert/Digital Logic 2.

4.3.4.1.

Exclusive OR logic gate

A060037

Fig. 4.3.4.1.-1 Function block exclusive OR logic gate with varying input number

Function

The exclusive OR logic gates execute a logical exclusive OR interconnection of their inputs (left on the function block). The result of this logical operation is available at the output (right on the function block).

Therefore a logical 1 is displayed at the output when at least one of the inputs is set to logical 1. In contrast to the OR logic gate, a logical 0 is displayed on the output if all inputs are set to logical 1. The exclusive OR logic gates shown in Fig. differ only in the number of inputs.

Logic table

The following logic Table 4.3.4.1.-1 shows as an example the function of the exclusive OR logic gate with two inputs.


Table 4.3.4.1.-1 Exclusive OR logic gate with two inputs

On 1	On 2	Off
0	0	0
0	1	1
1	0	1
1	1	0

Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.4.2.**Exclusive OR logic gates with inverting output**

A060038

Fig. 4.3.4.2.-1 Function block exclusive OR logic gate with inverting output and varying number of inputs

Function

The exclusive OR logic gates with inverting output execute a logical exclusive OR interconnection of their inputs (left on the function block). The result of this logical operation is available in inverted form at the output (right on the function block).

Therefore, a logical 1 is displayed at the output if all inputs are set to logical 0 or logical 1. In contrast to OR logic gates with inverting output, a logical 1 is displayed at the output if all inputs are set to logical 1.

Logic table

The following logic table 4.3.4.2.-1 shows as an example the function of the exclusive OR logic gate with two inputs.

Table 4.3.4.2.-1 Exclusive OR logic gate with two inputs

On 1	On 2	Off
0	0	1
0	1	0
1	0	0
1	1	1

Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.5.**Flip-Flops**

The following sections describe the function blocks that are available in **Drawing Menu > Insert > Flip-Flops**.


Flip-Flops are memory elements with two stable states. Switching between the states is referred to as toggling. A suitable actuation (depending on the type of flip-flop) switches it to the other state. Because this state remains effective at the outputs of the flip-flop if there are no input signals, they are referred to as memory elements. Some flip-flops are also actuated by a timing input.

To enable the time sequence to be taken into account in the logic tables as well, a time before toggling the flip-flop (t_n) and a time after toggling (t_{n+1}) are defined. Therefore, output signals before toggling are labeled Q_n and Q_{n+1} after toggling.

If the flip-flop has also a timing input, the state before the timing input is labeled index n and the state after the timing input as index $n+1$. The change of state at the timing input from logical 0 to logical 1 or vice versa is decisive for the switching process. It is referred to as the rising or falling slope.

4.3.5.1.

R-S Flip-Flop



A060039

Function

A logical 1 at the S-input results in a logical 1 at the Q-output. A logical 1 at the R-input results in a logical 0 at the Q-output.

If the input signals are reset to logical 0, the signals remain active at the outputs. If both inputs are at logical 1, the R-input is dominant. However, this state contradicts the basic flip-flop principle of two stable states and must therefore be avoided.

Logic table

Q_{inverted} is not included in the following Table 4.3.5.1.-1 because the state is always opposite to Q.

Table 4.3.5.1.-1 Logic table

R	S	Q
0	0	Q_n
0	1	1
1	0	0
1	1	0


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.5.2.

R-S Flip-Flop with timing input (clock)



A060040

Fig. 4.3.5.2.-1 Function block RS Flip-Flop with timing input

Function

A logical 1 at the S-input combined with a rising slope at the timing input (C) results in a logical 1 at the Q-output. A logical 1 at the R-input combined with a rising slope at the timing input (C) results in a logical 0 at the Q-output.

If the input signals are reset to logical 0, the signals on the outputs remain active if there is no longer a rising slope at the timing input. With the rising slope the signals at the inputs are input.

If both inputs are at logical 1, both outputs are at logical 1 with the rising slope at the timing input. However, this state contradicts the basic flip-flop principle of two stable states and therefore must be avoided.

Logic table

$Q_{inverted}$ is not included in the following Table 4.3.5.2.-1 because the state is always set opposite to Q.
 t_n is the time before the rising slope at the timing input
 t_{n+1} is the time after it.

Table 4.3.5.2.-1 Logic table

tn		tn+1	
R	S	Q	Remark
0	0	Qn	
0	1	0	
1	0	1	
1	1	-	Illegal state


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.5.3.

J-K Flip-Flop



A060041

Fig. 4.3.5.3.-1 Function block J-K Flip-Flop with timing input (clock)

Function

A logical 1 at the J-input (logical 0 at the K-input) combined with a falling slope at the timing input (C) results in a logical 1 at the Q-output. A logical 1 at the K-input (logical 0 at the J-input) combined with a falling slope at the timing input (C) results in a logical 0 at the Q-output.

If the input signals are reset to logical 0, the signals remain active at the outputs regardless of the timing input.

If both inputs are at logical 1, the signals on the two outputs with the falling slope are inverted at the timing input.

Logic table

Q_{inverted} is not included in the following Table 4.3.5.3.-1 because the state is always set opposite to Q.

t_n is the time before the falling slope at the timing input.

t_{n+1} is the time after it.

Table 4.3.5.3.-1 Logic table

t_n		t_{n+1}	
J	K	Q	Remark
0	0	Q_n	The prior state remains
0	1	0	
1	0	1	
1	1	Q_n	The prior state is inverted


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.5.4.

D Flip-Flop



A060042

Fig. 4.3.5.4.-1 Function block D Flip-Flop

Function

The signal at the D-input of the flip-flop is transferred with the next positive slope of the Q-output. The timing pulses (clock) cause a delayed output of the input signal on the output.

Logic table

$Q_{inverted}$ is not included in the following table because the state is always set opposite to Q.
 t_n is the time before the rising slope at the timing input and
 t_{n+1} is the time after it.

t_n	t_{n+1}
D	Q
0	0
1	1


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.5.5.

T Flip-Flop



A060043

Fig. 4.3.5.5.-1 Function block T Flip-Flop

Function

The signals at the outputs are inverted with the positive slope at the timing input T. Q is logical 0 as the output state, to ensure that there is a defined state during the REF 542plus starting procedure. The signal at the output is always opposite to the signal at the output Q.

This enables the T flip-flop to operate as a binary divider; the period duration of the signals at the outputs is double the length of the clock at the T-input. A constant frequency clock signal is required.


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.5.6.

Monoflop retriggerable



A060044

Fig. 4.3.5.6.-1 Function block Monoflop retriggerable

Function

The logical value at the D-input is directly incorporated (in practice with its own rising slope) on the Q-output. It remains there for the configurable time. Finally, the output falls back to the only stable state of logical 0 again. The Q-output is set immediately to logical 0 by a logical 1 on the reset input (RES or K). If a rising slope occurs at the D-input again while the output is also still at logical 1, the timing circuit is restarted.

The signal at the inverted is always opposite to the signal at the output Q.

Configuration

Time [ms]

Enter the time in ms in the Time text box for which the output signal should be kept after a rising slope of the input signal.

Setting range: 15 ... 65 000 ms (increment: 1 ms)
Default: 15

Pins

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.3.5.7.**Monoflop non-retriggerable**

A060045

Fig. 4.3.5.7.-1 Function block Monoflop non-retriggerable

Function

The logical value at the D-input is directly incorporated (in practice with its own rising slope) on to the Q-output. It remains there for the configurable time. Finally, the output falls back to the only stable state of logical 0 again. The Q-output is set immediately to logical 0 by a logical 1 on the reset input (RES or K). If a rising slope occurs at the D-input again while the output is also still at logical 1, this signal is ignored.

The signal at the inverted is always opposite to the signal at the output Q.

Configuration**Time [ms]**

Enter the time in ms in the Time text box for which the output signal should be kept after a rising slope of the input signal.

Setting range: 15 ... 65 000 ms (increment: 1 ms)

Default: 15

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

OK


Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.3.5.8.

Drop Delay/Rise Delay (slope delay)



A060046


Fig. 4.3.5.8.-1 Function blocks slope delay: rising and falling

Function

Drop Delay and Rise Delay function blocks delay the falling and rising slope of a logical signal at the input (left connection).

The delayed logical signal is then available at the output (right connection). The delay period can be input in the configuration dialog box.


The following Fig. 4.3.5.8.-2 shows how the two function blocks operate.



A060047

Fig. 4.3.5.8.-2 Flow chart of the slope delay function blocks

Configuration dialog box



A060048

Fig. 4.3.5.8.-3 Configuration dialog box slope delay rising (and falling)

The setting options are identical in both configuration dialog boxes. Only the name of the function block in the window's title bar is different.

Time [ms]

Enter the delay period in ms in the Time [ms] text box. The rising/falling slope of the output signal is delayed for this period relative to the input signal. The input period is also shown in the function chart below the FUPLA symbol.

Setting range: 15 ... 65 000 ms (increment: 1 ms)
Default: 15

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

OK


Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.3.5.9.

Counter



A060049


Fig. 4.3.5.9.-1 Function block Counter

Function

The function block Counter puts a logical 1 on its output (right on the function block) after a preset No. of cycles have been sent to its CLOCK input (timing input, left on the function block). The output is set with the rising slope of the last required input impulse.

If a logical 1 is set to the RESET input (left on the function block), the output is reset to logical 0 or the counting process is stopped and the internal counter is set to 0.

Configuration dialog box



A060050

Fig. 4.3.5.9.-2 Configuration dialog box Counter

Number

Enter the number of input impulses required to generate a logical 1 at the output of the function block (right on the FUPLA symbol). The rising slopes of the input signal are decisive for the function block. The number is also shown in the function chart below the FUPLA symbol.

Setting range: 0 ... 65 000 ms (increment: 1 ms)

Default: 0

Pins


Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.


4.3.5.10.**Pulse generator**

A060051

*Fig. 4.3.5.10.-1 Function block Pulse generator***Function**

The function block Pulse generator sends a pulse sequence at its output (right on the function block). Logical 1 and logical 0 values alternate in this process. Their duration can be set in the configuration dialog box.

The following Fig. 4.3.5.10.-2 shows the setting options for the pulse generator.




A060052

*Fig. 4.3.5.10.-2 Output signal of the Pulse generator***Output (right on the function block)**

The generated pulse sequence can be tapped here.

Configuration



A060053

Fig. 4.3.5.10.-3 Configuration dialog box Pulse generator

High Time [ms]

The duration in ms of the logical 1 impulse (t_{ON}) is entered in the High Time [ms] text box. The input period is also visible in the FUPLA below the function block.

Setting range: 15 ... 65 000 ms (increment: 1 ms)

Default: 15

Low time [ms]

The duration in ms of the logical 0 impulse (t_{OFF}) is entered in the Low Time [ms] text box. The input period is also visible in the FUPLA below the function block.

Setting range: 15 ... 65 000 ms (increment: 1 ms)

Default: 15

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

OK


Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.3.5.11.

Digital Store object



A060054

Fig. 4.3.5.11.-1 Function block Digital Store object

Function

The digital store object continuously saves the current digital values at its input. If the auxiliary supply voltage fails, the last saved values are kept. In this event they are available at the appropriate outputs after REF 542plus has restarted. If the reset or RESET input is at logical 1, the output signals are set to logical 0.

Typical application

The signals that, for example, have generated a switching authorization, are kept in this way after a power failure. Otherwise the switching authorization would be lost, because all outputs and inputs on the REF 542plus take a defined state.

Configuration


The connections of the function block are shown in the configuration dialog box with the connection numbers to which they are connected. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.6. Analog Objects

The following sections contain the descriptions of the function blocks that are available in **Drawing Menu > Insert > Analog Objects**.

4.3.6.1. Analog Threshold



A060055

Fig. 4.3.6.1.-1 Function block Analog Threshold

Function

Each of the eight analog measuring inputs can be monitored to detect if it falls below or exceeds a threshold value. If the measured value falls below or exceeds the configurable trip threshold (threshold value), the supervision function is activated. If the trip threshold exceeds or is below the threshold after a configurable period, a trip signal is generated. The trip threshold and the period for exceeding or falling below the measured value can be configured separately.

Connections

B> input:	If there is a logical 1 at this input, the trip signal for signaling that the threshold value has been exceeded is suppressed.
B< input:	If there is a logical 1 at this input, the trip signal for signaling that the threshold value has not been reached is suppressed.
S> output:	The starting signal (logical 1) can be tapped here if the threshold value has been exceeded.
S< output:	The starting signal (logical 1) can be tapped here if the threshold value has not been reached.
> output:	The trip signal (logical 1) can be tapped here if the threshold value has been exceeded.
< output:	The trip signal (logical 1) can be tapped here if the threshold value has not been reached.
Valid output:	A logical 1 is set whenever the chosen analog signal is valid.
Not Valid output:	A logical 1 is set whenever the chosen analog signal is not valid.

Typical application

The threshold values can be used to ascertain that a bay has no voltage. It is recommended to generate various interlock conditions with this signal. Please observe the restrictions regarding the threshold object:

- Maximum of 10 threshold objects per analog measuring input (= 80 per configuration)
- Minimum reaction time around 50 to 100 ms
- The threshold objects cannot select a direct switching output

Configuration


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A060056

Fig. 4.3.6.1.-2 General tab in the configuration dialog box Analog Objects

This is automatically assigned but can also be changed in the adjacent set limits. All (max. 10) threshold objects that refer to a measuring input have the same Field bus address. The Field bus address is used for addressing the function block in the event of field bus commands. It is also shown in the function chart below the function block.

Number

The sequential number of the threshold object is entered in the **Number** drop-down menu. It is also shown in the function chart below the function block. It is also used to distinguish a maximum of 10 threshold objects per analog measuring input.

Analog inputs

The measuring input that is to be monitored by the threshold object can be selected from the **Analog Inputs** drop-down menu.

Setting range: All configured analog signals
Default: None

TR >

The trip threshold for exceeding the threshold is entered in the TR> text box in multiples of the rated voltage or of the rated current.

Setting range: 0.1 ... 10 (increment: 0.01)
Default: 1.00

Time (under TR>)

Enter the time in seconds in the Time text box for which the measured value must exceed the threshold value before a trip signal is generated.

Setting range: 0.5 ... 300 s (increment 0.01 s)
Default: 1.00

TR<

The trip threshold for falling below the threshold is entered in the TR< text box in multiples of the rated voltage or of the rated current.

Setting range: 0.1 ... 10 (increment: 0.01)
Default: 1.00


Time (under TR<)

Enter the time in seconds in the Time text box for which the measured value must fall below the threshold value before a trip signal is generated.

Setting range: 0.5 ... 300 s (increment 0.01 s)

Default: 1.00

Pins



A060057

Fig. 4.3.6.1.-3 Pins tab in Configuration box Analog objects

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.6.2.

Measurement supervision NPS and PPS

REF 542plus provides two types of measurement supervision functions. Each of them can be independently activated:

- Positive Phase Sequence (PPS)
- Negative Phase Sequence (NPS)



A050689

Fig. 4.3.6.2.-1 Measurement supervision

Input/output description

Table 4.3.6.2.-1 Input

Name	Type	Description
BS	Digital signal (active high)	Blocking signal

When the BS signal becomes active, the measurement supervision function is reset no matter its state. This means that all the output pins go low generating the required events (if any), and all the internal registers and timers are cleared. The protection function will then remain in idle state until the BS signal goes low.


Table 4.3.6.2.-2 Output

Name	Type	Description
Warning	Digital signal (active high)	Warning signal
Failing	Digital signal (active high)	Failing signal

Warning is the start signal. Warning signal will be activated when the start conditions are true. The negative phase sequence value exceeds the setting threshold value for NPS , and the positive phase sequence value falls below the setting threshold value for PPS.


Failing signal will be activated when the start conditions are true and the operating time has elapsed.

Configuration



A050690


Fig. 4.3.6.2.-2 General



A050691

Fig. 4.3.6.2.-3 Sensors


The measurement supervision functions operate on all sensors in a triple. The analog channels 1-3 or 4-6 can be used to supervise the phase currents, phase voltages or line voltages.



A050692


Fig. 4.3.6.2.-4 Parameters

Start Value: Positive/Negative phase sequence threshold for Start condition detection.
Time: Time delay for Trip condition detection.



A080242

Fig. 4.3.6.2.-5 Events



A050694

Fig. 4.3.6.2.-6 Pins

Measurement mode

Measurement supervision functions evaluate the measured amount of positive and negative phase sequence values at the fundamental frequency.

Operation criteria

If the negative phase sequence value exceeds the setting threshold value (Start value) in the NPS based functions, or if the positive phase sequence value falls below the setting threshold (Start value) the function enters the START status and raises the warning. After the preset operating time (Time delay) has elapsed, the failing signal is generated.

The measurement function will come back in passive status and the warning signal will be cleared, if the negative phase sequence value falls below 0.95 the setting threshold value for NPS , or if the positive phase sequence value exceed 1.05 the setting threshold value for PPS.

The measurement function will exit the failing status and the failing signal will be cleared when the negative phase sequence value falls below 0.4 the setting threshold value for NPS, or if the positive phase sequence value exceed 1.05 the setting threshold value for PPS.

Setting groups

Two parameter sets can be configured for each of the measurement supervision functions.


Parameters and events

Table 4.3.6.2.-3 **Setting values**

Parameter	Values	Unit	Default	Explanation
Start value (PPS)	0.30 ... 0.90	In or Un	0.85	PPS threshold to undergo.
Time delay	30 ... 30000	ms	1000	Time delay from start condition (warning signal) to failing signal.
Start value (NPS)	0.05 ... 0.40	In or Un	0.10	NPS threshold to be exceeded.
Time delay	30 ... 30000	ms	1000	Time delay from start condition to failing signal.

Table 4.3.6.2.-4 Events

Code	Event reason
E0	Warning signal is active
E1	Warning signal cancelled
E6	Failing signal is active
E7	Failing signal is back to inactive state
E18	Function block signal is active
E19	Function block signal is back to inactive state

4.3.6.3.**Analog Input 20mA object**

AI 20mA

A051055

*Fig. 4.3.6.3.-1 Function block Analog Input 20mA***Function**

Up to 48 Analog Input 20mA objects (instances) can be used. Each object can be assigned to one of the six Analog Inputs 20mA of the REF 542plus. Depending on the state of the measured value of the dedicated sensor, the analog input 20mA object generates a valid/not valid signal. If the measured value of the dedicated sensor exceeds or falls below the configured threshold, a warning signal is generated.

Typical application

The threshold supervision of the Analog Input 20mA objects can, for example, be used for supervision of gas density or temperature. Several thresholds can be assigned to each sensor.

Connections


Valid output: The valid signal (logical 1) can be tapped here if the dedicated sensor is working properly.

Not valid output: The not valid signal (logical 1) can be tapped here if the dedicated sensor is not working properly.

Warning output: The warning signal (logical 1) can be tapped here.

Configuration

Start with the General tab



A051056


Fig. 4.3.6.3.-2 Configuration dialog Analog Input 20mA object, tab "general"

The **Instance number** selection list: Select the desired instance number. It is displayed under the FUPLA block through the string "Nr.:x", where x is the instance number. The selection list includes the numbers from 1 to 48 excluding the already used ones.

The **Name** input field: Name of the warning that shall be displayed on the RHMI. Max. number of characters: 20.

The **Sensor number** selection list. This list shows all configured sensors. Select a sensor number to assign the Analog Input 20mA object to this sensor. Whenever the sensor number is changed, all parameters will be set to their default values.

The **Parameters** configuration.




A051057

Fig. 4.3.6.3.-3 Configuration dialog Analog Input 20mA object, tab “Parameters”

The **Direction** selection list: The default-direction is **Up**. This means that the warning signal is active when the measured value of the dedicated sensor exceeds the configured threshold. The direction **Down** has to be selected when the warning signal is active or should be active, that is, when the measured value falls below the configured threshold.


The **Threshold** input field: The desired threshold-level can be entered here. If the measured value of the dedicated sensor exceeds or falls below (according to the configured direction) this threshold, the warning signal is activated.

The **Hysteresis** input field: The desired hysteresis can be entered here. See Fig. 4.3.6.3.-4 and Fig. 4.3.6.3.-5 to view how the hysteresis works depending on configured direction.



A051058

Fig. 4.3.6.3.-4 Hysteresis (Direction: Down)



A051059

Fig. 4.3.6.3.-5 Hysteresis (Direction: Up)

The Debounce time input field: The width of the debounce time window for debouncing the warning can be entered here.

Setting range: 0..100ms (increment: 1ms)


The **Override value** selection list: The override value overrides the state of the Warning output in case that the state of the dedicated sensor is invalid. The override-value can be **Inactive** or **Active**. Default: **Inactive**.

The **Apply** button: All settings are saved in the configuration software.

The **OK** button: All settings are saved in the configuration software. The dialog window is closed.

The **Cancel** button: Settings are not saved in the configuration software. The dialog window is closed.

Information about pins:




A051060

Fig. 4.3.6.3.-6 Information dialog pins

4.3.6.4.

Energy management



A060063

Fig. 4.3.6.4.-1 Function block Energy management

Function

The Energy management function block is used to influence the internal energy calculations in REF 542plus. On one hand the count process can be stopped and on the other hand a return block can be activated. In this case the energy is not counted backwards if the energy direction changes.

Depending on the hardware configuration the power is calculated from the current and voltage values at the analog inputs. The internal REF 542plus time clock is then used to calculate the energy. The energy values can be displayed on the LCD.



The internal energy calculation functions only with configured power calculation.

Connections

COUNT/no count input: The count process is stopped if there is a logical 1 at this input.

BACK/no back input: If there is a logical 1 at this input, backwards counting is suppressed if the energy direction changes.

Typical application

The energy count provides an overview of the generated/consumed bay-specific energy.


Configuration

The function block connections with the connection numbers attached to them are displayed in the configuration dialog box. Inputs are not possible.

The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made. These inputs are then confirmed with the **OK** button.

4.3.6.5.

Energy Counter

default Nr.1
165

Adr.: 110 Nr.: 1

The image shows a square function block icon with a blue border. Inside the square, there is a grey background. At the top, it says 'x 1.0'. Below that, there is a blue 'I' symbol. At the bottom, the words 'ENERGY COUNTER' are written in blue capital letters.

A060064


Function

The Energy Counter function block uses impulses to meter energy. Every impulse is assigned to a configurable energy value. The energy metered here is then displayed in the measured value display on the LCD of the REF 542plus HMI control unit.

Typical application

The Energy Counter function block is used if there is an energy measuring instrument in the bay that is being configured. Its impulses can be sent to the energy counter in the function chart over a binary input.

Configuration



A060065

Fig. 4.3.6.5.-1 Configuring Energy Counter

Field bus address

The permanently assigned Field bus address is displayed here. All energy counters have the same address.

Number

Enter a number to distinguish several configured energy counters. The number is also shown in the function chart above the function block.

Setting range: 1 ... 15 (increment: 1)

Default: The next free energy counter number

Multiplication factor

The energy in kWh that represents an incoming impulse is entered in the Multiplication factor text box. The multiplier is shown in the function chart in the function block.

Setting range: 0.1 ... 1000 (increment: 0.1)

Default: 100

Display text (LCU)

Enter text in the Display text (LCU) that is to be displayed on the LCD to enable several energy counters to be distinguished more easily.

Setting range: 0 ... 18 characters (standard character set)

Default: Default no. [Number of the energy counter]

BI

The number of the connection is shown here. If there is no connection yet, a 1 is shown.

OK


Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.3.6.6.

Energy Pulse Output



A060066

Fig. 4.3.6.6.-1 Function block Energy Pulse Output

Function

The Energy Pulse Output function block sends pulses that represent a specific energy quantity to its output (energy). The pulses are generated based on the internal energy calculations of REF 542plus.

The DSP calculates the energy and sends standardized energy packets to the microcontroller. This receives a number of standardized energy packets about twice a second and calculates the absolute energy amount from them.

The energy amount is then converted to the corresponding No. of cycles. If there is a remainder after the conversion into pulses, it is included in the next conversion.

The energy pulse output can send up to 70 pulses after a calculation. Additional pulses are ignored and the overflow output is then set to logical 1. If the number of calculated pulses is reduced below 65 again, the overflow output is reset to logical 0.



To add the Energy Pulse Output function block, the power calculation must be activated.



Use the Energy Pulse Output function block only with binary input/output boards with solid state relays. The conventional relays are limited in their number of switching cycles and therefore are not suited for this.


Typical application

Use the Energy Pulse Output function block to control an external energy display with the pulses from REF 542plus.

Example:

Application in a system with rated voltage U_r 11 kV and rated current I_r 300A. Under a rated load condition with $\cos \phi = 0.9$ and CT rated current 300A, the active power is $\sqrt{3} \times 11 \text{ kV} \times 300 \text{ A} \times 0.9 = 5144 \text{ kW}$. The energy portion per second is $5144 \text{ kW} \times 1 \text{ h} / 3600 \text{ sec} = 1,43 \text{ kWh}$. In case that the setting parameter Pulse per kWh = 0.7 is selected, the value of 1 Pulse is equal to $1 \text{ kWh} / 0.7 = 1.43 \text{ kWh}$. As a consequence, a pulse is generated every second at the ENERGY output. If the value of the setting parameter is enlarge, for example from 0.7 to 2.1, which means that the value of 1 Pulse is equal to 0.43 kWh, three pulses are generated each second.

Configuration



A060068

Fig. 4.3.6.6.-2 Configuration dialog box Energy Pulse Output

Energy

Select here whether the pulse should represent Active or Reactive energy.

Energy Flow

Select the direction of the energy flow. Only energy of this direction is converted to the corresponding pulse.

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

Pulse per kWh

Enter the calculated energy amount that an pulse represents in kWh.

Setting range: 0.1 ... 1000 (increment: 0.1)

Default: 1.0

Pulse Lenght

The duration of the output pulse in ms can be varied in the Pulse Length text box to ensure that the external energy display functions correctly.

Setting range: 50 ... 150 ms (increment: 1 ms)

Default: 150

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

4.3.6.7. Power Factor Controller



A060069

Fig. 4.3.6.7.-1 Function block Power Factor Controller

Connections

BL (Blocking) input: A logical 1 signal at this input suppresses the power factor controller functions.

Disconnect input: A logical 1 signal at this input switches off all active capacitor banks.

Reset input: A logical 1 signal at this input resets the General Alarm. If this alarm status is not reset, the control function remains blocked.

Overtemp. input: A logical 1 signal at this input generates a General Alarm message and immediately switches off all capacitor banks.

V MIN/MAX input: A logical 1 signal at this input generates a General Alarm message and immediately switches off all capacitor banks.

V A MAX input: A logical 1 signal at this input results in a General Alarm message.

Mode: Man. input: A logical 1 signal on this input changes switches the operating mode of the Power Factor Controller from automatic to manual.

Set Night input: A logical 1 signal on this input switches the parameter setting from day to night.

Manual Control Bank 0 ... 3 input (once per capacitor bank): A logical 1 signal on this input results in capacitor bank C₀ ... capacitor bank C₃ being switched on or off depending on its switch status.

Checked Back Bank 0 ... 3 input: A logical 1 signal on this input indicates whether capacitor bank C_0 ... capacitor bank C_3 is switched on.

Alarm Q output: A logical 1 signal can be tapped here if all capacitor banks in the network are already switched on and the power factor for the reactive power control still remains below the limit.

Alarm $\cos \Phi$ output: A logical 1 signal can be tapped here if the set power factor $\cos \Phi$ for the alarm is instantaneously below the limit.

Alarm Operat. output: A logical 1 signal can be tapped here if the set maximum number of switching cycles for one of the capacitor banks is exceeded.

Alarm General output: A logical 1 signal can be tapped here if a general alarm is generated following relevant input information such as (OVERTEMP., V MIN/MAX, VA MAX, DISCONNECT).

The function is blocked as long as the alarm is active. The Power Factor Controller is only ready for operation again after the alarm has been acknowledged.

Switch On/Off Bank 0 ... 3 output (once per condensator bank): A logical 1 signal or logical 0 signal can be tapped here if capacitor bank C_0 ... C_3 is to be switched on or off.

Configuration

The following sections describe several tabs. In all tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A060070

Fig. 4.3.6.7.-2 General tab, Function block Power Factor Controller

Field bus address

Set for every protection function and used to address the function block for field bus commands.

Switching Sequence

In the Switching Sequence select how the capacitor banks should be switched on or off when they are the same size:

Linear

It is switched on in ascending sequence and switched off in descending sequence.

Circular

It is switched on and off in ascending sequence.

Switching Hysteresis

Under Switching Hysteresis enter the settings for switching the capacitor banks on or off for reactive power control:

Neutral zone (K_{OFF})

The threshold for switching off is calculated with the adjustable percentage factor, which is based on the smallest installed capacitor output Q_{C0} .

Setting range: 105 ... 200 % of Q_{C0} (increment: 1).

Default: 115


Pickup value (K_{ON})

The threshold for switching on is calculated with the adjustable percentage factor, which is based on the smallest installed capacitor output Q_{C0} .

Setting range: 0 ... 100 % of Q_{C0} (increment: 1).

Default: 0

Capacitor Banks



A060071

Fig. 4.3.6.7.-3 Capacitor Banks tab, function block Power Factor Controller

Reactive power of smallest bank Q_{C0}

The default of the smallest module of the set capacitor output in bank is 0.

Setting range: 1,000 ... 20,000 kVAr (increment: 1)
Default: 100,000

Configuration of banks

The default of the combinations of output units of the capacitor banks in the sequence bank 0, bank 1, bank 2 and bank 3. Using less than 4 banks the figures beginning from the right are ignored.

Setting range: 1:1:1:1; 1:1:2:2; 1:2:2:2; 1:2:4:4; 1:2:4:8
Default: 1:1:1:1

Number of banks

Setting the number of installed capacitor banks.


Setting range: 1 ... 4 (increment: 1)
Default: 1

Maximum switching cycles

An alarm message can be generated with this setting if the number of switching cycles of one switching device of a capacitor bank is exceeded.

Setting range: 0 ... 10000 (increment: 1)
Default: 2500

Control Data



A060072

Fig. 4.3.6.7.-4 Control Data tab, function block Power Factor Controller

Setpoint cos phi, day (once per parameter set)

Enter the set point of the power factor cos phi for day control of the reactive power. If the value drops below the set point, the control is activated.

Setting range: 0.70 ... 1.00 (increment: 0.01)
Default: 0,90

Setpoint cos phi, night (once per parameter set)

Enter the set point of the power factor cos phi for night control of the reactive power. If the value drops below the set point, the control is activated.

Setting range: 0.70 ... 1.00 (increment: 0.01)
Default: 0,90

Inductive/capacitive (under Setpoint cos phi)

Allows setting of the type of reactive power to be compensated.

Default: Inductive

Limiting value cos phi (Alarm) Day (once per parameter set)

Enter the limit value of the power factor cos phi for the alarm during day operation. If the value falls below the limit value, an alarm message is generated.

Setting range: 0.00 ... 1.00 (increment: 0.01)
Default: 0,00

Inductive/capacitive (under Limiting value cos phi (Alarm) Day)

Allows setting of the type of reactive power to be compensated.

Default: Inductive

Limiting value cos phi (Alarm) Night (once per parameter set):

Enter the limit value of the power factor cos phi for the alarm during night operation. If the value falls below the limit value, an alarm message is generated.

Setting range: 0.00 ... 1.00 (increment: 1)
Default: 0,00

Inductive/capacitive (under Limiting value cos phi (Alarm) Night)

Allows setting of the type of reactive power to be compensated.

Default: Inductive


Method of operation (once per parameter set)

The criteria for controlling the reactive power can be determined directly from the current values or after integration of averaging the values.

Setting range: Direct/integrating

Default: Direct

Time



A060073

Fig. 4.3.6.7.-5 Time tab, function block Power Factor Controller

Discharge blocking time (once per parameter set)

After a capacitor bank is switched off, it can only be switched on again after the discharge period has expired.

Setting range: 1 ... 7200 s (increment: 1)

Default: 900

Dead time (once per parameter set)

After a capacitor bank is switched on, the control function is initially deactivated for the period of the dead time. Setting range: 1 ... 120 s (increment: 1) Default: 10

Setting range: 1 ... 120 s (increment: 1)

Default: 10

Power on delay (once per parameter set)

After a complete switch off of all capacitor banks the reclosing is avoided for the power on delay time.

Setting range: 1 ... 7200 s (increment: 1)

Default: 900


Duration of integration (once per parameter set)

The reactive power or the power factor is determined after the values have been averaged within the set integration period. The Duration of integration parameter is used from the function block only if integration is used as a method of operation.

Setting range: 1 ... 7200 s (increment: 1)

Default: 900

Events



A080244

Fig. 4.3.6.7.-6 Events tab, function block Power Factor Controller

The main part in the Events tab is the list of events. The channel number over which the events are sent is shown in the left column near the check box. To enable the individual events to be transmitted to the substation automation system, transmission of events must be generally enabled.

The events of the function block Power Factor Controller must also be enabled. Mark the adjacent check box so the event is generated and sent as required.

Set All

Click the **Set All** button to select, generate and send all events as required.

Clear All

Click the **Clear All** button to clear the selection.

Set Default

Click the **Set Default** button to use the default configuration for events. The default configuration for events for each function object is defined in the associated file *.rce.

Save Default

Click the **Save Default** button to save the checked events in the associated *.rce file.

Event Masks E15 ... E0 and E31 ... E16


The selecting of events is also possible in the Event Masks text boxes. The input must be in hexadecimal code (Refer to the following table for the events E0 to E15). The input for the events E16 to E31 is in principle similar. The events 28 to 31 are not used in this function block. If you select the check boxes in the list you can read the hexadecimal code in the text boxes.

Table 4.3.6.7.-1 Power Factor Controller

97	E00	Bank 0 ON	E04	Bank 0 OFF
97	E01	Bank 1 ON	E05	Bank 1 OFF
97	E02	Bank 2 ON	E06	Bank 2 OFF
97	E03	Bank 3 ON	E07	Bank 3 OFF
97	E08	Overtemperature started	E09	Overtemperature back
97	E10	Va max started	E11	Va max back
97	E12	Vmin/max started	E13	Vmin/max back
97	E14	Command DISCONNECT started	E15	Command DISCONNECT back
97	E16	Cos phi warning started	E17	Cos phi warning back
97	E18	Alarm Q started	E19	Alarm Q back

97	E20	Warning switching cycles	E21	Alarm reset
97	E22	Block signal started	E23	Block signal back
97	E24	Manual operating mode	E25	Automatic operating mode
97	E26	Night mode	E27	Day mode

Pins



A060075

Fig. 4.3.6.7.-7 Pins tab, function block Power Factor Controller

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.7.

Communication objects

The sections below describe the function blocks that are available in **Drawing Menu > Insert > Communication Objects**.

The following function block is used for vertical communication to the host with LON per LAG 1.4. Also horizontal communication for interlocking between the bays is possible.

4.3.7.1.

Binary Write



A060076

Fig. 4.3.7.1.-1 Function block Binary Write

Function

The Binary Write function block is used for vertical communication in transmitting the binary information to the host. This function block must be updated by the field bus during the configured time. After a time out the output valid and the 16 data outputs are reset with logical 0. After each new update the output valid is set back again to logical 1. The default time is 1000 ms. If the time is set to 0, the time controlling is not active, valid is permanently 1 and the output is never reset.



A maximum of 32 Binary Write function blocks can be entered.

Connection

- Output 1: Connection of the logical signal that is to be sent to the substation control system.
- Output VALID: Logical signal 1 is present, if the binary information has a valid qualifier.

Configuration

The following describes two tabs in the Binary Write dialog box. In all the tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A060077

Fig. 4.3.7.1.-2 General tab, function block Binary Write

Field bus address

Set for every protection function and used to address the function block for field bus commands.

Instance number

Select the number of the used function block in the **Instance number** drop-down menu. In total 64 function blocks and respectively instance are available.

Setting range: 1 ... 32 [instance number] (increment: 1)

Default: 1


Refresh timeout period

The time duration to be set for recognizing the information from the host.

Setting range: 0 ... 65000 ms (increment: 1)

Default: 1000

Pins




A060078

Fig. 4.3.7.1.-3 Pins tab, function block Binary Write

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.7.2.

16-Bit Write



A060079

Fig. 4.3.7.2.-1 Function block 16-Bit Write

Function

The 16-Bit Write function block is dedicated as well for the vertical communication to receive RESERVE requests and RESERVE confirmations as also for horizontal communication to receive the interlocking information from other bays. Each change of the inputs creates an event with the port number of the changed input as its value information.

The function block must be updated by the field bus during the configured time. After a time out the output valid and the 16-data outputs are reset to logical 0. After each new update the output valid is set back again to logical 1. The default time is 1000 ms. If the time is set to 0, the time controlling is not active, valid is permanently 1 and the output is never reset.



A maximum of 64 16-Bit Write function block can be entered.

Connection

Output 1 ... 16: Connection of the logical signal that is to be sent to the substation control system.

Output VALID: Logical signal 1 is present, if the binary information has a valid qualifier.

Configuration

The following describes two tabs in the 16-Bit Write dialog box. In all the tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A060080

Fig. 4.3.7.2.-2 General configuration dialog box, function block 16-Bit Write

Field bus address

The Field bus address is set for every protection function and used to address the function block for field bus commands.

Instance number

Select the number of the used function block in the **Instance number** drop-down menu. In total 64 function blocks and respectively instance are available.

Setting range: 1 ... 64 [instance number] (increment: 1)

Default: 1


Refresh timeout period

The time duration to be set for recognizing the information from the host.

Setting range: 0 ... 65000 ms (increment: 1)

Default: 1000Pins

Pins



A060081

Fig. 4.3.7.2.-3 Pins tab, function block 16-Bit Write

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.7.3.**Binary Read**

A060081

*Fig. 4.3.7.3.-1 Function block Binary Read***Function**

The Binary Read function block is used as vertical communication to read binary information transmitted by the host.



A maximum of 32 Binary Read function block can be entered.

Connection

Input 1: Connection of the logical signal that is to be read from the host within the substation control system.

Configuration

The following sections describe two tabs in the Binary Read dialog box. In all tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A060083

Fig. 4.3.7.3.-2 General tab, function block Binary Read

Field bus address

The Field bus address is set for every protection function and used to address the function block for field bus commands.

Instance number

Select the number of the used function block in the **Instance number** drop-down menu. In total 64 function blocks and respectively instance are available.

Setting range: 1 ... 64 [instance number] (increment: 1)

Default: 1


Event: 0->1

The event number assigned to the event when sent. The event is generated if the logical state at the input changes from 0 to 1 and is sent via the related channel with the selected event number.

Event: 1->0

The event number assigned to the event when sent. The event is generated if the logical state at the input changes from 1 to 0 and is sent via the related channel with the selected event number.


Pins



A060084

Fig. 4.3.7.3.-3 Pins tab, function block Binary Read

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.7.4.**16-Bit Read**

A060085

Fig. 4.3.7.4.-1 Function block 16-Bit Read

Function

The 16-Bit Read function block is used as well for vertical communication to receive the RESERVE requests and RESERVE confirmations transmitted by the host, as also for horizontal communication to receive the interlocking information from other bays. All changes of the inputs create an event with the instance number of the changed input as its value information.



A maximum of 32 binary read function block can be entered.

Connection

Input 1 ... 16: Connection of the logical signal that is to be read from the host within the substation control system.

Configuration

The following sections describe two tabs in the 16-Bit Read dialog box. In all tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A060086

Fig. 4.3.7.4.-2 General tab, function block 16-Bit Read

Field bus address

The Field bus address is set for every protection function and used to address the function block for field bus commands.

Instance number

Select the number of the used function block in the **Instance number** drop-down menu. In total 64 function blocks and respectively instance are available.

Setting range: 1 ... 64 [instance number] (increment: 1)

Default: 1

Delay time


Setting range: 0 ... 65000 ms

Default: 0

Event

The number of the event being used by the function block.

Pins




A060087

Fig. 4.3.7.4.-3 Pins tab, function block Binary Read

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.7.5.

Direct Read-Write



A060088

*Fig. 4.3.7.5.-1 Function block Direct Read-Write***Function**

The Direct Read-Write function block enables logical signals to be exported from the function chart to a station control system. Logical signals can also be sent in the reverse direction from the control system to the function chart.



A maximum of 100 Direct Read-Write commands can be entered.

Typical application

A typical application is implementing station-level interlocking over the field bus.

Connections

Input R: Connection of the logical signal that is to be sent to the station control system.

Output W: Signaling output of the logical signal that the station control system is send to the function chart.

Configuration

The following sections describe two tabs in the **Direct Read-Write** dialog box. In all tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A060089

Fig. 4.3.7.5.-2 General tab, function block Direct read-write

Field bus address

The Field bus address is set for every protection function and used to address the function block for field bus commands.


Signal number

Select the signal number/event number over which a logical signal is sent or received. Channel and signal/event number are also shown in the function chart below the function block.

Setting range: 0 ... 99 (increment: 1)

Default: Next free signal number

Pins




A060090

Fig. 4.3.7.5.-3 Pins tab, function block Binary Read

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.7.6.

Event Generator



A060091

Fig. 4.3.7.6.-1 Function block Event Generator

Function

The Event Generator function block generates an event if the state at the input changes from logical 0 to logical 1 or vice versa. This event can be processed by the station control system.



A maximum of 63 events can be generated with event generators, with every event generator being able to transmit 2 events.

Typical application

A typical application is generating a real-time event for the substation control system, if a function block does not provide a corresponding event.

Connections

Input left: Every change of the logical state generates an event.

Configuration

The following section describes two tabs in the Event Generator dialog box. In all the tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General



A060092

Fig. 4.3.7.6.-2 General tab, function block Event generator

Field bus address

The Field bus address is set for every protection function and used to address the function block for field bus commands.

Event: 0->1

The event number assigned to the event when sent. The event is generated if the logical state at the input changes from 0 to 1 and is sent via the related channel with the selected event number. The event is generated if the logical state at the input changes from 0 to 1 and is sent via channel 100 (default) with the selected event number. The input "0" prevents an event from being transmitted.


Setting range: 0 ... 63 (increment: 1)
Default: 0

Event: 1->0

The event number assigned to the event when sent. The event is generated if the logical state at the input changes from 1 to 0 and is sent via channel 100 (default) with the selected event number. The input "1" prevents an event from being transmitted.

Setting range: 0 ... 63 (increment: 1)
Default: 1

Pins




A060093

Fig. 4.3.7.6.-3 Pins tab, function block Event generator

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.7.7.

Bay Reserve



A060094

Fig. 4.3.7.7.-1 Function block Bay Reserve

Function

The function block Bay Reserve is used to handle the SELECT/RESERVE mechanism and is needed once per bay. A maximum of 8 switching devices can be served by this function block. As well as the internal bay RESERVE requests, the RESERVE requests from other bays can be processed.

Reservation request

A switching device requires a reservation by putting a logical signal 1 on the related input RES.REQ.i (i = 1 ... 8). This request can be configured by the input INT.REQ.i (i = 1 ... 8) either only as an internal bay request or as a request, in which external bays must also be taken into account.

Reservation confirmation

The reservation is granted if the following conditions are fulfilled:

- No switching devices have already asked for reservation.
- No reservation request is present.

In case of an external bay reservation, all bays have already confirmed the reservation.

In case of granted reservation, the output RES.GRANT.i ($i = 1 \dots 8$) for the switching device, which is requesting the reservation, changes to logical signal 1. The same happens with the output RESERVED. The reservation is then granted until the reservation is reset by the corresponding switching device.

If an external reservation is configured by INT.RES.i ($i = 1 \dots 8$) = 0, the request is executed after the input GRANT FROM ANY is set to logical 0, which means that all other bay reservations have been reset. Subsequently the output EXT.RES is set to logical 1. This information must then be transmitted to the host of the substation control system by the 16-Bit Read function block.

The Bay Reserve function block now waits for the logical signal 1 at the input GRANT FROM ALL and the input GRANT VALID, which indicates the validity of the information on the field bus.

Reservation request from other bays

A logical 1 signal at the input of EXT.RES.REQ. shows a reservation request from another bay. The bay must confirm the reservation and cannot generate any bay internal reservation any more. The bay confirms the reservation under the following condition:

- The bay is not internally or externally reserved.
- The input EXT.REQ.VALID is set to a logical 1 signal and indicates the validity of the reservation on the field bus.

The reservation is confirmed, if the related output RES-GRANT.i ($i = 1 \dots 8$) becomes a logical 1 signal. This information must then be transmitted by the field bus to the external bay, which is requesting the reservation.

Connections

Input RES.REQ.i ($i = 1 \dots 8$): If a reservation of the assigned switching device is requested, the input is set with a logical 1 signal.

Input INT.REQ.i ($i = 1 \dots 8$): If an external reservation for the assigned switching device is needed, the input is set with a logical 1 signal. If only internal reservation for the assigned switching device is needed, the input is set with a logical 0 signal.

Input GRANT FROM ALL: If all other external bays have confirmed the reservation, the input is set with a logical 1 signal.

Input GRANT FROM ANY: If at least one external bay still indicates a confirmation of a previous reservation, the input is set with a logical 1 signal.

Input GRANT VALID: If all reservation confirmations are valid after cyclic actuation by the field bus, the input is set with a logical 1 signal.

Input EXT:RES.REQ.: If a reservation request from an other bay is present, the input is set with a logical 1 signal.

Input EXT.REQ.VALID: If the external request is valid, the input is set with a logical 1 signal.

Input BLOCK: If all reservations, inclusive the ongoing reservation, is blocked, the input is set with a logical 1 signal.

Input OVERRIDE: If the mechanism of the reservation is set out of order, the input is set with a logical 1 signal. All reservation requests, internally and externally are granted.

Output RES.GRANT.i (i = 1 ... 8): If reservation of the assigned switching device is granted, the output becomes logical 1.

Output EXT.RES.: If reservation of the assigned switching device is granted, the output becomes logical 1.

Output EXT.GRANT.: To confirm the related external bays, that this bay is already prepared for executing the reservation request, the output becomes logical 1.

Output RESERVED: To indicate the reservation status of this bay, the output becomes logical 1.

Configuration

The following section describes two tabs in the Bay Reserve dialog box. In all the tabs the **OK** and **Cancel** buttons are available.


OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

General




A060095

Fig. 4.3.7.7.-2 General tab, function block Bay Reserve

No parameters can be set in the General tab of the Bay Reserve dialog box.

Pins



A060096

Fig. 4.3.7.7.-3 Pins tab, function block Bay Reserve

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.

4.3.7.8. Switch Authority Allocation



A060097

Fig. 4.3.7.8.-1 Function block Switch Authority Allocation

Function

This function block is used to set and to verify the switch authority allocation of all switching devices installed in the switchgear. Without this function block the status of the electronic key on the HMI as Local Control Unit is taken as the control status (NO CONTROL, LOCAL, REMOTE, LOCAL & REMOTE). This function block can be applied to override the control status of the HMI electronic key or to extend the REMOTE definition for the allocation of the switch authority. In this case, when the control status evaluated by the function is REMOTE the switch authority allocation can be assigned to the Station Control Unit or to the Remote Control System.

Connection

Input VALID: Logical 1 signal makes the status of all inputs valid. Logical 0 causes the reset of all the output signals, that is all the switching commands are rejected. The output signals will be reset with a delay of 500 ms.

Input OFF: Logical 1 signal will set the control status as NO CONTROL. The OFF output signal will be put at logical 1 and the LOCAL/REMOTE/STATION output signals will be put at logical 0, i.e. all switching commands are rejected.

Input EXTERNAL: Logical 1 signal leads to an evaluation of the switch authority allocation to the EXT.KEY LOCAL/REMOTE input signals. The HMI electronic key state cannot be updated anymore. In case of logical 0, the function will evaluate

the switch authority allocation from the HMI electronic key. In this case the EXT.KEY LOCAL/REMOTE input signals are ignored and the HMI electronic key state can be updated.

Input EXT.KEY LOCAL: Logical 1 signal, together with EXTERNAL input at logical 1, activates the LOCAL control status. Logical 0 signal deactivates the LOCAL control status.

Input EXT.KEY REMOTE: Logical 1 signal, together with EXTERNAL input at logical 1, activates the REMOTE control status. Logical 0 signal deactivates the REMOTE control status.

Input STATION LOCAL: Logical 1 rising slope will enable the local control of the station.

Input STATION REMOTE: Logical 1 rising slope will change the station control to remote control.

Input STATION KEY LOCAL: Logical 1 rising slope advises that the station key is set to local.

Input STATION KEY REMOTE: Logical 1 rising slope advises that the station key is set to remote.

Input FORCE VALID: Logical 1 signal forces the control status as REMOTE.

Output VALID: Logical 1 signal is present if the input signal is valid.


Output OFF: Logical 1 signals NO CONTROL status, that is all switching commands are rejected.

Output LOCAL: Logical 1 signals LOCAL control status, that is switching commands from HMI Control Unit are accepted.

Output STATION: Logical 1 signals station control status, that is switching commands from Station Control Unit are accepted. It is activated in REMOTE control status when the local control of the station is enabled (input STATION LOCAL) or the station key is set to local (input STATION KEY LOCAL).

Output REMOTE: Logical 1 signals remote control status, that is switching command from Remote Control System are accepted. It is activated in REMOTE control status when the remote control of the station is enabled (input STATION REMOTE) and the station key is set to remote (input STATION KEY REMOTE)

General




A060098

Fig. 4.3.7.8.-2 General tab, function block Switch Authority Allocation

No parameters can be set in the General tab of the Switch Authority Allocation dialog box.

Pins



A060099

Fig. 4.3.7.8.-3 Pins tab, function block Switch Authority Allocation

In the Pins tab, the user can see a list of connections on the function block and information about the wire number connected to the pin is available. There is also information regarding whether the pin is an input or an output of the function block. The connection numbers 1 (on one input) or 2 (on one output) are displayed if the function block still has no connections made.


4.3.8. CAN Communication Objects

Applicable only for ABB the switchgear companies.

4.3.9. Miscellaneous objects

The following sections contain the descriptions of the function blocks that are available in **Drawing Menu > Insert > Miscellaneous Objects**.

4.3.9.1. Parameter Set Selector



A060100

Fig. 4.3.9.1.-1 Function block Parameter Set Selector

Function

The Parameter Set Selector function block can switch the parameters set of the protections via FUPLA. The parameter set can be changed if the device is in “run mode” and one of the activation inputs has a rising edge.

After a parameter set selection the outputs of the function block are updated, showing which parameter set is active. Additionally the FUPLA signals show command and storing feedback and status.

Connections

Input ACTIVATE SET1: If REF 542plus is in “run mode” and input shows a rising edge, parameter set 1 is activated. Default: The input pin is bound to “LOW” (wire number 1 ;the wire # for open inputs).

Input ACTIVATE SET2: If REF 542plus is in “run mode” and input shows a rising edge, parameter set 2 is activated. Default: The input pin is bound to “LOW” (wire number 1 ; the wire # for open inputs).

Input DISABLE COMMANDS: A logical 1 signal at this input disables changing of the active parameter set when a command is detected. In this case, that is command detected while SetCommandDisable input is at logical 1, the SetCommandFail output is set to logical 1.

Input DISABLE STORING: A logical 1 signal at this input disables FLASH storing of configuration at successful commands.

Output SET1 ACTIVE: High if Parameter Set 1 is active.

Output SET2 ACTIVE: High if Parameter Set 2 is active.


Output SET CMD ENABLED: A logical 1 at this output indicates that a set command is enabled. The enable conditions are: Logical 0 at Disable Commands input, Autoreclose is not active, and Alarm LED is not active.

Output SET CMD FAIL: A logical 1 at this output indicates that the last set command has been detected but it has not been processed due to fail in the enable conditions.

Output STORING: A logical 1 at this output indicates that a configuration storing is active. Note that the configuration storing signaling is independent from the parameter set selector command, that is it is at logical 1 also after a parameterization (HMI, communication board and so on) or after a configuration download.

Output STORING FAIL: A logical 1 at this output indicates that the last configuration storing has failed. Note that the configuration storing fail signaling is independent from the parameter set selector command, that is it is at logical 1 also when a parameterization (HMI, communication board and so on) or a configuration download storing fails.


Configuration



A060101

Fig. 4.3.9.1.-2 General tab of configuration dialog box for Parameter Set Selector

Events



A080246

Fig. 4.3.9.1.-3 Events tab of configuration dialog box for Parameter Set Selector

Events description:

E0, E1:	Disable commands started/back
E2, E3:	Disable storing started/back
E4, E5:	Set1 command started/back
E6, E7:	Set2 command started/back
E16, E17:	Storing started/back
E18, E19:	Storing fail started/back
E20, E21:	Set command enabled started/back
E22, E23:	Set command fail started/back
E24, E25:	Set1 active started/back
E26, E27:	Set2 active started/backPins

Pins

Switching Object 1-2

Field bus address: 013

Output No.:

Imp.length[ms]: 100

No. of cycles: 0

Input No. open: 0

Filtertime[ms]: 100

Input No. close: 0

Filtertime[ms]: 100

☒ Indicate Intermediate Position

☐ Use Two Step Switch Command

☐ Invert inputs

Comment:

OK Cancel Events...

Pins

PO active: 1

BI open: 2

BI close: 2

IL: 1

Pulse: 2

BL: 1


Time >: 2

A060103

Fig. 4.3.9.1.-4 Pins tab of configuration dialog box for Parameter Set Selector

4.3.9.2.

Operating hours counter



A060104

*Fig. 4.3.9.2.-1 Function block Operating hours counter***Function**

The Operating hours counter function block counts the operating hours as long as there is a logical 1 at its input. A number of operating hours can be set as the start value.

If an Operating hours counter function block is implemented, the internal Operating hours counter counts only the hours for which REF 542plus is connected to the auxiliary voltage. The number of operating hours is shown on the HMI of the REF 542plus LCD in the operational measured values ring menu. The count of the internal counter or of the Operating hours counter function block, if activated, is used.



Only one Operating hours counter function block can be used in the application.


Typical application

A typical application is that the operating hours of any equipment can be recorded.

Connections

Input left: If this input is set with logical 1, the operating hours counting begins.

Configuration



A060105

Fig. 4.3.9.2.-2 Configuration dialog box of function block Operating hours counter

Operating hours

Input of the factor multiplied by 1000 that sets the initial value of the Operating hours counter.

Setting range: 0...9 (increment: 0.001)

Default: 0.000

Pins

Under Pins is a list of connections on the function block with adjacent connection number. The connection numbers 1 (on one input) and 2 (on one output) are displayed if the function block still has no connections made.

OK

Click **OK** to save all settings in the configuration software. The dialog box is closed.

Cancel

When clicking on the **Cancel** button, the settings are not saved in the configuration software. The dialog box is closed.

5. Terminology

Term	Description
Configuration Tool	Software program to configure the REF 542plus. This program runs on a PC.
Ethernet	Physical communication network to transfer Internet data of the REF 542plus to the PC and back.
Modbus	By extension, communication board implementing the Modbus protocol for REF 542plus.

6. Abbreviations

Abbreviation	Description
ANSI	American National Standards Institute
AR	Autoreclosure
ASCII	American Standard Code for Information Interchange
ASDU	Application Service Data Unit (IEC 60870-5-103 communication protocol).
BI	Binary input
CAN	Controller area network
CB	Circuit-breaker
CT	Current transformer
FUPLA	Function block programming language; Functional programming language; Function plan; Function chart
GPS	Global positioning system
HMI	Human-machine interface
ID	Identifier; identification
IEC	International Electrotechnical Commission
IEC 61850	International standard for substation communication and modelling
IP	Internet protocol
LAG	Lon application guide
LCD	Liquid crystal display
LD HMI	Local detachable human-machine interface
LED	Light-emitting diode
LON	Local operating network
MAC	Media access control
MC	Micro controller
MSI	Microsoft installer technology
NPS	Negative-phase-sequence
PC	Personal computer
PLC	Programmable logical controller
PO	Power output, process object
RSV	Rated secondary value
SNTP	Simple Network Time Protocol
SPA	Data communication protocol developed by ABB
TCP	Transmission Control Protocol
VS	Voltage supervision
VT	Voltage transformer
XML	Extensible markup language



ABB Oy
Distribution Automation
P.O. Box 699
FI-65101 Vaasa
FINLAND
+358 10 2211
+358 10 224 1080
www.abb.com/substationautomation