

# Process Power Manager 5 Library for 800xA PMS 5.6.5 Circuit Breaker Control Library Manual

Version 5.6-5





# Process Power Manager 5 Library for 800xA

Library for 800xA PMS 5.6.5 Circuit Breaker Control Library Manual

Version 5.6-5

#### NOTICE

This document contains information about one or more ABB products and may include a description of or a reference to one or more standards that may be generally relevant to the ABB products. The presence of any such description of a standard or reference to a standard is not a representation that all of the ABB products referenced in this document support all of the features of the described or referenced standard. In order to determine the specific features supported by a particular ABB product, the reader should consult the product specifications for the particular ABB product.

ABB may have one or more patents or pending patent applications protecting the intellectual property in the ABB products described in this document.

The information in this document is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this document.

In no event shall ABB be liable for direct, indirect, special, incidental or consequential damages of any nature or kind arising from the use of this document, nor shall ABB be liable for incidental or consequential damages arising from use of any software or hardware described in this document.

This document and parts thereof must not be reproduced or copied without written permission from ABB, and the contents thereof must not be imparted to a third party nor used for any unauthorized purpose.

This product is designed to be connected to and to communicate information and data via a network interface. It is the reader's sole responsibility to provide and continuously ensure a secure connection between the product and the reader's network or any other network (as the case may be). The reader shall establish and maintain any appropriate measures (such as but not limited to the installation of firewalls, application of authentication measures, encryption of data, installation of anti-virus programs, etc) to protect the product, the network, its system and the interface against any kind of security breaches, unauthorized access, interference, intrusion, leakage and/or theft of data or information. ABB is not liable for damages and/or losses related to such security breaches, any unauthorized access, interference, intrusion, leakage and/or theft of data or information.

The software or hardware described in this document is furnished under a license and may be used, copied, or disclosed only in accordance with the terms of such license. This product meets the requirements specified in EMC Directive 2004/108/EC and in Low Voltage Directive 2006/95/EC.

#### TRADEMARKS

All rights to copyrights, registered trademarks, and trademarks reside with their respective owners.

Copyright © 2002 – 2022 by ABB. All Rights Reserved.

Release: September 2022 Document number: 3BNP100234-0391 B

# **Table of Contents**

Table of Contents			
List of Figures7			
List of	Tables	. 8	
About This	User Manual	11	
Gener	al	11	
Docun	nent Conventions	11	
Warnir	ng. Caution. Information, and Tip Icons.	11	
Termir	nology	12	
Relate	d Documentation	15	
Target	Audience	15	
Compa	atibility	15	
Syster	n Security	15	
Section 1	Function	17	
Soction 2	Control Modulo pmsCBStandardM	10	
		13 04	
2.1 Int	roduction	21	
2.2 De	talled Engineering	23	
4	2.2.1 Operator Note	23	
4	2.2.2 Measurements	24	
4	2.2.3 Breaker Position	25	
4	2.2.4 Graphic Symbol Standard	21	
4	2.2.5 Indications for Breaker Status, Mode, Alarm and	ഹ	
		20	
4	2.2.0 Output commanus	29 24	
4	2.2.7 Interlocking	31 24	
	2.2.0 Polific of Control medeo	34 25	
4	2.2.9 Control modes	30 20	
4	2.2.10 Operation continands	20 20	
4		29 70	
4	2.2.12 Ald1115	40	
4	2.2.13 Events	45	
4	2.2.14 Required 1/0	40	
2302	rameters	40 1 Q	
2.51 a	2 3 1 Parameter details	40 / 0	
2		+3	
Section 3	Control Module pmsCBIndM	57	
3.1 Int	roduction	60	
3.2 De	tailed Engineering	61	
3	3.2.1 Measurements	61	
3	3.2.2 Position status	62	
3	3.2.3 Graphic Symbol Standard	64	
3	3.2.4 Alarms	65	
3	3.2.6 Events	67	
3.3 Pa	rameters	67	
3	3.3.1 Parameter details	69	
Section 4	Control Module pmsCBSyncM	72	
4 1 Int	roduction	- 7/	
7.1111		, <del>+</del>	

4.2 D	etailed Engineering	76
Section 5	Capacity & Performance	77
5.1 H	eap Utilization	77
	5.1.1 pmsCBStandardM	77
	5.1.2 pmsCBIndM	77
	5.1.3 pmsCBSyncM	77
5.2 E	xecution Time	
	5.2.1 pmsCBStandardM	
	5.2.2 pmsCBIndM	
	5.2.3 pmsCBSyncM	
Appendix /	A Appendix1	79
A.1 B	reaker Open/Closed indications	79
A.3 T	ruck Position Indications	80
A.4 T	ruck Position Indications	
A.5 T	ruck Position Indications	
Appendix /	A Revision table	83

# List of Figures

Figure 1 Control module pmsCBStandardM	19
Figure 2 Operator note	23
Figure 3 Faceplate tab Main and Extended faceplate, Edit	24
Figure 4 Circuit breaker status	25
Figure 5 Breaker indications	28
Figure 6 Faceplate tab Parameters - Pulse time configuration	29
Figure 7 Presentation of interlock in the main faceplate	31
Figure 8 Override of interlock A	32
Figure 9 Faceplate tab Edit for Interlocks	33
Figure 10 Local point of control	34
Figure 11 Extended faceplate, maintenance mode	35
Figure 12 Faceplate tab Simulation	36
Figure 13 Auto and Manual status connected back to AutoPar input	37
Figure 14 Main faceplate, Auto mode	37
Figure 15 Main faceplate, Manual mode	38
Figure 16 Faceplate tab Maintenance, Number of operations counter	39
Figure 17 Faceplate tab Alarms	40
Figure 18 Faceplate tab Alarms for customized alarms	42
Figure 19 Faceplate tab Events / Edit for customized events	43
Figure 20 Faceplate tab Trend	46
Figure 21 Control Module pmsCBIndM	57
Figure 22 pmsCBIndM Faceplate tab Main	61
Figure 23 Position status pmsCBIndM	62
Figure 24 Faceplate tab Alarms for pmsCBIndM	65
Figure 25 Control module pmsCBSyncM	72

## **List of Tables**

Table 1 Terminology	12
Table 2 Related Documentation	15
Table 3 Parameters of the control module pmsCBStandardM	19
Table 4 Parameter configuration for measurement signals	24
Table 5 Parameter configuration for circuit breaker status	25
Table 6 Configuration values for the FBConfig parameter	26
Table 7 Breaker indications	28
Table 8 Output open and close commands from pmsCBStandardM	29
Table 9 Time configuration for intermediate pos. alarms and open/close commands	
Table 10 Configuration values for the FollowLocalFB parameter	
Table 11 Configuration parameters for interlock	31
Table 12 Parameter configuration for interlocking behaviour	32
Table 13 Faceplate configuration for overriding an interlock	33
Table 14 Parameter configuration for interlock time-out	
Table 15 Configuration parameters for interlock	
Table 16 Parameter and faceplate configuration for local point of control	
Table 17 Faceplate configuration for Maintenance mode	
Table 18 Faceplate configuration for simulation mode	
Table 19 Faceplate configuration for Auto mode	37
Table 20 Faceplate configuration for Manual mode	38
Table 21 Faceplate configuration for Number of operations	
Table 221 ist of alarms and message configuration	40
Table 22 Eist of alarms and message configuration	
Table 24 Parameter and faceplate configuration for customized alarms	
Table 25 List of standard events and massage configuration	
Table 26 Significance of IODer components	
Table 20 Significance of IOPar components	
Table 27 Parameter and Taceplate configuration for Trend	
Table 28 Parameters of pmsCBStandardM	
Table 29 Name and description	
Table 30 Voltage Level	
Table 31 CBT ype and FBConfig	
Table 32 NormalMode	
Table 33 FollowLocalFB	
Table 34 EvSeverity, AlSeverity and Class	
Table 35 IOPar	
Table 36 Digital I/O for pmsCBStandardM	51
Table 37 Analogue Inputs for pmsCBStandardM	51
Table 38 FBConfig values	51
Table 39 Circuit breaker commands	
Table 40 AutoPar	52
Table 41 AutoPar components	52
Table 42 AlarmPar	52
Table 43 AlarmPar components	53
Table 44 IlockPar	53
Table 45 IlockPar components	53
Table 46 IlockConfig values	54
Table 47 ErrPar	54
Table 48 ErrPar for pmsCBStandardM	54
Table 49 Status	54
Table 50 Status parameters	54
Table 51 Checked positions and position related alarms (FBConfig=3)	55
Table 52 Parameters of the control module pmsCBIndM	58
Table 53 Parameter configuration for measurement signals	61
Table 54 Position status pmsCBIndM	62
Table 55 Configuration values for the FBConfig parameter	
Table 56 List of alarms and message configuration.	
Table 57 List of standard events and message configuration	
Table 58 Parameters of pmsCBIndM	
Table 59 Position feedbacks for pmsCBIndM	69

Table 60 Measurement connections	. 69
Table 61 Error signals	. 70
Table 62 Status (output)	. 71
Table 63 Control module pmsCBSyncM parameters	. 72
Table 64 Firmware version downloaded on the utilized controllers	. 77
Table 65 Heap utilization of pmsCBStandardM	. 77
Table 66 Heap utilization of pmsCBIndM	. 77
Table 67 Heap utilization of pmsCBSyncM	. 77
Table 68 Execution time of pmsCBStandardM	. 78
Table 69 Execution time of pmsCBIndM	. 78
Table 70 Execution time of pmsCBSyncM	. 78
Table 71 Breaker open/closed indications	. 79
Table 72 Truck position indications, IEC	. 80
Table 73 Truck position indications, ANSI	. 81
Table 74 Truck position indications, ANSI	. 82

# **About This User Manual**

### General

This User Manual provides the configuration information for the Circuit Breaker control modules, which are part of the PMS Library. The information in this manual is directed towards the project engineers.

The reader should be familiar with the Control IT for AC 800M/C and Operate IT environment.

## **Document Conventions**

Microsoft Windows conventions are normally used for the standard presentation of material when entering text, key sequences, prompts, messages, menu items, screen elements, and so on.

The following conventions are used for the presentation of material:

- The words in names of screen elements (for example, the title in the title bar of a window, the label for a field in a dialog box) are initially capitalized.
- Capital letters are used for the name of a keyboard key if it is labelled on the keyboard. For example, press the ENTER key.
- Lowercase letters are used for the name of a keyboard key that is not labelled on the keyboard. For example, the space bar, comma key, and so on.
- Press CTRL+C indicates that you must hold down the CTRL key while pressing the C key (to copy a selected object in this case).
- The names of push and toggle buttons are boldfaced. For example, click OK.
- The names of menus and menu items are boldfaced. For example, the File menu.
- The following convention is used for menu operations: MenuName > MenuItem > CascadedMenuItem. For example: choose File > New > Type.
- The Start menu name always refers to the Start menu on the Windows Task Bar.
- System prompts/messages are shown in the Courier font, and user responses/input in boldfaced Courier font. For example, if you enter a value out of range, the following message is displayed:

Entered value is not valid. The value must be 0 to 30.

• You may be instructed to enter the string TIC132 in a field. The string is shown as follows in the procedure:

**TIC132** 

• Variables are shown in italics:

IOPar.Govmode8.value

• Faceplate tabs are boldfaced:

AVR Mode handler

### Warning, Caution, Information, and Tip Icons

This publication includes **Warning**, **Caution**, and **Information** if/where appropriate to point out safety related or other important information. It also includes **Tip** to point out useful hints to the reader. The corresponding symbols should be interpreted as follows:



Electrical warning icon indicates the presence of a hazard which could result in *electrical shock*.

Warning icon indicates the presence of a hazard which could result in personal injury.

Caution icon indicates important information or warning related to the concept discussed in the text. It might indicate the presence of a hazard which could result in *corruption of software or damage to equipment/property*.



Information icon alerts the reader to pertinent facts and conditions.

Tip icon indicates advice on, for example, how to design your project or how to use a certain function.

Although **Warning** hazards are related to personal injury, and **Caution** hazards are associated with equipment or property damage, it should be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process performance leading to personal injury or death. Therefore, comply fully with all **Warning** and **Caution** notices.

# Terminology

 Table 1 lists terms used in this document and associated with the Process Power Manager 5.

 The reader should be familiar with these terms before proceeding further in this user manual.

Term	Description
AC 800M/C Connect	Name of the connection/integration between Control IT for AC 800M/C and Operate IT. The following software packages are included under this name: - Aspect System for AC 800M/C - Graphics Object Type Library for AC 800M/C
Aspect	A description of some properties of an Aspect Object. Some examples of aspects are name, circuit diagram, process display and control logic.
Aspect Object	A computer representation of a real object, such as a pump, a valve, an order or a virtual object, such as a service or an object type. An Aspect Object is described by its aspects and these aspects are organized in structures.
Aspect System for AC 800M/C	One part of the AC 800M/C Controller Integration product (the other part is the Graphics Type Library for AC 800M/C, see below). Gives access to the controllers AC 800M, AC 800C and Advant Controller 250, by mirroring all functions in the controllers and their I/O to Operate IT Process Portal from Control Builder Professional.

#### Table 1 Terminology

Connectivity Server	Provides the integration between the Operate IT system and a controller or a device capable of sourcing data.
Contingency	An electrical network within the plant consists of at least one load busbar to which loads, generation and the public grid can be connected. Several of these electrical networks can exist at the same time within the plant electrical network. Each combination is called a contingency.
Control Builder M	Name of the Control Builder M software products. Available in three versions: Control Builder Basic, Control Builder Standard and Control Builder Professional. These are fully integrated Windows 2000 Professional / Windows XP applications for efficient configuration and programming of the ABB controllers AC 800M, AC 800C and Advant Controller 250.
Control Builder Professional	The powerful programming version of the Control Builder M software.
Control Builder Project Explorer	The name of the project navigator in the Control Builder M software, which is used to navigate through, create or modify an automation project.
Control IT for AC 800M/C	The name of the collection of ABB hardware and software products for AC 800M/C.
Control Network	Product name of the ABB network between AC 800M/C controllers, tools and Operator workplaces.
Critical breaker	A breaker the position of which determines the electrical network configuration.
Display Element	A graphical element, which illustrates an object (motor, regulator etc.). In general, clicking on the element will show a faceplate for supervision and control of the object.
Electrical network	A combination of components such as load busbars, generators, transformers and cables connected electrically. A network contains at least one load busbar.
Faceplate	A configurable type of graphic interface normally used by operators for process supervision and control.
Graphics Type Library for AC 800M/C	One part of the AC 800M/C Controller Integration product (the other part is the Aspect System for AC 800M/C, see above). Graphic aspects such as display elements, faceplates and dialogs are available for use in Operate IT Workplace. The graphic aspects correspond to the types delivered in the Control Builder library.
HSI	Human System Interface.
	An individual description of the type.
Instance	Every instance has the characteristics defined by the type, but each instance has its own individual behaviour.
I/O	Input / Output signals.
IT	Information Technologies.
LVS	Low Voltage Switchgear.
MCC	Motor Control Center.
MMS	Manufacturing Message Specification. Specifies the structure of messages used for industrial communication (manufacturing, process robotics, etc.). This is the application layer used within MAP (Manufacturing Automation Protocol), a specification for open communication based on the OSI model. MMS for AC 800M/C is a protocol used in ABB Control Network communication.

Object	Objects represent the combination of data and associated procedures (operations that can be applied to the data) are represented. Objects represent significant elements or functions in the process control/process automation domain. Combining these objects creates applications.
OPC	OLE for Process Control. The Control IT for AC 800M/C software contains an OPC Server for AC 800M/C.
Operate IT	The name of the collection of ABB products for daily operation and supervision of an automated process. These products provide an environment for different user categories, such as engineers, operators and maintenance personnel.
Plant Explorer	The name of the project or plant navigator in the Operate IT workplace for creating the Aspect Objects that are used for assembling various components of the plant. Can also be used for browsing and searching the structures of the plant.
PMS	Power Management System.
PPM	Process Power Manager
Process Panel	The name of the ABB product for local process monitoring and control. The key functionality is presentation of process information (numerical, text or graphical) on local operator or process panels including functional control keys.
Process Portal A	The name of the ABB product for process monitoring and control. The key functionality is presentation of process graphics, usage of faceplates, presentation of trends, and presentation of alarms.
Structure	A hierarchical tree organization of Aspect Objects that describes the dependencies between the real objects. An Aspect Object can exist in multiple structures, e.g. both in a functional structure and in a location structure.
System Extension	A plug-in software package, which provides the Operate IT system with extended functions and properties.
Туре	A general description of a unit that defines the behaviour of an individual unit called Instance. See also Instance.
DCS	Distributed Control System
ENMC	Electrical Network Monitoring & Control

## **Related Documentation**

Related documentation includes, but is not limited to, the table below. Other ABB 800xA documentation may also be relevant when configuring an 800xA Process Power Manager.

Document ID	Title
3BNP100234-0390	PMS Library 5.6-5 Release Notes
3BNP100234-0391	PMS Library 5.6-5 Circuit Breaker Control
3BNP100234-0392	PMS Library 5.6-5 Generator Control
3BNP100234-0393	PMS Library 5.6-5 Transformer Control
3BNP100234-0394	PMS Library 5.6-5 Loadshedding
3BNP100234-0395	PMS Library 5.6-5 Power Control
3BNP100234-0396	PMS Library 5.6-5 Restart & Reacceleration
3BNP100234-0397	PMS Library 5.6-5 Report Data Collector
3BNP100234-0398	PMS Library 5.6-5 Synchronization
3BSE037410	Administration and Security

#### Table 2 Related Documentation

## **Target Audience**

This user manual is primarily intended for technical sales personnel, application, system engineers and maintenance personnel within ABB, external users and customers.



This user manual does not contain last-minute product information and updates which might affect functionality and/or performance. For information on last revisions, late changes and restrictions the user shall refer to *Release Notes*.



Some graphics have been carried over from previous loadshedding manuals, hence Windows frames, aspect names, library versions, etc. might be different than in current 800xA and PMS version. (e.g. PG2 suffix in aspect names is no longer present, etc.)

# Compatibility

For compatibility with previous versions of the product, refer to the *Release Notes*.

## **System Security**

The supplier of automation systems, based on PMS libraries, is responsible for the system integrity and security. We strongly recommend that strict password policies are applied.



Reference is made to document *Administration and Security*. The whole manual must be carefully consulted, with special attention given to *Security Planning* and *Security Configurations* for guidelines regarding system security, user authentication and password policies and setting up audit trails.

# **Section 1 Function**

There are three types of circuit breaker control modules in the PMS Library pmsCBLib:

- *pmsCBStandardM* Circuit breaker with control and supervision features.
- *pmsCBIndM* Circuit breaker with no control, only supervision features.
- *pmsCBSyncM* Circuit breaker with control, supervision and synchronization features.

The three control modules are described in the following chapters.

# Section 2 Control Module pmsCBStandardM

The *pmsCBStandardM* control module is included in the *pmsCBLib* library. A block presentation of the control module is shown in Figure 1. The parameters are briefly described in Table 3.



Figure 1 Control module pmsCBStandardM

Parameter	Significance			
Name	Name of the circuit breaker. With the name upload tool from the process portal, this property will be used for identifying the object in 800xA. The name will be used to group the alarms and events and to identify the faceplate of the object. The name must be unique in the project.			
Description	Description of the circuit breaker. With the name upload tool of process portal, this property will be used for identifying the object in 800xA.			
Voltage level	Voltage level for object colouring. This property gives the object a colour in Single Line Diagrams. Default settings for the colours are: Level 1 - RGB N(0,176,232) - D(0,126,182) - L(50,226,255) Level 2 - RGB N(232,160,168) - D(182,110,118) - L(255,210,218) Level 3 - RGB N(176,232,176) - D(126,182,126) - L(226,255,226) Level 4 - RGB N(255,255,128) - D(205,205,78) - L(255,255,178) Level 5 - RGB N(64,128,128) - D(14,78,78) - L(114,178,178)			
	Level 6 - RGB N(198,101,0) - D(140,70,0) - L(255,154,53) Level 7 - RGB N(240,160,13) - D(182,121,10) - L(249,209,136) Level 8 - RGB N(207,204,73) - D(153,150,40) - L(227,225,149) Level 9 - RGB N(81,181,171) - D(53,125,120) - L(174,221,217) Level10- RGB N(185,157,91) - D(135,112,58) - L(223,210,181)			

Table 3 Parameters	of the	control	module	pmsCBStandardM
--------------------	--------	---------	--------	----------------

Parameter	Significance
СВТуре	The parameter is used for configuring the graphical presentation of the circuit breaker; '1'= circuit breaker, '3'= isolator (disconnector), '11'= circuit breaker with earthing, '13'= isolator (disconnector) with earthing.
FBConfig	Configuration parameter for position status signals applicable for the circuit breaker; '0'= Open and Closed positions, '1'= Closed position, '2'= Open, Closed and Service positions, '3'= Closed and Service positions, '4'= Open, Closed, Service position and Test Position, '5'= Closed, Service position and Test position.
NormalMode	The parameter is used to configure the graphical presentation of normal mode; '1'= Manual, '2'= Auto, '3'= Local, ref. Table 7 Breaker indications
FollowLocalFB	Configuration parameter for the circuit breaker when in local point of control 'False'= Cmd0\Cmd1Level output is reset in local, 'True' = Cmd0\Cmd1Level follows FB in local.
AlSeverity	Alarm severity. The alarm severity can be used for filtering the alarm list. Range 1-1000.
EvSeverity	Event severity. The event severity can be used for filtering the event list. Range 1-1000.
Class	Alarm and Event Class. This property can be used for grouping objects to appear in separate alarm/event lists. Range 1-9999.
IOPar	Input/Output signals. This parameter is used for connecting the I/O signals to the object. This parameter is a structured data type.
AutoPar	Structured parameter for connecting auto open/close commands to the circuit breaker.
AlarmPar	Structured parameter for 16 user defined alarms.
EventPar	Structured parameter for 16 user defined events.
llockPar	Structured parameter for and configuring interlock signals.
ErrPar	Structured parameter for error signals to the circuit breaker.
MeasPar	Structured parameter for 16 user defined analogue measurements.
ExtPar	External parameters for application interaction. With this parameter it is possible to disable standard alarms and to disable the mode command buttons of the faceplate.
Status	Status indication for the checked closed/open position and the manual/auto mode of the breaker.

## **2.1 Introduction**

The control module type *pmsCBStandardM* provides control and supervision of circuit breakers. Following features are supported:

#### • Measurements

There are two kinds of mesurements, standard and customized:

- Standard measurements: Important electrical measurements displayed in the main faceplate tab:
  - Voltage
  - Frequency
  - Active power
  - Reactive power
  - Power factor
  - Current
- Customized measurements: Additionally, up to 16 customized measurements can be displayed numerically in another faceplate tab.

#### Position status

The following feedback signals facilitates supervision of circuit breaker position status:

- o Open indication
- o Closed indication
- Service position
- Test position
- o Earthed position

#### • Graphical Standard - IEC, ANSI

The graphical element can be configured to follow either the IEC or ANSI graphical standard.

#### • Output commands

Open and close commands can be issued as pulsed or as steady outputs:

- Open command (level)
- Open command (edge)
- Close command (level)
- Close command (edge)

Pulsed outputs remain high for a configurable time period. Steady outputs remain active until the opposite command is initiated. The control module checks for discrepancies between output commands and position status. Conflicts will raise alarms after a configurable period.

In local point of control steady outputs follow local feedback if the parameter 'Follow LocalFB' is set to 'True'.

#### • Interlocking

The circuit breaker can be interlocked for operation by conditions arising from supervisory programs or other objects. Five interlocks are available; one A-interlock (which can be overridden) and four B-interlocks.

#### • Point of Control (PoC)

The circuit breaker can be controlled from two locations:

- o Remote point of control: PMS-level of control via ABB's graphical aspects.
- Local point of control: equipment-level of control via vendor's local panel.

#### Control modes

Different control modes affect the operability:

- Maintenance mode: No operation commands are allowed.
- Simulation mode: The operation commands are simulated.
- Auto mode: Operation commands are controlled by application logic.
- Manual mode: Operation commands are issued via the faceplate.

#### • Operation commands

Following operations are available to the operator via the circuit breaker faceplate:

- Change of control modes
- Open/Close commands
- Override interlock

#### • Operations counter

A counter is provided to calculate how many times the circuit breaker is operated. It only counts when the circuit breaker is opened and it does not count when the maintenance or simulation mode are activated.

#### • Alarms

Alarms are divided in two categories:

- Standard alarms: : Alarms informing the operator of essential alarm conditions, and conditions arising from internal control module logic.
- Customized alarms: Up to 16 customized alarms can be raised through the control module although they originate from external logic.

#### • Events

Events are divided in two categories:

- Standard events: Default events informing the operator of operational status changes according to internal logic of the control module.
- Customized events: Up to 16 customized events informing the operator of status/events programmed outside the control module logic.

# 2.2 Detailed Engineering

#### 2.2.1 Operator Note



Figure 2 Operator note

The Operator Note is an aspect in the Control Structure that can contain information that an operator may wish to share with other operators. When the operator presses the button (1), a window with an editor will be opened, in which the operator can write a message. When the aspect contains information, this will be indicated with an envelope (2) in the faceplate and with an "I" (3) in the graphic element.



Only users with operator role can write to the Operator Note aspect.

#### 2.2.2 Measurements

The faceplate tab **Main** presents the standard measurements, as shown in Figure 3. These analogue signals are configured via the IOPar parameter of the control module, as shown in Table 4.

	👑 CBSt	andardM : Faceplate_PG2	_		🙀 CBStandardM : Faceplate_PG2	
	$\overset{\frown}{\bigcirc}$	CBStanda pmsCBStan	ndM dardM		CBStandardM pmsCBStandardM	
				/		
	Main	Trend Alarms Events	Measurements		Maintenance Parameters Simulation Edit	
1 2 3 4 5 6	U f P Q F I	M I I 132.0 kV 50.0 Hz 22.0 MW 5.0 MVAr 0.97 50.0 A	Active Interlocks Interlock A Interlock B1 Interlock B2 Interlock B3 Interlock B4 Commands Open Close M Mode		Selection Meas. Handler ▼ 1 ♥ U 2 ♥ f 3 ♥ P 4 ♥ Q 5 ♥ PF 6 ♥ I	
		◊		B	00 000	ß

Figure 3 Faceplate tab Main and Extended faceplate, Edit

Table 4 Parameter configur	ation for measurement signals
----------------------------	-------------------------------

Field	Indication	Parameter configuration	Description
1	Voltage	IOPar.MeaInput.Voltage	Voltage measurement
2	Frequency	IOPar.MeaInput.Freq	Frequency measurement
3	Active power	IOPar.MeaInput.ActPow	Active power measurement
4	Reactive power	IOPar.MeaInput.RePow	Reactive power measurement
5	Power factor	IOPar.MeaInput.PowFact	Power factor measurement
6	Current	IOPar.MeaInput.Cur	Current measurement

The measurements which are not available can be hidden by deselecting them from the extended faceplate tab **Edit** in the extended faceplate.



There is no built in signal error handling for measurements inside the control module logic. External collection of relevant IO signal status must be made. The external code must set the ErrPar.IOErr to TRUE in case of signal error detection.

#### 2.2.3 Breaker Position

The circuit breaker position is presented in the Main tab of the faceplate, as shown in Figure 4.



Figure 4 Circuit breaker status

ltem	Indication	Parameter configuration	Description
1	Opened position	IOPar.OI	Feedback from open limit switch.
2	Closed position	IOPar.Cl	Feedback from close limit switch.
3	Racked-Out position	IOPar.SP, (IOPar.TP)	Feedback from 'in-service' limit switch.
4	Earthed position	IOPar.FBE	Feedback from earth-switch.

The *FBConfig* parameter shall be used for enabling the open and/or service position feedbacks, as shown in Table 6.



**Open, Closed** and **Test Position** feedback raise the IOError alarm automatically if faulty. The circuit breaker is not forced to **Manual** mode if rased through these signals.

The status of other relevant digital signal must be collected. The external code must set the ErrPar.IOErr to TRUE in case of signal error detection.



The control module is forced to **Manual** as long as the ErrPar.IOErr remains TRUE. When returning to FALSE the circuit breaker will return to **Auto** mode, if initially selected.

FBConfig value	Applicable feedback signals	Remarks
0	- Feedback Opened - Feedback Closed	Two limit switches are monitored; the Service Position input is not included. Note: service position is the opposite of racked out position.
1	- Feedback Closed	Only closed limit switch feedback is considered.
2	<ul> <li>Feedback Opened</li> <li>Feedback Closed</li> <li>Feedback Service Position</li> </ul>	Both opened and closed limit switches are considered in conjunction with the service position. Note: that if the service position is '0', i.e. the circuit breaker is racked out; the checked open indication is always true to indicate an electrical disconnection.
3	- Feedback Closed - Feedback Service Position	The close limit switch and the service position feedbacks are monitored.
4	<ul> <li>Feedback Opened</li> <li>Feedback Closed</li> <li>Feedback Service Position</li> <li>Feedback Test Position</li> </ul>	Both opened and closed limit switches are considered in conjunction with the service position. Both the service position and the test position is monitored before the circuit breaker is considered racked out; the checked open indication is always true to indicate an electrical disconnection.
5	- Feedback Closed - Feedback Service Position - Feedback Test Position	The close limit switch and both service position and test position feedbacks are monitored.

Table 6 Configuration values for the FBConfig parameter

#### 2.2.4 Graphic Symbol Standard

The graphic symbols standard (IEC or ANSI) used in the faceplates can be configured by setting the project constant **pmsConstants.cGraphicSymbolStd\_IEC\_ANSI**.

Value Standard		Symbols	
0		γ° Ϊ	
1(default)	IEC(default)	× *	
2	ANSI		

When ANSI is selected, the fill color of the symbol can be configured by setting

#### the project constant pmsConstants.cANSI\_FillColouring.

Value	Remarks	Symbols	
0(default)	Green = Open Red = Closed	•	
1	Not filled = Open Filled = Closed		

The position of the breaker symbol when racked out can be configured by setting

#### the project constant pmsConstants.cBreaker\_RackoutConfig.

Value	Remarks	Symbols		
0(default)	Move symbol outside line when racked out.	\$ \$ }		
1	Keep symbol on line when racked out.	(*,~) (*,~)	< ← → →	

See Appendix1 for detailed table with configuration and corresponding symbols.

### 2.2.5 Indications for Breaker Status, Mode, Alarm and Synchronization



Figure 5 Breaker indications

#### Table 7 Breaker indications

Item	Indication	Symbol		Description
		B		Maintenance
		F		Forced
1	Status	S		Simulation
		Ι		Interlocked
		B		Blocked
	Mode	÷		Earthed
		NormalMode		
		1 2	3	
2		M M	Μ	Manual
		A A	Α	Auto
		LL	L	Local
3	Alarm/Sync	Α		Alarm
		Ι		Information (Operator note)
		S		Indicates synchronizable breaker
		S		Synchronization request active

#### 2.2.6 Output commands

The commands can be either pulsed or steady outputs. The pulsed open and close commands are available through the output parameters *IOPar.Cmd0Edge* and *IOPar.Cmd1Edge*, respectively. The pulse time is configurable, as shown in Figure 6. The steady open and close commands are available through the output parameters *IOPar.Cmd0Level* and *IOPar.Cmd1Level*, respectively.

Table 8 Output open and close commands from pmsCBStandardM

Item	Output	Parameter configuration	Description
1	Open command	IOPar.Cmd0Edge	Pulsed open command
		IOPar.Cmd0Level	Continuous open command
2	Close command	IOPar.Cmd1Edge	Pulsed close command
		IOPar.Cmd1Level	Continuous close command



Figure 6 Faceplate tab Parameters - Pulse time configuration

Field	Indication	Faceplate configuration	Description
1	Switch over time	Numerical input field	Time duration before intermediate position alarm is activated.
2	Truck switch over time	Numerical input field	Time duration before intermediate position alarm for truck is activated.
3	Pulse Time	Numerical input field	Time duration for open/close pulsed type commands to the circuit breaker.

The *FollowLocalFB* parameter shall be used for configuring the behavior of the steady open and close commands *IOPar.Cmd0Level* and *IOPar.Cmd1Level* when the circuit breaker is in local point of control. The open and close steady commands behavior is described according to Table 10.

FollowLocalFB value	IOPar.POCLoc value	Remarks
false	false	<i>IOPar.Cmd0Level</i> and <i>IOPar.Cmd1Level</i> are not following the position feedback signals.
true	false	<i>IOPar.Cmd0Level</i> and <i>IOPar.Cmd1Level</i> are not following the position feedback signals.
true	true	<i>IOPar.Cmd0Level</i> and <i>IOPar.Cmd1Level</i> are following the position feedback signals.

Table 10 Configuration values for the FollowLocalFB parameter

If the circuit breaker is in remote point of control, the steady output commands remain active until the opposite command is initiated.

#### 2.2.7 Interlocking

The interlocking function prevents the operation of the open/close command buttons in the circuit breaker faceplate. This function does not have any impact on the actual position of the breaker; it is an operation restriction for the open or close commands.

One process interlock (Interlock A) and four safety interlock (Interlock B1, B2, B3 and B4) are available for interconnection with other control modules or dedicated digital input signals. The interlock status is presented to the operator through the faceplate, as shown in Figure 7.

un costanuaru	M : Faceplate_PG2		1
	CBStandard pmsCBStanda	IM ardM	
Main Trend	d   Alarms   Events   M	easurements	]
U f Q	132.0 kV 50.0 Hz 22.0 MW 5.0 MVAr	Active Interlocks	- 1 - 2 - 3 - 4 - 5
PF I	0.97 50.0 A	M Mode	

Figure 7 Presentation of interlock in the main faceplate

Table 11 Configuration parameters for interlock				
Field	Indication	n Parameter Description configuration		
1	Interlock A	llockPar.llockA	Interlock condition active when IlockPar.IlockA = true.	
2	Interlock B1	llockPar.llockB1	Interlock condition active when IlockPar.IlockB1 = true.	
3	Interlock B2	llockPar.llockB2	Interlock condition active when IlockPar.IlockB2 = true.	
4	Interlock B3	llockPar.llockB3	Interlock condition active when IlockPar.IlockB3 = true.	
5	Interlock B4	llockPar.llockB4	Interlock condition active when IlockPar.IlockB4 = true.	

110

The parameter *llockPar* must be used for configuring how an interlock condition shall affect the open or close command buttons. It is possible to assign a condition as an interlock for opening or closing or both opening/closing, as shown in Table 12.

ltem	Parameter configuration	Description
1	llockPar.llockAConfig	When parameter is 1, the open command button is disabled. When parameter is 2, the close command button is disabled. When parameter is 3, the open and close command buttons are disabled.
2	llockPar.llockB1Config	When parameter is 1, the open command button is disabled. When parameter is 2, the close command button is disabled. When parameter is 3, the open and close command buttons are disabled.
3	llockPar.llockB2Config	When parameter is 1, the open command button is disabled. When parameter is 2, the close command button is disabled. When parameter is 3, the open and close command buttons are disabled.
4	llockPar.llockB3Config	When parameter is 1, the open command button is disabled. When parameter is 2, the close command button is disabled. When parameter is 3, the open and close command buttons are disabled.
5	llockPar.llockB4Config	When parameter is 1, the open command button is disabled. When parameter is 2, the close command button is disabled. When parameter is 3, the open and close command buttons are disabled.





If any of the parameters in Table 12 is configured with a value different than 1, 2 or 3, the interlocking function will not work.

It is possible for an operator to override the interlock A, as shown in Figure 8.

👑 CBSt	andardM : Faceplate_PG2		🕍 CBSI	andardM : Faceplat	te_PG2		×
	CBStanda pmsCBStan	ndM dardM		C pm:	BStanda sCBStan	ardM dardM	
							<u>/</u>
Main	Trend Alarms Events	Measurements	Main	Trend Alarms	Events	Measurements	
		Active Interlocks				Active Interlocks	
		I Bypass on Bypass	off			I Interlock A	
	1	Interlock B1		Ţ		Interlock B1	
	M	Interlock B2		мŢ		Interlock B2	
	1	Interlock B3				Interlock B3	
		Interlock B4				Interlock B4	
U	132.0 kV	Commands	U	132	.0 kV	Commands	
f	50.0 Hz	Open	f	50	.0 Hz	<b>O</b>	
Р	22.0 MW	Open	Р	22	.0 MW	U Open	
Q	5.0 MVAr	Close	Q	5	.0 MVAr	Close	
T	50.0A	M Mode	PF I	50	97 10 A	M Mode	
	outri			50			
	0 00	  کر  ∞		0	00	000	8

Figure 8 Override of interlock A

Field	Indication Configuration method		Description	
1	Bypass	Option button	Override of interlock A	

The override of interlock A can be automatically reset, after a timer has elapsed while the faceplate is selected for control (via the object-lock icon). The configuration is done via the *llockPar*, as shown in Table 14. In this way, the override function will not be active continuously, but only when an operation is required.

Table 14 Parameter configuration for interlock time-	out
------------------------------------------------------	-----

Item	Parameter configuration	Description
1	llockPar.llockAtimed	If parameter is true, then the reset is enabled by timeout or selection.
2	llockPar.llockAtimeout	Timer duration for the override reset, if <i>llockPar.llockAtimed</i> = true.

The text description of the interlock conditions can be configured via the extended faceplate tab **Edit > Interlocks**, as shown in Figure 9.

	CBStandardM pmsCBStandardM	
1)	Maintenance Parameters Simulation Edit Selection Interlocks Interlock A Interlock B1 Interlock B2 Interlock B3 S Interlock B4	

Figure 9 Faceplate tab Edit for Interlocks

Field	Indication	Configuration method	Description
1	Interlock A	Text input field	Interlock description. Empty field hides the interlock from faceplate.
2	Interlock B1	Text input field	Interlock description. Empty field hides the interlock from faceplate.
3	Interlock B2	Text input field	Interlock description. Empty field hides the interlock from faceplate.
4	Interlock B3	Text input field	Interlock description. Empty field hides the interlock from faceplate.
5	Interlock B4	Text input field	Interlock description. Empty field hides the interlock from faceplate.

#### Table 15 Configuration parameters for interlock

#### 2.2.8 Point of Control

The circuit breaker can be controlled from two different levels, either locally or remotely:

The Local point of control is the equipment-level. This is any kind of panel located locally at the field equipment.

The Remote point of control is the PMS-level of control. This is the OperateIT graphical aspects of the control module provided by ABB's PMS Library.

When the parameter *IOPar.POCLoc.Value* is True, the circuit breaker is expected to be locally controlled (e.g. via local panel).



Figure 10 Local point of control

Field	Indication	Configuration method	Description
1	Local icon	IOPar.POCLoc.Value	When <i>IOPar.POCLoc.Value</i> = True, the breaker is in local point of control and a graphic symbol is shown in the faceplate.

#### 2.2.9 Control modes

The circuit breaker supports the following control modes (listed in order of priority):

- o Maintenance mode
- o Simulation mode
- $\circ \quad \text{Auto mode} \quad$
- o Manual mode

#### 2.2.9.1 Maintenance Mode

If the circuit breaker is being serviced by an electrician, unnecessary alarms can be inhibited and operational commands can be blocked by activating the maintenance mode. This mode is enabled from the faceplate tab **Block**, as shown in Figure 11. It is also possible to block the control/alarms/events, without enabling the maintenance mode, by utilizing the **Block control**, **Block alarms** and **Block events** check boxes.

CBStandardM pmsCBStandardM	CBStandardM pmsCBStandardM	
Maintenance       Parameters       Simulation       Edit         Maintenance       Maintenance on Maintenance off       Block control         Block alarms       Block events         Operations       1         Actual Operations       100         Preset operations       0         Reset number of operations       Reset	Main Trend Alarms Events Measurements Active Interlocks Active Interlocks Interlock B1 Interlock B2 Interlock B3 Interlock B4 U 132.0 kV f 50.0 Hz P 22.0 MW Q 5.0 MVAr PF 0.97 I 50.0 A M Mode	
<u> </u>		

Figure 11 Extended faceplate, maintenance mode

Field	Indication	Parameter configuration	Description
1	Maintenance mode	Option button	Enables/disables the maintenance mode.
2	Block control	Option button	Enables/disables the Block control.
3	Block alarms	Option button	Enables/disables the Block alarms.
4	Block events	Option button	Enables/disables the Block events.
5	Maintenance icon	Graphic symbol	Indication that maintenance mode is active.

Table 17 Faceplate configuration for Maintenance mode

#### 2.2.9.2 Simulation Mode

The simulation is a practical mode that allows software functionality testing in a controlled environment (for example during Factory Acceptance Test) without creating application logic outside the control module. The simulation is accessible from the faceplate tab **Simulation**, as shown in Figure 12.

🔀 CBStandardM : Faceplate_PG2		🚾 CBStandardM : Faceplate_PG2
CBStandardM pmsCBStandardM		CBStandardM pmsCBStandardM
Maintenance Parameters Simulation Edit Simulation	6	Main Trend Alarms Events Measurements Alarms Events Measurements Active Interlocks Interlock A Interlock B1 Interlock B2 Interlock B3 Interlock B4 U 132.0 kV f 50.0 Hz P 22.0 MW Q 5.0 MVAr PF 0.97 I 50.0 A M Mode
00 000	R	جر 👐 💿

Figure 12 Faceplate tab Simulation

Field	Indication	Configuration method	Description
1	Simulation mode	Option button	Enables/disables the simulation.
2	Simulate feedback	Option button	Feedback follows issued commands.
3	Simulation limit switch Open	Option button	Selects simulated open position.
4	Simulation limit switch Close	Option button	Selects simulated closed position.
5	Simulation racked out	Option button	Selects simulated racked-out position.
6	Simulation icon	Graphic symbol	Indication that simulation mode is active.

Table 18 Faceplate configuration for simulation mod
-----------------------------------------------------

If the **Simulate feedback** checkbox is checked, the feedback positions will follow the open/close commands. Auto or manual mode can be selected. By selecting either **Simulation limit switch Open / Close / Racked-out** the feedbacks will be forced into the desired position. This allows simulation of position error alarms. No actual commands are being issued to the circuit breaker outputs.



The simulation must not be activated during normal operation of the plant. This may lead to dangerous situations for equipment and personnel.

#### 2.2.9.3 Auto Mode

The **Auto** mode is intended for open or close commands issued by an external code.

As long as there are no relevant interlocks active and parameter AutoPar.AutoSel is TRUE then parameters AutoPar.AutoCmd0 and AutoPar.AutoCmd1 will open or close the circuit breaker, respectively, on rising flank. Automatic open or close commands are accepted as long as the circuit breaker is in remote point of control. Open and close command pushbuttons are disabled in Auto mode, as shown in Figure 14.

Auto mode can be activated from the mode option button in the faceplate or when the parameter AutoPar.AutoSel is set from False to TRUE. The Auto mode option will be disabled (dimmed) when the parameter ExtPar.ExtDimAutoMode is TRUE or if Auto mode is active.



Selecting Auto/Manual from faceplate does not change status on AutoPar.AutoSel.

Writing to AutoPar.AutoSel, however, changes mode indicated in the faceplate.

If mode selection shall be done via faceplate the output parameters Status. AutoMode and Status.ManMode must be connected to the input parameters AutoPar.AutoSel and AutoPar.ManSel respectively.

기 ( 그와 그와 비비 ) 20 ( 🔚 드리 ) then \*\*\* 147 ( 전\* 167)

Ref example in Figure 13 Auto and Manual status connected back to AutoPar input.

pCBPar.CB18\_BusTieEF.AutoPar.AutoSel := pCBPar CB18\_BusTieEF Status AutoMode; pCBPar.CB18\_BusTieEF.AutoPar.ManSel

:= pCBPar.CB18\_BusTieEF.Status.ManMode;





Figure 14 Main faceplate, Auto mode

Table 19 Faceplate configuration for Auto mode

Field	Indication	Configuration method	Description
1	Auto/manual icon	Graphic symbol	Indicates that Auto (A) or Manual (M) mode is active.
2	Auto/Manual	Option button	Button for selecting Auto/Manual.
#### 2.2.9.4 Manual Mode

The Manual mode shall be used when the open or close commands are issued from the faceplate command buttons. The open or close command buttons will be enabled when the circuit breaker is in remote point of control and there is no active interlock condition.

The Manual mode can be activated from the Manual/Auto mode button in the faceplate or when the parameter *AutoPar.ManSel* is set from False to True. The Manual mode button will be disabled (dimmed) when the parameter *ExtPar.ExtDimManMode* is True or when the Manual mode is already active, as shown in Figure 15.



Figure 15 Main faceplate, Manual mode

Table 20	Faceplate	configuration	for	Manual	mode
----------	-----------	---------------	-----	--------	------

Field	Indication	Configuration method	Description
1	Auto/manual icon	Graphic symbol	Indicates that Auto (A) or Manual (M) mode is active.
2	Open button	Push button	Open command button.
3	Close button	Push button	Close command button.
4	Auto/Manual	Option button	Button for selecting Auto/Manual.

# 2.2.10 Operation commands

The following operation features are provided the operator via the circuit breaker faceplate:

- Change of control modes (refer to section 2.2.9)
- Open and Close commands (refer to section 2.2.6)
- View the circuit breaker status (refer to section 2.2.5)
- View and override interlocks (refer to section 2.2.7)

# 2.2.11 Operations counter

Every time the circuit breaker is opened a counter is activated, accumulating the number of circuit breaker opening operations. A configurable limit is provided to aid in the maintenance planning. An alarm is generated, when the number of operations has been exceeded. The counter should be reset after maintenance is carried out.

🕊 CBStandardM : Faceplate_PG2	1	👑 CBSta	ndardM : Fa	aceplate_PG2		_ 🗆 X
CBStandardM pmsCBStandardM		$\sim$		CBStand pmsCBSta	dardM andardM	
Maintenance Parameters Simulation Edit		Main	Trend Ala	arms Events	Measurements	
Maintenance		O Bre	eaker inter	r. pos. (00)	🔘 Alarm text 4	
Maintenance mode		O Bre	eaker pos.	. error (11)	Alarm text 5	
		O Tru	uck inter.	pos. (00)	🔘 Alarm text 6	
Block control		O Tru	uck pos. e	error (11)	🔘 Alarm text 7	
Block alarms		O AC	OF Error	-	Alarm text 8	
Block events		O IO	Error		🔘 Alarm text 9	
Occurting		O Cor	mm. Error	r (	🔘 Alarm text 10	
Operations		O Pro	otection tri	rip	Alarm text 11	
Actual Operations 5		O Spi	urious ope	eration	🔘 Alarm text 12	
Max. number of operations 4	-25-	- O Ma	ax no. of o	operations	Alarm text 13	
Preset operations 3	_3 _	O She	ed comma	and	Alarm text 14	
Reset number of operations Reset	-4	O Ala	arm text 1		Alarm text 15	
		O Ala	arm text 2	2	Alarm text 16	
		O Ala	arm text 3	1		
اکر 🚥 💿				0	·	ß

Figure 16 Faceplate tab Maintenance, Number of operations counter

Field	Indication	Configuration method	Description
1	Actual operation	Numerical field	Operations counter.
2	Max. allowed operations	Numerical input field	Limit of allowed operations.
3	Preset operations	Numerical input field	Start value of the counter after reset.
4	Reset number of operations	Push button	Resets the operations counter.
5	Max. number of operations	Status box	The limit of operations is exceeded.

Table 2	1 Faceplate	configuration	for Number	of operations
		o o ning an a don		

# 2.2.12 Alarms

The control module supports standard and customized alarms:

- The standard alarms represent alarm conditions that are monitored by the internal logic of the control module.
- The customized alarms represent 16 free programmable alarm conditions that must be configured outside the control module.

Alarms presented in the tab Alarms of the circuit breaker faceplate, as shown in Figure 17.

CBSta pmsCBS	andardM StandardM
	1
Main Trend Alarms Eve	nts Measurements
Breaker inter. pos. (0	0) O Alarm text 4
- 🔘 Breaker pos. error (11	l) 🔘 Alarm text 5 ———
- O Truck inter. pos. (00)	Alarm text 6
Truck pos. error (11)	Alarm text 7
- O ACOF Error	Alarm text 8
O IO Error	Alarm text 9
- O Comm. Error	Alarm text 10
Protection trip	O Alarm text 11
- O Spurious operation	🔘 Alarm text 12
Max no. of operations	Alarm text 13
- 🔘 Shed command	O Alarm text 14
O Alarm text 1	Alarm text 15
O Alarm text 2	O Alarm text 16
O Alarm text 3	

Figure 17 Faceplate tab Alarms

Field	Indication	Alarm condition	Alarm message (Resource Id)	Note
1	Intermediate position (00)	When neither the open nor the closed position feedbacks are received; the parameters <i>IOPar.OI.Value</i> and <i>IOPar.CI.Value</i> are False for more than a configurable time.	NLSID_CBPosError	
2	Position error (11)	When both the open and closed position feedbacks are received; the parameters <i>IOPar.OI.Value</i> and <i>IOPar.CI.Value</i> are True.	NLSID_CBFault	
3	Truck intermediate position (00)	When neither the service nor the test position feedbacks are received; the parameters <i>IOPar.SP.Value</i> and <i>IOPar.TP.Value</i> are False for more than a configurable time.	NLSID_CBTruckPo sError	

Table 22 List of alarms and	I message configuration
-----------------------------	-------------------------

Field	Indication	Alarm condition	Alarm message (Resource Id)	Note
4	Truck position error (11)	When both the service and test position feedbacks are received; the parameters <i>IOPar.SP.Value</i> and <i>IOPar.TP.Value</i> are True.	NLSID_CBTruckPo sFault	
5	ACOF error	When a close or open command is issued and the proper change of position feedbacks has not occurred within a configurable time.	NLSID_CmdError	S
6	IO Error	The parameter <i>ErrPar.IOErr</i> is dedicated to receive any error indication from IO related to the circuit breaker. The alarm is activated when this parameter is True. The alarm is also activated when the position feedback signals are not reporting healthy status.	NLSID_IOError	
7	Communicati- on error	The parameter <i>ErrPar.ComErr</i> is dedicated to receive any error indication from communication links related to the circuit breaker. The alarm is activated when the parameter is True.	NLSID_ComError	
8	Protection	The parameter <i>ErrPar.ProtTrp</i> is dedicated to receive any trip indication from protection relays related to the circuit breaker. The parameter <i>ErrPar.LO</i> is used for receiving the hardwired trip signal. The alarm is activated when either of the parameters is True.	NLSID_ProtectionTr ip	
9	Spurious operation	When the position feedbacks are changing status without any command being issued, unless the circuit breaker is in local point of control.	NLSID_CBSpur	
10	Max. number of operations	When the circuit breaker is opened, a counter is increasing the number of operations. The alarm is activated when a configurable limit has exceeded.	NLSID_NoHL	
11	Shed command	The parameter <i>ErrPar.Shed</i> is dedicated to receive a shed indication from a load shedding application. The alarm is activated when the parameter is True.	NLSID_ShedCmd	
12	Alarm text 1	AlarmPar.UserDefAlm01stat.Signal	AlarmPar.UserDefAl m01stat.Message	
	Alarm text 16	AlarmPar.UserDefAlm16stat.Signal	AlarmPar.UserDefAl m16stat.Message	



Note: S = Supressed in Local control.

Each standard alarm can be disabled by configuring the corresponding parameter *ExtPar.DisAlmIntermedPos...*ExtPar.DisAlmShedCmd. When the value is set to True, the relevant alarm is disabled.

The parameter AlarmPar shall be used for implementing up to 16 user defined alarms. The alarm descriptions can be changed by editing the text fields in the extended faceplate tab **Edit** > **Alarms**, as shown in Figure 18.

2	y pn	CBStanda nsCBStand	rdM JardM
Mai	ntenance   Paramete	rs Simul	stion Edit
1 Your	Selection	•	
_ 1	Alarm text 1	9	Alarm text 9
- 2	Alarm text 2	10	Alarm text 10
- 3	Alarm text 3	11	Alarm text 11
- 4	Alarm text 4	12	Alarm text 12
- 5	Alarm text 5	13	Alarm text 13
- 6	Alarm text 6	14	Alarm text 14
	Alarm text 7	15	Alarm text 15
- /	1 · · · · · · · · · · · · · · · · · · ·	- Aller	and the second se

Figure 18 Faceplate tab Alarms for customized alarms

Table 23 Parameter and faceplate configuration for customized alarms					
	Table 22 Darameter	and faconiato	configuration f	or oustamized a	Jarma
		and laceplate	connguiation i		aiaiiiis

Field	Indication	Configuration method	Description
1	Alarm text 1 Alarm text 16	Text input field	Customized alarms description. Empty field hides the alarm from the faceplate.

# 2.2.13 Events

The control module supports standard and customized events:

- The standard events represent operational changes that are monitored by the internal logic of the control module.
- The customized events represent 16 free programmable status/event conditions that can be configured outside the control module.

The events are presented in the Event List. The customized events are also presented in the tab **Status** of the circuit breaker faceplate, as shown in Figure 19. The purpose of the customized events is mainly for user defined on/off type of status signals.

CBStandardM : Faceplate_PG2		🔀 CBStandardM : Facepla	ite_PG2	- I X
CBStandardM pmsCBStandardM		ا pn	CBStandardM nsCBStandardM	
Main Trend Alarms Events Measurements		Maintenance Paramete	rs Simulation Edit	
- O Status text 1 O Status text 15	8	Selection		
- O Status text 2 O Status text 16	8			
— 🔘 Status text 3		Events		
— 🔘 Status text 4		1		
— 🔘 Status text 5		- 1 Status text 1	9 Status text 9	1
— 🔘 Status text 6		- 2 Status text 2	10 Status text 10	
— 🔘 Status text 7		2 Chattan text 2		
— 🔘 Status text 8		- 3 Status text 3	II Status text II	
- O Status text 9	2	4 Status text 4	12 Status text 12	
- O Status text 10		- 5 Status text 5	13 Status text 13	
- O Status text 11		- 6 Status text 6	14 Status text 14	1
- O Status text 12		7 Status text 7	15 Status text 15	1
- O Status text 13		9 Status text 9	16 Status text 16	
- O Status text 14		o Status text o		
0 00 000	8	9	00 000	3

Figure 19 Faceplate tab Events / Edit for customized events

Field	Indication	Configuration method	Description
1	Status text 1	EventPar.UserDefEvt01stat.Signal	Status of the event condition (i.e. On, Off).
	Status text 16	EventPar.UserDefEvt16stat.Signal	
2	Status text 1	Text input field	Customized events description. Empty field hides the event from the faceplate.
	Status text 16		

Table 24 Parameter an	d faceplate	configuration	for custor	<i>mized events</i>
-----------------------	-------------	---------------	------------	---------------------

The text messages (i.e. in Event List) for the standard events are configurable via the Alarm and Event Translator aspect in Plant Explorer under Library Structure > Preferences & Customizations > PMS\_Alarm&Event. The messages can be changed from English language to another language by modifying the text description of a relevant Resource Id (NLSID\_), as shown in Figure 12, to a desired message (a text string up to 60 characters).

No.	Indication	Event condition	Event message On
1	Opened	Position feedback opened	NLSID_OpenPosition+ NLSID_EventOn (or NLSID_EventOff)
2	Closed	Position feedback closed	NLSID_ClosePosition+ NLSID_EventOn (or NLSID_EventOff)
3	RackedOut	Position feedback racked-out (not in service)	NLSID_RackedOutOn (or NLSID_RackedOutOff)
4	BlkAlm	Block alarms command button	NLSID_BlkAlarmOn (or NLSID_BlkAlarmOff)
5	BlkEvent	Block events command button	NLSID_BlkEventOn (or NLSID_BlkEventOff)
6	BlkCntrl	Block control command button	NLSID_BlkControlOn (or NLSID_BlkControlOff)
7	POC	Local point of control	NLSID_POCNumber+NLSID_Local (or NLSID_POCNumber+NLSID_CentralPortal)
8	RstOpCnt	Reset the number of operations counter	NLSID_RstOpCounter
9	SelMode	Mode change to Manual, Auto, Maintenance.	NLSID_Manual or NLSID_Auto or NLSID_Maintenance
10	OpenCmd	Open circuit breaker command button	NLSID_CmdOpen
11	CloseCmd	Close circuit breaker command button	NLSID_CmdClose
12	IntlBypass	Inhibit interlock A check box	NLSID_InterLockByPassOn (or NLSID_InterLockByPassOff)
13	llockAact	Interlock A active	NLSID_IlockA+NLSID_EventOn (or NLSID_EventOff)
14	llockB1act	Interlock B1 active	NLSID_IlockB1+NLSID_EventOn (or NLSID_EventOff)
15	llockB2act	Interlock B2 active	NLSID_IlockB2+NLSID_EventOn (or NLSID_EventOff)
16	llockB3act	Interlock B3 active	NLSID_IlockB3+NLSID_EventOn (or NLSID_EventOff)
17	IlockB4act	Interlock B4 active	NLSID_IlockB4+NLSID_EventOn (or NLSID_EventOff)

# Table 25 List of standard events and message configuration



It is possible to suppress each standard event from appearing in the Event List. This configuration is done via the input parameter *ExtPar* and the data type components starting with *DisEvt* (e.g. when the parameter *ExtPar.DisEvtOpenCmd* is set to true, the event for circuit breaker open command is disabled).

It is possible to assign another interlock event message, different from the standard, via the input parameter *ExtPar.ExtIlockEvtMsg*.

# 2.2.14 Required I/O

An overview of the *IOPar* components is listed in Table 26, with respect to significance when setting up the interface connections for the circuit breaker control module. The description "mandatory" implies that the internal logic of the control modules requires data from the variable in order to function properly. The description "optional" implies that the internal logic of the control modules can also handle data from the variable, but it could be omitted without affecting the functionality of the module.

Field	IO_Input	Importance	Description
1	IOPar.Cl	Mandatory	Closed position
2	IOPar.OI	Optional	Opened position
3	IOPar.SP	Optional	Racked-In position
4	IOPar.TP	Optional	Racked-Out position
5	IOPar.FBE	Optional	Earthed position
6	IOPar.DeadNetRelease	Optional	Dead net release condition
7	IOPar. POCLoc	Optional	Local point of control
8	IOPar.LO	Optional	Lock-out condition
9	IOPar.Cmd0Edge	Mandatory	Open command
10	IOPar.Cmd1Edge	Mandatory	Close command
11	IOPar.Cmd0Level	Optional	Open command
12	IOPar.Cmd1Level	Optional	Close command
13	IOPar.MeaInput.ActPow	Optional	Active Power
14	IOPar.MeaInput.RePow	Optional	Reactive Power
15	IOPar.MeaInput.Voltage	Optional	Voltage
16	IOPar.MeaInput.Freq	Optional	Frequency
17	IOPar.MeaInput.Cur	Optional	Current

Table 26 Significance of IOPar components

# 2.2.15 Trend

The **Trend** tab is used to monitor and display the historical data for the 6 main measurements:

- Active power
- Reactive power
- Voltage
- Current
- Frequency
- Power factor

It is possible to set which measurements to be displayed in the trend area. The check boxes shall show/hide the measurement signals, as shown in Table 27. A user with *Operator* role and *Operate* permission rights can perform the configuration of these parameters.



Figure 20 Faceplate tab Trend

Field	Indication	Configuration method	Description
1	Trend	Trend field	Used to display the historical data
2	Current	Check box	Show/hide the trace pen for I in the Trend field
3	Frequency	Check box	Show/hide the trace pen for F in the Trend field
4	Power factor	Check box	Show/hide the trace pen for Pf in the Trend field
5	Active power	Check box	Show/hide the trace pen for P in the Trend field
6	Reactive power	Check box	Show/hide the trace pen for Q in the Trend field
7	Voltage	Check box	Show/hide the trace pen for U in the Trend field
8	Max range	Input field	Y max margin
9	Min range	Input field	Y min margin
10	Max time	Input field	Max time value visible in the trend
11	Min time	Text field	Min time value visible in the trend

Table 27	' Parameter	and fa	aceplate	configuration	for	Trend
	i aramotor	and re	acoprato	ooningan ation		

# 2.3 Parameters

This chapter describes the parameters and configuration settings for the control module *pmsCBStandardM*.

	Name	Туре	Initial value	Description
1	Name	string[30]	'Name'	IN EDIT:Name of the object
2	Description	string[40]	'Description'	IN EDIT:Description of the object
3	VoltageLevel	tageLevel dint		IN EDIT:Voltage level [110], for object colouring
4	CBType dint		1	IN EDIT:[1=Circuit Breaker] [3=Disconnector] [11=Circuit Breaker w/Earth] [13= Disconnector w/Earth]
5	FBConfig dint		0	IN EDIT:Configuration of position feedbacks
6	NormalMode dint		1	IN EDIT: [1=Manual][2=Auto][3=Local]
7	FollowLocalFB	bool	false	IN EDIT: Configuration of Cmd0\Cmd1Level output
8	AlSeverity	dint	900	IN EDIT:Alarm severity
9	EvSeverity	dint	400	IN EDIT:Event severity
10	Class	dint	50	IN EDIT: Alarm and Event Class
11	IOPar	pmsCBIOPar	default	IN_OUT:Circuit Breaker I/O signals
12	AutoPar	pmsCBAutoPar	default	IN:Parameters for Auto mode control
13	AlarmPar	pmsExtAll	default	IN:For Extended Alarm indication In Faceplate
14	EventPar	pmsExtEvt	default	IN:For Extended Event indication in Faceplate
15	llockPar	pmslLockPar	default	IN:Interlock input signals and configuration
16	ErrPar	pmsErrPar	default	IN:Error Indication
17	MeasPar	pmsExtIO	default	IN:For Extended Measurements in Faceplate
18	ExtPar	pmsCBExtPar	default	IN:External parameters, for application interaction
19	Status	pmsCBstatus	default	OUT:Circuit Breaker status

# Table 28 Parameters of pmsCBStandardM

# 2.3.1 Parameter details

#### 2.3.1.1 Name and Description

#### Table 29 Name and description

	Name	Туре	Initial value	Description
1	Name	string[30]	'pmsCBStandardM'	IN EDIT:Name of the object
2	Description	string[40]	'pmsCBStandardM'	IN EDIT: Description of the object

The parameters Name and Description of the control module must be unique in the project. The text can be assigned directly.

e.g. : Name : 'CB3401A'

: Description : 'Circuit breaker 3401A'

#### 2.3.1.2 Voltage level

#### Table 30 Voltage Level

	Name	Туре	lnitial value	Description
3	VoltageLevel	Dint	1	IN EDIT VoltageLevel [1-10]

The VoltageLevel is used for the colour of the circuit breaker graphic object in 800xA displays.

#### e.g. : VoltageLevel: 3

In this example the colour of the breaker will be light green.

## 2.3.1.3 CBType and FBConfig

#### Table 31 CBType and FBConfig

	Name	Туре	Initial value	Description
4	СВТуре	dint	1	IN EDIT:[1=CB][3=Disc][11=CB w/Earth][13=Disc. w/Earth]
5	FBConfig	dint	0	IN EDIT:[0=FB0,FB1][1=FB1][2=FB0,FB1,SP][3=FB1,SP] [4=FB0,FB1,SP,TP][5=FB1,SP,TP]

The CBType parameter is used for determining the graphical presentation of the circuit breaker object in the 800xA displays. The FBConfig parameter is used for determining the combination of position signals that are applicable for a certain breaker.

e.g. : CBType: 3

# FBConfig: 0

In this example the circuit breaker will be shown as a disconnector with open and close position signals.

### 2.3.1.4 NormalMode

	Name	Туре	Initial value	Description
6	NormalMode	dint	1	IN EDIT: [1=Manual][2=Auto][3=Local]

Table 32 NormalMode

The *NormalMode* parameter is used for determining the graphical presentation of the mode indication in the 800xA displays. The mode which is configured as normal will be indicated in green, while the two other modes which are not the normal mode will be indicated in white/blue.

i.e. : NormalMode=1: A M L NormalMode=2: A M L NormalMode=3: A M L

#### 2.3.1.5 FollowLocalFB

#### Table 33 FollowLocalFB

	Name	Туре	Initial value	Description
7	FollowLocalFB	bool	false	IN EDIT: [False = Cmd0\Cmd1Level output is reset in local, True = Cmd0\Cmd1Level output follow FB in local]

The *FollowLocalFB* parameter is used to configure the value of the steady open and close commands *IOPar.Cmd0Level* and *IOPar.Cmd1Level* when the circuit breaker is in local point of control

e.g. : FollowLocalFB: true

IOPar.POCLoc: true

In this example the circuit breaker *IOPar.Cmd0Level* and *IOPar.Cmd1Level* will follow the value of the configured position feedback signals.

## 2.3.1.6 EvSeverity, AlSeverity and Class

## Table 34 EvSeverity, AlSeverity and Class

	Name	Туре	Initial value	Description
8	EvSeverity	Dint	900	IN EDIT: Event severity
9	AlSeverity	Dint	400	IN EDIT: Alarm severity
10	Class	Dint	50	IN EDIT: Alarm and Event Class

The *EvSeverity* and *AlSeverity* parameters are used for determining the severity of the internal alarms and events. The Class parameter determines the alarm and event class in the 800xA system.

## 2.3.1.7 IOPar

	Name	Туре	Initial value	Description
11	IOPar	pmsCBIOPar		IN_OUT: IO signals for Circuit breaker

Table 35 IOPar

Table 36 Digital I/O for pmsCBStandardM

The following components from the structured data type *IOPar* are used for the *pmsCBStandardM* connections to digital I/O signals:

POCLoc	Point of control set to Local (input)
OI	Feedback open limit switch (input)
CI	Feedback close limit switch (input)
SP	Feedback Service Position limit switch (input)
ТР	Feedback Test Position limit switch (input)
FBE	Feedback Earthed limit switch (input)
LO	Locked-out indication (input)
Cmd0Edge	Command open output pulse (output)
Cmd1Edge	Command close output pulse (output)
Cmd0Level	Command open output continuous (output)
Cmd1Level	Command close output continuous (output)

The parameter *IOPar.MeaInput* is used for connecting the standard analogue measurements to the control module. The measured values are presented in the faceplate.

Voltage	Voltage, U
Freq	Frequency, f
ActPower	Active Power, P
RePow	Reactive Power, Q
PowFact	Power Factor, cos φ
Cur	Current, I

#### Table 37 Analogue Inputs for pmsCBStandardM

The control module must be configured for the actual available position I/O of the circuit breaker. The parameter *FBConfig* value is 0-5, representing six possible configurations, as shown in the table below.

FBConfig	OI	CI	SP	ТР
0	OI	CI	-	
1	-	CI	-	
2	OI	CI	SP	
3	-	CI	SP	
4	OI	CI	SP	ТР
5		CI	SP	TP

#### Table 38 FBConfig values

As indicated in Table 38, configuration 0 or 1 is to be implemented when there is no racked out functionality required.

The parameters Out0Puls and Out1Puls (or Out0Continous and Out1Continous) shall be used for the opening or closing commands and must be connected to the output signals of the physical breaker.

Table 39 Circuit breaker command
----------------------------------

Out0Puls	OUT Command Open Pulse
Out1Puls	OUT Command Close Pulse
Out0Continous	OUT Continuous Open command
Out1Continous	OUT Continuous Close command

## 2.3.1.8 AutoPar

#### Table 40 AutoPar

	Name	Туре	Initial value	Description
12	AutoPar	pmsCBAutoPar		IN: Parameters for Auto mode control

The components from the parameter *AutoPar* are used for the *pmsCBStandardM* control module to create application logic for automatic open/close commands and manual/auto mode change.

#### Table 41 AutoPar components

AutoSel	Select Auto Mode
AutoCmd0	Auto open command
AutoCmd1	Auto close command
ManSel	Select Manual Mode

#### 2.3.1.9 AlarmPar

The parameter *AlarmPar* contains components for up to 16 user defined alarms. These alarms will have no effect on the control module functionality.

#### Table 42 AlarmPar

	Name	Туре	Initial value	Description
13	AlarmPar	pmsExtAll	default	IN: For Extended Alarm indication In Faceplate

UserDefAlm01stat	Status for User defined Alarm1
UserDefAlm02stat	Status for User defined Alarm2
UserDefAlm03stat	Status for User defined Alarm3
UserDefAlm04stat	Status for User defined Alarm4
UserDefAlm05stat	Status for User defined Alarm5
UserDefAlm06stat	Status for User defined Alarm6
UserDefAlm07stat	Status for User defined Alarm7
UserDefAlm08stat	Status for User defined Alarm8
UserDefAlm09stat	Status for User defined Alarm9
UserDefAlm10stat	Status for User defined Alarm10
UserDefAlm11stat	Status for User defined Alarm11
UserDefAlm12stat	Status for User defined Alarm12
UserDefAlm13stat	Status for User defined Alarm13
UserDefAlm14stat	Status for User defined Alarm14
UserDefAlm15stat	Status for User defined Alarm15
UserDefAlm16stat	Status for User defined Alarm16

#### Table 43 AlarmPar components

#### 2.3.1.10 llockPar

The circuit breaker can be interlocked for operation by signals from supervisory programs or other objects. A total of five interlocks are available: one A-interlock and four B-interlocks.

The A-interlock or process interlock has a lower priority than safety interlocks. The operator can override (or bypass) the A-interlock. Therefore careful consideration needs to be made before an interlock is implemented as A-interlock.

B-interlocks or safety interlocks have highest priority. The operator can not override the B-interlocks.

Table 44 I	llockPar
------------	----------

	Name	Туре	Initial value	Description
15	llockPar	pmsILockPar	default	Parameter for connecting and configuring Interlocks.

#### Table 45 llockPar components

llockAConfig	IN EDIT Interlock A Configuration
IlockB1Config	IN EDIT Interlock B1 Configuration
llockB2Config	IN EDIT Interlock B2 Configuration
llockB3Config	IN EDIT Interlock B3 Configuration
IlockB4Config	IN EDIT Interlock B4 Configuration
llockA	IN Interlock A input
llockB1	IN Interlock B1 input
llockB2	IN Interlock B2 input
llockB3	IN Interlock B3 input
llockB4	IN Interlock B4 input

The interlocks must be configured to either interlock the open, close or both open/close operations of the circuit breaker. The parameter llockXConfig value is 0-3, representing four possible configurations as shown in the table below.

	llockXConfig	Interlock Open command	Interlock Close Command
0		-	-
1		х	-
2		-	х
3		Х	Х

# Table 46 llockConfig values

#### 2.3.1.11 ErrPar

It is possible to connect externally triggered error signals to the control module. These error signals only give error indications on the object and in the faceplate; no action is taken by the control module.

Table 47 ErrPar

	Name	Туре	Initial value	Description
16	ErrPar	pmsErrPar	Default	Parameter for connecting Error signals.

The following components from the parameter *ErrPar* are used for the control module *pmsCBStandardM*.

#### Table 48 ErrPar for pmsCBStandardM

Shed	IN Load shed action by load shedding function
IOErr	IN IO Error
ComErr	IN Communication Error
ProtTrp	IN Protection trip

#### 2.3.1.12 Status

The opened or closed status and the manual or automatic mode of the circuit breaker are indicated from the parameter *Status*.

#### Table 49 Status

	Name	Туре	Initial value	Description
19	Status	pmsCBstatus	default	Status of breaker Checked positions.

The following components from the parameter Status are applicable for the control module *pmsCBStandardM*.

#### Table 50 Status parameters

OX	Checked open position
CX	Checked close position
AutoMode	Auto mode is active
ManMode	Manual mode is active

Depending on the *FBConfig* settings, the position status is determined according to the table below.

Open feedback IOPar.OI	Closed feedback IOPar.Cl	Service Position IOPar.SP	Checked opened IOPar.OX	Checked closed IOPar.CX	Position error Alarm	Intermediate position alarm
0	0	0	1	0	0	1
1	0	0	1	0	0	0
0	1	0	1	0	0	0
1	1	0	1	0	1	0
0	0	1	0	0	0	1
1	0	1	1	0	0	0
0	1	1	0	1	0	0
1	1	1	0	0	1	0

Table 51 Checked position	ns and position related	l alarms (FBConfig=3)
---------------------------	-------------------------	-----------------------

# Section 3 Control Module pmsCBIndM

The *pmsCBIndM* control module is included in the *pmsCBLib* library. A block presentation of the control module is shown in Figure 21. The parameters are briefly described in Table 52.



Figure 21 Control Module pmsCBIndM

Parameter	Significance		
Name	Name of the circuit breaker. With the name upload tool of process portal, this property will be used for identifying the object in 800xA. The name will be used to group the alarms and events and to identify the faceplate of the object. The name must be unique in the project.		
Description	Description of the circuit breaker. With the name upload tool of process portal, this property will be used for identifying the object in 800xA.		
Voltage level	Voltage level for object colouring. This property gives the object a colour in Single Line Diagrams. Default settings for the colours are: Level 1 - RGB N(0,176,232) - D(0,126,182) - L(50,226,255) Level 2 - RGB N(232,160,168) - D(182,110,118) - L(255,210,218) Level 3 - RGB N(176,232,176) - D(126,182,126) - L(226,255,226) Level 4 - RGB N(255,255,128) - D(205,205,78) - L(255,255,178) Level 5 - RGB N(64,128,128) - D(14,78,78) - L(114,178,178) Level 6 - RGB N(198,101,0) - D(140,70,0) - L(255,154,53) Level 7 - RGB N(240,160,13) - D(182,121,10) - L(249,209,136) Level 8 - RGB N(207,204,73) - D(153,150,40) - L(227,225,149) Level 9 - RGB N(81,181,171) - D(53,125,120) - L(174,221,217) Level10- RGB N(185,157,91) - D(135,112,58) - L(223,210,181)		
AlSeverity	Alarm severity. The alarm severity can be used for filtering the alarm list. Range 1- 1000.		
EvSeverity	Event severity. The event severity can be used for filtering the event list. Range 1-1000.		
Class	Alarm and Event Class. This property can be used for grouping objects to appear in separate alarm/event lists. Range 1-9999.		
СВТуре	The parameter is used for configuring the graphical presentation of the circuit breaker; '1'= circuit breaker, '3'= isolator (disconnector), '4'= circuit breaker without service position feedback.		
FBConfig	Configuration parameter for the position status signals that are applicable for the circuit breaker; '0'= Open and Closed positions, '1'= Closed position, '2'= Open, Closed and Service positions, '3'= Closed and Service positions, '4'= Open, Closed, Service position and Test Position, '5'= Closed, Service position and Test position		
NormalMode	The parameter is used for configuring the graphical presentation of the normal mode; '1'= Manual, '2'= Auto, '3'= Local, '4'= Remote.		
OI	Feedback open indication.		
CI	Feedback close indication.		
SP	IN: Feedback service position.		
ТР	IN: Feedback Test position.		
LO	Lockout (Trip) input.		
Shed	Indication that breaker has been shed.		
Meas_V	Measurement input for Voltage.		
Meas_F	Measurement input for Frequency.		
Meas_P	Measurement input for Active power.		

Table 52 Parameters	of the control	l module pmsCBIndM	

Parameter	Significance	
Meas_Q	Measurement input for Reactive power.	
En_Meas_PF_Calc	Power factor calculated value from Meas_P and Meas_Q.	
Meas_PF	Measurement input for Power factor.	
En_Meas_I_Calc	Current calculated value from Meas_P, Meas_PF and Meas_V.	
Meas_I	Measurement input for Current.	
IOErr	Indication that an IO error is active.	
CommErr	Indication that a Communication error is active.	
PosAlarmEnable	Enable the position error alarms.	
PosAlarmTimer	Time delay for position error alarms.	
POS_OX	Checked open position.	
POS_CX	Checked close position.	
EvPar	Parameter for configuring external timestamp for events [NOT USED].	
AlarmPar	Structured parameter for 16 user defined alarms.	
EventPar	Structured parameter for 16 user defined events.	
MeasPar	Structured parameter for 16 user defined analogue measurements.	
DisEvtOpened	External disabling of event condition for OI.	
DisEvtClosed	External disabling of event condition for CI.	
DisEvtRackedOut	External disabling of event condition for SP.	

# **3.1 Introduction**

The control module pmsCBIndM is used for monitoring of non-controllable circuit breakers (i.e. no remote open/close operation). The following features are supported:

#### • Measurements

Two kinds of mesurements are featured, standard and customized:

- Standard measurements: Important electrical available for monitoring in the main faceplate tab:
  - Voltage
  - Frequency
  - Active power
  - Reactive power
  - Power factor
  - Current
- Customized measurements: Additionally, up to 16 customized measurements can be displayed numerically in another faceplate tab).

#### Position status

The following feedback signals facilitates supervision of circuit breaker position status:

- Open indication
- Closed indication
- Service position
- Test position

#### Graphical Standard - IEC, ANSI

The graphical element can be configured to follow either the IEC or ANSI graphical standard.

#### Alarms

Alarms are divided in two categories:

- Standard alarms: Default alarms informing the operator of alarm conditions, according to the internal logic of the control module.
- Customized alarms: Up to 16 customized alarms can be raised through the control module although they originate from external logic.

#### • Events

Events are divided in two categories:

- Standard events: Default events informing the operator of operational status changes.
- Customized events: Up to 16 customized events informing the operator of status/events programmed outside the control module logic.

# **3.2 Detailed Engineering**

Engineering details of the control module *pmsCBIndM* are similar to *pmsCBStandardM*. The following chapters will point out the differences compared to chapter 2.2

#### **3.2.1 Measurements**

The faceplate tab Main presents the standard measurements, as shown in Figure 22. These analogue signals are configured via the parameters of the control module, as shown in Table 53.



Figure 22 pmsCBIndM Faceplate tab Main

Table 53 Parameter configuration for	or measurement signals
--------------------------------------	------------------------

Field	Indication	Parameter configuration	Description
1	Voltage	Meas_V	Voltage measurement.
2	Frequency	Meas_F	Frequency measurement.
3	Active power	Meas_P	Active power measurement.
4	Reactive power	Meas_Q	Reactive power measurement.
5	Power factor	Meas_PF	Power factor measurement. If <i>En_Meas_PF_Calc</i> =True, the power factor value will be calculated based on the parameters <i>Meas_P</i> and <i>Meas_Q</i> .
6	Current	Meas_I	Current measurement. If <i>En_Meas_I_Calc</i> =True, the Current value will be calculated based on the parameters <i>Meas_P</i> , <i>Meas_PF</i> and <i>Meas_V</i> .
7	Meas text 1	MeasPar.UserDefMea s01	User defined measurement 1.
8	Meas text 2	MeasPar.UserDefMea s02	User defined measurement 2.

# 3.2.2 Position status

The position status of the circuit breaker is presented by the graphic symbol of the circuit breaker in the faceplate tab **Main**.



Figure 23 Position status pmsCBIndM

Table 54	Position	status	pmsCBIndM
----------	----------	--------	-----------

Field	Parameter configuration	Description	
1	CI=1 and OI=0 and SP =1	Circuit breaker closed.	
2	CI=0 and OI=1 and SP =1	Circuit breaker opened.	
3	CI=0 and OI=0 and SP =1	Circuit breaker intermediate position.	
4	CI=1 and OI=0 and SP=0	Circuit breaker closed and racked-out.	
5	CI=0 and OI=1 and SP=0	Circuit breaker open and racked-out.	
6	CI=0 and OI=0 and SP=0	Circuit breaker intermediate position and racked-out.	

The FBConfig parameter shall be used for enabling the open and/or service position feedbacks, as shown in Table 55.

FBConfig value	Applicable feedback signals	Remarks
0	- Feedback Opened - Feedback Closed	Two limit switches are monitored; the Service Position input is not included. Note: service position is the opposite of racked out position
1	- Feedback Closed	Only closed limit switch feedback is considered.
2	- Feedback Opened - Feedback Closed - Feedback Service Position	Both opened and closed limit switches are considered in conjunction with the service position. Note: that if the service position is '0', i.e. the circuit breaker is racked out; the checked open indication is always true to indicate an electrical disconnection.
3	- Feedback Closed - Feedback Service Position	The close limit switch and the service position feedbacks are monitored.
4	<ul> <li>Feedback Opened</li> <li>Feedback Closed</li> <li>Feedback Service Position</li> <li>Feedback Test Position</li> </ul>	Both opened and closed limit switches are considered in conjunction with the service position. Both the service position and the test position is monitored before the circuit breaker is considered racked out; the checked open indication is always true to indicate an electrical disconnection.
5	- Feedback Closed - Feedback Service Position - Feedback Test Position	The close limit switch and both service position and test position feedbacks are monitored.

 Table 55 Configuration values for the FBConfig parameter

# 3.2.3 Graphic Symbol Standard

The graphic symbols standard (IEC or ANSI) used in the faceplates can be configured by setting the project constant **pmsConstants.cGraphicSymbolStd\_IEC\_ANSI**.

Value	Standard	Symbols
0		γ°°,
1(default)	IEC(default)	* *
2	ANSI	

# When ANSI is selected, the fill color of the symbol can be configured by setting the project constant **pmsConstants.cANSI\_FillColouring**.

Value	Remarks	Symbols
0(default)	Green = Open Red = Closed	
1	Not filled = Open Filled = Closed	

The position of the breaker symbol when racked out can be configured by setting

the project constant pmsConstants.cBreaker\_RackoutConfig.

Value	Remarks	Symbols
0(default)	Move symbol outside line when racked out.	< <sup>←</sup>
1	Keep symbol on line when racked out.	< <b>← ■ →</b> >

See Appendix A for detailed table with configuration and corresponding symbols.

#### 3.2.4 Alarms

The control module supports standard and customized alarms:

- The standard alarms represent alarm conditions that are monitored by the internal logic of the control module.
- The customized alarms represent 16 free programmable alarm conditions that must be configured outside the control module.

All alarms are presented in the tab Alarms of the circuit breaker faceplate, as shown in Figure 24.

CB) CB) pmsC	indM :BIndM	4
Trend Alarms Events Mea Breaker inter. pos. (00 Breaker pos. error (11 Truck inter. pos. (00) Truck pos. error (11) IO Error Comm. Error Comm. Error Protection trip Shed command Alarm text 1 Alarm text 2 Alarm text 3 Alarm text 4 Alarm text 5	surements Alarm text 7 Alarm text 8 Alarm text 9 Alarm text 10 Alarm text 11 Alarm text 11 Alarm text 12 Alarm text 13 Alarm text 14 Alarm text 15 Alarm text 16	

Figure 24 Faceplate tab Alarms for pmsCBIndM

The alarm for the intermediate position is enabled if the parameter *PosAlarmEnable* is set to True. An alarm delay can be configured via the parameter *PosAlarmTimer* for the allowed changeover time of the position signals.

Field	Indication	Alarm condition	Alarm message (Resource Id)
1	Intermediate position (00)	When neither the open nor the closed position feedbacks are received; the parameters <i>OI.Value</i> and <i>CI.Value</i> are false for more than a configurable time.	NLSID_CBPosError
2	Position error (11)	When both the open and closed position feedbacks are received; the parameters <i>OI.Value</i> and <i>CI.Value</i> are True.	NLSID_CBFault
3	Truck intermediate position (00)	When neither the service nor the test position feedbacks are received; the parameters <i>IOPar.SP.Value</i> and <i>IOPar.TP.Value</i> are False for more than a configurable time.	NLSID_CBTruckPosError
4	Truck position error (11)	When both the service and test position feedbacks are received; the parameters <i>IOPar.SP.Value</i> and <i>IOPar.TP.Value</i> are True.	NLSID_CBTruckPosFault
5	IO Error	The parameter <i>IOErr</i> is dedicated to receive any error indication from IO related to the circuit breaker. The alarm is activated when the parameter is True. The alarm is also activated when the position feedback signals are not reporting healthy status.	NLSID_IOError
6	Communication error	The parameter <i>ComErr</i> is dedicated to receive any error indication from communication links related to the circuit breaker. The alarm is activated when the parameter is True.	NLSID_ComError
7	Protection	The parameter <i>LO</i> is used for receiving the hardwired trip signal. The alarm is activated when the parameter is True.	NLSID_ProtectionTrip
8	Shed command	The parameter <i>Shed</i> is dedicated to receive a shed indication from a load shedding application. The alarm is activated when the parameter is True.	NLSID_ShedCmd
9	Alarm text 1	AlarmPar.UserDefAlm01stat.Signal	AlarmPar.UserDefAlm01stat.Message
	Alarm text 16	AlarmPar.UserDefAlm16stat.Signal	AlarmPar.UserDefAlm16stat.Message

# Table 56 List of alarms and message configuration

# 3.2.6 Events

The control module supports standard and customized events:

- The standard events represent operational changes that are monitored by the internal logic of the control module.
- The customized events represent 16 free programmable status/event conditions that can be configured outside the control module.

The events are presented in the Event List. The purpose of the customized events is mainly for user defined on/off type of status signals.

No.	Indication	Event condition	Event message On
1	Opened	Position feedback opened.	NLSID_OpenPosition+ NLSID_EventOn (or NLSID_EventOff)
2	Closed	Position feedback closed.	NLSID_ClosePosition+ NLSID_EventOn (or NLSID_EventOff)
3	RackedOut	Position feedback racked-out (not in service).	NLSID_RackedOutOn (or NLSID_RackedOutOff)

Table 57 List of standard events and message configuration

# 3.3 Parameters

This chapter describes the parameters and configuration settings for the control module *pmsCBIndM*. In practice the *pmsCBIndM* is a simplified version of the *pmsCBStandardM* module therefore only the differences will be highlighted.

	Name	Туре	Initial value	Description
1	Name	string[30]	'pmsCBIndM'	IN EDIT: Name of the object
2	Description	string[40]	'pmsCBIndM'	IN EDIT: Description of the object
3	VoltageLevel	dint	1	IN EDIT: Voltage level for object colouring [110]
4	AlSeverity	dint	900	IN EDIT: Alarm severity
5	EvSeverity	dint	400	IN EDIT: Event severity
6	Class	dint	50	IN EDIT: Alarm and Event Class
7	СВТуре	dint	1	IN EDIT: [1=CB] [3=Disconnector, no SP] [4=CB, no SP]
8	FBConfig	dint	0	IN EDIT: [0=FB1,FB0] [1=FB1] [2=FB1,FB0,SP] [3=FB1,SP] [4=FB1,FB0,SP,TP] [5=FB1,SP,TP]
9	NormalMode	dint	3	IN EDIT: [1=Manual][2=Auto][3=Local][4=Rem ote]
10	OI	BoollO	default	IN: Feedback open
11	CI	BoollO	default	IN: Feedback closed

Table 58 Parameters of pmsCBIndM

	Name	Туре	Initial value	Description
12	SP	BoollO	default	IN: Feedback service position
13	ТР	BoollO	default	IN: Feedback Test position [NOT USED]
14	LO	BoollO	default	IN: Trip Input, Lockout
15	Shed	bool	default	IN: Load shed action by load shedding function
16	Meas_V	ReallO	default	IN: Measurement Voltage
17	Meas_F	ReallO	default	IN: Measurement Frequency
18	Meas_P	ReallO	default	IN: Measurement Power
19	Meas_Q	ReallO	default	IN: Measurement Reactive Power
20	En_Meas_PF_Calc	bool	false	IN EDIT: Enable PF calculated out of P, Q, PF: P / {sqrt[(P)^2 + (Q)^2]}
21	Meas_PF	ReallO	default	IN: Measurement Power factor
22	En_Meas_I_Calc	bool	false	IN EDIT: Enable I calculated out of P, PF, V: I = P / (PF x V x sqrt(3))
23	Meas_I	ReallO	default	IN: Measurement Current
24	lOErr	bool	default	IN: IO Error
25	ComErr	bool	default	IN: Communication Error
26	PosAlarmEnable	bool	true	IN: Enable alarm condition
27	PosAlarmTimer	time	5s	IN: Time setting for alarm condition
28	TruckPosAlarmEnable	bool	true	IN: Enable alarm condition
29	TruckPosAlarmTimer	time	5s	IN: Time setting for alarm condition
30	POS_OX	bool	default	OUT: Circuit Breaker position open checked
31	POS_CX	bool	default	OUT: Circuit Breaker position closed checked
32	EvPar	pmsCustom EvPar	default	IN_OUT: Circuit Breaker custom defined SOE events [NOT USED]
33	AlarmPar	pmsExtAll	default	IN: For Extended Alarm indication in Faceplate
34	EventPar	pmsExtEvt	default	IN: For Extended Event indication in Faceplate
35	MeasPar	pmsExtIO	default	IN: For Extended Measurements indication in Faceplate
36	DisEvtOpened	bool	false	IN: External disabling of event condition for CI
37	DisEvtClosed	bool	false	IN: External disabling of event condition for OI
38	DisEvtRackedOut	bool	false	IN: External disabling of event condition for RO

# 3.3.1 Parameter details

#### 3.3.1.1 Position status

#### Table 59 Position feedbacks for pmsCBIndM

	Name	Туре	Initial value	Description
1	OI	BoollO	default	IN: Feedback open limit switch
2	CI	BoollO	default	IN: Feedback close limit switch
3	SP	BoollO	default	IN: Feedback service position limit switch
4	TP	BoollO	default	IN: Feedback test position limit switch

These position feedbacks are normally connected to digital I/O signals. They shall be handled in the same manner as the relevant components found in the parameter IOPar of the *pmsCBStandardM* control module.

#### Example:

Global variable: IO (structured type) with component CB4301A (type pmsCBIndPar)

- OI : IO.CB4301A.OI
- CI : IO.CB4301A.CI
- SP : IO.CB4301A.SP
- TP : IO.CB4301A.TP

#### 3.3.1.2 Measurements

#### Table 60 Measurement connections

	Name	Туре	Initial value	Description
F	Maga V/	DeallO	defecult	
Э	weas_v	ReallO	derault	IN: Measurement voltage
6	Meas_F	ReallO	default	IN: Measurement Frequency
7	Meas_P	ReallO	default	IN: Measurement Power
9	Meas_Q	ReallO	default	IN: Measurement Reactive Power
10	Meas_PF	ReallO	default	IN: Measurement Power factor
11	Meas_I	ReallO	default	IN: Measurement Current

These input measurements are typically connected to analogue I/O signals. They shall be handled in the same manner as the relevant components found in the parameter *IOPar.MeaInput* of the *pmsCBStandardM* control module

Example:

Global variable: IO (structured type) with component CB4301A (type pmsCBIndPar)

- Meas\_V : IO.CB4301A.Meas\_V
- Meas\_F : IO.CB4301A.Meas\_F
- Meas\_P : IO.CB4301A.Meas\_P
- Meas\_Q : IO.CB4301A.Meas\_Q
- Meas\_PF : IO.CB4301A.Meas\_PF
- Meas\_I : IO.CB4301A.Meas\_I

## 3.3.1.3 Error parameters

	Name	Туре	Initial value	Description
12	LO	BoollO	default	IN: Trip Input, Lockout
13	Shed	bool	default	IN: Load shed action by load shedding function
14	IOErr	bool	default	IN: IO Error
15	ComErr	bool	default	IN: Communication Error

Table 61 Error signals

Example:

Global variable: IO (structured type) with component CB4301A (type pmsCBIndPar).

The parameter *Shed* should be connected to a Load Shedding function.

e.g.

Shed : IO.CB4301A.Shed

The parameter *IOErr* should be a summation of the signal errors applicable for the circuit breaker.

e.g.

IO.CB4301A.IOErr := IO.CB4301A. Meas\_F.Status ≠ 16#C0 or

IO.CB4301A. Meas\_P.Status ≠ 16#C0 or

IO.CB4301A.Meas\_V.Status  $\neq$  16#C0;

The *CommErr* can be used to monitor the MMS communication status and/or serial link communication status to protection relays.

e.g.

CommErr : IO.CB4301A. CommErr

# 3.3.1.4 Status

Table 62 Status (	′output)
-------------------	----------

	Name	Туре	Initial value	Description
16	POS_OX	bool	default	OUT: Circuit breaker pos open checked
17	POS_CX	bool	default	OUT: Circuit breaker pos closed checked

These outputs indicate the confirmed open or closed position of the circuit breaker for use by other control modules or programs. They shall be handled in the same manner as the parameters *Status.OX* and *Status.CX* of the *pmsCBStandardM* control module.

Example:

Global variable: IO (structured type) with component CB4301A (type pmsCBIndPar)

POS\_CX : IO.CB4301A.POS\_CX POS\_OX : IO.CB4301A.POS\_OX

# Section 4 Control Module pmsCBSyncM

The *pmsCBSyncM* control module is included in the *pmsCBLib* library. A block presentation of the control module is shown in Figure 25. The parameters are briefly described in Table 63.



Figure 25 Control module pmsCBSyncM

Table 63 Control module	e pmsCBSyncM	l parameters
-------------------------	--------------	--------------

Parameter	Significance		
Name	Name of the circuit breaker. With the name upload tool of process portal, this property will be used to identify the object in 800xA. The name will be used to group the alarms and events and for identifying the faceplate of the object. The name must be unique in the project.		
Description	Description of the circuit breaker. With the name upload tool of process portal, this property will be used for identifying the object in 800xA.		
Voltage level	$\begin{array}{l} \mbox{Voltage level for object colouring. This property gives the object a colour in Single Line Diagrams. Default settings for the colours are: \\ \mbox{Level 1 - RGB N(0,176,232) - D(0,126,182) - L(50,226,255) \\ \mbox{Level 2 - RGB N(232,160,168) - D(182,110,118) - L(255,210,218) \\ \mbox{Level 3 - RGB N(176,232,176) - D(126,182,126) - L(226,255,226) \\ \mbox{Level 4 - RGB N(255,255,128) - D(205,205,78) - L(255,255,178) \\ \mbox{Level 5 - RGB N(64,128,128) - D(14,78,78) - L(114,178,178) \\ \mbox{Level 6 - RGB N(198,101,0) - D(140,70,0) - L(255,154,53) \\ \mbox{Level 7 - RGB N(240,160,13) - D(182,121,10) - L(249,209,136) \\ \mbox{Level 8 - RGB N(207,204,73) - D(153,150,40) - L(227,225,149) \\ \mbox{Level 9 - RGB N(185,157,91) - D(135,112,58) - L(223,210,181) \\ \end{array}$		

Parameter	Significance
СВТуре	The parameter is used for configuring the graphical presentation of the circuit breaker; '1'= circuit breaker, '2'= circuit breaker synch, '11'= circuit breaker with earthing, '12'= circuit breaker synch. with earthing.
FBConfig	Configuration parameter for the position status signals that are applicable for the circuit breaker; '0'= Open and Closed positions, '1'= Closed position, '2'= Open, Closed and Service position, '3'= Closed and Service position, '4'= Open, Closed and Service position and Test position, '5'= Closed and Service position and Test position.
NormalMode	The parameter is used for configuring the graphical presentation of the normal mode; '1'= Manual, '2'= Auto, '3'= Local.
FollowLocalFB	Configuration parameter for the circuit breaker when in local point of control 'False'= Cmd0\Cmd1Level output is reset in local, 'True' = Cmd0\Cmd1Level follows FB in local.
Index	The index shall be unique for each circuit breaker in the synchronization function. This parameter shall identify the breaker to the Synchronization module (pmsSNSyncSuperv) from the pmsSNLib library.
AlSeverity	Alarm severity. The alarm severity can be used for filtering the alarm list. Range 1-1000.
EvSeverity	Event severity. The event severity can be used for filtering the event list. Range 1-1000.
Class	Alarm and Event Class. This property can be used for grouping objects to appear in separate alarm/event lists. Range 1-9999.
IOPar	Input/Output signals. This parameter is used for connecting the I/O signals to the object. This parameter is a structured data type.
AutoPar	Structured parameter for connecting auto open/close commands to the circuit breaker.
AlarmPar	Structured parameter for 16 user defined alarms.
EventPar	Structured parameter for 16 user defined events.
llockPar	Structured parameter for and configuring interlock signals.
ErrPar	Structured parameter for error signals to the circuit breaker.
SyncPar	Configuration settings for the network determination.
SynCBPar	Structured parameter for receiving data from the Synchronization module.
MeasPar	Structured parameter for 16 user defined analogue measurements.
ExtPar	External parameters for application interaction. With this parameter it is possible to disable standard alarms and to disable the mode command buttons of the faceplate.
Status	Status indication for the checked closed/open position and the manual/auto mode of the breaker.
CBSynPar	Structured parameter for sending data to the Synchronization module.
## 4.1 Introduction

The control module type pmsCBSyncM is used for the control and supervision of circuit breakers involved in a synchronization scheme. The following features are supported:

### • Measurements

Two kinds of mesurements are featured, standard and customized:

- Standard measurements: Important electrical available for monitoring in the main faceplate tab:
  - Voltage
  - Frequency
  - Active power
  - Reactive power
  - Power factor
  - Current
- Customized measurements: Additionally, up to 16 customized measurements can be displayed numerically in another faceplate tab

### • Position status

The following feedback signals facilitates supervision of circuit breaker position status:

- Open indication
- Closed indication
- Service position
- Test position
- Earthed position

#### • Graphical Standard - IEC, ANSI

The graphical element can be configured to follow either the IEC or ANSI graphical standard.

#### Outputs

Open and close commands can be issued as pulsed or as steady outputs:

- Open command (level)
- Open command (edge)
- Close command (level)
- Close command (edge)

The pulsed outputs remain high for a configurable time period. The steady outputs remain active until the opposite command is initiated. The control module checks for discrepancies between output commands and position status. The conflicts are generating alarms after a configurable timeout setting.

• Interlocking

The circuit breaker can be interlocked for operation by conditions received from supervisory programs or other objects. Five interlocks are available; one A-interlock (which can be overridden) and four B-interlocks.

#### Point of Control (PoC)

The circuit breaker can be controlled from two locations:

- Remote point of control: PMS-level of control via ABB's graphical aspects.
- o Local point of control: equipment-level of control via vendor's local panel.

#### Control modes

Different control modes affect the operability:

- o Maintenance mode: No operation commands are allowed.
- o Simulation mode: The operation commands are simulated.
- o Auto mode: Operation commands are controlled by application logic.
- Manual mode: Operation commands are issued via the faceplate.

#### • Operation commands

Following operations are available to the operator via the circuit breaker faceplate:

- Change of control modes
- Open/Close commands
- o Initiate synchronization
- Override interlock

#### • Operations counter

A counter is provided to calculate how many times the circuit breaker is operated. It only counts when the circuit breaker is opened and it does not count when the maintenance or simulation mode are activated.

#### Alarms

Alarms are divided in two categories:

- Standard alarms: Default alarms informing the operator of alarm conditions, according to the internal logic of the control module.
- Customized alarms: Up to 16 customized alarms can be raised through the control module although they originate from external logic.

#### Events

- Events are divided in two categories:
- Standard events: Default events informing the operator of operational status changes according to internal logic of the control module.
- Customized events: Up to 16 customized events informing the operator of status/events programmed outside the control module logic.

# 4.2 Detailed Engineering

The control module *pmsCBSyncM* includes the same functionality implemented in the *pmsCBStandardM* module. In addition, the *pmsCBSyncM* module supports the synchronization function.



The features related to the synchronization function are described in a separate document "User Manual, Synchronization", 3BNP100234-0338.

# Section 5 Capacity & Performance

Table 64 Firmware version downloaded on the utilized controllers

Unit	Firmware version
PM866	FW866 5.1.48.40 2010-07-02 (BasicHwLib 5.1-0)
PM891	FW891 5.1.48.40 2010-07-02 (BasicHwLib 5.1-0)

## 5.1 Heap Utilization

## 5.1.1 pmsCBStandardM

### Table 65 Heap utilization of pmsCBStandardM

	First instance	2 <sup>nd</sup> and following instances
Heap utilization(MB) in PM866	0.185	0.123
Heap utilization(MB) in PM891	0.187	0.125

## 5.1.2 pmsCBIndM

### Table 66 Heap utilization of pmsCBIndM

	First instance	2 <sup>nd</sup> and following instances
Heap utilization(MB) in PM866	0.159	0.113
Heap utilization(MB) in PM891	0.16	0.113

## 5.1.3 pmsCBSyncM

Table 67 Heap utilization of pmsCBSyncM

	First instance	2 <sup>nd</sup> and following instances
Heap utilization(MB) in PM866	0.188	0.125
Heap utilization(MB) in PM891	0.19	0.124

## **5.2 Execution Time**

## 5.2.1 pmsCBStandardM

## Table 68 Execution time of pmsCBStandardM

Execution time (ms)	Notes
0.6 ms	For one instance in PM866
0.4 ms	For one instance in PM891

## 5.2.2 pmsCBIndM

## Table 69 Execution time of pmsCBIndM

Execution time (ms)	Notes			
0.3 ms	For one instance in PM866			
0.25 ms	For one instance in PM891			

## 5.2.3 pmsCBSyncM

## Table 70 Execution time of pmsCBSyncM

Execution time (ms)	Notes
0.7 ms	For one instance in PM866
0.44 ms	For one instance in PM891

# Appendix A Appendix1

# A.1 Breaker Open/Closed indications

Table 71 Breaker open/closed indications

	Open	Closed	Inter-mediate	Faulty
IOPar.OI.Value	True	False	False	True
IOPar.CI.Value	False	True	False	True
	IEC			
CBType = 1 or 11Circuit Breaker	×	*	× T	*
CBType = 3 or 13 Disconnector		+	L T	, ▼
ANSI	cAnsi_FillC	olouring = 0		
CBType = 1 or 11 Circuit Breaker	•	+	×	+
CBType = 3 or 13 Disconnector			×	
ANSI	cAnsi_FillC	olouring = 1		
CBType = 1 or 11 Circuit Breaker	<b>P</b>	•	×	+
CBType = 3 or 13 Disconnector			×	N

# **A.3 Truck Position Indications**

IEC					
	Racked Out	Racked In	Inter- mediate	Faulty	
IOPar.SP.Value	False	True	False	True	
IOPar.TP.Value	True	False	False	True	
cBreaker_RackoutConfig = 0		÷.	× *、	+*	Circuit Breaker
cBreaker_RackoutConfig = 1	) )	ų į	×	1	Open
cBreaker_RackoutConfig = 0		*	*	+ *	Circuit Breaker
cBreaker_RackoutConfig = 1	(*+)	Ų	×	1	Closed
cBreaker_RackoutConfig = 0	$- \begin{pmatrix} \\ \\ \\ \\ \end{pmatrix}$	Ť	×	ţ	Isolator
cBreaker_RackoutConfig = 1	<u> </u>	ې ۲	×	1	Open
cBreaker_RackoutConfig = 0	) t	\$	× +	+	Isolator Closed
cBreaker_RackoutConfig = 1	ŧ	ţ	×	+	

Table 72 Truck position indications, IEC

# **A.4 Truck Position Indications**

ANSI cBreaker_ANSI_FillColouring = 0								
	Racked Out	Racked In	Inter- mediate	Faulty				
IOPar.SP.Value	False	True	False	True				
IOPar.TP.Value	True	False	False	True				
cBreaker_RackoutConfig = 0	↓ ↓ ↓	*	×	+	Circuit Breaker			
cBreaker_RackoutConfig = 1	(←■))		-×		Open			
cBreaker_RackoutConfig = 0	↓ ↓ ↓		<b></b>			<b>→</b> ×	<u>+</u>	Circuit Breaker
cBreaker_RackoutConfig = 1	÷	¥	×	Ţ	Closed			
cBreaker_RackoutConfig = 0	$\downarrow^{\uparrow}$	<b>*</b>	×	+ \	Isolator			
cBreaker_RackoutConfig = 1	$\langle \uparrow \rangle$	À	×		Open			
cBreaker_RackoutConfig = 0			×	+	Isolator Closed			
cBreaker_RackoutConfig = 1	Ĵ	*	×	+				

Table 73 Truck position indications, ANSI

# **A.5 Truck Position Indications**

ANSI cBreaker_ANSI_FillColouring = 1					
	Racked Out	Racked In	Inter- mediate	Faulty	
IOPar.SP.Value	False	True	False	True	
IOPar.TP.Value	True	False	False	True	
cBreaker_RackoutConfig = 0		-«-[	×		Circuit Breaker
cBreaker_RackoutConfig = 1	( ←□+ )	]->	Ъ×	J+	Open
cBreaker_RackoutConfig = 0		<del>~</del>	×-	Ť	Circuit Breaker
cBreaker_RackoutConfig = 1	< ← ■ → >	₩	-x	÷	Closed
cBreaker_RackoutConfig = 0		余、	×	<b>†</b>	Isolator
cBreaker_RackoutConfig = 1	< <i>←,</i> ,,} >	~*	×	1	Open
cBreaker_RackoutConfig = 0		Ŷ	×	Ť	lsolator Closed
cBreaker_RackoutConfig = 1	$\widehat{\downarrow}$	₩	×	+	

Table 74 Truck position indications, ANSI

# Appendix A Revision table

Rev. ind.	Page (P) / Chapter ©	Description	Date
А		Initial document release for 5.6-5	2022.08.30/KAA

# Contact us

ABB AS **PA Energy Industries** Oslo, Norway E-mail: power.management@no.abb.com ABB Oil and Gas

Copyright  $\ensuremath{\textcircled{C}}$  2002 – 2022 by ABB. All Rights Reserved.

