

# AC 800M

## AC 800M DriveBus

System Version 6.0

Power and productivity  
for a better world™





# **AC 800M**

## **AC 800M DriveBus**

**System Version 6.0**

---

## NOTICE

This document contains information about one or more ABB products and may include a description of or a reference to one or more standards that may be generally relevant to the ABB products. The presence of any such description of a standard or reference to a standard is not a representation that all of the ABB products referenced in this document support all of the features of the described or referenced standard. In order to determine the specific features supported by a particular ABB product, the reader should consult the product specifications for the particular ABB product.

ABB may have one or more patents or pending patent applications protecting the intellectual property in the ABB products described in this document.

The information in this document is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this document.

In no event shall ABB be liable for direct, indirect, special, incidental or consequential damages of any nature or kind arising from the use of this document, nor shall ABB be liable for incidental or consequential damages arising from use of any software or hardware described in this document.

This document and parts thereof must not be reproduced or copied without written permission from ABB, and the contents thereof must not be imparted to a third party nor used for any unauthorized purpose.

The software or hardware described in this document is furnished under a license and may be used, copied, or disclosed only in accordance with the terms of such license. This product meets the requirements specified in EMC Directive 2004/108/EC and in Low Voltage Directive 2006/95/EC.

## TRADEMARKS

All rights to copyrights, registered trademarks, and trademarks reside with their respective owners.

Copyright © 2003-2014 by ABB.  
All rights reserved.

Release: August 2014  
Document number: 2PAA113566-600

---

# Table of Contents

## About This User Manual

General .....	11
Warning and Caution Icons .....	12
Terminology.....	13
Related Documents.....	15

## Section 1 - Hardware and connections

Introduction .....	17
CI858 Features.....	19
CI858 Connections .....	21
Drive Channel / DDCS DriveBus .....	22
Special I/O Channel .....	24

## Section 2 - Mounting

Introduction .....	25
Mounting the Unit onto the DIN rail.....	25

## Section 3 - Communication

Introduction .....	27
Dataset Communication .....	29
Example of Datasets in the ACS800 Standard Application Program .....	30
Example of Datasets in the ACS800 System Application Program .....	31

## Section 4 - Configuration

Introduction .....	33
Control Builder.....	33
CI858 Configuration.....	36
Adding a CI858 Unit.....	36
CI858 Parameters .....	36

Drive Configuration .....	38
Adding a Drive.....	38
Drive Parameters.....	39
ABB Standard Drive and ABB Engineered Drive.....	39
ABB Drive Template (basic/extension).....	40
BusManager .....	41
Special I/O Configuration .....	42
Adding a Special I/O Unit .....	42
Special I/O Parameters.....	43
Special I/O Template.....	44
Connections.....	44
Special I/O Function Blocks .....	46
How to Insert a Library File .....	46
How to Insert a Special I/O Unit .....	46
Activating a Function Block.....	47
NBIO-21 .....	48
BIO2CONF .....	48
BIO2DI .....	50
BIO2DO .....	51
BIO2AO .....	51
BIO2AI .....	54
NBIO-31 .....	57
BIO3DI .....	57
BIO3DO .....	58
NDIO .....	59
NDIO1DI .....	59
NDIO1DO .....	60
NAIO .....	61
NAIO2AO .....	61
NAIO2AI .....	64
NPCT .....	67
PCT_CONF .....	67

	SPEEDPO1 .....	71
	SPEED_R .....	75
	POS_IL1 .....	76
	CONV24 .....	77
NTAC .....		78
	TAC_SP .....	78
NWIO .....		80
	NWIO1DI .....	81
	NWIO1DO .....	82
NCTI .....		83
NDSC .....		83
Output Error .....		84
Changing the CI858 System Settings .....		85
Online Help .....		85

## **Appendix A - Technical Data**

General Technical Data .....	87
Ambient Data .....	87
LED Indicators .....	88
Power Supply Requirements .....	88
Optical Connectors .....	89
DIN rail - TS 35/7.5 .....	89
CEB Connector, X1 .....	90
CEX Bus Interface .....	91



---

# Safety Summary

## Introduction

The complete safety instructions stated in the appropriate ABB Drive Hardware Manual must be followed when installing, operating and servicing the frequency converters. Study the complete safety instructions carefully.

## General Safety Instructions for AC and DC Drives

These general safety instructions include only main parts of the complete safety instructions. Neglecting these instructions may cause physical injury or death.



**WARNING!** All electrical installation and maintenance work on the drive should be carried out by qualified electricians.

Ground the drive, the motor and adjoining equipment to ensure personnel safety in all circumstances, and to reduce electromagnetic emission and pick-up.

Any installation work must be done with power off, and power is not to be reconnected unless the installation work is complete. Wait 5 minutes after switching off the supply before starting work. Always ensure by measuring that the drive is de-energized.

If the auxiliary voltage circuit of the drive is powered from an external power supply, opening the disconnecting device does not remove all voltages. Before starting work, check which circuits remain live after opening of the disconnecting device by referring to the circuit diagrams for your particular delivery. Ensure by measuring that the part of the cabinet you are working on is not live.

Do not make any voltage withstand tests on any part of the unit while the unit is connected.

Disconnect motor cables before making any measurements on motors or motor cables.

Live parts on the inside of doors are protected against direct contact. Special safety attention shall be paid when handling shrouds made of sheet metal.

---

## Safety Summary

Check the cable connections at the shipping split joints before switching on the supply voltage.



**WARNING!** Close switch fuses of all parallel connected inverters before starting the frequency converter.

Do not open the drive section switch fuses when the inverter is running.

**WARNING!** Fans may continue to rotate for a while after the disconnection of the electrical supply.

**WARNING!** Some parts like heatsinks of power semiconductors and toroidal cores on motor cables inside of cabinet remain hot for a while after the disconnection of the electrical supply.

---

# About This User Manual

## General

This manual introduces the installation and start-up of the CI858 communication interface.

CI858 is a communication interface for the DriveBus protocol. ABB Drives and Special I/O units communicate with the AC 800M controller via the CI858. The CI858 is designed especially for sectional drive applications, for example ABB rolling mill drive systems and ABB paper machine drive systems.

### *Section 1, Hardware and connections*

Provides an overview of the CI858 hardware and physical connections.

### *Section 2, Mounting*

Describes the mounting of the CI858.

### *Section 3, Communication*

Introduces the software and the content of messages used for communication between the CI858, AC 800M, ABB Drives and Special I/O units.

### *Section 4, Configuration*

Describes how to prepare the CI858 and its units for communication i.e. how to make logical connections between the AC 800M application variables and the ABB Drives' internal variables

### *Appendix A, Technical Data*

Contains technical data.

## Warning and Caution Icons

This publication includes **Warning** and **Caution** where appropriate to point out safety related or other important information. The corresponding symbols should be interpreted as follows:



Electrical warning icon indicates the presence of a hazard which could result in *electrical shock*.



Caution icon indicates important information or warning related to the concept discussed in the text. It might indicate the presence of a hazard which could result in *corruption of software or damage to equipment/property*.

Although **Warning** hazards are related to personal injury, and **Caution** hazards are associated with equipment or property damage, it should be understood that operation of damaged equipment could, under certain operational conditions, result in degraded process performance leading to personal injury or death. Therefore, **fully comply** with all **Warning** and **Caution** notices.

## Terminology

The following table lists the terms used in this document.

<b>Term</b>	<b>Description</b>
ABB Drives	DC and AC drives by ABB
ABB Drive Template (basic / extension)	ABB Drive Template (basic) is a CI858 configuration option with eight dataset pairs. With ABB Drive Template (extension) the dataset pair number can be extended
ABB Standard Drive	CI858 configuration option with two dataset pairs. Standard Drive option is used with Standard Application firmware.
ABB Engineered Drive	CI858 configuration option with eight dataset pairs. Engineered Drive option is used with System Application firmware.
AC 800M	Advant Controller 800M series, general purpose process controller
CEB	Communication Expansion Base Plate
CEM	Communication Expansion Module
CEX bus	Communication Expansion Bus
CI858	Communication Interface
Control Builder	engineering tool
CPU	Central processing unit
CSR	Communication and Status Register
DDCS	Distributed Drives Communication System
DPM	Dual port memory
DPRAM	Dual Port Random Access Memory

Term	Description
DriveBus	Communication link dedicated for ABB drives
DS	Dataset
DSP	Digital Signal Processor
DW	Data word
EMC	Electromagnetic Compatibility
FPGA	Field Programmable Gate Array
hardware tree	The data structure of a hardware configuration for a controller.
ICMC02	Integrated Control module Circuit (=communications ASIC)
LED	Light Emitting Diode
LVDS	Low Voltage Differential Signaling
NAIO	Analogue I/O Extension Module
NBIO	Basic I/O Unit
NCTI	Crane Transducer Interface
NDBU	Branching Unit
NDIO	Digital I/O Extension Module
NDSC-01	control board of the ACS600 Diode Supply Unit
NPCT	Pulse Counter and Timer Unit
NTAC	Pulse Encoder Interface Module
NWIO	Watchdog I/O Module
ONCE	On-Chip Emulation unit
PPP	Point-to-Point Protocol
TCP/IP	Transmission Control Protocol/Internet Protocol

## Related Documents

The following table lists the documentation related to this manual.

Category	Title
Hardware	AC 800M Controller Hardware, [3BSE036351* (English)]
	NDBU-85/95 DDCS Branching Units User's Manual, [3BFE64285513(English)]
	NTAC-0x/NDIO-0x/NAIO-0x Installation and Start-up Guide [3AFY58919730 (English)]
	Crane transducer Interface User's manual [3ASC23F207 (English)]
	ACA 631/633 Diode Supply Section User's Manual [3AFY61451544 (English)]
	NPCT-01 Pulse Counter/Timer Unit description [3AFY64362828(English)]
Software	AC 800M Communication Protocols, [3BSE035982* (English)]



---

# Section 1 Hardware and connections

## Introduction

The CI858 unit consists of a communication expansion base plate board CEB, a communication expansion module board CEM, and mechanics. All electronic devices and all functions are located on the CEM board.




Figure 1. CI858 communication interface.

The CEM board connects via connector X1 to the CEB board, which in turn is connected to the CEX bus.




Figure 2. CI858 CEM board.

## CI858 Features

The maximum number of CI858 units connected to the AC 800M is two.

The functional structure of the CI858 includes

- CEX bus interface:

Communication between the CI858 and the AC 800M is implemented through the CEX bus. The CEX bus operates with a clock frequency of 64 MHz. The maximum transfer data is ~1.25 MBytes/s.

- DDCS interfaces for
  - DriveBus
  - I/O Bus
  - PC Tool
- +24 V power supply from the CEX bus.
- DC/DC conversion from +24 V to +5 V, + 3.3V and +2.5 V.
- Motorola Digital Signal processor DSP56303 with 72 MHz CPU frequency.
- Xilinx XC2S50 FPGA for the CEX bus interface. 94 user I/O pins available on CI858.
- 32 kB boot PROM, AT27LV256, for boot code.
- 1 MB flash PROM, Am29DL800B, for program code.
- 768 kB SRAM program and data memory.

AC 800M and CI858 communicate with each other via dual-port RAM, DPRAM. The DPRAM has the following functionalities:

- Dual-port memory, 32 \* 16 kB.
- One interrupt in each direction.
- Eight semaphores which simplifies the utilization of shared resources.
- ONCE port which can be used for reprogramming the module.




Figure 3. Functional block diagram of the CI858.

## CI858 Connections




Figure 4. CI858 connections.

### Drive Channel / DDCS DriveBus

ABB Drives can be connected to the AC 800M via the CI858.




Figure 5. DriveBus topology.

Main communication functions of the Drive channel are:

- dataset communication
- broadcast system time
- supervision and diagnostics functions

The data exchange between the AC 800M and ABB Drives consists of dataset pairs. The DriveBus is able to transfer at the maximum 8 dataset pairs / 1 ms.

The Drive channel can be used for controlling up to 24 drives. Connecting more than one drive to the CI858 requires the use of a branching unit NDBU, which enables the construction of a logical bus with physical star topology. The branching units can be chained. For more information on the NDBU branching unit, see *DDCS Branching Units User's Manual, 3BFE 64285513*.

The Drive channel supports the following drives:

- ACS800 / ACS600 single drive
- ACS800 / ACS600 multidrive
- ACS800 / ACS600 IGBT supply units
- ACS600 thyristor supply units
- ACS140...ACS400
- DCS600 and DCS400
- ACS6000 product family / large drives
- ACS1000 product family
- future drive types which are provided with DDCS interface
- special drive applications, see ABB Drive Templates in *Drive Parameters* on page 39

## Special I/O Channel



Special I/O will not be a part of the Control and I/O functionality in the System version 3.1 released and owned by ABB Automation Technology Products AB.

The CI858 Special I/O channel can be used to connect up to 12 I/O's per unit. The I/O channel is able to transfer 2 dataset pairs / 1 ms. The I/O units are connected in a ring topology.

The following I/O units are supported:

- NAI0-03 Analogue I/O Extension Module - contains 2 current or voltage inputs and 2 current outputs
- NBIO-21 Basic I/O Unit 2 - contains 3 digital inputs, 2 analogue inputs, 2 digital outputs and 2 analogue outputs
- NBIO-31 Basic I/O Unit 3 - contains 4 digital inputs and 3 digital outputs
- NCTI-01 Crane Transducer Interface
- NDIO-02 Digital I/O Extension Module - contains 2 digital inputs and 2 relay outputs
- NDSC-01 control board of the ACS600 Diode Supply
- NPCT-01 Pulse Counter and Timer Unit - contains 2 encoder inputs, 4 digital inputs, 4 digital outputs
- NTAC-02 Pulse Encoder Interface Module - contains an interface for a digital pulse encoder connection
- NWIO-01 Watchdog I/O Module - contains watchdog logic for supervising the operation of the software
- special I/O applications, see [Special I/O Parameters](#) on page 43

---

## Section 2 Mounting


### Introduction

The CI858 is powered from the processor unit via the CEX bus and requires therefore no additional external power source. The unit is mounted onto a horizontal DIN rail.

### Mounting the Unit onto the DIN rail

The base plate has a locking mechanism that connects the metallic back plate to the DIN rail, providing an effective ground connection.

1. Rotate the locking device to the OPEN position. Hook the upper lip at the rear of the base plate over the upper edge of the DIN rail and snap the base plate fully into the mounting position.
2. Rotate the locking device to the SLIDE position. Slide the unit along the DIN rail to the desired mounting position and attach it to the adjacent unit base plate with the connector plugs and sockets.
3. Rotate the locking device clockwise to the LOCKED position.



The additional screw lugs, located in the lower part of the base plate, serve no electrical function. They provide secure mounting in locations subject to vibration.

---

## Section 3 Communication


### Introduction

The CI858 software consists of three parts: AC 800M controller software, Control Builder software and CI858 digital signal processor software.

The most important functions of the CI858 software are:

- Cyclic output/input to/from drives.
- Cyclic data to/from I/O units
- Easy configurability of drives and I/O's to the AC 800M.
- Identification method, self-checking and preventive systems to avoid incorrect configurations.
- Time synchronization of drives to the common calendar time.
- Communication diagnostics for the application

The following picture presents parts of the CI858 software, and how they reside with the AC 800M hardware and software.



ATLAS is a generic framework code for the AC 800M CPU firmware.  
 OMEGA is a hardware abstraction layer for the AC 800M CPU firmware.  
 VICI is a very intelligent CI, communications interface. DPM specification for all new intelligent CI units for AC 800M.

## Dataset Communication

The data exchange between the AC 800M, ABB Drives and I/O units via the CI858 consists of dataset pairs, which include input and output datasets. One dataset (DS) consists of three 16-bit words called data words (DW).

Datasets are read from ABB Drives. Therefore datasets need to be defined by setting ABB Drive dataset parameters during the system configuration. See chapter [Section 4, Configuration](#).




Figure 6. Dataset communication.

## Example of Datasets in the ACS800 Standard Application Program

The ACS800 Standard Application Program 7.x supports the use of four datasets, two in each direction.

The two datasets for controlling the drive are referred to as the Main Reference dataset and the Auxiliary Reference dataset. The sources from which the drive reads the Main and Auxiliary Reference datasets are defined by parameters 90.04 and 90.05 respectively. The contents of the Main Reference dataset are fixed. The contents of the Auxiliary Reference dataset can be selected using parameters 90.01, 90.02 and 90.03.

The two datasets containing actual information on the drive are referred to as the Main Actual Signal dataset and the Auxiliary Actual Signal dataset. The contents of both datasets are partly selectable with the parameters at group 92.

External control is activated by setting parameter 98.02 COMM. MODULE LINK to ADVANT.

Table 1. ACS800 Standard Application Program datasets

Data from advant controller to drive			Data from drive to advant controller		
Word	Contents	Selector	Word	Contents	Selector
<b>Main Reference dataset DS1</b>			<b>Main actual Signal dataset DS2</b>		
1st Word	Control Word	(Fixed)	1st Word	Status Word	(Fixed)
2nd Word	Reference 1	(Fixed)	2nd Word	Actual 1	*Par.92.02
3rd Word	Reference 2	(Fixed)	3rd Word	Actual 2	Par.92.03
<b>Auxiliary Reference dataset DS3</b>			<b>Aux. Actual Signal dataset Ds4</b>		
1st Word	Reference 3	Par.90.01	1st Word	Actual 3	Par.90.04
2nd Word	Reference 4	Par.90.02	2nd Word	Actual 4	Par.90.05
3rd Word	Reference 5	Par.90.03	3rd Word	Actual 5	Par.90.06

\*Actual 1 is fixed to actual signal 01.02 SPEED (in DTC motor control mode) or 01.03 FREQUENCY (in Scalar mode).

## Example of Datasets in the ACS800 System Application Program

The System Application Program supports the use of datasets 1, 2 or datasets 10...33. Datasets 10...25 are used for data exchange between the AC 800M, ABB Drives and I/O units via the CI858.

Datasets 10...25 are activated by setting parameter 98.02 COMM MODULE to FBA DSET10. Every dataset has a specified read and write task interval in the drive program. The contents of datasets can be selected using parameter Groups 90...93.

Table 2. An example of the System Application datasets.

Data from advant controller to drive			
DS no.	Word	Contents	Selector
10	1st Word	Main Ctrl Word	Par.90.01
	2nd Word	Speed Ref	Par.90.02
	3rd Word	Torque Ref A	Par.90.03
12	1st Word	Reference 3	Par.90.04
	2nd Word	Reference 4	Par.90.05
	3rd Word	Reference 5	Par.90.06
14, 16, 18, 20	1st Word		Par.90.07... 90.18
	2nd Word		
	3rd Word		
22,24	1st Word		Par.91.01 ... 90.06
	2nd Word		
	3rd Word		

Data from drive to advant controller			
DS no.	Word	Contents	Selector
11	1st Word	Main status word	Par.92.01
	2nd Word	Speed measured	Par.92.02
	3rd Word	Torque Ref B	Par.92.03
13	1st Word	Aux Status Word	Par.92.04
	2nd Word	Motor Speed	Par.92.05
	3rd Word	Torque	Par.92.06
15	1st Word	Fault Word 1	Par.92.07
	2nd Word	Fault Word 2	Par.92.08
	3rd Word	Fault Word 3	Par.92.09
17	1st Word	Alarm 1	Par.92.10
	2nd Word	Alarm 2	Par.92.11
	3rd Word		Par.92.12
19	1st Word	Limit Word 1	Par.92.12
	2nd Word	Limit Word 2	Par.92.13
	3rd Word		Par.92.14
21	1st Word	Temperature (of the heatsink)	Par.92.16
	2nd Word	Motor Meas Temp	Par.92.17
	3rd Word		Par.92.18
23,25	1st Word		Par.93.01... Par 93.06
	2nd Word		
	3rd Word		

---

# Section 4 Configuration

## Introduction

To activate communication between AC 800M, CI858, ABB Drives and I/O units the system must be configured with valid parameters:

- Configure the CI858 system with the Control Builder engineering tool.
- Define the system datasets by setting the ABB Drive dataset parameters, for example parameter groups 90...93 for Engineered Drives. See appropriate ABB Drive Firmware Manual for dataset and other required parameter settings.

## Control Builder

CI858 system is configured with the Control Builder engineering tool. The configuration includes the following steps:

1. Add units to the hardware tree.
2. Define parameters.
3. Connect variables.
4. Download the project to the controller when all the required steps have been completed.



The CI858 network can be halted during download.

The CI858 and its units are inserted and defined in the hardware tree with the following hierarchical levels

- CI858
- Drive channel and Special I/O channel
- drives and I/O units




Figure 7. Control Builder's hardware tree in the Project Explorer.

The Control Builder hardware editor contains the following tabs:

**Settings Tab:** Under the Settings tab you define the parameters.

**Connections Tab:** Under the Connections tab you connect the variables to the hardware channels.

**Status Tab:** Under the Status tab you can see the current value and status of each channel.

**Unit Status Tab:** Under the Unit Status tab you can see the current and latched status of the unit.



Figure 8. Control Builder hardware editor tabs.

The Control Builder SFC (The Sequential Function Chart) programming editor is divided into four panes: Declaration pane, Code pane, Structure pane and Message pane.




Figure 9. Control Builder programming editor panes.

## CI858 Configuration

### Adding a CI858 Unit

To add a CI858 to the controller proceed as follows in the Project Explorer:

- Right-click the AC 800M hardware object and select New Unit.
- Select a CI858 unit.
- Select the position for the unit and click ok.
- Double-click on the unit and adjust the CI858 parameters in the Settings tab by double-clicking in the value fields. See [CI858 Parameters](#) on page 36.
- Apply and close the editor (Ctrl + U).

### CI858 Parameters

The following parameters can be specified in the CI858 configuration editor in the Settings tab.

Table 3. DriveBus CI858 parameters.

Parameter	Selection	Description	Default value
Light intensity DriveBus	1...15	With the maximum length of optic fiber cable, use value 15.	15
Max allowed break time	0...32767 ms	If there has not been any communication during this time, the connection is closed. The recommended value is 1000-2000 ms.	2000
Light Intensity I/O	1...15	With the maximum length of optic fibre cable, use value 15.	15
Broadcast timesync	True/False	If the parameter is set to True, the AC 800M clock will synchronize the drive clocks. The resolution is 100 us.	True



The screenshot shows a software window titled "Hardware - Controller\_1.1 CI858". Below the title bar is a menu bar with "Editor", "Edit", "View", "Insert", "Tools", "Window", and "Help". A toolbar with various icons is located below the menu bar. The main area contains a table with the following data:

Parameter	Value	Type	Unit	Min	Max
Light intensity Drivebus	15	dint		1	15
Max allowed break time	2000	dint	ms	0	32767
Light intensity I/O	15	dint		1	15
Broadcast timesync	true	bool			

Figure 10. The CI858 hardware configuration window.

## Drive Configuration

### Adding a Drive

To add a drive to the CI858 proceed as follows in the Project Explorer:

- Right-click the CI858 unit and select New Unit.
- Select Drive Channel
- Right-click the Drive Channel and select New Unit.
- Select the appropriate drive option:
  - ABB Standard Drive with two dataset pairs. (Standard Drive option is used with Standard Application firmware.)
  - ABB Engineered Drive with eight dataset pairs. (Engineered Drive option is used with System Application firmware.)
  - ABB Drive Template (basic) with eight dataset pairs. With ABB Drive Template (extension) the dataset pair number can be extended. With ABB Drive Templates the dataset numbers are user-defined.



With ABB Drive products it is always recommended to use ABB Standard Drive or ABB Engineered Drive option.

- Select the position (address of the drive) for the unit and click ok.



Use consecutive numbering between ABB Drive Template (basic) and ABB Drive Template (extension). The position number of the ABB Drive Template (basic) determines the address of the drive associated with the basic and extension templates.

- Double-click on the unit and adjust the drive parameters in the Settings tab by double-clicking in the value fields. See [Drive Parameters](#) on page 39.
- Connect variables to the channels in the Connections tab. See [Connections](#) on page 44.
- Apply and close the editor (Ctrl + U).

## Drive Parameters

### ABB Standard Drive and ABB Engineered Drive

The following parameters can be specified in the ABB Standard Drive or in the ABB Engineered Drive configuration editor in the Settings tab.

Table 4. ABB Standard Drive and ABB Engineered Drive parameters.

Parameter	Selection	Description
Use BusManager	True/False	If parameter is set to True, the BusManager monitors the connection. The default value is True.
Address of Application ID in Drive	1...9999	ABB Drive parameter index, which defines the application ID. For example 9910 = parameter 99.10.
Configured application ID	1...65535	Indicates what the application ID of the drive should be.
Configured application ID data type	No Checking / Check Numbers	If Check Numbers is selected, the application checks that the Configured application ID parameter value is correct.
Address of drive type in drive	1...9999	ABB Drive parameter index, which defines the drive type. For example 401 = parameter 4.01.
Drive type		Defines the drive firmware type. For example AMXG6000
Drive type checking mask		Defines the allowed drive firmware type. For example AM??????, where '?' is a wild card. The ABB Drive firmware version is compared to this value.
Dataset x config status	off/read/ read&write	Defines the dataset access in the Connections tab.
Dataset x priority	high priority / normal priority	Defines the dataset priority. It is possible to specify that 1-4 (depending on the drive type) datasets have higher communication priority than the others.

**ABB Drive Template (basic/extension)**

The following parameters can be specified in the ABB Drive Template (basic/extension) configuration editor in the Settings tab.


Table 5. ABB Drive Template (basic/extension) parameters.

Parameter	Selection	Description
Use BusManager	True/False	If parameter is set to True, the BusManager monitors the connection. The default value is True.
Address of Application ID in Drive	1...9999	ABB Drive parameter index, which defines the application ID. For example 9910 = parameter 99.10.
Configured application ID	1...65535	Indicates what the application ID of the drive should be.
Configured application ID data type	No Checking / Check Numbers	If Check Numbers is selected, the application checks that the Configured application ID parameter value is correct.
Address of drive type in drive	1...9999	ABB Drive parameter index, which defines the drive type. For example 401 = parameter 4.01.
Drive type		Defines the drive firmware type. For example AMXG6000
Drive type checking mask		Defines the allowed drive firmware type. For example AM??????, where '?' is a wild card. The ABB Drive firmware version is compared to this value.
Dataset x ID	0...200	ABB Drive parameter index, which defines the dataset ID.
Dataset x config status	off/read/read&write	Defines the dataset access in the Connections tab.
Dataset x priority	high priority / normal priority	Defines the dataset priority. It is possible to specify that 1-4 (depending on the drive type) datasets have higher communication priority than the others.

## BusManager

The BusManager is used for reading and checking the actual drive configuration. It is also used for recovery of broken communication links. Normal communication to the broken link is suspended until the link is reported to be recovered.

If the BusManager function is disabled, the communication is assumed to be cyclic and continuous. A missing drive causes extra communication, because the messages towards it are repeated continuously.



Parameter	Value	Type	Unit	Min	Max
Use BusManager	true	bool			
Address of Application ID in Drive	1	dint		1	9999
Configured Application ID	1	dint		1	65535
Configured Application ID data type	No Checking	enum			
Address of drive type in drive	3301	dint		1	9999
Drive Type	ASXG6000	string			
Drive Type Checking Mask	AS??????	string			
Dataset 1 config status	Read/Write	enum			
Dataset 3 config status	Read/Write	enum			
Dataset 1 Priority	Normal Prio	enum			
Dataset 3 Priority	Normal Prio	enum			

Figure 11. ABB Standard Drive parameter window.

## Special I/O Configuration

### Adding a Special I/O Unit

Before Special I/O Channel can be selected, the Special I/O Channel Hardware definition file has to be imported into the project.

To add a Special I/O unit to the CI858 proceed as follows in the Project Explorer:

- Right-click the CI858 unit and select New Unit.
- Select Special I/O channel.
- Right-click the Special I/O channel and select New Unit.
- Select the appropriate I/O unit.
- Select the position (address of the I/O unit) for the unit and click ok.
- Double-click on the unit and adjust the Special I/O parameters in the Settings tab by double-clicking in the value fields. See [Special I/O Parameters](#) on page 43.
- Connect variables to the channels in the Connections tab. See [Special I/O Function Blocks](#) on page 46 and [Connections](#) on page 44.
- Apply and close the editor (Ctrl + U).




ID number of the I/O unit in the hardware tree has to match the device number configured with switch S1 on the unit.

## Special I/O Parameters

The following parameters can be specified in the Special I/O configuration editor in the Settings tab for the available Special I/O units: Special I/O Template, NBIO-21, NBIO-31, NWIO, NAI0, NDIO, NTAC, NPCT, NDSC, NCTI.

Table 6. Special I/O parameters

Parameter	Selection	Description
Configured device type		Select the appropriate I/O type.
Initialization style for device		Parameter is set automatically according to the configured device type. In the Special I/O Template parameter is user-defined Defines the ASIC type. Set parameter to 0 or 1. Select 1 if the ASIC is of the IOCC type.
MAFR Code		Major function code. Parameter is set automatically according to the configured device type. In the Special I/O Template parameter is user-defined. Defines whether the dataset is I/O or drive related. Set parameter to 0...255.
Overlaid datasets		Parameter is set automatically according to the configured device type. In the Special I/O Template parameter is user-defined. Set parameter to True or False. Select True if the returned dataset has the same dataset ID.
Dataset x ID	0...200	ABB Drive parameter index, which defines the Special I/O Template dataset ID.
Dataset x config status <sup>1)</sup>	off/read/ read&write	Defines the dataset access in the Connections tab.
Dataset x priority	high priority / normal priority	Defines the dataset priority. It is possible to specify that 1-4 (depending on the drive type) datasets have higher communication priority than the others.
<sup>1)</sup> Configuration status for datasets for reading digital inputs are marked with R (read) and dataset for reading and writing digital outputs are marked with R/W (read and write).		



Parameter	Value	Type	Unit	Min	Max
Configured Device type	Type 0	enum			
Dataset 51 config status	Read	enum			
Dataset 99 config status	Read/Write	enum			
Dataset 51 Priority	Normal Prio	enum			
Dataset 99 Priority	Normal Prio	enum			

Figure 12. NAI0 parameter window.

### Special I/O Template

With Special I/O Template, the dataset numbers are user-defined.

## Connections

Variables are connected to the input and output dataset channels in the connections window shown below.



All connected variables must be in the same task: All connected, accessed variables will be copied to the same task. All connected, unaccessed variables will be copied to a background task.



When dataset access is defined as Read&Write, variables of at least one input channel and one output channel must be connected. With Read only datasets variables of all three input channels must be connected.

Channel	Name	Type	Variable	I/O Description
IW1.0.2.1	DS 2, in channel 1	dint		
IW1.0.2.2	DS 2, in channel 2	dint		
IW1.0.2.3	DS 2, in channel 3	dint		
IW1.0.2.4	DS 4, in channel 1	dint		
IW1.0.2.5	DS 4, in channel 2	dint		
IW1.0.2.6	DS 4, in channel 3	dint		
QW1.0.2.7	DS 1, out channel 1	dint		
QW1.0.2.8	DS 1, out channel 2	dint		
QW1.0.2.9	DS 1, out channel 3	dint		
QW1.0.2.10	DS 3, out channel 1	dint		
QW1.0.2.11	DS 3, out channel 2	dint		
QW1.0.2.12	DS 3, out channel 3	dint		
IW1.0.2.13	UnitStatus	dint		

Figure 13. ABB Standard Drive connections window.

Channel	Name	Type	Variable	I/O Description
IW1.1.1.1	DS 51 in 1	dint		
IW1.1.1.2	DS 51 in 2	dint		
IW1.1.1.3	DS 51 in 3	dint		
IW1.1.1.4	DS 99 in 1	dint		
IW1.1.1.5	DS 99 in 2	dint		
IW1.1.1.6	DS 99 in 3	dint		
QW1.1.1.7	DS 99 out 1	dint		
QW1.1.1.8	DS 99 out 2	dint		
QW1.1.1.9	DS 99 out 3	dint		
IW1.1.1.10	UnitStatus	dint		

Figure 14. NAI0 connection window.

## Special I/O Function Blocks

This chapter introduces the Special I/O units supported by the CI858 and gives instructions on how to configure the input and output channels of the I/O units in the application program.

I/O units can be controlled with function blocks. All connected I/O units require their own function block, which is selected according to the I/O unit type. A function block has a defined set of input and output variables and variables for internal storage. It also has an algorithm to operate these variables. When a function block is executed, it evaluates all its variables and computes new values for the output and internal variables.

Special I/O function blocks are stored in the Special I/O library delivered with the product. By connecting the library to a project in the Control Builder, the function blocks become available to the application.



Before using function blocks, appropriate library must be inserted into the project and the I/O unit must be inserted into the CI858 hardware tree.

### How to Insert a Library File

1. Select from the Control Builder menu Insert File Into Project - Library.
2. The Insert Library dialog box is displayed. Select a library from the list in the dialog box or type the name of the library in the File name field (extension \*.lbr).
3. Click the Open button to insert the library.
4. The inserted library is displayed in the Project Explorer as a subfolder to the Library folder.

### How to Insert a Special I/O Unit

See [Adding a Special I/O Unit](#) on page 42.



More information on how to configure and use Special I/O is described in the Special I/O documentation. This documentation, together with the Special I/O library and Special I/O Hardware file, is delivered with the Special I/O product.

## Activating a Function Block

A Function block is activated in the programming editor.

1. Expand the root Application(s) folder and select the Programs folder. Double-click the appropriate program to enter the programming editor.




Figure 15. Hierarchical structure of the application.

2. Select Function blocks tab in the Declaration pane and fill in the following items:

**Name:** User-defined name of the function block.

**Function Block Type:** Name of the function block used in the library file as defined in this manual. See the following function block descriptions.

**Task Connection:** This section needs to be filled only if distributed execution is applied to the application program.

**Description:** User-defined information about the function block.

	Name	Function Block Type	Description
1	MY_BI	BIO2CONF	Configures NBIO-21
2			
3			

} Declaration pane

Variables    **Function blocks**

3. Type the user-defined name of the function block followed by a left parenthesis in the Code pane. A connection editor is automatically displayed to assist you in specifying the input/output parameters. (You cannot edit the parameter list itself, you can only connect already defined parameters.)



Each I/O unit in the hardware tree must have their own function block. I.e. if there are tree NTAC-02 units, tree TAC\_SP function blocks need to be called.

## NBIO-21

The Basic I/O unit NBIO-21 has 3 digital inputs, 2 analogue inputs, 2 digital outputs and 2 analogue outputs.

There are five library function blocks for handling the NBIO-21 unit: BIO2CONF, BIO2DI, BIO2DO, BIO2AO and BIO2AI.

### BIO2CONF

Function block BIO2CONF is used to configure the NBIO-21 unit. BIO2CONF selects the hardware gain of the analogue inputs and provides automatic calibration for the A/D converter.

BIO2CONF should be called if function block BIO2AI is in use, and if the default configuration of the unit is not sufficient. To reduce system load, BIO2CONF is recommended to be executed at a longer time cycle than BIO2AI, for example > 1000 ms.

The actual selection of the I/O unit is made in Control Builder's hardware editor by connecting respective channels of the NBIO-21 unit to input and output signals 4...12 (conf\_inw1... UnitStatus). See [Table 7](#) and [Connections](#) on page 44.



Cyclic DDCS messages from BIO2CONF cannot be disabled.

Table 7. Input and output signals of the BIO2CONF.

No	Name	Direction	Data type	Description
1	CONV_AI1	in	bool	Hardware gain for channel 1. See table 8.
2	CONV_AI2	in	bool	Hardware gain for channel 2. See table 8.
3	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
4	conf_inw1	in	dint	First input word of DS 101.
5	conf_outw1	out	dint	First output word of DS 101.
6	conf_outw2	out	dint	Second output word of DS 101.
7	conf_outw3	out	dint	Third output word of DS 101.
8	calib_inw	in	dint	First input word of DS 32.
9	calib_outw1	out	dint	First output word of DS 32.
10	calib_outw2	out	dint	Second output word of DS 32.
11	calib_outw3	out	dint	Third output word of DS 32.
12	UnitStatus	in	dint	Unit Status

Table 8. Hardware gain of the analogue inputs.

Type	Values	Channel AI1	Channel AI2
Voltage	-10...10 V	CONV_AI1 = 0	CONV_AI2 = 0
Voltage	-2...2 V	CONV_AI1 = 1	CONV_AI2 = 1
Current	-20...20 mA	CONV_AI1 = 1	CONV_AI2 = 1

**BIO2DI**

Function block BIO2DI is used for reading digital input signals from the NBIO-21 unit.

The actual selection of the I/O unit is made in Control Builder's hardware editor by connecting respective channels of the NBIO-21 unit to input signals 5...8 (inword1... UnitStatus). See [Table 9](#) and [Connections](#) on page 44.

Table 9. Input and output signals of the BIO2DI.

No	Name	Direction	Data type	Description
1	DI1	out	bool	Output for digital input DI1.
2	DI2	out	bool	Output for digital input DI2.
3	DI3	out	bool	Output for digital input DI3.
4	ERR	out	bool	Communication status. 1 = error See <a href="#">Output Error</a> on page 84.
5	Inword1	in	dint	First input word of DS 100 (R).
6	Inword2	in	dint	Second input word of DS 100 (R).
7	Inword3	in	dint	Third input word of DS 100 (R).
8	UnitStatus	in	dint	Unit status

## BIO2DO

Function block BIO2DO is used for writing digital output signals to the NBIO-21 unit.

The actual selection of the I/O unit is made in Control Builder's hardware editor by connecting respective channels of the NBIO-21 unit to input and output signals 4...8 (outword1... UnitStatus). See [Table 10](#) and [Connections](#) on page 44.

Table 10. Input and output signals of the BIO2DO.

No	Name	Direction	Data type	Description
1	DO1	in	bool	Input for digital output DO1
2	DO2	in	bool	Input for digital output DO2
3	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
4	outword1	out	dint	First output word of DS 100 (R/W).
5	outword2	out	dint	Second output word of DS 100 (R/W).
6	outword3	out	dint	Third output word of DS 100 (R/W).
7	inword1	in	dint	First input word (= dummy) of DS 100 (R/W).
8	UnitStatus	in	dint	Unit status.

## BIO2AO

Function block BIO2AO is used for writing analogue output signals (voltage/current) to the NBIO-21 unit.

The actual selection of the I/O unit is made in Control Builder's hardware editor by connecting respective channels of the NBIO-21 unit to input and output signals 4...8 (dummy\_in... UnitStatus). See [Table 11](#) and [Connections](#) on page 44.

Table 11. Input and output signals of the BIO2AO.

No	Name	Direction	Data type	Description
1	AO1	in	dint	Input for analogue output AO1.
2	AO2	in	dint	Input for analogue output AO2.
3	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
4	dummy_in	in	dint	First input word (=dummy) of DS 99.
5	outword1	out	dint	First output word of DS 99.
6	outword2	out	dint	Second output word of DS 99.
7	outword3	out	dint	Third output word of DS 99.
8	UnitStatus	in	dint	Unit status

BIO2AO does not scale the analogue output signals. Scaling between application software and analogue output AO1/AO2 requires extra application blocks.

*Scaling example:*

Analogue output value -10 V...+10 V corresponds to integer (I) input value -20000...+20000 in the application software.



$$AO1 = (IN * VALUE_{10V} / MAX\_IN\_VALUE) + 8388607$$

$$MAX\_IN\_VALUE = 20000$$

$$VALUE_{10V} = (10.00 / 11.02) * 8388607 = 7612166$$

Table 12. Analogue output scaling.

Channel	Type	Nominal value	Scaling for nominal value	Full scaling range
AO1, AO2	Voltage	-10.00...+10.00 V	776440...16000773	-11.02...+11.02 V 0...16777215
AO1, AO2	Current	0...20.0 mA	0...15183000	0...22.10 mA 0...16777215



Voltage scaling  
 $+10.00 \text{ V} == (10.00 \text{ V} / 11.02 \text{ V}) * 8388607 = 7612166$   
 $-10.00 \text{ V} == (10.00 \text{ V} / 11.02 \text{ V}) * -8388607 = -7612166$

## BIO2AI

Function block BIO2AI is used for reading analogue input signals (voltage/ current) from the NBIO-21 unit.

The actual selection of the I/O unit is made in Control Builder's hardware editor by connecting respective channels of the NBIO-21 unit to input signals 4...7 (inword1... UnitStatus). See [Table 13](#) and [Connections](#) on page 44.

Voltage/current measurement is selected using a 2-pole DIP switch S2 on the NBIO-21 unit.

Table 13. Input and output signals of the BIO2AI.

No	Name	Direction	Data type	Description
1	AI1	out	dint	Output for analogue input AI1.
2	AI2	out	dint	Output for analogue input AI2.
3	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
4	inword1	in	dint	First input word of DS 54.
5	inword2	in	dint	Second input word of DS 54.
6	inword3	in	dint	Third input word of DS 54.
7	UnitStatus	in	dint	Unit status

BIO2AI does not scale the analogue input signals. Scaling between application software and analogue input requires extra application blocks.

*Scaling example 1:*

Analogue input value -10 V ...+10 V corresponds to integer (I) value -20000...+20000 in the application software.

$$AI1_{\text{scaled}} = (AI1 * \text{MAX\_OUT\_VALUE}) / \text{VALUE}_{10V}$$

$$\text{MAX\_OUT\_VALUE} = 20000$$

$$\text{VALUE}_{10V} = (10.00 / 11.25) * 8388607 = 7456540$$

*Scaling example 2:*

Analogue input value 4 mA ...20 mA corresponds to integer (I) value 0...+20000 in the application software.

$$AI1_{\text{scaled}} = ((AI1 - \text{VALUE}_{4\text{mA}}) * \text{MAX\_OUT\_VALUE}) / \text{VALUE}_{16\text{mA}}$$

$$\text{MAX\_OUT\_VALUE} = 20000$$



$$\text{VALUE}_{4\text{mA}} = (4 / 22.5) * 8388607 = 1491308$$

$$\text{VALUE}_{16\text{mA}} = (16 / 22.5) * 8388607 = 5965231$$

Scaled output AI1 value must be limited between 0...32767.

Table 14. Analogue input scaling.

Channel	Type	Nominal value	Scaling for nominal value	Full scale range
AI1, AI2	Voltage	-10...10 V	-7456540...7456540	-11.25...11.25 V, +/-8388607
AI1, AI2	Voltage	-2...2 V	-7456540...7456540	-2.25...2.25 V, +/-8388607
AI1, AI2	Current	-20...20 mA	-7456540...7456540	-22.5...22.5 mA, +/-8388607



Voltage scaling

$$+10.00 \text{ V} == (10.00 \text{ V} / 11.25 \text{ V}) * 8388607 = 7456540$$

$$-10.00 \text{ V} == (10.00 \text{ V} / 11.25 \text{ V}) * -8388607 = -7456540$$

## NBIO-31

The Basic I/O unit NBIO-31 has 4 digital inputs and 3 digital outputs.

There are two library function blocks for handling the NBIO-31 unit: BIO3DI and BIO3DO.

### BIO3DI

Function block BIO3DI is used for reading digital input signals from the NBIO-31 unit.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NBIO-31 unit to input signals 6...9 (inword1... UnitStatus). See [Table 15](#) and [Connections](#) on page 44.

Table 15. Input and output signals of the BIO3DI.

No	Name	Direction	Data type	Description
1	DI1	out	bool	Output for Digital Input DI1.
2	DI2	out	bool	Output for Digital Input DI2.
3	DI3	out	bool	Output for Digital Input DI3.
4	DI4	out	bool	Output for Digital Input DI4.
5	ERR	out	bool	Communication Status. 1 = Error See <a href="#">Output Error</a> on page 84.
6	inword1	in	dint	First input word of DS 100 (R).
7	inword2	in	dint	Second input word of DS 100 (R).
8	inword3	in	dint	Third input word of DS 100 (R).
9	UnitStatus	in	dint	Unit Status

## BIO3DO

Function block BIO3DO is used for writing digital output signals to the NBIO-31 unit.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NBIO-31 unit to input and output signals 5...9 (outword1... UnitStatus). See [Table 16](#) and [Connections](#) on page 44.

Table 16. Input and output signals of the BIO3DO.

No	Name	Direction	Data type	Description
1	DO1	in	bool	Input for digital output DO1.
2	DO2	in	bool	Input for digital output DO2.
3	DO3	in	bool	Input for digital output DO3.
4	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
5	outword1	out	dint	First output word of DS 100 (R/W).
6	outword2	out	dint	Second output word of DS 100 (R/W).
7	outword3	out	dint	Third output word of DS 100 (R/W).
8	inword1	in	dint	First input word (=dummy) of DS 100 (R/W).
9	UnitStatus	in	dint	Unit status

## NDIO

The NDIO unit has two digital inputs and two relay outputs. For more information see *NTAC-0x/NDIO-0x/NAIO-0x Installation and Start-up Guide [3AFY 58919730 (English)]*.

There are two library function blocks for handling NDIO units: NDIO1DI and NDIO1DO.

### NDIO1DI

Function block NDIO1DI is used for reading digital input signals from the NDIO unit.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NDIO unit to input signals 4...7 (inword1... UnitStatus). See [Table 17](#) and [Connections](#) on page 44.

Table 17. Input and output signals of the NDIO1DI.

No	Name	Direction	Data type	Description
1	DI1	out	bool	Output for digital input DI1.
2	DI2	out	bool	Output for digital input DI2.
3	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
4	inword1	in	dint	First input word of DS 100 (R).
5	inword2	in	dint	Second input word of DS 100 (R).
6	inword3	in	dint	Third input word of DS 100 (R).
7	UnitStatus	in	dint	Unit status

**NDIO1DO**

Function block NDIO1DO is used for controlling digital outputs of the NDIO.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NDIO unit to input and output signals 4...8 (outword1... UnitStatus). See [Table 18](#) and [Connections](#) on page 44.

Table 18. Input and output signals of the NDIO1DO.

No	Name	Direction	Data type	Description
1	DO1	in	bool	Input for digital output DO1.
2	DO2	in	bool	Input for digital output DO2.
3	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
4	outword1	out	dint	First output word of DS 100 (R/W).
5	outword2	out	dint	Second output word of DS 100 (R/W).
6	outword3	out	dint	Third output word of DS 100 (R/W).
7	inword1_dummy	in	dint	First input word (=dummy) of DS 100 (R/W).
8	UnitStatus	in	dint	Unit status

## NAIO

The NAIO unit has two current or voltage inputs and two current outputs. For more information see *NTAC-0x/NDIO-0x/NAIO-0x Installation and Start-up Guide [3AFY 58919730 (English)]*.

There are two library function blocks for handling NAIO units: NAI02AI and NAI02AO.

### NAIO2AO

Function block NAI02AO is used for writing analogue output signals (current) to the NAIO unit.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NAIO unit to input and output signals 4...8 (outword1... UnitStatus). See [Table 19](#) and [Connections](#) on page 44.

Table 19. Input and output signals of the NAI02AO.

No	Name	Direction	Data type	Description
1	AO1	in	dint	Input for analogue output AO1
2	AO2	in	dint	Input for analogue output AO2.
3	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
4	outword1	out	dint	First output word of DS 99.
5	outword2	out	dint	Second output word of DS 99.
6	outword3	out	dint	Third output word of DS 99.
7	inword1_dummy	in	dint	First input word (=dummy) of DS 99.
8	UnitStatus	in	dint	Unit status

NAIO2AO does not scale the analogue output signals. Scaling between application software and analogue output AO1/AO2 requires extra application blocks.

*Scaling example:*

An integer (I) input value 0...+20000 in the application software corresponds to analogue output value 0...+20 mA.



$$AO1 = (IN * VALUE_{20mA}) / MAX\_IN\_VALUE$$

$$MAX\_IN\_VALUE = 20000$$

$$VALUE_{20mA} = (20.00 / 22.09) * 16777215 = 15189873$$

Table 20. Analogue output scaling

Channel	Type	Nominal value	Scaling for nominal value	Full scaling range
AO1, AO2	Current	0...20 mA	0...15189873	0...22.09 mA, 0...16777215



Current scaling  
 +20 mA == (20 mA / 22.09 mA) \* 16777215 = 15189873  
 0 mA == 0

**NAIO2AI**

Function block NAIO2AI is used for reading analogue input signals (voltage/current) from the NAIO unit.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NAIO unit to input signals 4...7 (inword1...UnitStatus). See [Table 21](#) and [Connections](#) on page 44.

Table 21. Input and output signals of the NAIO2AI.

No	Name	Direction	Data type	Description
1	AI1	out	dint	Output for digital input DI1.
2	AI2	out	dint	Output for digital input DI2.
3	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
4	inword1	in	dint	First input word of DS 51.
5	inword2	in	dint	Second input word of DS 51.
6	inword3	in	dint	Third input word of DS 51.
8	UnitStatus	in	dint	Unit status

The voltage/current measurement is selected using DIP switches on the NAIO unit.

NAIO2AI does not scale the analogue input signals. Scaling between application software and analogue input requires extra application blocks.

*Scaling example:*

Analogue input value -10...+10 V corresponds to integer (I) value -20000...+20000 in the application software.

$$AI1_{\text{scaled}} = ((AI1 - \text{VALUEOFFSET}_{0V}) * \text{MAX\_OUT\_VALUE}) / \text{VALUE}_{10V}$$

$$\text{MAX\_OUT\_VALUE} = 20000$$

$$\text{VALUEOFFSET}_{0V} = 8388607 / 2 = 4194303$$



$$\text{VALUE}_{10V} = (10.00 / 10.18) * 8388607 / 2 = 4120140$$

Table 22. Unipolar Analogue Input Scaling.

Channel	Type	Nominal value	Scaling for nominal value	Full scaling range
AI1, AI2	Voltage	0...10 V	0...8240282	0...10.18 V, 0...8388607
AI1, AI2	Voltage	0...2 V	0...8240282	0...2.037 V, 0...8388607
AI1, AI2	Current	0...20 mA	0...8240282	0...20.37mA, 0...8388607

Table 23. Bipolar Analogue Input Scaling.

Channel	Type	Nominal value	Scaling for nominal value	Full scaling range
AI1, AI2	Voltage	-10...10 V	74160...8314400	-10.18...10.18 V, 0...8388607
AI1, AI2	Voltage	-2...2 V	74160...8314400	-2.037...2.037 V, 0...8388607
AI1, AI2	Current	-20...20 mA	74160...8314400	-20.37...20.37mA, 0...8388607



## NPCT

NPCT-01 Pulse Counter / Timer Unit is an I/O option board used with CI858. Its main areas of use are speed and position measurement and applications which require programmable, hardware based counter functions such as fast control of digital outputs as a function of position or time and holding registers for capturing events. For more information see *NPCT-01 Pulse Counter/Timer Unit description [3AFY64362828(English)]*.

There are five library function blocks for handling the NPCT-01 board: PCT\_CONF, SPEEDPO1, SPEED\_R, POS\_IL1 and CONV24.

### PCT\_CONF

Function block PCT\_CONF is used to change the default configuration of the NPCT-01 board.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NPCT board to input and output signals 12...20 (outword2\_ds3... UnitStatus). See [Table 24](#) and [Connections](#) on page 44.

Board specific configurations are sent to NPCT board via dataset 5 by using Outword3\_ds5. Dataset 3 (encoder channel 1) and dataset 4 (encoder channel 2) are used for channel specific configurations.

Table 24. Input and output signals of the PCT\_CONF. (DS= dataset, DW = data word)

No	Name	Direction	Data type	Description
1	WD_TO	in	bool	Selection of WatchDog time out. 0 = 100 ms, 1 = 1 s (default)
2	WD_ENA	in	bool	Enables WatchDog function between CI858 and NPCT. 0 = disabled, 1 = enabled (default)
3	CALC_INT	in	bool	Speed calculation interval. 0 = 250 us (=default), 1 = 10 ms
4	MODE1	in	dword	Encoder channel 1 configuration command. Default = 17 (HEX)
5	MODE2	in	dword	Encoder channel 2 configuration command. Default = 17 (HEX)

Table 24. Input and output signals of the PCT\_CONF. (DS= dataset, DW = data word)

No	Name	Direction	Data type	Description
6	PPR1	in	int	Encoder channel 1 pulse numbers.
7	PPR2	in	int	Encoder channel 2 pulse numbers.
8	BOARD_St	out	dword	Board configuration status. See next table.
9	CH1Conf_St	out	dword	Encoder channel 1 configuration status.
10	CH2Conf_St	out	dword	Encoder channel 2 configuration status.
11	ERR	out	bool	Communication status. 1 = Error. See <a href="#">Output Error</a> on page 84.
12	Outword2_ds3	out	dint	Second output word of DS 3
13	Outword3_ds3	out	dint	Third output word of DS 3
14	Outword2_ds4	out	dint	Second output word of DS 4
15	Outword3_ds4	out	dint	Third output word of DS 4
16	Outword3_ds5	out	dint	Second output word of DS 3
17	Inword3_ds3	in	dint	Third input word of DS 3
18	Inword3_ds4	in	dint	Third input word of DS 4
19	Inword3_ds5	in	dint	Third input word of DS 5
20	UnitStatus	in	dint	Unit status

Table 25. Basic configuration status of BOARD\_St.

Bit	Name	Description
D0	WD_TO	WatchDog time out: 0 = 100 ms, 1 = 1 s
D1	WD_ENA	WatchDog enable: 0 = disabled, 1 = enabled
D2	not used	
D3	CALC_INT	Speed calculation interval: 0 = 250 us, 1 = 10 ms
D4	CTRL_TYPE	Application controller type: 0 = CI858, 1 = AMC

Table 25. Basic configuration status of BOARD\_St.

Bit	Name	Description
D5	CPLD_CONF	CPLD configuration status: 0 = configuration completed, 1 = configuration in progress
D6	CPLD_ERR	Error in configuring the CPLD: 0 = configuration successful, 1 = configuration error

Table 26. Encoder channel configuration commands of MODE1, MODE2.

Bit	Name	Description
D0	EOSC_MODE	Selection of edge oscillation inhibition mode: 0 = disabled, 1 = enabled The edge oscillation inhibition mode, EOSC_MODE, is used to prevent false occurrences of pulse edges that are caused mainly by mechanical vibration of the motor shaft at slow or zero speed. When this mode is enabled, pulse edges are rejected unless they occur alternately on CHA and CHB, i.e. an edge is rejected if the previous edge occurred on the same channel. Both CHA and CHB must be connected when EOSC_MODE is enabled.
D1...D2	EDGE_MODE	Selection of pulse counter edge mode: 00 = Rising edges of CHA are counted, CHB determines the direction. 01 = Rising and falling edges of CHA are counted, CHB is not used. 10 = Rising and falling edges of CHA are counted, CHB determines the direction. 11 = Rising and falling edges of CHA and CHB are counted, CHB determines the direction.
D3	POS_MODE	Selection of position value calculation mode: 0 = incremental mode, 1 = absolute mode In incremental mode the position value varies between -32768...32767. Function Block POS_IL1 extends the 16-bit position value into a 32-bit value for wider range measurements. In absolute mode the position value varies between 0... (edgeno * ppr)-1 indicating the angular displacement from the zero position, i.e. the encoder zero pulse. The absolute mode position calculation requires a rising edge of the zero pulse to be selected as the position strobe signal.
D4	SYNC_MODE	Selection of channel synchronisation mode: 0 = disabled, 1 = enabled In synchronised speed measurement mode the speed and position measurement and the DDCCS communication are tied together in a way that ensures that the speed and position values of both encoder inputs (CH1 and CH2) are measured during the same cycle time.
D5...D7	not used	

Table 27. Encoder channel configuration status of CH1Conf\_St, CH2Conf\_St

Bit	Name	Description
D0	CH_CONF	Channel configuration status: 0 = channel is not configured, default values are in use 1 = channel is configured
D1	ZERO_STAT	Indicates detection of a single zero strobe*: 0 = zero strobe not detected, 1 = zero strobe detected ZERO_STAT is set when the first zero strobe is detected. For dynamic monitoring of zero strobe occurrences bit NEW_ZERO can be used.
D2	NEW_SPEED	Indicates that a new speed value is available: 0 = not available, 1 = available NEW_SPEED is set when the calculated speed is based on actual pulses i.e. at least one pulse is received during the last sampling time. If calculated speed is an estimate, NEW_SPEED is not set.
D3	ENC_STAT	Encoder motion status: 0 = running, 1 = stopped
D4...D5	not used	
D6	NEW_ZERO	Indicates detection of a new zero strobe: 0 = not detected. 1 = detected. NEW_ZERO is set if a zero strobe has been detected since the last communication request.
D7	SPEED_SIGN	Sign of the current speed value: 0 = positive, 1 = negative

\*The position value can be set to zero with an external signal, zero strobe. The zero strobe signal can be a combination of the encoder zero pulse CHZ and a digital input.

**SPEEDPO1**

Speed and position measurement values of encoder channels CH1 and CH2 are read from the NPCT-01 board with function block SPEEDPO1.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NPCT board to input and output signals 16...26 (outword2\_ds1... UnitStatus). See [Table 28](#) and [Connections](#) on page 44.

Table 28. Input and output signals of the SPEEDPO1.

No	Name	Direction	Data type	Description
1	FILT1	in	dint	Sampling time of the speed calculation (CH1). Input signal CALC_INT of PCT_CONF effects the sampling time. If the calculation interval is set to 10 ms, CALC_INT = 1, one sample time unit corresponds to 40 ms. If CALC_INT = 0, 1...25 = 1...25 ms (default 2 ms) If CALC_INT = 1, 1...25 = 40...1000 ms
2	STRB1	in	dword	Zero strobe configuration command (CH1). STRB1 is set with a rising edge of WR_STRB1. (0 -> 1). See next table.
3	WR_STRB1	in	bool	Dynamic input for new zero strobe configuration (CH1). STRB1 is set with a rising edge of WR_STRB1 (0 -> 1).
4	FILT2	in	dint	Sampling time of speed calculation (ch2). Input signal CALC_INT of PCT_CONF effects the sampling time. If the calculation interval is set to 10 ms (CALC_INT=1) one sample time unit corresponds to 40 ms. If CALC_INT=0, 1...25 = 1...25 ms, (default 2 ms) If CALC_INT=1, 1...25 = 40...1000 ms
5	STRB2	in	dword	Zero strobe configuration command (CH2). STRB2 is set with a rising edge of WR_STRB2. (0 -> 1). See next table.
6	WR_STRB2	in	bool	Dynamic input for new zero strobe configuration (CH2). STRB2 is set with a rising edge of WR_STRB2. (0 -> 1)
7	SPEED1	out	dint	Actual speed value (CH1).
8	POSACT1	out	int	Actual position value (CH1).
9	STRBRDY1	out	bool	Zero strobe detection (CH1). 1 = detected
10	STATUS1	out	dword	Encoder channel 1 status. See table STATUS.
11	SPEED2	out	dint	Actual speed value (CH2).

Table 28. Input and output signals of the SPEEDPO1.

No	Name	Direction	Data type	Description
12	POSACT2	out	int	Actual position value (CH2).
13	STRBRDY2	out	bool	Zero strobe detection (CH2). 1 = detected
14	STATUS2	out	dword	Encoder channel CH2 status. See table STATUS
15	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
16	Outword2_ds1	out	dint	Second output word of DS 1.
17	Outword3_ds1	out	dint	Third output word of DS 1.
18	Outword2_ds2	out	dint	Second output word of DS 2.
19	Outword3_ds2	out	dint	Third output word of DS 2.
20	Inword1_ds1	in	dint	First input word of DS 1.
21	Inword2_ds1	in	dint	Second input word of DS 1.
22	Inword3_ds1	in	dint	Third input word of DS 1.
23	Inword1_ds2	in	dint	First input word of DS 2.
24	Inword2_ds2	in	dint	Second input word of DS 2.
25	Inword3_ds2	in	dint	Third input word of DS 2.
26	UnitStatus	in	dint	Unit status

Value of POSACT1/POSACT2 is equal to the amount of pulse edges received from the incremental encoder, i.e. if four encoder signal edges are counted, the position value will increase by four times the encoder pulse number with each turn.

SPEED1/SPEED2 corresponds to the signed actual value of the tacho frequency. The frequency is calculated from the ratio of the number of received encoder pulse edges ( $D_p$ ) and the time between the first and last received pulse edge ( $D_t$ ) during the selected sampling time  $FILT1/FILT2$ .

*Scaling of SPEED1:*

When tacho frequency is 500000 Hz the output value of SPEED1 is 8388607.

$SPEED1 = (D_p * 8388607) / (D_t * 500000 * n)$   
 $n$  is the number of edges counted (1, 2 or 4)

*Calculation example:*

$$f_{\text{encoder}} = 25000 \text{ Hz (four edges} = 100000 \text{ Hz)}$$

$$Dt = 0.016 \text{ ms}$$

$$Dp = (0.016 \text{ ms} / 1 \text{ s}) * 100000 = 1600$$

$$\text{SPEED1} = (1600 * 8388607) / (0.016 * 500000 * 4) = 419430.35$$

Table 29. Zero strobe configuration commands STRB1, STRB2

Bit	Name	Description
D0...D2	ZERO_MODE	Selection of zero strobe* mode for encoder channel 1/2: 000 = strobe disabled 001 = rising edge of the zero pulse 010 = rising edge of the zero pulse when DI1/DI2 = 0 011 = rising edge of the zero pulse when DI1/DI2 = 1 100 = rising edge of DI1/DI2 signal followed by a zero pulse 101 = DI1/2 falling edge followed by a zero pulse rising edge 110 = DI1/2 rising edge 111 = DI1/2 falling edge DI1 is used for encoder channel 1 and DI2 for encoder channel 2.
D3	ZERO_RST	Selection of zero strobe mode reset control: 0 = no reset, 1 = reset zero strobe mode to 000 after zero strobe. Setting ZERO_RST to 1 makes it possible to accept a single zero strobe. A new zero strobe is enabled by writing a new value to ZERO_MODE and setting bit ZERO_UPD to 1.
D4	ZERO_FILT	Selection of hardware filter time constant for DI1/2: 0 = 100 us, 1 = 5 ms
D5	ZERO_UPD	Updating of zero strobe configuration: 0 = not updated, 1 = the zero strobe configuration is updated according to bits D0...D4.
D6...D7	not used	

\* Position value can be set to zero with an external hardware signal, a zero strobe. The zero strobe signal can be a combination of the encoder zero pulse CHZ and a digital input, see table [Table 27](#). Status signal NEW\_ZERO indicates a detection of a new zero strobe. NEW\_ZERO is set if a zero strobe has been detected since the last communication request.

Table 30. Encoder channel status: STATUS1, STATUS2

Bit	Name	Description
D0	CH_CONF	Channel configuration status: 0 = not configured, default values are in use, 1 = configured
D1	ZERO_STAT	Indicates detection of a single zero strobe: 0 = not detected, 1 = detected ZERO_STAT is set when the first zero strobe is detected. NEW_ZERO can be used for dynamic monitoring of zero strobe occurrences.
D2	NEW_SPEED	Indicates if the new speed value is available: 0 = not available, 1 = available NEW_SPEED is set when the calculated speed is based on actual pulses i.e. at least one pulse is received during the last sampling time. If calculated speed is an estimate, NEW_SPEED is not set.
D3	ENC_STAT	Encoder motion status: 0 = running, 1 = stopped
D4...D5	not used	
D6	NEW_ZERO	Indicates detection of a new zero strobe: 0 = not detected, 1 = detected NEW_ZERO is set if a zero strobe has been detected since the last request.
D7	SPEED_SIGN	Sign of the current speed value: 0 = positive, 1 = negative

**SPEED\_R**

Function block SPEED\_R converts long integer (IL) values of the actual speed into real number values (rpm). SPEED\_R is intended for use with function blocks SPEEDPO1 and TAC\_SP.

Table 31. Input and output signals of the SPEED\_R.

No	Name	Direction	Data type	Description
1	PPR	in	real	Encoder channel pulse number.
2	NSPEED	in	real	Nominal rotational speed in rpm.
3	SCALE	in	real	Output value at nominal rotational speed in rpm.
4	SPEED	in	dint	Actual speed.
	RPM	out	real	Actual speed in rpm.

SPEED\_R realises the following formula:

$$\text{RPM} = (60 * 500000 * \text{SPEED} * \text{SCALE}) / (\text{PPR} * 8388607 * \text{NSPEED})$$

Conversion to rpm is made by using the following part of the formula:

$$\text{RPM} = (60 * 500000 * \text{SPEED}) / \text{PPR} * 8388607$$

Scaling of rpm value is made by SCALE and NSPEED.

*Example:*

$$\text{PPR} = 2048$$

$$\text{SPEED} = 419430$$

$$\text{SCALE} = 1500$$

$$\text{NSPEED} = 1500 \text{ rpm}$$

$$\text{RPM} = (60 * 500000 * 419430 * 1500) / (2048 * 8388607 * 1500) = 732.421 \text{ rpm}$$

**POS\_IL1**

Function block POS\_IL1 extends the 16-bit position value into a 32-bit value for wider range measurements. Function block POS\_IL1 is intended to be used with function blocks SPEEDPO1 and TAC\_SP.

Table 32. Input and output signals of POS\_IL1.

No	Name	Direction	Data type	Description
1	SW_STRB	in	bool	Zero strobe within the application program. (0 - > 1 new zero strobe)
2	STRB_VAL	in	dint	Value of the zero strobe.
3	POSACT	in	int	16-bit actual position value.
4	STATUS SPEED	in	dword	Encoder channel status.
5	POS_IL	out	dint	32-bit actual position value.

POSACT is a 16-bit position value received from the output of SPEEDPO1 or TAC\_SP. STATUS SPEED indicates the encoder channel status, which is received from the output of SPEEDPO1.

When zero strobe is detected (bit 6 of STATUS signal of function block SPEEDPO1 is 1), POS\_IL is set to the value of STRB\_VAL. A zero strobe can also be activated from the application program by connecting a rising edge to the input SW\_STRB.

Incremental mode should be selected for position calculation with function blocks SPEEDPO1 or TAC\_SP.

**CONV24**

AC 800M dataset communication consists of 16-bit data words while NPCT communication consists of 24-bit data words. To simplify the programming of the NPCT board, function block CONV24 is used to convert 24-bit input values INVAL1 and INVAL2 into three 16-bit output words outword1...3 (or inword1...3 into OUTVAL1 and OUTVAL2).

Table 33. Input and output signals of CONV24.

No	Name	Direction	Data type	Description
1	INVAL1	out	dint	24-bit input value.
2	INVAL2	out	dint	24-bit input value.
3	OUTVAL1	in	dint	24-bit output value.
4	OUTVAL2	in	dint	24-bit output value.
5	ERR	out	bool	Communication status. 1 = Error. See <a href="#">Output Error</a> on page 84.
6	Outword1	out	dint	First output word of DS x.*
7	Outword2	out	dint	Second output word of DS x.*
8	Outword3	out	dint	Third output word of DS x.*
9	Inword1	in	dint	First input word of DS x.*
10	Inword2	in	dint	Second input word of DS x.*
11	inword3	in	dint	Third input word of DS x.*
12	UnitStatus	in	dint	Unit status

\* x = 6...10

## NTAC

NTAC-02 is a speed and position measurement unit which can be used with CI858. Software revision of the NTAC-02 unit should be 2.07 or later (absolute mode for position calculation does not work correctly with older revisions). For more information see *NTAC-0x/NDIO-0x/NAIO-0x Installation and Start-up Guide [3AFY 58919730 (English)]*.



NTAC unit functions only with original configuration settings i.e. when dataset 2 is OFF. This limitation is due to the fact, that all dataset communications from AC 800M to Special I/O units must be cyclic. If NTAC-02 receives a configuration dataset, it aborts current operation and restarts all internal counters. (it is not possible to send datasets “on demand”-basis)

There is one function block, TAC\_SP, for handling the NTAC-02 unit.

### TAC\_SP

The encoder speed and position measurement values are read from NTAC-02 with function block TAC\_SP. Functions SPEED\_R and POS\_IL1 can be used with TAC\_SP. See [SPEED\\_R](#) on page 75 and [POS\\_IL1](#) on page 76.

The actual selection of the I/O unit is made in the Control Builder’s hardware editor by connecting respective channels of the NTAC unit to input signals 20...26 (inword1... UnitStatus). See [Table 34](#) and [Connections](#) on page 44.

Table 34. Input and output signals of the TAC\_SP.

No	Name	Direction	Data type	Description
7	SPEED	out	dint	Actual speed value
8	POSACT	out	int	Actual position value
9	NEW_SP	out	bool	Indicates that new speed value is available. 1 = detected
10	ENC_STAT	out	bool	Encoder motion status. 0 = running, 1 = stopped
15	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
20	Inword1	in	dint	First input word of DS 1.
21	Inword2	in	dint	Second input word of DS 1.
22	Inword3	in	dint	Third input word of DS 1.
26	UnitStatus	in	dint	Unit status.

SPEED corresponds to the signed actual value of the tacho frequency. The frequency is calculated from the ratio of the number of received encoder pulse edges ( $D_p$ ) and the time between the first and last received pulse edge ( $D_t$ ) during the selected sampling time FILT.

*Output SPEED scaling:*

When tacho frequency is 500000 Hz then output value of SPEED is 8388607.

$$\text{SPEED} = (D_p * 8388607) / (D_t * 500000 * n)$$

n is the number of edges counted (1, 2 or 4).

*Calculation example:*

$$F_{\text{encoder}} = 25000 \text{ Hz (four edges, 100000 Hz)}$$

$$D_t = 0.016 \text{ ms}$$

$$D_p = (0.016 \text{ ms} / 1 \text{ s}) * 100000 = 1600$$

$$\text{SPEED} = (1600 * 8388607) / (0.016 * 500000 * 4) = 419430.35$$

Value of POSACT is equal to the amount of pulse edges received from the incremental encoder, i.e. if four encoder signal edges are counted, the position value will change by four times the encoder pulse number with each turn.

## NWIO

NWIO-01 Watchdog & I/O is a digital I/O option unit. It contains a watchdog logic for supervising the operation of the AC 800M and the CI858 software. The unit has two digital inputs (24 VDC or 115/230 VAC) and two digital outputs. Using a slide switch on the top of the unit, the watchdog logic can be connected to control the state of the digital output DO2.

The watchdog supervises the following operations of the CI858:

- Functioning of the CI858 application program.
- Communication over the dual port memory.
- Functioning of the CI858 operative system.
- Communication on the optical I/O ring.




Figure 16. Simplified block diagram of the NWIO-01 unit.

There are two function blocks for handling the NWIO-01 unit: NWIO1DI and NWIO1DO.

**NWIO1DI**

Function block NWIO1DI is used for reading digital input signals from the NWIO-01 unit.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NWIO unit to input signals 5...8 (inword1... UnitStatus). See [Table 35](#) and [Connections](#) on page 44.

Table 35. Input and output signals of NWIO1DI.

No	Name	Direction	Data type	Description
1	DI1	out	bool	Output for digital input DI1.
2	DI2	out	bool	Output for digital input DI2.
3	WD_STAT	out	bool	Selection of WatchDog function. 0 = not selected, 1 = selected
4	ERR	out	bool	Communication status. 1 = Error See <a href="#">Output Error</a> on page 84.
5	Inword1	in	dint	First input word of DS 100 (R).
6	Inword2	in	dint	Second input word of DS 100 (R).
7	Inword3	in	dint	Third input word of DS 100 (R).
8	UnitStatus	in	dint	Unit status.

**NWIO1DO**

Function block NWIO1DO is used for writing digital output signals to the NWIO-01 unit.

The actual selection of the I/O unit is made in the Control Builder's hardware editor by connecting respective channels of the NDIO unit to input and output signals 5...9 (outword1... UnitStatus). See [Table 36](#) and [Connections](#) on page 44.

Table 36. Input and output signals of NWIO1DO.

No	Name	Direction	Data type	Description
1	DO1	in	bool	Input for digital output DO1
2	DO2	in	bool	Input for digital output DO2.
3	WD_SEL	in	bool	Selection of the DO2 operation mode. DO2 can be used as normal software controlled digital output or as a watchdog output.
4	ERR	out	bool	Communication status. See <a href="#">Output Error</a> on page 84.
5	outword1	out	dint	First output word of DS 100 (R/W).
6	outword2	out	dint	Second output word of DS 100 (R/W).
7	outword3	out	dint	Third output word of DS 100 (R/W).
8	inword1_dummy	in	dint	First input word (=dummy) of DS 100 (R/W).
9	UnitStatus	in	dint	Unit status

Digital output DO2 can be used as a normal software controlled digital output or as a watchdog output. The operation mode is selected with the WATCHDOG ENABLED / DISABLED switch on the top of the unit and with input signal WD\_SEL. In watchdog mode, a retriggerable one shot circuit is connected between the software controlled output and the actual output relay. Changing the state of digital output DO2 refreshes the one shot circuit (software oscillator is made by the inverter element).




Figure 17. Watchdog operation.

The factory setting of the watchdog time constant is 1 s but it can be shortened to 0.2 s with jumper X1 inside the unit (X1, pins 1-2 = 0.2 s; pins 3-4 = 1 s).

The cycle time of the oscillator is  $2 * \text{execution interval of the NWIO1DO}$ . The cycle time must be fast enough compared with the time constant selection in the NWIO-01 unit.

Time constant 1 s: Execution interval of the task  $\leq 100$  ms, thus the cycle time of the oscillator is  $\leq 200$  ms.

Time constant 0,2 s: Execution interval of the task  $\leq 20$  ms, thus the cycle time of the oscillator is  $\leq 40$  ms.

## NCTI

For information about the NCTI-01 Crane Transducer Interface see *Crane transducer Interface User's manual [3ASC23F207 (English)]*.

## NDSC

NDSC-01 is the control board of the ACS600 Diode Supply Unit. For more information see *ACA 631/633 Diode Supply Section User's Manual [3AFY 61451544 (English)]*.

Configuration of the NDSC board is similar to the configuration of a drive.

## Output Error

When a communication error is detected in the cyclic DDCS message, output ERR is set according to the UnitStatus signal. Output ERR is cleared when an acknowledgement to the cyclic DDCS message without any errors is received from the I/O unit and old error indications are acknowledged.

Table 37. Output error (derived from UnitStatus).

Unit status	Error	Description
0	0	No errors detected.
1	1	Communication fails
2	1	Unacknowledged alarm or forced operation (i.e. output signal is forced to a value defined by the user in the hardware editor)

## Changing the CI858 System Settings

When a modified hardware configuration is downloaded to the controller, communication with hardware units can be interrupted:

- If modified CI858 parameters are downloaded to the controller, the CI858 communication is interrupted and the CI858 will reboot.
- If modified drive parameters are downloaded to the controller, communication with the drive is interrupted and a drive fault message indicating communication loss might be activated. If BusManager is not selected to monitor the connection, the fault can be avoided by adjusting the time delay of the drive communication loss supervision.
- If modified I/O parameters are downloaded to the controller, communication with the I/O unit is interrupted.
- If a drive or an I/O is added to or deleted from the hardware tree and the changes are downloaded to the controller, the CI858 will reboot.
- If the hardware tree positions of different types of drives or I/O's are changed and the changes are downloaded to the controller, the CI858 will reboot. Changing the position between two similar units will not result in CI858 rebooting.
- Changing the connected channels of a drive or an I/O causes recalculation of the connections.

## Online Help

For more information on how to configure the CI858 unit with the Control Builder Engineering Tool, see Online Help.



---

# Appendix A Technical Data

## General Technical Data

Table 38. General technical data

Protection class:	IP20
Approval:	CE-marked and meets the requirements specified in EMC Directive 89/336/EEC according to the standards EN 50081-2 and EN 61000-6-2.

## Ambient Data

Table 39. Ambient conditions

	<b>Operation</b> installed for stationary use	<b>Storage</b> in a protective package
Air temperature	+5 to +55 °C	-25 to +70 °C
Relative humidity (non-condensing)	5 to 95%	5 to 95%

## LED Indicators

Table 40. LED indicators

LED marking	Color	Reset state	Normal state	Description
F	RED	ON	OFF	Unit error or unit initializing.
R	GREEN	OFF	ON	Unit running.
Dbus; Rx	YELLOW			RECIEVE LED indicating reception of data frames on the DriveBus.
DBus; Tx	YELLOW			TRANSMIT LED indicating transmission of data frames on the DriveBus.
I/O; Rx	YELLOW			RECIEVE LED indicating reception of data frames on the I/O bus.
I/O; Tx	YELLOW			TRANSMIT LED indicating transmission of data frames on the I/O bus.
Tools	YELLOW			RECIEVE LED indicating reception of data frames on the PC Tool Bus. *
Tools	YELLOW			TRANSMIT LED indicating transmission of frames on the PC tool bus.*

\*This LED is not visible in the front of the unit. It can be seen through the ventilation holes in the plastic housing.

## Power Supply Requirements

Power supply for the unit is taken from L+ and L- on the CEX bus.

Table 41. Technical data for the power supply

	Minimum	Typical	Maximum
external supply voltage	17 V	24 V	30 V
external supply current			200 mA

## Optical Connectors

The CEM board connects to the drive system via three optical receiver/transmitter pairs. HP/Agilent Technologies Versatile Link Series (HFBR family) optical receiver/transmitters are used. Transmission speed of the optical fibres is 4 Mbit/s..

Table 42. Optical connectors D27-D29

Pin	Designator	Description	Pin	Designator	Description
1	TxD	transmit data	2	RxD	receive data

## DIN rail - TS 35/7.5

The figure below shows the profile and dimensions in mm (in.) of the DIN-rail TS 35/7.5.

Normal supplied length is 2m (6.6ft.) (to standard DIN 46 277, EN 50 022).




Figure 18. DIN-rail TS 35/7.5 dimensions

## CEB Connector, X1

The communication expansion module board CEM connects to the CEX bus via connector X1.

Table 43. CEB connector X1.

Pin	Designator	Description	Pin	Designator	Description
A1	CEX_L-	power supply	B1	CEX_L-	power supply
A2	CEX_L+_PRGS	power supply	B2	CEX_L+	power supply
A4	0 V		B4	INSERTED_HI_N	used in power supply
A5	0 V		B5	0 V	
A6	CLK+	CEX bus clock	B6	0 V	
A7	CLK-	CEX bus clock	B7	0 V	
A8	0 V		B8	0 V	
A9	DATA+	CEX bus data	B9	0 V	
A10	DATA-	CEX bus data	B10	0 V	
A11	0 V		B11	0 V	
A12	STRB+	CEX bus data strobe	B12	0 V	
A13	STRB-	CEX bus data strobe	B13	0 V	
A14	0 V		B14	0 V	
A15	INT_N	CEX bus interrupt	B15	0 V	
A16	0 V		B16	GSA	
A17	INIT	CEX bus reset	B17	GSB	
A18	0 V		B18	0 V	
A19- A37	not used	not used	B19- B24	not used	not used
A38	EM		B25	0 V	
A39	0 V		B26- B37	not used	not used
A40	EM		B38	EM	

Pin	Designator	Description	Pin	Designator	Description
A41	CEX_L+_PRCG	power supply	B39	INSERTER_LO_N	used in power supply
A42	CEX_L-	power supply	B40	EM	
			B41	CEX_L+	power supply
			B42	CEX_L-	power supply

## CEX Bus Interface

The CEX bus signals are listed in below.

Table 44. CEX bus signals.

Signal name	Level	Description	Note
DATA+	LVDS	Data	
DATA-	LVDS	Data	
STRB+	LVDS	Data strobe	
STRB-	LVDS	Data strobe	
CLK+	LVDS	CEX bus clock	
CLK-	LVDS	CEX bus clock	
INT0_N	TTL	Interrupt to CEX bus master	Open collector output
INIT	TTL	Init (reset) selected unit	
GSA(2:0)	TTL	Geographical select signals	
GSB(3:0)	TTL	Geographical select signals	
CEX_L+	+24 V	Power supply	17-30 V, 200 mA
CEX_L-	0 V	Power supply	





# Contact us

[www.abb.com/800xA](http://www.abb.com/800xA)  
[www.abb.com/controlsystems](http://www.abb.com/controlsystems)

Copyright© 2003-2014 ABB.  
All rights reserved.

2PAA113566-600

Power and productivity  
for a better world™

