

FUNCTIONS OF KEYS

↵ RETURNS (or ENTER, EXE, etc.)

- Scrolls through main menu or submenu

Read 1> + ↵ → Disp 2>

Flow Rng 1> + ↵ → Flow Unit 2>

- Enters default or confirms existing value.

Login En 1> 0? + ↵ → Login En 1> 0

1 ↵ ALPHANUMERIC plus RETURN

- Selects menu (or submenu) item and advances to its first submenu

Read 1> + 5 ↵ → Anlg Fsd 1>

Anlg Fsd 1> + 3 ↵ → Anlg Dir Fwd 1>

- Keystrokes can be combined as a shortcut

Read 1> 5 3 ↵ → Anlg Dir Fwd 1>

- Selects submenu and displays current value
A '?' indicates current value is configurable

Anlg Fsd 1> + 1 ↵ → Anlg Fsd 1> 20?

- Enters selected value at '?' prompt

Anlg Fsd 1> 20? + 9 ↵ → Anlg Fsd 1> 9

- Note. In some submenus, 1 = select, 0 = deselect

Q ↵ QUIT plus RETURN

- In main menu, exits system (Security access reverts to Level 0)

Read 1> + Q ↵ → Bye

- In submenu, returns to top of main menu, or parent submenu

Flow Rng 1> + Q ↵ → Read 1>

Flow Unit Ltr 1> + Q ↵ → Flow Rng 1>

ESC ESCAPE

- In any menu or submenu, returns to top of main menu

Flow Unit Ltr 1 + ESC → >

CONFIGURATION PROCEDURE

Main Menu	Submenus	Description
ABB Process ‡ MagMaster V 1.10 17/05/93		Indicates model variant software version, date ‡ or 'Slurry'
READ		
Read 1>	Read Flow 1> Read % 2> Read Fwd 3> Read Rev 4> Read Net 5> Read Alm 6> ** Read Vel 7>	Flow rate in selected units Flow rate in % of range Total in forward totalizer‡ Total in reverse totalizer‡ Net total (fwd minus rev) Current active alarms True flow velocity in m/sec, or ft/sec if flow units are in UGal or ft^3
		‡ Resettable to 0 if Tot ClrEn is set.

DISPLAY OPTIONS

Disp 2>	Disp Mode 1>	0 = Single line display 1 = Double line display 2 = New line for each update (for printers, etc.)
	Disp Res 2>	Resolution of flow display Enter number of decimal places required (max. = 6)

PASSWORDS

See information in Security Access section for detailed description

Login 3>	Login En 1>	Current Security level 0 = default For default passwords Enter 'user' for Level 1, 'engineer' for Level 2. Note: enter these passwords in ALL lower case
	** Login Key 2>	Changes Level 1 password
	** Login Key 3>	Changes Level 2 password

FLOW MEASUREMENT*

Flow 4>	# Flow Rng 1>	Enter 100% primary range in selected units
	Flow Unit 2>	Enter '1' ONE place only Ltr 1> Litres m^3 2> Cubic meters IGal 3> Imperial gal UGal 4> US gallons ft^3 5> Cubic feet

Main Menu	Submenus	Description
Flow 4>	Flow Mult 3>	Enter '1' ONE place only m 1> Thousandths c 2> Hundredths 3> Unity h 4> Hundreds k 5> Thousands M 6> Millions
	Flow Time 4>	Enter '1' ONE place only s 1> Seconds Min 2> Minutes Hr 3> Hours Dy 4> Days Wk 5> Weeks
	Flow Rspns 5>	Nominal time constant for output in seconds. Enter display setting value. Display Seconds Setting
		0 0.6 1 1 2 2 3 3 4 4 5 8 6 15 7 30 8 60 9 120
	Flow Probe 6> #	Ins 1> Insertion factor # Prof 2> Profile correction factor
	Flow % 7>	Present flow as % of primary range.
	** Flow Cutoff 8>	Minimum flow velocity in mm/sec, below which all outputs set to zero.

ANALOG OUTPUT*

Anlg 5>	Anlg Fsd 1>	Enter 0 to 21. Output current in mA for 100% flow
	Anlg Zero 2>	Enter 0 to 21. Output current in mA for 0% flow
	Anlg Dir 3>	Enter '1' to select Select both parameters for bidirectional flow Fwd 1> Current responds to forward flow Rev 2> Current responds to reverse flow
	Anlg No2 4>	Secondary range as % of primary range
	Anlg mA 5>	Present output current, mA
	Anlg HART**	HART Variant only, see full manual

Main Menu	Submenus	Description
PULSE OUTPUT*		
Pls 6>	# Pls Fact 1>	Enter output pulses per flow volume unit
	Pls Cutoff 2>	Flow rate in % of primary range, below which pulse output and totalizer stop
	Pls Max 3>	Maximum output freq. in Hz
	Pls Hz 4>	Frequency in Hz
	** Pls Idle 5>	Pulse output in idle (off)
	** Pls Size 6>	Enter pulse width in msec (will round up to nearest 10msec) 0 = square wave
TOTALIZER*		
Tot 7>	Tot Unit 1>	See Flow Unit 2> for parameters
	Tot Mult 2>	See Flow Mult 3> for parameters
	Tot ClrEn 3>	Enables totalizer reset function from terminal, transmitter display or input contact
ALARMS*		
Alm 8>	Alm No1 1>	Any combination of alarms 1 = Select 0 = Deselect Idle 1> Idle state En 2> 0 = Disabled 1 = Enabled Fault 3> Measurement fault Fwd 4> Forward flow Rev 5> Reverse flow Cutoff 6> Pulse output cutoff Mtsnsr 7> Empty sensor Hi 8> High flow Lo 9> Low flow Anlg A> Analog output overrange Pls B> Pulse output overrange
	Alm No2 2>	Same parameters as No.1 Factory default – Rev flow enabled, required for dual current option
	Alm Trip 3>	Hi 1> High flow trip-point, % range Lo 2> Low flow trip-point % range Hyst 3> Hysteresis Disp 4> Enables display of Hi and Lo Alarms

Main Menu	Submenus	Description
INPUT CONTACT*		
Input 9>	Input Analg 1>	Enter '1' to select. Active level selects second analog range
	Input Clr 2>	Active level resets all totalizers
	Inpt Hld 3>	Active level holds flowmeter flow value
	Inpt Zero 4>	Active level selects downscale drive
	** Inpt Idle 5>	Enter inactive state of input contact 1 = Hi normal, 0 = Lo normal

EMPTY PIPE DETECTION**

Mtsnsr A>	Mtsnsr Trip 1>	Enter empty pipe detector trip threshold Note. Set to zero for a 'slurry' MagMaster
	Mtsnsr mV 2>	Measured indication used for empty pipe trip. When valve below 'trip' threshold then all outputs driven to zero

SENSOR DATA AND CALIBRATION**

Snsr B>	Snsr No 1>	Serial number of sensor
	Snsr Tag 2>	Tag number of sensor
	Snsr Size 3>	Calibrated bore (mm)
	Snsr Vel 4>	Present velocity in sensor
	Snsr Fact 5>	1>, 2>, 3>, 4> = calibration data. Same as on sensor data label

SYSTEM TEST**

Test C>	Test Mode 1>	If '1', transmitter is in test mode. Self-cancels after 30min. if no entry made
	# Test Flow 2>	Present flow rate. In test mode, any value may be entered manually
	Test % 3>	Flow rate in %‡
	Test Hz 4>	Output frequency in Hz‡
	Test mA 5>	Output current in mA‡
	Test Vel 6>	Flow velocity in sensor ‡
	Test Alm 7>	Current active alarms‡ Clr = none
	Test Txv 8>	Flow velocity, uncorrected for sensor calibration ‡ Calculated from Test Flow 2

*Requires Level 1 access

**Requires Level 2 access

The maximum no. must not exceed 21000. The value entered may display with a small error, e.g. 1.900 may display as 1.899. 1.900 is used in calculation

INTRODUCTION


The Magmaster™ provides high-precision electromagnetic flow metering for conductive fluids of $>5\mu\text{S/cm}$, in sizes of 2.5 to 2200mm (0.1 to 86 in.). It has state-of-the-art accuracy, repeatability and rangeability.

The MagMaster offers a choice of liners and electrodes, flange or wafer tubes, integral or remote electronics and an optional keypad display.

Standard outputs include fully-programmable analog output (0 to 21mA), dual pulse (forward and reverse), dual alarm (flow rate, fault conditions, etc) and a RS232 connection. Optional outputs include dual analog and RS422/423.

The MagMaster has been designed to eliminate traditional noisy signals in slurry applications. It has multiple self-monitoring and diagnostic functions, and a comprehensive test mode to test the system without interrupting the process or power.

SIMPLE READ AND RESET



- Top line of display indicates flow totals, velocity, % of range and alarm status. Second line shows flow rate.

- Applying wand to the left icon steps the top line display through this sequence:


- > Forward flow total
- < Reverse flow total
- * Net flow total
- Alm Alarms in sequence ('Alm Clr' when no alarms are activated)
- Vel Flow velocity
- % Flow rate as % of full scale range

- Applying wand to right icon resets the flow total displayed on the top line if parameter 73 (Tot Clr En) is enabled

- For keypad/display version, see separate Quick Reference Guide.


CONFIGURATION

- Set up serial communications* on terminal or PC
- For PC use a laplink/null modem cable. A cable is available from ABB.
- Connect terminal cable to transmitter's D-connector as shown
- Press RETURN or equivalent (ENTER, EXE, etc).



*Serial communications setup	
Baud rate	4800
Data bits	8
Stop bits	1
Parity	None
Handshake	None

RELATIONSHIP OF MENUS



SECURITY ACCESS

Any of three security levels can be selected. In Levels 0 and 1, the operator is restricted to certain menus as listed below. In Level 2, the operator has full access to all menus and can change passwords.

- 1> Read flow parameters, etc.
 - 2> Set display options
 - 3> Security access, passwords
- Level 0
- 4> Set flow parameters
 - 5> Analog output
 - 6> Pulse output
 - 7> Set totalizer parameters
 - 8> Alarm operation
 - 9> Input contact
- Level 1
- A> Empty pipe detection
 - B> Sensor data and calibration
 - C> Test operation
- Level 2

Quick Reference Programming Guide



IM/MM/QRG2 Issue 5

The Company's policy is one of continuous product improvement and the right is reserved to modify the information contained herein without notice.

© 2004 ABB Printed in UK (12.04)

ABB has Sales & Customer Support expertise in over 100 countries worldwide
www.abb.com

ABB

ABB Limited
Oldends Lane, Stonehouse,
Gloucestershire
GL10 3TA
UK
Tel: +44 (0) 1453 826661
Fax: +44 (0) 1453 829671

ABB Inc.
125 E. County Line Road
Warminster
PA 18974
USA
Tel: +1 215 674 6000
Fax: +1 215 674 7183

MagMaster™
Electromagnetic Flowmeters

ABB