

2101562-001 rev. AB

Totalflow[®]

ABB Multivariable (XMV) with Totalflow XSeries Equipment

User's Manual



TOTALFLOW
MEASUREMENT & CONTROL SYSTEMS

ABB

Intellectual Property & Copyright Notice

©2009 by ABB Inc., Totalflow ("Owner"), Bartlesville, Oklahoma 74006, U.S.A. All rights reserved.

Any and all derivatives of, including translations thereof, shall remain the sole property of the Owner, regardless of any circumstances.

The original US English version of this manual shall be deemed the only valid version. Translated versions, in any other language, shall be maintained as accurately as possible. Should any discrepancies exist, the US English version will be considered final.

Notice: This publication is for information only. The contents are subject to change without notice and should not be construed as a commitment, representation, warranty, or guarantee of any method, product, or device by Owner.

Inquiries regarding this manual should be addressed to ABB Inc., Totalflow Products, Technical Communications, 7051 Industrial Blvd., Bartlesville, Oklahoma 74006, U.S.A.

TABLE OF CONTENTS

INTRODUCTION	IV
Organization & Style.....	iv
Chapter Descriptions.....	iv
Getting Help	iv
Before Calling.....	iv
Key Symbols	iv
Safety Practices and Precautions	v
Safety Guidelines	v
Safety First	v
Equipment Markings.....	vi
Grounding the Product	vi
Operating Voltage.....	vi
Danger From Loss of Ground.....	vi
Safe Equipment.....	vi
1.0 MECHANICAL INSTALLATION.....	1-1
1.1 Unpacking and Inspection	1-1
1.1.1 Unpacking.....	1-1
1.1.2 Inspection	1-1
1.1.3 Damaged Components.....	1-1
1.2 Pipe Mount Installation	1-1
1.2.1 Flange Type Manifold Assembly	1-1
1.2.2 Non - Flange Type Manifold Assembly	1-3
1.3 Direct Mount Installation	1-3
1.3.1 Step-by-Step Instructions	1-4
2.0 XMV SETUP	2-1
2.1 Overview.....	2-1
2.2 XMV Setup	2-1
2.3 XMV Setup With Display and Keys	2-1
2.4 XMV Setup Without Display and Keys	2-2
2.5 Adding a Display and Keys to an XMV.....	2-4
2.5.1 Adjusting the XMV Static Pressure Response Time	2-4
3.0 XSERIES SETUP TO SUPPORT THE ABB XMV.....	3-1
3.1 XSeries Configuration Files.....	3-1
3.2 XMV Support Applications.....	3-1
3.3 XMV Interface.....	3-2
3.4 XMV Communications Port Setup	3-3
3.5 Assigning XMVs to Measurement Tubes	3-9
3.6 Displays for XMV	3-10
4.0 XSERIES TO ABB XMV WIRING AND INTERCONNECT.....	4-1
4.1 Summary	4-3

TABLE OF FIGURES

Figure 1–1 Pipe Mount Assembly – Flange Manifold	1–2
Figure 1–2 Pipe Mount Assembly – Flange Manifold	1–2
Figure 1–3 Pipe Mount Assembly – Non Flange Manifold.....	1–3
Figure 1–4 Side Assembly Direct Mount.....	1–4
Figure 2–1 Push Button Key Menu	2–1
Figure 2–2 TFModbus.....	2–3
Figure 2–3 Device Address Screen	2–3
Figure 2–4 TFModbus Device Communication.....	2–3
Figure 3–1 PCCU Application Screen.....	3–2
Figure 3–2 PCCU XMV Setup	3–2
Figure 3–3 PCCU XMV1 Setup	3–3
Figure 3–5 XMV MRB Registers, Address 1.....	3–4
Figure 3–6 XMV MRB Registers, Address 2.....	3–4
Figure 3–7 XMV MRB Registers, Address 3.....	3–5
Figure 3–8 XMV MRB Registers, Address 4.....	3–5
Figure 3–9 XMV MRB Registers, Address 5.....	3–5
Figure 3–10 XMV MRB Registers, Address 6.....	3–6
Figure 3–12 Save and Restore Utility	3–7
Figure 3–14 Modbus Host Request Block Editor	3–8
Figure 3–15 MRB Entry Screen	3–9
Figure 3–16 XMV Values Screen (APP/ARRAY/REG).....	3–9
Figure 3–17 PCCU Menu Bar (Calibrate)	3–10
Figure 3–18 PCCU32 Calibrate Measurement Tubes	3–10
Figure 4–1 Wiring and Interconnect XMV to XSeries, Pg. 1	4–1
Figure 4–2 Wiring and Interconnect XMV to XSeries, Pg. 2.....	4–2
Figure 4–3 Back View of the XMV	4–3

LIST OF TABLES

Table 2—1 XMV Menu Tree 2-2
Table 2—2 XMV Display & Keys Parts List..... 2-4
Table 3—1 Standard Configuration Files 3-1

INTRODUCTION

This manual is written to provide an experienced meter technician with the requirements necessary to install, setup and operate a ABB Multivariable.

Organization & Style

Each of the chapters in this manual presents information in an organized and concise manner. Readers are able to look at the headings and get a broad picture of the content without reading every word. Also, there are overviews at the beginning of each chapter that provides the user with an idea of what is in the chapter and how it fits into the overall manual.

Chapter Descriptions

The following are the chapter descriptions for the manual.

Chapter	Name	Description
1	Mechanical Installation	Provides a description of the mechanical installation of the XMV.
2	XMV Setup	Provides a description of the Totalflow XMV system components and specifications.
3	PCCU Setup	Provides information on the setup of PCCU, in relation to the XMV.
4	Wiring	Provides instructions on the wiring and interconnect of the ABB XMV.

Getting Help

Totalflow takes pride in the on going support provided to customers. When purchasing a product, the user receives documentation which should answer their questions; however, Totalflow technical support provides an 800 number as an added source of information.

If requiring assistance, call:

USA: (800) 442-3097



International: 001-918-338-4888

Before Calling

- Know the Totalflow model and serial number. Serial numbers can be found on a plate located on each unit.
- Be prepared to give the customer service representative a detailed description of the problem.
- Note any alarms or messages as they appear.
- Prepare a written description of the problem.
- Know the software version, board and optional part numbers.

Key Symbols

The following symbols are used frequently in the manual. These are intended to draw attention to important information.

- FYI**  Intended to draw attention to useful information or to clarify a statement made earlier.
- TIP**  Intended to draw attention to a fact that may be useful or helpful in understanding a concept.



Intended to draw attention to a statement that might keep the user from making a mistake, keep the user from destroying equipment or parts or keep the user from creating a situation that could cause personal injury, if caution is not used. Please refer to the “Safety Practices and Precaution” section for additional information.



Intended to draw attention to a statement regarding the likelihood of personal injury or fatality that could result from improper access or techniques used while working in hazardous locations. Please refer to the “Safety Practices and Precaution” section for additional information.

Safety Practices and Precautions

This manual contains information and warnings which have to be followed by the user to ensure safe operation and to retain the product in a safe condition. Installation, maintenance and repairs should only be performed by a trained and qualified technician. Please refer to certification drawings, shipped with this unit, for specific guidelines. Extra copies of the certification drawings, referenced on the unit name tag, can be obtained, free of charge, by contracting Totalflow technical support at the number listed in the “Getting Help” section.

Safety Guidelines

- DO NOT open the equipment to perform any adjustments, measurements, maintenance, parts replacement or repairs until all external power supplies have been disconnected.
- Only a properly trained technician should work on any equipment with power still applied.
- When opening covers or removing parts, exercise extreme care. Live parts or connections can be exposed.
- Installation and maintenance must be performed by person(s) qualified for the type and area of installation, according to national and local codes.
- Capacitors in the equipment can still be charged, even after the unit has been disconnected from all power supplies.

Safety First

Various statements in this manual, identified as conditions or practices that could result in equipment damage, personal injury or loss of life, will be highlighted using the following icons.



Exercise caution while performing this task. Carelessness could result in damage to the equipment, other property and personal injury.



STOP. Do not proceed without first verifying that a hazardous condition does not exist. This task may not be undertaken until proper protection has been adopted, or the hazardous condition has been removed. Personal injury or fatality could result. Examples of these warnings include:

- Removal of enclosure cover(s) in a hazardous location must follow guidelines stipulated in the certification drawings shipped with this unit.
- If unit is installed or to be installed in a hazardous location, technician must follow the guidelines stipulated in the certification drawings shipped with this unit.
- Access to the unit via PCCU cable in a hazardous location must follow guidelines stipulated in the certification drawings shipped with this unit.
- Connecting or disconnecting equipment in a hazardous location for installation or maintenance of electric components must follow guidelines stipulated in the certification drawings shipped with this unit.

WARNING indicates a personal injury hazard immediately accessible as one reads the markings.

CAUTION indicates a personal injury hazard not immediately accessible as one reads the markings or a hazard to property, including the equipment itself.

Equipment Markings



Protective ground (earth) terminal.

Grounding the Product

If a grounding conductor is required, it should be connected to the grounding terminal before any other connections are made.

Operating Voltage

Before switching on the power, check that the operating voltage listed on the equipment agrees with the power being connected to the equipment.

Danger From Loss of Ground

A grounding conductor may or may not be required, depending on the hazardous classification. If required, any interruption of the grounding conductor inside or outside the equipment or loose connection of the grounding conductor can result in a dangerous unit. Intentional interruption of the grounding conductor is not permitted.

Safe Equipment

If it is determined that the equipment cannot be operated safely, it should be taken out of operation and secured against unintentional usage.

1.0 MECHANICAL INSTALLATION

This chapter provides the user with the information for the installation and setup of the Totalflow XMV. By the time this chapter is concluded, the XMV should be unpacked, installed and ready for operation.

FYI



Read through this chapter before beginning the installation.

1.1 Unpacking and Inspection

1.1.1 Unpacking

The XMV is shipped in a specially designed shipping carton which contains the unit, parts list and wiring and interconnect diagrams.

Carefully remove the items from each carton.

1.1.2 Inspection

- Inspect the shipping carton for damage. If the shipping carton is damaged, keep it until the contents have been inspected for damage.
- Inspect the unit's exterior for dents, chipped paint, etc.
- Inspect the LCD window for breakage.
- Open the housing by first removing the bolt and releasing the latch/latches.
- Visually inspect the electronics and XMV unit for damage.

1.1.3 Damaged Components

If any components have been damaged or if there are noticeable defects, notify the Totalflow representative. Keep all shipping materials for the carrier's inspection. Totalflow will arrange for immediate repair or replacement.

1.2 Pipe Mount Installation

If the user is installing directly to the mounting pipe, the following procedure should be used. Before beginning, review the procedure and the materials required for installation.

There are different methods of installing the XMV mounting bracket. The following will cover the more popular methods.

1.2.1 Flange Type Manifold Assembly

1.2.1.1 Materials Supplied

- Two U-bolts plus fastening hardware
- XMV mounting bracket

1.2.1.2 Step-by-Step Instructions

- 1) Ascertain where the XMV is to be placed on the mounting pipe.
- 2) Once decided, secure the bracket to the mounting pipe with two U-bolts, flat washers, split washers and bolts (see).
- 3) Once the bracket is attached to the pipe, attach the XMV to the underside of the bracket, using four bolts (see Figure 1–2).




Figure 1-1 Pipe Mount Assembly – Flange Manifold




Figure 1-2 Pipe Mount Assembly – Flange Manifold

1.2.2 Non - Flange Type Manifold Assembly

1.2.2.1 Materials Supplied

- Two U-bolts plus fastening hardware
- XMV mounting bracket

1.2.2.2 Step-by-Step Instructions

- 1) Ascertain where the XMV is to be placed on the mounting pipe.
- 2) Once decided, attach the bracket to the mounting pipe with two U-bolts, washers, split washers and bolts (see Figure 1–3).
- 3) Next, attach the XMV unit to the top of the bracket with four screws.




Figure 1–3 Pipe Mount Assembly – Non Flange Manifold

1.3 Direct Mount Installation

If the user is installing directly to the meter run, the following procedure should be used. Before beginning, review the procedure and the materials required for installation.

When ordering, the user can choose from either a side assembly or top assembly. For the purposes of this manual, the following will detail a side assembly.

1.3.1 Step-by-Step Instructions

- 1) Attach the XMV to the manifold and align bolt holes (see Figure 1–4).
- 2) Using the supplied bolts, bolt the manifold securely to the XMV.
- 3) Next, using the supplied bolts, secure the manifold assembly to the meter run.




Figure 1–4 Side Assembly Direct Mount

2.0 XMV SETUP

2.1 Overview

This document describes the setup of an ABB Multivariable transmitter (XMV).

2.2 XMV Setup

The XMV measures static pressure, differential pressure and process temperature in a gas, vapor or liquid media. The XMV is a 2-wire, RS-485 Modbus device with two additional wires required for power. It has a permissible terminal voltage range of 10.5 – 30 VDC. The current draw is 10 mA per XMV. The unit must be set up to operate with the XFC or XRC flow computers.

2.3 XMV Setup With Display and Keys

An optional Push Button Key Unit is located at the top of the XMV (see Figure 2–1). It is used to setup the configuration parameters in the XMV. To make the keys accessible, release the screw and flip the protective cap aside. Pushing the key down with an instrument screwdriver activates the key. See the menu tree below in Table 2—1.

With the mode key “M”, the user can start the menu-controlled programming. To call the next menu item, press the “+” key. To call the previous menu item, press the “-” key. Sub-menu items / selection list are activated via the mode “M” key. A numerical value can be changed using the “+” key to increment the value by 1 and the “-” key to move the cursor to the left. The mode “M” key is used to accept the changes. When setup is finished, go to the menu “Exit” screen, and press the mode “M” key.




Figure 2–1 Push Button Key Menu

Table 2—1 XMV Menu Tree

Enter Program Menu with Mode Key 'M'	
Description	Typical Setting
Exit	N/A
View	Any (Not Used)
Shift Zero	None (Not Used)
Damping	0.125 Seconds
Device Mode	Operate
Baud Rate	9600
Bus Address	1 (Set 1–8 as required)
Resp-Delay	20 Ms
Display	User Text*
Exit	N/A

FYI



Upon exit from the XMV setup mode, the display will show SP, DP or temperature from the XSeries, if communications are operational OR the message, "User-Text", will appear. This indicates the XMV is waiting on the XSeries to write the display data.

2.4 XMV Setup Without Display and Keys

An XMV without a display and keys may be setup using a PC, running PCCU software with a RS-485 communication link to the XMV. Use a RS-232 to RS-485 converter assembly (2100241-002) and adapter cable (2100248-001) to make this connection. On the adapter cable, the "Bus –" (black alligator clip) connects to XMV "Com –" terminal. "Bus +" (red alligator clip) connects to XMV "Com +" terminal. The XMV must be powered up from an external power source, during this setup sequence.

- 1) Open the "TFModbus" utility in PCCU (see Figure 2–2).
- 2) Open "XmvSetup.ini".
- 3) The INI program will cycle through the Modbus addresses and baud rates until it communicates with the XMV (see Figure 2–3). The address search will stop when the XMV responds. The current Modbus address and baud rate of the XMV are displayed in the address search box.
- 4) Please note the device address of the XMV, then click the OK button.
- 5) If the address is correct and the response delay is 20 ms, no further action is needed for setup on this device. Skip to Step 8.
- 6) If the address is correct, but the response delay is not 20 ms, select a different address tab and then reselect the original address tab so the response delay parameter will be updated to 20 ms in the XMVsetup.ini. Skip to step 8; otherwise, continue to step 7.
- 7) If a different address is required, select the Tab with the required address. The Xmvsetup.ini will re-address the XMV to the address specified and set the response delay to 20 ms. The process data will be read and displayed from the XMV, using the new address and setup parameters.

- 8) Power must be maintained for 60 seconds after selecting the new address tab for data to be saved in the XMV.
- 9) For setting up multiple XMVs, the user will need to connect directly with each device and follow steps 1 through 8.




Figure 2–2 TFMdbus




Figure 2–3 Device Address Screen

Figure 2–4 TFMdbus Device Communication

2.5 Adding a Display and Keys to an XMV

A display and keys may be added permanently to an XMV. They can also be added temporarily under power for XMV setup. The required parts are listed in Table 2—2.

Table 2—2 XMV Display & Keys Parts List

Item	Part Number	Description
1	1801000-001	LCD Display
2	1801001-001	Mounting Screws for Display (2) required
3	1801002-001	LCD Glass Cover
4	1801003-001	Keys for programming

If adding keys to an XMV that was shipped without keys, a 3/32-inch hex wrench (not shipped with transmitter) is needed to remove the blank cover. Additionally, a #10 torque driver is needed to secure the keys properly to the transmitter base.

The 2.5 mm and 3 mm hex wrenches shipped with the XMV are used for the “head lock and cover lock.

2.5.1 Adjusting the XMV Static Pressure Response Time

The standard response time for the XMV to fully reach the applied static pressure is four seconds. Refer to Totalflow Technical Bulletin #113, if the XMV Static Pressure response time needs to be adjusted.

3.0 XSERIES SETUP TO SUPPORT THE ABB XMV

3.1 XSeries Configuration Files

Totalflow has standard configuration files (see Table 3–1) that have all the setup parameters and support files for use with the XMV. Totalflow recommends using these released files, when possible.

A few of the standard configuration files for use with the XSeries and XMVs are shown below. Contact Totalflow for other available configurations.

Table 3—1 Standard Configuration Files

Part Number	Description
2100961-xxx	XFC with AGA3 support for 1-3 ABB XMVs
2100922-xxx	XRC with AGA3 support for 1 ABB XMV
2100962-xxx	XRC with AGA3 support for 1-4 ABB XMVs
2101469-xxx	XRC with AGA3 support for 1-6 ABB XMVs with Station totals for pod applications

- 1) All standard XMV configuration files are built to support the XMV with display. If the display is not used, the user should delete the MVxxTXT.mrb files in the Modbus folder under the XMV communications port.
- 2) If one of the multi-tube XMV configurations are used, the actual number of XMVs must be entered within PCCU under the Communication Setup tab. The user should un-instantiate any unused measurement tubes by setting the application to 'spare' within the Applications tab. The user should also delete the associated display group in "Save and Restore" in the tfData/Display folder to customize the configuration files for a specific configuration.

3.2 XMV Support Applications

To support an XMV with an XSeries flow computer, the following applications are required (see Figure 3–1):

- 1) XMV Interface Application—typically instantiated at app# 8.
- 2) Communications Application—typically COM 2 instantiated at app# 3.
- 3) Measurement Tube Application—typically instantiated at app# 11-18 as required.
- 4) Display Application—typically instantiated at app# 23 with a display group for each measurement tube.




Figure 3-1 PCCU Application Screen

3.3 XMV Interface

- 1) Enter the number of XMVs in the system within PCCU under the Communication Setup tab, as shown in Figure 3-2.
- 2) Enter the XMV setup parameters within PCCU under the XMV# Setup tab, as shown in Figure 3-3.




Figure 3-2 PCCU XMV Setup




Figure 3–3 PCCU XMV1 Setup

3.4 XMV Communications Port Setup

- 1) Setup the Communication Port parameters (see Figure 3–4) in PCCU under Communications in the tree-view.




Figure 3–4 Setup Parameters

- 2) Setup the Communication Port MRB(s) (Modbus Request Block).

In step 1, a “Modbus” folder was created for the communications port. There are two supported types of MRBs. The user needs to determine which method is desired and create the required Modbus Request Block(s).

Legacy Method

- The Legacy method uses two Modbus blocks per XMV and is supported by all versions of the XSeries Flash software. There are two Modbus Request Blocks (MRB) that need to be created and stored in the Modbus folder for each XMV installed (See Figure 3–5 through Figure 3–10, as needed).
 - Mv1.MRB (block one) is required for reading registers from the XMV and storing the raw values into the XMV application.
 - Mv1Txt.MRB (block two) writes the SP, DP & temperature data to the XMV display.

The image shows two side-by-side configuration windows for Modbus Request Blocks (MRB).

Mv1.MRB Configuration:

- Modbus Function: 4 - Read Input Registers
- Slave Address: 1
- Starting Register: 21
- # Registers: 3
- Register Type: Float
- Trigger Type: Trigger
- Trigger Register: 8.13.0
- Response Status Register: 8.0.1
- Destination Table:

Register	Value
1	8.3.0
2	8.3.1
3	8.3.2

Mv1Txt.MRB Configuration:

- Modbus Function: 16 - Write Multiple Registers
- Slave Address: 1
- Starting Register: 1001
- # Registers: 7
- Register Type: Int16
- Trigger Type: Trigger
- Trigger Register: 8.9.0
- Response Status Register: 0.0.0
- Source Table:

Register	Value
1	8.2.0
2	8.2.1
3	8.2.2
4	8.2.3
5	8.2.4
6	8.2.5
7	8.2.6

Figure 3–5 XMV MRB Registers, Address 1

The image shows two side-by-side configuration windows for Modbus Request Blocks (MRB).

Mv2.MRB Configuration:

- Modbus Function: 4 - Read Input Registers
- Slave Address: 2
- Starting Register: 21
- # Registers: 3
- Register Type: Float
- Trigger Type: Trigger
- Trigger Register: 8.13.1
- Response Status Register: 8.0.2
- Destination Table:

Register	Value
1	8.3.3
2	8.3.4
3	8.3.5

Mv2Txt.MRB Configuration:

- Modbus Function: 16 - Write Multiple Registers
- Slave Address: 2
- Starting Register: 1001
- # Registers: 7
- Register Type: Int16
- Trigger Type: Trigger
- Trigger Register: 8.9.1
- Response Status Register: 0.0.0
- Source Table:

Register	Value
1	8.2.7
2	8.2.8
3	8.2.9
4	8.2.10
5	8.2.11
6	8.2.12
7	8.2.13

Figure 3–6 XMV MRB Registers, Address 2




Figure 3–7 XMV MRB Registers, Address 3




Figure 3–8 XMV MRB Registers, Address 4




Figure 3–9 XMV MRB Registers, Address 5




Figure 3–10 XMV MRB Registers, Address 6

- Interface Controlled Method

The Interface Controlled method uses one Modbus block and is supported by all XSeries Flash software released after 4/21/2004 (XFC flash 2101050-011 and XRC flash 2101052-009 and later). Regardless of the number of XMVs used, this method requires one Modbus block (see Figure 3–11).




Figure 3–11 XMV Interface Control Block

- 3) Once the method is determined, the required block(s) must be created.

FYI



Instructions shown are for using PCCU 4.53 or later. If using PCCU4.52 or earlier, the blocks must be created and saved to the users PC hard drive and then downloaded, using the “Save and Restore” utility, to the Modbus folder under the XMV Com Port.

- 4) Go to “File Utilities” and then “Save and Restore” in the Operate menu (see).




Figure 3–12 Save and Restore Utility

- 5) Under “tfData: drive” in the tree-view, select the XMV Com Port (see Figure 3–13).




Figure 3–13 Save and Restore Tree-View

- 6) Return to “File Utilities” in the Operate menu, and select “Modbus Host Request Block Editor” (see).






Figure 3–14 Modbus Host Request Block Editor

- 7) Create the required MRBs, using Figure 3–5 through Figure 3–10.
- 8) When finished with each MRB, press the Send button (see Figure 3–15) to load the MRB into the tfData: drive.

FYI  If modifying an existing block, to create a new block, the user will need to use the “File/Send As” feature to rename and save the block to the Modbus folder.

FYI  Refer to Totalflow Technical Bulletin No. 118 or the PCCU help files for more details on creating and using Modbus blocks.




Figure 3–15 MRB Entry Screen

3.5 Assigning XMVs to Measurement Tubes

The data inputs from the XMVs can be assigned to any measurement tube.

- 1) To assign the input, the user must note the App/Array/Register for the scaled values for each XMV (see Figure 3–16).
- 2) Next, click the Calibration icon(see Figure 3–17).
- 3) Select the measurement tube to be configured from the tree-view (see Figure 3–18).
- 4) Select the Setup tab.
- 5) Enter the appropriate App/Array/Register for static pressure, differential pressure and temperature on the Values tab.




Figure 3–16 XMV Values Screen (APP/ARRAY/REG)



Figure 3–17 PCCU Menu Bar (Calibrate)




Figure 3–18 PCCU32 Calibrate Measurement Tubes

3.6 Displays for XMV

There are no actual displays in the XSeries for the XMV. Instead, the XMV is typically assigned to a measurement tube, and the measurement tube has an associated display group. If a measurement tube has been added, a display group for that tube needs to be added with the following procedure:

- 1) Move to the Save and Restore utility.
- 2) Go to the Display folder on tfData, and double-click on an existing display group for a measurement tube.
- 3) Modify the group name, display names and display registers for the new measurement tube.
- 4) Use the “File / Send As...” option to download the modified file with a new file name to the Display folder.
- 5) Go to “Entry “ mode and check displays.

4.0 XSERIES TO ABB XMV WIRING AND INTERCONNECT




Figure 4-1 Wiring and Interconnect XMV to XSeries, Pg. 1




Figure 4-2 Wiring and Interconnect XMV to XSeries, Pg. 2



Figure 4–3 Back View of the XMV

4.1 Summary

At this point, the XFC or XRC should be receiving data from the XMV. Data updates can be verified by viewing the data in the Values tab. The data should be reflecting process conditions and be updating every second.

Communication success can be monitored in “Entry / Communications / COMxx / Host Status”. The number of polls should be incrementing without any change in the number of errors. For easier viewing, all data fields on the Host Status tab can be reset to “0” by writing a “0” in the fields and clicking the Send button.

The measurement tube, using the XMV inputs, should now be calibrated.

FYI



Be sure and save the system configuration to the tfCold: drive, using the Save and Restore utility.

Blank Page



ABB Inc.

Totalflow Products

7051 Industrial Blvd.

Bartlesville, Oklahoma 74006

Tel: USA (800) 442-3097

International 001-918-338-4880

2101562-001 (AB)

