

6-Way Valve

Voltage values in the FCC/S

GPG BUILDING AUTOMATION

Doc.-Type: Function Description

Doc.-Nr. 9AKK107492A6742

Revision: A

Department: BA Engineering

Author: Engineering Team BA/DESTO

System: i-bus® KNX

Product: FCC/S 1.x.x.1

Page: 1/4

Date: 1 August 2019



Liability Disclaimer:

This document serves the sole purpose of providing additional, technical information and possible application and use cases for the contained products and solutions. It **does not** replace the necessary technical documentation required for planning, installation and commissioning of the product. Technical details are subject to change without notice.

Despite checking that the contents of this document are consistent with the current versions of the related hard and software of the products mentioned within, deviations cannot be completely excluded. We therefore assume no liability for correctness. Necessary corrections will be introduced as and when new versions of the document are generated.

Introduction

This document provides a brief introduction to the 6-way valve, including its functions and how to connect it to the FSS/S using parametrization.

It also explains how to send the valve's technical data to the FCC/S parameters in ETS.

Objectives of the document


- Provide an introduction to the 6-way valve
- Provide an example of technical data transfer

Content

1. Basic information

The 6-way valve has six separate pipe connections. When installing the valve, it's essential to note the flow direction. As a rule, this is marked with arrows on the corresponding valve.

Heating circuit connection



Cooling circuit connection




Fig. 1 Heating and cooling circuit connections

The 6-way valve is specially designed for use in heating/cooling ceilings, and also very compact. It operates up to four straightway valves using just one 0–10 V connection. Its advantages in these types of applications are easier troubleshooting and less cabling work.

2. FCC/S connection and settings

The 6-way valve connects to the 0–10 V interface on the FCC/S (Channel A). The valve also requires an auxiliary voltage.

You can enable the 6-way valve via application parameters straight from the application, where all the additional settings options will then be shown.




Fig. 2 FCC/S ETS parameters

Example of voltage settings for the 6-way valve based on a 6-way ball valve. You will find this type of curve in the valve manufacturer's technical data.




Fig. 3 Valve voltage values

max. valve position, cooling at 2 V
max. valve position, cooling at 4.7 V

max. valve position, heating at 10 V
max. valve position, heating at 7.3 V

Closed
4.7 V–7.3 V

Check and adjust the voltage values based on the valve manufacturer!

The voltage curve provides the settings values for entry in the FCC/S parameters.

You need to enter the voltage values for both minimum and maximum heating/cooling so that the valve can be actuated coherently.

The opening/closing time of the drive provides the specific information that ensures the valve purge works properly.

Valve output	Activated	
Voltage range for cooling		
Voltage for maximum cooling	2	V
Voltage for minimum cooling/ cooling valve closed	4.7	V
Voltage range for heating		
Voltage for minimum heating/ heating valve closed	7.3	V
Voltage for maximum heating	10	V
Valve drive opening/closing time	180	s

Fig. 4 FCC/S ETS parameters

The entered voltage values are then used to calculate and set the actual control values for the 6-way valve.

References to other documents

- [FAQ Home and Building Automation](#)
- [FAQ 6-way valve and FCC/S](#)
- [Engineering Guide Database](#)

Summary

The 6-way valve is a highly compact solution that makes it easy to control heating/cooling ceilings. Certain specifications are required (voltage curve adjustment) in order to actuate the valve. The FCC/S supports these automatically.