

ACSM1

Application Guide Fieldbus Control with FPBA-01 PROFIBUS DP Adapter Module and ABB AC500 PLC



ACSM1 Drive Manuals

DRIVE HARDWARE MANUAL*

ACSM1-04 Drive Modules (0.75 to 45 kW) Hardware Manual – 3AFE68797543 (English)

ACSM1-04 Drive Modules (55 to 110 kW) Hardware Manual – 3AFE68912130 (English)

ACSM1-04Lx Liquid-cooled Drive Modules (55 to 160 kW) Hardware Manual – 3AUA0000022083 (English)

DRIVE FIRMWARE MANUALS

ACSM1 Speed and Torque Control Program Firmware Manual – 3AFE68848261 (English)

For drives of type ACSM1-04xS...

ACSM1 Motion Control Program Firmware Manual – 3AFE68848270 (English)

For drives of type ACSM1-04xM...

DRIVE PC TOOLS MANUALS

DriveStudio User Manual – 3AFE68749026 (English)

DriveSPC User Manual – 3AFE68836590 (English)

APPLICATION GUIDES

Safe Torque Off Function for ACSM1, ACS850 and ACQ810 Drives Application Guide – 3AFE68929814 (English)

System Engineering Manual – 3AFE68978297 (English)

ACSM1 Fieldbus Control with FPBA-01 PROFIBUS DP Adapter Module and ABB AC500 PLC; Application Guide – 3AUA0000049359 (English)

OPTION MANUALS

FIO-01 Digital I/O Extension User's Manual* – 3AFE68784921 (English)

FIO-11 Analog I/O Extension User's Manual* – 3AFE68784930 (English)

FEN-01 TTL Encoder Interface User's Manual* – 3AFE68784603 (English)

FEN-11 Absolute Encoder Interface User's Manual* – 3AFE68784841 (English)

FEN-21 Resolver Interface User's Manual* – 3AFE68784859 (English)

FEN-31 HTL Encoder Interface User's Manual* – 3AUA0000031044 (English)

ACSM1 Control Panel User's Guide – 3AUA0000020131 (English)

*A multilingual quick installation guide is included with the delivery.

AC500 manuals can be found in the CoDeSys online help. Press F1 in the CoDeSys software.

Fieldbus Control with FPBA-01 PROFIBUS DP Adapter Module and ABB AC500 PLC

Application Guide

3AUA0000049359 Rev C
EN
EFFECTIVE: 2010-05-03

Table of contents

Table of contents

Introduction to the manual

Applicability	9
Purpose of the manual	10
Contents of the manual	10
Related manuals	10
Terms and abbreviations	11
Standards	11

Fieldbus control description

What this chapter contains	13
System overview	13
Setting up communication through a fieldbus adapter module	14
Drive control parameters	15
The fieldbus control interface	16
The Control Word and the Status Word	17
Actual values	17
FBA communication profile	17
Fieldbus references	17
State diagram	19

Starting up the FPBA-01 adapter for different communication profiles

Overview	21
Mechanical and electrical installation	21
Drive configuration	21
Cyclic data handling	21
Parameter setting examples	22
PROFIdrive communication profile (Speed Control Mode) with PPO Type 1	23
ABB DRIVES communication profile (Speed/Torque Control Mode) with PPO Type 4	24
PROFIdrive communication profile (Positioning Mode) with PPO Type 4	26

Starting up fieldbus communication and programming the ABB PLC (one-drive system)

What this chapter contains	29
Safety	29
Equipment and programs	30
Start-up flowchart	31
Connections	34
Installing the DriveStudio PC tool	35
Installing the AC500 Control Builder PS501 software	35

Installing the PS551-MC Motion Control Library	37
Installing additional GSD files and libraries	38
Setting the drive control program parameters	40
Setting up the communication	45
Create a new project	45
Configure communication with the SYCON fieldbus configurator	50
Programming the PLC main program	63
Load additional libraries for programming assistance	63
Add function block ACSM1_ACCESS_dc	66
Add function block MC_ReadStatus	72
Add function block MC_ReadActualPosition	72
Add function block MC_ReadAxisError	72
Add function block MC_Reset	73
Add function block MC_Power	73
The complete main program is shown here	74
Programming actions	77
How to create actions	77
Program velocity (MC_MoveVelocity)	80
Program stopping (MC_Stop)	81
Program positioning (MC_MoveAbsolute)	82
Program relative movement (MC_MoveRelative)	83
Program homing (MCA_Home)	84
Program toggling between two positions	84
Call the actions into the main program	87
Programming visualizations	89
Create an empty visualization field	90
Create buttons	91
How to create and configure a button	91
Create indicators	95
Create visualization elements	96
Running and testing the program	99
Load the program to the controller	99
Test the program	102

Starting up fieldbus communication and programming the ABB PLC (multi-axis systems)

What this chapter contains	105
Equipment and programs	105
Setting up the communication	105
Configure communication with the SYCON fieldbus configurator	106
Programming the PLC main program	116
Programming actions	120
Programming visualizations	123
Running and testing the program	124

Example program for a two-axis loading machine

Description of the machine	125
Diagram of the system	125

Description of the program	125
Loading sequence	125
Program	126

Appendix A - How to find out the serial communication parameter values of your PC?

What this chapter contains	129
How to find out the serial communication parameter values of your PC?	129

Further information

Product and service inquiries	133
Product training	133
Providing feedback on ABB Drives manuals	133
Document library on the Internet	133

Introduction to the manual

What this chapter contains

This chapter describes the target audience, purpose and contents of this manual.

Applicability

The manual is compatible with ACSM1-04 and ACSM1-04LC drive modules of frame sizes from A to E.

Safety instructions

Follow the safety instruction given in *ACSM1-04 Drive Modules (0.75 to 45 kW) Hardware Manual* (3AFE68797543 [English]). The main instructions are repeated below.



WARNING! Ignoring the following instructions can cause physical injury or death, or damage to the equipment.

- **Only qualified electricians are allowed to install and maintain the drive.**
- Never work on the drive, motor cable or motor when main power is applied. After disconnecting the input power, always wait for 5 min to let the intermediate circuit capacitors discharge before you start working on the drive, motor or motor cable.

Always ensure by measuring with a multimeter (impedance at least 1 Mohm) that:

1. voltage between drive input phases U1, V1 and W1 and the frame is close to 0 V.
 2. voltage between terminals UDC+ and UDC- and the frame is close to 0 V.
 3. voltage between terminals R+ and R- and the frame is close to 0 V.
- Do not work on the drive when the permanent magnet motor is rotating. Also, when the supply power is switched off and the inverter is stopped, a rotating permanent magnet motor feeds power to the intermediate circuit of the drive and the supply connections become live. See the hardware manual for precautions before installation and maintenance work on the drive.
 - Do not work on the control cables when power is applied to the drive or to the external control circuits. Externally supplied control circuits may cause dangerous voltages inside the drive even when the main power on the drive is switched off.
-

Target audience

This manual is intended for people who plan the drive application control, commission, use, and service the drive with fieldbus communication. Read the ACSM1 firmware and hardware manuals before working on the drive.

You are expected to know the fundamentals of electricity, wiring and electrical components as well as drive control methods, fieldbus communication concepts and function block programming.

Purpose of the manual

The purpose of this manual is to show how to configure fieldbus communication with the drive control program parameters and, as an example, to show how the drive can be controlled through fieldbus by using the ABB AC500 programmable logic controller with PS551 Control Builder.

Contents of the manual

The chapters of this manual are briefly described below.

[Introduction to the manual](#) introduces this manual.

[Fieldbus control description](#) describes how the drive can be controlled by external devices over a communication network.

[Starting up the FPBA-01 adapter for different communication profiles](#) presents the steps to take during the start-up of the FPBA-01 PROFIBUS DP Adapter Module with the drive.

[Starting up fieldbus communication and programming the ABB PLC \(one-drive system\)](#) presents the steps to take during the start-up of the drive fieldbus control with ABB AC500 PLC and PROFIBUS DP adapter module. A system with one drive is set up.

[Starting up fieldbus communication and programming the ABB PLC \(multi-axis systems\)](#) presents the additional steps compared to the ones in the previous chapter that you must take during the start-up of the drive fieldbus control with ABB AC500 PLC and PROFIBUS DP adapter module in a multi-axis system. A system with two drives is set up.

[Example program for a two-axis loading machine](#) presents an example sequence program which controls a loading machine with two axes.

[Appendix A - How to find out the serial communication parameter values of your PC?](#) instructs how to find out the serial communication parameter values of your PC.

Related manuals

- *ACSM1-04 Drive Modules Hardware Manual* (3AFE68797543 [English])
- *ACSM1-04LC Drive Modules Hardware Manual* (3AUA0000022083 [English])
- *ACSM1 Motion Control Program Firmware Manual* (3AFE68848270 [English])

- *ACSM1 Speed and Torque Control Program Firmware Manual (3AFE68848261 [English])*
- *PROFIBUS DP Adapter Module FPBA-01 User's Manual (3AFE68573271 [English])*
- *User Manual for PS551-MC (Motion Control library for ABB PLC AC500) according to Technical Specification PLCopen – Technical Committee 2 – Task Force; Function Blocks for motion control*
- *User Manual for PLC Programming with CoDeSys 2.3 by 3S – Smart Software Solutions GmbH*
- ABB AC500 scalable programmable logic controller manuals

Terms and abbreviations

Term/Abbreviation	Explanation
CM572	Profibus DP Master communication module for AC500
CM575	DeviceNet Master communication module for AC500
CM578	CANopen Master communication module for AC500
CPU	Central Processing Unit
FCAN-0x	Optional CANopen adapter
FDNA-0x	Optional DeviceNet adapter
FPBA-0x	Optional PROFIBUS DP adapter
Frame (size)	Size of the drive module.
GSD	Generic Station Description. A GSD file contains a description of the PROFIBUS DP/PA device and is provided by the device manufacturer. GSD files provide a way for an open configuration tool to automatically get the device characteristics.
PLCopen	Vendor- and product-independent worldwide association for resolving topics related to control programming to support the use of international standards in this field. For more information, see http://www.plcopen.org/
PLCopen Motion Control Function Blocks	Technical Committee 2 – Task Force Motion Control – of PLCopen defines libraries of Function Blocks, like the Motion Control Specification.
PROFIBUS DP	PROFIBUS version for Decentralized Periphery. PROFIBUS is an open serial communication standard that enables data exchange between all kinds of automation components.
PROFIBUS PA	PROFIBUS version for Process Automation.

Standards

IEC 61131-3:2003, Programmable controllers – Part 3: Programming languages.


Fieldbus control description

What this chapter contains

The chapter describes how the drive can be controlled by external devices over a communication network.

System overview

The drive can be connected to a fieldbus controller via a fieldbus adapter module. The adapter module is connected to drive Slot 3.



The drive can be set to receive all of its control information through the fieldbus interface, or the control can be distributed between the fieldbus interface and other available sources, for example digital and analogue inputs.

The drive can communicate with a fieldbus controller through a fieldbus adapter using one of the following serial communication protocols:

- PROFIBUS DP (FPBA-01 adapter)
- CANopen (FCAN-01 adapter)
- DeviceNet™ (FDNA-01 adapter).
- Modbus/RTU (FSCA-01 adapter) or Modbus/TCP (FENA-01 adapter)
- Ethernet/IP™ (FENA-01 adapter)
- EtherCAT (FECA-01 adapter)

Setting up communication through a fieldbus adapter module

Before configuring the drive for fieldbus control, the adapter module must be mechanically and electrically installed according to the instructions given in the User's Manual of the appropriate fieldbus adapter module.

The communication between the drive and the fieldbus adapter module is activated by setting parameter 50.01 FBA ENABLE to (1) ENABLE. The adapter-specific parameters must also be set. See the table below.

Parameter	Setting for fieldbus control	Function/Information
COMMUNICATION INITIALISATION AND SUPERVISION		
50.01 FBA ENABLE	(1) ENABLE	Initialises communication between drive and fieldbus adapter module.
50.02 COMM LOSS FUNC	(0) NO (1) FAULT (2) SPD REF SAFE (3) LAST SPEED	Selects how the drive reacts in a fieldbus communication break.
50.03 COMM LOSS T OUT	0.3...6553.5 s	Defines the time between communication break detection and the action selected with parameter 50.02 COMM LOSS FUNC.
50.04 FBA REF1 MODESEL and 50.05 FBA REF2 MODESEL	(0) RAW DATA (1) TORQUE (2) SPEED (3) POSITION * (4) VELOCITY * (5) AUTO	Defines the fieldbus reference scaling. When (0) RAW DATA is selected, see also parameters 50.06...50.11. * in Motion Control Program only
ADAPTER MODULE CONFIGURATION		
51.01 FBA TYPE	–	Displays the type of the fieldbus adapter module.
51.02 FBA PAR2 ... 51.26 FBA PAR26	These parameters are adapter module-specific. For more information, see the User's Manual of the fieldbus adapter module. Note that not all of these parameters are necessarily used.	
51.27 FBA PAR REFRESH	(0) DONE (1) REFRESH	Validates any changed adapter module configuration parameter settings.
51.28 PAR TABLE VER	–	Displays the parameter table revision of the fieldbus adapter module mapping file stored in the memory of the drive.
51.29 DRIVE TYPE CODE	–	Displays the drive type code of the fieldbus adapter module mapping file stored in the memory of the drive.
51.30 MAPPING FILE VER	–	Displays the fieldbus adapter module mapping file revision stored in the memory of the drive.
51.31 D2FBA COMM STA	–	Displays the status of the fieldbus adapter module communication.
51.32 FBA COMM SW VER	–	Displays the common program revision of the adapter module.
51.33 FBA APPL SW VER	–	Displays the application program revision of the adapter module.
Note: In the User's Manual of the fieldbus adapter module, the parameter group number is 1 or A for parameters 51.01...51.26.		

Parameter	Setting for fieldbus control	Function/Information
TRANSMITTED DATA SELECTION		
52.01 FBA DATA IN1 ... 52.12 FBA DATA IN12	0 4...6 14...16 101...9999	Defines the data transmitted from drive to fieldbus controller. Note: If the selected data is 32 bits long, two parameters are reserved for the transmission.
53.01 FBA DATA OUT1 ... 53.12 FBA DATA OUT12	0 1...3 11...13 1001...9999	Defines the data transmitted from fieldbus controller to drive. Note: If the selected data is 32 bits long, two parameters are reserved for the transmission.
Note: In the User's Manual of the fieldbus adapter module, the parameter group number is 3 or C for parameters 52.01...52.12 and 2 or B for parameters 53.01...53.12.		

After the module configuration parameters have been set, the drive control parameters (see section [Drive control parameters](#)) must be checked and adjusted when necessary.

The new settings will take effect when the drive is powered up the next time (before powering off the drive, wait at least 1 minute), or when parameter 51.27 FBA PAR REFRESH is activated.

Drive control parameters


The Setting for fieldbus control column gives the value to use when the fieldbus interface is the desired source or destination for that particular signal. The Function/Information column gives a description of the parameter.

Parameter	Setting for fieldbus control	Function/Information
CONTROL COMMAND SOURCE SELECTION		
10.01 EXT1 START FUNC	(3) FBA	Selects fieldbus as the source for the start and stop commands when EXT1 is selected as the active control location.
10.04 EXT2 START FUNC	(3) FBA	Selects fieldbus as the source for the start and stop commands when EXT2 is selected as the active control location.
24.01 SPEED REF1 SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as speed reference 1.
24.02 SPEED REF2 SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as speed reference 2.
32.01 TORQ REF1 SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used as torque reference 1.
32.02 TORQ REF ADD SEL	(3) FBA REF1 (4) FBA REF2	Fieldbus reference REF1 or REF2 is used for torque reference addition.
SYSTEM CONTROL INPUTS		
16.07 PARAM SAVE	(0) DONE (1) SAVE	Saves parameter value changes (including those made through fieldbus control) to permanent memory.

The fieldbus control interface

The cyclic communication between a fieldbus system and the drive consists of 16/32-bit input and output data words. The drive supports at the maximum the use of 12 data words (16-bit) in each direction.

Data transmitted from the drive to the fieldbus controller is defined by parameters 52.01...52.12 (FBA DATA IN) and data transmitted from the fieldbus controller to the drive is defined by parameters 53.01...53.12 (FBA DATA OUT).



- 1) See also other parameters which can be controlled by the fieldbus.
- 2) The maximum number of used data words is protocol-dependent.
- 3) Profile/instance selection parameters. Fieldbus module specific parameters. For more information, see the User's Manual of the appropriate fieldbus adapter module.
- 4) With DeviceNet the control part is transmitted directly.
- 5) With DeviceNet the actual value part is transmitted directly.

The Control Word and the Status Word

The Control Word (CW) is the principal means of controlling the drive from a fieldbus system. The Control Word is sent by the fieldbus controller to the drive. The drive switches between its states according to the bit-coded instructions of the Control Word.

The Status Word (SW) is a word containing status information, sent by the drive to the fieldbus controller.

Actual values

Actual values (ACT) are 16/32-bit words containing information on selected operations of the drive.

FBA communication profile

The FBA communication profile is a state machine model which describes the general states and state transitions of the drive. The [State diagram](#) on page 19 presents the most important states (including the FBA profile state names). The FBA Control Word (2.12 FBA MAIN CW) commands the transitions between these states and the FBA Status Word (2.13 FBA MAIN SW) indicates the status of the drive.

Fieldbus adapter module profile (selected by adapter module parameter) defines how the control word and status word are transmitted in a system which consists of fieldbus controller, fieldbus adapter module and drive. With transparent modes, control word and status word are transmitted without any conversion between the fieldbus controller and the drive. With other profiles (e.g. PROFIdrive for FPBA-01, AC/DC drive for FDNA-01, DS-402 for FCAN-01 and ABB Drives profile for all fieldbus adapter modules) fieldbus adapter module converts the fieldbus-specific control word to the FBA communication profile and status word from FBA communication profile to the fieldbus-specific status word.

For descriptions of other profiles, see the *User's Manual* of the appropriate fieldbus adapter module.

Fieldbus references

References (FBA REF) are 16/32-bit signed integers. A negative reference (indicating reversed direction of rotation) is formed by calculating the two's complement from the corresponding positive reference value. The contents of each reference word can be used as torque or speed reference.

When torque or speed reference scaling is selected (by parameter 50.04 FBA REF1 MODESEL / 50.05 FBA REF2 MODESEL), the fieldbus references are 32-bit integers. The value consists of a 16-bit integer value and a 16-bit fractional value. The speed/torque reference scaling is as follows:

Reference	Scaling	Notes
Torque reference	FBA REF / 65536 (value in%)	Final reference is limited by parameters 20.06 MAXIMUM TORQUE and 20.07 MINIMUM TORQUE.
Speed reference	FBA REF / 65536 (value in rpm)	Final reference is limited by parameters 20.01 MAXIMUM SPEED, 20.02 MINIMUM SPEED and 24.12 SPEED REFMIN ABS.
Position reference	See parameter group 60 POS FEEDBACK.	
Velocity reference		

Starting up the FPBA-01 adapter for different communication profiles

Overview

This chapter presents the steps to take during the start-up of the FPBA-01 PROFIBUS DP Adapter Module with the drive. For more detailed information, see *PROFIBUS DP Adapter Module FPBA-01 User's Manual (3AFE68573271 [English])*.



WARNING! Follow the safety instructions given in this manual and in the hardware manual of the drive.

Mechanical and electrical installation

- Insert the FPBA-01 into its specified slot in the drive.
- Fasten the screw.
- Plug the fieldbus connector to the module.

Drive configuration

- Power up the drive.
- A parameter must be adjusted to activate the communication: set parameter 50.01 FBA ENABLE to ENABLE.
- Parameter group 51 shows the status of the FPBA configuration parameters.
- At minimum, set the required node address at parameter 50.02 NODE ADDRESS and the communication profile at 5105 PROFILE. Finally, validate the settings with 51.27 FBA PAR REFRESH.

Cyclic data handling

With the FPBA-01, both data-consistent and non-consistent communication can be used, data-consistent meaning that the whole cyclic data frame is transmitted during a single program cycle. Some PLCs handle this internally, but others must be programmed to transmit data-consistent telegrams (for more information, see *PROFIBUS DP Adapter Module FPBA-01 User's Manual (3AFE68573271 [English])* chapter *Communication*).

Parameter setting examples

This section gives the recommended drive parameter settings for different communication profiles. For more information on the communication profiles used in the communication between the PROFIBUS network, the FPBA-01 module and the drive, such as the contents of the Control Word and Status Word and the state machines of the profiles, refer to *PROFIBUS DP Adapter Module FPBA-01 User's Manual* (3AFE68573271 [English]): chapter *Communication profiles*.

PROFIdrive communication profile (Speed Control Mode) with PPO Type 1

The start/stop commands and reference are according to the PROFIdrive profile *Speed Control Mode*.

A reference value of ± 16384 (4000h) corresponds to parameter 25.02 SPEED SCALING in forward and reverse directions.

Direction	PZD1	PZD2
Out	Control Word	Speed reference
In	Status Word	Speed actual value

The table below gives the recommended drive parameter settings.

Drive parameter	Name	Value	Description
50.01	FBA ENABLE	ENABLE	Communication enable between the drive and fieldbus module
50.04	FBA REF1 MODESEL	SPEED	Fieldbus reference 1 mode selection
10.01	EXT1 START FUNC	FBA	External 1 control source selection
24.01	SPEED REF1 SEL	FBA REF 1	Fieldbus reference 1 is the source for speed reference 1.
34.03	EXT1 CTRL MODE 1	SPEED	External 1 control mode 1: Speed
51.01	FBA TYPE	PROFIBUS DP*	Displays the type of the fieldbus adapter module.
51.02	NODE ADDRESS	3**	Profibus node address of the fieldbus module
51.03	BAUDRATE	12000*	Displays current baud rate on the Profibus network.
51.04	TELEGRAM TYPE	1 (= PPO1)*	Displays telegram type selected by PLC configuration tool.
51.05	PROFILE	0 (= PROFIdrive)	Control word according to the PROFIdrive Speed mode
52.01	FBA DATA IN1	4*	Virtual address for Status Word (PZD 1)
52.02	FBA DATA IN2	5	Virtual address for actual value 1 (PZD 2)
53.01	FBA DATA OUT2	1*	Virtual address for Control Word (PZD 1)
53.02	FBA DATA OUT2	2	Virtual address for reference 1 (PZD 2)
51.27	FBA PAR REFRESH	REFRESH	Refreshing parameter settings of the module

*Read-only or automatically detected/set

**Example

The Control Word is used to send commands from a master to a slave unit. The start sequence for the parameter example above is given below.

Control Word:

47Eh (1150 decimal) => READY TO SWITCH

47Fh (1151 decimal) => OPERATING.

ABB DRIVES communication profile (Speed/Torque Control Mode) with PPO Type 4

The start/stop commands and reference are according to the ABB DRIVES profile Speed Control Mode.

When Reference 1 (REF1) is used, a reference value of ± 20000 (4E20h) corresponds to the reference set by parameter 25.02 SPEED SCALING in the forward and reverse directions.

When Reference 2 (REF2) is used, a reference value of ± 10000 (2710h) corresponds to the reference set by parameter 32.04 TORQUE REF 1 MAX in the forward and reverse directions.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control Word	Speed reference	Torque reference		Not used	
In	Status Word	Speed actual value	Torque actual		Not used	

The table below gives the recommended drive parameter settings.

Drive parameter	Name	Setting	Description
50.01	FBA ENABLE	ENABLE	Communication enable between the drive and the fieldbus module
50.04	FBA REF1 MODESEL	SPEED	Fieldbus reference 1 mode selection
50.05	FBA REF2 MODESEL	TORQUE	Fieldbus reference 2 mode selection
10.01	EXT1 START FUNC	FBA	External 1 control source selection
10.04	EXT2 START FUNC	FBA	External 2 control source selection
24.01	SPEED REF1 SEL	FBA REF 1	Fieldbus reference 1 is the source for speed reference 1
32.02	TORQ REF1 SEL	FBA REF 2	Fieldbus reference 2 is the source for Torque reference 1
34.01	EXT1/EXT2 SEL	C.False	External 1 / External 2 selection from fieldbus only (bit 11 in the fieldbus Control Word)
34.03	EXT1 CTRL MODE 1	SPEED	External 1 control mode 1: Speed
34.05	EXT2 CTRL MODE 1	TORQUE	External 2 control mode 1: Torque
51.01	FBA TYPE	PROFIBUS DP*	Displays the type of the fieldbus adapter module.
51.02	NODE ADDRESS	3**	Profibus node address of the fieldbus module.
51.03	BAUDRATE	12000*	Displays current baud rate on the Profibus network.
51.04	TELEGRAM TYPE	4 (= PPO4)*	Displays telegram type selected by the PLC configuration tool.
51.05	PROFILE	1(= ABB Drives)	Control Word according to the ABB Drives profile.
52.01	FBA DATA IN1	4*	Status Word (PZD 1)
52.02	FBA DATA IN2	5	Actual value 1
52.03	FBA DATA IN3	6	Actual value 2
53.01	FBA DATA OUT2	1*	Control Word

53.02	FBA DATA OUT2	2	Reference 1
53.03	FBA DATA OUT3	3	Reference 2
51.27	FBA PAR REFRESH	REFRESH	Refreshing parameter settings of the module

*Read-only or automatically detected/set

**Example

The start sequence for the parameter example above is given below.

Control Word:

47Eh (1150 decimal) => READY TO SWITCH ON

47Fh (1151 decimal) => OPERATING (Speed mode)

C7Fh (3199 decimal)=> OPERATING (Torque mode).

PROFIdrive communication profile (Positioning Mode) with PPO Type 4

The start/stop commands and reference are according to the PROFIdrive profile *Positioning Mode*. The Position setpoint and velocity reference are defined as 32-bit integer values; both are scaled as defined by drive parameter settings.

Direction	PZD1	PZD2	PZD3	PZD4	PZD5	PZD6
Out	Control Word (STW1)	Position setpoint		Velocity reference		N/A
In	Status Word (ZSW1)	Position actual value		Velocity actual value		N/A

The table below gives the recommended drive parameter settings.

Drive parameter	Name	Value	Description
50.01	FBA ENABLE	ENABLE	Communication enable between the drive and the fieldbus module
50.04	FBA REF1 MODESEL	POSITION	Fieldbus reference 1 mode selection
50.05	FBA REF2 MODESEL	VELOCITY	Fieldbus reference 2 mode selection
10.01	EXT1 START FUNC	FBA	External 1 control source selection
22.01	SPEED FB SEL	ENC1 SPEED**	Speed feedback selection
34.02	EXT1 MODE 1/2SEL	P.FBA MAIN CW.26	External 1 control mode selection. Selection is done by START_HOMING bit (bit 11 in Profibus Control Word). Mode 1: Position, Mode 2: Homing
34.03	EXT1 CTRL MODE 1	POSITION	External 1 control mode 1:Position
34.04	EXT1 CTRL MODE 2	HOMING	External 1 control mode 2: Homing
62.01	HOMING METHOD	CAN Methodxx	Selects the homing mode. Select the appropriate CAN Method.
62.03	HOMING START	C.False	Homing start from fieldbus only
65.01	POS REFSOURCE	FIELDBUS	Position reference and speed are read from fieldbus.
65.03	POS START 1	C.False	Position start 1 from fieldbus only
65.04	POS 1 REF SEL	FBA REF 1	FBA reference 1 is the position reference source.
65.11	POS START 2	C.False	Position start 2 from fieldbus only.
65.22	PROF VEL REF SEL	FBA REF2	FBA reference 2 is the velocity reference source.
66.05	POS ENABLE	C.False	Position reference generator is enabled by fieldbus only.
70.03	POS REF ENA	C.False	Position reference enable command from fieldbus only
51.01	FBA TYPE	PROFIBUS DP*	Displays the type of the fieldbus adapter module.
51.02	NODE ADDRESS	3**	Profibus node address of the fieldbus module
51.03	BAUDRATE	12000*	Displays current baud rate on the Profibus network.
51.04	TELEGRAM TYPE	4 (= PPO4)*	Displays telegram type selected by PLC configuration tool.

51.05	PROFILE	4 (= PROFIdrive Positioning)	Control Word according to the PROFIdrive Positioning mode
52.01	FBA DATA IN1	4*	Status Word
52.02	FBA DATA IN2	15	Actual value 1
52.04	FBA DATA IN4	16	Actual value 2
53.01	FBA DATA OUT2	1*	Control Word
53.02	FBA DATA OUT2	12	Reference 1
53.04	FBA DATA OUT4	13	Reference 2
51.27	FBA PAR REFRESH	REFRESH	Refreshing parameter settings of the module

*Read-only or automatically detected/set


Note: By default, fieldbus is not the only control source. See actual signal 2.12 FBA MAIN CW in *ACSM1 Motion Control Program Firmware Manual* for details.

The position setpoint is scaled as follows:

Drive parameter	Setting
60.05 POS UNIT (Position unit)	m**
60.08 POS2INT SCALE	100**

**Example

The position setpoint and actual values are scaled with the above example values as follows:




Example for velocity setpoint scale:

Drive parameter	Name	Value	Description
60.10	POS SPEED UNIT	u/s**	Unit/s (in this case m/s)
60.11	POS SPEED2INT	100**	Scales position speed values to integer values. Selections: 1/10/100/1000/10000/100000

**Example

The velocity setpoint and actual values are scaled with the above example values as follows:



Pay attention to the following parameters:

Group	Description
90	Encoder selection
91/92/93	Settings of the encoder

The start sequence for above parameter example is given below:

Control word:

406h (1150 decimal) => READY TO SWITCH ON

40Fh (1039 decimal) => OPERATING

43Fh (1087 decimal)=> OPERATING (Do not reject traversing task with no intermediate stop.)

47Fh (1151 decimal)=> OPERATING (Activate traversing task.)

C0Fh (3087 decimal)=> OPERATING (Start homing procedure.)

Starting up fieldbus communication and programming the ABB PLC (one-drive system)

What this chapter contains

This chapter presents the steps to take during the start-up of the drive fieldbus control with ABB AC500 PLC and PROFIBUS DP adapter module. A system with one drive is set up. For a system where two drives are controlled simultaneously, see also chapter [Starting up fieldbus communication and programming the ABB PLC \(multi-axis systems\)](#), page 105.

For more information on the fieldbus adapter module, such as

- mechanical and electrical installation
- PROFIBUS specific parameters
- components
- protocols

see *PROFIBUS DP Adapter Module FPBA-01 User's Manual* (3AFE68573271 [English]).

For more information on the PLC, see ABB AC500 PLC manuals.

Safety



WARNING! Follow the safety instructions given in this manual and in the drive hardware manual.

Equipment and programs

Equipment used in the examples:

- **ACSM1-04 demosuitcase** (order code 68836808) containing two ACSM1-04AM-02A5-4 drives with FPBA-01 PROFIBUS DP Adapter Modules



- **AC500 demosuitcase TA510-CASE:** AC500 PLC *) equipped with a CPU of type PM571 and a communications module, CM572-DP, for communication over PROFIBUS DP field.





Programs used in the examples:

- ACSM1 Motion Control Program version UMF11480
- ABB DriveStudio PC tool
- AC500 Control Builder PS501 *). Code of the installation CD: 1SAP 190 100 R0002 C2 V1.3.0 / 11.2008
- PS551-MC PLCopen Motion Control Library *) for AC500. Single license 1SAP190600R0001. Multiple license 1SAP190600R0101.

*) Manufacturer ABB STOTZ-KONTAKT GmbH, <http://www.abb.de/stotz-kontakt>

Start-up flowchart

The steps of the start-up procedure are presented below. Perform the steps from first to last.




No.	Task	Description / See instruction
ELECTRICAL INSTALLATION		
In this section, you wire the equipment used in this programming example.		
1	Connect the PC RJ-45 cable to drive terminal X7.	<i>ACSM1-04 Drive Modules Hardware Manual</i> (3AFE68797543 [English]) Page 34
2	Connect the PLC fieldbus master (CM572-DP) to the fieldbus adapter module (FPBA-01) of the drive.	Installation of the TA510-CASE , page 34
3	Connect the PC serial port (COM) to the PLC programming port. OR: Connect the PC Ethernet port to the PLC Ethernet port with an RJ-45 Ethernet cable. OR: Connect the PLC serial port to the PC USB port with a TK503 programming cable	Installation of the TA510-CASE , page 34 TK503 programming cable order code: 1TN968901R1100
		
SOFTWARE INSTALLATION		
In this section, you install the programming tools.		
1	Install the DriveStudio PC tool if not yet installed.	Installing the DriveStudio PC tool , page 35
2	Install the AC500 Control Builder PS501 software.	Installing the AC500 Control Builder PS501 software , page 35
3	Install the PS551-MC Motion Control library.	Installing the PS551-MC Motion Control Library , page 37
4	If needed, install additional GSD files and libraries.	Installing additional GSD files and libraries , page 38
		
PROGRAMMING		
In this section, you set up the communication between the drive and the PLC and make the PLC program that controls the drive through fieldbus.		
--- ONE-DRIVE SYSTEM ---		
1	Set the drive control program parameters.	In this section you set the drive parameters needed for communication with the FPBA-01 fieldbus adapter module. Setting the drive control program parameters , page 40

No.	Task	Description / See instruction
2	Set up the communication.	<p>In this section, you configure communication between the PLC and the drive.</p> <p>Setting up the communication, page 45</p> <ul style="list-style-type: none"> • <i>Create a new project</i>, page 45 • <i>Configure communication with the SYCON fieldbus configurator</i>, page 50
3	Program the main program to the PLC.	<p>In this section, you program function blocks for communication and basic drive control.</p> <p>Setting up the communication, page 45</p> <ul style="list-style-type: none"> • <i>Create a new project</i>, page 45 • <i>Configure communication with the SYCON fieldbus configurator</i>, page 50 <p>Programming the PLC main program, page 63</p> <ul style="list-style-type: none"> • <i>Load additional libraries for programming assistance</i>, page 63 • <i>Add function block ACSM1_ACCESS_dc</i>, page 66 • <i>Add function block MC_ReadStatus</i>, page 72 • <i>Add function block MC_ReadActualPosition</i>, page 72 • <i>Add function block MC_ReadAxisError</i>, page 72 • <i>Add function block MC_Reset</i>, page 73 • <i>Add function block MC_Power</i>, page 73 • <i>The complete main program is shown here</i>, page 74
4	Program actions to the PLC program.	<p>In this section, you program function blocks for motion control.</p> <p>Programming actions, page 77</p> <ul style="list-style-type: none"> • <i>How to create actions</i>, page 77 • <i>Program velocity (MC_MoveVelocity)</i>, page 80 • <i>Program stopping (MC_Stop)</i>, page 81 • <i>Program positioning (MC_MoveAbsolute)</i>, page 82 • <i>Program relative movement (MC_MoveRelative)</i>, page 83 • <i>Program homing (MCA_Home)</i>, page 84 • <i>Program toggling between two positions</i>, page 84 • <i>Call the actions into the main program</i>, page 87
5	Program the visualization.	<p>In this section, you program function blocks for visualizing the motion control.</p> <p>Programming visualizations, page 89</p> <ul style="list-style-type: none"> • <i>Create an empty visualization field</i>, page 90 • <i>Create buttons</i>, page 91 • <i>Create indicators</i>, page 95 • <i>Create visualization elements</i>, page 96
6	Run and test the program.	<p>In this section, you run and test the program that you have made.</p> <p>Running and testing the program, page 99</p> <ul style="list-style-type: none"> • <i>Load the program to the controller</i>, page 99 • <i>Test the program</i>, page 102

No.	Task	Description / See instruction
--- TWO-DRIVE SYSTEM ---		
	Set up the communication. Program the main program to the PLC. Program actions to the PLC program. Program the visualization. Run and test the program.	In this section, you program additional function blocks for the second drive for communication and basic drive control, and program additional actions and visualizations, and run and test the program. Setting up the communication , page 105 <ul style="list-style-type: none"> • <i>Configure communication with the SYCON fieldbus configurator</i>, page 106 Programming the PLC main program , page 116 Programming actions , page 120 Programming visualizations , page 123 Running and testing the program , page 124

Connections

PC:
 - DriveStudio
 - AC500 Control Builder PS501



Connections for the setup in section [Starting up fieldbus communication and programming the ABB PLC \(multi-axis systems\)](#), page 105

Note: Both drives are followers/slaves for the communication module of the PLC.

Installation of the TA510-CASE

- ① 24 V DC input socket
- ② 24 V DC on/off switch
- ③ Analog potentiometer
- ④ Digital switches
- ⑤ Programming port
- ⑥ CM572-DP communication module
- ⑦ CPU unit PM571
- ⑧ Analog module AX522
- ⑨ Remote digital I/O module DC505-FBP


Installing the DriveStudio PC tool

Insert the DriveStudio installation CD into the CD drive of your the PC. Follow the instructions given by the installation program.


For more information, see DriveStudio online Help folder DriveStudio: Installing and uninstalling.

Installing the AC500 Control Builder PS501 software


1. Insert the AC500 Control Builder PS501 installation CD into the CD drive of your PC. Click the **Read me first** button and read the instructions.
2. Click the **Installation PS501** button.



3. Click the **Read me for installation** button and read the instructions.



4. Click the **Step 1: Installation Control Builder PS501** button. Follow the instructions.




5. Click the **Step 2: Installation Fieldbus Configuration SYCON.net** button. Follow the instructions.

6. Click the **Installation GSD and ESD files** button. Follow the instructions.

7. Click the **Opt. 1: Installation CodeSys Service Tool**.

Installing the PS551-MC Motion Control Library

Insert the *PS551-MC Motion Control Library for AC500* (code: 1SAP190600R0001) installation CD into the CD drive of your the PC. If the installation does not start automatically, double-click setup.exe.



Installing additional GSD files and libraries

The GSD file DP-V0 for the FPBA-01 fieldbus adapter module (ABB0959.gsd) is included in the *PS551-MC Motion Control Library* CD and was installed in the previous step.

The GSD files DP-V0 and DP-V1 for FPBA-01 can also be found at the manufacturer's website. Go to www.abb.com and select Product Guide / Drives / Drive Options / Fieldbus Options. From the Please select category list, select “..FPBA - PROFIBUS (3)”.

The screenshot shows the ABB website interface in Microsoft Internet Explorer. The browser's address bar displays the URL: <http://www.abb.com/product/seitp322/f12b5520207bb331c1257265002a17d6.aspx>. The page title is "ABB Communication Options - Drive Options (Drives) - Microsoft Internet Explorer".

The website header includes the ABB logo and the tagline "Power and productivity for a better world™". Navigation tabs include "Home", "About ABB", "Products & services", "News center", "Careers", and "Investor relations". The "Products & services" tab is active, showing a breadcrumb trail: "Product Guide > Drives > Drive Options > Communication Options".

The main content area is titled "Fieldbus options" and has three sub-tabs: "Overview", "Service & Support", and "Contacts". The "Overview" tab is selected.

The "Overview" section contains the following text:

ABB offers several interfaces for the data transfer of drives and system integration. The functionality of the drives can be further extended with fieldbuses, I/O modules, encoders and resolvers.

The following fieldbus protocols are available (some protocols are not supported by every drive type):

- CANopen
- ControlNet
- DeviceNet
- EtherCat
- Interbus
- LonWorks
- Modbus
- PROFIBUS DP-V0 / DP-V1

Industrial Ethernet protocols:

- Ethernet/IP
- Modbus/TCP
- PROFINET IO

The "Documentation and downloads" section features a "Show options for filtering result" link and a "Please select category" dropdown menu. The dropdown menu is open, showing a list of categories:

- Fieldbus Options <=
- ..FLON - LonWorks (2)
- ..FMBA - Modbus (1)
- ..FPBA - PROFIBUS (3)**
- ..FRSA - RS-485 (1)
- ..FSCA - Serial communication (2)
- ..NAFA - AF 100 (1)
- ..NBAA - Building Automation (3)
- ..NCAN - CANopen (1)
- ..NCNA - ControlNet (2)
- ..NCSA - CS 31 (1)
- ..NDNA - DeviceNet (2)


On the right side of the page, there is a search bar with the text "Search" and an "OK" button. Below the search bar, there are several utility options:

- Products & Services only
- ☆ Rate this page
- ← Share this page

 Social media sharing icons for Facebook, Twitter, LinkedIn, and Email are also present. Below these, the "Your preferences" section includes:

- Finland (selected in a dropdown menu)
- Select language (dropdown menu)

If needed, copy additional GSD files to the following folder in your PC:
C:\Program Files\Hilscher GmbH\SYCONnet\ABBPBGenericSlaveDTM\GSD.



Step

Setting the drive control program parameters

This section lists the ACSM1 Motion Control Program parameter settings that you need to do for successful communication with the FPBA-01 fieldbus adapter module. If needed, set also other parameters to meet the application needs.

For more information on the parameters, refer to *ACSM1 Motion Control Program Firmware Manual (3AFE68848270 [English])*.

For advice on using the DriveStudio, refer to the DriveStudio online Help.

1. Open the DriveStudio.
2. Set the parameters as shown below.

10 START/STOP				
1	EXT1 START FUNC			FBA
2	EXT1 START IN1			P.DI STATUS.0
3	EXT1 START IN2			C.False
4	EXT2 START FUNC			FBA
5	EXT2 START IN1			P.DI STATUS.0
6	EXT2 START IN2			C.False
7	JOG1 START			C.False
8	FAULT RESET SEL			P.DI STATUS.2
9	RUN ENABLE			C.True
10	EM STOP OFF3			C.True
11	EM STOP OFF1			C.True
12	START INHIBIT			Disabled
13	FB CW USED			P.FBA MAIN CW
14	JOG2 START			C.False
15	JOG ENABLE			C.False
16	D2D CW USED			P.D2D MAIN CW
17	START ENABLE			C.True
24 SPEED REF MOD				
1	SPEED REF1 SEL	FBA REF1	0	8
2	SPEED REF2 SEL	ZERO	0	8
3	SPEED REF1 IN	P.SPEED REF1		
4	SPEED REF2 IN	P.SPEED REF2		
5	SPEED REF 1/2SEL			C.False
6	SPEED SHARE	1.000	-8.000	8.000
7	SPEEDREF NEG ENA			C.False
8	CONST SPEED	0 rpm	-30000	30000
9	CONST SPEED ENA			C.False
10	SPEED REF JOG1	0 rpm	-30000	30000
11	SPEED REF JOG2	0 rpm	-30000	30000
12	SPEED REFMIN ABS	0 rpm	0	30000

Step

Setting the drive control program parameters

34 REFERENCE CTRL

1	EXT1/EXT2 SEL	C.False		
2	EXT1 MODE 1/2SEL	C.False		
3	EXT1 CTRL MODE1	Position	1	9
4	EXT1 CTRL MODE2	Homing	1	9
5	EXT2 CTRL MODE1	Prof Vel	1	9
7	LOCAL CTRL MODE	Speed	1	6
8	TREF SPEED SRC	P.TORQ REF SP CT...		
9	TREF TORQ SRC	P.TORQ REF RUSH...		
10	TORQ REF ADD SRC	P.TORQUE REF ADD		

50 FIELDBUS

1	FBA ENABLE	Enable	0	1
2	COMM LOSS FUNC	Fault	0	3
3	COMM LOSS T OUT	0.3 s	0.3	6553.5
4	FBA REF1 MODESEL	Position	0	5
5	FBA REF2 MODESEL	Velocity	0	5
6	FBA ACT1 TR SRC	P.SPEED ACT		
7	FBA ACT2 TR SRC	P.TORQUE		
8	FBA SW B12 SRC	C.False		
9	FBA SW B13 SRC	C.False		
10	FBA SW B14 SRC	C.False		
11	FBA SW B15 SRC	C.False		

51 FBA SETTINGS

1	FBA TYPE	PROFIBUS-DP		
2	FBA PAR2			3
3	FBA PAR3			12000
4	FBA PAR4			5
5	FBA PAR5			4
6	FBA PAR6			100
7	FBA PAR7			0
8	FBA PAR8			0

Step

Setting the drive control program parameters

▣ 52 FBA DATA IN

1 FBA DATA IN1	4	0	9999
2 FBA DATA IN2	15	0	9999
3 FBA DATA IN3	0	0	9999
4 FBA DATA IN4	16	0	9999
5 FBA DATA IN5	0	0	9999
6 FBA DATA IN6	413	0	9999
7 FBA DATA IN7	0	0	9999
8 FBA DATA IN8	801	0	9999
9 FBA DATA IN9	0	0	9999
10 FBA DATA IN10	805	0	9999
11 FBA DATA IN11	0	0	9999
12 FBA DATA IN12	0	0	9999

▣ 53 FBA DATA OUT

1 FBA DATA OUT1	1	0	9999
2 FBA DATA OUT2	12	0	9999
3 FBA DATA OUT3	0	0	9999
4 FBA DATA OUT4	13	0	9999
5 FBA DATA OUT5	0	0	9999
6 FBA DATA OUT6	6506	0	9999
7 FBA DATA OUT7	0	0	9999
8 FBA DATA OUT8	6507	0	9999
9 FBA DATA OUT9	0	0	9999
10 FBA DATA OUT10	6509	0	9999
11 FBA DATA OUT11	0	0	9999
12 FBA DATA OUT12	0	0	9999

▣ 60 POS FEEDBACK

1 POS ACT SEL	ENC1	0	1
2 POS AXIS MODE	Linear	0	1
3 LOAD GEAR MUL	1	-2147483...	21474836...
4 LOAD GEAR DIV	1	1	21474836...
5 POS UNIT	Meter	0	3
6 FEED CONST NUM	10	1	21474836...
7 FEED CONST DEN	100	1	21474836...
8 POS2INT SCALE	1000	1	1000000
9 POS RESOLUTION	16 bits	10	24
10 POS SPEED UNIT	u/min	0	2
11 POS SPEED2INT	10	1	1000000
12 POS SPEED SCALE	1.0000	0.0000	32768.0000
13 MAXIMUM POS	3276.800 m	-3276.800	3276.800
14 MINIMUM POS	-3276.800 m	-3276.800	3276.800
15 POS THRESHOLD	0.000 m	-3276.800	3276.800


Step

Setting the drive control program parameters

62 POS CORRECTION				
1	HOMING METHOD	CAN Method19	0	35
2	HOMING STARTFUNC	Normal	0	1
3	HOMING START	C.False		
4	HOME SWITCH TRIG	ENC1_DI1	0	3
5	NEG LIMIT SWITCH	C.False		
6	POS LIMIT SWITCH	C.False		
7	HOMING SPEEDREF1	6.0 u/min	0.0	196608.0
8	HOMING SPEEDREF2	1.5 u/min	0.0	196608.0
9	HOME POSITION	0.000 m	-3276.800	3276.800
10	HOME POS OFFSET	0.000 m	-3276.800	3276.800
11	PRESET MODE	Whole system	0	3
12	PRESET TRIG	Homing start	0	12
13	PRESET POSITION	0.000 m	-3276.800	3276.800
14	CYCLIC CORR MODE	Disabled	0	5
15	TRIG PROBE1	Disabled	0	28
16	PROBE1 POS	0.000 m	-3276.800	3276.800
17	TRIG PROBE2	Disabled	0	28
18	PROBE2 POS	0.000 m	-3276.800	3276.800
19	MAX CORRECTION	500.000 m	0.000	3276.800
20	POS ACT OFFSET	0.000 m	-3276.800	3276.800
21	POS COR MODE	Normal	0	1
65 PROFILE REFERENCE				
1	POS REFSOURCE	Fieldbus	0	2
2	PROF SET SEL	C.False		
3	POS START 1	C.False		
4	POS REF 1 SEL	FBA REF1	0	8
5	POS SPEED 1	100.0 u/min	0.0	196608.0
6	PROF ACC 1	100.0 min-2	0.0	196608.0
7	PROF DEC 1	-100.0 min-2	-196608.0	0.0
8	PROF FILT TIME 1	0 ms	0	1000
9	POS STYLE 1	0b0010000	0b00000000	0b11111111
10	POS END SPEED 1	0.0 u/min	-196608.0	196608.0
11	POS START 2	C.False		
12	POS REF 2 SEL	POS REF2	0	8
13	POS SPEED 2	100.0 u/min	0.0	196608.0
14	PROF ACC 2	100.0 min-2	0.0	196608.0
15	PROF DEC 2	-100.0 min-2	-196608.0	0.0
16	PROF FILT TIME 2	0 ms	0	1000
17	POS STYLE 2	0b0010100	0b00000000	0b11111111
18	POS END SPEED 2	0.0 u/min	-196608.0	196608.0
19	POS REF 1	0.000 m	-3276.000	3276.000
20	POS REF 2	0.000 m	-3276.000	3276.000
21	POS REF ADD SEL	ZERO	0	8
22	PROF VEL REF SEL	FBA REF2	0	7
23	PROF VEL REF1	100.0 u/min	-196608.0	196608.0
24	POS START MODE	NORMAL	0	1

Step

Setting the drive control program parameters

66 PROFILE GENERATOR					
1	PROF GENERAT IN		P.POS REF		
2	PROF SPEED MUL		1.000	0.000	1.000
3	PROF ACC WEAK SP		196608.0	u/min	0.0 196608.0
4	POS WIN		0.010	m	0.000 3276.800
5	POS ENABLE		C.True		

Tool/Step Setting up the communication

For setting up communication between the PLC and the drive, first, create a new project. After that, you can open the SYCON.net configuring tool and configure the communication.

CoDeSys


Create a new project

1. Open the AC500 Control Builder PS501 programming tool by double-clicking the icon:




Installation path:
C:\Program Files\3S Software\CoDeSys V2.3\Codesys.exe

2. Select from the **File** menu **New**. -> Dialog box **Target settings** opens.
3. In the **Configuration:** box, select AC500 PM571. Click **OK**.




Tool/Step Setting up the communication

4. In the **New POU** dialog box, select as shown below.




5. -> The programming view opens. Open the **Resources** field by clicking its tab.




Tool/Step Setting up the communication

6. In the **Resources** folder, double-click PLC Configuration.




7. In the **PLC Configuration** dialog box, click the plus sign to open the AC500 folder.




Tool/Step **Setting up the communication**

- Right-click the Couplers[FIX] folder. Select **Append Subelement** and **CM572 - External-PROFIBUS DP Master....**




Tool/Step Setting up the communication

9. In the Couplers[FIX] folder, right-click the Internal - none[SLOT] file and select **Replace element** and **PM5x1-ETH - Internal-Ethernet**.



10. From the **File** menu, select **Save as** and name the project. Click **Save**.




Tool/Step

Setting up the communication

CoDeSys

Configure communication with the SYCON fieldbus configurator


1. Open the project that you created.
2. Click the **Resources** tab to show the Resources folders.
3. Under **Tools**, double-click SYCON.net <R>.




Tool/Step Setting up the communication

SYCON.net

- > The SYCON.net tool opens:




- From the **Network** menu, select the **Device Catalog...** command. Click the **Reload** button. -> PROFIBUS options appear in the ABB Oy folder. Click **OK**.




Tool/Step **Setting up the communication**

6. Drag and drop CM572-DPM on the green line. In the **netConnect-Driver Parameter** dialog box, select 1 for the **Board no:** box. This is because the CM572-DP communications module is installed next to the CPU on the left-hand side in the installation example of this manual.




Tool/Step Setting up the communication

7. Drag and drop the FPBA-01 DP-V0 on the purple line.



Tool/Step Setting up the communication


- In the **netDevice** field, right-click the CM572-DPM icon. Select **Configuration**. In the **Navigation area** field, click 3S Gateway Driver. Click the **Gateway Configuration** button.




- In the **Communication Parameters** dialog box, set the communication parameters according to the serial port of your PC. See [Appendix A - How to find out the serial communication parameter values of your PC?](#)

Tool/Step Setting up the communication

10. In the **Pages Three-View**, click Device Assingment. Activate the device by ticking it.




11. In the **Pages Tree-view**, click Configuration / Bus Parameters. In the **Bus Parameters** dialog box, set the Baud Rate. If there is warning sign, click the **Adjust** button and set the other timing parameters.



Tool/Step **Setting up the communication**


12. In the **Pages Tree-view**, click Station Table under Configuration. Set the station address for the FPBA-01. Click the **Apply** button and then **OK**.

Note: The station address here must be the same as the value of Parameter 51.02 FBA PAR2 in the drive control program. Set parameter Parameter 51.02 FBA PAR2 with DriveStudio.




Tool/Step Setting up the communication

- Right-click the ABB Drives FPBA-01 icon connected to the purple line in the netDevice field. In the Navigation area field, click Modules in the Configuration folder. In the Available modules: box, select PPO-05. Click the **Insert** button and then **Apply** and **OK**.



Tool/Step Setting up the communication

14. In the Configuration folder, click Parameters. Set the values of parameters Fail Safe mode and Control-zero mode as shown below.



Tool/Step Setting up the communication

15. In the **netConnect** field, click PPO-5, 4PKW + 10 PZD <Slot 1>. -> A list of inputs and outputs appears.

The screenshot displays the SYCON.net software interface for configuring a fieldbus communication system. The main window is titled 'SYCON.net - [demo2.spj]'. It features a menu bar (File, View, Help) and a toolbar. The interface is divided into several panes:


- netProject:** Shows a project tree with 'Project: demo2' containing 'CMS572-DPM[CM572-DPM]<1>(#1)' and 'ABB Drives FPBA-01 DP-V0[ABB Drive]'. A 'Vendor' field is visible at the bottom.
- netDevice:** Displays a network diagram with a green bus and connected devices, including 'CMS572-DPM[CM572-DPM]<1>(#1)' and 'ABB Drives FPBA-01 DP-V0'.
- netConnect:** Shows a tree view of the selected device and its slot configuration, including 'Project: demo2', 'CMS572-DPM[CM572-DPM]<1>(#1), Slot 1', and 'ABB Drives FPBA-01 DP-V0[ABB Drives FPBA-01 DP-V0]<1>'. The selected slot is 'PPO-05, 4 PKW + 10 PZD <Slot 1>'. Below this is a table listing the available signals.

Name of signal	Data ...	I/O	Name of v...	Comment
Input_1	SIGN...	I	field_in1	PPO-05, 4 PKW
Input_2	SIGN...	I		
Input_3	SIGN...	I		
Input_4	SIGN...	I		
Output_1	SIGN...	O	field_out1	PPO-05, 4 PKW
Output_2	SIGN...	O		
Output_3	SIGN...	O		
Output_4	SIGN...	O		
Input_5	SIGN...	I		
Input_6	SIGN...	I		
Input_7	SIGN...	I		
Input_8	SIGN...	I		
Input_9	SIGN...	I		
Input_10	SIGN...	I		
Input_11	SIGN...	I		
Input_12	SIGN...	I		
Input_13	SIGN...	I		
Input_14	SIGN...	I		
Output_5	SIGN...	O		
Output_6	SIGN...	O		
Output_7	SIGN...	O		
Output_8	SIGN...	O		
Output_9	SIGN...	O		
Output_10	SIGN...	O		

Tool/Step Setting up the communication

16. Name the signals. In this example configuration, Input 1 is named field_in1 and Output 1 field_out1.

Note: You can name all signals here and they will be automatically in use in the Control Builder.




Name of signal	Data ...	I/O	Name of variable	Comment
Input_1	SIGN...	I	field_in1	PPO-05, 4 PKW + 10 PZ
Input_2	SIGN...	I		
Input_3	SIGN...	I		
Input_4	SIGN...	I		
Output_1	SIGN...	O	field_out1	PPO-05, 4 PKW + 10 PZ
Output_2	SIGN...	O		
Output_3	SIGN...	O		
Output_4	SIGN...	O		
Input_5	SIGN...	I		
Input_6	SIGN...	I		
Input_7	SIGN...	I		
Input_8	SIGN...	I		
Input_9	SIGN...	I		
Input_10	SIGN...	I		
Input_11	SIGN...	I		
Input_12	SIGN...	I		
Input_13	SIGN...	I		
Input_14	SIGN...	I		
Output_5	SIGN...	O		
Output_6	SIGN...	O		
Output_7	SIGN...	O		
Output_8	SIGN...	O		
Output_9	SIGN...	O		
Output_10	SIGN...	O		
Output_11	SIGN...	O		
Output_12	SIGN...	O		
Output_13	SIGN...	O		
Output_14	SIGN...	O		

17. Check that the PLC is in the Stop state (Stop in the display).

Note: The downloading is not possible if the PLC is in the Run state.

18. Download the communication configuration to the PLC: first, right-click the CM572-DPM icon and, then click **Download**.



netDevice

Device: CM572-DPM[CM572-DPM]<1>(#1)

Download running...


9 % complete

Cancel

Tool/Step Setting up the communication

19. When the downloading is completed, right-click the CM572-DPM icon and then click **Disconnect**.
20. Save the project with the **Save** command under the **File** menu.
21. Close the SYCON.net tool.
22. Variables field_in1 and field_out1 are now found in the Resources sheet, under Global variables.

CoDeSys



Tool/Step Programming the PLC main program

In this section, you program the PLC main program which contains function blocks for communication and basic drive control.

For detailed function block descriptions, refer to

- CoDeSys Help (Press F1 in CoDeSys software)
- *User Manual for PLC Programming with CoDeSys 2.3* by 3S – Smart Software Solutions GmbH


For ACSM1 PLCopen function blocks, refer to

- *User Manual for PS551-MC (Motion Control library for ABB PLC AC500) according to Technical Specification PLCopen – Technical Committee 2 – Task Force; Function Blocks for motion control.*

Load additional libraries for programming assistance

It is necessary to load additional libraries to make additional function blocks active.


1. Click the Resources tab. Double-click the Library Manager.



2. From the **Insert** menu, select **Additional libraries....**



Tool/Step Programming the PLC main program

3. Select the following libraries and click **Open**.



Tool/Step Programming the PLC main program

4. Double-click the PS551-MC folder and select the following libraries. Click **Open**.




Note: If you cannot see the PS551-MC folder, you have copied the motion control libraries to another folder, or you have not copied them at all. Go to the location where you have pasted the libraries, or copy the libraries from the installation CD to the following folders:

C:\Program Files\Common Files\CAA-Targets\ABB_AC500\Library
 C:\Program Files\Common Files\CAA-Targets\ABB_AC500\AC500_V12\Library

Tool/Step Programming the PLC main program


5. In this example, the following libraries were inserted.



Add function block ACSM1_ACCESS_dc


ACSM1_ACCESS_dc is an interface block that converts the PLC commands to the control word format of the ACSM1. The control word is in PROFIdrive positioning mode.

1. Click the POU's tab. In the POU's field, double-click PLC_PRG(PRG). -> The Box tool for adding function blocks appears in the tool bar. Click the Box button.




Tool/Step Programming the PLC main program

- Replace the default text AND with text acsm1_access_dc. Now, the CoDeSys program recognizes the function block and the block appearance changes automatically.



- Name the function block access_axis1 and press **Enter**.




Tool/Step Programming the PLC main program

- > The Declare Variable assistant appears. In the Class dialog box, select VAR_GLOBAL which denotes global variables. The content of box Type is configured automatically to ACSM1_ACCESS_dc. Click **OK**.

Note 1: If you want to call Declare Variable assistant again, click on the demanded variable and press **Shift+F2**.

Note 2: When defining inputs, you can use help of Input assistant. Click on the demanded input and press **F2**.

- Configure inputs OFF1, OFF2 and OFF3. Name the fields Off1, Off2 and Off3 and press **Enter**. The program configures the Type of these inputs automatically to BOOL and the Class to VAR. Click **OK**. Inputs RESET_POS_SYS and ROLLOVER are left blank.




Tool/Step Programming the PLC main program

- Configure input axis. Name it axis1 and press **Enter**. Class: VAR_GLOBAL. Type: AXIS_REF. **Note:** AXIS_REF is not configured automatically, you must type it. Click **OK**.

- Select the left-hand side of input field_in. Click the Box button in the tool bar. Name the new function block ADR which denotes address. Press **Enter**. Repeat the same for input field_out.


Note: Inputs field_in1 and field_out1 were configured with SYCON.net on page 60.



Tool/Step Programming the PLC main program

8. In this section a new program row is made before the access_axis1 block. This is because the state of input switches Off1, Off2 and Off3 must be TRUE before starting block access_axis1 when the program is run.

Right-click somewhere in the blank area to open the following menu and select **Network (before)**. -> A new programmable area (program row 0001) is made.




The switches have to go to the TRUE state in the following order: Off2, Off3 and Off1. They cannot turn on immediately, one after another, so add delay function blocks (TON) with a delay time of 200 ms.

In case of errors, output ERR_REMOTE has to be evaluated before start. This is done by block AND with an inverted input. To invert the input, right-click on the input and select **Negate**.


Off1_3 is a switch which is later used starting the drive when the program is run. It is a global variable (Class: VAR_GLOBAL; Type: BOOL).

Tool/Step Programming the PLC main program

The program made so far is shown below.



Right-click in the blank area and select **Network (after)** from the menu. Add the following blocks to the main program: MC_ReadStatus, MC_ReadActualPosition, MC_ReadAxisError, MC_Reset, MC_Power. Configuring the blocks is described below.




Programming the PLC main program

Add function block MC_ReadStatus

This function block returns in detail the status of the axis with respect to the motion currently in progress.


Name the block mc_reads. Press **Enter**. Class: VAR; Type: MC_ReadStatus. The block must be enabled all the time -> name input Enable TRUE. Name input Axis axis1 which is already configured.



Add function block MC_ReadActualPosition

This function block returns the actual position.


Name the block mc_readpos. Press **Enter**. Class: VAR; Type: MC_ReadActualPosition. The block must be enabled all the time -> name input Enable TRUE. Add global variable actual_pos_axis1 for later use in visualization, Class: VAR_GLOBAL, Type: LREAL.



Add function block MC_ReadAxisError

This function block describes general axis errors not related to the function blocks.

Class: VAR, Type: MC_ReadAxisError.



Tool/Step


Programming the PLC main program

Add function block MC_Reset

This function block makes the transition from state ErrorStop to STANDSTILL by resetting all internal axis-related errors. It does not affect the output of the function block instances.

Class: VAR, Type: MC_Reset. Add global variable reset_axis1 for switching purposes, because the reset block cannot be active constantly,


Class: VAR_GLOBAL, Type: BOOL.



Add function block MC_Power

This function block controls the power stage on or off.

Class: VAR, Type: MC_Power. Add global variables enable_axis1 and power_status_axis1 for start-up and visualization, Class: VAR_GLOBAL, Type: BOOL.



Tool/Step

Programming the PLC main program

The complete main program is shown here

The complete program is shown below. The local variables are shown in the right-hand-side top field.

The screenshot shows the CoDeSys interface for the PLC main program. The left pane displays the project structure with 'PLC_PRG (PRG)' selected. The main editor shows the following code:

```

0001 PROGRAM PLC_PRG
0002 VAR
0003   Off1: BOOL;
0004   Off2: BOOL;
0005   Off3: BOOL;
0006   ton_1: TON;
0007   ton_2: TON;
0008   mc_reads: MC_ReadStatus;
0009   mc_readpos: MC_ReadActualPosition;
0010   mc_readaxe: MC_ReadAxisError;
0011   MC_Reset: MC_Reset;
0012   MC_Power: MC_Power;
0013 END_VAR
0014

```

The ladder logic diagram for step 0001 shows an AND gate with inputs 'access_axis1.ERR_REMOTEC' and 'off1_3'. The output of the AND gate is connected to the 'IN' input of a TON timer block labeled 'ton_1'. The timer is set to a delay of '#200ms'. The 'Q' output of the timer is connected to an 'Off' output.

The global variables are shown below when the Resources field is clicked open.

The screenshot shows the CoDeSys interface for Global Variables. The left pane displays the 'Resources' tree with 'Global Variables' selected. The main editor shows the following code:


```


0001 VAR_GLOBAL
0002   access_axis1: ACSM1_ACCESS_dc;
0003   axis1: AXIS_REF;
0004   off1_3: BOOL;
0005   reset_axis1: BOOL;
0006   enable_axis1: BOOL;
0007   actual_pos_axis1: LREAL;
0008   power_status_axis1: BOOL;
0009 END_VAR
0010
0011
0012
0013
0014

```

Tool/Step Programming the PLC main program

View of the main program rows:



Tool/Step Programming the PLC main program

Tool/Step Programming actions

In this section, you program actions and add them to the PLC main program. Actions are needed for controlling the motor movement. PLCopen library offers many simple and very useful functions for the ACSM1.

For detailed function block descriptions, refer to


- CoDeSys Help (Press F1 in CoDeSys software)
- *User Manual for PLC Programming with CoDeSys 2.3* by 3S – Smart Software Solutions GmbH

For ACSM1 PLCopen function blocks, refer to

- *User Manual for PS551-MC (Motion Control library for ABB PLC AC500)* according to *Technical Specification PLCopen – Technical Committee 2 – Task Force; Function Blocks for motion control.*


How to create actions

1. In the POU's field, right-click PLC_PROG(PRG) and select **Add Action**.




Tool/Step Programming actions

2. Name the action for example velocity. Select FBD for the programming language. Click **OK**.




3. -> An empty programming space appears.




Tool/Step Programming actions

4. Create separate actions which are needed in the program for example homing, position_toggle, positioning, relative, stop and velocity.



5. Program the actions in the same way as you programmed the function blocks in the main program. For example, under action velocity there will be function block MC_MoveVelocity. For programming the blocks, see the next steps.



Programming actions

Program velocity (MC_MoveVelocity)

This Function Block commands a never ending controlled motion at a specific velocity.

By clicking the Box tool button, insert a new box. Replace the default text AND with MC_MoveVelocity. Name the block, for example, movevelo1, Class: VAR, Type: MC_MoveVelocity. Name the Execute input velo1, Class: VAR_GLOBAL, Type: BOOL.

Define inputs Velocity, Acceleration and Deceleration with numeric values as shown in the window below, or declare them static values in the main program local variable list by writing, for example, the following lines to the list.

Acceleration: LREAL:=1000;

Deceleration: LREAL:=1000;


Velocity1: LREAL:=200;

(Note: For editing the variable list, double-clicking PLC_PROG(PRG) in the POU's field, see page 74.)

Name Direction either POSITIVE or NEGATIVE.

Leave Jerk and BufferMode blank.

Input Axis defines the controlled axis. Name it axis1.



See the next page.

Tool/Step Programming actions

The block in the previous picture runs axis1 constantly at velocity 200.

The speed and position scaling is defined by setting drive control program parameters of group 60 POS FEEDBACK, see page 42. With the settings on page 42, a speed reference of 1000 corresponds to a speed of 1000 rpm that means 1000 motor axis rotations per minute.

Program stopping (MC_Stop)


This function block commands a controlled motion stop and transfers the axis to the STOPPING state. The block aborts any ongoing function block execution. While the axis is in the STOPPING state, no other function block can perform any motion on the same axis. After the axis has reached the zero velocity, the Done output is set to TRUE immediately. The axis remains in the STOPPING state as long as the Execute input remains TRUE or the zero velocity is not yet reached. As soon as output Done is set and input Execute is FALSE, the axis goes to the STANDSTILL state. For the states, refer to the state machine (Axis StateMachine) on page 102.

By clicking the Box tool button, insert a new box. Replace the default text AND with MC_Stop. Name the block, for example, stop1, Class: VAR, Type: MC_Stop. Name input Execute stop_axis1, Class: VAR_GLOBAL, Type: BOOL.

Define input Deceleration with a numeric value.

Leave Jerk and BufferMode blank.

Input Axis defines the controlled axis. Name it axis1.



Tool/Step

Programming actions**Program positioning (MC_MoveAbsolute)**

This function block commands a controlled motion to a specified absolute position.


By clicking the Box tool button, insert a new box. Replace the default text AND with MC_MoveAbsolute. Name the block, for example, absolute1, Class: VAR, Type: MC_MoveAbsolute. Name input Execute move_pos1, Class: VAR_GLOBAL, Type: BOOL.

Define inputs Position, Velocity, Acceleration and Deceleration with numeric values.

Leave Direction, Jerk and BufferMode blank.

Input Axis defines the controlled axis. Name it axis1.

The following block drives axis1 to position 1000.



Tool/Step Programming actions

Program relative movement (MC_MoveRelative)

This function block commands a controlled motion of a specified distance relative to the actual position at the time of the execution.

By clicking the Box tool button, insert a new box. Replace the default text AND with MC_MoveRelative. Name the block, for example, relative1, Class: VAR, Type: MC_MoveRelative.


Name the Execute input move_rel1, Class: VAR_GLOBAL, Type: BOOL.

Define inputs Position, Velocity, Acceleration and Deceleration with numeric values.

Leave Jerk and BufferMode blank.

Input Axis defines the controlled axis. Name it axis1.

Name input Direction either POSITIVE or NEGATIVE.



Programming actions

Program homing (MCA_Home)


This function block commands the axis to perform the Search home sequence. The details of this sequence depend on the drive manufacturer and can be set by the axis parameters. The Position input is used to set the absolute position when a reference signal is detected. The execution of this function block comes to an end at the STANDSTILL state.

By clicking the Box tool button, insert a new box. Replace the default text AND with MCA_Home. Name the block, for example, home1, Class: VAR, Type: MC_MoveRelative.

Name the Execute input move_home1, Class: VAR_GLOBAL, Type: BOOL.

Input Axis defines the controlled axis. Name it axis1.

Note 1: This function block is not working with FPBA-01 version 200D or older.



Program toggling between two positions


This section presents an example of a function block program for toggling between two positions. At the page 81, action position_toggle was created. Write the program below into the action position_toggle.

Name the Execute input move_toggle1, Class: VAR_GLOBAL, Type: BOOL.

Name variable pos_step, Class: VAR, Type: WORD.

See the next page for the descriptions of the program rows.

Tool/Step Programming actions



Tool/Step	Programming actions
-----------	---------------------

Row 0001

This section is the main switch. When the drive needs to be stopped, function block SEL sets the value of output pos_step to 0. Otherwise the value of output pos_step remains unchanged and the program keeps running.

Row 0002

This section starts up the whole program sequence and repeats it as long as the value of input move_toggle1 is TRUE.

Block trigger2 is needed for the first start-up. The block triggers one time when the value of input move_toggle1 turns to TRUE.

The output of block OR is TRUE, when the trigger block output is TRUE. In this case, block SEL selects value 1 to output pos_step.

Row 0003

This section compares the value of input pos_step with 1. When the values match, block EQ returns the value of its output to TRUE.

TON block pause1 sets its output movement1 to TRUE with a delay of one second. The program runs through sections 4 and 5, there is nothing to do.

Row 0006

This section executes MC_MoveAbsolute block togglemove1. The block moves axis1 to position 800. After the movement, the value of output togglemove1.Done is TRUE.

Now the program runs through sections from 7 to 3, there is nothing to do.

Section 4 is executed.

Row 0004

The values of inputs move_toggle1 and togglemove1.Done in the AND block are TRUE. Block SEL sets the value of its output pos_step to 2.

Row 0005

This section is similar to section 3. Block EQ compares the value of its input pos_step with 2. Now, the values match and the output of block EQ returns to TRUE.

TON block pause2 sets its output movement2 to TRUE with a delay of one second

The program runs through section 6, there is nothing to do.

Row 0007

This block executes MC_MoveAbsolute block togglemove2. The block moves axis1 to position -1200. After the movement, the value of output togglemove2.Done is TRUE.

The program starts the whole sequence again from row 0002. The toggling is continuous as long as the value of input move_toggle1 is TRUE.

Tool/Step

Programming actions



Call the actions into the main program

To activate the actions that you created, call them into the main program:

- In the POUs field, double-click PLC_PRG(PRG).
- Right-click and select **Network (after)** from the opening menu.
- Click the Box tool button and name the appearing box homing.
- Repeat the procedure for the other actions and give the boxes the same names as in the configuring steps before.

See the next page for the program rows.

Tool/Step Programming actions

The action boxes are shown at the end of the main program as follows.

The screenshot displays the CoDeSys software interface for a PLC program. The window title is "CoDeSys - demo2.pro - [PLC_PRG (PRG-FBD)]". The menu bar includes File, Edit, Project, Insert, Extras, Online, Window, and Help. The toolbar contains various icons for file operations, execution, and navigation. The main workspace is divided into several sections:

- Left Panel (POUs):** A tree view showing the project structure under "POUs". The "PLC_PRG (PRG)" folder is expanded, revealing sub-folders for "homing", "position_toggle", "positioning", "relative", "stop", and "velocity".
- Top Right (Code Editor):** Displays the program code starting with "0001 PROGRAM PLC_PRG" and "0002 VAR".
- Center (Action Boxes):** A sequence of action boxes is shown, each with a label and a box containing a diagram:
 - 0007 mc_reset:** A box labeled "MC_Reset" with inputs "reset_axis1" (Execute) and "axis1" (Axis ▶), and outputs "Done", "Busy", "Error", and "ErrorID".
 - 0008 homing:** A simple rectangular box labeled "homing".
 - 0009 position_toggle:** A simple rectangular box labeled "position_toggle".
 - 0010 positioning:** A simple rectangular box labeled "positioning".
 - 0011 relative:** A simple rectangular box labeled "relative".
 - 0012 stop:** A simple rectangular box labeled "stop".
 - 0013 velocity:** A simple rectangular box labeled "velocity".
- Bottom Right (Hardware Configuration):** A section titled "Hardware-Configuration" showing "POU indices:392 (38%)".
- Bottom Bar:** Contains buttons for "POUs", "Data...", "Visu...", and "Res...", along with "ONLINE", "OV", and "READ" status indicators.

Tool/Step

Programming visualizations


CoDeSys

In this section, you program visualizations. By visualizations, you create the user interface for the PLC program: buttons, switches and indicators for measuring, viewing and controlling the movement. The PS551-MC Motion Control Library for ABB PLC AC500 also contains ready-made visualization elements for the ACSM1, for example, the ACSM1 MainControlWord and Axis StateMachine.

Tool/Step Programming visualizations

Create an empty visualization field


Click the Visualization tab. Right-click the Visualizations folder. From the menu opening, select **Add Object...**. Name the New Visualization, for example, visu1 and click **OK**.



Tool/Step Programming visualizations

Create buttons


Create buttons for the needed switches, for example, for each global variable:



In our example, buttons are made for off1_3, enable_axis1, reset_axis1, velo1, stop_axis1, move_pos1, move_home_axis1, move_rel1 and move_toggle1.


How to create and configure a button

1. In the upper tool bar, click the OK button and drag with the cursor a rectangle in visualization field.




Tool/Step Programming visualizations

- Configure the button as follows. Right-click the button. From the menu opening, select **Configure**.




- In the **Category:** dialog box, select **Text**. To the Text Content: dialog box, write the name for the button, for example, Off1_3 which indicates the action the button will perform.



Tool/Step Programming visualizations

- In the **Category:** dialog box, select **Input**. Under Input, tick Toggle variable and write the name of the input to the dialog box, in this case global variable off1_3. Click **OK**.


Note: When defining inputs, you can use help of Input assistant. Click on Toggle variable field and press **F2**.



Now, you have created a button with which you can switch the value of global variable off1_3 between FALSE and TRUE.

Tool/Step Programming visualizations

5. After making all buttons, the visualization field looks like this. Table below indicates the buttons and variables to which the buttons must be toggled.




Button	Toggle variable
Off1_3	off1_3
Enable	enable_axis1
Velocity 1	velo1
Position 1	move_pos1
Relative 1	move_rel1
Toggle move	move_toggle1
Stop	stop_axis1
Reset	reset_axis1
Homing	move_home1


Tool/Step Programming visualizations

Create indicators

1. In the upper tool bar, click the Bar display button and drag with the cursor a bar in visualization field. -> Configure bar display dialog box opens. Click the **Variable/Scale** button.



2. Set the scale. Write the name of the indicated variable (actual_pos_axis1 in this case) in the Variable: box. Click **OK** and **OK**. -> The indicator has been created.




Tool/Step Programming visualizations

Create visualization elements


1. Visualization elements are ready-made visualization components.

In the upper tool bar, click the Visualization button and with the cursor drag a rectangle in the visualization field. In the opening Select Visualization dialog box, select the visualization, MC_VISU_ACSM1_mcw, in this case. Click **OK**.



Tool/Step Programming visualizations

2. Double-click the created element. In the Visualization dialog box that opens, click the **Placeholder...** button. In the Replace placeholders dialog box, write `.access_axis1` to the Replacement field. This points to the `access_axis1` function block. Click **OK** and **OK**.



Tool/Step Programming visualizations

3. Add other elements in the same way as described above.

Note: In the Replacement field, write .access_axis1 for the ACSM1 main control word and main status word visualizations. Write .axis1 for the Axis actual values and Axis state machine values visualizations. The replacement points always to the values that the visualization is presenting.

Here is an example of the finished visualization.


The screenshot displays the CoDeSys software interface for a visualization. The main window is titled "CoDeSys - demo2.pro* - [visu1]". The interface is divided into several sections:

- Control Panel:** Contains buttons for "Off1_3", "Enable", "Velocity 1", "Position 1", "Relative 1", "Toggle move", "Stop", "Reset", and "Homing".
- ACSM1 Main Control Word:** A table with 12 rows and 4 columns of status indicators.
- ACSM1 Main Status Word:** A table with 12 rows and 4 columns of status indicators.
- Axis State Machine:** A state transition diagram with nodes for "DISCRETE MOTION", "CONTINUOUS MOTION", "STOPPING", "RRRORSTO", "HOMING", "STANDSTILL", and "DISABLED".
- Position Scale:** A horizontal scale from -5000.0 to 5000.0 with a green bar indicating the current position.
- Axis actual values:** A table with 3 rows and 2 columns for "Positic", "veloci", and "axis en".

Tool/Step	Running and testing the program
CoDeSys	In this section, you download the program to the PLC. Thereafter, you can run the program and test it.
	Load the program to the controller <ol style="list-style-type: none"><li data-bbox="336 539 1495 584">1. Turn the drive on with the I/O switch of the demosuitcase.<li data-bbox="336 595 1495 660">2. Turn the PLC on with the on/off switch in its demosuitcase. For the location of the on/off switch, refer to the photo on page 34.

Tool/Step Running and testing the program


- From the **Online** menu, select **Communication Parameters...** Check that the communication parameters correspond to the serial port of your PC (see [Appendix A - How to find out the serial communication parameter values of your PC?](#)).




- Open the AC500 Control Builder PS501 programming tool by double-clicking the CoDeSys icon in the desktop of your computer.
- Click the Visualization tab.

Tool/Step Running and testing the program

6. From the **Online** menu, click **Login**. The program asks you to download the program to the controller. Click **Yes**.



If you get a communication error message,



Check the cables and connections. From the **Online** menu, select **Communication Parameters...** and remove irrelevant communication parameters. Configure the communication with the SYCON.net again and download the configuration as described above. To find out the communication parameter values of your PC, see [Appendix A - How to find out the serial communication parameter values of your PC?](#)

7. From the **Online** menu, click **Run**. -> Now, your program is active and you can run the functions.

Tool/Step Running and testing the program

Test the program

1. Start the drive by clicking the **Off1_3** button and, after that, the **Enable** button.
-> The drive should start and the values of the first six ACSM1 MainControlWord bits should change to TRUE.

CoDeSys - demo2.pro - [visu1]

File Edit Project Insert Extras Online Window Help

Visualizations
L visu1

Off1_3

Enable

Velocity 1

Position 1

Relative 1

Toggle move

Stop

Reset

Homing

ACSM1 MainControlWord			
OFF1	TRUE	INCHING_1	FALSE
OFF2	TRUE	INCHING_2	FALSE
OFF3	TRUE	REMOTE_CM	TRUE
DP_ENABLE	TRUE	START_HOM	FALSE
NO_REJECT	TRUE	PAR934	FALSE
NO_STOP	TRUE	PAR935	FALSE
TOGGLE	FALSE	PAR936	FALSE
RESET	FALSE	PAR937	FALSE

ACSM1 MainStatusWord			
RDY_ON	TRUE	AT_SETPOIN	FALSE
RDY_RUN	TRUE	REMOTE	TRUE
RDY_REF	TRUE	TARGET	TRUE
TRIPPED	FALSE	HOMING_DC	TRUE
OFF_2_STA	TRUE	TRAY_ACK	FALSE
OFF_3_STA	TRUE	DRIVE_STOP	TRUE
SWC_ON_IN	FALSE	PAR942	FALSE
WARN_ALAR	FALSE	PAR943	FALSE

Axis StateMachine

-5000.0 0.0 5000.0

Axis actual values	
Positio	0
velocit	0.000000
axis er	0

Tool/Step Running and testing the program

- Test the other actions that you have made by clicking the action buttons. Velocity 1 is running in the following picture.

Off1_3

Enable

Velocity 1

Position 1

Relative 1

Toggle move

Stop

Reset

Homing


ACSM1 MainControlWord

DF1	TRUE	INCHING_1	FALSE
DF2	TRUE	INCHING_2	FALSE
DF3	TRUE	REMOTE_CM	TRUE
DP_ENABLE	TRUE	START_HOM	FALSE
NO_REJECT	TRUE	PAR934	FALSE
NO_STOP	TRUE	PAR935	FALSE
TOGGLE	TRUE	PAR936	FALSE
RESET	FALSE	PAR937	FALSE

ACSM1 MainStatusWord

RDY_ON	TRUE	AT_SETPOIN	TRUE
RDY_RUN	TRUE	REMOTE	TRUE
RDY_REF	TRUE	TARGET	FALSE
TRIPPED	FALSE	HOMING_DC	FALSE
DF1_2_STA	TRUE	TRAY_ACK	FALSE
DF1_3_STA	TRUE	DRIVE_STOP	FALSE
SWC_ON_IN	FALSE	PAR942	FALSE
WARN_ALAR	FALSE	PAR943	FALSE

Axis StateMachine
axis1



Axis actual values	
axis1	
Position	1851.0000
velocity	181.0000
axis error	#000000000000000000

Starting up fieldbus communication and programming the ABB PLC (multi-axis systems)

What this chapter contains

This chapter presents the additional steps compared to the ones in the previous chapter that you must take during the start-up of the drive fieldbus control with ABB AC500 PLC and PROFIBUS DP adapter module in a multi-axis system. A system with two drives is set up here.

Equipment and programs

The equipment and programs used in this chapter are the same as in the previous chapter of this manual. They are listed under [Equipment and programs](#), page 30.

Tool/Step

Setting up the communication

Proceed in the start-up as described earlier in this manual up to page 50.


Tool/Step

Setting up the communication

CoDeSys

Configure communication with the SYCON fieldbus configurator


1. Open the project that you created.
2. Click the **Resources** tab to show the Resources folders.
3. Under **Tools**, double-click SYCON.net <R>.




Tool/Step Setting up the communication

SYCON.net

4. -> The SYCON.net tool opens:




5. From the **Network** menu, select the **Device Catalog...** command. Click the **Reload** button. -> PROFIBUS options appear in the ABB Oy folder. Click **OK**.




Tool/Step Setting up the communication

6. Drag and drop CM572-DPM on the green line. In the **netConnect-Driver Parameter** dialog box, select 1 for the **Board no:** box. This is because the CM572-DP communications module is installed next to the CPU on the left-hand side in the installation example of this manual.




7. Drag and drop the FPBA-01 DP-V0 two times on the purple line.



Tool/Step Setting up the communication


- In the **netDevice** field, right-click the CM572-DPM icon. Select **Configuration**. In the **Navigation area** field, click 3S Gateway Driver. Click the **Gateway Communication** button.




- In the **Communication Parameters** dialog box, set the communication parameters according to the serial port of your PC. See [Appendix A - How to find out the serial communication parameter values of your PC?](#)

Tool/Step Setting up the communication

- In the **Pages Three-View**, click Device Assignment. Activate the device by ticking it.




- In the **Pages Tree-view**, click Configuration / Bus Parameters. In the **Bus Parameters** dialog box, set the Boud Rate. If there is warning sign, click the **Adjust** button and set the other timing parameters.



Tool/Step Setting up the communication


12. In the **Pages Tree-view**, click Station Table under Configuration. Set the station address for the FPBA-01 fieldbus adapter modules. Click the **Apply** button and then **OK**.

Note: The station addresses here must be the same as the value of Parameter 51.02 FBA PAR2 in the drive control program. Set parameter Parameter 51.02 FBA PAR2 with DriveStudio.




Tool/Step Setting up the communication

13. Right-click the ABB Drives FPBA-01 icon connected to the purple line in the netDevice field. In the Navigation area field, click Modules in the Configuration folder. In the Available modules: box, select PPO-05. Click the **Insert** button and then **Apply** and **OK**. Do this for the both FPBA-01 units.



Tool/Step Setting up the communication

14. In the Configuration folder, click Parameters. Set the values of parameters Fail Safe mode and Control-zero mode as shown below.



Tool/Step Setting up the communication

15. In the **netConnect** field, click PPO-5, 4PKW + 10 PZD <Slot 1>. -> A list of inputs and outputs appears.

Name the signals. In this example configuration, Input_1 is named field_in1 and Output_1 field_out1.

Note: You can name all signals here and they will be automatically in use in the Control Builder.


Name of signal	Data ...	I/O	Name of v...
Input_1	SIGN...	I	field_in1
Input_2	SIGN...	I	
Input_3	SIGN...	I	
Input_4	SIGN...	I	
Output_1	SIGN...	O	field_out1
Output_2	SIGN...	O	
Output_3	SIGN...	O	
Output_4	SIGN...	O	
Input_5	SIGN...	I	
Input_6	SIGN...	I	
Input_7	SIGN...	I	
Input_8	SIGN...	I	
Input_9	SIGN...	I	
Input_10	SIGN...	I	
Input_11	SIGN...	I	
Input_12	SIGN...	I	
Input_13	SIGN...	I	
Input_14	SIGN...	I	

16. Name the signals in the same way for the second drive: Input_1 for field_in2 and Output_1 field_out2.

Name of signal	Data ...	I/O	Name of v...	Comment
Input_1	SIGN...	I	field_in2	PPO-05, 4 PKW +
Input_2	SIGN...	I		
Input_3	SIGN...	I		
Input_4	SIGN...	I		
Output_1	SIGN...	O	field_out2	PPO-05, 4 PKW +
Output_2	SIGN...	O		
Output_3	SIGN...	O		

Tool/Step Setting up the communication

17. Check that the PLC is in the Stop state (Stop in the display).
Note: The downloading is not possible if the PLC is in the Run state.
18. Download the communication configuration to the PLC: first, right-click the CM572-DPM icon and, then click **Download**.



19. When the downloading is completed, right-click the CM572-DPM icon and then click **Disconnect**.
20. Save the project with the **Save** command from the **File** menu.
21. Close the SYCON.net tool.

Programming the PLC main program

Programming of the PLC main program is described earlier in this manual beginning from page 63. For a system with two drives, program similar function blocks for both drives. In this case, main program for both drives is programmed inside actions, this is done to achieve more clear presentation of the program.

Note: Name every function block uniquely, otherwise the program will not work correctly.

A list of the Local variables is shown below.

The screenshot displays the CoDeSys software interface for a PLC program. The title bar reads "CoDeSys - demo2multi2.pro* - [PLC_PRG (PRG-FBD)]". The menu bar includes "File", "Edit", "Project", "Insert", "Extras", "Online", "Window", and "Help". The toolbar contains various icons for file operations and execution. The left pane shows the project structure with "POUs" containing "PLC_PRG (PRG)", which has sub-items "access_axis1", "access_axis2", and "toggle_movement". The main editor area shows the variable declaration section of the program, starting with "PROGRAM PLC_PRG" and "VAR".

```

0001 PROGRAM PLC_PRG
0002 VAR
0003   ton_1: TON;
0004   ton_2: TON;
0005   access_axis1: ACSM1_ACCESS_dc;
0006   Off1: BOOL;
0007   Off2: BOOL;
0008   Off3: BOOL;
0009   mc_reads: MC_ReadStatus;
0010   mc_readpos: MC_ReadActualPosition;
0011   mc_readaxise: MC_ReadAxisError;
0012   MC_Reset: MC_Reset;
0013   MC_Power: MC_Power;
0014
0015
0016   ton_1_2: TON;
0017   ton_2_2: TON;
0018   access_axis2: ACSM1_ACCESS_dc;
0019   Off2_2: BOOL;
0020   Off3_2: BOOL;
0021   Off1_2: BOOL;
0022   mc_reads2: MC_ReadStatus;
0023   mc_readpos2: MC_ReadActualPosition;
0024   mc_readaxise2: MC_ReadAxisError;
0025   mc_reset2: MC_Reset;
0026   mc_power2: MC_Power;
0027
0028   pause1: TON;
0029   trigger1: R_TRIG;
0030   pos_step: WORD;
0031   movement1: BOOL;
0032   movement2: BOOL;
0033   trigger2: R_TRIG;
0034   togglemove1: MC_MoveAbsolute;
0035   togglemove2: MC_MoveAbsolute;
0036   togglemove3: MC_MoveAbsolute;
0037   togglemove4: MC_MoveAbsolute;
0038   pause2: TON;
0039
0040 END_VAR

```

Below the variable declarations, a ladder logic diagram is visible, showing three rungs. Rung 0001 contains a box labeled "access_axis1". Rung 0002 contains a box labeled "access_axis2". Rung 0003 contains a box labeled "toggle_movement".

Programming the PLC main program


A list of the Global variables is shown below.

The screenshot shows the CoDeSys software interface for a project named 'demo2multi2.pro*'. The 'Global Variables' window is open, displaying a list of variables. The left pane shows a tree view of the project structure, with 'Global Variables' selected. The right pane shows the following list of variables:

Address	Variable Name	Data Type
0001	VAR_GLOBAL	
0002	axis1: AXIS_REF;	AXIS_REF
0003	off1_3: BOOL;	BOOL
0004	actual_pos_axis1: LREAL;	LREAL
0005	reset_axis1: BOOL;	BOOL
0006	enable_axis1: BOOL;	BOOL
0007	power_status_axis1: BOOL;	BOOL
0008		
0009		
0010	axis2: AXIS_REF;	AXIS_REF
0011	off1_3_2: BOOL;	BOOL
0012	actual_pos_axis2: LREAL;	LREAL
0013	reset_axis2: BOOL;	BOOL
0014	enable_axis2: BOOL;	BOOL
0015	power_status_axis2: BOOL;	BOOL
0016		
0017	move_toggle1: BOOL;	BOOL
0018	END_VAR	
0019		
0020		
0021		
0022		
0023		
0024		
0025		
0026		
0027		
0028		
0029		
0030		
0031		
0032		

Tool/Step Programming the PLC main program

The finished main program is shown below.




Tool/Step Programming the PLC main program

The screenshot displays the CoDeSys software interface for programming a PLC main program. The project tree on the left shows the structure: POU's > PLC_PRG (PRG) > access_axis1 > access_axis2 > toggle_movement. The main workspace is divided into several networks:

- Network 0001:** A ladder logic network starting with an AND block. The first input is 'access_axis2.ERR_REMOTE' and the second is 'off1_3_2'. The output of the AND block is connected to the IN input of a TON (Timer On Delay) block 'ton_1_2'. The PT (preset time) of 'ton_1_2' is '#200ms'. The Q output of 'ton_1_2' is connected to the IN input of another TON block 'ton_2_2'. The PT of 'ton_2_2' is also '#200ms'. The Q output of 'ton_2_2' is connected to 'Off1_2'.
- Network 0002:** A function block call for 'access_axis2' (ACSM1_ACCESS_dc). It has several inputs: 'field_in2' and 'field_out2' are connected to 'ADR' blocks, which then connect to 'field_in' and 'field_out' respectively. 'Off1_2', 'Off2_2', and 'Off3_2' are connected to 'OFF1', 'OFF2', and 'OFF3' inputs. 'axis2' is connected to the 'axis' input. There are also outputs for 'ERR_REMOTE' and 'ERR_PARA'.
- Network 0003:** A function block call for 'mc_read2' (MC_ReadStatus). The 'Enable' input is set to 'TRUE' and 'axis2' is connected to the 'axis' input. The block has multiple outputs: Error, ErrorID, Errorstop, Disabled, Stopping, StandStill, DiscreteMotion, ContinuousMotion, SynchronizedMotion, Homing, ConstantVelocity, Accelerating, and Decelerating.
- Network 0004:** A function block call for 'mc_readpos2' (MC_ReadActualPosition). The 'Enable' input is set to 'TRUE' and 'axis2' is connected to the 'axis' input. The 'Position' output is connected to 'actual_pos_axis2'.
- Network 0005:** A function block call for 'mc_readaxis2' (MC_ReadAxisError). The 'Enable' input is set to 'TRUE' and 'axis2' is connected to the 'axis' input. The block has outputs for Done, Error, ErrorID, and AxisErrorID.
- Network 0006:** A function block call for 'mc_reset2' (MC_Reset). The 'axis2' input is connected to the 'axis' input. The 'Execute' input is connected to 'reset_axis2'. The block has outputs for Done, Busy, Error, and ErrorID.
- Network 0007:** A function block call for 'mc_power2' (MC_Power). The 'enable_axis2' input is connected to the 'Enable' input and 'axis2' is connected to the 'axis' input. The 'Status' output is connected to 'power_status_axis2'. The block has outputs for Error and ErrorID.


Tool/Step **Programming actions**

Programming of the actions is described earlier in this manual beginning from page [77](#). For a system with two drives, program similar actions for the both axes: axis1 and axis2.



Tool/Step Programming actions

The program shown below controls a two-axis toggle movement. For a description of the toggle movement, refer to section *Program toggling between two positions*, page 84.



Tool/Step Programming actions

Add the action block toggle_movement to the main program.

The screenshot displays the CoDeSys software interface for editing a PLC program. The window title is "CoDeSys - demo2multi2.pro* - [PLC_PRG (PRG-FBD)]". The menu bar includes File, Edit, Project, Insert, Extras, Online, Window, and Help. The toolbar contains various icons for file operations and editing. The left pane shows the project tree with "POUs" expanded to "PLC_PRG (PRG)", which contains sub-items "access_axis1", "access_axis2", and "toggle_movement". The main editor shows the program code:

```

0001 PROGRAM PLC_PRG
0002 VAR
0003   ton_1: TON;
0004   ton_2: TON;
0005   access_axis1: ACSM1_ACCESS_dc;
0006   Off1: BOOL;
0007   Off2: BOOL;
0008   Off3: BOOL;
0009   mc_reads: MC_ReadStatus;
0010   mc_readpos: MC_ReadActualPosition;
0011   mc_readaxe: MC_ReadAxisError;
0012   MC_Reset: MC_Reset;
0013   MC_Power: MC_Power;

```

The ladder logic editor shows three rungs. Rung 0001 contains the "access_axis1" block. Rung 0002 contains the "access_axis2" block. Rung 0003 contains the "toggle_movement" block, which is highlighted with a red rectangular box. The status bar at the bottom indicates "Loading library" and "ONLINE | OV | READ".

Tool/Step Programming visualizations

Programming of the visualizations is described earlier in this manual beginning from page 89. An example visualization is shown below.

CoDeSys - demo2multi2.pro - [visu1]

File Edit Project Insert Extras Online Window Help

100 %

POUs
 PLC_FRG (PRG)
 toggle_movement

Off1_3_1 Off1_3_2

Enable_1 Enable_2

Toggle move Reset

Axis StateMachine

Axis StateMachine

5000.0 0.0

5000.0 -200.0 0.0 200.0

ACSM1 MainControlWord			
DF1	%s	INCHING_1	%s
DF2	%s	INCHING_2	%s
DF3	%s	REMOTE_CN	%s
DP_ENABLE	%s	START_HDM	%s
NO_REJECT	%s	PAR934	%s
NO_STOP	%s	PAR935	%s
TOGGLE	%s	PAR936	%s
RESET	%s	PAR937	%s

ACSM1 MainStatusWord			
RDY_ON	%s	AT_SETPOIN	%s
RDY_RUN	%s	REMOTE	%s
RDY_REF	%s	TARGET	%s
TRIPPED	%s	HOMING_DC	%s
DRIVE_STOP	%s	TRAV_ACK	%s
DRIVE_STOP	%s	DRIVE_STOP	%s
PAR942	%s	PAR942	%s
PAR943	%s	PAR943	%s

ACSM1 MainControlWord			
DF1	%s	INCHING_1	%s
DF2	%s	INCHING_2	%s
DF3	%s	REMOTE_CN	%s
DP_ENABLE	%s	START_HDM	%s
NO_REJECT	%s	PAR934	%s
NO_STOP	%s	PAR935	%s
TOGGLE	%s	PAR936	%s
RESET	%s	PAR937	%s

ACSM1 MainStatusWord			
RDY_ON	%s	AT_SETPOIN	%s
RDY_RUN	%s	REMOTE	%s
RDY_REF	%s	TARGET	%s
TRIPPED	%s	HOMING_DC	%s
DRIVE_STOP	%s	TRAV_ACK	%s
DRIVE_STOP	%s	DRIVE_STOP	%s
PAR942	%s	PAR942	%s
PAR943	%s	PAR943	%s

Tool/Step Running and testing the program

CoDeSys

Load and test the program as described earlier in this manual beginning from page 99.

Clicking order:

Click first both Off1_3 buttons and the both Enable buttons. -> The drives should start. Click the Toggle move button. -> The toggle movement should start.

The screenshot displays the CoDeSys software interface. On the left is a 'Resources' tree. The main workspace shows two 'Axis StateMachine' diagrams. Each diagram is a state transition graph with states: NCHRONIZE MOTION, DISCRETE MOTION, CONTINUOUS MOTION, STOPPING, ERROR/STO, HOMING, STANDSTILL, and DISABLED. Below the diagrams are two tables for 'ACSM1 MainControlWord' and 'ACSM1 MainStatusWord'.

ACSM1 MainControlWord				ACSM1 MainStatusWord			
DF1	TRUE	INCHING_1	FALSE	RDY_ON	TRUE	AT_SETPOINT	FALSE
DF2	TRUE	INCHING_2	FALSE	RDY_RUN	TRUE	REMOTE	TRUE
DF3	TRUE	REMOTE_CN	TRUE	RDY_REF	TRUE	TARGET	TRUE
OP_ENABLE	TRUE	START_HOM	FALSE	TRIPPED	FALSE	HOMING_DC	TRUE
NO_REJECT	TRUE	PAR934	FALSE	DF1_2_STA	TRUE	TRAV_ACK	TRUE
NO_STOP	TRUE	PAR935	FALSE	DF1_3_STA	TRUE	DRIVE_STOP	FALSE
TOGGLE	TRUE	PAR936	FALSE	SWC_ON_IN	FALSE	PAR942	FALSE
RESET	FALSE	PAR937	FALSE	WARN_ALARM	FALSE	PAR943	FALSE

Example program for a two-axis loading machine


What this chapter contains

This chapter presents an example sequence program which controls a loading machine with two axes.

Description of the machine

The machine loads boxes. The first axis loads ten items to each box and the second axis moves the filled boxes forward on a conveyor.

Diagram of the system



Description of the program


Loading sequence

The first axis toggles between positions 50 and 0. Every time when it does a forward movement, it pushes one item to a box. Thereafter, the axis moves backwards. When the first axis has finished one forward-backward movement, the second axis makes a movement of distance 10, and the next empty slot in the box comes in front of the machine's loading point. This way, the machine fills the 10 slots of the box.


When the loading sequence has repeated 10 times, the box is full. The program, then, moves the box a distance of 1000. This is the distance between the boxes. After this, the sequence starts again and fills the next box.

Program

The program for the toggle movement control is shown below.



Example program for a two-axis loading machine



Appendix A - How to find out the serial communication parameter values of your PC?


What this chapter contains

This chapter instructs how to find out the serial communication parameter values of your PC.

Tool/Step	How to find out the serial communication parameter values of your PC?
-----------	--

1. Go to Windows Control Panel and click the **System** icon.


Microsoft Windows




Tool/Step

How to find out the serial communication parameter values of your PC?

2. Click the **Hardware** tab and then the **Device Manager** button.




3. In the Ports (COM & LPT) folder, click Communications Port, which is connected to AC500, in this case port (COM1).



Tool/Step **How to find out the serial communication parameter values of your PC?**

4. The communication port settings are shown.



Further information

Product and service inquiries

Address any inquiries about the product to your local ABB representative, quoting the type designation and serial number of the unit in question. A listing of ABB sales, support and service contacts can be found by navigating to www.abb.com/drives and selecting *Sales, Support and Service network*.

Product training

For information on ABB product training, navigate to www.abb.com/drives and select *Training courses*.

Providing feedback on ABB Drives manuals

Your comments on our manuals are welcome. Go to www.abb.com/drives and select *Document Library – Manuals feedback form (LV AC drives)*.

Document library on the Internet

You can find manuals and other product documents in PDF format on the Internet. Go to www.abb.com/drives and select *Document Library*. You can browse the library or enter selection criteria, for example a document code, in the search field.



3AUA0000049359 Rev C / EN
EFFECTIVE: 2010-05-03

ABB Oy

Drives
P.O. Box 184
FI-00381 HELSINKI
FINLAND
Telephone +358 10 22 11
Fax +358 10 22 22681
www.abb.com/drives

ABB Inc.

Automation Technologies
Drives & Motors
16250 West Glendale Drive
New Berlin, WI 53151
USA
Telephone 262 785-3200
1-800-HELP-365
Fax 262 780-5135
www.abb.com/drives

ABB Beijing Drive Systems Co. Ltd.

No. 1, Block D, A-10 Jiuxianqiao Beilu
Chaoyang District
Beijing, P.R. China, 100015
Telephone +86 10 5821 7788
Fax +86 10 5821 7618
www.abb.com/drives