


NOTES:

- WARNING: This drawing does not illustrate completely the installation methods required for hazardous locations. Prior to any installation in a Classified Hazardous Location, verify installation methods by the Control Drawing referenced on the product's name tag and national and local codes.
- 2. To access wiring remove the End Cap of the explosion-proof unit




120VAC/230VAC HEATER

| ARR | TOTALFLOW | ACTION | DOC TYPE | TITLE NGC DUAL8200 COLD WEATHER ENCLOSURE | DWG NO. | REV | SHEET |
|-----|-----------|--------|----------|--|---------|-----|--------|
| | Products | L19649 | UD | WIRING INTERCONNECTS | 2103090 | AA | 6 OF 7 |

NOTES:

- WARNING: This drawing does not illustrate completely the installation methods required for hazardous locations. Prior to any installation in a Classified Hazardous Location, verify installation methods by the Control Drawing referenced on the product's name tag and national and local codes.
- 2. To access wiring remove the End Cap of the explosion-proof unit



CATALYTIC HEATER OPTION

| Γ | 40 | TOTAL FLOW | ACTION | DOC TYPE | TITLE | DWG NO. | REV | SHEET |
|---|-----|------------|--------|----------|-------------------------------------|---------|-----|--------|
| 4 | ABB | TOTALFLOW | | | NGC DUAL8200 COLD WEATHER ENCLOSURE | | | |
| | | Products | L19649 | UD | WIRING INTERCONNECTS | 2103090 | AA | 7 of 7 |