
Chapter	Page
Installation	1
<hr/>	
Commissioning	15
<hr/>	
References	45
<hr/>	
Index	47
<hr/>	
Customer feedback report	49
<hr/>	

Installation and commissioning manual

The chapter "Installation".

This chapter instructs the user how to install the protection terminal RET 521. The instructions covers mechanical, electrical and fiber optical installation, which has to be done before the commissioning work can be performed.

Introduction	3
Preparations	3
Receiving, unpacking and checking	3
Storage	3
Mechanical installation	3
19" rack installation	4
Single case installation	4
Side-by-side mounting	5
Flush mounting	6
Mounting procedure	7
Semi-flush mounting	7
Wall mounting	8
Case and cut-out dimensions	9
Electrical installation	10
Connectors for CT and VT circuits	10
Signal connectors	11
Safety and EMC earthing	13
Protection terminals with COMBITEST test switch	13
Fiber optic installation	13

1 Introduction

The mechanical and electrical environmental conditions at the installation site must be within the permissible range according to the data sheets of the terminal. Dusty, damp places, places liable to rapid temperature variations, powerful vibrations and shocks, surge voltages of high amplitude and fast rise time, strong induced magnetic fields or similar extreme conditions should be avoided.

Sufficient space must be available in front of and at rear of the terminal to allow access for maintenance and future modifications.

2 Preparations

2.1 Receiving, unpacking and checking

1 Remove the protection terminal from the transport case and perform a visual inspection of any possible transport damage.

Check that all items are included in accordance with the delivery documents. In case of transport damage, appropriate action must be taken against the last carrier and the nearest ABB office or agent should be informed. ABB should be notified immediately if there are any discrepancies in relation to the delivery documents.

2 Check that the terminal has the correct identity markings on the front.

The check should confirm that the terminal type, markings and serial number corresponds to what ordered.

2.2 Storage

If the protection terminal is to be stored before installation, this must be done in a dry and dust-free place, preferably in the original transport case.

3 Mechanical installation

The RET 521 protection terminal is built in the mechanical packaging system described in the Buyer's Guide. See "References" on page 45. See also .

Suitable mounting kits for 19" rack mounting, flush mounting, semi-flush mounting and wall mounting can be ordered. The mounting kits contains all parts needed for the mounting, including screws and assembly instructions.

3.1

19" rack installation

3.1.1

Single case installation





Fig. 1 RET 521 with side plate mounted in 19" rack

The mounting kit, article number 1MRK 000 020-BA for case size 6Ux3/4 consists of:

- one mounting angle for 6U, 19" rack, with four screws (TORX T20), pos (1) and (2)
- one mounting angle for 6U, with four screws (TORX T20) and a side plate suitable for case size 6Ux 3/4, pos (3) and (4)
- assembly instructions.

3.1.2

Side-by-side mounting



(98000030)

Fig. 2 Side-by-side mounting

The mounting kit, article number 1MRK 000 020-CA for side-mounting of one case size 6U x 3/4 and one case size 6Ux 1/4 consists of:

- two mounting angles for 6U, 19" rack, each with four screws (TORX T20), pos (1)
- two side-by-side mounting plates, each with with four screws (TORX T20), pos (3) and (4)
- assembly instructions.

3.2

Flush mounting




Fig. 3 Flush mounting

Mounting kit, article number 1MRK 000 020-Y, for flush-mounting of all sizes of case 6U consists of:

- four side holders and a sealing strip, pos (4) and (5)
- four small (TORX T10), pos (3), and four big screws (TORX T25), not shown
- assembly instructions.

Also see “Case and cut-out dimensions” .

3.2.1

Mounting procedure

- 1 Cut and affix the sealing strip if IP 54 is required.
- 2 Put the protection terminal in the cut-out.
- 3 Fasten the side holders to the back of the protection terminal with the small screws.
- 4 Fix the protection terminal with the big screws.

3.3


Semi-flush mounting

Fig. 4 Semi-flush mounting

The mounting kit, Article number 1MRK 000 020-AL, for semi-flush mounting of case size 6U x 3/4, consists of the same parts as the flush-mounting kit, plus a distance frame. The distance frame is mounted around the protection terminal case before it is placed in the terminal cut-out.

3.4

Wall mounting





Fig. 5 Wall mounting

Mounting kit, article number 1MRK 000 020-DA, for wall mounting of all sizes of case 6U consists of:

- two mounting angles (side plates), pos (3)
- screws (grip size TORX T20, T25 and T30), pos (4), (5) and (6)
- two mounting bars to be mounted on the wall, pos (2)
- assembly instructions.


3.5

Case and cut-out dimensions





Case size	A	B	C	D	E	F	G	H	I	J	K	L
6U x 1/2	265,9	223,7	204,1	245,1	255,8	205,7	190,5	203,7	—	227,6	—	189,7
6U x 3/4		336				318		316	—		—	302
6U x 1/1		448,3				430,3		426,3	465,1 ^{*)}		482,6	414,3

^{*)} equal to 19" (mm)



Case size	Cut-out dimensions	
	A ±1	B ±1
6U x 1/2	210,1	259,3
6U x 3/4	322,4	
6U x 1/1	434,7	

(mm)



(98000047)

Case size	A	B	C	D
6U x 1/2	292	267,1	272,8	390
6U x 3/4	404,3	379,4		
6U x 1/1	516	491,1		

(mm)

E = 247 mm

4 Electrical installation

The wiring from the cubicle terminals to the terminals on the rear side of the unit must be made in accordance with the established guidelines for this type of equipment. The wires for binary inputs and outputs and the auxiliary supply should be laid separated from the current and voltage transformer cables between the cubicle terminals and the protection terminal.

The external connections to the terminals of RET 521 shall be made in accordance with the valid terminal diagram. The cables from the current and voltage transformers should be identified with regards to phases and connected to the proper terminals.

4.1 Connectors for CT and VT circuits

Connectors X31 and X71 for current and voltage transformer circuits are so called “feed-through terminal blocks” and are designed for conductors with cross sectional area up to 4 mm².

4.2

Signal connectors

Signal cabling are connected to female screw compression connector, which in turn is connected to corresponding circuit board male connectors, sited at the rear of the unit.

At installation, all wiring to the female connector should be done before plugged into the male part and fixed to the case by screws. The conductors can be of rigid type (solid, stranded) or of flexible type

The female connectors can be used with conductors with a cross section area of 0.2-2.0 mm². If more than one conductor is used in the same screw terminal, the allowed cross section area is 0.2-1 mm².

If two conductors, each with area 1,5 mm² shall be applied to the same socket, a ferrule must be used. This ferrule, ABB article number 1MKC 840 003-4 or Phoenix type AI-TWIN 2 . 1,5 - 8 BK, is applied with crimping pliers type ZA3 from Phoenix. No soldering is needed.




Fig. 6 Signal connector




Fig. 7 Rear side of RET 521 with maximum number of connectors.

The number of connectors depends on the type of RET 521. Connectors which are not included are replaced with a blanking plate.

Table 1: Connectors and associated printed board assemblies

Connector	Location of PBA	Type of PBA (printed board assembly)
X31	P3	Analogue input module
X71	P7	Analogue input module
X81-X84	P8	Optical communication module
X91/X92	P9	Binary I/O module, or binary input module, or binary output module
X101/X102	P10	Same alternatives as for P9
X111/X112	P11	Same alternatives as for P9
X121/X122	P12	mA input unit or same alternatives as for P9
X141	P14	DC/DC converter module

Also see the terminal diagrams, part of the Technical descriptions manual, see “Reference publications” on page 45.

4.3 Safety and EMC earthing

To fulfill safety regulations and to get a full EMC protection, a separate flexible earthing wire must be connected the shortest possible route from the earthing screw at the rear of the terminal case to the nearest earthing point in the cubicle. The cubicle must be properly connected to the station earthing system.

4.4 Protection terminals with COMBITEST test switch

If RET 521 is provided with a COMBITEST test switch, COMBIFLEX wires are used to interconnect the test switch and the connection terminals on the rear side of the terminal. The wires have 20 A sockets on the end which is connected to the test switch. See the Buyer's Guide.

5 Fiber optic installation

The terminal can, if ordered accordingly, be equipped with optical SPA and LON communication. In such case optical ports are provided on the rear side of the case for connection of the optic fibres. Optical ports X81 and X82 are used for the SPA bus communication, and ports X83 and X84 are used for the LON bus communication.

Either plastic or glass fibres can be used. Plastic fibres use a snap-in connector, glass fibres a bayonet connector. Connectors are colour coded to help avoid making faulty connections. Blue or dark grey fibre connector always goes to blue or dark grey chassis connector, and is used for receiving data. Black or grey fibre connector always goes to black or grey chassis connector, and is used for transmitting data. Depending on the fibre type used, plastic or glass, the blue/black (plastic) or dark grey/grey (glass) connector colours are used.

Fibre optical cables are sensitive to handling. The most important to have in mind when handling optical fibres is that they must not be bent too sharply. The minimum curvature radius is:

- 5 cm for plastic fibres.
- 15 cm for glass fibres.



When connecting or disconnecting the optical fibres, be certain not to apply any force to the fibre itself. Always hold the contact in a firmly grip, without twisting, pulling or bending the optical fibre.

If the optical fibre is too long and cable straps have to be used, the cable strap must not be applied too hard. There should always be some space between the optical fibre and the cable strap.

The commissioning chapter

This chapter instructs the user how to perform the commissioning work. The commissioning work includes general testing of associated equipment, entering the configuration and setting values into the terminal, secondary injection testing and primary injection test.

Introduction	17
Preparations	17
General testing	17
Check of CT circuits	17
Check of VT circuits	18
Check of auxiliary voltage circuits	18
Check of binary input circuits	18
Check of binary output circuits	18
Check of trip circuits and circuit breakers	18
Generating setting and configuration values	19
Built-in human machine interface (HMI)	19
Front Communication	19
Remote Communication, SMS or SCS	20
Secondary injection testing	21
General	21
Set active group (GRP)	24
Restricted settings (BLOCKSET)	24
I/O system configuration (IOHW)	24
Configurable logic	25
Command function (CM/CD)	25
Transformer Differential protection (DIFP)	25
Three-phase time overcurrent protection (TOC)	26
Directional overcurrent function	26
Nondirectional overcurrent function	27
Restricted earth fault protection (REF)	27
Earth fault time current protection (TEF)	28
Directional earth fault current function	28
Check of the nondirectional current function	28
Single/three-phase overvoltage protection (TOV)	29
Check of the 3-phase overvoltage function	29
Check of the single-phase overvoltage function	29
Using TOV as neutral overvoltage protection	29
Single/three-phase time undervoltage protection (TUV)	30
Check of the 3-phase undervoltage function	30
Check of the single-phase undervoltage function	31
Thermal overload protection (THOL)	31

Overexcitation protection (OVEX)	32
Voltage control (VCTR)	33
Procedure	34
Secondary test	34
Check the activation of the Voltage Control Operation	34
Check the setting of parameter U_{min} and U_{max}	34
Overcurrent blocking	36
Load drop compensation function, LDC	36
Testing the LDC function	37
Voltage control of Parallel Transformers	38
Minimum Circulating Current (MCC) method	38
Event function (EV)	40
Disturbance Report (DRP)	40
Remote communication (RC)	41
Front communication	41
Communication via the rear ports	42
SPA communication	42
LON communication	42
Secondary testing of several setting groups	42
Check of the trip circuits	42
Primary injection test	42

1 Introduction

A number of checks must be carried out before the protection terminal is taken into service.

Secondary testing of RET521 is made to verify that the all protection functions operate in accordance with the relay setting plan.

Checking of external circuits and associated equipment, such as CT's and VT's, circuit-breakers and signalling equipment is part of the commissioning work.

The commissioning work must also be properly documented for future reference.

2 Preparations

Before the commissioning work is started up, check that all necessary test equipment and documentation are available at site. Necessary documentation for commissioning includes:

- operators manual for RET 521. See "References" on page 45.
- valid circuit diagrams.
- protection setting list and sheets for test protocols.

For secondary testing of RET 521, a test set with three-phase current and voltage outputs and time measuring function should be available. The magnitude and phase angle of the output currents and voltages should be variable. The FREJA computer aided test set according to the Buyer's Guide is recommended. See "References" on page 45.

3 General testing

3.1 Check of CT circuits

The CT's must be connected in accordance with the circuit diagram provided with the terminal, both with regards to phases and polarity. The following tests are recommended:

- primary injection test to verify the current ratio and the correct wiring up to the protection terminal for all current transformers and phases.
- polarity check.
- check of the earthing of the CT circuits.
- verification of data for the CT's.

CT circuits must be properly connected to the station earth and only at one electrical point.

A plotting of the excitation characteristic of the CT secondary windings will verify the data for saturation voltage and hence the performance of the CT.

Note!

Both primary and secondary side must be disconnected from line and terminal when plotting the excitation characteristics.



Check that the screen is earthed outside the cable current transformers used for measuring of earth-fault currents.

3.2

Check of VT circuits

The VT's must be connected in accordance with the circuit diagram provided with the terminal, both with regards to phases and polarity. The following checks should be made:

- check of the connection up to the protection terminal for all voltage transformers and all phases.
- polarity check.
- check of the earthing of the VT circuits.

3.3

Check of auxiliary voltage circuits

Check that the auxiliary voltage supplied to the DC/DC converter is in accordance with the data for the terminal and that the voltage has correct polarity.

3.4

Check of binary input circuits

Check the connections to the digital inputs so that both input levels and polarity are in accordance with terminal specifications.

3.5

Check of binary output circuits

Check the connections to the digital outputs so that both output loads and polarity are in accordance with terminal specifications.

3.6

Check of trip circuits and circuit breakers

The trip circuits are tested as part of the secondary injection test.

4 Generating setting and configuration values

All parameter settings can be made:

- locally, via the built-in human-machine interface (HMI) module
- locally, from a PC via the optical front connector, using SMS
- locally or remotely, via one of the ports on the rear, using SMS or SCS.

The configuration of functions and logics in RET 521 is made from the configuration tool CAP 531. This tool can be connected either to the front of the terminal or to the rear SPA-port.

4.1 Built-in human machine interface (HMI)

The setting access on the built-in HMI can be blocked by configuring a binary input to the HMI--BLOCKSET signal. When this signal is active, the LEDs can still be cleared from the front. This configuration can be performed only from the built-in HMI under the menu:

Configuration
BuiltInHMI

4.2 Front Communication

When a PC is used for connection to the front, you need the SMS-BASE and SM/RET 521. (For the collection of disturbances to a front connected PC, RECOM is not required because all necessary functionality is built in to SM/RET 521). The configuration tool CAP 531 is used for the configuration.

You must use a special interface cable for connecting your PC to the front of the terminal. This can be ordered from ABB Network Partner AB, order No. 1MKC 950 001-1. It is plugged into the optical contact on the left side of the built-in HMI. The other end of the cable is plugged directly into the serial port of the PC. The cable includes an optical contact, an opto/electrical converter and an electrical cable with a standard 9-pole D-sub contact. This gives you a disturbance-free and safe communication with the terminal.

When communicating with a PC, the setting of the slave number and baud rate (communication speed) must be equal in the program and in the terminal. Further instructions on how to set these parameters in the PC program is found in the SM/RET 521 user's manual, and the SMS-BASE user's guide. For more information see "References" on page 45.

The setting of the slave number and baud rate of the front port of the terminal is done on the built-in HMI at:

Configuration
SPAComm
Front

4.3**Remote Communication, SMS or SCS**

Setting can be performed via either of the optical ports at the rear of the terminal. When a PC is connected to the SMS system, SMS-BASE and SM/RET 521 are used. For the configuration, CAP 531 is used. For the collection of analogue data to a PC, RECOM is also required in the PC. Setting can also be done via the SCS based on MicroSCADA including the library module HV/RET 521.

For all setting and configuration via the optical ports on the rear, set the Setting Restrictions to Open. Otherwise, no setting is allowed via the rear communication ports. This setting applies for both the SPA port and the LON port. This parameter can only be set on the local HMI, and is located at:

Configuration
SPAComm
Rear
SettingRestrict

You can also permit changes between active setting groups with ActGrpRestrict in the same menu section.

When communicating with SMS or SCS via the SPA port, the setting of the slave number and baud rate (communication speed) must be equal in the computer program and in the terminal. Further instructions on how to set these parameters in the PC program is found in the SM/RET 521 user's manual, and the SMS-BASE user's guide. For more information see "References" on page 45.

The setting of the slave number and baud rate of the rear SPA port of the terminal is done on the built-in HMI at:

Configuration
SPA Comm
Rear

When communicating via the LON port, the settings are made with the LNT 505, LON Configuration Tool. See "Reference publications" on page 45 for details. The settings are shown on the built-in HMI at:

Configuration
LON Comm

From this menu, it is also possible to send the "ServicePinMessage" to the LNT. For further instructions, see the section "*Remote communication*" in the application manual.

5 Secondary injection testing

5.1 General

Secondary injection testing is a normal part of the commissioning. The operating value of all protection functions, the output to the proper trip and alarm contacts and the operation of digital input signals is checked and documented for future reference.

The connection of the test set to RET 521 is greatly simplified if the RTXP 24 test switch is included. When the test handle RTXH 24 is inserted in the test switch, preparations for testing are automatically carried out in the proper sequence, i.e. blocking of the tripping circuits, short-circuiting of the current circuits on the transformer side, opening of the voltage and current transformer circuits and making relay terminals accessible from the terminals on the test plug handle.

If RET 521 is not provided with a test switch, the terminal has to be tested in the proper way from external circuit terminals. Make sure that the instrument transformers are isolated from the circuits connected to the test set. The secondary phase terminals of the current transformers must be short-circuited to neutral before the circuit is opened if any current can flow on the primary side.

The testing requires a good understanding of the protection functions and the functional logic downloaded into the terminal. Several protection functions of the same type can be available within one RET 521, e.g. there are available three identical time-overcurrent functions. The commissioning engineer must be able to read out from the configuration diagram the connections from analog and digital inputs to the different protection functions and also the outputs from the functions to tripping and alarm relays.

A testing instruction is given for each type of protection function. In some cases, blocking of one stage, e.g. blocking of the high set stage when testing the low set stage, is used. The testing is performed in a sequence which secures that the blocked stage is released and tested. Blocking and releasing of stages are made in the setting menu and can be done on the built-in HMI.

Blocking or release of protection functions from digital input(s) shall, when included, be checked as a part of the secondary testing of the individual protection functions.

Before starting the test, go to the Test menu in the built-in HMI and activate the test mode with the setting:

Test

TestMode

Operation = On

When the setting has been saved, the test mode is activated and the yellow LED starts to flash.

When the test menu is activated, the setting:

DisturbReport**Operation = On**

has the effect that:

- information on start and trip is displayed on the built-in HMI.
- disturbances are stored.

The different protection functions can be individually blocked in the sub-menu:

Test**TestMode****BlockFunctions**

when the Test menu is activated. A slower back-up function can then be tested without interference from a faster function. E.g. with the setting BlockDÍFP = On, a three-phase time delayed over-current protection function with the same current inputs as the differential protection function can be conveniently tested.

In the Service Report/Functions menu, the start of the low or high set stage can be read when selecting the actual protection function and submenu FuncOutputs. For example, when function TOC1, low set stage of phase L1 operates, the reading in the built-in HMI changes to TOC1-STLSL1=1.

Note that RET 521 is designed for a maximum continuous current of four times rated value and a maximum continuous voltage of 1,5 times rated value.

below shows test set FREJA connected to the two-winding transformer terminal RET 521, Configuration No 1, for testing of protection functions connected to CT's and VT's on the delta (LV) side of the power transformer




Fig. 1 Example of Freja test set connection to RET 521

5.2**Set active group (GRP)**

Configure the GRP--ACTGRPn input signals to the corresponding binary inputs of a terminal and browse the local HMI for the information about the active setting group under the menu:

ServiceReport
ActiveGroup

Connect the appropriate dc voltage to the corresponding binary input of the terminal and observe the information presented on the HMI display. The displayed information must always correspond to the activated input. Check that corresponding output indicates the active group.

5.3**Restricted settings (BLOCKSET)**

- 1 **Configure the MMI--BLOCKSET functional input to the binary input, which is determined by the engineering or the input that is not used by any other function.**
- 2 **Set the setting restriction to SettingRestrict = Block.**
- 3 **Connect the rated control DC voltage to the selected binary input.**
- 4 **Try to change the setting of any parameter for one of the functions. Reading of the values must be possible. The terminal must not respond to any attempt to change the setting value or configuration.**
- 5 **Disconnect the control DC voltage from the selected binary input.**
- 6 **Repeat the attempt under item 1.4. The terminal must accept the changed setting value or configuration.**
- 7 **Depending on the requested design for a complete terminal, leave the function active or reconfigure the function into the default configuration and set the setting restriction function out of operation to SettingRestrict = Open.**

5.4**I/O system configuration (IOHW)**

I/O modules that are not configured are not supervised. When an I/O module is configured as a logical I/O module (AIM, BIM, BOM, IOM, or MIM), the logical I/O modules are supervised.

Each logical I/O module has an error flag that is set if anything is wrong with any signal or the whole module. The error flag is also set when there is no physical I/O module of the right type present in the connected slot.

When the error output is set, *Internal Fail* will be indicated and the erroneous module is pointed out under the HMI menu:

Terminal Status
SelfSuperv

5.5

Configurable logic

You can separately test configurable logic function blocks. To perform the test you must connect all:

- Input signals to the function block to the corresponding binary inputs.
- Output signals to the function block to the corresponding binary outputs of the terminal.

Then check the operation of each function block by applying the rated DC voltage to the corresponding binary inputs and observing the logic status of the corresponding binary outputs.

5.6

Command function (CM/CD)

For each Single Command (CD) function block, it is necessary to connect the output signals to corresponding binary outputs of the terminal. Each function block is then operated from the built-in HMI command menu. Change the function block configuration by using the CAP 531 configuration tool between Off, Not pulsed and Pulsed and observe the status/operation of the connected binary outputs.

Test of the Multiple Command (CM) function block is recommended to be performed in a system, that is, either in a complete delivery system as an acceptance test (FAT/SAT).

5.7

Transformer Differential protection (DIFP)

- 1 **Go to the Test/TestMode/BlockFunction menu and block the time earth-fault (TEF) and restricted earth-fault (REF) functions, which are configured to the same current transformer inputs as the transformer differential protection.**
- 2 **Connect the test set for injection of 3-phase current to the current terminals of RET 521 which are connected to the CT's on the HV side of the power transformer.**
- 3 **Increase the current in phase L1 until the protection function operates and note the operating current.**
- 4 **Check that trip and alarm contacts operate according to the configuration logic.**
- 5 **Decrease the current slowly from operate value and note the reset value.**

Depending of the power transformer vector group (Yd etc.), the single phase injection current may appear as differential current in one or two phases and the operating value of the injected single-phase current will be different.

- 6 Check in the same way the function by injecting current in phases L2 and L3.
- 7 Inject a symmetrical 3-phase current and note the operate value.
- 8 Connect the timer and set the current to twice the operate value.
- 9 Switch on the current and note the operate time.
- 10 Check in the same way the functioning of the measuring circuits connected to CT's on the LV side and other current inputs to the transformer differential protection.
- 11 Finally check that trip information is stored in the Event menu.

Information on how to use the event menu is found in the RET 521 operator's manual. See "References" on page 45.

The balancing of currents flowing into and out of the differential zone is checked by primary injection testing, See "Primary injection test" on page 42.

5.8

Three-phase time overcurrent protection (TOC)

5.8.1

Directional overcurrent function

- 1 Connect the test set for injection of symmetrical 3-phase currents to the appropriate current terminals of RET 521 and symmetrical 3-phase voltages to the appropriate voltage terminals.
- 2 Set the phase currents to lag the phase voltages by an angle equal to the set relay characteristic angle (rca) if forward directional function is selected.

If reverse directional function is selected, set the phase currents to lag the phase voltages by an angle equal to $rca + 180$ degrees.

- 3 Increase the current in phase L1 until the low set stage operates.
- 4 Decrease the current slowly and check the reset value.
- 5 Block high set stage if the injection current will activate the high set stage when testing the low set stage according to below.
- 6 Connect a trip output contact to the timer.
- 7 Set the current to 200 % of the operate value of low set stage , switch on the current and check the time delay.

For inverse time curves, check the operate time at a current equal to 110% of the operate current at t_{min} .

- 8 Check that trip and start contacts operate according to the configuration logic.
- 9 Reverse the direction of the injection current and check that the protection does not operate.
- 10 Check with low polarisation voltage that the function becomes nondirectional or blocked according to the setting.
- 11 Check in the same way the function for phases L2 and L3.
- 12 Release the blocking of the high set stage and check the operate and reset value and the time delay for the high set stage in the same way as for the low set stage.
- 13 Finally check that start and trip information is stored in the Event menu.

Information on how to use the event menu is found in the RET 521 operators manual. See “References” on page 45.

5.8.2

Nondirectional overcurrent function

Check in principle as instructed above, without applying any polarising voltage.

5.9

Restricted earth fault protection (REF)

- 1 Connect the test set for single-phase current injection to the protection terminals connected to the CT in the power transformer neutral-to-earth circuit.
- 2 Increase the injection current and note the operating value of the protection function.
- 3 Check that all trip and start contacts operate according to the configuration logic.
- 4 Decrease the current slowly from operate value and note the reset value.
- 5 Connect the timer and set the current to twice the operate value.
- 6 Switch on the current and note the operate time.
- 7 Connect the test set to terminal L1 and neutral of the 3-phase current input configured to the REF protection.

Increase the current injected in the neutral side, and note the operate value.
Decrease the current slowly and note the reset value.

- 8 Inject current into terminals L2 and L3 and note the operate and reset values.
- 9 Inject a current equal to 10 % of rated current into terminal L1.
- 10 Inject a current in the neutral-to-earth circuit with the same phase angle and with polarity corresponding to an external fault.
- 11 Increase the current to five times the operating value and check that the protection does not operate.
- 12 Finally check that trip information is stored in the Event menu.

Information on how to use the event menu is found in the RET 521 operators manual. See “References” on page 45.

5.10 Earth fault time current protection (TEF)

5.10.1 Directional earth fault current function

1 Connect the test set for single-phase current injection to the appropriate protection terminals.

If the function is configured to a 3-phase current input, connect the injection current to terminals IL1 and neutral.

2 Set the polarising voltage to 2% of rated voltage U_r and set the injection current to lag the voltage by an angle equal to the set relay characteristic angle (rca) if forward directional function is selected.

If reverse directional function is selected, set the injection current to lag the polarising voltages by an angle equal to rca +180 degrees.

3 Increase the current in phase L1 and note the operate value of the low set stage.

4 Decrease the current slowly and note the reset value.

5 Note the operating value when injecting current into terminals L2 and L3 with polarising voltage connected to terminals L2 respectively L3.

6 Block the high set stage if the injection current will activate the high set stage when testing the low set stage according to below.

7 Connect a trip output contact to the timer.

8 Set the current to 200% of the operate value of the low set stage, switch on the current and check the time delay.

For inverse time curves, check the operate time at a current equal to 110% of the operate current of t_{min} .

9 Check that all trip and start contacts operate according to the configuration logic.

10 Reverse the direction of the injection current and check that the protection does not operate.

11 Check that the protection does not operate when the polarising voltage is zero.

12 Release the blocking of the high set stage and check the operate, reset value and the time delay for this stage in the same way as for the low set stage.

13 Finally check that start and trip information is stored in the Event menu.

Information on how to use the event menu is found in the RET 521 operators manual. See "References" on page 45.

5.10.2 Check of the nondirectional current function

Check in principle as instructed above, without applying any polarising voltage.

5.11 Single/three-phase overvoltage protection (TOV)

5.11.1 Check of the 3-phase overvoltage function

- 1 Connect the test set for 3-phase voltage injection to the appropriate terminals.
- 2 Increase the voltage in phase L1 until the low set stage operates and note the operate value.
- 3 Decrease the voltage slowly and check the reset value.
- 4 Block of the high set stage if the injection voltage will activate the high set stage when testing the low set stage according to below.
- 5 Connect a trip output contact to the timer.
- 6 Set the voltage to 160% of the operate value of the low set stage, switch on the voltage and check the time delay.

For inverse time curves, check the operate time at a voltage equal to 110% of the operate voltage of t_{min} .

- 7 Check that all trip and start contacts operate according to the configuration logic.
- 8 Check in the same way the functions for phases L2 and L3.
If the function is configured to give trip only when all phase voltages exceed the limit, the time measurement is done with symmetrical 3-phase voltage injection.
- 9 Release the blocking of the high set stage and check the operate and reset value and the time delay for this stage in the same way as for the low set stage.
- 10 Finally check that start and trip information is stored in the Event menu.

Information on how to use the event menu is found in the RET 521 operators manual. See "References" on page 45.

5.11.2 Check of the single-phase overvoltage function

Connect a single-phase injection voltage the appropriate terminals and test the function in principle as stated above.

5.11.3 Usingf TOV as neutral overvoltage protection

- 1 Connect the test set for single-phase voltage injection to the appropriate protection terminals.

If the function is configured to a 3-phase voltage input, connect the single phase voltage input to terminals UL1 and neutral.

- 2 Increase the injection voltage until the low set stage operates and note the operate value.

Decrease the voltage slowly and note the reset value.

- 3 Connect the voltage to terminals U2 and then U3 and note the operate and reset values.
- 4 Block the high set stage if the injection voltage will activate the high set stage when testing the low set stage according to below.
- 5 Connect a trip output contact to the timer.
- 6 Set the voltage to 120 % of the operate value of the low set stage and check the time delay.

For inverse time curves, check one more point, e.g. at voltage 1,5 times the low set stage.

- 7 Check that all trip and alarm contacts operate according to the configuration logic.
- 8 Release the blocking of the high set stage and check the operate and reset value and the time delay for this stage in the same way as for the low set stage.
- 9 Finally check that start and trip information is stored in the Event menu.

Information on how to use the event menu is found in the RET 521 operators manual. See "References" on page 45.

5.12

Single/three-phase time undervoltage protection (TUV)

5.12.1

Check of the 3-phase undervoltage function

- 1 Connect the test set for 3-phase voltage injection to the appropriate terminals if the undervoltage function is configured to a 3-phase voltage input.

Start with a symmetrical 3-phase injection voltage higher than the high set stage.

- 2 Decrease the injection voltage in phase L1 until the high set stage operates and note the operating value.
- 3 Increase the voltage slowly and note the reset value.
- 4 Block the low set stage.
- 5 Set the symmetrical 3-phase voltage to 110% of the operate value of the high set stage, and connect a trip output contact to the timer.
- 6 Switch off the voltage in phase L1 and check the time delay tDefHigh.
- 7 Check that all trip and start contacts operate according to the configuration logic.
- 8 Check in the same way the functions for phases L2 and L3.
- 9 Release the low set stage and disconnect the trip input to the timer.

Start with a symmetrical 3-phase injection voltage higher than the low set stage.

- 10 Decrease the injection voltage in phase L1 until the stage the low set stage operates and note the operating value.
- 11 Increase the voltage slowly and note the reset value.
- 12 Set the symmetrical 3-phase voltage to 110% of the operate value of the high set stage, and connect a trip output contact to the timer.
- 13 Switch off the voltage in phase L1 and check the time delay t_{DefLow} .
- 14 Check that all trip and start contacts operate according to the configuration logic.
- 15 Check in the same way the functions for phases L2 and L3.
- 16 Finally check that start and trip information is stored in the Event menu.

Information on how to use the event menu is found in the RET 521 operators manual. See "References" on page 45.

5.12.2

Check of the single-phase undervoltage function

- 1 Connect a single-phase injection voltage to the input terminals.

The high and low set functions are in principle tested in the same way as described above for the 3-phase protection function.

5.13

Thermal overload protection (THOL)

- 1 Connect symmetrical 3-phase currents to the appropriate current terminals of RET 521.
- 2 Set the Time constant 1 and Time Constant 2 temporarily to 1 minute.
- 3 Set the 3-phase injection currents slightly lower than the set operate value of stage Ib1, increase the current in phase L1 until stage Ib1 operates and note the operate value.
- 4 Decrease the current slowly and note the reset value.
Check in the same way the operate and reset values of Ib1 for phases L2 and L3.
- 5 Activate the digital input for cooling input signal to switch over to base current Ib2.
- 6 Check for all three phases the operate and reset values for Ib2 in the same way as described above for stage Ib1.
- 7 Deactivate the digital input signal for stage Ib2.
- 8 Set the time constant for Ib1 in accordance with the setting plan.
- 9 Set the injection current for phase L1 to $1,50 \times Ib1$.
- 10 Connect a trip output contact to the timer and the output of contacts Alarm 1 and Alarm 2 to digital inputs in Freja.

Read the heat content in the thermal protection from the built-in HMI and wait until the content is zero.

-
- 11 Switch on the injection current and check that Alarm 1 and Alarm 2 contacts operate at the set percentage level and that the operate time for tripping is in accordance with the set Time Constant 1.**

With setting $I_{tr} = 101\% I_{bx}$ and injection current $1,50 \times I_{b1}$, the trip time from zero content in the memory shall be $0,60 \times \text{Time Constant 1}$.

- 12 Check that all trip and alarm contacts operate according to the configuration logic.**

- 13 Switch off the injection current and check from the service menu readings of thermal status and THOL LOCKOUT that the lockout resets at the set percentage of heat content.**

- 14 Activate the digital input for cooling input signal to switch over to base current I_{b2} .**

Wait 5 minutes to empty the thermal memory and set Time Constant 2 in accordance with the setting plan.

- 15 Test with injection current $1,50 \times I_{b2}$ the thermal alarm level, the operate time for tripping and the lockout reset in the same way as described for stage I_{b1} .**

- 16 Finally check that start and trip information is stored in the Event menu**

Information on how to use the event menu is found in the RET 521 operators manual. See "References" on page 45.

5.14

Overexcitation protection (OVEX)

- 1 Enable frequency measuring (FRME function)**

- 2 Connect a symmetrical 3-phase voltage input from the test set to the appropriate connection terminals if the overexcitation function is configured to a 3-phase voltage input.**

A single-phase injection voltage is applied if the function is configured to a phase-to-phase voltage input.

The function is conveniently tested using rated frequency for the injection voltage and increasing the injection voltage to get the desired overexcitation level.

- 3 Connect the alarm contact to the timer and set the time delay for the alarm temporarily to zero.
- 4 Increase the voltage and note the operate value Emaxcont.
- 5 Reduce the voltage slowly and note the reset value.
- 6 Set the alarm time delay to the correct value according to the setting plan and check the time delay, injecting a voltage corresponding to $1,2 \times E_{\text{maxcont}}$.
- 7 Connect a trip output contact to the timer and set the time delay tmin temporarily to 0,5 s.
- 8 Increase the voltage and note the operate value Emax.
- 9 Reduce the voltage slowly and note the reset value.
- 10 Set the time delay to the correct value according to the setting plan and check the time delay tmin, injecting a voltage corresponding to $1,2 \times E_{\text{max}}$.
- 11 Check that trip and alarm contacts operate according to the configuration logic.
- 12 Set the cooling time constant temporarily to min value (1min.) to empty the thermal content quickly.
- 13 Wait a time equal to 6 times Tcool, switch on a voltage $1,15 \times E_{\text{maxcont}}$ and check the inverse operate time.

Wait until the thermal memory is emptied, set the cooling time constant according to the setting plan and check another point on the inverse time curve injecting a voltage $1,3 \times E_{\text{maxcont}}$.

- 14 Finally check that start and trip information is stored in the Event menu.

Information on how to use the event menu is found in the RET 521 operators manual. See "References" on page 45.

5.15

Voltage control (VCTR)

Secondary currents have to be measured respectively. The function also includes an option for parallel control of power transformer based on the minimum circulating current method with terminal-to-terminal communication.

The busbar voltage UB is a shorter notation for the measured voltages Ua, Ub, Uc and Uij, where Uij is the phase-to-phase voltage, $U_{ij} = U_i - U_j$.

IL is a shorter notation for the measured load current; it is be used instead of the three phase quantities Ia, Ib, Ic or the two phase quantities Ii and Ij.

The VCTR in single operation mode assumes that the configuration consists of one tap changer on a single power transformer,

The test consists mainly in:

- 1 Changing the voltage at the analogue inputs of the protection , either increasing or decreasing it.
- 2 Checking that the corresponding signals (Lower or Raise) are issued by the voltage control function.

5.15.1**Procedure**

Before starting any test, check the set Output duration $t_{PulseDur}$ to be suitable to the actual tap changer step requirements.

5.15.2**Secondary test**

Regulating limits and actions.

Operation of VCTR.

When the load voltage, U_L , stays within the interval between $[U_1, U_2]$, no actions will be taken. If $U_L < U_1$ or $U_L > U_2$, a command timer will start (constant time or inverse time) The command timer will be running as long as the measured voltage stays outside the inner deadband, which is set to 70% of $U_{deadband}$ otherwise the command will be cancelled. This procedure will be repeated until the measured voltage is brought back within the inner deadband.

5.15.3**Check the activation of the Voltage Control Operation****1 Operation = 1**

(When the parameter Operation is = 0 the Voltage Control function is inoperative)

The test set is connected but no voltage is applied: The parameter "BlockCond" will be shown in the built in HMI (value = 1).

2 Check that the U_{set} corresponds to the system voltage.**3 Apply the corresponding voltage**

(three phase to ground or phase to phase voltage depending on the Function Selector setting; 0, 1, 2).

The parameter "Block Cond " in the Built in HMI will assume value 0 (zero).

4 Apply a voltage slightly below U_{block} :

The parameter "Block Cond " in the Built in HMI will assume value 1.

5.15.4**Check the setting of parameter U_{min} and U_{max}** **1 Decrease the applied voltage slightly below the U_{min} value**

The command will be inhibited independently of control mode

2 Increase the voltage to nominal value**3 Check the setting of parameter U_{\max}** **4 Increase the applied voltage slightly above the U_{\max} value**

The command will be inhibited independently of control mode. The VCTR function will try to decrease the voltage to nominal value U_{set} .

The delay time for operation will be time t2 (See setting of constant or inverse time characteristic).

5 Decrease the applied voltage about 1% below U_{set}

The VCTR function will try to increase the voltage to nominal value U_{set} .

After Time t1 has elapsed the RAISE output will show a positive voltage (value 1).

6 Repeat the operation increasing the applied voltage 1% above U_{set}

The VCTR function will try to decrease the voltage to nominal value U_{set} .

After time t1 has elapsed the LOWER output will show a positive voltage (value 1).

If the input signal DISC, indicating disconnected transformer is set High (=1) no automatic control function is allowed.

5.15.5**Overcurrent blocking****1 Inject a current higher than the Iblock setting.**

The VCTR function will be blocked and the parameter Iblock assume status 1. IBLK output will show a positive voltage (value 1). Both automatic and manual mode will be blocked.

Beside the status of the configured BOs, signals issued by the VCTR can be checked via the HMI in the Disturbance Report and Service Report.

5.15.6**Load drop compensation function, LDC**

This function can be tested directly with operational currents i.e. with the power transformer in service and loaded.

When the system is carrying load there will be a difference between the busbar voltage (transformer output) and the voltage at the load point. This difference is load dependent and can be compensated.

The load current is fed into the VCTR function where parameters corresponding to the line data for resistance and inductance are set.

The voltage drop calculated by the LDC will be proportional to the voltage drop in the system up to the load point.

In the terminal this voltage will be subtracted from the measured busbar voltage and the result, corresponding to the voltage at load point, presented to the VCTR function. This voltage will be lower than the U_{set} voltage and VCTR will increase the voltage in order to achieve the correct system voltage at the load point.

1 Set the line data (RL + j XL) for the LDC.**2 Check the position of the tap changer.****3 Read the busbar and load voltage in the HMI under Service Report**

Note the values and the difference. The voltage at the busbar will be the system voltage corresponding to U_{set}. At load point it will be lower than the system voltage.

4 Set R and XL for the LDC to 0 (Zero)**5 Check again busbar and load voltage in the in the HMI.**

a) Both shall be higher than the first readings. At load point it will be the system voltage and at the busbar the system voltage increased with the line voltage drop.

b) The VCTR will have operated.

6 Check the position of the tap changer.

5.15.7

Testing the LDC function

1 Check the correct setting of Uset and Udeadband

2 Switch the tap changer control to manual mode and step up to the correct tap changer position.

To determine whether the currents for the LDC are correctly oriented the transformer must be subject to a load.

3 Set R_{line} and X_{line} for the LDC to 0 (Zero).

4 Manually operate the tap changer so that the voltage at the transformer corresponds to the regulating value U_s .

Neither the "Raise" nor the "Lower" command shall be operating. (Check the configured BOs and the Event Report)

The test of the LDC should be carried out with a current at the time from the main transformers in L1 and L3 phase.

a) When measuring the current from the L1 phase the main CT in L3 phase must have its secondary winding short circuited and the cables to the RET terminal disconnected.

b) When measuring the current from the L3 phase the main current transformer in L1 phase must have its secondary winding shortcircuited and the cables to the terminal disconnected in the same way.

1 Increase slowly the setting of U_s until the RAISE output activates.

2 Modify the connections according to a) above

3 Set R_{line} and X_{line} to zero.

4 Increase slightly the setting U_s so that the RAISE output is on the verge of activation

The RAISE output will activate when either R_{line} or X_{line} will be set to the maximum value.

The operation can be checked at the corresponding binary output. and in the Event Report.

If the RAISE output does not activate reset both R_{line} and X_{line} to Zero and set U_{set} to a little lower value until the Lower circuit is on the verge of operation.

If the LOWER output activates when either R_{line} or X_{line} have a high setting the current circuits of the L1 phase are incorrect and must be reversed.

The operation can be checked at the corresponding binary output and in the Event Report.

5 Restore the original connections at the CT in phase T

6 Modify the connections according to b)

7 Increase slowly the setting of U_s until the "Raise" circuit is on the verge of operation.

8 Set R_{line} and X_{line} to zero.

9 Increase slightly the setting U_s so that the Raise function is on the verge of operation

The Raise circuit will operate when either R_{line} or X_{line} will be set to the maximum value.

The operation can be checked at the corresponding B.O. and in the Event Report.

10 Set back R_{line} and X_{line} to Zero.

11 Decrease slowly the setting of U_s until the "Lower" circuit is on the verge of operation.

12 Increase the setting of X_{line} to its maximum until the "Lower" circuit operates.

If the operation of Raise and Lower is inverted (Lower instead of Raise and Raise instead Lower) the current connections have to be reversed.

13 Restore the original connections at the CT in phase T

After these tests the individually operating RET 521 can be taken in to service

5.16

Voltage control of Parallel Transformers

5.16.1

Minimum Circulating Current (MCC) method

The method is used when more than one transformers are to be parallel controlled and complete load drop compensation is required. A maximum of four transformers can be controlled simultaneously.

To use this method, each transformer protection terminal must be connected to the station communication bus, in order to exchange data.

Check all settings and signals according to following tables:

- Settings Parallel Control
- Connectables
- Output signals Parallel Control
- Service Report Parallel Control

If all previous tests have been successful the VCTRs of the transformer group can be checked during load.

- 1 **Set Uset and Udeadband to the correct operate values.**
- 2 **Set the Overcurrent blocking level to the correct operate value.**
- 3 **Set R_{line} and X_{line} to 0**
- 4 **Set the parallel operation Off, i.e. parameter Operation PAR = Off**
- 5 **Set CtrlMode = Manual**
- 6 **Connect all transformers to the Busbar**
 - Step up the Tap Changer for transformer T1, two steps above the setting for the other transformers.
 - Change the setting of Uset to correspond to the manually determined busbar voltage. Check it in the:

Service report

VCTR/VoltLev

BusbarVoltage

- c) Set in all the parallel connected bays the parameter

OperationPAR = On

At transformer T1 adjust the parameter Comp so that the LOWER output is activated due to circulating current.

- 7 **Set back Uset to the correct setting and step down the tap changer to its normal position.**

If there are three transformers connected in parallel, and the tap changer of transformer T1 lies two steps over the tap changer of T2 and T3, the circulating current detected by the VCTR for T1 will be twice the current measured at T2 and T3.

If the voltage is close to the upper limit of the Udeadband the tap changer of T1 will try to decrease the controlled voltage, but in the opposite case, i.e. the voltage is close to the lower limit of Udeadband, the tap changer at T1 will not try to decrease the controlled voltage.

The tap changer for T2 and T3 will not operate due to the fact that the detected circulating current will be half of the current detected at T1.

The setting of the parameter Comp then might need to be increased a little.

- d) The setting of the parameter Comp at T2 and T3 will be carried out in the same manner as at T1. According to the described procedure when the Tap Changer of one transformer lies two steps above the others, it shall automatically step down.

When there are only two transformers in the group either shall one step down or the other step up depending on the voltage level at the VCR.

At least one Tap Changer step difference between the different transformers should be allowed in order to avoid the Tap Changers to operate too often.

If the allowed difference is for example two steps, the Tap Changer shall be stepped up three steps when setting parameter Comp.

This applies to all the VCR in the same group.

After test under 6.4.1 has been carried out the VCR can be put in service.

- 1 Check again the correct settings of Uset, Udeadband, the sending and receiving intervals TXINT and RXINT, the blocking settings for overcurrent and undervoltage, the compensating parameters R_{line} and X_{line} .**
- 2 Switch back to CtrlMode = 1 for automatic operation and set the parameter OperationPAR = 1 for parallel control of the tap changers.**

5.17

Event function (EV)

During testing, the terminal can be set in Test Mode from the SMS. The functionality of the event reporting during Test Mode is set from the SMS as follows:

- *Use event masks*; the normal reporting of events, that is, the events are reported as defined in the database. An event mask can be set individually for each available signal in the terminal. The setting of the event mask can only be performed from the SMS. All event mask settings are treated commonly for all communication channels of the terminal.
- *Report no events*; means blocking of all events in the terminal.
- *Report all events*; means that all events, that are set to OnSet/OnReset/OnChange are reported as OnChange, that is, both at set and reset of the signal. For double indications when the suppression time is set, the event ignores the timer and is reported directly. Masked events are still masked.

Test of the Event function blocks are recommended to be performed in a system, that is, either in a complete delivery system as an acceptance test (FAT/SAT).

5.18

Disturbance Report (DRP)

The function can preferably be tested when tests of other functions are carried out. Test of other functions will generate suitable trig conditions, events and analogue quantities for the disturbance recorder.

The following points should be checked:

- the function operates when enabled and does not operate when disabled.
- events are recorded and the capacity is correct.
- indications are available.
- trip values correspond to the injected quantities.
- re-trig operates when enabled and does not when disabled.
- recording times including the limit time.

In case the optional disturbance recorder is included, the following should be checked:

- recording is generated for all trig conditions.
- recording can be retrieved with RECOM and can be analysed using REVAL.

5.19

Remote communication (RC)

5.19.1

Front communication

The front communication function is a standard function in the RET 521 terminal. For the communication the following is required:

- a special interface cable, optically isolating the PC from the terminal, which minimises interference
- a PC with suitable software installed, as listed below.

Suitable software:

- SMS-BASE (for application structure and communication)
- SM/RET 521 (function library for reading settings and information and changing parameter values)
- RECOM (for retrieving disturbance files)
- REVAL (for displaying disturbance files)
- CAP531 (configuration software)
- CAP/RET 521 (function library for configuration).

The communication shall work properly provided that

- the slave number and baud rate values match each other in the terminal, SMS-BASE, RECOM and/or CAP 531.
- communication parameters are correctly set in SMS-BASE. RECOM and/or CAP 531.

5.19.2 Communication via the rear ports

5.19.2.1 SPA communication

SPA communication is normally used by SMS. The communication link is optical fibre within the substation and switched telephone network for communication outside the substation.

The test can only be carried out when the whole communication system is installed. Thus, the test is a system test and is not dealt with here.

5.19.2.2 LON communication

LON communication is normally used by SCS. The communication link is optical fibre within the substation.

The test can only be carried out when the whole communication system is installed. Thus, the test is a system test and is not dealt with here.

5.20 Secondary testing of several setting groups

All secondary testing of the functions in one setting group should be made before starting to test the next group.

5.21 Check of the trip circuits

Check that the circuit breakers of the power transformer operate when the tripping relays are activated. The trip relays are conveniently activated by secondary injection to activate a suitable protection function.

6 Primary injection test

A test with primary current through the power transformer constitutes a final check that the current circuits are correctly connected and balanced so that the currents in the differential circuits will be small in the case of a fully operational power transformer. The overcurrent protection on the injection side should be activated with a short time delay on the low set stage and the differential protection blocked when performing the test.

1 Apply a three-phase injection voltage source outside the current transformers on one side of the power transformer and a three-phase short-circuit outside the current transformers on the other side of the power transformer.

The injection current I_{inj} in per cent of rated transformer current on the injection side will be

$$I_{inj} = 100 / Z_k \times U_1 / U (\%)$$

where Z_k = short-circuit impedance in per cent and U_1 / U is the ratio between rated voltage of the power transformer on the injection side and the injection voltage.

The injection current should be at least 10% of rated transformer current and the differential current in all phases should be negligible. If the differential current is small, check the influence of the tap-changer position.

A differential current equal to twice the injection current probably indicates wrong polarity of the CT's on one side. A differential current in all three phases equal to the injection current probably indicates a configuration not corresponding to the connection group of the power transformer.

2 Set the time delay of the low set stage in accordance with the setting plan and release the differential function when satisfactory balance is obtained.

The power transformer can now be connected to the network.



Reference publications

Buyer's Guide, Series RE 500 Mechanical design and mounting accessories,
1MRK 514 003-BEN

Buyer's Guide, Combiflex Connection and installation components,
1MRK 513 003-BEN

User's manual SM/RET 521*2.1 1MRK 511 063-UEN*2.1-00

User's Guide SMS-BASE 1MRS 750 146-ESD

User's Guide CAP 531*1.3 1MRK 511 056-UEN

User's Guide CAP/RET 531*2.1 1MRK 511 060-UEN

Operator's manual RET 521*2.1 1MRK 504 012-UEN*2.1-00

Technical description manual RET 521*2.1 1MRK 504 012-UEN*2.1-00

LNT 505, LON Configuration Tool, 1MRS 151 400

SLDT, LON configuration module REx 500, 1MRK 001 700-A

Symbols

"feed-through terminal blocks" 10

Numerics

3-phase overvoltage function 29
3-phase undervoltage function 30

A

acceptance test (FAT/SAT) 25, 40
ActGrpRestrict 20
associated printed board assemblies 12
auxiliary voltage circuit 18

B

baud rate 19
baud rate of the front port 19
bayonet connection 13
blanking plate 12
BlockFunctions 22
built-in HMI 19

C

cable straps 13
CAP/RET 521 41
Check of auxiliary voltage circuits 18
Check of CT circuits 17
Check of the tripping circuits 42
Check of tripping circuits 18
Check of VT circuits 18
collection of disturbances 19
COMBIFLEX wires 13
COMBITEST test switch 13
Command function (CM_D) 25
communicating with SMS or SCS 20
communication speed 19
Configurable logic (CL) 25
configurable logic circuits 25
configuration tool CAP 531 19
configuration values 19
connection of the test set 21
Connector
 X101/X102 12
 X111/X112 12
 X121/X122 12
 X141 12
 X31 12
 X71 12
 X81-X84 12
 X91/X92 12
Connectors for CT and VT circuits 10
crimping pliers type ZA3 11
CT circuit 17

D

DC/DC converter 18
digital input signals 21
Directional earth fault current function 28
Directional overcurrent function 26

distance frame 7
Disturbance Report (DRP) 40
disturbance-free 19

E

Earth fault time current protection (TEF) 28
earthing of the CT circuits 17
earthing screw 13
Electrical installation 10
EMC earthing 13
Event function (EV) 40
excitation characteristics 18

F

feed-through terminal blocks 10
Fiber optic installation 13
Flush mounting 6
flush mounting 3
FREJA computer aided test set 17
Front Communication 19

G

General testing 17

H

HMI--BLOCKSET signal 19
human-machine interface (HMI) 19

I

I/O system configuration (IOHW) 24
injection current 43

L

LEDs 19
library module HV/RET 521 20
local HMI 20
Location of PBA
 P10 12
 P11 12
 P12 12
 P14 12
 P3 12
 P7 12
 P8 12
 P9 12
logical I/O module 24
LON Comm 20
LON communication 42
LON Network Tool 20
LON port 20

M

Mechanical installation 3
 mechanical packaging system 3
 Suitable mounting kits 3
MicroSCADA 20
minimum curvature radius 13

mounting kits 3
Mounting procedure 7
Multiple Command function 25

N

Neutral time voltage protection (NOV) 29
nondirectional current function 28
Nondirectional overcurrent function (TOC) 27
number of connectors 12

O

OnChange 40
OnReset 40
OnSet 40
optic fibres 13
optical front connector 19
optical ports 13
opto/electrical converter 19
Overexcitation protection (OVEX) 32

P

parameter settings 19
Phoenix type AI-TWIN 2 . 1,5 - 8 BK 11
polarity check 17
ports on the rear 19
primary current 42
Primary injection test 42
primary injection test 17
printed board assembly
 Analog input module 12
 Binary I/O module 12
 binary input modul 12
 binary output module 12
 DC/DC converter module 12
 mA input unit 12
 Optical communication module 12
protection setting list 17

R

rack installation 4
rear communication ports 20
rear SPA port 20
RECOM 19
Remote Communication 20
Remote communication (RC) 41
 Communication via the rear ports 42
Report all events 40
Report no events 40
Restricted earth fault protection (REF) 27
REVAL 41
RTXH 21 21
RTXP 21 21

S

safe communicatio 19

Safety and EMC earthing 13
SCS 19
Secondary injection testing 21
secondary testing 17
Secondary testing of several setting groups 42
Self Superv 24
semi-flush mountin 3
Semi-flush mounting 7
serial port of the PC 19
ServicePinMessage 20
setting of the slave number 19
SettingRestrict 20
Side-by-side mounting 5
Signal connectors 11
Single case installation 4
Single Command function 25
Single/three-phase overvoltage protection 29
Single/three-phase time undervoltage protection (TUV) 30
single-phase O/V function 29
single-phase undervoltage function 31
slave number 19
SM/RET 521 19
SMS 19
SMS-BASE 19
snap-in connection 13
SPA bus communication 13
SPA communication 42
SPA port 20
SPA-port 19

T

Test Mode 22
Test of the Event function 40
test se 17
The operating value 21
Thermal overload protection (THOL) 31
three-phase injection 42
Three-phase time overcurrent protection (TOC) 26
time measuring function 17
Transformer Differential protection (DIFP) 25
trig conditions 41
trip and alarm contacts 21

U

Use event masks 40

V

valid circuit diagrams 17
VT circuit 18

W

Wall mounting 8
wall mounting 3

Product:

ABB Automation Products AB would appreciate your comments on this product. Please grade the following questions by selecting one alternative per category. Your answer will enable us to improve our products.

How do you grade the quality of the product?

	Exellent				Poor
Total impression	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Useability	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Functionality	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Human machine interface (HMI)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Comments: _____

How do you grade the quality of the documentation?

	Exellent				Poor
Total impression	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Layout	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Illustrations	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Readability	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Easy to find	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Content structure	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

Comments: _____

Customer feedback report

Suggestions on improvments:

[illegible]

Please send this report to:

ABB Automation Products AB
Division Substation Automation
Dept. TMD4
S-721 59 Västerås
Sweden