



Fluorescent Bulb Sleeve

This accessory is for use with 7 and 9 watt compact fluorescent light bulbs installed in Midwest Electric PARKMATE™, PARKRANGER™, DOCKMASTER™, and DOCKMATE™ pedestals (also used in HARBORLIGHT™ fixtures).

Installation Instructions

- Turn power OFF to lamp socket
- Remove bulb cover/lens (5/16" nut driver)
- Remove fluorescent bulb (if present)
- Slide sleeve over bulb up to the edge of plug (as shown)
- Install bulb/sleeve assembly into lamp socket
- Replace bulb cover/lens
- Turn power back ON

