

INSTALLATION INSTRUCTIONS

ReliaMod™ Modular Metering

RENCLGANG



**HAZARDOUS VOLTAGE.
WILL CAUSE SEVERE
INJURY OR DEATH.**

Turn OFF power supplying this equipment before working inside.

Please read these instructions completely before installing or removing device. Improper installation could be hazardous to personnel and/or equipment.

Kit Contains:

Ganging Bolt	2
Ganging Nut	2




Right Enclosure



Left Enclosure

- Turn “OFF” power supplying the meter module.
- Slide the clip of the ganging bolt to the top slot of the gangway opening on the left-hand side of the enclosure.
- Repeat for the bottom slot of the gangway opening on the lefthand side of the enclosure.
- Slide the modules together, assuring main busbars intertwine, and the ganging bolts go through holes of the left-side module.
- Install the ganging nut to both locations.
- Torque to 26 in-lbf.
- Ensure the embosses on the left and right ganging plates are touching to assure proper enclosure ganging



Emboss on ganging brackets

INSTRUCCIONES DE INSTALACIÓN

ReliaMod™ Modular Metering

RENCLGANG



**VOLTAJE PELIGROSO.
PODRA CAUSAR MUERTE
O LESIONES SERIAS.**

Desconecte la alimentación eléctrica de este equipo antes de realizar cualquier trabajo dentro o fuera de él.

Lea atentamente estas instrucciones antes de instalar o retirar el dispositivo. Una instalación incorrecta podría resultar peligrosa para el personal y/o el equipo.

El kit contiene:

Perno de agrupamiento	2
Tuerca de agrupamiento	2



Panel derecho



Panel izquierdo

- Desconecta la alimentación del módulo de medidor.
- Deslica el clip del perno de agrupamiento a la ranura superior de la abertura en el lado izquierdo del panel.
- Repita el procedimiento para la ranura inferior de la abertura en el lado izquierdo del panel.
- Deslica los módulos entre sí, asegurándose de que las barras principales se entrecruzen y de que los pernos de agrupamiento pasen por los orificios del módulo del lado izquierdo.
- Instala la tuerca de agrupamiento en ambas ubicaciones.
- Aprieta a 26 in-lbf.
- Asegúrese de que las estampas de las placas de agrupamiento izquierda y derecha estén en contacto para garantizar una agrupamiento correcto del panel.



Estampas en los soportes de agrupamiento