



JULY 2020

KNX LED Dimmer UD/S 2x315W/4x315W/6x315W

Webinar – Competence Center Europe – Smart Buildings

Thorsten Reibel, Jürgen Schilder, Stefan Grosse, Martin Wichary & Olaf Stutzenberger

Agenda

KNX LED Dimmer UD/S 2x315W/4x315W/6x315W

Introduction and general product information

Main functions and benefits

ETS application

ABB i-bus[®] Tool

Commercial data

KNX LED Dimmer UD/S 2x315W/4x315W/6x315W

Introduction and general product information

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

General product information

Typical application examples

Applications in residential buildings:

- Realize a warm and cozy atmosphere in the living room by dimming the light down
- Dimming the light in the bathroom
 - Bright light for making up in the morning
 - Darker, relaxing light to take a bath in the evening
- Wake up with sunrise simulation (wake up function)
- Sleep function

Applications in commercial buildings:

- Realize constant light control in offices
- Dim down the light in the meeting rooms when presentations are held



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

Technical Data

LED Dimmer 2-fold, 315W/VA

- Outputs: 2, individual L and N per channel
- Rated power: 2-315 W/VA
- Dimensions 90 mm x 72 mm x 64 mm
- Mounting depth 64 mm
- Module width: 4 MW
- Power supply 110-230 V AC +/- 10%, 50/60 Hz
- Channel bridging:

4 MW - 2 Channel, 2x1	A	B
4 MW - 2 Channel, 1x2	A + B 500/200 W/VA	



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

Technical Data

LED Dimmer 4-fold, 315W/VA

- Outputs: 4, individual L and N per channel
- Rated power: 2-315 W/VA
- Dimensions 90 mm x 144 mm x 64 mm
- Mounting depth 64 mm
- Module width: 8 MW
- Power supply 110-230 V AC +/- 10%, 50/60 Hz
- Channel bridging:

8 MW - 4 Channel, 4x1	A	B	C	D
8 MW - 4 Channel, 2x2	A + B 500/200 W/VA		C + D 500/200 W/VA	



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

Technical Data

LED Dimmer 6-fold, 315W/VA

- Outputs: 6, individual L and N per channel
- Rated power: 2-315 W/VA
- Dimensions 90 mm x 216 mm x 64 mm
- Mounting depth 64 mm
- Module width: 12 MW
- Power supply 110-230 V AC +/- 10%, 50/60 Hz
- Channel bridging:

12 MW - 6 Channel, 6x1	A	B	C	D	E	F
12 MW - 6 Channel, 3x2	A + B 500/200 W/VA		C + D 500/200 W/VA		E + F 500/200 W/VA	
12 MW - 6 Channel, 2x3	A + B + C 700/250 W/VA			D + E + F 700/250 W/VA		
12 MW - 6 Channel, 1x3, 1x2, 1x1	A + B + C 700/250 W/VA			D	E + F 500/200 W/VA	
12 MW - 6 Channel, 1x3, 1x2, 1x1	A + B 500/200 W/VA		C	D + E + F 700/250 W/VA		



Webinar "KNX LED Dimmer UD/S 2x315W/4x315W/6x315W"

Technical Data

Operating mode: Leading edge control

	[A]	[B]	[C]	[A]	[B]	[C]	[A]	[B]	[C]	[D]
	110 V 127 V 230 V	110 V 127 V	230 V	— — 230 V	110 V 127 V	230 V	110 V 127 V 230 V	110 V 127 V	230 V	
	min.	max.	max.	min.	max.	max.	min.	max.	max.	
LEDi 230 V AC	2 W/VA	40 W/VA	80 W/VA	2 W/VA	60 W/VA	120 W/VA	20 W/VA	240 W/VA	480 W/VA	 ← Leading edge
LED	2 W/VA	40 W/VA	80 W/VA	2 W/VA	60 W/VA	120 W/VA	20 W/VA	240 W/VA	480 W/VA	
LED	2 W/VA	105 W/VA	210 W/VA	2 W/VA	160 W/VA	315 W/VA	20 W/VA	630 W/VA	1260 W/VA	
	1			2			3			

LEDi 230 V AC	230 V LEDi retrofit with inductive L ballast	1 UD/S (210W)
LED	Low-voltage LED on electronic LC transformers	2 UD/S (315W)
LED	Low-voltage LED on inductive L transformers	3 6197/52 (1260W)

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

Technical Data

Operating mode: Trailing edge control

	[A]	[B]	[C]	[A]	[B]	[C]	[A]	[B]	[C]	[D]
	110 V 127 V 230 V	110 V 127 V	230 V	— — 230 V	110 V 127 V	230 V	110 V 127 V 230 V	110 V 127 V	230 V	
	min.	max.	max.	min.	max.	max.	min.	max.	max.	
LEDi 230 V AC	2 W/VA	105 W/VA	210 W/VA	2 W/VA	160 W/VA	315 W/VA	20 W/VA	630 W/VA	1260 W/VA	<p>Trailing edge</p>
LED	2 W/VA	105 W/VA	210 W/VA	2 W/VA	160 W/VA	315 W/VA	20 W/VA	630 W/VA	1260 W/VA	
230 V AC	10 W	105 W	210 W	10 W	160 W	315 W	40 W	630 W	1260 W	
	1			2			3			

LEDi 230 V AC	230 V LEDi retrofit with capacitive C ballast	1 UD/S (210W)
LED	Low-voltage LED on electronic C transformers	2 UD/S (315W)
230 V AC	230 V halogen lamps	3 6197/52 (1260W)

KNX LED Dimmer UD/S 2x315W/4x315W/6x315W, MDRC



Main functions and benefits

Webinar “KNX LED Dimmers UD/S 2x315W/4x315W/6x315W”

Main functions and benefits

Functions and Configuration

- Different type of loads as well as automatic load detection selectable
- All standard dimming parameters like brightness values, lower and upper dimming limits, dimming speed feedback objects, etc.
- Channel bridging to increase the connectable load per channel
- Template function to save time in programming
- Easy scene concept
- Free-adjustable dimming curve correction
- Generator-operation
- Wake-up function
- Automatic load detection after power failure can be switched off
- Staircase lighting, delay and further logic functions
- ABB i-bus® Tool for easy commissioning




Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

Main applications

Commissioning and diagnostics

Several testing, diagnostic and failure feedback possibilities can be used with the ABB i-bus® Tool

- Testing of the different dim modes
- Trying different min and max values when adjusting the lamps
- What kind of failure has occurred?
- Which channel is affected?
- Etc.



KNX LED Dimmer UD/S 2x315W/4x315W/6x315W, MDRC

ETS application

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Functions and parameter

Main functions:

- Channel allocation
- 32 scenes
- Template / parameter master
- Central commands for switching, dimming and value
- Correction of characteristic
- Wake-up and sleep function
- Logic functions

--- UD/S6.315.2.11 LED Dimmer 6x315W > Channel allocation

Channel allocation

i Allocation of the physical outputs for logical KNX channels

Bundling outputs (parallel switching)

Output A	Channel A
Output B	Channel B
Output C	Channel C
Output D	Channel D
Output E	Channel E
Output F	Channel F

+ Device settings

+ Scenes

+ Parameter masters

+ Channel A

+ Channel B

+ Channel C

+ Channel D

+ Channel E

+ Channel F

+ General functions

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Channel allocation – 6 x 315W

Easy channel bridging to increase the rated power

Max. 3 channels can be bundled

12 MW - 6 Channel, 6x1	A	B	C	D	E	F
12 MW - 6 Channel, 3x2	A + B 500/200 W/VA		C + D 500/200 W/VA		E + F 500/200 W/VA	
12 MW - 6 Channel, 2x3	A + B + C 700/250 W/VA			D + E + F 700/250 W/VA		
12 MW - 6 Channel, 1x3, 1x2, 1x1	A + B + C 700/250 W/VA			D	E + F 500/200 W/VA	
12 MW - 6 Channel, 1x3, 1x2, 1x1	A + B 500/200 W/VA		C	D + E + F 700/250 W/VA		

UD/S6.315.2.11 LED Dimmer 6x315W > Channel allocation

Channel allocation

Allocation of the physical outputs for logical KNX channels

Bundling outputs (parallel switching)

Output A Channel A

Output B Channel A Channel B

Output C Channel A

Output D Channel C Channel D

Output E Channel D Channel E

Output F Channel D

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Channel allocation – 4 x 315W

Easy channel bridging to increase the rated power

Max. 2 channels can be bundled

8 MW - 4 Channel, 4x1	A	B	C	D
8 MW - 4 Channel, 2x2	A + B 500/200 W/VA		C + D 500/200 W/VA	

1.1.19 UD/S4.315.2.11 LED Dimmer 4x315W > Channel allocation

Channel allocation

Allocation of the physical outputs for logical KNX channels

Bundling outputs (parallel switching)

Output A

Output B Channel A Channel B

Output C

Output D Channel C Channel D

- + Device settings
- + Scenes
- + Parameter masters
- + Channel A
- + Channel B
- + Channel C
- + General functions

Webinar "KNX LED Dimmers UD/S 2x315W/4x315W/6x315W"

ETS application

Channel allocation – 2 x 315W

Easy channel bridging to increase the rated power

Max. 2 channels can be bundled

4 MW - 2 Channel, 2x1	A	B
4 MW - 2 Channel, 1x2	A + B 500/200 W/VA	

1.1.21 UD/S2.315.2.11 LED Dimmer 2x315W > Channel allocation

Channel allocation

Allocation of the physical outputs for logical KNX channels

+ Device settings Bundling outputs (parallel switching)

+ Scenes Output A

+ Parameter masters Output B Channel A Channel B

+ Channel A


+ General functions

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Device settings – General

- In this parameter window the overriding parameter settings relevant for the entire device are made
- Allow manual operation (Always / Only at KNX failure)
 - This parameter is used to enable the buttons on the front in general or only at a failure of the KNX bus
- Use of the ripple control signal filter (yes/no)
 - With this parameter the ripple control signals of the network operators can be filtered out via the ripple control signal filter
 - Since generally no ripple control signals occur with the use of a generator (e.g. on ships), in this case it is recommended to deactivate the ripple control signal filter
- Enable communication object "In operation"
 - No
 - Yes (send value 0/1 cyclic)



- Manual operation:
 - Brief press of the button: On / Off (press in case of an error)
 - Long press of the button: Dimming
 - Press at least 10 sec: Load test

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Scenes

- Easy configuration for up to 32 scenes
- Clear set-up for each scenes
- Individual transition time for each scene
- Enable communication object “Scene”
- Trigger the scene with (1 byte)
- 64 KNX scenes can be allocated to the scenes of the UD/S

Channel allocation	Dimmer scene 1: KNX scene	1
+ Device settings	Dimmer scene 2: KNX scene	2
- Scenes	Dimmer scene 3: KNX scene	Scene not used
Configure scenes	Dimmer scene 4: KNX scene	Scene not used
Dimmer scene 1	Dimmer scene 5: KNX scene	Scene not used
Dimmer scene 2	Dimmer scene 6: KNX scene	Scene not used
	Dimmer scene 7: KNX scene	Scene not used



Scene transition time	00:00:04	hh:mm:ss
Stored scene values overwrite at download	<input checked="" type="radio"/> no <input type="radio"/> yes	
Channel A scene value	100%	
Channel B scene value	100%	
Channel C scene value	100%	
Channel D scene value	100%	

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters / Templates

- In many cases each dimmer channel is configured as all other channels
- With the new LED-Dimmer only 1 master channel has to be configured
- All other channels can be copied by the master channel or be configured individually
- Advantage: Save of time and work during parametrization as typically channels need the same adjustments
- If you select “Individual” you start with the default parameters



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Basic settings

Load Detection:

- Automatic load detection
 - The dimmer senses automatically whether it is an inductive or capacitive load and adjusts the control accordingly
- LED / leading edge (inductive load)
 - No softstart - attuned to the operation of LEDs
- LED trailing edge and loads with RC behavior
 - For LEDs with trailing edge control
- Incandescent lamp / trailing edge (capacitive)
 - At the zero transit the incandescent lamp is switched on and switched off again after the expiry of a set time
- Inductive load / leading edge
 - A softstart usually takes place when switching on

Parameter masters	Load selection	Automatic load detection
<u>Basic settings</u>	Minimum dimming value	1%
Feedback and error messages	Maximum dimming value	100%

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Basic settings

- Detailed parameters for switch-on/off behavior
- Switch-on value (0,4%-100% or last value)
- Dimming time reached up to switch-on value – Softstart
 - 0: Start-up – the output switches ON immediately (ON command)
 - 00:00:01....18:12:15 – during this period the output is dimmed from 0% brightness to the switch-on value
 - Fade time used [s] according to DIN EN 62 386-102
- Dimming time adjustable via object "Flexible dimming time/fade time"
- Allow switching on via dimming (Relative dimming function)
- Allow switching on via dimming value (Dimming value function)

Switch-on behaviour	
Switch-on value (Switching function)	last value
Dimming time reached up to switch-on value (0 = start-up)	00:00:01 hh:mm:ss
Dimming time adjustable via object "Flexible dimming time/fade time"	<input type="checkbox"/>
Allow switching on via dimming (Relative dimming function)	<input checked="" type="checkbox"/>
Allow switching on via dimming value (Dimming value function)	<input checked="" type="checkbox"/>
Switch-off behaviour	
Switching off at switch-off value (Switching function)	<input type="checkbox"/>
Dimming time reached up to switch-off (0 = start-up)	00:00:01 hh:mm:ss
Dimming time adjustable via object "Flexible dimming time/fade time"	<input type="checkbox"/>
Allow switching off via dimming (relative dimming function)	<input type="checkbox"/>
Allow switching off via dimming value (dimming value function)	<input checked="" type="checkbox"/>

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Basic settings

- Dimming time for relative dimming 0-100%
- Dimming time reached up to switch-on/off/value:
 - 00:00:00 – jump to value
 - 00:00:08 – softstart: seconds from zero to switch-on/off value (for values <32s depending DIN EN 62 386-102 “Fade Time”)

Relative dimming function		
Dimming time for relative dimming 0-100%	<input type="text" value="00:00:04"/>	hh:mm:ss
Dimming value function		
Dimming time reached up to dimming value (0 = start-up)	<input type="text" value="00:00:01"/>	hh:mm:ss
Dimming time adjustable via object "Flexible dimming time/fade time"	<input type="checkbox"/>	

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Feedback and error messages

- Status communication objects for switching and dimming value
- Error diagnosis as KNX standard bit field (8 codes) or error number (13 errors)
- Flexible sending cycle
- Flexible definition, which errors trigger the communication object “Error”

– Parameter masters	Enable communication object "Switching status"	<input checked="" type="checkbox"/>
Basic settings	Send object value	<input type="radio"/> no <input checked="" type="radio"/> In case of change
Feedback and error messages	Enable communication object "Dimming value status"	<input checked="" type="checkbox"/>
Block and forced function	Send object value	<input type="radio"/> no <input checked="" type="radio"/> In case of change
Faults	Send intermediate values at transitions (e.g. dimming or scene transition)	<input type="checkbox"/>
Central objects	Enable communication object "Error diagnosis"	<input checked="" type="checkbox"/>
Correction of characteristic	Diagnosis format	<input type="radio"/> KNX standard bit field <input checked="" type="radio"/> Error number
Wake-up/sleep function	Sending cycle	<input type="text" value="00:10:00"/> hh:mm:ss
– Channel A	Enable communication object "Error"	<input checked="" type="checkbox"/>
Basic settings	For overload	<input checked="" type="checkbox"/>
Feedback and error messages	For overvoltage	<input checked="" type="checkbox"/>
Block and forced function	For excess temperature	<input checked="" type="checkbox"/>
Faults	For short-circuit	<input checked="" type="checkbox"/>
Central objects	For mains failure	<input checked="" type="checkbox"/>
Correction of characteristic	For hardware error	<input checked="" type="checkbox"/>
Wake-up/sleep function	for "Dimmer detects other load as parameterized"	<input checked="" type="checkbox"/>
+ Channel B		

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Error num. / KNX Standard bit field

Format:	8 bit: U ₈
Octet no.	1
Designation of field	Value not assigned
Octet no.	Error code
Encryption	00h = no error
Designations of field	01h = critical temperature
	02h = short-circuit
	03h = connected unit does not function
	04h = excess current
	05h = error of device software
	06h = mains failure
	07h = load defective
	08h = error of mains synchronization
	09h = overload
	0Ah = error of load type
	0Bh = internal error
	0Ch - FFh = reserved

Bit fields	Description		Unit / range of values
Attribute	Bit no.		Bit set B ₈
Load detection error	0 (lsb)	Load detection failed / incorrect load type	0: true 1: false
Undervoltage	1	Undervoltage of mains supply	0: true 1: false
Excess current	2	Excess current / short-circuit on load side	0: true 1: false
Underload	3	Under load / no load on loa side	0: true 1: false
Faulty load	4	Overvoltage / excess current pulses on load side	0: true 1: false
Lamp failure	5	General lamp failure	0: true 1: false
Overheating	6	Thermal overheating of actuator	0: true 1: false
Reserved	7 (msb)		0: true 1: false

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Block and forced function

- The active forced operation, irrespective of whether triggered via a 1-bit or 2-bit activation, has an influence on the entire behaviour of the channel. When forced operation is called up, the brightness value parameterized in the ETS is set. A currently running dimming telegram is interrupted
- Brightness values received during forced operation are not set, but tracked and stored in the background. Also switching telegrams are stored in the background. Relative dimming telegrams and dimming ramps are ignored. At time variations (e.g. scenes) the end brightness value is noted
- At the end of forced operation the brightness value tracked in the background is set. The channel returns to the state prior to forced operation
- The forced operation function has a higher priority than manual operation

1.1.19 UD/S4.315.2.11 LED Dimmer 4x315W > Parameter masters > Block and forced function

Channel allocation	Enable forced operation	<input checked="" type="checkbox"/>
+ Device settings	Format of the force object	<input type="radio"/> 1 bit <input checked="" type="radio"/> 2 bit
+ Scenes	Activating dimming at force	No change (disable) ▼
- Parameter masters	Deactivating dimming value at force	Current KNX status ▼
Basic settings	Status after KNX return of voltage	Inactive ▼
Feedback and error messages	Enable communication object "Forced operation status"	<input type="checkbox"/>

[Block and forced function](#)

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Block and forced function

- The active forced operation, irrespective of whether triggered via a 1-bit or 2-bit activation, has an influence on the entire behavior of the channel. When forced operation is called up, the brightness value parameterized in the ETS is set. A currently running dimming telegram is interrupted
- Brightness values received during forced operation are not set, but tracked and stored in the background. Also switching telegrams are stored in the background. Relative dimming telegrams and dimming ramps are ignored. At time variations (e.g. scenes) the end brightness value is noted
- At the end of forced operation the brightness value tracked in the background is set. The channel returns to the state prior to forced operation.
- The forced operation function has a higher priority than manual operation

Value	Bit 1	Bit 0	Status	Description
0	0	0	Free	If a telegram with value 0 (binary 00) or 1 (binary 01) is received on communication object forced operation, the channel is enabled and can be activated via the different communication objects.
1	0	1	Free	
2	1	0	Forced operation OFF	If a telegram with value 2 (binary 10) is received on communication object forced operation, the forced operation OFF channel is switched and blocked until the forced operation is deactivated again. As long as forced operation is active, the activation via a different communication object is ignored. Telegrams are tracked in the background and the final values are stored. After the forced operation is deactivated, the brightness value constantly tracked in the background is set.
3	1	1	Force ON	If a telegram with value 3 (binary 11) is received on communication object forced operation, the forced operation ON channel is switched with the parameterized brightness value and blocked until the forced operation is deactivated again. As long as forced operation is active, the activation via a different communication object is ignored. Telegrams are tracked in the background and the final values are stored. After the forced operation is deactivated, the brightness value constantly tracked in the background is set.

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Faults

- This parameter window is used to specify how devices are to respond during certain malfunctions
- Settings for dimmer behavior in case of a fault
- Status of the dimmer after loss of KNX or mains voltage
- Status of the dimmer after return of voltage
- Automatic load test can be repeated
- Communication object for load test (can also be activated manual on the device)

1.1.19 UD/S4.315.2.11 LED Dimmer 4x315W > Parameter masters > Faults

Channel allocation	Dimming value during loss of KNX voltage	no change
+ Device settings	Dimming value at KNX return of voltage	As prior to failure
+ Scenes	Does not apply when forced/blockage is active at return of KNX voltage	
- Parameter masters	Dimming value at return of mains voltage	Current KNX status
Basic settings	Does not apply when forced/blockage is active at return of KNX voltage	
Feedback and error messages	Run through automatic load test at return of mains voltage	<input type="checkbox"/>
Block and forced function	Enable communication object "Trigger load test"	<input type="checkbox"/>

[Faults](#)

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Central objects

- The operating mode of the central objects "Switching", "Dimming" and "Value" are similar to the normal channel objects "Switching", "Dimming" and "Value“
- The difference is that central objects, such as broadcast objects, operate simultaneously the same on all channels
- Advantage: Less group address assignments, especially for multi channel devices

1.1.19 UD/S4.315.2.11 LED Dimmer 4x315W > Parameter masters > Central objects

Channel allocation	Respond to communication object "Central switching"	<input checked="" type="checkbox"/>
+ Device settings	Respond to communication object "Central dimming"	<input checked="" type="checkbox"/>
+ Scenes	Respond to communication object "Central value"	<input checked="" type="checkbox"/>
- Parameter masters		
Basic settings		
Feedback and error messages		
Block and forced function		
Faults		
<u>Central objects</u>		

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Correction of characteristic

- This function is used to correct the set values of problem systems with lamps which continue to exhibit an uneven dimming behavior in standard settings
- For lamps with a non-linear behavior
- The characteristic curve is measured ideally in a fully darkened room
- The dimmer automatically calculates the corrected set values from the recorded characteristic curve, so that a linear connection is re-established on the lamp between KNX set values and brightness
- Correction with lux values or direct value input (%)


1.1.19 UD/S4.315.2.11 LED Dimmer 4x315W > Parameter masters > Correction of characteristic

Channel allocation	Use characteristic	<input checked="" type="checkbox"/>
+ Device settings	Correction by	<input checked="" type="radio"/> Measured value (lux) <input type="radio"/> Direct value input (%)
+ Scenes	Number of correcting points	1
- Parameter masters	KNX dimming value 0% (OFF)	0 %
Basic settings	Measured lux value/sensor value at 0% (Offset correction)	0
Feedback and error messages	Correction point 1	
Block and forced function	KNX dimming value	20 %
Faults	Measured lux value/sensor value	1000
Central objects	KNX dimming value 100%	100 %
Correction of characteristic	Measured lux value/sensor value at 100%	1000
Wake-up/sleep function		

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Correction of characteristic (lux)



1.1.19 UD/S4.315.2.11 LED Dimmer 4x315W > Parameter masters > Correction of characteristic

Channel allocation	Use characteristic	<input checked="" type="checkbox"/>
+ Device settings	Correction by	<input checked="" type="radio"/> Measured value (lux) <input type="radio"/> Direct value input (%)
+ Scenes	Number of correcting points	1
- Parameter masters	KNX dimming value 0% (OFF)	0 %
Basic settings	Measured lux value/sensor value at 0% (Offset correction)	5
Feedback and error messages	Correction point 1	
Block and forced function	KNX dimming value	50 %
Faults	Measured lux value/sensor value	250
Central objects	KNX dimming value 100%	100 %
<u>Correction of characteristic</u>	Measured lux value/sensor value at 100%	1000
Wake-up/sleep function		

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Wake-up/Sleep function

- Wake-up function: slowly dimming up
 - Initial brightness can be set as current value or defined percentage
 - Target brightness (0,4% - 100%)
 - Time to reach target brightness (00:00:00 – 18:12:15 hh:mm:ss) can be adjusted via group object
 - Start/Stop via 1 bit telegram (DPT 1.010 start/stop)
- Sleep function: slowly dimming down
 - Initial brightness can be set as current value or defined percentage
 - Target brightness (0% - 100%)
 - Time to reach target brightness (00:00:00 – 18:12:15 hh:mm:ss) can be adjusted via group object
 - Start/Stop via 1 bit telegram (DPT 1.010 start/stop)

1.1.21 UD/S2.315.2.11 LED Dimmer 2x315W > Parameter masters > Wake-up/sleep function

Channel allocation	Use wake-up function	<input checked="" type="checkbox"/>
+ Device settings	Initial brightness	Current value
+ Scenes	Target brightness	100%
- Parameter masters	Time to reach target brightness	00:00:30 hh:mm:ss
Basic settings	Use sleep function	<input checked="" type="checkbox"/>
Feedback and error messages	Initial brightness	Current value
Block and forced function	Target brightness	0%
Faults	Time to reach target brightness	00:00:30 hh:mm:ss
Central objects		
Correction of characteristic		

[Wake-up/sleep function](#)

Kanal A: Wake-up function start/stop	Input	A: Wake-up function start/stop	1/1/4	1 bit
Kanal A: Time to reach target brightness wake-up function	Input	Time to reach target brightness wake-up function	1/1/8	2 bytes
Kanal A: Sleep function start/stop	Input	A: Sleep function start/stop	1/1/5	1 bit
Kanal A: Time to reach target brightness sleep function	Input	Time to reach target brightness sleep function	1/1/9	2 bytes

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

Parameter masters – Wake-up/Sleep function example

# ^	Time	Serv	Fla	Pri	Source Add	Source Name	Destination	Destination Name	Rout	Type	DPT	Info
1	25.06.2020 11:19:50,362	fro...	L...	1.1.10	6127/02	c. elem., solo® conf. 4g...	1/1/5	A: Sleep function start/st...	6	GroupValueWrite		\$01 Start
2	25.06.2020 11:19:58,653	fro...	L...	1.1.10	6127/02	c. elem., solo® conf. 4g...	1/1/5	A: Sleep function start/st...	6	GroupValueWrite		\$00 Stop
3	25.06.2020 11:19:58,887	fro...	L...	1.1.21	UD/S2.315.2.11	LED Dimmer 2x31...	1/1/6	A: Brightness value status	6	GroupValueWrite	5.001 percentage...	\$49 29 %
4	25.06.2020 11:20:02,467	fro...	L...	1.1.10	6127/02	c. elem., solo® conf. 4g...	1/1/5	A: Sleep function start/st...	6	GroupValueWrite		\$01 Start
5	25.06.2020 11:20:32,527	fro...	L...	1.1.21	UD/S2.315.2.11	LED Dimmer 2x31...	1/1/6	A: Brightness value status	6	GroupValueWrite	5.001 percentage...	\$00 0 %
6	25.06.2020 11:20:46,202	fro...	L...	1.1.10	6127/02	c. elem., solo® conf. 4g...	1/1/1	A: Relative Dimming	6	GroupValueWrite		\$09 Increase, 100 %
7	25.06.2020 11:20:50,526	fro...	L...	1.1.21	UD/S2.315.2.11	LED Dimmer 2x31...	1/1/6	A: Brightness value status	6	GroupValueWrite	5.001 percentage...	\$FF 100 %
8	25.06.2020 11:20:50,823	fro...	L...	1.1.10	6127/02	c. elem., solo® conf. 4g...	1/1/1	A: Relative Dimming	6	GroupValueWrite		\$08 Increase, Break
9	25.06.2020 11:20:54,136	fro...	L...	1.1.10	6127/02	c. elem., solo® conf. 4g...	1/1/9	Time to reach target brig...	6	GroupValueWrite	7.005 time (s)	00 3C 60 s
10	25.06.2020 11:20:57,222	fro...	L...	1.1.10	6127/02	c. elem., solo® conf. 4g...	1/1/5	A: Sleep function start/st...	6	GroupValueWrite		\$01 Start
11	25.06.2020 11:21:57,446	fro...	L...	1.1.21	UD/S2.315.2.11	LED Dimmer 2x31...	1/1/6	A: Brightness value status	6	GroupValueWrite	5.001 percentage...	\$00 0 %

After manual stop, actual value is sent to the bus, if the feedback object is activated

Adjustment of the time to 60 sec.


New value is used by the dimmer

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions

- 5 channels for logic functions
 - Telegram cyclical
 - Gate
 - Staircase lighting
 - Delay
 - Priority
 - Logic gate
 - Min/max value transducer
 - Threshold value / Hysteresis
 - Flashing



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Telegram cyclical

- Telegrams that are received on object "GFx: Input" are transferred directly to object "GFx: Output" and there sent cyclic
- Object type and time can be adjusted
- Always activated or activated at a specific value (or except a specified value)

GF1: Input	Input	A: Switching	1/1/0	1 bit
GF1: Output	Output	Cyclical Sending	0/0/1	1 bit

06.07.2020 08:34:09,0... from bus	S=4	Low	1.1.21	UD/S2.315.2.11 LED Di...	0/0/1	Cyclical Sending	6	GroupValueWrite	\$01 On
06.07.2020 08:34:10,3... from bus	S=6	Low	1.1.21	UD/S2.315.2.11 LED Di...	1/1/6	A: Brightness value status	6	GroupValueWrite	\$FF 100 %
06.07.2020 08:34:34,1... from bus	S=0	Low	1.1.20	Master: SBC/U6.0 HVA...	9/3/0	CO2 value	6	GroupValueWrite	35 7E 899,84
06.07.2020 08:35:04,0... from bus	S=2	Low	1.1.21	UD/S2.315.2.11 LED Di...	0/0/1	Cyclical Sending	6	GroupValueWrite	\$01 On

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Gate

- The application allows specific signals to be filtered and the signal flow to be temporarily blocked
- The objects "GFx: input" and "GFx: output" can take on different sizes
- If, for example, the "Control input" setting is set on "ON telegram," only telegrams from the input are transmitted to the output

GF1: Input	Input	A: Switching	1/1/0	1 bit
GF1: Output	Output	Gate	0/0/2	1 bit

06.07.2020 08:44:35,...	from bus	S=7	Low	1.1.10	6127/02 c. elem., solo...	1/1/0	A: Switching	6	GroupValueWrite	\$00 Off
06.07.2020 08:44:35,...	from bus	S=1	Low	1.1.21	UD/S2.315.2.11 LED Di...	0/0/2	Gate	6	GroupValueWrite	\$00 Off

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Staircase lighting

- With the application, switching telegrams and value telegrams can be provided with a switch-off delay
- The objects "GFx: input" and "GFx: output" can take on size 1 bit or 1 byte, depending on the object type selected
- Input/Output can be separated or used with the same object

GF1: Input	Input	Staircase Lighting	0/0/3	1 bit
GF1: Light-on time	Input			2 bytes
GF1: Output	Output	Light 1	1/0/0	1 bit

06.07.2020 09:08:14,4... from bus	S=7	Low	1.1.9	6127/02 c. elem., solo...	0/0/3	Staircase Lighting	6	GroupValueWrite	\$01 On
06.07.2020 09:08:14,4... from bus	S=1	Low	1.1.21	UD/S2.315.2.11 LED Di...	1/0/0	Light 1	6	GroupValueWrite	\$01 On
06.07.2020 09:08:14,5... from bus	S=3	Low	1.1.30	SA/S4.16.6.1 Switch Act...	1/5/0	Light 1	6	GroupValueWrite	\$01 On
06.07.2020 09:08:24,4... from bus	S=5	Low	1.1.21	UD/S2.315.2.11 LED Di...	1/0/0	Light 1	6	GroupValueWrite	\$00 Off
06.07.2020 09:08:24,5... from bus	S=7	Low	1.1.30	SA/S4.16.6.1 Switch Act...	1/5/0	Light 1	6	GroupValueWrite	\$00 Off

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Delay

- The application can be used to receive telegrams via the "Input" object
- The telegrams received are sent out via the "Output" object with a set delay time
- Retriggering: The light-on time is always restarted when a telegram is received via the "GFx: Input“ object
- Filter function: only specific values are delayed

Retriggering	<input checked="" type="radio"/> deactivated <input type="radio"/> activated
Filter active	<input type="radio"/> deactivated <input checked="" type="radio"/> activated
Filter function	Filter value is delayed, other values are sent directly
Filter value	<input checked="" type="radio"/> off <input type="radio"/> on
Overwrite delay time for download	<input checked="" type="radio"/> deactivated <input type="radio"/> activated

06.07.2020 09:14:56,4... from bus	S=1	Low	1.1.9	6127/02 c. elem., solo...	0/0/4	Delay	6	GroupValueWrite	\$01 On
06.07.2020 09:14:56,4... from bus	S=3	Low	1.1.21	UD/S2.315.2.11 LED Di...	1/0/0	Light 1	6	GroupValueWrite	\$01 On
06.07.2020 09:14:56,5... from bus	S=5	Low	1.1.30	SA/S4.16.6.1 Switch Act...	1/5/0	Light 1	6	GroupValueWrite	\$01 On
06.07.2020 09:15:01,357from bus	S=7	Low	1.1.9	6127/02 c. elem., solo...	0/0/4	Delay	6	GroupValueWrite	\$00 Off
06.07.2020 09:15:06,3... from bus	S=1	Low	1.1.21	UD/S2.315.2.11 LED Di...	1/0/0	Light 1	6	GroupValueWrite	\$00 Off
06.07.2020 09:15:06,4... from bus	S=3	Low	1.1.30	SA/S4.16.6.1 Switch Act...	1/5/0	Light 1	6	GroupValueWrite	\$00 Off

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Priority


- The application can be used to activate a forced guidance (priority) for switching outputs
- The telegrams received on "GFx: switch input" are transferred to object "GFx: output" depending on the state of the "GFx: priority input" object
- The 2-bit object "GFx: priority input" can receive and differentiate between four different values (0, 1, 2 and 3)
- Here, the "GFx: output" object is positively driven. Three different states are differentiated:
 - "GFx: priority input" has the value "3". The value that is present on "GFx: switch input" has no meaning. The "GFx: output" object is switched and has the value "1"
 - "GFx: priority input" has the value "2". The value that is present on "GFx: switch input" has no meaning. The "GFx: output" object is switched and has the value "0"
 - "GFx: priority input" has the value "1" or "0". The "GFx: output" object is not affected. The "GFx: switch input" is linked to the status bit of the priority object OR and transferred to the "GFx: output" object

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Logic Gate

- Logic gate for sending an output depending on two or more inputs
- Up to 10 inputs can be used



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Min/Max value transmitter

- For each assignment of the inputs the largest/smallest/average value will be sent to the bus
- Up to 8 inputs can be used

+ Channel C	Channel name	Channel
- General functions	Object type	1-byte 0..100%
Channel 1	Number of input objects	1
Common parameter	Output sends	<input checked="" type="radio"/> for every assignment of the inputs <input type="radio"/> with a change of the output object
Channel 2	Output object	adopts the largest value of the inputs
Channel 3		adopts the largest value of the inputs ✓
Channel 4		adopts the smallest value of the inputs
Channel 5		adopts the average value of the inputs

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Threshold value / Hysteresis

– If input is exceeding the upper threshold (or is falling below the lower threshold) the values which are set up will be sent to the output

General functions	Channel name	Channel
Channel 1	Object type input	1-byte 0..100%
Common parameter	Object type output	1-bit switching
Extended parameters		

General functions	Enable object	<input checked="" type="radio"/> deactivated <input type="radio"/> activated
Channel 1	Behaviour output after return of voltage	deactivated
Common parameter	Send behaviour	<input type="radio"/> for every object receipt <input checked="" type="radio"/> only with a change of the output object
Extended parameters	Upper threshold (%)	80
Channel 2	Output value for exceeding the upper threshold	<input type="radio"/> off <input checked="" type="radio"/> on
Channel 3	Lower threshold (%)	20
Channel 4	Output value for falling below the lower threshold	<input checked="" type="radio"/> off <input type="radio"/> on
Channel 5		

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ETS application

General functions – Flashing

- Activated with 1 bit object = “on”
- Number of flashing cycles can be limited

– General functions	Channel name	Channel
Channel 1	Flashing	for input = 1
Common parameter	Switch-on interval (s) - LED on	01.000 ss.fff
Extended parameters	Switch-off interval (s) - LED off	01.000 ss.fff

– General functions	Flashing cycle limit	<input type="radio"/> deactivated <input checked="" type="radio"/> activated
Channel 1	Number of flashing cycles	2
Common parameter		
Extended parameters		

KNX LED Dimmer UD/S 2x315W/4x315W/6x315W, MDRC


ABB i-bus® Tool

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ABB i-bus® Tool

Functions

- Overview of all channels
- Overview of the detected load type
- Information force lock
- Trigger load test and error acknowledge
- Detailed information about error types
- Recommended solution



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ABB i-bus® Tool

Overview

- The ABB i-bus® Tool can be used for extensive test and error diagnosis functions
- The overview page provides a comprehensive overview of the essential settings and statuses of the individual dimming channels


 Back	 Home	 Help	 Select Configuration mode	Device type 0x4A14	Physical address 1.1.1		
				Application 1.0	Device UD/S4.210.2.1		
Welcome	Channel	Load type in ETS	Load type detected	Brightness	Force lock	Error	Assigned outputs
Connect to device	A	Auto detect	Inductive load (leading edge)	49% (123)	Inactive	 Mains fault	A
	B	Auto detect	LED and RC load (falling edge)	11% (27)	Active	 No error	B
	C	Auto detect	Auto detect	33% (82)	Inactive	 Overload	C

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ABB i-bus® Tool

Detail

- The detail page can be used by the user to set specific dimming values separately for each channel, and so record the limits of the dimming ranges for example
- Also a load test can be triggered or an error acknowledged
- Additional information about load types, a possible existing error or about a possible restricted guidance that has been set, the user can read in the "Status" overview block



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ABB i-bus® Tool

Output statuses

- Detailed information about possible existing errors is provided channel-related on page "Status outputs“
- The physical outputs of the dimmers are portrayed in column "Output", while column "Channel" provides information about which channel the respective physical address is assigned to in the ETS
- This information is especially important for the bundling of channels
- This, for example, would allow output A and output B to be bundled, parameterized and controlled on the ETS side via channel A

Output	Error	Channel
A	 Mains fault	A
B	 Overtemperature	B
C	 Shorted	C
D	 No load	D
E	 Overvoltage	F
F	 Hard fault	F

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

ABB i-bus® Tool

Overview errors

Errors	Recommended solution
Excess temperature	Reduce connected loads, provide sufficient cooling and increase the distance to adjacent devices.
Short-circuit	Check the wiring and rectify the short-circuit.
No load	Check the wiring and lamps.
Overvoltage	Check the wiring, supply voltage and parameterized load type.
Final stage defective	Switch the voltage off and on again. If the error persists, exchange the device.
230 V failure	Check the supply voltage.
Load failure	Check wiring and lamps and, if necessary, replace defective lamps.
Mains failure	Check the supply voltage.
Overload	Reduce the connected load.
Conflict of load type	The load type detected by the dimmer did not correspond to the load set in the ETS. The dimmer automatically adjusted the load type to prevent possible damage.
Internal error	Disconnect the bus and supply voltage from the device and reconnect it again.

KNX LED Dimmer UD/S 2x315W/4x315W/6x315W, MDRC


Commercial and technical data

Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

Commercial data

Overview

Article No.	Order No.	Name	Version
UD/S2.315.2.11	2CKA006197A0052	LED-Dim actuator 2x315W	BJE
UD/S2.315.2.1	2CKA006197A0053	LED-Dim actuator 2x315W	ABB
UD/S4.315.2.11	2CKA006197A0056	LED-Dim actuator 4x315W	BJE
UD/S4.315.2.1	2CKA006197A0057	LED-Dim actuator 4x315W	ABB
UD/S6.315.2.11	2CKA006197A0060	LED-Dim actuator 6x315W	BJE
UD/S6.315.2.1	2CKA006197A0061	LED-Dim actuator 6x315W	ABB




Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

Technical data

www.abb.com/KNX

→ Products and Downloads
→ Lighting Control
→ Universal Dim Actuators

- Product Manual
- Installation and Operating Instructions
- ETS Application
- EU - Declaration of Conformity
- ...



The screenshot shows the ABB product details page for the UD/S2.315.2.1 dimmer actuator. The page includes a navigation menu, a language selector, and a search bar. The main content area displays the product name, a brief description, and a table of technical specifications. A large image of the physical device is shown on the right side of the page.

ABB PRODUCT-DETAILS GLOBAL SITE

You can view this page in: EN DE SV FI CS DA EL ES FR HU IT JA KO NL NO PL PT RU SK TR ZH

Detailed information for: UD/S2.315.2.1

This page contains technical data sheet, documents library and links to offering related to this product. If you require any other information, please contact us using form located at the bottom of the page. [Print...](#) [Print to Pdf...](#)

[Data Sheet](#) [Downloads](#)

UD/S2.315.2.1

General Information

Extended Product Type:	UD/S2.315.2.1
Product ID:	2CKA006197A0053
EAN:	4011395251928
Catalog Description:	UD/S2.315.2.1

Long Description: Multichannel universal dimming actuator optimised for dimming retrofit LED lamps (LED). Also suitable for dimming incandescent lamps, low-voltage halogen lights with conventional or electronic transformers, 230 V halogen lamps and dimmable energy-saving halogen lamps. Automatic load detection (can be deactivated). Separate N-connection per channel. Parallel connection of the outputs possible to increase the output power. Outputs can be connected in parallel in groups. Minimum load: 2 W. Manual operation on device also possible without bus voltage or in an unprogrammed status. Programming of the device also possible without applied 230V supply voltage. Extensive test and diagnosis functions for the I-Bus tool. Fast parameter setting in ETS using copyable channel templates. With integrated bus coupler. Nominal power at 230 V~ mains voltage:



Webinar “KNX LED Dimmer UD/S 2x315W/4x315W/6x315W”

Training & Qualification Calendar

In addition to the online modules and the traditional training programs offered by your local ABB sales team, we offer a variety of on-site trainings conducted by our specialists at different ABB training facilities

In this Training & Qualification Calendar you can find the educational events that are taking place during 2020

If you are interested in a training please click the training und you will be forwarded to register in “ABB MyLearning”

www.abb.com/knx or <https://go.abb/ba-training>

→ Services & Tools

→ Training and Qualification

→ Training Calendar




ABB HOME • OFFERINGS • LOW VOLTAGE PRODUCTS • HOME AND BUILDING AUTOMATION • TRAINING AND QUALIFICATION • TRAINING & QUALIFICATION CALENDAR GLOBAL SITE

Training & Qualification Calendar

In addition to the online modules and the traditional training programs offered by your local ABB sales team, we offer a variety of webinars and on-site trainings conducted by our specialists at different ABB Competence Centers.

In this Training & Qualification Calendar you can find the educational events that are taking place during 2018.

If you are interested in a training please [REGISTER HERE](#).

To search the Calendar, select the required search criteria. To make multiple selections press [Ctrl].

System	Date	Location
All	All	Webinar
Door Entry Systems	January 2018	Heidelberg, Germany
Free@home	February 2018	Lödenscheid, Germany
Fire Alarm Systems	March 2018	s. Palomba (Rome), Italy
I-bus KNX	April 2018	Vittuone (Milan), Italy

Content	Date	Location	Language
KNX for Commercial Building	05.04.2018 - 06.04.2018	Lödenscheid, Germany	EN
Building Automation Light + Building 2018	10.04.2018	Webinar	EN
KNX in Hotels	19.04.2018 - 20.04.2018	Heidelberg, Germany	EN
HVAC Automation	23.04.2018 - 24.04.2018	Heidelberg, Germany	EN

ABB MyLearning

HOME CATALOG PROFILE ADMINISTER REPORTS MY LEARNING

CERTIFIED KNX BASIC COURSE
Code : 9CSC007151-GLB-EN-20190218_22
Certified KNX Basic Course at ABB in Heidelberg, Germany, 5 days
★★★★★ | Share

Disclaimer

Technical data in this presentation are only approximate figures. The information in this presentation is subject to change without notice and should not be construed as a commitment by ABB. ABB assumes no responsibility for any errors that may appear in this presentation.

ABB shall in no case be liable under, or in connection with the presentation towards any person or entity, to which the presentation has been made available, in view of any damages or losses – irrespective of the legal grounds. In particular ABB shall in no event be liable for any indirect, consequential or special damages, such as - but not limited to – loss of profit, loss of revenue, loss of earnings, cost of capital or cost connected with an interruption of business.

© Copyright 2020 ABB. All rights reserved.

AABB