







# Quick Installation Guide 630 series







# Protective earthing






# Flush mounting 4U





# Semi-flush mounting 4U







# Wall mounting 4U



# Rack mounting a single IED 4U





# Rack mounting two IEDs 4U








# Rack mounting kit for single IED and test switch RTXP



# Ceiling mounting with external display module
















# Wall mounting with external display module



# Mounting the external display module



Panel drill plan 1:1  
See the center page




4U half 19"

⑤








6U half 19"






# Mounting the optional cable shield rail



# Rack mounting two IEDs with the optional cable shield rail











# Contact us

**ABB Oy**

**Distribution Automation**

P.O. Box 699

FI-65101 VAASA, Finland

Phone +358 10 22 11

Fax +358 10 22 41094

**[www.abb.com/substationautomation](http://www.abb.com/substationautomation)**



1MPS757518

© Copyright 2011 ABB. All rights reserved.

Power and productivity  
for a better world™

