



---

## 266 Transmitter Parts

Field maintenance made easy

The 266 transmitter family offers in-field maintenance operations. Both terminal block and communication assemblies can be replaced in minutes helping your operations stay on-line saving time and lowering your operation costs.

ABB Inc.  
Measurement & Analytics  
Tel. +1 800 442 3097  
E-mail: [totalflow.inquiry@us.abb.com](mailto:totalflow.inquiry@us.abb.com)  
[www.abb.com/upstream](http://www.abb.com/upstream)



## 266 Field Replaceable Parts



Modbus Communication assembly  
Product: 266JST Modbus XMV  
Part Number: 2105784-001



LCD display assembly w/ HMI Connector  
Product: 266HSH 4-20mA PT / 266JST Modbus XMV  
Part Number: 2105784-002



LCD display, HMI 6 pin connector, front cover  
Product: 266JST Modbus XMV  
Part Number: 2105784-003



Termination assembly with surge protection  
Product: 266JST Modbus XMV  
Part Number: AU3083



Transmitter back cover  
Product: 266HSH 4-20mA PT / 266JST Modbus XMV  
Part Number: 214915



Termination assembly with surge protection  
Product: 266HSH 4-20mA PT  
Part Number: AU3067



HART Communication assembly  
Product: 266HSH 4-20mA PT  
Part Number: AU3074



Communication assembly with integrated display  
Product: 266HSH 1-5V Pressure Transmitter  
Part Number: 3KQZ207116U0100



Termination assembly with surge protection  
Product: 266HSH 1-5V Pressure Transmitter  
Part Number: 3KQZ207114U0200



HMI 6 Pin Connector  
Product: 266HSH 4-20mA PT / 266JST Modbus XMV  
Part Number: ET3020