


How to get to Monitor Window after using Data Logger


How to close Data logger window and return to Monitor window in Drive Composer Pro


This document discusses how to exit the data logger in the event that someone would like to get access to monitoring again after having the Data logger window open.


When accessing the data logger in 80 series drives, a user may want to go back to using the monitoring function. If the event logger is opened (part of a support package or online with a drive), a fault data can be viewed on some of the recent faults.



When the fault data monitor file is opened, it will open it in the monitoring window as the data logger. It will show the events at the time of the fault.



From here to get back to the monitoring window to do some live monitoring, simply press the settings button  and it will prompt about the data on the display being lost. Click yes to change to monitoring mode.



After this, it will switch to monitoring mode and the monitoring settings will be shown below. Click the Ok button, unless settings need to be adjusted. This will return you to the Monitor window.

Monitor settings [Close]

Auto interval Sample interval [] ms

Monitor start

By Hand

By Time [11:58:00 AM]

Monitor stop

By Hand


By Time Duration [] h [] min

Temporary files: [C:\Users\USWINYB\OneDrive - ABB\Documents\DriveWare\Composer] [Browse...]

[1000] MB minimum space to leave on the hard drive before automatically stopping monitoring

Currently free disk space: 475009 MB.

[OK] [Save...] [Open...]



For more information see the manuals below.

- Drive Composer Pro User Manual 3AUA0000094606