



NOTES:

1. Wiring status: Draft - Not tested. The ballast / power pack combination has not been wired up and tested to confirm functional compatibility.
2. This wiring diagram is provided in good faith and the best of our knowledge at the time of publication. Thomas and Betts does not give any warranty or representation as to the accuracy, reliability or completeness of the information. Thomas and Betts shall not be liable for any loss or damage arising in any way from or in connection with any information provided or omitted, or from anyone acting or refraining to act in reliance on this information.
3. Changes to ballast specification by the manufacturer are beyond our control and may cause adverse effect on the performance, EMC issue and compatibility issue. Consult Thomas and Betts for further advise.

DRAWN	G.K.Grover	Thomas&Betts A Member of the ABB Group		
CHECKED	-----	© ABN 62074810898 23A NYRANG ST, LIDCOMBE NSW 2141 AUSTRALIA		
APPROVED	G.K.Grover	TITLE Wiring diagram PPNXS18D/E-PL4PIN using TRIDONIC PC 2x18 TCD PRO Art. No. 22088937 Elect Ballast		
DATE:	23/11/15	ALSO USED ON PPNRF18D/E-PL4PIN	DRAWING NUMBER NPWD144A	SHEET SIZE A3
DRAWING STD AS 1100		SCALE N.T.S.	SHEET 1 OF 1	