


Iberville® Boxes

Meaning of letters and numbers

1st number after the CI or BC for device boxes

(CI : Commander Iberville BC : Bar Coded)

Reference No.	Description
1	Gangable (except for utility box BC1110)
2	Welded box
3	Gangable
4	Gangable
52	Square box 4 in.
53	Extension ring for square box 4 in.
54	Octagonal box
55	Extension ring for octagonal box
72	Square box 4 11/16 in.
73	Extension ring for square box 4 11/16 in.



Meaning of the last letters and numbers

Reference No.	Description
CIXX151	1-1/2 in. deep
BCXX171	2-1/8 in deep
MBD	Masonry Box Deep
MBS	Masonry Box Shallow
HV	High Voltage (347 Volts)
B	Bracket for wood stud
L	Loomex cable
LA	Loomex and Armoured cable (BX)
K	Concentric Knockouts (1/2 in or 3/4 in)
SSX	Steel Stud
LHTQ	L for Loomex, H is for extended sides for external nailing, T is positioning tab, Q is for one screw quick mount feature
LLE	Loomex Less Mounting Ear
P	Partition
SB	Side Bracket for wood and metal studs
-1	Offset for 2 x 1/2 in drywall thickness
-1.25	Offset for 2 x 5/8 in drywall thickness
LRB	Loomex Rework Box



Scan this QR code for more information on technical aspects of all our IBERVILLE boxes.