


Emax - Tmax




DOC. N.° 1SDH000529R0637 - B1651

Protezione trasparente pulsanti T7M-X1
Transparent push button cover T7M-X1
Transparente Schutzabdeckung für Drucktaster T7M-X1
Protection transparente boutons T7M-X1
Protección transparente pulsadores T7M-X1

T7M




X1




A

T7M




B

X1




C

T7M




D

X1



E

T7M - X1



Atrezzo per aprire o chiudere l'interruttore
 Tool for opening or closing the circuit-breaker
 Einschalten des Leistungsschalters
 Outil pour ouvrir ou fermer le disjoncteur
 Herramienta para abrir o cerrar el interruptor