



OTDC Switch-disconnector

OTDC800...1000FS_22, OTDC800...1000UFS_22

Circuit 6c, 6g – Single Circuit



1000 Vdc OTDC800...1000FS_22, OTDC800...1000UFS_22
1500 Vdc OTDC800...1000FSV_22, OTDC800...1000UFSV_22

NOTE! Phase barriers are not included – installation NOT mandatory