

UniSec Pro Configuration Software Installation

Registration

Please connect yourself to site:

<https://www111.abb.com/online/tn.dll/unisec/register>

Fill the form and click 'Register' button. Remember to fill correctly email field because this will be your userid and will be used for news. After the registration, you'll receive another e-mail with your user id (e-mail address) and first password (you can change it on the site).

Re-Installation


To reinstall software (for example to install software to another PC), the registration activity is not necessary. It's only necessary to contact the software administrator to receive an email with latest user and password (if lost or unknow). Otherwise, please follow instruction from "Download" chapter.

Download

Please connect to:

<https://www111.abb.com/online/tn.dll/unisec>

- Use received user and password to login yourself
- Click on "Program & Files" link
- Search "Programs" section
- Click on "UnisecPro - FF Italy (UnisecInstall....exe)" link to download program.



Installation

Start program and follow instructions. During installation, the software will ask you to insert your e-mail, user id (e-mail again) and password.

Pay attention: these fields are most important for the right operation of the program.

After installation you can start UnisecPro. First time, will be necessary few minutes to download all necessary updates.

Registration and Installation of other MV Switchgear Softwares

The instructions are the same for all Medium Voltage Switchgear Configurators. You need to connect to the web page to fill the form (for new user) for each requested software.

To login, please specify your account ID and password. If you don't have an account, you may [apply for one here](#).

A screenshot of a web form showing a text input field with the label "Account ID" on the left. The field is empty and has a standard rectangular border.

[UniGear Pro](#)

[UniGear ZS2 Pro](#)

[UniGear ZS3.2 Pro](#)

[ZS 8.4 Pro](#)

[ZN1 Pro](#)

[MVP Pro](#)

[OEM Pro](#)

[ZX Pro](#)

[Unisec Pro](#)

[Safe Pro](#)

[SafeLink Pro](#)

[CSS Pro](#)

[Nes Pro](#)