


INSTALLATION INSTRUCTION

Enclosed Maintenance Switches

Handle also lockable in On position





Contact us

ABB Oy

Muottitie 2A 65320

Vaasa, Finland

abb.com/lowvoltage