



—
INSTALLATION INSTRUCTION

Parallel connection kit


OZXA40-41



OZXA40



OZXA41





Contact us

ABB Oy

P.O. Box 622
FI-65101 Vaasa
Finland

abb.com/lowvoltage