


SACE Tmax XT



PLL - Blocco a lucchetti XT6 in aperto o aperto-chiuso.
PLL - Padlock device XT6 in open or open-close position.
PLL - Schlobverriegelung XT6 für ausgeschaltet oder ausgeschaltet-eingeschaltet.
PLL - Verrouillage par cadenas XT6 portatif en position ouverte ou ouverte-fermé.
PLL - Bloqueo por candados XT6 portátil en posición de abierto o abierto-cerrado.
PLL - 操作手柄分闸、分/合闸位置挂锁装置 XT6

XT6




Open position

Open-Close position




1

XT6 F



2

XT6 F



3

XT6 F

