

- This Version Matrix document helps you to find out what kind of software is available for this field device and which software version you have to use with which kind of Hardware and Firmware Revision.

- You will find the latest software, documentations or this Version Matrix (recommended) available on:  
<http://www.abb.com/Fieldbus>  
 -> select "[Fieldbus protocol] field devices" -> go to [device type name] -> select "latest info"  
 Tab "Fieldbus & HART Files" opens

## FSM4000

### HART

		Revision	
Title (ID-001D) [Doc.-No.]	Hardware	all released	
	Software	B.11 - B.34	≤ C.10
	Device	00	01
DTM (FDT 1.2) part of DTM400 [3KXF240400S0002]		01.01.16	
EDD (General) [3KDE195004S0003] When integrated in tools, this separate driver not needed!		00 00 (Dev. / EDD)	01 01 (Dev. / EDD)
EDD for PDM V5.2 [3KDE195004S0003]		00 00 (Dev. / EDD)	01 01 (Dev. / EDD)
EDD integrated in PDM ≥ V6.0. No separate driver needed		00 00 (Dev. / EDD)	01 01 (Dev. / EDD)
Supplem. Info.-Driver (DTM) [3KDE195041R39xx]		✓	

## FSM4000

### PROFIBUS PA

		Revision	
Title (ID-078C) [Doc.-No.]	Hardware	all released	
	Firmware	B.11 - B.14	≤ C.12
GSD [3KDE195004S0004]		01.03	01.04
DTM (FDT 1.2) part of DTM400 [3KXD800400S0030]		01.00.05	
EDD for PDM V5.2 [3KDE195004S0006]		01	
EDD integrated in PDM ≥ V6.0. No separate driver needed		01	
Supplem. Info.-Driver(DTM) [3KDE195044R39xx]		✓	

## FSM4000

### FOUNDATION Fieldbus-H1

		Revision	
Title (ID-0017) [Doc.-No.]	Device	01	02
	EDD/CF (General-registered) [3KDE195004S0007] When integrated in tools, this separate driver not needed!	010101	020101
EDD/CF integrated in AMS ≥ V8.0. No separate driver needed		010201	020201