

SACE Emax 2

Terminali anteriori F - E2.2-E4.2-E6.2


Front terminals F - E2.2-E4.2-E6.2

Vorderseitige Anschlüsse F - E2.2-E4.2-E6.2

Prises avant F - E2.2-E4.2-E6.2

Terminales anteriores F - E2.2-E4.2-E6.2


E2.2-E4.2-E6.2





	E2.2		E4.2		E6.2	
	III	IV	III	IV	III	IV (FS)
A	3	4	-	-	-	-
B	-	-	3	4	-	1(0)
C	-	-	-	-	3	3(4)
**D	3	4	-	-	-	-
**E	-	-	3	4	6	7(8)
F	3	4	-	-	-	-
G	-	-	3	4		1(0)
H	-	-	-	-	3	3(4)
**I	3	4	-	-	-	-
**J	-	-	3	4	6	7(8)
K	1	-	1	-	2	1(0)
L	-	1	-	1	-	1(2)
**M	3	4	3	4	6	7(8)
N	-	-	24	32	48	56(64)
O	24	32	-	-	-	-
Q	3	4	3	4	6	7(8)
R	3	4	3	4	6	7(8)

F


W





**** FOR UPPER TERMINALS KIT ONLY**




Non serrare
Do not tighten
Nicht festziehen
Ne serrez pas
No apriete















































For more information please contact:

ABB S.p.A.
Via Pescaria, 5
24123 Bergamo - Italy
Phone: +39 035 395 111