

# 9T58K0000G04 332A1500AAG04

## TYPICAL INSTALLATION INSTRUCTIONS FOR 9T58K0000G04 MOUNTING PLATE KIT

MOUNTING PLATE KIT 9T58K0000G04 IS A UNIVERSAL DESIGN INTENDED TO FIT ALL ENCAPSULATED TYPE IP TRANSFORMERS. FIELD INSTALLATION OF THIS KIT DOES NOT AFFECT UL LISTING OF THE UNIT.

### IMPORTANT:

REMOVE ALL POWER TO THE TRANSFORMER BEFORE INSTALLING THE MOUNTING PLATE KIT OR SERIOUS ELECTRICAL SHOCK MAY RESULT. IF YOU ARE UNSURE OF THE CORRECT CONNECTIONS TO BE MADE, CONTACT AN ABB AUTHORIZED DISTRIBUTOR FOR ASSISTANCE

332A1089AAP004

### STEP 1

ORIENT THE OPTIONAL FUSE-HOLDER OR OTHER ACCESSORY SO THAT IT WILL BE LOCATED ON THE SECONDARY SIDE OF THE TRANSFORMER (SEE STEP 2 FOR ACTUAL ASSEMBLY).

### STEP 2

USE THE #6 SCREW PROVIDED TO MOUNT THE OPTIONAL FUSE-HOLDER DIRECTLY ON TOP OF THE TRANSFORMER AS SHOWN. THE SCREW WILL GO THROUGH THE FUSE-HOLDER MOUNTING SLOT AND THROUGH THE MOUNTING PLATE AND ENGAGE WITH THE TRANSFORMER MOUNTING TAB. AVOID OVER TIGHTENING THE SCREW.

