

SACE Emax 2

Guida di blocco - E2.2-E4.2-E6.2



Locking guide - E2.2-E4.2-E6.2

Verriegelungsführung - E2.2-E4.2-E6.2


Glissière de blocage - E2.2-E4.2-E6.2

Guía de bloqueo - E2.2-E4.2-E6.2


E2.2-E4.2-E6.2




1




2




3




4




5




6




7




8




9




10



11




12



PRIMA DI OPERARE
BEVOR MAN ANFÄNGT
AVANT D'INTERVENIR
ANTES DE OPERAR

- 1** VERIFICARE POSIZIONE CHIAVE - CHECK KEY POSITION - SCHLÜSSELPOSITION PRÜFEN
VÉRIFIER POSITION CLÉ - VERIFICAR POSICIÓN DE LA LLAVE
- 2** VERIFICARE POSIZIONE SEGNALETORE - CHECK INDICATOR POSITION
ANZEIGE POSITION PRÜFEN - VÉRIFIER POSITION INDICATEUR
VERIFICAR POSICIÓN INDICADOR
- 3** VERIFICARE POSIZIONE PULSANTE - CHECK BUTTON POSITION
TASTE POSITION PRÜFEN - VÉRIFIER POSITION BOUTON
VERIFICAR POSICIÓN PULSADOR



For more information please contact:

ABB S.p.A.
Via Pescaria, 5
24123 Bergamo - Italy
Phone: +39 035 395 111