


NOTES:

1. Prior to any installation in a classified hazardous location, verify installation methods by the Control Drawing referenced on the product's name tag.
2. To access termination board, remove Power I/O Junction Box front cover.



RS-232 Communications Module
Totalflow P/N 2015192

Enclosure (6490/6890)

BTU XMTR Power I/O Junction Box

RS-232 Term Bd.
P/N 2015611

Sealed Conduit Fittings
Or
Approved Cable Fittings

Hazardous Area

Non-Hazardous Area

REF: 2012658-WI

| | | | | | | |
|-------------------------------------|--------|----------|---|---------|-----|--------|
| ABB TOTALFLOW Products | ACTION | DOC TYPE | TITLE | DWG NO. | REV | SHEET |
| | L17574 | UD | BTU 8000\8100 TO XRC (2100355 BD) 6490/6890 COMM1 (RS-232) | 2102270 | AA | 1 OF 1 |