







—  
INSTALLATION INSTRUCTION

# Parallel connection kit OZXA38-39




# OZXA38



\* Stranded

# OZXA39





---

## Contact us

### **ABB Oy**

P.O. Box 622  
FI-65101 Vaasa  
Finland

[abb.com/lowvoltage](http://abb.com/lowvoltage)