

INSTALLATION INSTRUCTIONS

ReliaMod™ Modular Metering

RBUSGANG



**HAZARDOUS VOLTAGE.
WILL CAUSE SEVERE
INJURY OR DEATH.**


Turn OFF power supplying this equipment before working inside.

Please read these instructions completely before installing or removing device. Improper installation could be hazardous to personnel and/or equipment.

Kit Contains:

Shear Nut	4
-----------	---

- Turn “OFF” power supplying the meter module.
- Install a shear nut on each bus connection located on the left-hand side of the enclosure.
- Tighten until the shear nut breaks off, or to 840 in. lbf.



INSTRUCCIONES DE INSTALACIÓN

ReliaMod™ Modular Metering

RBUSGANG



**VOLTAJE PELIGROSO.
PODRA CAUSAR MUERTE
O LESIONES SERIAS.**

Desconecte la alimentación eléctrica de este equipo antes de realizar cualquier trabajo dentro o fuera de él.

Lea atentamente estas instrucciones antes de instalar o retirar el dispositivo. Una instalación incorrecta podría resultar peligrosa para el personal y/o el equipo.

El kit contiene:

Tuerca de esfuerzo constante

4

- Desconecta la alimentación del módulo de medidor.
- Instala una tuerca de esfuerzo constante en cada barra en el lado izquierdo del panel.
- Aprieta hasta que la tuerca de seguridad se rompa, o a 840 in-lbf.

