



MIDWEST ELECTRIC PRODUCTS INC.  
305 Gregson Drive Cary, NC 27511

<b>Instruction Bulletin (IBUL)</b>	<b>Drawing: MEPI61</b>
<b>Page 1 of 1</b>	<b>CN: C094002</b>
<b>Subject:</b>	<b>Revision: 03</b>
<b>Customer instruction for C-32-U angle caps</b>	<b>Created: 02/26/2002</b>

The following is the customer instruction for wiring the C-32-U angle cap.

**C-32-U**  
**ANGLE CAP**

**WIRING INSTRUCTION**

NOTICE: Connect only copper or copper clad wire to this device. Cord type: S, SJ, SJO, SO, ST, STO. Wire Size #8 through #10 AWG.

1. Strip outer insulation back 3 inches.
2. Cut white and black wire to 1-3/4 inches
3. Strip all wire ends 1 inch long.
4. Remove cap cover.
5. Screw wires to blades starting with green ground wire (make sure green wire is on top and the black and white wires are on the bottom). Tighten to a torque of 20-25 inch pounds.
6. Screw down cord clamp using (2) 7/8-#8 screws and fasten cover securely with (3) 1-1/4-inch-long #4 screws.

**MIDWEST ELECTRIC PRODUCTS, INC.**  
MEPI61 Cary, NC.