

For operating instructions see PSE manual 1SFC132057M0201 on www.abb.com/lowvoltage

Für mehr technische details siehe auch Bedienungsanleitung 1SFC132057M0201 oder unter www.abb.com/lowvoltage

Pour la mise en service, voir le manuel PSE sur www.abb.com/lowvoltage

För användarinstruktion se PSE manual 1SFC132057M0201 på www.abb.com/lowvoltage

有关外置键盘的使用说明请参阅PSE手册1SFC132057M0201, 网址: www.abb.com/lowvoltage

Para consultar las instrucciones de empleo, véase el manual 1SFC132057M0201 del arrancador suave PSE a través del enlace www.abb.com/lowvoltage

Per le istruzioni d'uso vedere il manuale del PSE 1SFC132057M0201 o il sito www.abb.com/lowvoltage

Para instruções de operação veja manual do PSE 1SFC132057M0201 em www.abb.com/lowvoltage

Рекомендации по эксплуатации смотрите в инструкции (1SFC132057M0201) для устройств плавного пуска серии PSE на www.abb.com/lowvoltage

Kullanım talimatları için www.abb.com/lowvoltage web sitesindeki PSE kullanım kılavuzuna bakınız 1SFC132057M0201

Voor bedienings instructies zie de PSE handleiding 1SFC132057M0201

Lisätietoja PSE käyttöohjeessa 1SFC132057M0201, ladattavissa www.abb.com/lowvoltage

Instrukcje obsługi softstartów PSE zawiera podrecznik 1SFC132057M0201. Jest dostępny w internecie pod adresem www.abb.com/lowvoltage

الإلكتروني الموقع على 1SFC132057M0201 رقم PSE بالخاص الفني الدليل راجع التشغيل تعليمات أجل من www.abb.com/lowvoltage

ABB

ABB AB
Cewe-Control

SE-721 61 Västerås Sweden
Tel: +46 21 32 07 00
Fax: +46 21 12 60 01


PSEEK

PSE External Keypad


External keypad
Externes Bedienfeld
Clavier externe
Extern keypad
外置键盘
Teclado externo
Tastiera esterna
IHM Externa
Выносная клавиатура
Harici tus takimi
Extern toetsenbord
Erillinen käyttöpaneeli
Zewnętrzny panel sterowniczy
خارجية مفاتيح لوحة

Installation instructions
Installations Anleitung
Instructions de montage
Installationsinstruktion
安装说明书
Instrucciones de instalación
Istruzioni di installazione
Instruções de instalação
Инструкция по монтажу
Kurulum talimatları
Installatie voorschrift
Asennusohje
Instrukcja montażu
التركيب تعليمات

1.




4 x 
(ST 4.2 x 13)




1SFC132061M0201

ABB


2.



4.



3.



5.

