





IMPORTANT
 In order for the Fieldbus to operate reliably, the CMN power connection (terminal 33) of the Communications Controller to which the UC32.16DI controller is connected must be earthed.

IMPORTANT
 Earth this controller by connecting the CMN wire (G₀), on the secondary side of the 24V AC transformer, to Earth at one point.