

INSTALLATION INSTRUCTIONS

ReliaMod™ Modular Metering

RMIC



**HAZARDOUS VOLTAGE.
WILL CAUSE SEVERE
INJURY OR DEATH.**

Turn OFF power supplying this equipment before working inside.

Please read these instructions completely before installing or removing device. Improper installation could be hazardous to personnel and/or equipment.

Kit Contains:

Anit-Inversion Clip	1
---------------------	---

- Turn “OFF” power supplying the meter module.
- Remove Meter from the meter socket.
- The anti-inversion clip is to be installed in the upper right-hand jaw of the meter socket only.
- Slide the long end of the anti-inversion clip into the lower portion of the meter jaw until the clip locks in place.

INSTRUCCIONES DE INSTALACIÓN

ReliaMod™ Modular Metering RMIC



**VOLTAJE PELIGROSO.
PODRA CAUSAR MUERTE
O LESIONES SERIAS.**

Desconecte la alimentación eléctrica de este equipo antes de realizar cualquier trabajo dentro o fuera de él.

Lea atentamente estas instrucciones antes de instalar o retirar el dispositivo. Una instalación incorrecta podría resultar peligrosa para el personal y/o el equipo.

El kit contiene:

Clip de inversión Anit

1

- Desconecte la alimentación del módulo de medición.
- Retire el medidor de la toma del medidor.
- El clip anti-inversión debe instalarse únicamente en la mordaza superior derecha de la toma del medidor.
- Deslice el extremo largo del clip anti-inversión en la parte inferior de la mordaza del medidor hasta que el clip encaje en su sitio.