Pos. Läge	H connects H förbinder
1	1 - 20
2	2 - 20
3	3 - 20
4	4 - 20
5	5 - 20
6	6 - 20
7	7 - 20
8	8 - 20
9	9 - 20
10	10 - 20
11	11 - 20
12	12 - 20
13	13 - 20

On-load tap-changer type UZEL., UZFL., 13 tap positions, linear switching.
Min. effective No. of turns in pos. 1.
The tap-changer is delivered set in pos. 7.

Lindningskopplare typ UZEL., UZFL., 13 lägen, linjär koppling.
Min. antal effektiva varv i läge 1.
Lindningskopplaren levereras inställd i läge 7.



The tap-changer is shown in pos. 7
Lindningskopplaren visad i läge 7

H Main contact / Huvudkontakt
M1, M2 Transition contacts / Motståndskontakter

1) Connections between the terminals 20 of the three phases are included in the star-point type.

Förbindningar mellan uttag 20 i de tre faserna ingår i nollpunktsutförandet.



We reserve all rights in this document and in the information contained therein. Reproduction, use or disclosure to third parties whithout express authority is strictly forbidden. © ABB 19

Drawn by	Form No.	Sheet
Design checked by	RevInd Dept Year Week	Cont

Rev Ind	Revision	Appd	Year Week
-	-	-	- -

Accepted by qual control: R.Yngvesson	Accepted for prod by:	Description (English): CONNECTION DIAGRAM	DATAORIGINAL
Design checked by: B-O.Stenestam	Drawn by: L.Bergman	Description (own language): KOPPLINGSSCHEMA	File name: 0396-9
Drawing checked by: M.Hedlund	Issued by Dept Year Week: COM/TKO 97 33	5492 0396-9	Lang: - Sheet: 1
ABB Asea Brown Boveri			RevInd: - Cont: -