| Pos.<br>Läge | H connects<br>H förbinder |
|---|---|
| 1 | 1 - 20 |
| 2 | 2 - 20 |
| 3 | 3 - 20 |
| 4 | 4 - 20 |
| 5 | 5 - 20 |
| 6 | 6 - 20 |
| 7 | 7 - 20 |
| 8 | 8 - 20 |
| 9 | 9 - 20 |
| 10 | 10 - 20 |
| 11 | 11 - 20 |
| 12 | 12 - 20 |
| 13 | 13 - 20 |
| 14 | 14 - 20 |

On-load tap-changer type UZEL., UZFL., 14 tap positions, linear switching.
Min. effective No. of turns in pos. 1.
The tap-changer is delivered set in pos. 7.

Lindningskopplare typ UZEL., UZFL., 14 lägen, linjär koppling.
Min. antal effektiva varv i läge 1.
Lindningskopplaren levereras inställd i läge 7.




The tap-changer is shown in pos. 7
Lindningskopplaren visad i läge 7

H Main contact / Huvudkontakt
M1, M2 Transition contacts / Motståndskontakter

1) Connections between the terminals 20 of the three phases are included in the star-point type.

Förbindningar mellan uttag 20 i de tre faserna ingår i nollpunktsutförandet.




We reserve all rights in this document and in the information contained therein. Reproduction, use or disclosure to third parties whithout express authority is strictly forbidden. © ABB 19

| Rev Ind | Revision | Appd | Year | Week |
|---|---|---|---|---|
| - | - | - | - | - |

| | | | |
|---|---|---|---|
| Accepted by qual control: R.Yngvesson | Accepted for prod by: | Description (English): CONNECTION DIAGRAM | DATAORIGINAL |
| Design checked by: B-O.Stenestam | Drawn by: L.Bergman | Description (own language): KOPPLINGSSCHEMA | File name: 0396-10 |
| Drawing checked by: M.Hedlund | Issued by Dept Year Week: COM/TKO 97 33 | 5492 0396-10 | Lang: - / Sheet: 1 |
| ABB Asea Brown Boveri | | | RevInd: - / Cont: - |

Drawn by | Design checked by | Form No. | RevInd | Dept | Year Week | Sheet | Cont