ABB Network Partner AB

User's Guide

REB 551

Breaker protection terminal

1MRK 505 001-UEN

Version 1.2-01
September 1997

1 User's Guide contents

2 Revisions

3 Introduction

4 Requirements and basic technical data

5 Construction and hardware characteristics

6 Man machine interface

7 Protection and control functions

8 Monitoring functions

9 Installation and commissioning

10 Terminal diagrams and default configuration

ABB Network Partner AB
S-721 71
Västerås, Sweden
Phone +46 21 321300
Fax +46 21 146918